

SUBSTATION EQUIPMENT - FAULT CODE MANUAL (Rev 4)

This manual lists the fault codes shown on the Ring Main Unit (RMU) and the Circuit Breaker (CB) control panel. Abbreviations: RMU (Ring Main Unit), CB (Circuit Breaker), MCB (Miniature Circuit Breaker), HV (High Voltage), LV (Low Voltage), SF6 gas insulated switchgear.

Always follow the site Standard Operating Procedure (SOP) before any intervention.

FAULT E-47

Code: E-47

Meaning: Low oil pressure in the tap changer

Recommended action:

Stop the transformer. Check oil level and top up with IEC 60296 oil.

WARNING: Do not reset E-47 more than twice without an inspection by a qualified engineer.

FAULT E-52

Code: E-52

Meaning: Over-temperature trip on the main breaker

Recommended action:

Wait for cool down below 60 °C, then reset the thermal relay.

WARNING: Do not reset E-52 more than twice without an inspection by a qualified engineer.

FAULT E-63

Code: E-63

Meaning: SF6 gas pressure low

Recommended action:

Isolate the bay and call the gas handling team. Do not operate the breaker.

WARNING: Do not reset E-63 more than twice without an inspection by a qualified engineer.

FAULT F-12

Code: F-12

Meaning: Auxiliary supply failure

Recommended action:

Check the 230 V auxiliary MCB and the battery charger output (110 V DC).

WARNING: Do not reset F-12 more than twice without an inspection by a qualified engineer.

FAULT F-21

Code: F-21

Meaning: Motor drive timeout in the Ring Main Unit (RMU)

Recommended action:

Inspect the motor limit switch and the 40 Nm drive coupling.

WARNING: Do not reset F-21 more than twice without an inspection by a qualified engineer.