

TRANSOL

TRANSFORMER OIL

GUIDELINES FOR STORAGE AND HANDLING OF TRANSOL - TRANSFORMER OIL

CONTENT

1. Introduction	2
2. Supply	2
3. Storage	
3.1 For Oil in Drums	2
3.2 For Oil in Tanks	3
4. Handling	4

1. Introduction:

TRANSOL Transformer Oil is manufactured, stored and handled with utmost care to obtain best performance. Storage and handling of Transformer Oil is of great importance in order to avoid contamination by polar impurities, water ingress during storage etc. and to maintain the properties of oil for achieving optimum result.

Transformer Oil during storage should confirm to the procedures, which has been accepted as International Practices for storage of Transformer Oil and code practices for maintenance and supervision of insulating oil in service as per IS:1866/IEC:60422.

It is also essential to recognize that there is not a 'shelf-life' as such, as preservation of oil quality during storage is largely dependent on the duration as well as method of storage and handling being adopted at site. It is further suggested to always store the oil in ideal conditions and keep periods of storage as short as possible.

2. Supply:

TRANSOL Transformer Oil is being supplied either in drum or in bulk tanker. Transformer Oil is hygroscopic in nature and can absorb moisture from humid atmosphere. To prevent moisture from absorbing into the oil, it is filled almost to the top of the drum or tanker leaving very little empty space above the oil. The empty space is further filled with dry nitrogen to avoid any possibility of moisture pick up.

3. Storage:

3.1 For oil in Drums:

- At the site, the drums should be stored under a roof on a flat, clean ground, protected from dirt, rain, snow and direct sunlight.
- They should be placed on stringers or pallets so as to be several inches above the ground to avoid standing in water.

- They should be stored on side with the bungs horizontal so that the bungs will always have the weight of the oil against them. This will prevent the breathing of the drums during extreme changes of whether.



- Drums stored in above manner should be covered with a tarpaulin. This preserves the product name and other markings on the drums from fading or being covered up by dirt.
- The drums should never be stored outside in open area. If drums were stored out of doors with the bungs end up, rain water would collect on the head. With expansion and contraction of the air and oil within the drums due to temperature changes, this water would be drawn into the drums and contaminate the Oil.
- If there is some oil remaining in a partly used drum, it should be stored on its side, protected as above, with the oil level above the bung however, it is recommended not to store half-emptied drums for long periods as there is a risk of contamination.
- Special attention should be given for tightness of bungs to avoid leakage during storage.

3.1 For oil in Tanks:

- The storage tank should be under roof, on several inches above the ground level to protect from rain, snow and direct sunlight.

- Transformer oil received at site in tanker must be unloaded to another tank through filter machine.
- Use dedicated storage tank for storing Transformer Oil. The storage tank should be nitrogen blanketed.
- It is preferable not to have free breathing tank. A suitable modification like installation of breathers are recommended to prevent air ingress inside the storage tank.
- The tank should be cleaned thoroughly and checked for rusting conditions or leakage.

4. Handling:

- All oil handling equipment's such as hoses, pipes, pumps, tanks etc. must be kept clean & dry and should be dedicated to Transformer Oil.
- The filter equipment should be thoroughly cleaned and checked for periodical replacement of filter.
- It is important that no air or moisture should come in contact with Transformer Oil at the time of filling the oil in transformer.
- The residual oil in the handling equipment should be sealed to prevent continuous exchange with atmospheric air, moisture or other contaminants.
- The oil may be tested prior to unloading and checked against agreed specifications.
- Don't mix any incompatible oil with TRANSOL. Please consult oil supplier to confirm suitability in all respects.

SAVITA OIL TECHNOLOGIES LIMITED

66/67, Nariman Bhavan,
Nariman Point, Mumbai - 400 021. India.

T +91-22-2288 3061, 6624 6200

tomktg@savita.com

| www.savita.com

Disclaimer – Details are subject to change as part of continuous improvement.