

Transmitter

Channel

Receiver

TV Remote Control

- **Function:** Emits Infrared (IR) light signals to change the channel.

Air (Open space in the room)

- **Noise / Interference:** Bright sunlight glare or signals from another remote or someone or something between the remote and the TV blocking or distorting the IR beam.

Television (IR Sensor)

- **Function:** Receives and decodes the IR signal to execute the command (e.g., change the TV channel)