## ECHONET Lite EPC Query Report

EPC	Description	Query	Response
0x80	Operation status	Get (0x62) for EPC 0x80	OFF (0x31)
0x82	Standard version information	Get (0x62) for EPC 0x82	00005202
0x83	Identification number	Get (0x62) for EPC 0x83	fe00000800000000000000000030303
0x84	Unknown/Reserved	Get (0x62) for EPC 0x84	ESV error code: 0x52
0x85	Unknown/Reserved	Get (0x62) for EPC 0x85	ESV error code: 0x52
0x86	Unknown/Reserved	Get (0x62) for EPC 0x86	ESV error code: 0x52
0x88	Fault status	Get (0x62) for EPC 0x88	41
0x8A	Manufacturer code	Get (0x62) for EPC 0x8A	000008
0x8B	Product code	Get (0x62) for EPC 0x8B	ESV error code: 0x52
0x8C	Production number	Get (0x62) for EPC 0x8C	000000000000000000000000000000000000000
0x8D	Production date	Get (0x62) for EPC 0x8D	ESV error code: 0x52
0x8E	Unknown/Reserved	Get (0x62) for EPC 0x8E	ESV error code: 0x52
0x90	ON timer reservation setting	Get (0x62) for EPC 0x90	ESV error code: 0x52
0x92	ON timer relative time setting	Get (0x62) for EPC 0x92	ESV error code: 0x52
0x93	Remote control setting	Get (0x62) for EPC 0x93	ESV error code: 0x52
0x94	OFF timer reservation setting	Get (0x62) for EPC 0x94	ESV error code: 0x52
0x98	Current date setting	Get (0x62) for EPC 0x98	07e90514
0x9B	SetM property map	Get (0x62) for EPC 0x9B	ESV error code: 0x52
0x9C	GetM property map	Get (0x62) for EPC 0x9C	ESV error code: 0x52
0x9E	Set property map	Get (0x62) for EPC 0x9E	0e819798a0a1a2c1e2e4e5e6e7e8e9
0xA3	Unknown/Reserved	Get (0x62) for EPC 0xA3	ESV error code: 0x52
0xA4	Unknown/Reserved	Get (0x62) for EPC 0xA4	ESV error code: 0x52
0xAE	Unknown/Reserved	Get (0x62) for EPC 0xAE	ESV error code: 0x52
0xB6	Unknown/Reserved	Get (0x62) for EPC 0xB6	ESV error code: 0x52
0xB9	Unknown/Reserved	Get (0x62) for EPC 0xB9	ESV error code: 0x52
0xBE	Unknown/Reserved	Get (0x62) for EPC 0xBE	ESV error code: 0x52
0xC0	Operation power factor setting value	Get (0x62) for EPC 0xC0	00
0xC1	FIT contract type	Get (0x62) for EPC 0xC1	43
0xC6	Unknown/Reserved	Get (0x62) for EPC 0xC6	ESV error code: 0x52
0xC8	Unknown/Reserved	Get (0x62) for EPC 0xC8	ESV error code: 0x52

0xCE	Unknown/Reserved	Get (0x62) for EPC 0xCE	ESV error code: 0x52
0xD0	System interconnection status	Get (0x62) for EPC 0xD0	02
0xE0	System interconnection status	Get (0x62) for EPC 0xE0	0000
0xE9	Power generation operation setting	Get (0x62) for EPC 0xE9	157c
0xF1	Unknown/Reserved	Get (0x62) for EPC 0xF1	ESV error code: 0x52
0xF9	Unknown/Reserved	Get (0x62) for EPC 0xF9	ESV error code: 0x52