

The Condition Field





0001 = NE - Z clear (not equal)

0010 = HS / CS - C set (unsigned higher or same)

0011 = LO / CC - C clear (unsigned lower)

0100 = MI - N set (negative)

0101 = PL - N clear (positive or zero)

0110 = VS - V set (overflow)

0111 = VC - V clear (no overflow)

1000 = HI - C set and Z clear (unsigned higher)

1001 = LS - C clear or Z (set unsigned lower or same)

1010 = GE - N set and V set, or N clear and V clear (>or =)

1011 = LT - N set and V clear, or N clear and V set (>)

1100 = GT - Z clear, and either N set and V set, or N clear and V set (>)

1101 = LE - Z set, or N set and V clear, or N clear and V set (<, or =)

1110 = AL - always

1111 = NV - reserved.

