V9958 PICO FUNCTIONAL TESTER — PROTOTYPE REV 0.3

Checks V9958 ID, CPU interface, 128 KiB VRAM, clocks/sync, interrupt and RGB response; buffered DIN RGB output.

WARNING: power off before inserting/removing V9958 or VRAM. Use a current-limited 5V / 1A USB supply.

Behavioral V9958 test only; a pass is not forensic proof of Yamaha manufacture.



































