HPE OneView
API Reference
Security Model
Response Codes
Association Names
Common Parameters
Common Attributes
Messaging
What's New?
SERVERS
Rack Managers
Server Hardware
Server Hardware Migration
Server Hardware Types
Server Profile Templates
Server Profiles
NETWORKING
STORAGE
FC-SANS
FACILITIES
EXTERNAL MANAGERS
HYPERVISORS
DATA SERVICES
FIRMWARE
ACTIVITY
SETTINGS
SECURITY
SEARCH
REMOTE SUPPORT

entation of a physical server. The server hardware resource provides APIs for server management tasks such as applying a profile,

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets a list of server hardware resources. Returns a list of resources based on optional sorting and filtering, and constrained by start and count parameters.

Get all server hardware resources:

Request

```
GET  https://{appl}/rest/server-hardware?start=0&count=-1

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Get maximum of 5 server hardware resources that do not have a profile assigned, sorted by enclosure bay number in descending order:

Request

```
GET  https://{appl}/rest/server-hardware?start=0&count=5&sort=position:desc&filter="serverProfileUri=null"

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Retrieve Server Hardware by Scope:

Request

```
GET  https://{appl}/rest/server-hardware?scopeUris="/rest/scopes/96b6131a-b458-47ab-bdaf-220bcdb0002a OR /rest/scopes/58d8ced0-5728-4dfb-97fb-4f5b68

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Get server hardware resources with all attributes of sub resources data:

Request

```
GET https://{appl}/rest/server-hardware?expand=all

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Query Parameters

`count` The number of resources to return. A count of -1 requests all the items. The actual number of items in the response can differ from the requested count if the sum of start and count exceed the total number of items, or if returning the requested number of items would take too long. integer

See the Common Parameters page for more information on the usage of count.

Default -1

`expand`
The expand parameter can have the value "all" or "none". The value "all" allows for the full expansion of sub resources data. The default value of the expand parameter is "none".
unknown type

`filter` A general filter/query string to narrow the list of items returned. The default is no filter - all resources are returned. array of string

See the Common Parameters page for more information on the usage of filter.

`sort` The sort order of the returned data set. By default, the sort order is based on create time, with the oldest entry first. string

See the Common Parameters page for more information on the usage of sort.

`start` The first item to return, using 0-based indexing. If not specified, the default is 0 - start with the first available item. integer

See the Common Parameters page for more information on the usage of start.

Default 0

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Response Body ServerHardwareListV12

category Identifies the resource type string
read only

count The actual number of resources returned in the specified page integer

created Date and time when the resource was created timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

eTag Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource string
read only

members The server hardware that comprises this list. array of ServerHardwareV12

assetTag The current value of the asset tag for this server hardware. This value can be set in the server hardware's BIOS interface. string
read only

capabilities Server Hardware capabilities array of ServerHardwareCapability
read only

Values

`NoFirmwareUpdateCapability` Denotes if firmware update is supported from OneView. `RackEdgeConnections`

Allows network connections for ProLiant DL servers.

category Identifies the resource type string
read only

created Date and time when the resource was created timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

description Brief description of the resource string

eTag Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource string
read only

formFactor
The physical dimensions of this server. For a blade server this is either HalfHeight or FullHeight. For a rack server this is expressed in U height, e.g. 4U. string
read only

generation Generation of server. string
read only

hostOsType
The type of Operating System installed on the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.
For HPE Superdome Flex and Superdome Flex 280 servers, this is reported by the Rack Management Controller(RMC). The RMC gets this information from a running operating system that has HPE Data Collection Daemon(DCD) installed.

integer

imlMode
The IML (Integrated Management Log) mode configured on iLO. When IML mode is "Enabled", iLO will generate service events for critical IML event entries which can result on remote support cases if remote support is enabled. Possible values: Enabled, Disabled, NotConfigured. The value will be empty if it is not supported by iLO.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

imlMode

Values `Disabled` IML Mode is disabled on iLO. `Enabled` IML Mode is enabled on iLO. `NotConfigured` IML Mode is not configured on iLO.

`intelligentProvisioningVersion` The installed version of the HPE Intelligent Provisioning embedded server provisioning tool. string

`licensingIntent` Product license assigned to the server hardware. LicensingIntent
read only

Values

`None` A license is not required for the current state `OneView` HPE OneView licenses `OneViewNoiLO` HPE OneView w/o iLO licenses `OneViewStandard`

HPE OneView Standard license

`locationUri`
For blade servers, the enclosure in which this blade server resides. This URI can be used to retrieve information about the enclosure. This value is not set for rack mount servers.
string
read only

`maintenanceMode`
True if the server is in maintenance mode, false otherwise. When in maintenance mode, the appliance will not send any email notifications or forward SNMP traps related to the server hardware and its associated profile. Apart from blocking these notifications, maintenance mode does not affect server or profile operations.
Boolean
searchable
read only

`memoryMb` Amount of memory installed on this server hardware in MiB (1 MiB = 1,048,576 bytes). integer
read only

`migrationState` The current migration state of the Server. MigrationState
read only

Values

`MigrateProfilePending` Indicates that the server profile migration for the migrated server has been queued up. `Migrated`

Indicates that the Server has been migrated successfully. `Migrating` Indicates that the Server migration is in-progress. `MigratingProfile`

Indicates that the server profile migration has started. `MigrationError` Indicates Server migration failed. `NotMigrated`

Indicates that the Server is not migrated, this is the default value. `ProfileMigrated` Indicates that the server profile migration has completed. `Removed`

Indicates that the Server which was migrated has been removed. `RemovingProfile`

Indicates that the server profile that is associated with the server being migrated is getting removed. `ServerAdded`

Indicates that the server has been added successfully.

`model` The full server hardware model string. string
searchable
read only

`modified` Date and time when the resource was last modified timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

`mpFirmwareVersion` The version of the firmware installed on the iLO. string
read only

`mpHostInfo` The host name and IP address information for the Management Processor that resides on this server. MpHostInfo

`mpHostName` The host name of the Management Processor. string

`mpIpAddresses` The list of IP addresses and corresponding subnet masks.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

mpIpAddresses The list of IP addresses and corresponding type information for the Management Processor. array of MpIpAddress

`mpIpAddresses[].address`
An IP address for the Management Processor. string

`mpIpAddresses[].type`
The type of IP address. InetAddressType

Values

`DHCP` Dynamic host configuration protocol. `LinkLocal` Link-local address (IPv6). `LinkLocal_Required`

Required Link-local Address (IPv6). This address type is used internally to identify servers that require an IPv6 link-local address be used to contact them. `Lookup`

Address was obtained internally via host lookup (DNS, host table). `SLAAC` Stateless address autoconfiguration (IPv6). `Static` Static IP address configuration.

`Undefined` There is no address type defined.

mpLicenseType
The license type installed on the management processor. "iLO Advanced" and "iLO Advanced Premium High Security" are examples of commonly installed license types.
"" - Indicates the management processor is not licensed.

"Unknown" - Indicates OneView hasn't established communication with the management processor and can't read the license type.

null - Indicates OneView encountered a problem while fetching the license type.

string
searchable
read only

mpModel The model type of the iLO, such as iLO4. string
read only

mpState Indicates the current state of the management processor. PhysicalServerMPState

Values

`OK` OneView is not currently causing the server iLO to reset. `Reset` Deprecated: Do not use. `Resetting`

OneView is currently managing the reset of the server's iLO. Note: While this is set, it will not allow other operations such as profile apply and refresh.

name
For blade servers, it is the location based name of the server, which is formed by concatenating the enclosure name and the bay number. For rack servers, it is the serial number prefixed by word "ILO" (e.g. ILOUSE31835LS).
string
searchable
read only

oneTimeBoot The server one-time boot device value. string
read only

operatingSystem
The name of the Operating System installed on the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.
For HPE Superdome Flex and Superdome Flex 280 servers, this is reported by the Rack Management Controller(RMC). The RMC gets this information from a running operating system that has HPE Data Collection Daemon(DCD) installed.

"" - Indicates the server does not have an operating system.

"Unknown" - Indicates OneView was not able to determine the operating system information on the server.

null - Indicates OneView encountered a

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

fail - indicates OneView encountered a problem while fetching the operating system.

string
searchable
read only

partNumber The part number for this server hardware. string
read only

physicalServerHardwareUri
The URI of the collection of physical blades for Superdome X or physical chassis for Superdome Flex that make up the hard partition this server hardware represents. Applicable only for 'Superdome X' and 'Superdome Flex'.
string
read only

platform Type of server (ex. BladeServer). string
read only

portMap A list of adapters/slots, their ports and attributes. ServerFabricMapV7
read only

deviceSlots List of each slot found on the server hardware. array of ServerFabricDeviceV7
read only

`deviceSlots[].`**deviceName**
The name or model of the adapter. string
read only

`deviceSlots[].`**deviceNumber**
The device number of a server. integer
read only

`deviceSlots[].`**location**
The location of the adapter in the server. Lom indicates LAN on motherboard, Flb is for FlexibleLOM for blades and Mezz is for Mezzanine adapters.
ServerFabricDeviceLocationEnum
read only

Values

`Flb` Flexible LOM for Blades - pluggable versions of LOMs for ProLiant blade servers. `Flr`

Flexible LOM for Racks - pluggable versions of LOMs for ProLiant rack servers. `Lom` LAN on motherboard - fixed devices on ProLiant G7 series and later servers.

`Mezz` Mezzanine cards - pluggable devices that provide additional network connectivity. `Ocp` Open Compute Project - open firmware OCP adapters. `Pci`

PCIe cards - standup cards that provide additional connectivity for ProLiant rack servers. `Unknown` The device location could not be determined.

`deviceSlots[].`**physicalPorts**
List of physical ports on the device. array of ServerFabricPhysicalPortV4
read only

`deviceSlots[].physicalPorts[].`**interconnectPort**
The downlink port number on the interconnect that hosts network connections for this adapter port. If the adapter port is not connected to an interconnect downlink port, the value will be 0.
integer
read only

`deviceSlots[].physicalPorts[].`**interconnectUri**
The URI of the interconnect that hosts network connections for this adapter port. string
read only

`deviceSlots[].physicalPorts[].`**mac**
Physical mac address of this physical port. string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

read only

`deviceSlots[].physicalPorts[].`**`nodeGuid`**
The effective current node GUID of virtual port of Infiniband Network Adapter. If an assignable node GUID is not supported, this value will be same as permanentNodeGUID
string
read only

`deviceSlots[].physicalPorts[].`**`permanentNodeGuid`**
The permanent node GUID assigned to the Infiniband Network Adapter. Typically, this value is programmed during manufacturing. This address is not assignable.
string
read only

`deviceSlots[].physicalPorts[].`**`physicalInterconnectPort`**
The downlink port number on the interconnect to which the adapter port is physically connected. If the adapter port is not connected to an interconnect downlink port, the value will be 0.
integer
read only

`deviceSlots[].physicalPorts[].`**`physicalInterconnectUri`**
The URI of the interconnect to which the adapter port is physically connected. string
read only

`deviceSlots[].physicalPorts[].`**`portNumber`**
Physical port number of the adapter. integer
read only

`deviceSlots[].physicalPorts[].`**`type`**
Physical port type. Values include Ethernet and FibreChannel. PhysicalServerPortType
read only

Values `Ethernet` Ethernet network `FibreChannel` Fibre Channel network `InfiniBand` InfiniBand network `SAS` Serial Attached SCSI

`deviceSlots[].physicalPorts[].`**`virtualPorts`**
For Flex-capable devices, a list of FlexNICs defined on the server. array of ServerFabricVirtualPortV4
read only

`deviceSlots[].physicalPorts[].virtualPorts[].`**`currentAllocatedVirtualFunctionCount`**
The number of virtual functions presently allocated to this virtual port. integer
read only

`deviceSlots[].physicalPorts[].virtualPorts[].`**`mac`**
The mac address assigned to this virtual port. string
read only

`deviceSlots[].physicalPorts[].virtualPorts[].`**`portFunction`**
The function identifier for this FlexNIC, such as a, b, c or d. string
read only

Default false

`deviceSlots[].physicalPorts[].virtualPorts[].`**`portNumber`**
The port number assigned to this virtual port. integer
read only

`deviceSlots[].physicalPorts[].virtualPorts[].`**`wwnn`**
The world wide node name assigned to this virtual port. string
read only

`deviceSlots[].physicalPorts[].virtualPorts[].`**`wwpn`**
The world wide port name assigned to th

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

read only

`deviceSlots[].physicalPorts[].wwn`
The world wide name of this physical port. string
read only

`deviceSlots[].slotNumber`
The slot number of the adapter on the server hardware within its specified location. integer
read only

position For blade servers, the number of the physical enclosure bay in which the server hardware resides. For rack mount servers, this value is null. integer
searchable
read only

powerLock
Indicates if an operation is being performed on this server hardware (such as a profile assignment) that prevents its power state from being manipulated via the server hardware API.
Boolean

Default false

powerState Current power state of the server hardware. Values are Unknown, On, Off, PoweringOn, PoweringOff or Resetting. PhysicalServerPowerState
required
searchable

Values

`Off` Power off `On` Power on `PoweringOff` Powering off `PoweringOn` Powering on `Resetting` Resetting `Unknown`

Unable to determine server power state.

processorCoreCount Number of cores available per processor. integer
read only

processorCount Number of processors installed on this server hardware. integer
read only

processorSpeedMhz Speed of the CPUs in megahertz. integer
read only

processorType Type of CPU installed on this server hardware. string
read only

refreshState Indicates if the resource is currently refreshing. Possible values are NotRefreshing, RefreshPending, Refreshing, and RefreshFailed. RefreshState

Values

`NotRefreshing` The resource is not currently refreshing `RefreshFailed` The refresh of this resource failed `RefreshPending`

The resource is waiting to be refreshed `Refreshing` The resource is currently being refreshed

remoteSupportSettings Settings to describe the state of Remote Support registration for the server. RemoteSupportSettings
read only

destination The appliance that the server is currently registered to. string
read only

Maximum Length 255 Minimum Length 0

remoteSupportCurrentState The current state of Remote Support registration for the server. string
read only

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

remoteSupportUri

The URI of the Remote Support settings object for the server, which contains information such as contact and channel partner assignments. string
read only

romVersion

The version of the server hardware firmware (ROM). After updating the ROM (BIOS) firmware for a server, the server hardware page and the REST API may report an inaccurate ROM version until the server is next powered on and allowed to complete the power-on self-test (POST).
string
read only

scopesUri The URI for the resource scope assignments. Refer to the GET /rest/scopes/resources/** API. string
read only

serialNumber Serial number of the server hardware. string
searchable
read only

serverFirmwareInventoryUri URI of the Firmware Inventory of this server string
read only

serverGroupUri

For blade servers, this is the URI of the containing enclosure's enclosure group. This URI can be used to retrieve information about the enclosure group or to identify all the servers in the same group. This value is not set for rack mount servers.
string
read only

serverHardwareTypeUri

URI of the server hardware type associated with the server hardware. This URI can be used to retrieve information about the server hardware type. string
read only

serverName

The name of the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.
string
read only

serverProfileUri URI of a server profile assigned to this server hardware, if one is assigned. If not assigned this value is null. string
searchable
read only

serverSettings Indicates the current settings on the server and state of these settings. ServerSettings
read only

firmwareAndDriversInstallState The current installation status details of the firmware and/or OS drivers on the server.
FirmwareAndDriversInstallState
read only

`firmwareAndDriversInstallState.`**installState**

The installation state information of the firmware and/or OS drivers on the server. InstallState
read only

Values

`ActivateFailed` Indicates activation of one or more smart components failed on the server. `Activated`

Indicates all the smart components from the Service Pack specified in the firmware and driver baseline settings are installed and activated on the server.

`Activating` Indicates Smart Update Tool is activating the installed smart components. `InstallFailed`

Indicates Smart Update Tool has failed installing one or more smart components. `InstalledPendingReboot`

Indicates Smart Update Tool has completed installing the smart components, however the server needs to be rebooted for the updates to take effect.

`Installing` Indicates Smart Update Tool is installing the smart components from the staged location. `Pending`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Indicates the firmware and/or OS driver baseline settings have been applied to the server hardware and will take effect when Smart Update Tool updates firmware and/or OS driver components based on these settings.

`PendingExternalAction`

Indicates another utility (E.g. OneView plug-in) is orchestrating the update and action external to OneView is needed to complete the update. Refer to the external utility for details to complete the update.

`SPPBootFailed` Indicates that the server did not boot into the Service Pack ISO image. The user needs to follow the resolution mentioned in the failed task.

`ScheduleDelayed`

Indicates that Smart Update Tools was not able to schedule it to the specified schedule date and time and has proposed a new schedule. User should review the new schedule in the profile and can choose to continue with the new schedule or can reschedule it to a new date and time.

`ScheduleFailed` The schedule operation has failed. The user needs to follow the resolution mentioned in the failed task. `Scheduled`

A firmware update has been scheduled successfully. `StageFailed`

Indicates Smart Update Tool has failed to stage the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings. `Staged`

Indicates Smart Update Tool has completed staging the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Staging`

Indicates Smart Update Tool is staging the firmware and/or OS driver smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Uninitialized` Indicates the current firmware and/or OS driver settings have been cleared. No components will be updated on the server. `Unknown`

Indicates the server failed to return the current settings, therefore, the actual values might not be current.

`firmwareAndDriversInstallState`**.installedStateTimestamp**
The timestamp information indicating the time when the install state value got updated. string
read only

firmwareInstallSchedule The installation schedule details of the firmware and/or OS drivers on the server. Firmware Install Schedule
read only

`firmwareInstallSchedule`**.dateTime**
Specifies the date and time at which the firmware baseline will get installed and activated. string

`firmwareInstallSchedule`**.scheduleOptions**
The firmware schedule options of the firmware and/or OS drivers on the server. Firmware Schedule Options

Values

`StageAlongWithDeploy` Indicates that the baseline specified in the firmware settings will be staged and installed at the scheduled time.

`StageImmediately` Indicates that the baseline specified in the firmware settings will be staged immediately and installed at the scheduled time.

`StageImmediatelyAndRetryAtDeployTime`

Indicates that the firmware baseline specified will be staged immediately and will be installed at the scheduled date and time. In case there is a failure during staging, a retry will be done prior to installation at the scheduled date and time.

hpSmartUpdateToolStatus The status of Smart Update Tools installed on the server. HpSmartUpdateToolStatus
read only

`hpSmartUpdateToolStatus`**.installState**
Smart Update Tool's installed state on the server indicating whether it is installed, not installed or unknown. HpSUTInstallState
read only

Values

`Installed` The tool is installed on the server. `NotInstalled` The tool is not installed on the server. `Unknown` The tool installation status is not known.

`hpSmartUpdateToolStatus`**.lastOperationTime**
The timestamp indicating when Smart Update Tool was active or running a firmware update operation. string
read only

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`hpSmartUpdateToolStatus.`**`mode`**
The current run mode configured for Smart Update Tool installed on the server. string
read only

`hpSmartUpdateToolStatus.`**`serviceState`**
The state of the Smart Update Tool Service running on the server operating system. string
read only

`hpSmartUpdateToolStatus.`**`version`**
The current version of the Smart Update Tool installed on the server. string
read only

`stagedInstallSetId` The stagedInstallSetId associated with the server. string
read only

`shortModel` Short version of the server hardware model string, typically something like BL460 Gen8. string
searchable
read only

`signature` Data representing the current configuration or 'signature' of the server. ServerSignature
read only

`personalityChecksum` A calculated checksum of the server 'personality,' based on the defined connections and server identifiers. integer
read only

`serverHwChecksum` A calculated checksum of the server hardware, based on the hardware components installed in the server. integer
read only

`updatedPersChecksum`
The personality checksum is a value calculated based on data retrieved from the network adapters within the particular server. This value is a secondary checksum calculated with an alternate algorithm intended to identify inconsistencies in the configuration of the server hardware and its associated profile. To avoid personality mismatch alerts, this value is used with the "personalityChecksum" value to update the profile data when appropriate.
integer
read only

`state`
The current resource state of the server hardware. Allowable values are: Unknown (not initialized), Adding (server being added), NoProfileApplied (server successfully added), Monitored (server being monitored), Unmanaged (discovered a supported server), Removing (server being removed), RemoveFailed (unsuccessful server removal), Removed (server successfully removed), ApplyingProfile (profile being applied to server), ProfileApplied (profile successfully applied), RemovingProfile (profile being removed), ProfileError (unsuccessful profile apply or removal), Unsupported (server model or version not currently supported by the appliance), and UpdatingFirmware (server firmware update in progress).
string
searchable
read only

`stateReason`
The reason for the current resource state of the server hardware. This only applies if the state is 'Unmanaged', otherwise it is set to 'NotApplicable'. Allowable values are: Unsupported (server model or version not currently supported by the appliance), UpdatingFirmware (server firmware update in progress), NotApplicable (when PhysicalServerState is anything besides 'Unmanaged'), NotOwner (no claim on server), Inventory (server added by PDU or discovered by Composable Cloud), Unconfigured (discovery data incomplete or iLO configuration failure), UnsupportedFirmware (iLO firmware version below minimum support level), Interrupted (when PhysicalServerState is a result of an operation that was terminated before completing), and CommunicationError (appliance cannot communicate with iLO or OA).
string
read only

`status` Overall health status of the resource. The following are the valid values for the status of the resource: string
OK - indicates normal/informational behavior;

Disabled - indicates that a resource is not operational or that a server profile has not been assigned;

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

assigned;

Warning - needs attention soon;

Critical - needs attention soon;

Unknown - should be avoided, but there may be rare occasions where status is Unknown;

subResources SubResources of the server hardware. EnumMap<SubResourceName, SubResourceV10>

AdvancedMemoryProtection Inventory of Advanced Memory Protection resources for the server hardware. SubResourceV10

`AdvancedMemoryProtection.`**collectionState**
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`AdvancedMemoryProtection.`**count**
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`AdvancedMemoryProtection.`**data**
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`AdvancedMemoryProtection.`**etag**
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`AdvancedMemoryProtection.`**modified**
Date and time when the subresource was last modified. string

`AdvancedMemoryProtection.`**name**
The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` Th

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`AdvancedMemoryProtection.`**`uri`**
The URI associated with this subresource. string

`Devices` Inventory of Devices for the server hardware. SubResourceV10

`Devices.`**`collectionState`**
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`Devices.`**`count`**
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`Devices.`**`data`**
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`Devices.`**`etag`**
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`Devices.`**`modified`**
Date and time when the subresource was last modified. string

`Devices.`**`name`**
The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`Devices.`**`uri`**
The URI associated with this subresource. string

`LocalStorage` Inventory of Local Storage resources for the server hardware. SubResourceV10

`LocalStorage.`**`collectionState`**
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`LocalStorage.`**`count`**
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`LocalStorage.`**`data`**
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`LocalStorage.`**`etag`**
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`LocalStorage.`**`modified`**
Date and time when the subresource was last modified. string

`LocalStorage.`**`name`**
The name of subresource data collected f

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`LocalStorage.`**`uri`**
The URI associated with this subresource. string

`LocalStorageV2`
Inventory of Local Storage v2 resources for the server hardware, containing information on RDE enabled storage controllers, drives, and volumes. SubResourceV10

`LocalStorageV2.`**`collectionState`**
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`LocalStorageV2.`**`count`**
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`LocalStorageV2.`**`data`**
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`LocalStorageV2.`**`etag`**
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`LocalStorageV2.`**`modified`**
Date and time when the subresource was

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`LocalStorageV2.name`
The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`LocalStorageV2.uri`
The URI associated with this subresource. string

`MPSettings` MPSettings defined on the server hardware. SubResourceV10

`MPSettings.collectionState`
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`MPSettings.count`
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`MPSettings.data`
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`MPSettings.etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`MPSettings.modified`

Date and time when the subresource was last modified. string

`MPSettings.name`

The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`MPSettings.uri`

The URI associated with this subresource. string

`Memory` Inventory of Memory resources for the server hardware. SubResourceV10

`Memory.collectionState`

String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`Memory.count`

The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`Memory.data`

The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`Memory.etag`

Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.

string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

string

`Memory.`**`modified`**

Date and time when the subresource was last modified. string

`Memory.`**`name`**

The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`Memory.`**`uri`**

The URI associated with this subresource. string

`MemoryList` Inventory of Memory List resources for the server hardware. SubResourceV10

`MemoryList.`**`collectionState`**

String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`MemoryList.`**`count`**

The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`MemoryList.`**`data`**

The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`MemoryList.`**`etag`**

Entity tag/version ID of the resource, the

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Entity tag, version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`MemoryList.modified`
Date and time when the subresource was last modified. string

`MemoryList.name`
The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`MemoryList.uri`
The URI associated with this subresource. string

`Unknown` Unknown resource type requested for the server hardware. SubResourceV10

`Unknown.collectionState`
String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`Unknown.count`
The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`Unknown.data`
The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`Unknown.`**`etag`**
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`Unknown.`**`modified`**
Date and time when the subresource was last modified. string

`Unknown.`**`name`**
The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`Unknown.`**`uri`**
The URI associated with this subresource. string

`supportDataCollectionState` The state of the data collection for the server. Possible values: PendingCollection, Completed, Error, NotSupported.
string
read only

`supportDataCollectionType` The type of data collection for the server. Possible values: Basic, ActiveHealthSystem. string
read only

`supportDataCollectionsUri` The URI of the data collections object for the server. string
read only

`supportState`
The state of Remote Support for the server. Possible values: PendingEnable, EnableRequested, Enabled, PendingDisable, DisableRequested, Disabled, NotSupported.
string
read only

`supportTestEventState`
The state of the request being submitted to the iLO to trigger a test event to be returned asynchronously to Remote Support. Possible values: PendingTestEvent, Completed, Error, NotSupported.
string
searchable
read only

`type` Uniquely identifies the type of the JSON object string
read only

Default server-hardware-12

`uidState` PhysicalServerUidState. PhysicalServerUidState

Values `Blinking` The UID light is blinking. `Off` The UID light is off. `On` The UID light is on. `Unsupported` UID light is not supported by this system.

`uri` The canonical URI of the resource string

`uuid` Universally Unique ID (UUID) of th

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

virtualSerialNumber Virtual serial number associated with this server hardware (if specified in the profile assigned to this server). string
read only

virtualUuid Virtual UUID associated with this server hardware (if specified in the profile assigned to this server). string
read only

modified Date and time when the resource was last modified timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

nextPageUri URI pointing to the page of resources following the list of resources contained in the specified collection string

prevPageUri URI pointing to the page of resources preceding the list of resources contained in the specified collection string

start The row or record number of the first resource returned in the specified page integer

total The total number of resources that would be returned from the query (including any filters), without pagination or enforced resource limits integer

type Uniquely identifies the type of the JSON object string
read only

Default server-hardware-list-12

uri The canonical URI of the resource string
read only

POST /rest/server-hardware

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Adds a rack-mount server for management by the appliance. This API initiates the asynchronous addition of supported server models. Note: servers in an enclosure are added by adding the enclosure resource. This is only supported on appliances which support rack mounted servers.

Adds a rack-mount server for management by the OneView appliance:

Request

```
POST  https://{appl}/rest/server-hardware

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
{
     "hostname" : "enc-ilo.corp.com",
     "username" : "Administrator",
     "password" : "mypassword",
     "force" : false,
     "licensingIntent":"OneView",
     "configurationState":"Managed",
     "initialScopeUris": ["/rest/scopes/13c1606f-f1cb-473b-9c01-02e3a1a54589"]
}
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category.

Action `Create`

Category `server-hardware`

Scoped By `initialScopeUris`

The table below describes the rights required to assign a resource to the request resource. To be authorized, in additional to the above rights, a session permission role must grant (Action, Category) rights and the Scoped By value(s) must be in the permission scope.

Property	Action	Category	Scoped By	Comment (*)
`initialScopeUris`	`Create`	`server-hardware`		*

When creating a new resource, a user is allowed to specify a set of initial scopes, provided a role grants permission to the scopes category or to Create the resource's Category in each initial scope. After the resource is created, permission to the scopes category is required to modify the resource's scope assignments.

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`

The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsu

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

string
required

Required Value application/json

X-Api-Version
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

Location The URI of the newly-created resource or a task created to perform the requested action. string

Request Body AddServerV4

configurationState Specifies the desired server state. Valid options are: Managed, Monitored. ConfigurationState

Default Managed

Values

`ImportSHT` For internal utilities only. Not supported for customer use. `Managed` Add the hardware as a managed server `Monitored`

Add the hardware as a monitored server

force Specify 'true' to force the addition of the server and take ownership away from any other manager. Use this optional flag with caution. The default is 'false'. Boolean

hostname IP address or host name of a rack mount server's iLO management processor. string
required

initialScopeUris
A list of URIs of the scopes to which the resource shall be initially assigned. It is only meaningful at resource creation time and is not included on resource retrieval.
array of string

licensingIntent
The type of product license to assign to the server hardware. Valid options for a Managed server are: OneView or OneViewNoiLO. The valid option for a Monitored server is: OneViewStandard.
string
required

password The password for the specified username. string
required

restore Deprecated: Do not use. Boolean

scopeUris
A list of URIs of the scopes to which the resource is assigned. Specific authorization is required to change the contents of the list. *Note: This attribute is subject to incompatible changes in future release versions, including redefinition or removal.*
array of string

username iLO user account login name with Administer User Accounts privilege. string
required

GET /rest/server-hardware/*/firmware

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets a list of firmware inventory across all servers. In order to filter the returned data, specify a filter expression to select a particular server model, component name and/or component firmware

...

POST **/rest/server-hardware/discovery**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Adds multiple rack-mount servers for management by the appliance. This API initiates the asynchronous addition of supported server models. Note: servers in an enclosure are added by adding the enclosure resource. This is only supported on appliances which support rack mounted servers.

Adds multiple rack-mount servers for management by the OneView appliance:

Request

```
POST  https://{appl}/rest/server-hardware/discovery

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
Content-Type: application/json
Accept-Language: en_US
{
     "mpHostsAndRanges" : ["enc-ilo.corp.com", "172.1.1.1-172.1.1.10"],
     "username" : "Administrator",
     "password" : "mypassword",
     "licensingIntent":"OneView",
     "configurationState":"Managed",
     "initialScopeUris": ["/rest/scopes/13c1606f-f1cb-473b-9c01-02e3a1a54589"]
}
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category.

Action `'Create'`

Category `server-hardware`

Scoped By None

The table below describes the rights required to assign a resource to the request resource. To be authorized, in additional to the above rights, a session permission role must grant (Action, Category) rights and the Scoped By value(s) must be in the permission scope.

Property	Action	Category	Scoped By	Comment (*)
`initialScopeUris`	`Create`	`server-hardware`		*

When creating a new resource, a user is allowed to specify a set of initial scopes, provided a role grants permission to the scopes category or to Create the resource's Category in each initial scope. After the resource is created, permission to the scopes category is required to modify the resource's scope assignments.

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`

The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsu

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

string
required

Required Value application/json

X-Api-Version
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

Location The URI of the newly-created resource or a task created to perform the requested action. string

Request Body RackServerDiscoveryDto

configurationState Specifies the desired server state. Valid options are: Managed, Monitored. ConfigurationState

Values

`ImportSHT` For internal utilities only. Not supported for customer use. `Managed` Add the hardware as a managed server `Monitored`

Add the hardware as a monitored server

initialScopeUris
A list of URIs of the scopes to which the resource shall be initially assigned. It is only meaningful at resource creation time and is not included on resource retrieval.
array of string

licensingIntent
The type of product license to assign to the server hardware. Valid options for a Managed server are: OneView or OneViewNoiLO. The valid option for a Monitored server is: OneViewStandard.
string
required

mpHostsAndRanges
Set of IP addresses, host names, and/or IPv4 address ranges of rack mount servers' iLO management processors. The recognized range format is xxx.xxx.xxx.xxx-xxx.xxx.xxx.xxx
array of string
required

password The password for the specified username. string
required

username iLO user account login name with Administrator User Accounts privilege. string
required

POST /rest/server-hardware/firmware-compliance

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Checks the firmware compliance of a server with the selected firmware baseline. Returns the compliance status of each individual component as well as the overall firmware compliance status of the server.

Check if server hardware requires a firmware update with selected baseline:

Request

```
POST https://{appl}/rest/server-hardware/firmware-compliance

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

{
    "firmwareBaselineId":"SPP2017101_2017_1027_10",
    "serverUUID":"36343537-3338-4E43-3735-313730343038"
}
```

Response


```
{
    "componentMappingList": [{
            "componentKey": "a6b1a447-382a-5a4f-9005-028f103c0602",
            "componentLocation": "Embedded RAID",
            "componentName": "HPE Smart Array P408i-a SR Gen10",
            "componentType": "Firmware",
            "installedVersion": "1.59-218",
            "baselineVersion": "1.04",
            "componentFirmwareUpdateRequired": false,
            "hpsumManaged": true
        },
        {
            "componentKey": null,
            "componentLocation": "System Board",
            "componentName": "System Programmable Logic Device",
            "componentType": "Firmware",
            "installedVersion": "0x28",
            "baselineVersion": "unknown",
            "componentFirmwareUpdateRequired": false,
            "hpsumManaged": false
        },
        {
            "componentKey": "00000000-0000-0000-0000-000000000204",
            "componentLocation": "System Board",
            "componentName": "System ROM",
            "componentType": "Firmware",
            "installedVersion": "U32 v1.40 (03/09/2018)",
            "baselineVersion": "06/01/2017",
            "componentFirmwareUpdateRequired": false,
            "hpsumManaged": true
        },
        {
            "componentKey": null,
            "componentLocation": "System Board",
            "componentName": "Power Management Controller FW Bootloader",
            "componentType": "Firmware",
            "installedVersion":
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "baselineVersion": "unknown",
                "componentFirmwareUpdateRequired": false,
                "hpsumManaged": false
            },
            {
                "componentKey": null,
                "componentLocation": "System Board",
                "componentName": "Redundant System ROM",
                "componentType": "Firmware",
                "installedVersion": "U32 v1.40 (02/27/2018)",
                "baselineVersion": "unknown",
                "componentFirmwareUpdateRequired": false,
                "hpsumManaged": false
            },
            {
                "componentKey": null,
                "componentLocation": "Embedded controller Port 1I Box 1 Bay 1",
                "componentName": "Drive",
                "componentType": "Firmware",
                "installedVersion": "HPD5",
                "baselineVersion": "unknown",
                "componentFirmwareUpdateRequired": false,
                "hpsumManaged": false
            },
            {
                "componentKey": "4764a662-b342-4fc7-9ce9-258c5d99e815",
                "componentLocation": "System Board",
                "componentName": "iLO 5",
                "componentType": "Firmware",
                "installedVersion": "1.30 Mar 12 2018",
                "baselineVersion": "1.10",
                "componentFirmwareUpdateRequired": false,
                "hpsumManaged": true
            }
        ],
        "serverFirmwareUpdateRequired": false
    }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json

X-Api-Version
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Request Body FirmwareComplianceRequest

firmwareBaselineId The resource ID of the selected firmware baseline resource. string
required

installationPolicy The policy based on which compliance is generated. InstallationPolicy

Values

`LowerThanBaseline` Version matching and above the baseline are compliant. `NotEqualToBaseline`

Versions exactly matching the baseline are compliant.

patchLevel Identifies the firmware baseline patch to be applied to the server hardware. string

serverUUID The universally unique ID of the server hardware resource. string
required

Response Body ServerFirmwareComplianceData

componentMappingList
This is a one-to-one mapping of the installed firmware components on the server hardware against the components present on the selected firmware baseline.
array of ComponentMapper

baselineVersion The firmware version of the component present in the selected baseline. string

componentFirmwareUpdateRequired Specifies true if the firmware component requires an update with the selected baseline, false otherwise. Boolean

componentFirmwareUpdateRequiredWithForce
Specifies true if the firmware component requires an update with the selected baseline and force installation, false otherwise. Boolean

componentKey The ID for the firmware component. string

componentLocation The location of the component on the server hardware. Examples: "System Board", "Embedded LOM 1" string

componentName The name of the firmware component. string

componentType This specifies the type of firmware component. Examples: "System ROM" is of type "Firmware", "iLO 5" is of type "Firmware". string

hpsumManaged Specifies true if the firmware component is managed by SUM, false otherwise. Boolean

installedVersion The current firmware version of the component on the server hardware. string

serverFirmwareUpdateRequired Specifies true if the server firmware is not up-to-date with the selected baseline, false otherwise. Boolean

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

GET **/rest/server-hardware/schema**

Gets the JSON schema of the server hardware resource.

Get the JSON schema of the server hardware resource:

Request

```
GET https://{appl}/rest/server-hardware/schema

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

This API requires no authorization.

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body any type

GET **/rest/server-hardware/{id}**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the server hardware resource for the specified URI.

Gets the server hardware resource for the specified URI:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Gets the server hardware resource for the specified URI with all attributes of sub resources data:

Request

```
GET https://{appl}/rest/server-hardware/123-45-67-89-123?expand=all

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Query Parameters

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

expand
The expand parameter can have the value "all" or "none". The value "all" allows for the full expansion of sub resources data. The default value of the expand parameter is "none".
unknown type

Response Body ServerHardwareV12

assetTag The current value of the asset tag for this server hardware. This value can be set in the server hardware's BIOS interface. string
read only

capabilities Server Hardware capabilities array of ServerHardwareCapability
read only

Values

`NoFirmwareUpdateCapability` Denotes if firmware update is supported from OneView. `RackEdgeConnections`

Allows network connections for ProLiant DL servers.

category Identifies the resource type string
read only

created Date and time when the resource was created timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

description Brief description of the resource string

eTag Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource string
read only

formFactor
The physical dimensions of this server. For a blade server this is either HalfHeight or FullHeight. For a rack server this is expressed in U height, e.g. 4U. string
read only

generation Generation of server. string
read only

hostOsType
The type of Operating System installed on the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.
For HPE Superdome Flex and Superdome Flex 280 servers, this is reported by the Rack Management Controller(RMC). The RMC gets this information from a running operating system that has HPE Data Collection Daemon(DCD) installed.

integer

imlMode
The IML (Integrated Management Log) mode configured on iLO. When IML mode is "Enabled", iLO will generate service events for critical IML event entries which can result on remote support cases if remote support is enabled. Possible values: Enabled, Disabled, NotConfigured. The value will be empty if it is not supported by iLO.
ImlMode

Values `Disabled` IML Mode is disabled on iLO. `Enabled` IML Mode is enabled on iLO. `NotConfigured` IML Mode is not configured on iLO.

intelligentProvisioningVersion The installed version of the HPE Intelligent Provisioning embedded server provisioning tool. string

licensingIntent Product license assigned to the server hardware. LicensingIntent

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Values

`None` A license is not required for the current state `OneView` HPE OneView licenses `OneViewNoiLO` HPE OneView w/o iLO licenses `OneViewStandard`

HPE OneView Standard license

`locationUri`
For blade servers, the enclosure in which this blade server resides. This URI can be used to retrieve information about the enclosure. This value is not set for rack mount servers.
string
read only

`maintenanceMode`
True if the server is in maintenance mode, false otherwise. When in maintenance mode, the appliance will not send any email notifications or forward SNMP traps related to the server hardware and its associated profile. Apart from blocking these notifications, maintenance mode does not affect server or profile operations.
Boolean
searchable
read only

`memoryMb` Amount of memory installed on this server hardware in MiB (1 MiB = 1,048,576 bytes). integer
read only

`migrationState` The current migration state of the Server. MigrationState
read only

Values

`MigrateProfilePending` Indicates that the server profile migration for the migrated server has been queued up. `Migrated`

Indicates that the Server has been migrated successfully. `Migrating` Indicates that the Server migration is in-progress. `MigratingProfile`

Indicates that the server profile migration has started. `MigrationError` Indicates Server migration failed. `NotMigrated`

Indicates that the Server is not migrated, this is the default value. `ProfileMigrated` Indicates that the server profile migration has completed. `Removed`

Indicates that the Server which was migrated has been removed. `RemovingProfile`

Indicates that the server profile that is associated with the server being migrated is getting removed. `ServerAdded`

Indicates that the server has been added successfully.

`model` The full server hardware model string. string
searchable
read only

`modified` Date and time when the resource was last modified timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

`mpFirmwareVersion` The version of the firmware installed on the iLO. string
read only

`mpHostInfo` The host name and IP address information for the Management Processor that resides on this server. MpHostInfo

`mpHostName` The host name of the Management Processor. string

`mpIpAddresses` The list of IP addresses and corresponding type information for the Management Processor. array of MpIpAddress

`address` An IP address for the Management Processor. string

`type` The type of IP address. InetAddressType

Values

`DHCP` Dynamic host configuration protoc

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Required Link-local Address (IPv6). This address type is used internally to identify servers that require an IPv6 link-local address be used to contact them. `Lookup`

Address was obtained internally via host lookup (DNS, host table). `SLAAC` Stateless address autoconfiguration (IPv6). `Static` Static IP address configuration.

`Undefined` There is no address type defined.

mpLicenseType
The license type installed on the management processor. "iLO Advanced" and "iLO Advanced Premium High Security" are examples of commonly installed license types.
"" - Indicates the management processor is not licensed.

"Unknown" - Indicates OneView hasn't established communication with the management
processor and can't read the license type.

null - Indicates OneView encountered a problem while fetching the license type.

string
searchable
read only

mpModel The model type of the iLO, such as iLO4. string
read only

mpState Indicates the current state of the management processor. PhysicalServerMPState

Values

`OK` OneView is not currently causing the server iLO to reset. `Reset` Deprecated: Do not use. `Resetting`

OneView is currently managing the reset of the server's iLO. Note: While this is set, it will not allow other operations such as profile apply and refresh.

name
For blade servers, it is the location based name of the server, which is formed by concatenating the enclosure name and the bay number. For rack servers, it is the serial number prefixed by word "ILO" (e.g. ILOUSE31835LS).
string
searchable
read only

oneTimeBoot The server one-time boot device value. string
read only

operatingSystem
The name of the Operating System installed on the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.
For HPE Superdome Flex and Superdome Flex 280 servers, this is reported by the Rack
Management Controller(RMC). The RMC gets this information from a running operating system
that has HPE Data Collection Daemon(DCD) installed.

"" - Indicates the server does not have an operating system.

"Unknown" - Indicates OneView was not able to determine the operating system information on
the server.

null - Indicates OneView encountered a problem while fetching the operating system.

string
searchable
read only

partNumber The part number for this server hardware. string
read only

physicalServerHardwareUri
The URI of the collection of physical blade racks, unassigned racks, or racks in a rack group

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The URI of the collection of physical blades for Superdome X or physical chassis for Superdome Flex that make up the hard partition this server hardware represents. Applicable only for 'Superdome X' and 'Superdome Flex'.
string
read only

platform Type of server (ex. BladeServer). string
read only

portMap A list of adapters/slots, their ports and attributes. ServerFabricMapV7
read only

deviceSlots List of each slot found on the server hardware. array of ServerFabricDeviceV7
read only

deviceName The name or model of the adapter. string
read only

deviceNumber The device number of a server. integer
read only

location The location of the adapter in the server. Lom indicates LAN on motherboard, Flb is for FlexibleLOM for blades and Mezz is for Mezzanine adapters.
ServerFabricDeviceLocationEnum
read only

Values

`Flb` Flexible LOM for Blades - pluggable versions of LOMs for ProLiant blade servers. `Flr`

Flexible LOM for Racks - pluggable versions of LOMs for ProLiant rack servers. `Lom` LAN on motherboard - fixed devices on ProLiant G7 series and later servers.

`Mezz` Mezzanine cards - pluggable devices that provide additional network connectivity. `Ocp` Open Compute Project - open firmware OCP adapters. `Pci`

PCIe cards - standup cards that provide additional connectivity for ProLiant rack servers. `Unknown` The device location could not be determined.

physicalPorts List of physical ports on the device. array of ServerFabricPhysicalPortV4
read only

`physicalPorts[].`**interconnectPort**
The downlink port number on the interconnect that hosts network connections for this adapter port. If the adapter port is not connected to an interconnect downlink port, the value will be 0.
integer
read only

`physicalPorts[].`**interconnectUri**
The URI of the interconnect that hosts network connections for this adapter port. string
read only

`physicalPorts[].`**mac**
Physical mac address of this physical port. string
read only

`physicalPorts[].`**nodeGuid**
The effective current node GUID of virtual port of Infiniband Network Adapter. If an assignable node GUID is not supported, this value will be same as permanentNodeGUID
string
read only

`physicalPorts[].`**permanentNodeGuid**
The permanent node GUID assigned to the Infiniband Network Adapter. Typically, this value is programmed during manufacturing. This address is not assignable.
string
read only

`physicalPorts[].`**physicalIn**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The downlink port number on the interconnect to which the adapter port is physically connected. If the adapter port is not connected to an interconnect downlink port, the value will be 0.
integer
read only

`physicalPorts[].`**`physicalInterconnectUri`**
The URI of the interconnect to which the adapter port is physically connected. string
read only

`physicalPorts[].`**`portNumber`**
Physical port number of the adapter. integer
read only

`physicalPorts[].`**`type`**
Physical port type. Values include Ethernet and FibreChannel. PhysicalServerPortType
read only

Values `Ethernet` Ethernet network `FibreChannel` Fibre Channel network `InfiniBand` InfiniBand network `SAS` Serial Attached SCSI

`physicalPorts[].`**`virtualPorts`**
For Flex-capable devices, a list of FlexNICs defined on the server. array of ServerFabricVirtualPortV4
read only

`physicalPorts[].virtualPorts[].`**`currentAllocatedVirtualFunctionCount`**
The number of virtual functions presently allocated to this virtual port. integer
read only

`physicalPorts[].virtualPorts[].`**`mac`**
The mac address assigned to this virtual port. string
read only

`physicalPorts[].virtualPorts[].`**`portFunction`**
The function identifier for this FlexNIC, such as a, b, c or d. string
read only

Default false

`physicalPorts[].virtualPorts[].`**`portNumber`**
The port number assigned to this virtual port. integer
read only

`physicalPorts[].virtualPorts[].`**`wwnn`**
The world wide node name assigned to this virtual port. string
read only

`physicalPorts[].virtualPorts[].`**`wwpn`**
The world wide port name assigned to this virtual port. string
read only

`physicalPorts[].`**`wwn`**
The world wide name of this physical port. string
read only

`slotNumber` The slot number of the adapter on the server hardware within its specified location. integer
read only

`position` For blade servers, the number of the physical enclosure bay in which the server hardware resides. For rack mount servers, this value is null. integer
searchable
read only

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

powerLock
Indicates if an operation is being performed on this server hardware (such as a profile assignment) that prevents its power state from being manipulated via the server hardware API.
Boolean

Default false

powerState Current power state of the server hardware. Values are Unknown, On, Off, PoweringOn, PoweringOff or Resetting. PhysicalServerPowerState
required
searchable

Values

`Off` Power off `On` Power on `PoweringOff` Powering off `PoweringOn` Powering on `Resetting` Resetting `Unknown`

Unable to determine server power state.

processorCoreCount Number of cores available per processor. integer
read only

processorCount Number of processors installed on this server hardware. integer
read only

processorSpeedMhz Speed of the CPUs in megahertz. integer
read only

processorType Type of CPU installed on this server hardware. string
read only

refreshState Indicates if the resource is currently refreshing. Possible values are NotRefreshing, RefreshPending, Refreshing, and RefreshFailed. RefreshState

Values

`NotRefreshing` The resource is not currently refreshing `RefreshFailed` The refresh of this resource failed `RefreshPending`

The resource is waiting to be refreshed `Refreshing` The resource is currently being refreshed

remoteSupportSettings Settings to describe the state of Remote Support registration for the server. RemoteSupportSettings
read only

destination The appliance that the server is currently registered to. string
read only

Maximum Length 255 Minimum Length 0

remoteSupportCurrentState The current state of Remote Support registration for the server. string
read only

remoteSupportUri
The URI of the Remote Support settings object for the server, which contains information such as contact and channel partner assignments. string
read only

romVersion
The version of the server hardware firmware (ROM). After updating the ROM (BIOS) firmware for a server, the server hardware page and the REST API may report an inaccurate ROM version until the server is next powered on and allowed to complete the power-on self-test (POST).
string
read only

scopesUri The URI for the resource scope assignments. Refer to the GET /rest/scopes/resources/** API. string
read only

serialNumber Serial number of the server hardware. string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

read only

serverFirmwareInventoryUri URI of the Firmware Inventory of this server string

read only

serverGroupUri

For blade servers, this is the URI of the containing enclosure's enclosure group. This URI can be used to retrieve information about the enclosure group or to identify all the servers in the same group. This value is not set for rack mount servers.

string

read only

serverHardwareTypeUri

URI of the server hardware type associated with the server hardware. This URI can be used to retrieve information about the server hardware type. string

read only

serverName

The name of the server as reported by the iLO. The iLO gets this information from a running operating system that has monitoring software installed, like Agentless Management Service.

string

read only

serverProfileUri URI of a server profile assigned to this server hardware, if one is assigned. If not assigned this value is null. string

searchable

read only

serverSettings Indicates the current settings on the server and state of these settings. ServerSettings

read only

firmwareAndDriversInstallState The current installation status details of the firmware and/or OS drivers on the server.

FirmwareAndDriversInstallState

read only

installState The installation state information of the firmware and/or OS drivers on the server. InstallState

read only

Values

`ActivateFailed` Indicates activation of one or more smart components failed on the server. `Activated`

Indicates all the smart components from the Service Pack specified in the firmware and driver baseline settings are installed and activated on the server.

`Activating` Indicates Smart Update Tool is activating the installed smart components. `InstallFailed`

Indicates Smart Update Tool has failed installing one or more smart components. `InstalledPendingReboot`

Indicates Smart Update Tool has completed installing the smart components, however the server needs to be rebooted for the updates to take effect.

`Installing` Indicates Smart Update Tool is installing the smart components from the staged location. `Pending`

Indicates the firmware and/or OS driver baseline settings have been applied to the server hardware and will take effect when Smart Update Tool updates firmware and/or OS driver components based on these settings.

`PendingExternalAction`

Indicates another utility (E.g. OneView plug-in) is orchestrating the update and action external to OneView is needed to complete the update. Refer to the external utility for details to complete the update.

`SPPBootFailed` Indicates that the server did not boot into the Service Pack ISO image. The user needs to follow the resolution mentioned in the failed task.

`ScheduleDelayed`

Indicates that Smart Update Tools was not able to schedule it to the specified schedule date and time and has proposed a new schedule. User should review the new schedule in the profile and can choose to continue with the new schedule or can reschedule it to a new date and time.

`ScheduleFailed` The schedule operation has failed. The user needs to follow the resolution mentioned in the failed task. `Scheduled`

A firmware update has been scheduled successfully. `StageFailed`

Indicates Smart Update Tool has failed to stage the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings. `Staged`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Indicates Smart Update Tool has completed staging the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Staging`

Indicates Smart Update Tool is staging the firmware and/or OS driver smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Uninitialized` Indicates the current firmware and/or OS driver settings have been cleared. No components will be updated on the server. `Unknown`

Indicates the server failed to return the current settings, therefore, the actual values might not be current.

`installedStateTimestamp` The timestamp information indicating the time when the install state value got updated. string
read only

`firmwareInstallSchedule` The installation schedule details of the firmware and/or OS drivers on the server. Firmware Install Schedule
read only

`dateTime` Specifies the date and time at which the firmware baseline will get installed and activated. string

`scheduleOptions` The firmware schedule options of the firmware and/or OS drivers on the server. Firmware Schedule Options

Values

`StageAlongWithDeploy` Indicates that the baseline specified in the firmware settings will be staged and installed at the scheduled time.

`StageImmediately` Indicates that the baseline specified in the firmware settings will be staged immediately and installed at the scheduled time.

`StageImmediatelyAndRetryAtDeployTime`

Indicates that the firmware baseline specified will be staged immediately and will be installed at the scheduled date and time. In case there is a failure during staging, a retry will be done prior to installation at the scheduled date and time.

`hpSmartUpdateToolStatus` The status of Smart Update Tools installed on the server. HpSmartUpdateToolStatus
read only

`installState` Smart Update Tool's installed state on the server indicating whether it is installed, not installed or unknown. HpSUTInstallState
read only

Values

`Installed` The tool is installed on the server. `NotInstalled` The tool is not installed on the server. `Unknown` The tool installation status is not known.

`lastOperationTime` The timestamp indicating when Smart Update Tool was active or running a firmware update operation. string
read only

`mode` The current run mode configured for Smart Update Tool installed on the server. string
read only

`serviceState` The state of the Smart Update Tool Service running on the server operating system. string
read only

`version` The current version of the Smart Update Tool installed on the server. string
read only

`stagedInstallSetId` The stagedInstallSetId associated with the server. string
read only

`shortModel` Short version of the server hardware model string, typically something like BL460 Gen8. string
searchable
read only

`signature` Data representing the current configuration or 'signature' of the server. ServerSignature
read only

`personalityChecksum` A calculate

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

read only

serverHwChecksum A calculated checksum of the server hardware, based on the hardware components installed in the server. integer

read only

updatedPersChecksum

The personality checksum is a value calculated based on data retrieved from the network adapters within the particular server. This value is a secondary checksum calculated with an alternate algorithm intended to identify inconsistencies in the configuration of the server hardware and its associated profile. To avoid personality mismatch alerts, this value is used with the "personalityChecksum" value to update the profile data when appropriate.

integer

read only

state

The current resource state of the server hardware. Allowable values are: Unknown (not initialized), Adding (server being added), NoProfileApplied (server successfully added), Monitored (server being monitored), Unmanaged (discovered a supported server), Removing (server being removed), RemoveFailed (unsuccessful server removal), Removed (server successfully removed), ApplyingProfile (profile being applied to server), ProfileApplied (profile successfully applied), RemovingProfile (profile being removed), ProfileError (unsuccessful profile apply or removal), Unsupported (server model or version not currently supported by the appliance), and UpdatingFirmware (server firmware update in progress).

string

searchable

read only

stateReason

The reason for the current resource state of the server hardware. This only applies if the state is 'Unmanaged', otherwise it is set to 'NotApplicable'. Allowable values are: Unsupported (server model or version not currently supported by the appliance), UpdatingFirmware (server firmware update in progress), NotApplicable (when PhysicalServerState is anything besides 'Unmanaged'), NotOwner (no claim on server), Inventory (server added by PDU or discovered by Composable Cloud), Unconfigured (discovery data incomplete or iLO configuration failure), UnsupportedFirmware (iLO firmware version below minimum support level), Interrupted (when PhysicalServerState is a result of an operation that was terminated before completing), and CommunicationError (appliance cannot communicate with iLO or OA).

string

read only

status Overall health status of the resource. The following are the valid values for the status of the resource: string

OK - indicates normal/informational behavior;

Disabled - indicates that a resource is not operational or that a server profile has not been assigned;

Warning - needs attention soon;

Critical - needs attention soon;

Unknown - should be avoided, but there may be rare occasions where status is Unknown;

subResources SubResources of the server hardware. EnumMap<SubResourceName, SubResourceV10>

AdvancedMemoryProtection Inventory of Advanced Memory Protection resources for the server hardware. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`data` The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`modified` Date and time when the subresource was last modified. string

`name` The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

`Devices` Inventory of Devices for the server hardware. SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`data` The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`modified` Date and time when the subresource was last modified. string

`name` The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

`LocalStorage` Inventory of Local Storage resources for the server hardware. SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag

Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

LocalStorageV2

Inventory of Local Storage v2 resources for the server hardware, containing information on RDE enabled storage controllers, drives, and volumes. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the any type

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

data section.

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

MPSettings MPSettings defined on the server hardware. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully popul

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

Memory Inventory of Memory resources for the server hardware. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

MemoryList Inventory of Memory List resources for the server hardware. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Wh

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

Unknown Unknown resource type requested for the server hardware. SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag

Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

supportDataCollectionState The state of the data collection for the server. Possible values: PendingCollection, Completed, Error, NotSupported.
string
read only

supportDataCollectionType The type of data collection for the server. Possible values: Basic, ActiveHealthSystem. string
read only

supportDataCollectionsUri The URI of the data collections object for the server. string
read only

supportState
The state of Remote Support for the server. Possible values: PendingEnable, EnableRequested, Enabled, PendingDisable, DisableRequested, Disabled, NotSupported.
string
read only

supportTestEventState
The state of the request being submitted to the iLO to trigger a test event to be returned asynchronously to Remote Support. Possible values: PendingTestEvent, Completed, Error, NotSupported.
string
searchable
read only

type Uniquely identifies the type of the JSON object string
read only

Default server-hardware-12

uidState PhysicalServerUidState. PhysicalServerUidState

Values `Blinking` The UID light is blinking. `Off` The UID light is off. `On` The UID light is on. `Unsupported` UID light is not supported by this system.

uri The canonical URI of the resource string

uuid Universally Unique ID (UUID) of the server hardware. string

virtualSerialNumber Virtual serial number associated with this server hardware (if specified in the profile assigned to this server). string
read only

virtualUuid Virtual UUID associated with this server hardware (if specified in the profile assigned to this server). string
read only

PATCH **/rest/server-hardware/{id}**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Performs a specific patch operation for the given server. If the server supports the particular operation, the operation is performed and a response is returned to the caller with the results.

Supported patch operations and parameters:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Description	Operation	Path	Value
Reset iLO	replace	/mpState	Reset
Turn the server UID light on	replace	/uidState	On
Turn the server UID light off	replace	/uidState	Off
Update server licensing intent	replace	/licensingIntent	OneView|OneViewNoiLO
Set the server one-time boot device to No one-time boot	replace	/oneTimeBoot	NORMAL
Set the server one-time boot device to CD/DVD Drive	replace	/oneTimeBoot	CDROM
Set the server one-time boot device to USB Storage Device	replace	/oneTimeBoot	USB
Set the server one-time boot device to Hard Disk Drive	replace	/oneTimeBoot	HDD
Set the server one-time boot device to Network	replace	/oneTimeBoot	NETWORK
Attempt a graceful shutdown of the server using the momentary press control	replace	/powerState	{"powerState": "Off", "powerControl":"MomentaryPress"}
Power on a server using the momentary press control	replace	/powerState	{"powerState": "On", "powerControl":"MomentaryPress"}
Immediately power off the server using the press and hold control	replace	/powerState	{"powerState": "Off", "powerControl":"PressAndHold"}
Reset the server using the cold boot control. This is a hard reset that immediately removes power from the server hardware and restarts the server after approximately eight seconds.	replace	/powerState	{"powerState": "On", "powerControl":"ColdBoot"}
Reset the server using the reset control. This will perform an immediate warm reboot of the server without removing power.	replace	/powerState	{"powerState": "On", "powerControl":"Reset"}
Put the server into maintenance mode	replace	/maintenanceMode	"true"
Take the server out of maintenance mode	replace	/maintenanceMode	"false"
Set the server product ID	replace	/partNumber	A valid product ID string
Set the server serial number	replace	/serialNumber	The serial number to set

Perform an iLO reset for the given server:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "path": "/mpState", "value": "Reset" }
]
```

Turn the server UID light on:

Request

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
PATCH  https://{appl}/rest/server-hardware/{id}/

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "path": "/uidState", "value": "On" }
]
```

Turn the server UID light off:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "path": "/uidState", "value": "Off" }
]
```

Update Server Licensing Intent

The licensing intent of the server may be changed to either "OneView" (HPE OneView Advanced) or "OneViewNoiLO" (HPE OneView Advanced w/o iLO). The server must be unlicensed and managed in order to be able to update the licensing intent.

In addition, a server licensed with "OneViewNoiLO" may be upgraded to "OneView", provided a "OneView" license is available and the server does not already have an embedded or "iLO Advanced" license installed.

Request

```
PATCH https://{appl}/rest/server-hardware/USE7335NW3

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
    { "op": "replace", "path": "/licensingIntent", "value": "OneView"}
]
```

The licensing intent of the server is changed, and if a license of the intended type is available, it is applied to the server. Once licensed, the only permitted change is an upgrade from "OneViewNoiLO" to "OneView".

This operation runs asynchronously, and

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

This operation runs asynchronously, and a Task URI is returned in the `Location` response header. Use it to track the status and progress of the operation.

Response

```
HTTP/1.1 202 Accepted
Content-Length: 0
Location: /rest/tasks/F81D4FAE-7DEC-11D0-A765-00A0C91E6BF6
```

Set the one-time boot value

Example of one-time boot value set to CDROM.

Request

```
PATCH https://{appl}/rest/server-hardware/USE7335NW3

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
    { "op": "replace", "path": "/oneTimeBoot", "value": "CDROM"}
]
```

This operation runs asynchronously, and a Task URI is returned in the `Location` response header. Use it to track the status and progress of the operation.

Response

```
HTTP/1.1 202 Accepted
Content-Length: 0
Location: /rest/tasks/F81D4FAE-7DEC-11D0-A765-00A0C91E6BF6
```

Power on a server that is off, using the momentary press control:

Request

```
PATCH https://{appl}/rest/server-hardware/USE7335NW3

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
    { "op": "replace", "path": "/powerState", "value": { "powerState": "On", "powerControl":"MomentaryPress"}}
]
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Put the server into maintenance mode:

When in maintenance mode, the appliance will not send any email notifications or forward SNMP traps related to the server hardware and its associated profile. Apart from blocking these notifications, maintenance mode does not affect server or profile operations.

Request

```
PATCH https://{appl}/rest/server-hardware/USE7335NW3

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
    { "op": "replace", "path": "/maintenanceMode", "value": "true"}
]
```

Take the server out of maintenance mode:

When not in maintenance mode, the appliance will send email email notifications related to the server hardware and its associated profile.

Request

```
PATCH https://{appl}/rest/server-hardware/USE7335NW3

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
    { "op": "replace", "path": "/maintenanceMode", "value": "false"}
]
```

Set the server serial number and product ID (part number):

The server serial number and product ID must be set together in a single PATCH call that contains no operations other than these. This operation is supported on Gen9 or later servers.

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

[
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
    { "op": "replace", "path": "/serialNumber", "value": "serial-number-to-set" },
    { "op": "replace", "path": "/partNumber", "value": "part-number-to-set" }
]
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. In addition, if the permission is scoped, the target resource URI(s) must be in the permission scope.

Action `Update`

Category `server-hardware`

Scoped By `uri`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`
The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json-patch+json

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

`Location` The URI of the newly-created resource or a task created to perform the requested action. string

Request Body array of PATCH Operation

`from` The JSON path to use as the source of a "move" or "copy" operation. Not used by "add", "remove", "replace", or "test". string
read only

`op` The type of operation: one of "add", "c

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

read only

Default Operation

path The JSON path the operation is to use. The exact meaning depends on the type of operation. string

required

value

The value to add or replace for "add" and "replace" operations, or the value to compare against for a "test" operation. Not used by "copy", "move", or "remove".

any type

read only

DELETE **/rest/server-hardware/{id}**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Removes the rack-server with the specified URI. Note: This operation is only supported on appliances which support rack mounted servers.

Removes the rack-server with the specified URI

Request

```
DELETE  https://{appl}/rest/server-hardware/{id}

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. In addition, if the permission is scoped, the target resource URI(s) must be in the permission scope.

Action `Delete`

Category `server-hardware`

Scoped By `uri`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

`Location` The URI of the newly-created resource or a task created to perform the requested action. string

Query Parameters

`force`
The default is false. If set to true, the operation completes even if there are network connectivity issues or resource errors. Even though it is possible to force remove the server hardware with issues

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

remove the server hardware with issues or errors, it is strongly recommended that the server hardware has any communication issue resolved before removing it. It is recommended that the servers be unconfigured or they will continue to operate as configured.

Boolean

`parentTaskUri` The URI of a parent task (UNUSED). string

GET **/rest/server-hardware/{id}/advancedMemoryProtection**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the advanced memory protection resource for the server.

Advanced memory protection resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/advancedMemoryProtection

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the advanced memory protection data based on the following schema:

Response


```
{
    "AmpModeActive": {
        "enum": [
            "Unknown",
            "Other",
            "None",
            "Mirroring",
            "OnlineSpare",
            "RAIDXOR",
            "AdvancedECC",
            "Lockstep",
            "A3DC"
        ],
        "enumDescriptions": {
            "A3DC": "The system is configured for AMP with A3DC.",
            "AdvancedECC": "The system is configured for AMP with the Advanced ECC engine.",
            "LockStep": "The system is configured for AMP with the LockStep engine",
            "Mirroring": "The system is configured for mirrored memory protection. All memory banks are duplicated in mirrored memory, as opposed to
            "None": "The management software cannot determine the AMP, or the system is not configured for AMP.",
            "OnlineSpare": "A single spare bank of memory is set aside at boot time. If enough ECC errors occur, the spare memory is activated and t
            "RAIDXOR": "The system is configured for AMP with the XOR engine.",
            "Unknown": "The management software cannot determine the AMP, host OS may not have provided it yet."
        },
        "type": "string"
    },
    "AmpModeStatus": {
        "enum": [
            "Unknown",
            "Other",
            "NotProtected",
            "Protected",
            "Degraded",
            "DIMMECC",
            "Mirroring",
            "DegradedMirroring",
            "OnlineSpare",
            "DegradedOnlineSpare",
            "RAIDXOR",
            "DegradedRAIDXOR",
            "AdvancedECC"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "AdvancedECC",
                "DegradedAdvancedECC",
                "Lockstep",
                "DegradedLockstep",
                "A3DC",
                "DegradedA3DC"
            ],
            "enumDescriptions": {
                "A3DC": "The system is protected by AMP in the A3DC mode.",
                "AdvancedECC": "The system is protected by AMP in the Advanced ECC mode.",
                "DIMMECC": "The system is protected by DIMM ECC (Error Correcting Code) only.",
                "Degraded": "The system was protected, but AMP is engaged. Therefore, AMP is no longer available.",
                "DegradedA3DC": "The system is protected by AMP in the A3DC mode. One or more DIMM faults have been deteced.",
                "DegradedAdvancedECC": "The system is protected by AMP in the Advanced ECC mode. One or more DIMM faults have been detected.",
                "DegradedLockStep": "The system is protected by AMP in the LockStep mode. One or more DIMM faults have been detected.",
                "DegradedMirroring": "The system is protected by AMP in the mirrored mode. One or more DIMM faults have been detected.",
                "DegradedOnline Spare": "The system is protected by AMP in the hot spare mode. One or more DIMM faults have been detected.",
                "DegradedRAIDXOR": "The system is protected by AMP in the XOR memory mode. One or more DIMM faults have been detected.",
                "LockStep": "The system is protected by AMP in the LockStep mode.",
                "Mirroring": "The system is protected by AMP in the mirrored mode. No DIMM faults have been detected.",
                "NotProtected": "The system supports AMP, but the feature is disabled.",
                "OnlineSpare": "The system is protected by AMP in the hot spare mode. No DIMM faults have been detected.",
                "Other": "The system does not support AMP, or the management software cannot determine the status.",
                "Protected": "The system supports AMP. The feature is enabled but not engaged.",
                "RAIDXOR": "The system is protected by AMP in the XOR memory mode. No DIMM faults have been detected.",
                "Unknown": "The management software cannot determine the status, host OS may not have provided it yet."
            },
            "type": "string"
        },
        "AmpModeSupported": {
            "items": {
                "enum": [
                    "RAIDXOR",
                    "DualBoardMirroring",
                    "SingleBoardMirroring",
                    "AdvancedECC",
                    "Mirroring",
                    "OnlineSpare",
                    "OnlineSpareRank",
                    "OnlineSpareChannel",
                    "IntersocketMirroring",
                    "IntrasocketMirroring",
                    "Lockstep",
                    "A3DC",
                    "None"
                ],
                "enumDescriptions": {
                    "A3DC": "The system can be configured for A3DC.",
                    "AdvancedECC": "The system can be configured for Advanced ECC.",
                    "DualBoardMirroring": "The system can be configured for mirrored advanced memory protection in a dual memory board configuration. Th
                    "IntersocketMirroring": "The system can be configured for mirrored intersocket AMP between the memory of two processors or boards.",
                    "IntrasocketMirroring": "The system can be configured for mirrored intrasocket AMP between the memory of a single processor or board
                    "LockStep": "The system can be configured for LockStep AMP.",
                    "Mirroring": "The system can be configured for mirrored AMP.",
                    "None": "The system cannot be configured for AMP.",
                    "OnlineSpare": "The system can be configured for online spare AMP.",
                    "OnlineSpareChannel": "The system can be configured for Online Spare Channel AMP.",
                    "OnlineSpareRank": "The system can be configured for Online Spare Rank AMP.",
                    "RAIDXOR": "The system can be configured for AMP using the XOR engine.",
                    "SingleBoardMirroring": "The system can be configured for mirrored advanced memory protection in a single memory board."
                },
                "type": "string"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            },
            "type": "array"
        }
    }
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET /rest/server-hardware/{id}/bios

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the list of BIOS/UEFI values currently set on the physical server.

Gets the list of BIOS/UEFI settings for the given server hardware resource:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/bios

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body ServerBiosSettings

`biosSettingsState` The state of the BIOS/UEFI settings. BiosSettingsStateEnum
read only

Values

`Applied` Indicates the current BIOS/UEFI settings were retrieved from the server successfully and no profile changes are pending. `Pending`

Indicates there are BIOS/UEFI settings defined in the server profile that have been applied to the server hardware and will take effect when the server hardware is next powered on and completes its power-on self-test.

`Unknown` Indicates the server failed to return the current settings, therefore, the actual values might not be current.

`currentSettings` The list of BIOS/UEFI values currently set on the physical server. array of ServerBiosSetting

`displayName` The localized name that describes a BIOS/UEFI setting. string

`id` Uniquely identifies a BIOS/UEFI setting within the server hardware. string
required

`menuPathDisplayName`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The localized string of the full menu path of a setting. Provided as a single string where sub-categories are separated from each other by a double slash (//). string

value The current value for the setting. string

valueDisplayName The localized name that describes the option. string

GET **/rest/server-hardware/{id}/chassis**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the chassis resource for the server.

Chassis resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/chassis

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the chassis data based on the following schema: :

Response


```
{
    "AssetTag": {
      "description": "The chassis user-assigned asset tag.",
      "etag": true,
      "readonly": false,
      "type": [
        "string",
        "null"
      ]
    },
    "ChassisType": {
      "description": "This property indicates the physical form factor type of this resource.",
      "enum": [
        "Rack",
        "Blade",
        "Enclosure",
        "StandAlone",
        "RackMount",
        "Card",
        "Cartridge",
        "Row",
        "Pod",
        "Expansion",
        "Sidecar",
        "Zone",
        "Sled",
        "Shelf",
        "Other"
      ],
      "enumDescriptions": {
        "Blade": "An enclosed or semi-enclosed, typically vertically-oriented, system chassis that must be plugged into a multi-system chassis to fu
        "Card": "A loose device or circuit board intended to be installed in a system or other enclosure.",
        "Cartridge": "A small self-contained system intended to be plugged into a multi-system chassis.",
        "Enclosure": "A generic term for a chassis that does not fit any other description.",
        "Expansion": "A chassis that expands the capabilities or capacity of another chassis.",
        "Other": "A chassis that does not fit any of these definitions.",
        "Pod": "A collection of equipment racks in a large, likely transportable, container.",
        "Rack": "An equipment rack, typically a 19-inch wide freestanding unit.",
        "RackMount": "A single system chassis designed specifically for mounting in an equipment rack."
        "Row": "A collection of equipment racks
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
      "Row": "A collection of equipment racks.",
      "Shelf": "An enclosed or semi-enclosed, typically horizontally-oriented, system chassis that must be plugged into a multi-system chassis to
      "Sidecar": "A chassis that mechanically connects with another chassis to expand its capabilities or capacity.",
      "Sled": "TBD",
      "StandAlone": "A single, free-standing system, commonly called a tower or desktop chassis.",
      "Zone": "A logical division or portion of a physical chassis that contains multiple devices or systems that cannot be physically separated."
    },
    "readonly": true,
    "type": "string"
  },
  "Description": {
    "description": "Provides a description of this resource and is used for commonality  in the schema definitions.",
    "type": [
      "string",
      "null"
    ]
  },
  "Id": {
    "description": "Uniquely identifies the resource within the collection of like resources.",
    "type": "string"
  },
  "IndicatorLED": {
    "description": "The chassis indicator LED that is used to identify the chassis. The user can manipulate this LED.",
    "enum": [
      null,
      "Unknown",
      "Lit",
      "Blinking",
      "Off"
    ],
    "enumDescriptions": {
      "Blinking": "The Indicator LED is blinking.",
      "Lit": "The Indicator LED is on.",
      "Off": "The Indicator LED is off.",
      "Unknown": "The state of the Indicator LED cannot be determined."
    },
    "etag": true,
    "readonly": false,
    "type": [
      "string",
      "null"
    ]
  },
  "Links": {
    "additionalProperties": false,
    "description": "The links array contains links to related resources.",
    "properties": {
      "ComputerSystems": {
        "description": "An array of references to the computer systems contained in this chassis. This will only reference ComputerSystems that ar
        "items": {
          "properties": {
            "@odata.id": {
              "format": "uri-reference",
              "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined i
              "type": "string"
            }
          },
          "type": "object"
        },
        "readonly": true,
        "type": "array"
      },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
"ContainedBy": {
  "description": "A reference to the chassis that contains this chassis.",
  "properties": {
    "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined i
        "type": "string"
    }
  },
  "readonly": true,
  "type": "object"
},
"Contains": {
  "description": "An array of references to any other chassis contained in this chassis.",
  "items": {
    "properties": {
      "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined i
        "type": "string"
      }
    },
    "type": "object"
  },
  "readonly": true,
  "type": "array"
},
"Drives": {
  "description": "An array of references to the drives contained in this chassis.",
  "items": {
    "properties": {
      "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined i
        "type": "string"
      }
    },
    "type": "object"
  },
  "readonly": true,
  "type": "array"
},
"LogServices": {
  "description": "A reference to the logs for this chassis.",
  "properties": {
    "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined i
        "type": "string"
    }
  },
  "readonly": true,
  "type": "object"
},
"ManagedBy": {
  "description": "An array of references to the managers contained in this chassis.",
  "items": {
    "properties": {
      "@odata.id": {
        "format": "uri-reference",
        "longDescription
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
              "type": "string"
            }
          },
          "type": "object"
        },
        "readonly": true,
        "type": "array"
      },
      "Oem": {
        "description": "This object represents the Oem property.",
        "type": "object"
      }
    },
    "readonly": true,
    "type": "object"
  },
  "Manufacturer": {
    "description": "The chassis manufacturer.",
    "etag": true,
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "Model": {
    "description": "The chassis model number.",
    "etag": true,
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "Name": {
    "description": "The name of the resource or array element.",
    "type": "string"
  },
  "NetworkAdapters": {
    "additionalProperties": false,
    "description": "The collection of network adapters contained within this chassis.",
    "etag": false,
    "properties": {
      "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in the
        "type": "string"
      }
    },
    "readonly": true,
    "type": "object"
  },
  "Oem": {
    "additionalProperties": true,
    "properties": {
      "Hpe": {
        "$ref": "HpeServerChassis.json#"
      }
    },
    "readonly": true,
    "type": "object"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        },
        "PartNumber": {
          "description": "The chassis part number.",
          "etag": true,
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "PhysicalSecurity": {
          "additionalProperties": false,
          "properties": {
            "IntrusionSensor": {
              "description": "This indicates the known state of the physical security sensor, such as if it is hardware intrusion detected.",
              "enum": [
                "Normal",
                "HardwareIntrusion",
                "TamperingDetected"
              ],
              "enumDescriptions": {
                "HardwareIntrusion": "A door, lock, or other mechanism protecting the internal system hardware from being accessed is detected as being
                "Normal": "No abnormal physical security conditions are detected at this time.",
                "TamperingDetected": "Physical tampering of the monitored entity is detected."
              },
              "readonly": true,
              "type": [
                "string",
                "null"
              ]
            },
            "IntrusionSensorReArm": {
              "description": "This indicates how the Normal state to be restored.",
              "enum": [
                "Manual",
                "Automatic"
              ],
              "enumDescriptions": {
                "Automatic": "This sensor would be restored to the Normal state automatically as no abnormal physical security conditions are detected."
                "Manual": "This sensor would be restored to the Normal state by a manual re-arm."
              },
              "readonly": true,
              "type": [
                "string",
                "null"
              ]
            }
          },
          "readonly": true,
          "type": "object"
        },
        "Power": {
          "description": "A reference to the thermal metrics (power supplies, power policies, sensors) for this chassis.",
          "properties": {
            "@odata.id": {
              "format": "uri-reference",
              "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in the
              "type": "string"
            }
          },
          "readonly": true,
          "type": "object"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
    "type": "object"
  },
  "PowerState": {
    "description": "This is the current power state of the chassis.",
    "enum": [
      null,
      "On",
      "Off",
      "Unknown",
      "Reset"
    ],
    "longDescription": "The value of this property shall contain the power state of the chassis.",
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "SKU": {
    "description": "The chassis SKU.",
    "etag": true,
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "SerialNumber": {
    "description": "The chassis serial number.",
    "etag": true,
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "Status": {
    "properties": {
      "Health": {
        "description": "This represents the health state of this resource in the absence of its dependent resources.",
        "enum": [
          null,
          "OK",
          "Warning",
          "Critical"
        ],
        "enumDescriptions": {
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condition exists that requires attention"
        },
        "longDescription": "This property shall represent the HealthState of the resource without considering its dependent resources. The values
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      },
      "HealthRollup": {
        "description": "This represents the overall health state from the view of this resource.",
        "enum": [
          null,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
          "OK",
          "Warning",
          "Critical"
        ],
        "enumDescriptions": {
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condition exists that requires attention"
        },
        "longDescription": "This property shall represent the HealthState of the resource and its dependent resources.  The values shall conform t
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      },
      "State": {
        "description": "This indicates the known state of the resource, such as if it is enabled.",
        "enum": [
          null,
          "Enabled",
          "Disabled",
          "StandbyOffline",
          "StandbySpare",
          "InTest",
          "Starting",
          "Absent",
          "UnavailableOffline",
          "Deferring",
          "Quiesced",
          "Updating"
        ],
        "enumDescriptions": {
          "Absent": "This function or resource is not present or not detected.",
          "Deferring": "The element will not process any commands but will queue new requests.",
          "Disabled": "This function or resource has been disabled.",
          "Enabled": "This function or resource has been enabled.",
          "InTest": "This function or resource is undergoing testing.",
          "Quiesced": "The element is enabled but only processes a restricted set of commands.",
          "StandbyOffline": "This function or resource is enabled, but awaiting an external action to activate it.",
          "StandbySpare": "This function or resource is part of a redundancy set and is awaiting a failover or other external action to activate i
          "Starting": "This function or resource is starting.",
          "UnavailableOffline": "This function or resource is present but cannot be used.",
          "Updating": "The element is updating and may be unavailable or degraded."
        },
        "longDescription": "This property shall represent if this component is available or not and why.  Enabled indicates the resource is availa
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      }
    },
  },
  "Thermal": {
    "description": "A reference to the thermal metrics (fans, cooling, sensors) for this chassis.",
    "properties": {
      "@odata.id": {
        "format": "uri-reference",
        "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in the
        "type": "string"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            }
          },
          "readonly": true,
          "type": "object"
        }
      },
    }
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server in

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET /rest/server-hardware/{id}/devices

Gets the devices resource for the server, which includes information for all devices available on the server.

Devices subresource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/devices

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the devices data based on the following schema:

Response

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
{
    "DeviceType": {
        "description": "Device type.",
        "enum": [
            "GPU",
            "PLX Controller",
            "Expansion Riser",
            "Smart Storage",
            "SAS/SATA Storage Controller",
            "IDE Storage controller",
            "USB Storage Controller",
            "Storage Controller",
            "LOM/NIC",
            "Converged Network Adapter",
            "Fibre Channel",
            "Direct Attached NVMe Device",
            "Backplane PIC",
            "Smart Storage Battery",
            "USB",
            "TPM",
            "Communication Controller",
            "Unknown"
        ],
        "enumDescriptions": {
            "GPU": "GPU",
            "PLX Controller": "PLX Controller (Bridge)",
            "Expansion Riser": "Expansion Riser",
            "Smart Storage": "Smart Storage",
            "SAS/SATA Storage Controller": "SAS/SATA Storage Controller",
            "Other PCI Device": "Other PCI Devices",
            "IDE Storage Controller": "IDE Storage Controller",
            "USB Storage Controller": "USB Storage Controller",
            "Storage Controller": "Storage Controller",
            "LOM/NIC": "LOM/NIC",
            "Converged Network Adapter": "Converged Network Adapter",
            "Fibre Channel": "Fibre Channel",
            "Direct Attached NVMe Device": "Direct Attached NVMe Device",
            "Backplane PIC": "Backplane PIC",
            "Smart Storage Battery": "Smart Storage Battery",
            "USB": "Universal Serial Bus",
            "TPM": "Trusted Platform Module",
            "Communication Controller": "Communication Controller",
            "Unknown": "Unknown Device Type"
        },
        "type": "string"
    },
    "FirmwareVersion": {
        "Current": {
            "VersionString": "Current firmware version"
        }
    },
    "Id": {
        "$ref": "Device Id"
    },
    "Location": {
        "description": "Location of the device.",
        "type": [
            "string",
            "null"
        ]
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        },
        "Manufacturer": {
            "description": "Device manufacturer.",
            "type": [
                "string",
                "null"
            ]
        },
        "MCTPProtocolDisabled": {
            "description": "Set to true to disable MCTP on this slot. Once disabled, can be enabled only through MCTP factory reset.",
            "type": "boolean"
        },
        "Name": {
            "description": "Product Name."
        },
        "PartNumber": {
            "description": "Board part Number which is HPE PCA Assembly Number.",
            "type": [
                "string",
                "null"
            ]
        },
        "ProductPartNumber": {
            "description": "Product Part Number.",
            "type": [
                "string",
                "null"
            ]
        },
        "ProductVersion": {
            "description": "Product Version.",
            "type": [
                "string",
                "null"
            ]
        },
        "SerialNumber": {
            "description": "Product Serial Number.",
            "type": [
                "string",
                "null"
            ]
        },
        "Status": {
            "Health": "Health status of the device.",
            "State": "State of the device, possible values: 'Absent', 'Enabled'"
        }
    }
```


Response Body

Response

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
{
    "uri": "/rest/server-hardware/36314C44-2030-6361-3030-303030306163/device",
    "collectionState": "Collected",
    "modified": "2018-05-07T08:51:28.087Z",
    "data": [{
            "@odata.etag": "W/\"D0E9DEF6\"",
            "@odata.type": "#HpeServerDevice.v2_0_0.HpeServerDevice",
            "Id": "1",
            "DeviceType": "LOM/NIC",
            "FirmwareVersion": {
                "Current": {
                    "VersionString": "00.00.00"
                }
            },
            "Location": "PCI-E Slot 1",
            "MCTPProtocolDisabled": false,
            "Manufacturer": "HPE",
            "Name": "HPE Eth 10Gb 2p 521T Adptr",
            "PartNumber": "869573-001",
            "ProductPartNumber": "867707-B21",
            "ProductVersion": "",
            "SerialNumber": "MY570907TX",
            "Status": {
                "Health": null,
                "State": null
            }
        },
        {
            "@odata.etag": "W/\"0E03CB16\"",
            "@odata.type": "#HpeServerDevice.v2_0_0.HpeServerDevice",
            "Id": "2",
            "DeviceType": "Unknown",
            "FirmwareVersion": {
                "Current": {
                    "VersionString": "N/A"
                }
            },
            "Location": "PCI-E Slot 2",
            "MCTPProtocolDisabled": false,
            "Manufacturer": "",
            "Name": "Empty slot 2",
            "PartNumber": "",
            "ProductPartNumber": "",
            "ProductVersion": "",
            "SerialNumber": "",
            "Status": {
                "State": "Absent"
            }
        },
        {
            "@odata.etag": "W/\"47FE4D32\"",
            "@odata.type": "#HpeServerDevice.v2_0_0.HpeServerDevice",
            "Id": "3",
            "DeviceType": "LOM/NIC",
            "FirmwareVersion": {
                "Current": {
                    "VersionString": "1.1882.0"
                }
            },
            "Location": "Embedde
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "Location": "Embedded LAN",
            "Manufacturer": "",
            "Name": "HPE Ethernet 1Gb 2-port 368i Adapter",
            "PartNumber": "",
            "ProductPartNumber": "",
            "ProductVersion": "",
            "SerialNumber": "",
            "Status": {
                "Health": "OK",
                "State": "Enabled"
            }
        },
        {
            "@odata.etag": "W/\"24ECB96B\"",
            "@odata.type": "#HpeServerDevice.v2_0_0.HpeServerDevice",
            "Id": "4",
            "DeviceType": "Smart Storage",
            "FirmwareVersion": {
                "Current": {
                    "VersionString": "1.59-302"
                }
            },
            "Location": "Embedded RAID",
            "Manufacturer": "",
            "Name": "HPE Smart Array P408i-a SR Gen10",
            "PartNumber": "836260-001",
            "ProductPartNumber": "",
            "ProductVersion": "B",
            "SerialNumber": "PEYHC0XRH4005M ",
            "Status": {
                "Health": "OK",
                "State": "Enabled"
            }
        },
        {
            "@odata.etag": "W/\"96249847\"",
            "@odata.type": "#HpeServerDevice.v2_0_0.HpeServerDevice",
            "Id": "5",
            "DeviceType": "Unknown",
            "FirmwareVersion": {
                "Current": {
                    "VersionString": "2.5"
                }
            },
            "Location": "Embedded Device",
            "Manufacturer": "",
            "Name": "Embedded Video Controller",
            "PartNumber": "",
            "ProductPartNumber": "",
            "ProductVersion": "",
            "SerialNumber": "",
            "Status": {
                "Health": "OK",
                "State": "Enabled"
            }
        }
    ],
    "etag": "8669439C",
    "count": 5,
    "name": "Device"
}
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET /rest/server-hardware/{id}/environmentalConfiguration

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the settings that describe the environmental configuration (supported feature set, calibrated minimum & maximum power, location & dimensions, ...) of the server hardware resource.

Retrieve environmental configuration data for a given server hardware resource:

Request

```
GET  https://{appl}/rest/server-hardware/{id}/environmentalConfiguration

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body EnvironmentalConfiguration

`calibratedMaxPower`
The calibrated maximum power. Calibrated Maximum Power is defined as the maximum potential power that the device can consume, subject to the following requirements and constraints:
1. The value reported MUST be the maximum which can be sustained for greater than 1/2 second (i.e., in-rush currents and other spikes that may persist for less than a 1/2 second are not to be included).
2. The value reported MUST represent the maximum total AC input across all power supplies
3. The value reported MUST represent the maximum AC input the device can sustain as configured at the time this metric is reported. If additional components are added later or if it is discovered at a later time that more power can be used, the larger number MUST be reported when the device is next queried for this metric.
4. The value reported does not represent potential input power in the case of error conditions such as short circuits.
5. The actual power used by the device MUST NOT exceed the reported Calibrated Maximum Power by greater than 1%.
6. The Calibrated Maximum Power SHOULD NOT exceed the actual maximum power that the device is capable of using by more than 5%.
This value will be calculated automatically for managed/monitored device.
integer
required

`capHistorySupported` Resource supports power cap value history. Boolean

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

height The height of the device in u-slots (-1 for unspecified). integer
required

historyBufferSize Number of history samples maintained by the device. For example, 288 samples at 5 minute intervals cover 24 hours. integer
required

historySampleIntervalSeconds Number of seconds in a power history sample interval. Typically 300 seconds (5 minutes). integer
required

idleMaxPower Minimum power consumption seen (in Watts), 0 if unknown. The minimum power consumption occurs when the device is in idle state. integer
required

licenseRequirement
Reflects any known missing license requirement that prevents access to environmental monitoring features of the resource. If the value is None, then there are no known issues preventing access to environmental monitoring features of the resource. If the value is iLOAdvanced, then the server hardware must have an iLOAdvanced license applied to environmental monitoring features. If the value is OneView, then it indicates that there are insufficient HPE OneView licenses available to the appliance to enable environmental management features on the resource.
LicenseRequirement
required

Values

`None` No missing requirements `OneView` HPE OneView license is required for history data access `iLOAdvanced`

iLO Advanced license is required for history data

powerCapType The type of power capping supported by this device. PowerCapType

Values `Electrical` Electrical power cap `None` No power cap `Thermal` Thermal power cap

powerHistorySupported
Resource supports monitoring and retrieval of power consumption history data. Lack of power consumption history also implies that the calibratedMaxPower cannot be automatically calculated.
Boolean
required

psuList The list of configuration data for each power supply of the device. array of PsuConfigurationData

capacity The size of the power supply in Watts. integer

inputVoltage The line voltage (input) to the power supply (sampled or nominal). integer

powerType The type of input power (AC or DC) of the power supply. PowerSupplyType

Values `AC` AC power supply `DC` DC power supply `Unknown` Unknown power supply type

psuId A small integer identifying the slot or bay number of the power supply starting at one (1). integer

side
The logical power delivery grouping of the power supply. In a known non-redundant configuration, all power supplies should be considered on side A. In a known AC-redundant configuration, the 2 sets of redundant power supplies should be identified as side A/B groupings. For an AC_REDUNDANT C-Class Blade System slot 1,2,3 is on Side B (right from the front), and 4,5,6 are on Side A (left from the front). If there is no inherent side-ness, then the side will be Dynamic.
PowerSupplySide

Values `A` A connection side `B` B connection side `Dynamic` Dynamic `Unspecified` Unspecified connection side

rackId The GUID of the containing rack if available; otherwise null. string

rackName The rack name associated to this device (null for unspecified). string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

relativeOrder

The relative order of a resource in a Rack when slot information cannot be discovered and is not yet configured. This information is derived from the management link cable connections in a Blade System enclosure. The values increase from top to bottom, the lowest number (one at top of rack) to highest number (bottom of rack). A value of -1 indicates unspecified.

integer

required

thermalHistorySupported Resource supports ambient temperature history reporting. Boolean

required

uSlot The top-u-slot number of the device in the associated rack if available; -1 otherwise. integer

utilizationHistorySupported Resource supports CPU utilization history. Boolean

required

PUT **/rest/server-hardware/{id}/environmentalConfiguration**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Sets the calibrated max power of an unmanaged or unsupported server hardware resource.

Specify the maximum power for an unmanaged server hardware resource 123-45-67-89-123:

Request

```
PUT  https://{appl}/rest/server-hardware/123-45-67-89-123/environmentalConfiguration

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

{
    "calibratedMaxPower" : 2500
}
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Update`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`
The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Request Body EnvironmentalConfigurationUpdate

`calibratedMaxPower`
The calibrated maximum power of the resource. Calibrated Maximum Power is defined as the maximum potential power that the device can consume, subject to the following requirements and constraints: 1. The value reported MUST be the maximum which can be sustained for greater than 1/2 second (i.e., in-rush currents and other spikes that may persist for less than a 1/2 second are not to be included). 2. The value reported MUST represent the maximum total AC input across all power supplies 3. The value reported MUST represent the maximum AC input the device can sustain as configured at the time this metric is reported. If additional components are added later or if it is disc

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

components are added later or if it is discovered at a later time that more power can be used, the larger number MUST be reported when the device is next queried for this metric. 4. The value reported does not represent potential input power in the case of error conditions such as short circuits. 5. The actual power used by the device MUST NOT exceed the reported Calibrated Maximum Power by greater than 1%. 6. The Calibrated Maximum Power SHOULD NOT exceed the actual maximum power that the device is capable of using by more than 5%.
integer
required

Response Body EnvironmentalConfiguration

`calibratedMaxPower`
The calibrated maximum power. Calibrated Maximum Power is defined as the maximum potential power that the device can consume, subject to the following requirements and constraints:
1. The value reported MUST be the maximum which can be sustained for greater than 1/2 second (i.e., in-rush currents and other spikes that may persist for less than a 1/2 second are not to be included).
2. The value reported MUST represent the maximum total AC input across all power supplies
3. The value reported MUST represent the maximum AC input the device can sustain as configured at the time this metric is reported. If additional components are added later or if it is discovered at a later time that more power can be used, the larger number MUST be reported when the device is next queried for this metric.
4. The value reported does not represent potential input power in the case of error conditions such as short circuits.
5. The actual power used by the device MUST NOT exceed the reported Calibrated Maximum Power by greater than 1%.
6. The Calibrated Maximum Power SHOULD NOT exceed the actual maximum power that the device is capable of using by more than 5%.
This value will be calculated automatically for managed/monitored device.
integer
required

`capHistorySupported` Resource supports power cap value history. Boolean
required

`height` The height of the device in u-slots (-1 for unspecified). integer
required

`historyBufferSize` Number of history samples maintained by the device. For example, 288 samples at 5 minute intervals cover 24 hours. integer
required

`historySampleIntervalSeconds` Number of seconds in a power history sample interval. Typically 300 seconds (5 minutes). integer
required

`idleMaxPower` Minimum power consumption seen (in Watts), 0 if unknown. The minimum power consumption occurs when the device is in idle state. integer
required

`licenseRequirement`
Reflects any known missing license requirement that prevents access to environmental monitoring features of the resource. If the value is None, then there are no known issues preventing access to environmental monitoring features of the resource. If the value is iLOAdvanced, then the server hardware must have an iLOAdvanced license applied to environmental monitoring features. If the value is OneView, then it indicates that there are insufficient HPE OneView licenses available to the appliance to enable environmental management features on the resource.
LicenseRequirement
required

Values

`None` No missing requirements `OneView` HPE OneView license is required for history data access `iLOAdvanced`

iLO Advanced license is required for history data

`powerCapType` The type of power capping supported by this device. PowerCapType

Values `Electrical` Electrical power cap `None` No power cap `Thermal` Thermal power cap

`powerHistorySupported`
Resource supports monitoring and retrieval of power consumption history data. Lack of power consumption history also implies that the calibratedMaxPower cannot be automatically calculated.
Boolean

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

required

psuList The list of configuration data for each power supply of the device. array of PsuConfigurationData

capacity The size of the power supply in Watts. integer

inputVoltage The line voltage (input) to the power supply (sampled or nominal). integer

powerType The type of input power (AC or DC) of the power supply. PowerSupplyType

Values `AC` AC power supply `DC` DC power supply `Unknown` Unknown power supply type

psuId A small integer identifying the slot or bay number of the power supply starting at one (1). integer

side
The logical power delivery grouping of the power supply. In a known non-redundant configuration, all power supplies should be considered on side A. In a known AC-redundant configuration, the 2 sets of redundant power supplies should be identified as side A/B groupings. For an AC_REDUNDANT C-Class Blade System slot 1,2,3 is on Side B (right from the front), and 4,5,6 are on Side A (left from the front). If there is no inherent side-ness, then the side will be Dynamic.
PowerSupplySide

Values `A` A connection side `B` B connection side `Dynamic` Dynamic `Unspecified` Unspecified connection side

rackId The GUID of the containing rack if available; otherwise null. string

rackName The rack name associated to this device (null for unspecified). string

relativeOrder
The relative order of a resource in a Rack when slot information cannot be discovered and is not yet configured. This information is derived from the management link cable connections in a Blade System enclosure. The values increase from top to bottom, the lowest number (one at top of rack) to highest number (bottom of rack). A value of -1 indicates unspecified.
integer
required

thermalHistorySupported Resource supports ambient temperature history reporting. Boolean
required

uSlot The top-u-slot number of the device in the associated rack if available; -1 otherwise. integer

utilizationHistorySupported Resource supports CPU utilization history. Boolean
required

GET /rest/server-hardware/{id}/firmware

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Get the firmware inventory of a server

Import the server defined by <AddBladeServer>:

Request

```
GET  https://{appl}/rest/server-hardware/{id}/firmware

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body ServerFirmwareInventory

`category` Identifies the resource type string
read only

`components` Firmware details for each component of the server array of FirmwareInventoryComponent

`componentDescription` Description of the firmware component string

`componentKey` Key of the firmware component string

`componentLocation` Location of the corresponding device like a slot string

`componentName` Name of the firmware component string

`componentVersion` Installed version of the firmware component string

`created` Date and time when the resource was created timestamp

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

eTag Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource string
read only

modified Date and time when the resource was last modified timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

serverFirmwareSettings The firmware settings of the server hardware. any type

serverHardwareUri URI of the server hardware. string

serverModel Model of the server string

serverName Name of the server string

serverSettings The server settings and state of these settings on the server hardware. ServerSettings

firmwareAndDriversInstallState The current installation status details of the firmware and/or OS drivers on the server.
FirmwareAndDriversInstallState
read only

installState The installation state information of the firmware and/or OS drivers on the server. InstallState
read only

Values

`ActivateFailed` Indicates activation of one or more smart components failed on the server. `Activated`

Indicates all the smart components from the Service Pack specified in the firmware and driver baseline settings are installed and activated on the server.

`Activating` Indicates Smart Update Tool is activating the installed smart components. `InstallFailed`

Indicates Smart Update Tool has failed installing one or more smart components. `InstalledPendingReboot`

Indicates Smart Update Tool has completed installing the smart components, however the server needs to be rebooted for the updates to take effect.

`Installing` Indicates Smart Update Tool is installing the smart components from the staged location. `Pending`

Indicates the firmware and/or OS driver baseline settings have been applied to the server hardware and will take effect when Smart Update Tool updates firmware and/or OS driver components based on these settings.

`PendingExternalAction`

Indicates another utility (E.g. OneView plug-in) is orchestrating the update and action external to OneView is needed to complete the update. Refer to the external utility for details to complete the update.

`SPPBootFailed` Indicates that the server did not boot into the Service Pack ISO image. The user needs to follow the resolution mentioned in the failed task.

`ScheduleDelayed`

Indicates that Smart Update Tools was not able to schedule it to the specified schedule date and time and has proposed a new schedule. User should review the new schedule in the profile and can choose to continue with the new schedule or can reschedule it to a new date and time.

`ScheduleFailed` The schedule operation has failed. The user needs to follow the resolution mentioned in the failed task. `Scheduled`

A firmware update has been scheduled successfully. `StageFailed`

Indicates Smart Update Tool has failed to stage the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings. `Staged`

Indicates Smart Update Tool has completed staging the smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Staging`

Indicates Smart Update Tool is staging the firmware and/or OS driver smart components from the Service Pack specified in the firmware and/or OS driver baseline settings.

`Uninitialized` Indicates the current firmware and/or OS driver settings have been cleared. No components will be updated on the server. `Unknown`

Indicates the server failed to return the current settings, therefore, the actual values might not be current.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

installedStateTimestamp The timestamp information indicating the time when the install state value got updated. string
read only

fwSettingsMessageID The firmware settings message ID. string
read only

hpSmartUpdateToolStatus The status of Smart Update Tools installed on the server. HpSmartUpdateToolStatus
read only

installState Smart Update Tool's installed state on the server indicating whether it is installed, not installed or unknown. HpSUTInstallState
read only

Values

`Installed` The tool is installed on the server. `NotInstalled` The tool is not installed on the server. `Unknown` The tool installation status is not known.

lastOperationTime The timestamp indicating when Smart Update Tool was active or running a firmware update operation. string
read only

mode The current run mode configured for Smart Update Tool installed on the server. string
read only

serviceState The state of the Smart Update Tool Service running on the server operating system. string
read only

version The current version of the Smart Update Tool installed on the server. string
read only

state State of the server firmware inventory:whether completely collected or partially collected Server Firmware Inventory State

Values

`Failed` Indicates that the server firmware inventory collection failed. `Invalid` Indicates that the server firmware inventory collection has invalid characters

`Supported` Indicates that the server firmware inventory collection is supported. `Unsupported`

Indicates that the server firmware inventory collection is unsupported.

type Uniquely identifies the type of the JSON object string
read only

Default server-hardware-firmware-1

uri The canonical URI of the resource string
read only

GET /rest/server-hardware/{id}/firmware/settings

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Performs get operation on the firmware settings for the given server.

Information describing firmware settings of the provided server is obtained.

Request

```
GET  https://{appl}/rest/server-hardware/{id}/firmware/settings

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body any type

PATCH **/rest/server-hardware/{id}/firmware/settings**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Performs a specific patch operation on the firmware settings for the given server. If the server supports the particular operation, the operation is performed and a response is returned to the caller with the results. This PATCH call also allows you to perform inventory based firmware update of the servers. This feature is not supported for HPE Synergy and HPE Superdome Flex servers.

Supported patch operations and parameters:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Description	Operation	Value
Perform Offline firmware update on a physical server	replace	{"baselineUri":"/rest/firmware-drivers/baselineuri", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"}
Perform Offline firmware update on a physical server with Force	replace	{"baselineUri":"/rest/firmware-drivers/baselineuri", "forceApplyFirmware":"true", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"}
Perform Online firmware update on a physical server	replace	{"baselineUri":"/rest/firmware-drivers/baselineuri", "firmwareInstallType":"FirmwareOnly", "installationPolicy":"LowerThanBaseline"}
Perform Stage operation during Online firmware update on a physical server	replace	{"baselineUri":"/rest/firmware-drivers/baselineuri", "firmwareInstallType":"FirmwareOnly", "installationPolicy":"LowerThanBaseline", "firmwareInstallAction":"Stage"}
Perform Activate operation during Online firmware update on a physical server	replace	{"firmwareInstallAction":"Activate"}
Perform Offline inventory based firmware update on a physical server	replace	{"baselineUri":"/rest/updates/updatesUri", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"}
Perform Online inventory based firmware update on a physical server	replace	{"baselineUri":"/rest/updates/updatesUri", "firmwareInstallType":"FirmwareOnly", "installationPolicy":"LowerThanBaseline"}
Perform Offline inventory based firmware update on a physical server using the specified patch version	replace	{"baselineUri":"/rest/updates/updatesUri", "patchLevel":"2023.03.00.02","firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"}

Value name	Value description
baselineUri	URI of the baseline or the update to be applied
forceApplyFirmware	Force installation of firmware even if same or newer version is installed. Downgrading the firmware can result in the installation of unsupported firmware and cause server hardware to cease operation. Value can be 'true' or 'false'.

firmwareInstallType	Specifies the way a firmware baseline is installed. Supported values are listed below
	`FirmwareAndOSDrivers`
	Updates the firmware and OS drivers without powering down the server hardware using Smart Update Tool.
	`FirmwareOnly`
	Updates the firmware without powering down the server hardware using Smart Update Tool.
	`FirmwareOnlyOfflineMode`
	Manages the firmware through HPE OneView. Selecting this option requires the server hardware to be powered down.

installationPolicy	The policy based on which compliance is generated. Supported values are listed below
	`LowerThanBaseline`
	Version matching and above the baseline are compliant.
	`NotEqualToBaseline`
	Versions exactly matching the baseline are compliant.

firmwareInstallAction	Specifies if the firmware update operation should initiate the staging and activation of components as one operation or allows to perform staging and activation as separate steps. Performing staging and activation as separate steps is only supported for online firmware updates. Supported values are listed below
	`Stage`
	Stage the components on the iLO for activation later.
	`Activate`
	Initiate the installation and activation process for the components that were previously staged.
	`Update`
	Initiate both staging and activation of components as a single operation. This is the default option and behavior.

patchLevel	Specifies the patc

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

optional parameter. If the parameter is provided then the given version is used. The baseline version is used by default if the parameter is not provided.

Stage firmware to server hardware online for later activation:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/firmware-drivers/{fwBaselineId}",
      "firmwareInstallType":"FirmwareOnly", "installationPolicy":"LowerThanBaseline", "firmwareInstallAction: "Stage"} }
]
```

Activate firmware on server hardware via an online update:

The activate operation does not require any additional parameters as it will use the same settings specified during the prior stage operation. However, if you specified a force reinstallation (e.g. forceApplyFirmware=true) during the stage operation to ensure all the components were staged, you also must specify it during the activate operation to ensure all components are reinstalled.

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"firmwareInstallAction: "Activate"} }
]
```

Perform Online firmware and drivers update on a physical server:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/firmware-drivers/baselineuri",
      "firmwareInstallType":"FirmwareAndOSDrivers", "installationPolicy":"LowerThanBaseline", "firmwareInstallAction":"Update"} }
]
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Or

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/firmware-drivers/baselineuri",
      "firmwareInstallType":"FirmwareAndOSDrivers", "installationPolicy":"LowerThanBaseline"} }
]
```

Perform Offline firmware update on a physical server:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/firmware-drivers/baselineuri",
      "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"} }
]
```

Perform Offline firmware update on a physical server with Force:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/firmware-drivers/baselineuri",
      "forceApplyFirmware":"true", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"} }
]
```

Perform Offline inventory based firmware update on a physical server with Force:

Request

```
PATCH  https://{appl}/rest/serve
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/updates/updatesUri",
      "forceApplyFirmware":"true", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"} }
]
```

Perform Online inventory based firmware and drivers update on a physical server:

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/updates/updatesUri",
      "firmwareInstallType":"FirmwareAndOSDrivers", "installationPolicy":"LowerThanBaseline", "firmwareInstallAction":"Update"} }
]
```

Perform Offline inventory based firmware update on a physical server with Force using the specified patch version (2023.03.00.02):

Request

```
PATCH  https://{appl}/rest/server-hardware/{id}/firmware/settings

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
[
    { "op": "replace", "value": {"baselineUri":"/rest/updates/updatesUri", "patchLevel":"2023.03.00.02",
      "forceApplyFirmware":"true", "firmwareInstallType":"FirmwareOnlyOfflineMode", "installationPolicy":"LowerThanBaseline"} }
]
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. In addition, if the permission is scoped, the target resource URI(s) must be in the permission scope.

Action `Update`

Category `server-hardware`

Scoped By `uri`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`
The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json-patch+json

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

`Location` The URI of the newly-created resource or a task created to perform the requested action. string

Request Body array of PATCH Operation

`from` The JSON path to use as the source of a "move" or "copy" operation. Not used by "add", "remove", "replace", or "test". string
read only

`op` The type of operation: one of "add", "copy", "move", "remove", "replace", or "test". string
read only

Default Operation

`path` The JSON path the operation is to use. The exact meaning depends on the type of operation. string
required

`value`
The value to add or replace for "add" and "replace" operations, or the value to compare against for a "test" operation. Not used by "copy", "move", or "remove".
any type
read only

GET /rest/server-hardware/{id}/firmwareInventory

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the firmware inventory resource for the server.

Firmware inventory resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/firmwareInventory

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the firmware inventory data based on the following schema:

Response

```
{
    "Manufacturer": {
      "description": "The manufacturer or producer of this software.",
      "longDescription": "This property shall represent the name of the manufacturer or producer of this software.",
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Name": {
      "description": "The name of the resource or array element.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "Oem": {
      "additionalProperties": true,
      "properties": {
        "Hpe": {
          "DeviceClass": {
            "description": "DeviceType GUID rendered by iLO for certain items iLO knows how to flash, and omitted for all other items.",
            "pattern": "([0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12})",
            "readonly": true,
            "type": [
              "string",
              "null"
            ]
          },
          "DeviceContext": {
            "description": "Friendly text string - same as 'Location' in fw inventory - omitted if not available.",
            "readonly": true,
            "type": "string"
          },
          "DeviceInstance": {
            "description": "UEFI Device Path if a PCI Device - omitted otherwise.",
            "readonly": true,
            "type": "string"
          },
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "Targets": {
          "description": "An array of possible target GUIDs (basically iLO makes educated guesses).  A client can match any one of these to a GUID
          "items": {
            "description": "A GUID indicating iLO's knowledge of a possible correlation GUIDs vs. components.",
            "pattern": "([0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12})",
            "type": [
              "string",
              "null"
            ]
          },
          "type": "array"
        }
      },
      "required": [
        "DeviceClass"
      ],
    },
    "type": "object"
  },
  "RelatedItem": {
    "description": "The IDs of the Resources associated with this software inventory item.",
    "items": {
      "properties": {
        "@odata.id": {
          "format": "uri-reference",
          "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in th
          "readonly": true,
          "type": "string"
        }
      },
      "type": "object"
    },
    "longDescription": "This property shall contain an array of IDs for pointers consistent with JSON Pointer syntax to the Resource that is assoc
    "readonly": true,
    "type": "array"
  },
  "RelatedItem@odata.count": {
    "description": "The number of items in a collection.",
    "longDescription": "The value of this property shall be an integer representing the number of items in a collection.",
    "readonly": true,
    "type": "number"
  },
  "SoftwareId": {
    "description": "The implementation-specific label that identifies this software.",
    "longDescription": "This property shall represent an implementation-specific label that identifies this software.  This string correlates with
    "readonly": true,
    "type": "string"
  },
  "Status": {
    "properties": {
      "Health": {
        "description": "This represents the health state of this resource in the absence of its dependent resources.",
        "enum": [
          null,
          "OK",
          "Warning",
          "Critical"
        ],
        "enumDescriptions": {
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condit
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
      },
      "longDescription": "This property shall represent the HealthState of the resource without considering its dependent resources. The values
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "HealthRollup": {
      "description": "This represents the overall health state from the view of this resource.",
      "enum": [
        null,
        "OK",
        "Warning",
        "Critical"
      ],
      "enumDescriptions": {
        "Critical": "A critical condition exists that requires immediate attention",
        "OK": "Normal",
        "Warning": "A condition exists that requires attention"
      },
      "longDescription": "This property shall represent the HealthState of the resource and its dependent resources.  The values shall conform t
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "State": {
      "description": "This indicates the known state of the resource, such as if it is enabled.",
      "enum": [
        null,
        "Enabled",
        "Disabled",
        "StandbyOffline",
        "StandbySpare",
        "InTest",
        "Starting",
        "Absent",
        "UnavailableOffline",
        "Deferring",
        "Quiesced",
        "Updating"
      ],
      "enumDescriptions": {
        "Absent": "This function or resource is not present or not detected.",
        "Deferring": "The element will not process any commands but will queue new requests.",
        "Disabled": "This function or resource has been disabled.",
        "Enabled": "This function or resource has been enabled.",
        "InTest": "This function or resource is undergoing testing.",
        "Quiesced": "The element is enabled but only processes a restricted set of commands.",
        "StandbyOffline": "This function or resource is enabled, but awaiting an external action to activate it.",
        "StandbySpare": "This function or resource is part of a redundancy set and is awaiting a failover or other external action to activate i
        "Starting": "This function or resource is starting.",
        "UnavailableOffline": "This function or resource is present but cannot be used.",
        "Updating": "The element is updating and may be unavailable or degraded."
      },
      "longDescription": "This property shall represent if this component is available or not and why.  Enabled indicates the resource is availa
      "readonly": true,
      "type": [
        "string",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "null"
              ]
            }
          },
          "type": "object"
        },
        "Updateable": {
          "description": "This is true if the item is updatable.",
          "readonly": true,
          "type": [
            "boolean",
            "null"
          ]
        },
        "Version": {
          "description": "same as 'VersionString' in existing FwSwVersionInventory",
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        }
      }
    }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET /rest/server-hardware/{id}/iloSsoUrl

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Retrieves the URL to launch a Single Sign-On (SSO) session for the iLO web interface. If the server hardware is unsupported, the resulting URL will not use SSO and the iLO web interface will prompt for credentials.

Retrieve the URL to launch a Single Sign-On (SSO) session for the iLO web interface:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/iloSsoUrl

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Query Parameters

`ip` IP address or host name of the server's iLO management processor (optional). string

Response Body IloSsoUrlResult

`iloSsoUrl` URL to launch a Single Sign-On (SSO) session for the iLO web interface. string
required

GET /rest/server-hardware/{id}/javaRemoteConsoleUrl

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Generates a Single Sign-On (SSO) session for the iLO Java Applet console and returns the URL to launch it. If the server hardware is unmanaged or unsupported, the resulting URL will not use SSO and the iLO Java Applet will prompt for credentials.

Generate a Single Sign-On (SSO) session for the iLO Java Applet console and return the URL to launch it:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/javaRemoteConsoleUrl

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Update`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Query Parameters

`ip` IP address or host name of the server's iLO management processor (optional). string

Response Body JavaRemoteConsoleUrlResult

`javaRemoteConsoleUrl` URL to launch a java remote console session for the iLO web interface. string
required

GET /rest/server-hardware/{id}/localStorage

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the local storage resource for the server, including storage controllers, storage enclosures, physical drives, and logical drives.

...

GET **/rest/server-hardware/{id}/localStorageV2**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the updated version 2 local storage resource for the server, including storage controllers, drives, and volumes. Starting with Gen 10 Plus, certain storage adapters will provide
Flex server types, storage inventory will be provided with /localStorageV2 instead of /localStorage.

Local storage v2 resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/localStorageV2

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the storage data based on the following schema:

Response

```
{
    "Drives": {
        "description": "Array of physical drives attached to this controller.",
        "items": {
            "properties": {
                "BlockSizeBytes": {
                    "description": "The size of the smallest addressable unit (block) of this drive in bytes.",
                    "type": ["integer", "null"]
                },
                "CapableSpeedGbs": {
                    "description": "The speed which this drive can communicate to a storage controller in ideal conditions in Gigabits per second.",
                    "type": ["integer", "null"]
                },
                "CapacityBytes": {
                    "description": "The size in bytes of this drive.",
                    "type": ["integer", "null"]
                },
                "FailurePredicted": {
                    "description": "Is this drive currently predicting a failure in the near future.",
                    "type": ["boolean", "null"]
                },
                "Id": {
                    "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
                    "type": "string"
                },
                "Identifiers": {
                    "description": "The durable names for the drive.",
                    "items": {
                        "properties": {
                            "DurableName": {
                                "description": "The world-wide, persistent name of the resource.",
                                "type": ["string", "null"]
                            },
                            "DurableNameFormat": {
                                "description": "The format of the durable name property.",
                                "type": ["string", "null"]
                            }
                        },
```

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "type": "object"
        },
        "type": "array"
    },
    "IndicatorLED": {
        "description": "The state of the indicator LED.",
        "enum": [
            "Lit",
            "Blinking",
            "Off"
        ],
        "enumDescriptions": {
            "Blinking": "The indicator LED is blinking.",
            "Lit": "The indicator LED is lit.",
            "Off": "The indicator LED is off."
        },
        "type": ["string", "null"]
    },
    "Location": {
        "items": {
            "description": "The location of the drive",
            "properties": {
                "Info": {
                    "description": "This indicates the location of the resource.",
                    "type": ["string", "null"]
                },
                "InfoFormat": {
                    "description": "This represents the format of the info property.",
                    "enum": [
                        "Box:Bay",
                        "BayNumber",
                        "Slot"
                    ],
                    "enumDescriptions": {
                        "BayNumber": "The info is the bay number of the drive.",
                        "Box:Bay": "The info is the box and bay number of the drive.",
                        "Slot": "The info is the PCIe slot of the drive (eg: NVMe drives)."
                    },
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        },
        "type": "array"
    },
    "Links": {
        "description": "The links to other resources that are related to this resource.",
        "properties": {
            "Chassis": {
                "description": "The link to the enclosure that contains this drive.",
                "type": ["array", "null"]
            },
            "Volumes": {
                "description": "An array of links to the volumes that this drive either wholly or only partially contains.",
                "type": ["array", "null"]
            }
        },
        "type": "object"
    },
    "Manufacturer": {
        "description": "This is the manufacturer of this drive.",
        "type": ["st
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
},
"MediaType": {
    "description": "The type of media contained in this drive.",
    "enum": [
        "HDD",
        "SSD"
    ],
    "enumDescriptions": {
        "HDD": "The drive media type is traditional magnetic platters",
        "SSD": "The drive media type is solid state or flash memory"
    },
    "type": ["string", "null"]
},
"Model": {
    "description": "This is the model number for the drive.",
    "type": ["string", "null"]
},
"Name": {
    "description": "The name of the Resource or array member.",
    "type": "string"
},
"NegotiatedSpeedGbs": {
    "description": "The speed which this drive is currently communicating to the storage controller in Gigabits per second",
    "type": ["integer", "null"]
},
"PartNumber": {
    "description": "The part number for this drive.",
    "type": ["string", "null"]
},
"PhysicalLocation": {
    "description": "The location of the drive.",
    "properties": {
        "PartLocation": {
            "description": "The part location within the placement.",
            "properties": {
                "LocationOrdinalValue": {
                    "description": "The number that represents the location of the part. If LocationType is 'slot' and this unit is
                    "type": ["integer", "null"]
                },
                "LocationType": {
                    "description": "The type of location of the part, such as slot, bay, socket and slot.",
                    "enum": [
                        "Slot",
                        "Bay",
                        "Connector",
                        "Socket"
                    ],
                    "enumDescriptions": {
                        "Bay": "The bay as the type of location.",
                        "Connector": "The connector as the type of location.",
                        "Slot": "The slot as the type of location.",
                        "Socket": "The socket as the type of location."
                    },
                    "type": ["string", "null"]
                },
                "ServiceLabel": {
                    "description": "The label of the part location, such as a silk-screened name or a printed label.",
                    "type": ["string", "null"]
                }
            },
            "typ
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    }
                },
                "type": "object"
            },
            "PredictedMediaLifeLeftPercent": {
                "description": "The percentage of reads and writes that are predicted to still be available for the media",
                "type": ["integer", "null"]
            },
            "Protocol": {
                "description": "The protocol this drive is using to communicate to the storage controller",
                "enum": [
                    "NVMe",
                    "SATA",
                    "USB"
                ],
                "enumDescriptions": {
                    "NVMe": "Non-Volatile Memory Express",
                    "SATA": "Serial AT Attachment",
                    "USB": "Universal Serial Bus"
                },
                "type": ["string", "null"]
            },
            "Revision": {
                "description": "The revision of this drive",
                "type": ["string", "null"]
            },
            "RotationSpeedRPM": {
                "description": "The rotation speed of this drive in revolutions per minute (RPM)",
                "minimum": 0,
                "type": ["integer", "null"]
            },
            "SerialNumber": {
                "description": "Serial number of the drive.",
                "type": ["string", "null"]
            },
            "Status": {
                "description": "The status and health of a resource and its children.",
                "properties": {
                    "Health": {
                        "description": "This represents the health state of this resource.",
                        "type": "string"
                    },
                    "State": {
                        "description": "This indicates the known state of the resource.",
                        "type": "string"
                    }
                },
                "type": "object"
            },
            "@odata.etag": {
                "description": "The current ETag of the drive resource. Currently this is applicable only for Superdome Flex server type.",
                "type": ["string", "null"]
            }
        }
    },
    "type": "array"
},
"Drives@odata.count": {
    "description": "This indicates the number of drives in the storage. Currently this is applicable only for Superdome Flex server type.",
    "type": "integer"
},
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "Location": {
                "description": "This indicates the chassis id for this drive resource. Currently this is applicable only for Superdome Flex server type.",
                "type": "string"
            },
            "Enclosures": {
                "description": "The physical sheet-metal confined enclosures containing or attached to this controller.",
                "items": {
                    "properties": {
                        "AssetTag": {
                            "description": "The user-assigned asset tag of this enclosure for inventory purposes.",
                            "type": ["string", "null"]
                        },
                        "ChassisType": {
                            "description": "The type of physical form factor of the chassis.",
                            "enum": [
                                "Rack",
                                "Blade",
                                "Enclosure",
                                "StandAlone",
                                "RackMount",
                                "Card",
                                "Cartridge",
                                "Row",
                                "Pod",
                                "Expansion",
                                "Sidecar",
                                "Zone",
                                "Sled",
                                "Shelf",
                                "Drawer",
                                "Module",
                                "Component",
                                "IPBasedDrive",
                                "RackGroup",
                                "StorageEnclosure",
                                "Other"
                            ],
                            "enumDescriptions": {
                                "Blade": "An enclosed or semi-enclosed, typically vertically-oriented, system chassis that must be plugged into a multi-syst
                                "Card": "A loose device or circuit board intended to be installed in a system or other enclosure.",
                                "Cartridge": "A small self-contained system intended to be plugged into a multi-system chassis.",
                                "Component": "A small chassis, card, or device that contains devices for a particular subsystem or function.",
                                "Drawer": "An enclosed or semi-enclosed, typically horizontally-oriented, system chassis that may be slid into a multi-syste
                                "Enclosure": "A generic term for a chassis that does not fit any other description.",
                                "Expansion": "A chassis that expands the capabilities or capacity of another chassis.",
                                "IPBasedDrive": "A chassis in a drive form factor with IP-based network connections.",
                                "Module": "A small, typically removable, chassis or card that contains devices for a particular subsystem or function.",
                                "Other": "A chassis that does not fit any of these definitions.",
                                "Pod": "A collection of equipment racks in a large, likely transportable, container.",
                                "Rack": "An equipment rack, typically a 19-inch wide freestanding unit.",
                                "RackGroup": "A group of racks that form a single entity or share infrastructure.",
                                "RackMount": "A single-system chassis designed specifically for mounting in an equipment rack.",
                                "Row": "A collection of equipment racks.",
                                "Shelf": "An enclosed or semi-enclosed, typically horizontally-oriented, system chassis that must be plugged into a multi-sy
                                "Sidecar": "A chassis that mates mechanically with another chassis to expand its capabilities or capacity.",
                                "Sled": "An enclosed or semi-enclosed, system chassis that must be plugged into a multi-system chassis to function normally
                                "StandAlone": "A single, free-standing system, commonly called a tower or desktop chassis.",
                                "StorageEnclosure": "A chassis that encloses storage.",
                                "Zone": "A logical division or portion of a physical chassis that contains multiple devices or systems that cannot be physic
                            },
                            "type": "string"
                        },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
},
"Description": {
    "description": "The description of this resource.",
    "type": ["string", "null"]
},
"Id": {
    "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
    "type": "string"
},
"IndicatorLED": {
    "description": "The state of the indicator LED, which identifies the enclosure.",
    "enum": [
        "Unknown",
        "Lit",
        "Blinking",
        "Off"
    ],
    "enumDescriptions": {
        "Blinking": "The indicator LED is blinking.",
        "Lit": "The indicator LED is lit.",
        "Off": "The indicator LED is off.",
        "Unknown": "The state of the indicator LED cannot be determined."
    },
    "type": ["string", "null"]
},
"Links": {
    "description": "The links to other resources that are related to this resource.",
    "properties": {
        "Drives": {
            "description": "An array of links to the drives located in this enclosure.",
            "type": ["array", "null"]
        }
    },
    "type": "object"
},
"Location": {
    "description": "The location of the enclosure.",
    "Placement": {
        "description": "The placement within the addressed location.",
        "properties": {
            "AdditionalInfo": {
                "description": "Area designation or other additional info.",
                "type": ["string", "null"]
            },
            "Rack": {
                "description": "The name of a rack location within a row.",
                "type": ["string", "null"]
            },
            "RackOffset": {
                "description": "The vertical location of the item, in terms of RackOffsetUnits.",
                "type": ["integer", "null"]
            },
            "RackOffsetUnits": {
                "description": "The type of rack unit in use.",
                "enum": [
                    "OpenU",
                    "EIA_310"
                ],
                "enumDescriptions": {
                    "EIA_310": "A rack unit that is equal to 1.75 in (44.45 mm).",
                    "OpenU": "A rack unit that is equal to 48 mm (1.89 in)."
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "type": ["string", "null"]
            },
            "Row": {
                "description": "The name of the row.",
                "type": ["string", "null"]
            }
        },
        "type": "object"
    }
    "type": ["object", "null"]
},
"Manufacturer": {
    "description": "The manufacturer of this enclosure.",
    "type": ["string", "null"]
},
"Model": {
    "description": "The model number of the enclosure.",
    "type": ["string", "null"]
},
"Name": {
    "description": "The name of the resource.",
    "type": "string"
},
"PartNumber": {
    "description": "The part number of the enclosure.",
    "type": ["string", "null"]
},
"PowerState": {
    "enum": [
        "On",
        "Off",
        "PoweringOn",
        "PoweringOff"
    ],
    "enumDescriptions": {
        "Off": "The components within the enclosure have no power. Some components may continue to have AUX power.",
        "On": "The components within the enclosure have power.",
        "PoweringOff": "A temporary state between on and off.",
        "PoweringOn": "A temporary state between off and on."
    },
    "type": ["string", "null"]
},
"SKU": {
    "description": "The SKU of the enclosure.",
    "type": ["string", "null"]
},
"SerialNumber": {
    "description": "The serial number of the enclosure.",
    "type": ["string", "null"]
},
"Status": {
    "description": "The status and health of a resource and its children.",
    "properties": {
        "Health": {
            "description": "This represents the health state of this resource.",
            "type": "string"
        },
        "State": {
            "description": "This indicates the known state of the resource.",
            "type": "string"
        }
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    },
                    "type": "object"
                }
            },
            "type": "object"
        },
        "type": "array"
    },
    "Id": {
        "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
        "type": "string"
    },
    "Name": {
        "description": "The name of the Resource or array member.",
        "type": "string"
    },
    "Status": {
        "description": "The status and health of a Resource and its children.",
        "properties": {
            "Health": {
                "description": "This represents the health state of this resource.",
                "type": "string"
            },
            "State": {
                "description": "This indicates the known state of the resource.",
                "type": "string"
            }
        },
        "type": "object"
    },
    "Controllers": {
        "description": "Properties related to this storage controller.",
        "items": {
            "properties": {
                "CacheSummary": {
                    "description": "The cache memory of the storage controller in general detail.",
                    "properties": {
                        "PersistentCacheSizeMiB": {
                            "description": "The portion of the cache memory that is persistent, measured in MiB.",
                            "type": ["integer", "null"]
                        },
                        "Status": {
                            "description": "The status and health of a Resource and its children.",
                            "properties": {
                                "Health": {
                                    "description": "This represents the health state of this resource.",
                                    "type": "string"
                                },
                                "State": {
                                    "description": "This indicates the known state of the resource.",
                                    "type": "string"
                                }
                            },
                            "type": "object"
                        },
                        "TotalCacheSizeMiB": {
                            "description": "The total configured cache memory, measured in MiB.",
                            "type": ["integer", "null"],
                            "units": "MiBy"
                        }
                    },
                    "type": "object"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "type": "object"
    },
    "ControllerRates": {
        "description": "This property describes the various controller rates used for processes such as Volume Rebuild or Consistency Ch
        "properties": {
            "ConsistencyCheckRatePercent": {
                "description": "The percentage of controller resources used for performing a data consistency check on volumes.",
                "type": ["integer", "null"]
            },
            "RebuildRatePercent": {
                "description": "The percentage of controller Resources used for rebuilding/repairing volumes.",
                "type": ["integer", "null"]
            },
            "TransformationRatePercent": {
                "description": "The percentage of controller Resources used for transforming volumes from one configuration to another."
                "type": ["integer", "null"]
            }
        },
        "type": "object"
    },
    "FirmwareVersion": {
        "description": "The firmware version of this storage controller.",
        "type": ["string", "null"]
    },
    "Identifiers": {
        "description": "The durable names for the storage controller.",
        "items": {
            "properties": {
                "DurableName": {
                    "description": "The world-wide, persistent name of the resource.",
                    "type": ["string", "null"]
                },
                "DurableNameFormat": {
                    "description": "The format of the durable name property.",
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        },
        "type": "array"
    },
    "Location": {
        "description": "The location of the storage controller.",
        "properties": {
            "PartLocation": {
                "description": "The part location within the placement.",
                "properties": {
                    "LocationOrdinalValue": {
                        "description": "The number that represents the location of the part. If LocationType is 'slot' and this unit is
                        "type": ["integer", "null"]
                    },
                    "LocationType": {
                        "description": "The type of location of the part, such as slot, bay, socket and slot.",
                        "enum": [
                            "Slot",
                            "Bay",
                            "Connector",
                            "Socket"
                        ],
                        "enumDescriptions": {
                            "Bay": "The bay as the type of location.",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    "Slot": "The slot as the type of location.",
                    "Socket": "The socket as the type of location."
                },
                "type": ["string", "null"]
            },
            "ServiceLabel": {
                "description": "The label of the part location, such as a silk-screened name or a printed label.",
                "type": ["string", "null"]
            }
        },
        "type": "object"
    }
},
"type": "object"
},
"Manufacturer": {
    "description": "The manufacturer of this storage controller.",
    "type": ["string", "null"]
},
"MemberId": {
    "description": "The identifier for the member within the collection.",
    "type": "string"
},
"Model": {
    "description": "The model number for the storage controller.",
    "type": ["string", "null"]
},
"Name": {
    "description": "The name of the resource or array member.",
    "type": "string"
},
"PCIeInterface": {
    "description": "The PCIe interface details for this controller.",
    "properties": {
        "LanesInUse": {
            "description": "This is the number of PCIe lanes in use by this device.",
            "type": ["integer", "null"]
        },
        "MaxLanes": {
            "description": "This is the number of PCIe lanes supported by this device.",
            "type": ["integer", "null"]
        },
        "MaxPCIeType": {
            "description": "The highest version of the PCIe specification supported by this device.",
            "enum": [
                "Gen1",
                "Gen2",
                "Gen3",
                "Gen4",
                "Gen5"
            ],
            "enumDescriptions": {
                "Gen1": "A PCIe v1.0 slot.",
                "Gen2": "A PCIe v2.0 slot.",
                "Gen3": "A PCIe v3.0 slot.",
                "Gen4": "A PCIe v4.0 slot.",
                "Gen5": "A PCIe v5.0 slot."
            },
            "type": "string"
        },
        "PCIeTyp
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "description": "The version of the PCIe specification in use by this device.",
                "enum": [
                    "Gen1",
                    "Gen2",
                    "Gen3",
                    "Gen4",
                    "Gen5"
                ],
                "enumDescriptions": {
                    "Gen1": "A PCIe v1.0 slot.",
                    "Gen2": "A PCIe v2.0 slot.",
                    "Gen3": "A PCIe v3.0 slot.",
                    "Gen4": "A PCIe v4.0 slot.",
                    "Gen5": "A PCIe v5.0 slot."
                },
                "type": "string"
            }
        },
        "type": "object"
    },
    "PartNumber": {
        "description": "The part number for this storage controller.",
        "type": ["string", "null"]
    },
    "Ports": {
        "description": "Array of ports that exist on the storage controller.",
        "items": {
            "properties": {
                "CurrentSpeedGbps": {
                    "description": "The current speed of this port.",
                    "type": ["number", "null"],
                    "units": "Gbit/s"
                },
                "Id": {
                    "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
                    "type": "string"
                },
                "Links": {
                    "description": "The links to other Resources that are related to this resource.",
                    "type": "object"
                },
                "Location": {
                    "description": "The location of the port.",
                    "properties": {
                        "PartLocation": {
                            "description": "The part location within the placement.",
                            "properties": {
                                "LocationOrdinalValue": {
                                    "description": "The number that represents the location of the part. If LocationType is 'slot' and t
                                    "type": ["integer", "null"]
                                },
                                "LocationType": {
                                    "description": "The type of location of the part, such as slot, bay, socket and slot.",
                                    "enum": [
                                        "Slot",
                                        "Bay",
                                        "Connector",
                                        "Socket"
                                    ],
                                    "enumDescriptions": {
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                        "Connector": "The connector as the type of location.",
                        "Slot": "The slot as the type of location.",
                        "Socket": "The socket as the type of location."
                    },
                    "type": ["string", "null"]
                },
                "ServiceLabel": {
                    "description": "The label of the part location, such as a silk-screened name or a printed label.",
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        }
    },
    "type": "object"
},
"MaxSpeedGbps": {
    "description": "The maximum speed of this port as currently configured.",
    "type": ["number", "null"],
    "units": "Gbit/s"
},
"Name": {
    "description": "The name of the resource or array member.",
    "type": "string"
},
"PortId": {
    "description": "The label of this port on the physical package for this port.",
    "type": ["string", "null"]
},
"PortProtocol": {
    "description": "The protocol being sent over this port.",
    "enum": [
        "PCIe",
        "SAS",
        "SATA",
        "NVMe",
        "FC",
        "FCoE",
        "USB"
    ],
    "enumDescriptions": {
        "FC": "Fibre Channel.",
        "FCoE": "Fibre Channel over Ethernet.",
        "NVMe": "Non-Volatile Memory Express.",
        "PCIe": "PCI Express.",
        "SAS": "Serial Attached SCSI.",
        "SATA": "Serial AT Attachment.",
        "USB": "Universal Serial Bus."
    },
    "type": ["string", "null"]
},
"PortType": {
    "description": "The type of this port.",
    "enum": [
        "UpstreamPort",
        "DownstreamPort",
        "InterswitchPort",
        "ManagementPort",
        "BidirectionalPort",
        "UnconfiguredPort"
    ],
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    "BidirectionalPort": "This port connects to any type of device.",
                    "DownstreamPort": "This port connects to a target device.",
                    "InterswitchPort": "This port connects to another switch.",
                    "ManagementPort": "This port connects to a switch manager.",
                    "UnconfiguredPort": "This port has not yet been configured.",
                    "UpstreamPort": "This port connects to a host device."
                },
                "type": ["string", "null"]
            },
            "Status": {
                "description": "The status and health of a resource and its children.",
                "properties": {
                    "Health": {
                        "description": "This represents the health state of this resource.",
                        "type": "string"
                    },
                    "State": {
                        "description": "This indicates the known state of the resource.",
                        "type": "string"
                    }
                },
                "type": "object"
            },
            "Width": {
                "description": "The number of lanes, phys, or other physical transport links that this port contains.",
                "type": ["integer", "null"]
            }
        },
        "type": "object"
    },
    "type": "array"
},
"SKU": {
    "description": "The SKU for this storage controller.",
    "type": ["string", "null"]
},
"SerialNumber": {
    "description": "The serial number for this storage controller.",
    "type": ["string", "null"]
},
"SpeedGbps": {
    "description": "The maximum speed of the storage controller's device interface.",
    "type": ["number", "null"],
    "units": "Gbit/s"
},
"Status": {
    "description": "The status and health of a Resource and its children.",
    "properties": {
        "Health": {
            "description": "This represents the health state of this resource.",
            "type": "string"
        },
        "State": {
            "description": "This indicates the known state of the resource.",
            "type": "string"
        }
    },
    "type": "object"
},
"SupportedControllerProtocols": {
    "description
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "items": {
                    "enum": [
                        "PCIe"
                    ],
                    "type": "string"
                },
                "type": "array"
            },
            "SupportedDeviceProtocols": {
                "description": "The protocols that the storage controller can use to communicate with attached devices.",
                "items": {
                    "enum": [
                        "USB",
                        "SATA",
                        "NVMe"
                    ],
                    "type": "string"
                },
                "type": "array"
            },
            "SupportedRAIDTypes": {
                "description": "The set of RAID types supported by the storage controller.",
                "items": {
                    "enum": [
                        "RAID0",
                        "RAID1",
                        "RAID5",
                        "RAID6",
                        "RAID10",
                        "RAID50",
                        "RAID60",
                        "RAID1Triple",
                        "RAID10Triple"
                    ],
                    "enumDescriptions": {
                        "RAID0": "There is no fault tolerance used on this logical drive",
                        "RAID1": "Two sets of duplicate data is being stored on a pair of drives",
                        "RAID5": "Fault tolerance is achieved by storing parity data across 3 or more disk drives",
                        "RAID6": "Fault tolerance is achieved by storing multiple sets parity data across 4 or more disk drives",
                        "RAID10": "Data is duplicated and striped across pairs of disk drives",
                        "RAID50": "Fault tolerance is achieved by storing parity data and striping the data across 6 or more disk drives",
                        "RAID60": "Fault tolerance is achieved by storing multiple sets parity data and striping the data across 8 or more disk
                        "RAID1Triple": "Three sets of duplicate data is being stored on a trio of drives",
                        "RAID10Triple": "Data is duplicated and striped across trios of disk drives"
                    },
                    "type": "string"
                },
                "type": "array"
            }
        },
        "type": "object"
    },
    "type": "array"
},
"StorageControllers": {
    "description": "[Deprecated] Properties related to this storage controller. This field is deprecated and replaced by the 'Controllers' objec
    "items": {
        "properties": {
            "CacheSummary": {
                "description": "The cache memory of the storage controller in general detail.",
                "properties"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "PersistentCacheSizeMiB": {
                    "description": "The portion of the cache memory that is persistent, measured in MiB.",
                    "type": ["integer", "null"]
                },
                "Status": {
                    "description": "The status and health of a Resource and its children.",
                    "properties": {
                        "Health": {
                            "description": "This represents the health state of this resource.",
                            "type": "string"
                        },
                        "State": {
                            "description": "This indicates the known state of the resource.",
                            "type": "string"
                        }
                    },
                    "type": "object"
                },
                "TotalCacheSizeMiB": {
                    "description": "The total configured cache memory, measured in MiB.",
                    "type": ["integer", "null"],
                    "units": "MiBy"
                }
            },
            "type": "object"
        },
        "ControllerRates": {
            "description": "This property describes the various controller rates used for processes such as Volume Rebuild or Consistency Ch
            "properties": {
                "ConsistencyCheckRatePercent": {
                    "description": "The percentage of controller resources used for performing a data consistency check on volumes.",
                    "type": ["integer", "null"]
                },
                "RebuildRatePercent": {
                    "description": "The percentage of controller Resources used for rebuilding/repairing volumes.",
                    "type": ["integer", "null"]
                },
                "TransformationRatePercent": {
                    "description": "The percentage of controller Resources used for transforming volumes from one configuration to another."
                    "type": ["integer", "null"]
                }
            },
            "type": "object"
        },
        "FirmwareVersion": {
            "description": "The firmware version of this storage controller.",
            "type": ["string", "null"]
        },
        "Identifiers": {
            "description": "The durable names for the storage controller.",
            "items": {
                "properties": {
                    "DurableName": {
                        "description": "The world-wide, persistent name of the resource.",
                        "type": ["string", "null"]
                    },
                    "DurableNameFormat": {
                        "description": "The format of the durable name property.",
                        "type": ["string", "null"]
                    }
                },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "type": "object"
        },
        "type": "array"
    },
    "Location": {
        "description": "The location of the storage controller.",
        "properties": {
            "PartLocation": {
                "description": "The part location within the placement.",
                "properties": {
                    "LocationOrdinalValue": {
                        "description": "The number that represents the location of the part. If LocationType is 'slot' and this unit is
                        "type": ["integer", "null"]
                    },
                    "LocationType": {
                        "description": "The type of location of the part, such as slot, bay, socket and slot.",
                        "enum": [
                            "Slot",
                            "Bay",
                            "Connector",
                            "Socket"
                        ],
                        "enumDescriptions": {
                            "Bay": "The bay as the type of location.",
                            "Connector": "The connector as the type of location.",
                            "Slot": "The slot as the type of location.",
                            "Socket": "The socket as the type of location."
                        },
                        "type": ["string", "null"]
                    },
                    "ServiceLabel": {
                        "description": "The label of the part location, such as a silk-screened name or a printed label.",
                        "type": ["string", "null"]
                    }
                },
                "type": "object"
            }
        },
        "type": "object"
    },
    "Manufacturer": {
        "description": "The manufacturer of this storage controller.",
        "type": ["string", "null"]
    },
    "MemberId": {
        "description": "The identifier for the member within the collection.",
        "type": "string"
    },
    "Model": {
        "description": "The model number for the storage controller.",
        "type": ["string", "null"]
    },
    "Name": {
        "description": "The name of the resource or array member.",
        "type": "string"
    },
    "PCIeInterface": {
        "description": "The PCIe interface details for this controller.",
        "properties": {
            "LanesInUse": {
                "description": "This is the number of PCIe lanes in use by this device.",
                "typ
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                },
                "MaxLanes": {
                    "description": "This is the number of PCIe lanes supported by this device.",
                    "type": ["integer", "null"]
                },
                "MaxPCIeType": {
                    "description": "The highest version of the PCIe specification supported by this device.",
                    "enum": [
                        "Gen1",
                        "Gen2",
                        "Gen3",
                        "Gen4",
                        "Gen5"
                    ],
                    "enumDescriptions": {
                        "Gen1": "A PCIe v1.0 slot.",
                        "Gen2": "A PCIe v2.0 slot.",
                        "Gen3": "A PCIe v3.0 slot.",
                        "Gen4": "A PCIe v4.0 slot.",
                        "Gen5": "A PCIe v5.0 slot."
                    },
                    "type": "string"
                },
                "PCIeType": {
                    "description": "The version of the PCIe specification in use by this device.",
                    "enum": [
                        "Gen1",
                        "Gen2",
                        "Gen3",
                        "Gen4",
                        "Gen5"
                    ],
                    "enumDescriptions": {
                        "Gen1": "A PCIe v1.0 slot.",
                        "Gen2": "A PCIe v2.0 slot.",
                        "Gen3": "A PCIe v3.0 slot.",
                        "Gen4": "A PCIe v4.0 slot.",
                        "Gen5": "A PCIe v5.0 slot."
                    },
                    "type": "string"
                }
            },
            "type": "object"
        },
        "PartNumber": {
            "description": "The part number for this storage controller.",
            "type": ["string", "null"]
        },
        "Ports": {
            "description": "Array of ports that exist on the storage controller.",
            "items": {
                "properties": {
                    "CurrentSpeedGbps": {
                        "description": "The current speed of this port.",
                        "type": ["number", "null"],
                        "units": "Gbit/s"
                    },
                    "Id": {
                        "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
                        "type": "string"
                    },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
"Links": {
    "description": "The links to other Resources that are related to this resource.",
    "type": "object"
},
"Location": {
    "description": "The location of the port.",
    "properties": {
        "PartLocation": {
            "description": "The part location within the placement.",
            "properties": {
                "LocationOrdinalValue": {
                    "description": "The number that represents the location of the part. If LocationType is 'slot' and t
                    "type": ["integer", "null"]
                },
                "LocationType": {
                    "description": "The type of location of the part, such as slot, bay, socket and slot.",
                    "enum": [
                        "Slot",
                        "Bay",
                        "Connector",
                        "Socket"
                    ],
                    "enumDescriptions": {
                        "Bay": "The bay as the type of location.",
                        "Connector": "The connector as the type of location.",
                        "Slot": "The slot as the type of location.",
                        "Socket": "The socket as the type of location."
                    },
                    "type": ["string", "null"]
                },
                "ServiceLabel": {
                    "description": "The label of the part location, such as a silk-screened name or a printed label.",
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        }
    },
    "type": "object"
},
"MaxSpeedGbps": {
    "description": "The maximum speed of this port as currently configured.",
    "type": ["number", "null"],
    "units": "Gbit/s"
},
"Name": {
    "description": "The name of the resource or array member.",
    "type": "string"
},
"PortId": {
    "description": "The label of this port on the physical package for this port.",
    "type": ["string", "null"]
},
"PortProtocol": {
    "description": "The protocol being sent over this port.",
    "enum": [
        "PCIe",
        "SAS",
        "SATA",
        "NVMe",
        "FC",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    "FCoE",
                    "USB"
                ],
                "enumDescriptions": {
                    "FC": "Fibre Channel.",
                    "FCoE": "Fibre Channel over Ethernet.",
                    "NVMe": "Non-Volatile Memory Express.",
                    "PCIe": "PCI Express.",
                    "SAS": "Serial Attached SCSI.",
                    "SATA": "Serial AT Attachment.",
                    "USB": "Universal Serial Bus."
                },
                "type": ["string", "null"]
            },
            "PortType": {
                "description": "The type of this port.",
                "enum": [
                    "UpstreamPort",
                    "DownstreamPort",
                    "InterswitchPort",
                    "ManagementPort",
                    "BidirectionalPort",
                    "UnconfiguredPort"
                ],
                "enumDescriptions": {
                    "BidirectionalPort": "This port connects to any type of device.",
                    "DownstreamPort": "This port connects to a target device.",
                    "InterswitchPort": "This port connects to another switch.",
                    "ManagementPort": "This port connects to a switch manager.",
                    "UnconfiguredPort": "This port has not yet been configured.",
                    "UpstreamPort": "This port connects to a host device."
                },
                "type": ["string", "null"]
            },
            "Status": {
                "description": "The status and health of a resource and its children.",
                "properties": {
                    "Health": {
                        "description": "This represents the health state of this resource.",
                        "type": "string"
                    },
                    "State": {
                        "description": "This indicates the known state of the resource.",
                        "type": "string"
                    }
                },
                "type": "object"
            },
            "Width": {
                "description": "The number of lanes, phys, or other physical transport links that this port contains.",
                "type": ["integer", "null"]
            }
        },
        "type": "object"
    },
    "type": "array"
},
"SKU": {
    "description": "The SKU for this storage controller.",
    "type": ["string", "null"]
},
"SerialNumber":
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "description": "The serial number for this storage controller.",
                "type": ["string", "null"]
            },
            "SpeedGbps": {
                "description": "The maximum speed of the storage controller's device interface.",
                "type": ["number", "null"],
                "units": "Gbit/s"
            },
            "Status": {
                "description": "The status and health of a Resource and its children.",
                "properties": {
                    "Health": {
                        "description": "This represents the health state of this resource.",
                        "type": "string"
                    },
                    "State": {
                        "description": "This indicates the known state of the resource.",
                        "type": "string"
                    }
                },
                "type": "object"
            },
            "SupportedControllerProtocols": {
                "description": "The supported set of protocols for communicating to this storage controller.",
                "items": {
                    "enum": [
                        "PCIe"
                    ],
                    "type": "string"
                },
                "type": "array"
            },
            "SupportedDeviceProtocols": {
                "description": "The protocols that the storage controller can use to communicate with attached devices.",
                "items": {
                    "enum": [
                        "USB",
                        "SATA",
                        "NVMe"
                    ],
                    "type": "string"
                },
                "type": "array"
            },
            "SupportedRAIDTypes": {
                "description": "The set of RAID types supported by the storage controller.",
                "items": {
                    "enum": [
                        "RAID0",
                        "RAID1",
                        "RAID5",
                        "RAID6",
                        "RAID10",
                        "RAID50",
                        "RAID60",
                        "RAID1Triple",
                        "RAID10Triple"
                    ],
                    "enumDescriptions": {
                        "RAID0": "There is no fault tolerance used on this logical drive",
                        "RAI
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                    "RAID5": "Fault tolerance is achieved by storing parity data across 3 or more disk drives",
                    "RAID6": "Fault tolerance is achieved by storing multiple sets parity data across 4 or more disk drives",
                    "RAID10": "Data is duplicated and striped across pairs of disk drives",
                    "RAID50": "Fault tolerance is achieved by storing parity data and striping the data across 6 or more disk drives",
                    "RAID60": "Fault tolerance is achieved by storing multiple sets parity data and striping the data across 8 or more disk
                    "RAID1Triple": "Three sets of duplicate data is being stored on a trio of drives",
                    "RAID10Triple": "Data is duplicated and striped across trios of disk drives"
                },
                "type": "string"
            },
            "type": "array"
        }
    },
    "type": "object"
},
"type": "array"
},
"Volumes": {
    "description": "Array of logical volumes associated with this storage system.",
    "items": {
        "properties": {
            "BlockSizeBytes": {
                "description": "The size of the smallest addressable unit (block) of this volume in bytes.",
                "type": ["integer", "null"]
            },
            "CapacityBytes": {
                "description": "The size in bytes of this volume.",
                "type": ["integer", "null"]
            },
            "DisplayName": {
                "description": "A user-configurable string to name the volume.",
                "type": ["string", "null"]
            },
            "Encrypted": {
                "description": "Is this volume encrypted.",
                "type": ["boolean", "null"]
            },
            "EncryptionTypes": {
                "description": "The types of encryption used by this volume.",
                "items": {
                    "enum": [
                        "NativeDriveEncryption",
                        "ControllerAssisted",
                        "SoftwareAssisted"
                    ],
                    "enumDescriptions": {
                        "ControllerAssisted": "The volume is being encrypted by the storage controller entity.",
                        "NativeDriveEncryption": "The volume is utilizing the native drive encryption capabilities of the drive hardware.",
                        "SoftwareAssisted": "The volume is being encrypted by software running on the system or the operating system."
                    },
                    "type": "string"
                },
                "type": "array"
            },
            "Id": {
                "description": "The identifier that uniquely identifies the resource within the collection of similar resources.",
                "type": "string"
            },
            "Identifiers": {
                "description": "The durable names for the volume.",
                "items": {
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "properties": {
                "DurableName": {
                    "description": "The world-wide, persistent name of the resource.",
                    "type": ["string", "null"]
                },
                "DurableNameFormat": {
                    "description": "The format of the durable name property.",
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        },
        "type": "array"
    },
    "Links": {
        "description": "Contains references to other resources that are related to this resource.",
        "properties": {
            "DedicatedSpareDrives": {
                "description": "An array of references to the drives which are dedicated spares for this volume.",
                "type": ["array", "null"]
            },
            "Drives": {
                "description": "An array of references to the drives which contain this volume.",
                "type": ["array", "null"]
            }
        },
        "type": "object"
    },
    "LogicalUnitNumber": {
        "description": "Indicates the host-visible LogicalUnitNumber assigned to this volume.",
        "type": ["integer", "null"]
    },
    "Name": {
        "description": "The name of the Resource or array member.",
        "type": "string"
    },
    "OptimumIOSizeBytes": {
        "description": "The size in bytes of this volume's optimum IO size.",
        "type": ["integer", "null"],
        "units": "By"
    },
    "RAIDType": {
        "description": "The RAID type of this volume.",
        "enum": [
            "RAID0",
            "RAID1",
            "RAID5",
            "RAID6",
            "RAID10",
            "RAID50",
            "RAID60",
            "RAID1Triple",
            "RAID10Triple"
        ],
        "enumDescriptions": {
            "RAID0": "There is no fault tolerance used on this logical drive",
            "RAID1": "Two sets of duplicate data is being stored on a pair of drives",
            "RAID5": "Fault tolerance is achieved by storing parity data across 3 or more disk drives",
            "RAID6": "Fault tolerance is achieved by storing multiple sets parity data across 4 or more disk drives",
            "RAID10": "Data is duplicated and striped across pairs of disk drives",
            "RAID50": "Fault tolerance is achieved by storing parity data and striping the data across 6 or more disk drives",
            "RAID60"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "RAID50": "Fault tolerance is achieved by storing multiple sets parity data and striping the data across 3 or more disk drive
            "RAID1Triple": "Three sets of duplicate data is being stored on a trio of drives",
            "RAID10Triple": "Data is duplicated and striped across trios of disk drives"
        },
        "type": ["string", "null"]
    },
    "ReadCachePolicy": {
        "description": "Indicates the read cache policy setting for the volume.",
        "enum": [
            "ReadAhead",
            "AdaptiveReadAhead",
            "Off"
        ],
        "enumDescriptions": {
            "AdaptiveReadAhead": "A caching technique in which the controller dynamically determines whether to pre-fetch data anticipat
            "Off": "The read cache is disabled.",
            "ReadAhead": "A caching technique in which the controller pre-fetches data anticipating future read requests."
        },
        "type": ["string", "null"]
    },
    "Status": {
        "description": "The status and health of a Resource and its children.",
        "properties": {
            "Health": {
                "description": "This represents the health state of this resource.",
                "type": "string"
            },
            "State": {
                "description": "This indicates the known state of the resource.",
                "type": "string"
            }
        },
        "type": "object"
    },
    "StripSizeBytes": {
        "description": "The number of blocks (bytes) in a strip in a disk array that uses striped data mapping.",
        "type": ["integer", "null"]
    },
    "VolumeType": {
        "description": "The type of this volume.",
        "enum": [
            "RawDevice",
            "NonRedundant",
            "Mirrored",
            "StripedWithParity",
            "SpannedMirrors",
            "SpannedStripesWithParity"
        ],
        "enumDescriptions": {
            "Mirrored": "The volume is a mirrored device.",
            "NonRedundant": "The volume is a non-redundant storage device.",
            "RawDevice": "The volume is a raw physical device without any RAID or other virtualization applied.",
            "SpannedMirrors": "The volume is a spanned set of mirrored devices.",
            "SpannedStripesWithParity": "The volume is a spanned set of devices which uses parity to retain redundant information.",
            "StripedWithParity": "The volume is a device which uses parity to retain redundant information."
        },
        "type": ["string", "null"]
    },
    "VolumeUsage": {
        "description": "Indicates the volume usage type setting for the Volume.",
        "enum": [
            "Data",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                        "SystemData",
                        "CacheOnly",
                        "SystemReserve",
                        "ReplicationReserve"
                    ],
                    "enumDescriptions": {
                        "CacheOnly": "The volume is allocated for use as a non-consumable cache only volume.",
                        "Data": "The volume is allocated for use as a consumable data volume.",
                        "ReplicationReserve": "The volume is allocated for use as a non-consumable reserved volume for replication use.",
                        "SystemData": "The volume is allocated for use as a consumable data volume reserved for system use.",
                        "SystemReserve": "The volume is allocated for use as a non-consumable system reserved volume."
                    },
                    "type": ["string", "null"]
                }
            },
            "type": "object"
        },
        "type": "array"
    },
    "type": "object"
}
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`data` The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`modified` Date and time when the subresource was last modified. string

`name` The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

GET /rest/server-hardware/{id}/memory

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the memory resource for the server, including information from all memory slots available on the server.

Memory resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/memory

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the memory data based on the following schema:

Response


```
{
    "BaseModuleType": {
        "enum": [
            "RDIMM",
            "UDIMM",
            "SO_DIMM",
            "LRDIMM",
            "Mini_RDIMM",
            "Mini_UDIMM",
            "SO_RDIMM_72b",
            "SO_UDIMM_72b",
            "SO_DIMM_16b",
            "SO_DIMM_32b"
        ],
        "enumDescriptions": {
            "LRDIMM": "Load Reduced",
            "Mini_RDIMM": "Mini_RDIMM",
            "Mini_UDIMM": "Mini_UDIMM",
            "RDIMM": "Registered DIMM",
            "SO_DIMM": "SO_DIMM",
            "SO_DIMM_16b": "SO_DIMM_16b",
            "SO_DIMM_32b": "SO_DIMM_32b",
            "SO_RDIMM_72b": "SO_RDIMM_72b",
            "SO_UDIMM_72b": "SO_UDIMM_72b",
            "UDIMM": "UDIMM"
        },
        "type": "string"
    },
    "BusWidthBits": {
        "description": "Bus Width in bits.",
        "type": "number"
    },
    "CapacityMiB": {
        "description": "Memory Capacity in MiB.",
        "type": "number"
    },
    "DataWidthBits": {
        "description": "Data Width in bits.",
        "type": "number"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        },
        "DeviceID": {
            "description": "Device ID",
            "type": "string"
        },
        "DeviceLocator": {
            "description": "Location of the Memory in the platform",
            "type": "string"
        },
        "ErrorCorrection": {
            "enum": [
                "NoECC",
                "SingleBitECC",
                "MultiBitECC",
                "AddressParity"
            ],
            "enumDescriptions": {
                "AddressParity": "Address Parity errors can be corrected",
                "MultiBitECC": "Multi-bit Data errors can be corrected by ECC",
                "NoECC": "No ECC available",
                "SingleBitECC": "Single bit Data error can be corrected by ECC"
            },
            "type": "string"
        },
        "FirmwareRevision": {
            "description": "The firmware revision of this device",
            "type": "string"
        },
        "Id": {
            "Memory module ID"
            "type": "string"
        },
        "Manufacturer": {
            "description": "The Memory manufacturer",
            "type": "string"
        },
        "MemoryDeviceType": {
            "enum": [
                "DDR",
                "DDR2",
                "DDR3",
                "DDR4",
                "DDR4_SDRAM",
                "DDR4E_SDRAM",
                "LPDDR4_SDRAM",
                "DDR3_SDRAM",
                "LPDDR3_SDRAM",
                "DDR2_SDRAM",
                "DDR2_SDRAM_FB_DIMM",
                "DDR2_SDRAM_FB_DIMM_PROBE",
                "DDR_SGRAM",
                "DDR_SDRAM",
                "ROM",
                "SDRAM",
                "EDO",
                "FastPageMode",
                "PipelinedNibble"
            ],
            "enumDescriptions": {
                "DDR": "DDR",
                "DDR2": "DDR2",
                "DDR2_SDRAM": "DDR2
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "DDR2_SDRAM_FB_DIMM": "DDR2 SDRAM FB_DIMM",
                "DDR2_SDRAM_FB_DIMM_PROBE": "DDR2 SDRAM FB_DIMM PROBE",
                "DDR3": "DDR3",
                "DDR3_SDRAM": "DDR3 SDRAM",
                "DDR4": "DDR4",
                "DDR4E_SDRAM": "DDR4E SDRAM",
                "DDR4_SDRAM": "DDR4 SDRAM",
                "DDR_SDRAM": "DDR SDRAM",
                "DDR_SGRAM": "DDR SGRAM",
                "EDO": "EDO",
                "FastPageMode": "Fast Page Mode",
                "LPDDR3_SDRAM": "LPDDR3 SDRAM",
                "LPDDR4_SDRAM": "LPDDR4 SDRAM",
                "PipelinedNibble": "Pipelined Nibble",
                "ROM": "ROM",
                "SDRAM": "SDRAM"
            },
            "type": "string"
        },
        "MemoryLocation": {
            "description": "Memory Module Location",
            "Channel": {
                "description": "Channel number in which Memory is connected",
                "type": "number"
            },
            "MemoryController": {
                "description": "Memory controller number in which Memory is connected",
                "type": "number"
            },
            "Slot": {
                "description": "Slot number in which Memory is connected",
                "type": "number"
            },
            "Socket": {
                "description": "Socket number in which Memory is connected",
                "type": "number"
            }
        },
        "MemoryMedia": {
            "description": "Media  of this Memory",
            "items": {
                "enum": [
                    "DRAM",
                    "NAND",
                    "Proprietary"
                ],
                "enumDescriptions": {
                    "DRAM": "DRAM media",
                    "NAND": "NAND media",
                    "Proprietary": "Proprietary media"
                },
                "type": "string"
            },
            "type": "array"
        },
        "MemoryType": {
            "enum": [
                "DRAM",
                "NVDIMM_N",
                "NVDIMM_F",
                "NVDIMM_P"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            ],
            "enumDescriptions": {
                "DRAM": "DRAM",
                "NVDIMM_F": "NVDIMM_F as defined by JEDEC.",
                "NVDIMM_N": "NVDIMM_N as defined by JEDEC.",
                "NVDIMM_P": "NVDIMM_P as defined by JEDEC."
            },
            "type": "string"
        },
        "Name": {
            "Memory module name"
            "type": "string"
        },
        "Oem": {
            "Hpe": {
                "description": "HPE extended properties of a memory module",
                "type": "object"
            }
        },
        "OperatingMemoryModes": {
            "description": "Memory modes supported by the Memory",
            "items": {
                "enum": [
                    "Volatile",
                    "PMEM",
                    "Block"
                ],
                "enumDescriptions": {
                    "Block": "Block accessible system memory",
                    "PMEM": "Persistent memory, byte accesible through system address space",
                    "Volatile": "Volatile memory"
                },
                "type": "string"
            },
            "type": "array"
        },
        "OperatingSpeedMhz": {
            "description": "Operating speed of Memory in MHz",
            "type": "number"
        },
        "PartNumber": {
            "description": "The product part number of this device",
            "type": "string"
        },
        "SerialNumber": {
            "description": "The serial number of this device",
            "type": "string"
        },
        "PersistentRegionSizeLimitMiB": {
            "description": "Total size of persistent regions in MiB",
            "type": "number"
        },
        "RankCount": {
            "description": "Number of ranks available in the Memory",
            "type": "number"
        },
        "Status": {
            "Health": {
                "description": "This represents the health state of this resource.",
                "type": "string"
            },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "State": {
                "description": "This indicates the known state of the resource.",
                "type": "string"
            }
        },
        "SubsystemDeviceID": {
            "description": "Subsystem Device ID",
            "type": "string"
        },
        "SubsystemVendorID": {
            "description": "SubSystem Vendor ID",
            "type": "string"
        },
        "VendorID": {
            "description": "Vendor ID",
            "type": "string"
        },
        "VolatileRegionSizeLimitMiB": {
            "description": "Total size of volatile regions in MiB",
             "type": "number"
        },
        "@odata.etag": {
            "description": "The current ETag of the memory resource. Currently this is applicable only for Superdome Flex server type.",
            "type": ["string", "null"]
        }
    }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`

The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`

Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Response Body SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET **/rest/server-hardware/{id}/memoryList**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the memory list resource for the server.

Memory list resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/memoryList

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the memory list data based on the following schema:

Response

```
{
    "BoardCpuNumber": {
        "description": "The CPU number on the board.",
        "type": "integer"
    },
    "BoardNumberOfSockets": {
        "description": "The number of present memory module sockets.",
        "type": "integer"
    },
    "BoardTotalMemorySize": {
        "description": "The total size of the memory populated on the board in MB.",
        "type": "integer"
    },
    "BoardOperationalFrequency": {
        "description": "The frequency at which memory on the board is operating in MHz.",
        "type": "integer"
    },
    "BoardOperationalVoltage": {
        "description": "The voltage at which memory on the board is operating in mV.",
        "type": "integer"
    }
}
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Auth
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

If-None-Match
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

X-Api-Version
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data coll

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

PUT **/rest/server-hardware/{id}/mpFirmwareVersion**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Updates the iLO firmware on a physical server to a minimum ILO firmware version required by OneView to manage the server.

Update the iLO firmware of the server to the minimum supported version.

Request

```
PUT  https://{appl}/rest/server-hardware/{id}/mpFirmwareVersion

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. In addition, if the permission is scoped, the target resource URI(s) must be in the permission scope.

Action `Update`

Category `server-hardware`

Scoped By `uri`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

`Location` The URI of the newly-created resource or a task created to perform the requested action. string

GET **/rest/server-hardware/{id}/networkAdapters**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the networkAdapters resource for the server.

Network Adapters resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/networkAdapters

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the network adapters data based on the following schema: :

Response


```
{
 "ControllerCapabilities": {
     "additionalProperties": false,
     "description": "The capabilities of a controller.",
     "properties": {
         "DataCenterBridging": {
             "description": "Data center bridging (DCB) for this controller.",
             "longDescription": "This property shall contain capability, status, and configuration values related to data center bridging (DCB) f
         },
         "NPAR": {
             "description": "NIC Partitioning (NPAR) capabilities for this controller.",
             "longDescription": "This property shall contain capability, status, and configuration values related to NIC partitioning for this co
             "versionAdded": "v1_2_0"
         },
         "NPIV": {
             "description": "N_Port ID Virtualization (NPIV) capabilities for this controller.",
             "longDescription": "This property shall contain N_Port ID Virtualization (NPIV) capabilities for this controller."
         },
         "NetworkDeviceFunctionCount": {
             "description": "The maximum number of physical functions available on this controller.",
             "longDescription": "This property shall contain the number of physical functions available on this controller.",
             "readonly": true,
             "type": [
                 "integer",
                 "null"
             ]
         },
         "NetworkPortCount": {
             "description": "The number of physical ports on this controller.",
             "longDescription": "This property shall contain the number of physical ports on this controller.",
             "readonly": true,
             "type": [
                 "integer",
                 "null"
             ]
         },
         "VirtualizationOffload": {
             "description": "Virtualization offload for this controller."
         }
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            },
            "type": "object"
        },
        "ControllerLinks": {
            "additionalProperties": false,
            "description": "The links to other resources that are related to this resource.",
            "properties": {
                "ActiveSoftwareImage": {
                    "description": "The link to the software inventory resource that represents the active firmware image for this controller.",
                    "readonly": false,
                    "versionAdded": "v1_10_0"
                },
                "NetworkDeviceFunctions": {
                    "description": "An array of links to the network device functions associated with this network controller.",
                    "readonly": true,
                    "type": "array"
                },
                "NetworkPorts": {
                    "deprecated": "This property has been deprecated in favor of the Ports property.",
                    "description": "An array of links to the network ports associated with this network controller.",
                    "readonly": true,
                    "type": "array",
                    "versionDeprecated": "v1_5_0"
                },
                "Oem": {
                    "description": "The OEM extension property.",
                    "longDescription": "This property shall contain the OEM extensions.  All values for properties contained in this object shall confor
                },
                "PCIeDevices": {
                    "description": "An array of links to the PCIe devices associated with this network controller.",
                    "longDescription": "This property shall contain an array of links to resources of type PCIeDevice that represent the PCIe devices as
                    "readonly": true,
                    "type": "array"
                },
                "Ports": {
                    "description": "An array of links to the ports associated with this network controller.",
                    "readonly": true,
                    "type": "array",
                    "versionAdded": "v1_5_0"
                },
                "SoftwareImages": {
                    "description": "The images that are associated with this controller.",
                    "readonly": true,
                    "type": "array",
                    "versionAdded": "v1_10_0"
                }
            },
            "type": "object"
        },
        "Controllers": {
            "additionalProperties": false,
            "description": "A network controller ASIC that makes up part of a network adapter.",
            "properties": {
                "ControllerCapabilities": {
                    "description": "The capabilities of this controller.",
                    "longDescription": "This property shall contain the capabilities of this controller."
                },
                "FirmwarePackageVersion": {
                    "description": "The version of the user-facing firmware package.",
                    "longDescription": "This property shall contain the version number of the user-facing firmware package.",
                    "readonly": true,
                    "type": [
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "string",
                "null"
            ]
        },
        "Identifiers": {
            "description": "The durable names for the network adapter controller.",
            "longDescription": "This property shall contain a list of all known durable names for the controller associated with the network ada
            "type": "array",
            "versionAdded": "v1_3_0"
        },
        "Links": {
            "description": "The links to other resources that are related to this resource.",
            "longDescription": "This property shall contain links to resources that are related to but are not contained by, or subordinate to,
        },
        "Location": {
            "description": "The location of the network adapter controller.",
            "longDescription": "This property shall contain the location information of the controller associated with the network adapter.",
            "versionAdded": "v1_1_0"
        },
        "PCIeInterface": {
            "description": "The PCIe interface details for this controller.",
            "longDescription": "This property shall contain details for the PCIe interface that connects this PCIe-based controller to its host.
            "versionAdded": "v1_2_0"
        }
    },
    "type": "object"
},
"DataCenterBridging": {
    "additionalProperties": false,
    "description": "Data center bridging (DCB) for capabilities of a controller.",
    "longDescription": "This type shall describe the capability, status, and configuration values related to data center bridging (DCB) for a co
    "properties": {
        "Capable": {
            "description": "An indication of whether this controller is capable of data center bridging (DCB).",
            "longDescription": "This property shall indicate whether this controller is capable of data center bridging (DCB).",
            "readonly": true,
            "type": [
                "boolean",
                "null"
            ]
        }
    },
    "type": "object"
},
"NPIV": {
    "additionalProperties": false,
    "description": "N_Port ID Virtualization (NPIV) capabilities for a controller.",
    "longDescription": "This type shall contain N_Port ID Virtualization (NPIV) capabilities for a controller.",
    "properties": {
        "MaxDeviceLogins": {
            "description": "The maximum number of N_Port ID Virtualization (NPIV) logins allowed simultaneously from all ports on this controlle
            "longDescription": "This property shall contain the maximum number of N_Port ID Virtualization (NPIV) logins allowed simultaneously
            "readonly": true,
            "type": [
                "integer",
                "null"
            ]
        },
        "MaxPortLogins": {
            "description": "The maximum number of N_Port ID Virtualization (NPIV) logins allowed per physical port on this controller.",
            "longDescription
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                "readonly": true,
                "type": [
                    "integer",
                    "null"
                ]
            }
        },
        "type": "object"
    },
    "NetworkAdapter": {
        "additionalProperties": false,
        "description": "The NetworkAdapter schema represents a physical network adapter capable of connecting to a computer network.  Examples inclu
        "longDescription": "This resource shall represent a physical network adapter capable of connecting to a computer network in a Redfish implem
        "Actions": {
            "description": "The available actions for this resource.",
            "longDescription": "This property shall contain the available actions for this resource."
        },
        "Assembly": {
            "description": "The link to the assembly resource associated with this adapter.",
            "longDescription": "This property shall contain a link to a resource of type Assembly.",
            "readonly": true,
            "versionAdded": "v1_1_0"
        },
        "Certificates": {
            "description": "The link to a collection of certificates for device identity and attestation.",
            "longDescription": "This property shall contain a link to a resource collection of type CertificateCollection that contains certificates
            "readonly": true,
            "versionAdded": "v1_6_0"
        },
        "Controllers": {
            "description": "The set of network controllers ASICs that make up this NetworkAdapter.",
            "longDescription": "This property shall contain the set of network controllers ASICs that make up this network adapter.",
            "type": "array"
        },
        "EnvironmentMetrics": {
            "description": "The link to the environment metrics for this network adapter.",
            "longDescription": "This property shall contain a link to a resource of type EnvironmentMetrics that specifies the environment metrics f
            "readonly": true,
            "versionAdded": "v1_7_0"
        },
        "Id": {
            "readonly": true
        },
        "Identifiers": {
            "description": "The durable names for the network adapter.",
            "longDescription": "This property shall contain a list of all known durable names for the network adapter.",
            "type": "array",
            "versionAdded": "v1_4_0"
        },
        "LLDPEnabled": {
            "description": "Enable or disable LLDP globally for an adapter.",
            "longDescription": "This property shall contain the state indicating whether LLDP is globally enabled on a network adapter.  If set to `
            "readonly": false,
            "type": "boolean",
            "versionAdded": "v1_7_0"
        },
        "Location": {
            "description": "The location of the network adapter.",
            "longDescription": "This property shall contain the location information of the network adapter.",
            "versionAdded": "v1_4_0"
        },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "Manufacturer": {
                "description": "The manufacturer or OEM of this network adapter.",
                "longDescription": "This property shall contain a value that represents the manufacturer of the network adapter.",
                "readonly": true,
                "type": [
                    "string",
                    "null"
                ]
            },
            "Measurements": {
                "deprecated": "This property has been deprecated in favor of the ComponentIntegrity resource.",
                "description": "An array of DSP0274-defined measurement blocks.",
                "longDescription": "This property shall contain an array of DSP0274-defined measurement blocks.",
                "type": "array",
                "versionAdded": "v1_6_0",
                "versionDeprecated": "v1_9_0"
            },
            "Metrics": {
                "description": "The link to the metrics associated with this adapter.",
                "longDescription": "This property shall contain a link to a resource of type NetworkAdapterMetrics that contains the metrics associated
                "readonly": true,
                "versionAdded": "v1_7_0"
            },
            "Model": {
                "description": "The model string for this network adapter.",
                "longDescription": "This property shall contain the information about how the manufacturer refers to this network adapter.",
                "readonly": true,
                "type": [
                    "string",
                    "null"
                ]
            },
            "Name": {
                "readonly": true
            },
            "NetworkDeviceFunctions": {
                "description": "The link to the collection of network device functions associated with this network adapter.",
                "longDescription": "This property shall contain a link to a resource collection of type NetworkDeviceFunctionCollection.",
                "readonly": true
            },
            "NetworkPorts": {
                "deprecated": "This property has been deprecated in favor of the Ports property.",
                "description": "The link to the collection of network ports associated with this network adapter.",
                "longDescription": "This property shall contain a link to a resource collection of type NetworkPortCollection.",
                "readonly": true,
                "versionDeprecated": "v1_5_0"
            },
            "Oem": {
                "description": "The OEM extension property.",
                "longDescription": "This property shall contain the OEM extensions.  All values for properties that this object contains shall conform t
            },
            "PartNumber": {
                "description": "Part number for this network adapter.",
                "longDescription": "This property shall contain the part number for the network adapter as defined by the manufacturer.",
                "readonly": true,
                "type": [
                    "string",
                    "null"
                ]
            },
            "Ports": {
                "description": "The
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "longDescription": "This property shall contain a link to a resource collection of type PortCollection.",
            "readonly": true,
            "versionAdded": "v1_5_0"
        },
        "Processors": {
            "description": "The link to the collection of offload processors contained in this network adapter.",
            "longDescription": "This property shall contain a link to a resource collection of type ProcessorCollection that represent the offload p
            "readonly": true,
            "versionAdded": "v1_8_0"
        },
        "SKU": {
            "description": "The manufacturer SKU for this network adapter.",
            "longDescription": "This property shall contain the SKU for the network adapter.",
            "readonly": true,
            "type": [
                "string",
                "null"
            ]
        },
        "SerialNumber": {
            "description": "The serial number for this network adapter.",
            "longDescription": "This property shall contain the serial number for the network adapter.",
            "readonly": true,
            "type": [
                "string",
                "null"
            ]
        },
        "Status": {
            "description": "The status and health of the resource and its subordinate or dependent resources.",
            "longDescription": "This property shall contain any status or health properties of the resource."
        }
    },
    "NicPartitioning": {
        "additionalProperties": false,
        "description": "NIC Partitioning capability, status, and configuration for a controller.",
        "longDescription": "This type shall contain the capability, status, and configuration values for a controller.",
        "properties": {
            "NparCapable": {
                "description": "An indication of whether the controller supports NIC function partitioning.",
                "longDescription": "This property shall indicate whether the controller supports NIC function partitioning.",
                "readonly": true,
                "type": [
                    "boolean",
                    "null"
                ],
                "versionAdded": "v1_2_0"
            },
            "NparEnabled": {
                "description": "An indication of whether NIC function partitioning is active on this controller.",
                "longDescription": "This property shall indicate whether NIC function partitioning is active on this controller.",
                "readonly": false,
                "type": [
                    "boolean",
                    "null"
                ],
                "versionAdded": "v1_2_0"
            }
        },
        "type": "object"
    },
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "OemActions": {
            "additionalProperties": true,
            "description": "The available OEM-specific actions for this resource.",
            "longDescription": "This type shall contain the available OEM-specific actions for this resource.",
            "properties": {},
            "type": "object"
        },
        "ResetSettingsToDefault": {
            "additionalProperties": false,
            "description": "This action is to clear the settings back to factory defaults.",
            "longDescription": "This action shall reset of all active and pending settings back to factory default settings upon reset of the network ad
            "parameters": {},
            "properties": {
                "target": {
                    "description": "Link to invoke action",
                    "format": "uri-reference",
                    "type": "string"
                },
                "title": {
                    "description": "Friendly action name",
                    "type": "string"
                }
            },
            "type": "object"
        },
        "SRIOV": {
            "additionalProperties": false,
            "description": "Single-root input/output virtualization (SR-IOV) capabilities.",
            "longDescription": "This type shall contain single-root input/output virtualization (SR-IOV) capabilities.",
            "properties": {
                "SRIOVVEPACapable": {
                    "description": "An indication of whether this controller supports single root input/output virtualization (SR-IOV) in Virtual Ethern
                    "longDescription": "This property shall indicate whether this controller supports single root input/output virtualization (SR-IOV) i
                    "readonly": true,
                    "type": [
                        "boolean",
                        "null"
                    ]
                }
            },
            "type": "object"
        },
        "VirtualFunction": {
            "additionalProperties": false,
            "description": "A virtual function of a controller.",
            "longDescription": "This type shall describe the capability, status, and configuration values related to a virtual function for a controller
            "properties": {
                "DeviceMaxCount": {
                    "description": "The maximum number of virtual functions supported by this controller.",
                    "longDescription": "This property shall contain the maximum number of virtual functions supported by this controller.",
                    "readonly": true,
                    "type": [
                        "integer",
                        "null"
                    ]
                },
                "MinAssignmentGroupSize": {
                    "description": "The minimum number of virtual functions that can be allocated or moved between physical functions for this controlle
                    "longDescription": "This property shall contain the minimum number of virtual functions that can be allocated or moved between physi
                    "readonly": true,
                    "type": [
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
                        "integer",
                        "null"
                    ]
                },
                "NetworkPortMaxCount": {
                    "description": "The maximum number of virtual functions supported per network port for this controller.",
                    "longDescription": "This property shall contain the maximum number of virtual functions supported per network port for this controll
                    "readonly": true,
                    "type": [
                        "integer",
                        "null"
                    ]
                }
            },
            "type": "object"
        },
        "VirtualizationOffload": {
            "additionalProperties": false,
            "description": "A Virtualization offload capability of a controller.",
            "longDescription": "This type shall describe the capability, status, and configuration values related to a virtualization offload for a cont
            "properties": {
                "SRIOV": {
                    "$ref": "#/definitions/SRIOV",
                    "description": "Single-root input/output virtualization (SR-IOV) capabilities.",
                    "longDescription": "This property shall contain single-root input/output virtualization (SR-IOV) capabilities."
                },
                "VirtualFunction": {
                    "$ref": "#/definitions/VirtualFunction",
                    "description": "The virtual function of the controller.",
                    "longDescription": "This property shall describe the capability, status, and configuration values related to the virtual function fo
                }
            },
            "type": "object"
        }
    }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.

string

required

`If-None-Match`

The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.

string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

X-Api-Version
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of these processors. `Unknown`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

GET **/rest/server-hardware/{id}/physicalServerHardware**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Information describing hard partitions (a hard partition constitutes one or more blades for 'Superdome X' or chassis for 'Superdome Flex') represented by a server hardware. Applicable only for 'Superdome X' and 'Superdome Flex'.

Information describing a hard partition.

Request

```
GET  https://{appl}/rest/server-hardware/{id}/physicalServerHardware

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body PhysicalServerHardwareInventoryV10

`category` Identifies the resource type string
read only

`created` Date and time when the resource was created timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

`eTag` Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource string
read only

`modified` Date and time when the resource was last modified timestamp
read only

Format yyyy-MM-dd'T'HH:mm:ss.SSS'Z' Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

`physicalServerHardware` A list containing all the details of each device that makes up the Superdome X or Superdome Flex hard partition.
array of PhysicalHardwareV10

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

assetTag The current value of the asset tag for this physical hardware. string

bladeNumber Blade number (1..N) in the device bay slot. Applicable only for Superdome X. integer

formFactor The physical dimensions of the physical hardware. For a server blade, it is always full height. For a chassis, this is expressed in U height, e.g. 5U. string

locationUri The URI of the hard partition in which this physical server resides. string

memoryMb Amount of memory installed on this physical hardware in MiB (1 MiB = 1,048,576 bytes). integer

model The full server hardware model string. string

name The name of the hardware resource. string

partNumber The part number for this physical hardware. string

physicalUuid The Universally Unique ID (UUID) of the individual physical hardware that can become part of a hard partition. string

position
For blade servers, the number of the physical enclosure bay (1..N) in which the hardware resides and for rack servers, this is the chassis bay (1..N) in which the hardware resides.
integer

processorCoreCount Number of cores available per processor. integer

processorCount Number of processors installed on this physical hardware. integer

romVersion The version of the hardware firmware (ROM). string

serialNumber Serial number of the physical hardware. string

status Physical hardware status. string

subResources Subresources of the physical hardware. map from string to SubResourceCollectionV1

count Number of subresources in the subresource collection. integer

data The actual subresource data collected from the server. The data is in JSON format based on RedFish schema. array of ISubResourcesV1

`data[].`**etag**
etag of the subresource. string

`data[].`**modified**
Date and time when the resource was last modified string

etag etag of the subresource. string

modified Last modified time stamp of the subresource. string

state The current state of the subresource collection. CollectionState

Values

`Collected` The data was successfully collected and was current at the time of collection. `CollectedStale`

The data was successfully collected, but the data may be out of date or missing. `CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

type Type of the subresource. string

uri URI of the subresource. string

type Physical hardware type. string

serverHardwareUri The URI of the server hardware that represents the Superdome X or Superdome Flex hard partition. string

serverModel The full server hardware model string. string

serverName
For a Superdome X server it is the enclosure name appended with the partition name and for a Superdome Flex server it is the rack manager name appended with the partition name.
string

state Current state of the resource string

type Uniquely identifies the type of the JSON object string
read only

Default physical-server-hardware-10

uri The canonical URI of the resource string
read only

PUT **/rest/server-hardware/{id}/powerState**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Requests a power operation to change the power state of the physical server.

Power off a server that is on, using the momentary press control:

Request

```
PUT  https://{appl}/rest/server-hardware/123-45-67-89-123/powerState

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400

{
     "powerState": "Off",
     "powerControl":"MomentaryPress"
}
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Update`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`
The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Response Headers

`Location` The URI of the newly-created resource or a task created to perform the requested action. string

Request Body ServerPowerControlRequest

`powerControl`

The desired power control specifying the method to achieve the desired power state. Allowed values are: MomentaryPress - power on or a normal (soft) power off (depending on powerState), PressAndHold - an immediate (hard) shutdown, ColdBoot - a hard reset that immediately removes power from the server hardware and then restarts the server after approximately six seconds,Reset - a normal server reset that resets the device in an orderly sequence. PhysicalServerPowerControl

Values

`ColdBoot`

Reset the server using the cold boot control. This is a hard reset that immediately removes power from the server hardware and restarts the server after approximately eight seconds.

`MomentaryPress` Power on or a normal (soft) power off, depending on powerState. `PressAndHold`

Immediately power off the server using the press and hold control. `Reset`

Reset the server using the reset control. This will perform an immediate warm reboot of the server without removing power.

`powerState` The desired power state. While a resource may be in several additional power states, the allowed values here are 'On' and 'Off'. PhysicalServerPowerState

Values

`Off` Power off `On` Power on `PoweringOff` Powering off `PoweringOn` Powering on `Resetting` Resetting `Unknown`

Unable to determine server power state.

GET /rest/server-hardware/{id}/powerSupplies

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the power supplies resource for the server.

Power supplies resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/powerSupplies

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the power supplies data based on the following schema: :

Response


```
{
      "additionalProperties": false,
      "description": "Details of a power supplies associated with this system or device",
      "properties": {
        "@odata.id": {
          "format": "uri-reference",
          "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in the
          "readonly": true,
          "type": "string"
        },
        "FirmwareVersion": {
          "description": "The firmware version for this Power Supply",
          "longDescription": "This property shall contain the firwmare version as defined by the manufacturer for the associated power supply.",
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "LastPowerOutputWatts": {
          "description": "The average power output of this Power Supply",
          "longDescription": "This property shall contain the average power output, measured in Watts, of the associated power supply.",
          "readonly": true,
          "type": [
            "number",
            "null"
          ]
        },
        "LineInputVoltage": {
          "description": "The line input voltage at which the Power Supply is operating",
          "longDescription": "This property shall contain the value in Watts of the line input voltage (measured or configured for) that the power s
          "readonly": true,
          "type": [
            "number",
            "null"
          ]
        },
        "LineInputVoltageType": {
          "description": "The line voltage type supported as an input to this Power Supply",
          "enum": [
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
      "enum": [
        null,
        "Unknown",
        "ACLowLine",
        "ACMidLine",
        "ACHighLine",
        "DCNeg48V",
        "HighVoltageDC"
      ],
      "enumDescriptions": {
        "ACHighLine": "277V AC input.",
        "ACLowLine": "100-127V AC input.",
        "ACMidLine": "200-240V AC input.",
        "DCNeg48V": "-48V DC input.",
        "HighVoltageDC": "High Voltage DC input (380V).",
        "Unknown": "The power supply line input voltage type cannot be determined."
      },
      "longDescription": "This property shall contain the type of input line voltage supported by the associated power supply",
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Manufacturer": {
      "description": "This is the manufacturer of this power supply.",
      "longDescription": "The value of this property shall be the name of the organization responsible for producing the power supply. This orga
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "MemberId": {
      "description": "This is the identifier for the member within the collection.",
      "longDescription": "The value of this string shall uniquely identify the member within the collection.",
      "type": "string"
    },
    "Model": {
      "description": "The model number for this Power Supply",
      "longDescription": "This property shall contain the model information as defined by the manufacturer for the associated power supply.",
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Name": {
      "description": "The name of the resource or array element.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "Oem": {
      "additionalProperties": true,
      "description": "This is the manufacturer/provider specific extension moniker used to divide the Oem object into sections.",
      "longDescription": "The value of this string shall be of the format for the reserved word *Oem*.",
      "properties": {
        "Hpe": {
            "AveragePowerOutputWatts": {
              "description": "The latest observed average power being drawn by the power supply (Watts). This is usually updated every 10 second
              "etag": true,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
      "minimum": 0,
      "readonly": true,
      "type": "integer"
    },
    "BayNumber": {
      "description": "The power supply bay number.",
      "etag": true,
      "minimum": 0,
      "readonly": true,
      "type": "integer"
    },
    "HotplugCapable": {
      "description": "If true, this power supply (and power supply bay) is capable of being hot-plugged.",
      "etag": true,
      "readonly": true,
      "type": "boolean"
    },
    "Id": {
      "description": "Uniquely identifies the resource within the collection of like resources.",
      "longDescription": "This property represents an identifier for the resource.  All values for resources described by this schema sh
      "readonly": true,
      "type": "string"
    },
    "MaxPowerOutputWatts": {
      "description": "The latest observed maximum output power being drawn by the power supply (Watts). This is usually updated every 10
      "etag": true,
      "minimum": 0,
      "readonly": true,
      "type": "integer"
    },
    "Mismatched": {
      "description": "If true, this power supply is mismatched with others in the system.",
      "etag": true,
      "readonly": true,
      "type": "boolean"
    },
    "PowerSupplyStatus": {
      "additionalProperties": false,
      "description": "This object represents the status of power the power supply.",
      "properties": {
        "State": {
          "description": "Indicates the known state of the resource.",
          "enum": [
            "Unknown",
            "Ok",
            "Degraded",
            "Failed",
            "OverVoltage",
            "OverCurrent",
            "OverTemperature",
            "ACPowerLost",
            "FanFailure",
            "WarningHighInputVoltage",
            "WarningLowInputVoltage",
            "WarningHighOutputVoltage",
            "WarningLowOutputVoltage",
            "WarningInletTemperature",
            "WarningInternalTemperature",
            "WarningHighAuxiliaryVoltage",
            "WarningLowAuxiliaryVoltage",
            "PowerSu
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "GoodInStandby"
      ],
      "etag": true,
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    }
  },
  "readonly": true,
  "type": "object"
},
"iPDU": {
  "additionalProperties": false,
  "properties": {
    "IPAddress": {
      "description": "The IP address of the iPDU connected to this power supply.",
      "etag": true,
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Id": {
      "description": "The iPDU ID.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "MacAddress": {
      "description": "The Ethernet MAC address of the iPDU connected to this power supply.",
      "etag": true,
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Model": {
      "description": "The model number of the iPDU connected to this power supply.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "SerialNumber": {
      "description": "The serial number of the iPDU connected to this power supply.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "iPDUStatus": {
      see PowerSupplyStatus above
    }
  },
  "type": "object"
},
"iPDUCapable": {
  "description": "If true, this power supply is capable of being connected to an iPDUs.",
  "etag": true,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "readonly": true,
            "type": "boolean"
          }
        },
        "readonly": true,
        "title": "#HpeServerPowerSupply.v2_0_0.HpeServerPowerSupply",
        "type": "object"
      }
    },
    "readonly": true,
    "type": "object"
  },
  "PartNumber": {
    "description": "The part number for this Power Supply",
    "longDescription": "This property shall contain the part number as defined by the manufacturer for the associated power supply.",
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "PowerCapacityWatts": {
    "description": "The maximum capacity of this Power Supply",
    "longDescription": "This property shall contiain the maximum amount of power, in Watts, that the associated power supply is rated to deliv
    "readonly": true,
    "type": [
      "number",
      "null"
    ]
  },
  "PowerSupplyType": {
    "description": "The Power Supply type (AC or DC)",
    "enum": [
      null,
      "Unknown",
      "AC",
      "DC"
    ],
    "enumDescriptions": {
      "AC": "Alternating Current (AC) power supply",
      "DC": "Direct Current (DC) power supply",
      "Unknown": "The power supply type cannot be determined"
    },
    "etag": true,
    "longDescription": "This property shall contain the input power type (AC or DC) of the associated power supply.",
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "SerialNumber": {
    "description": "The serial number for this Power Supply",
    "longDescription": "This property shall contain the serial number as defined by the manufacturer for the associated power supply.",
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "SparePartNumber": {
    "description": "The sr
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
      "description": "This spare part number for this Power Supply",
      "longDescription": "This property shall contain the spare or replacement part number as defined by the manufacturer for the associated pow
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Status": {
  "additionalProperties": false,
  "properties": {
    "Health": {
      "description": "This represents the health state of this resource in the absence of its dependent resources.",
      "enum": [
        null,
        "OK",
        "Warning",
        "Critical"
      ],
      "enumDescriptions": {
        "Critical": "A critical condition exists that requires immediate attention",
        "OK": "Normal",
        "Warning": "A condition exists that requires attention"
      },
      "longDescription": "This property shall represent the HealthState of the resource without considering its dependent resources. The values
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "HealthRollup": {
      "description": "This represents the overall health state from the view of this resource.",
      "enum": [
        null,
        "OK",
        "Warning",
        "Critical"
      ],
      "enumDescriptions": {
        "Critical": "A critical condition exists that requires immediate attention",
        "OK": "Normal",
        "Warning": "A condition exists that requires attention"
      },
      "longDescription": "This property shall represent the HealthState of the resource and its dependent resources.  The values shall conform t
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "State": {
      "description": "This indicates the known state of the resource, such as if it is enabled.",
      "enum": [
        null,
        "Enabled",
        "Disabled",
        "StandbyOffline",
        "StandbySpare",
        "InTest",
        "Starting",
        "Absent",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
              "UnavailableOffline",
              "Deferring",
              "Quiesced",
              "Updating"
            ],
            "enumDescriptions": {
              "Absent": "This function or resource is not present or not detected.",
              "Deferring": "The element will not process any commands but will queue new requests.",
              "Disabled": "This function or resource has been disabled.",
              "Enabled": "This function or resource has been enabled.",
              "InTest": "This function or resource is undergoing testing.",
              "Quiesced": "The element is enabled but only processes a restricted set of commands.",
              "StandbyOffline": "This function or resource is enabled, but awaiting an external action to activate it.",
              "StandbySpare": "This function or resource is part of a redundancy set and is awaiting a failover or other external action to activate i
              "Starting": "This function or resource is starting.",
              "UnavailableOffline": "This function or resource is present but cannot be used.",
              "Updating": "The element is updating and may be unavailable or degraded."
            },
            "longDescription": "This property shall represent if this component is available or not and why.  Enabled indicates the resource is availa
            "readonly": true,
            "type": [
              "string",
              "null"
            ]
          }
        },
        "type": "object"
          }
        },
        "type": "object"
      }
    }
  }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`

The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

X-Api-Version

Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

collectionState String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag

Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

uri The URI associated with this subresource. string

GET **/rest/server-hardware/{id}/processors**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the updated processors resource for the server.

Processors resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/{id}/processors

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the processor data based on the following schema:

Response


```
{
    "InstructionSet": {
      "description": "The instruction set of the processor",
      "enum": [
        "x86",
        "x86-64",
        "IA-64",
        "ARM-A32",
        "ARM-A64",
        "MIPS32",
        "MIPS64",
        "OEM"
      ],
      "enumDescriptions": {
        "ARM-A32": "ARM 32-bit",
        "ARM-A64": "ARM 64-bit",
        "IA-64": "Intel IA-64",
        "MIPS32": "MIPS 32-bit",
        "MIPS64": "MIPS 64-bit",
        "OEM": "OEM-defined",
        "x86": "x86 32-bit",
        "x86-64": "x86 64-bit"
      },
      "longDescription": "This property shall contain the string which identifies the instruction set of the processor contained in this socket.",
      "readonly": true,
      "type": "string"
    },
    "Manufacturer": {
      "description": "The processor manufacturer",
      "etag": true,
      "longDescription": "This property shall contain a string which identifies the manufacturer of the processor.",
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "MaxSpeedMHz": {
      "description": "The maximum clock speed of the processor",
      "longDescription": "This property shall contain the maximum clock speed of the processor.",
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
    "longDescription": "This property shall indicate the maximum rated clock speed of the processor in MHz.",
    "readonly": true,
    "type": [
      "integer",
      "null"
    ]
  },
  "Model": {
    "description": "The product model number of this device",
    "longDescription": "This property shall indicate the model information as provided by the manufacturer of this processor.",
    "readonly": true,
    "type": [
      "string",
      "null"
    ]
  },
  "Name": {
    "description": "The name of the resource or array element.",
    "type": "string"
  },
  "Oem": {
    "additionalProperties": true,
    "properties": {
      "Hpe": {
        "$ref": "HpeProcessorExt.json#",
        "readonly": true
      }
    },
    "readonly": true,
    "type": "object"
  },
  "ProcessorArchitecture": {
    "description": "The architecture of the processor",
    "enum": [
      "x86",
      "IA-64",
      "ARM",
      "MIPS",
      "OEM"
    ],
    "enumDescriptions": {
      "ARM": "ARM",
      "IA-64": "Intel Itanium",
      "MIPS": "MIPS",
      "OEM": "OEM-defined",
      "x86": "x86 or x86-64"
    },
    "longDescription": "This property shall contain the string which identifies the architecture of the processor contained in this Socket.",
    "readonly": true,
    "type": "string"
  },
  "ProcessorId": {
    "additionalProperties": false,
    "description": "Identification information for this processor.",
    "etag": true,
    "longDescription": "This object shall contain identification information for this processor.",
    "properties": {
      "EffectiveFamily": {
        "description": "The effective Family for this processor",
        "etag": true,
        "longDescription": "This property shall indicate the effective Family information as provided by the manufacturer of this processor.",
        "readonly": true,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
          "type": [
            "string",
            "null"
          ]
        },
        "EffectiveModel": {
          "description": "The effective Model for this processor",
          "etag": true,
          "longDescription": "This property shall indicate the effective Model information as provided by the manufacturer of this processor.",
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "IdentificationRegisters": {
          "description": "The contents of the Identification Registers (CPUID) for this processor",
          "etag": true,
          "longDescription": "This property shall include the raw CPUID instruction output as provided by the manufacturer of this processor.",
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "MicrocodeInfo": {
          "description": "The Microcode Information for this processor",
          "etag": true,
          "longDescription": "This property shall indicate the Microcode Information as provided by the manufacturer of this processor.",
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "Step": {
          "description": "The Step value for this processor",
          "etag": true,
          "longDescription": "This property shall indicate the Step or revision string information as provided by the manufacturer of this processor
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "VendorId": {
          "description": "The Vendor Identification for this processor",
          "etag": true,
          "longDescription": "This property shall indicate the Vendor Identification string information as provided by the manufacturer of this proc
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        }
      },
      "readonly": true,
      "type": "object"
    },
    "ProcessorType": {
      "description": "The type c
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "enum": [
              "CPU",
              "GPU",
              "FPGA",
              "DSP",
              "Accelerator",
              "OEM"
            ],
            "enumDescriptions": {
              "Accelerator": "An Accelerator",
              "CPU": "A Central Processing Unit",
              "DSP": "A Digital Signal Processor",
              "FPGA": "A Field Programmable Gate Array",
              "GPU": "A Graphics Processing Unit",
              "OEM": "An OEM-defined Processing Unit"
            },
            "longDescription": "This property shall contain the string which identifies the type of processor contained in this Socket.",
            "readonly": true,
            "type": "string"
          },
          "Socket": {
            "description": "The socket or location of the processor",
            "longDescription": "This property shall contain the string which identifies the physical location or socket of the processor.",
            "readonly": true,
            "type": [
              "string",
              "null"
            ]
          },
          "Status": {
            "additionalProperties": false,
            "properties": {
              "Health": {
                "description": "This represents the health state of this resource in the absence of its dependent resources.",
                "enum": [
                  null,
                  "OK",
                  "Warning",
                  "Critical"
                ],
                "enumDescriptions": {
                  "Critical": "A critical condition exists that requires immediate attention",
                  "OK": "Normal",
                  "Warning": "A condition exists that requires attention"
                },
                "longDescription": "This property shall represent the HealthState of the resource without considering its dependent resources. The values
                "readonly": true,
                "type": [
                  "string",
                  "null"
                ]
              },
              "HealthRollup": {
                "description": "This represents the overall health state from the view of this resource.",
                "enum": [
                  null,
                  "OK",
                  "Warning",
                  "Critical"
                ],
                "enumDescriptions": {
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condition exists that requires attention"
        },
        "longDescription": "This property shall represent the HealthState of the resource and its dependent resources.  The values shall conform t
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      },
      "State": {
        "description": "This indicates the known state of the resource, such as if it is enabled.",
        "enum": [
          null,
          "Enabled",
          "Disabled",
          "StandbyOffline",
          "StandbySpare",
          "InTest",
          "Starting",
          "Absent",
          "UnavailableOffline",
          "Deferring",
          "Quiesced",
          "Updating"
        ],
        "enumDescriptions": {
          "Absent": "This function or resource is not present or not detected.",
          "Deferring": "The element will not process any commands but will queue new requests.",
          "Disabled": "This function or resource has been disabled.",
          "Enabled": "This function or resource has been enabled.",
          "InTest": "This function or resource is undergoing testing.",
          "Quiesced": "The element is enabled but only processes a restricted set of commands.",
          "StandbyOffline": "This function or resource is enabled, but awaiting an external action to activate it.",
          "StandbySpare": "This function or resource is part of a redundancy set and is awaiting a failover or other external action to activate i
          "Starting": "This function or resource is starting.",
          "UnavailableOffline": "This function or resource is present but cannot be used.",
          "Updating": "The element is updating and may be unavailable or degraded."
        },
        "longDescription": "This property shall represent if this component is available or not and why.  Enabled indicates the resource is availa
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      }
    },
  },
  "TotalCores": {
    "description": "The total number of cores contained in this processor",
    "longDescription": "This property shall indicate the total count of independent processor cores contained within this processor.",
    "readonly": true,
    "type": [
      "integer",
      "null"
    ]
  },
  "TotalThreads": {
    "description": "The total number of execution threads supported by this processor",
    "longDescription": "This property shall indicate the total count of independent execution threads supported by this processor.",
    "readonly": true,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "type": [
          "integer",
          "null"
        ]
      }
  }
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server in

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

count The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

data The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

etag
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

modified Date and time when the subresource was last modified. string

name The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

uri The URI associated with this subresource. string

PUT **/rest/server-hardware/{id}/refreshState**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Refreshes the server hardware to fix configuration issues.

Initiate a server hardware refresh operation:

Request

```
PUT  https://{appl}/rest/server-hardware/{id}/refreshState
{
     "refreshState" : "RefreshPending"
}
Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Update`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`Content-Type`
The data format sent in the request body. If the Content-Type header is not provided, application/octet-stream is assumed. Any value other than the required value will result in a response code of 415 Unsupported Media Type.
string
required

Required Value application/json

`If-Match`
The request is conditionally processed only if the current ETag for the resource matches the ETag passed in this header. If the ETag specified in this header does not match the resource's current ETag, status code 412 Precondition Failed will be returned. The request can be forced without specifying an explicit ETag by specifying an If-Match header of "*".
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Headers

`Location` The URI of the newly-create

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Request Body ServerRefreshRequest

`hostname`
IP address or host name of the server's iLO management processor. This optional field can be used with rack servers to update the appliance if the iLO IP address has been changed.
string

`password` The password for the specified username. This field is ignored for blade servers. string

`refreshActions`
Specify the action items to refresh for the server. The allowed values are: Default, ClearSyslog, and PortMapEndPoint. An empty list (default) or the value Default will result in a full server refresh. Individual actions may result in an optimized refresh that updates specific aspects of the server state more efficiently than a full refresh. If multiple actions are combined, all specified actions will be performed, possibly resulting in a full refresh.
array of RefreshAction

Values

`ClearSyslog` ClearSyslog action clears the iLO remote syslog configuration if OneView remote syslog destination has been disabled. `Default`

Default action (or empty action list) is the default full refresh action. `PortMapEndPoint`

Refresh the interconnect downlink port connections of all physical adapter ports `PowerOff` Deprecated: Do not use.

`refreshState` The target refresh state -- must be 'RefreshPending'. RefreshState
required

Values

`NotRefreshing` The resource is not currently refreshing `RefreshFailed` The refresh of this resource failed `RefreshPending`

The resource is waiting to be refreshed `Refreshing` The resource is currently being refreshed

`restore` Indicates that the server is being refreshed after a restore operation. Callers should set this 'false'. Boolean

`username` iLO user account login name with Administer User Accounts privilege to use when refreshing the server. This field is ignored for blade servers. string

GET **/rest/server-hardware/{id}/remoteConsoleUrl**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Generates a Single Sign-On (SSO) session for the iLO's .Net or HTML5 Integrated Remote Console Application (IRC) and returns the URL to launch it. If the server hardware is unmanaged or unsupported, the resulting URL will not use SSO and the console will prompt for credentials. Note that the HTML5 console launch from OneView is supported for iLO5 starting version 2.14 and for iLO4 starting version 2.70. Additionally, use of the .Net IRC URL requires a previous installation of the .Net IRC and is supported only on Windows clients.

Generate a Single Sign-On (SSO) session for the iLO's .Net or HTML5 Integrated Remote Console Application (IRC)and return the URL to launch it:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/remoteConsoleUrl?consoleType=HTML5

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Update`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Query Parameters

`consoleType`
Is the type of console requested. The default (when no value is specified) is the .Net IRC for iLO6 and earlier. Use HTML5 to get the iLO's HTML5 remote console URL. For iLO7, the default is HTML5. The .Net IRC is not supported on iLO7.
string

`ip` IP address or host name of the server's iLO management processor (optional). string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Response Body RemoteConsoleUrlResult

`remoteConsoleUrl` URL to launch a remote console session for the iLO web interface. string
required

GET **/rest/server-hardware/{id}/softwareInventory**

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the software resource for the server.

Software resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/softwareInventory

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the software data based on the following schema:

Response


```
{
    "Name": {
      "description": "The name of the resource or array element.",
      "etag": true,
      "readonly": true,
      "type": "string"
    },
    "Oem": {
      "additionalProperties": true,
      "properties": {
        "Hpe": {
          "DeviceClass": {
            "description": "DeviceType GUID rendered by iLO for certain items iLO knows how to flash, and omitted for all other items.",
            "pattern": "([0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12})",
            "readonly": true,
            "type": [
              "string",
              "null"
            ]
          },
          "DeviceContext": {
            "description": "Friendly text string - same as 'Location' in software - omitted if not available.",
            "readonly": true,
            "type": "string"
          },
          "DeviceInstance": {
            "description": "UEFI Device Path if a PCI Device - omitted otherwise.",
            "readonly": true,
            "type": "string"
          },
          "Targets": {
            "description": "An array of possible target GUIDs (basically iLO makes educated guesses).  A client can match any one of these to a GUID
            "items": {
              "description": "A GUID indicating iLO's knowledge of a possible correlation GUIDs vs. components.",
              "pattern": "([0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12})",
              "type": [
                "string",
                "null"
              ]
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
          },
          "type": "array"
        }
      },
      "required": [
        "DeviceClass"
      ],
    },
    "type": "object"
  },
  "RelatedItem": {
    "description": "The IDs of the Resources associated with this software inventory item.",
    "items": {
      "properties": {
        "@odata.id": {
          "format": "uri-reference",
          "longDescription": "The value of this property shall be the unique identifier for the resource and it shall be of the form defined in th
          "readonly": true,
          "type": "string"
        }
      },
      "type": "object"
    },
    "longDescription": "This property shall contain an array of IDs for pointers consistent with JSON Pointer syntax to the Resource that is assoc
    "readonly": true,
    "type": "array"
  },
  "RelatedItem@odata.count": {
    "description": "The number of items in a collection.",
    "longDescription": "The value of this property shall be an integer representing the number of items in a collection.",
    "readonly": true,
    "type": "number"
  },
  "SoftwareId": {
    "description": "The implementation-specific label that identifies this software.",
    "longDescription": "This property shall represent an implementation-specific label that identifies this software.  This string correlates with
    "readonly": true,
    "type": "string"
  },
  "Status": {
    "properties": {
      "Health": {
        "description": "This represents the health state of this resource in the absence of its dependent resources.",
        "enum": [
          null,
          "OK",
          "Warning",
          "Critical"
        ],
        "enumDescriptions": {
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condition exists that requires attention"
        },
        "longDescription": "This property shall represent the HealthState of the resource without considering its dependent resources. The values
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      },
      "HealthRollup": {
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "description": "This represents the overall health state from the view of this resource.",
        "enum": [
          null,
          "OK",
          "Warning",
          "Critical"
        ],
        "enumDescriptions": {
          "Critical": "A critical condition exists that requires immediate attention",
          "OK": "Normal",
          "Warning": "A condition exists that requires attention"
        },
        "longDescription": "This property shall represent the HealthState of the resource and its dependent resources.  The values shall conform t
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      },
      "State": {
        "description": "This indicates the known state of the resource, such as if it is enabled.",
        "enum": [
          null,
          "Enabled",
          "Disabled",
          "StandbyOffline",
          "StandbySpare",
          "InTest",
          "Starting",
          "Absent",
          "UnavailableOffline",
          "Deferring",
          "Quiesced",
          "Updating"
        ],
        "enumDescriptions": {
          "Absent": "This function or resource is not present or not detected.",
          "Deferring": "The element will not process any commands but will queue new requests.",
          "Disabled": "This function or resource has been disabled.",
          "Enabled": "This function or resource has been enabled.",
          "InTest": "This function or resource is undergoing testing.",
          "Quiesced": "The element is enabled but only processes a restricted set of commands.",
          "StandbyOffline": "This function or resource is enabled, but awaiting an external action to activate it.",
          "StandbySpare": "This function or resource is part of a redundancy set and is awaiting a failover or other external action to activate i
          "Starting": "This function or resource is starting.",
          "UnavailableOffline": "This function or resource is present but cannot be used.",
          "Updating": "The element is updating and may be unavailable or degraded."
        },
        "longDescription": "This property shall represent if this component is available or not and why.  Enabled indicates the resource is availa
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      }
    },
    "type": "object"
  },
  "Updateable": {
    "description": "This is true if the item is updatable.",
    "readonly": true,
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
        "type": [
          "boolean",
          "null"
        ]
      },
      "Version": {
        "description": "same as 'VersionString' in existing FwSwVersionInventory",
        "readonly": true,
        "type": [
          "string",
          "null"
        ]
      }
    }
  }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

existing data is not overwritten.

`InsufficientFirmware`

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`data` The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`modified` Date and time when the subresource was last modified. string

`name` The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

GET /rest/server-hardware/{id}/thermal

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Gets the thermal resource for the server.

Thermal resource by server uuid {id}:

Request

```
GET  https://{appl}/rest/server-hardware/123-45-67-89-123/thermal

Content-Type: application/json
Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

The "data" attribute from response body will have the thermal data based on the following schema: :

Response


```
{
    "MemberId": {
      "description": "This is the identifier for the member within the collection.",
      "longDescription": "The value of this string shall uniquely identify the member within the collection.",
      "type": "string"
    },
    "Name": {
      "description": "The name of the fan sensor.",
      "etag": true,
      "readonly": true,
      "type": [
        "string",
        "null"
      ]
    },
    "Oem": {
      "additionalProperties": true,
      "properties": {
        "Hpe": {
          "$ref": "HpeServerFan.json#"
        }
      },
      "readonly": true,
      "type": "object"
    },
    "Reading": {
      "description": "The current speed of the fan.",
      "etag": false,
      "minimum": 0,
      "readonly": true,
      "type": [
        "integer",
        "null"
      ]
    },
    "ReadingUnits": {
      "description": "Units for the CurrentReading.",
      "enum": [
        null,
        "Percent"
```


(C) Copyright 2026 Hewlett Packard Enterprise Development LP

```
            "percent"
          ],
          "etag": true,
          "readonly": true,
          "type": [
            "string",
            "null"
          ]
        },
        "Status": {
          "$ref": "Resource.json#/definitions/Status"
        }
    }
```


Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`
The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`
Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.
string
required

`If-None-Match`
The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.
string

`X-Api-Version`
Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.
integer
required

Response Body SubResourceV10

`collectionState` String value of an enum value from CollectionState. CollectionState

Values

`Collected` The data was successfully collected from the iLO and was current at the time of collection. `CollectedStale`

The data was successfully collected from the iLO, but the data may be out of date or missing due to the server state. This typically happens when the server is powered off or in POST.

`CollectionError`

An error occurred during the collection of the data and it may be incorrect. When an error occurs collecting the data and there is already data in OneView, the existing data is not overwritten.

`InsufficientFirmware`

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The iLO firmware on the server is too low to collect the inventory. The minimum version to collect some types of inventory is iLO 5 v1.20. `NotCollected`

The initial state of a subresource when a server is added, before any inventory collection has been done. It means inventory data is expected, but it has not been collected yet.

`Unknown` Unable to determine server inventory collection state or null returned from the server.

`count` The number of subresource entries in the data field array. This field shows a count regardless of whether or not the expand parameter is used. integer

`data` The actual subresource data collected from the Management Processor. The data is in JSON format based on RedFish schema. See the individual GET /rest/server-hardware/{id}/(subresource name) API documentation for the specific field names and descriptions that might appear in the data section. any type

When performing a GET of the full server-hardware object, the subresource metadata fields will be populated, but the data field will be empty to avoid sending large amounts of unwanted data. If you want the data field fully populated, use the 'expand=all' parameter when performing the GET of the server-hardware object.

When performing a GET of the subresource directly, the data field will always be populated.

`etag`
Entity tag/version ID of the resource, the same value that is returned in the ETag header on a GET of the resource. This is a string value that uniquely identifies the state of the resource over its lifetime. Whenever there is a change in the resource, the ETag value changes.
string

`modified` Date and time when the subresource was last modified. string

`name` The name of subresource data collected from a server, such as Memory, LocalStorage, etc. SubResourceName

Values

`AdvancedMemoryProtection` The Advanced Memory Protection capabilities and current settings for the server. `Devices`

A list of all I/O devices installed in the server. `LocalStorage` Inventory of local storage resources for the server. `LocalStorageV2`

Inventory of local storage v2 resources for the server. `MPSettings` MPSettings defined on the server hardware. `Memory`

Inventory of memory resources for the server. `MemoryList`

Lists each processor in the server and the various memory statistics associated with each of those processors. `Unknown`

Unknown resource type requested for the server.

`uri` The URI associated with this subresource. string

GET /rest/server-hardware/{id}/utilization

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

Retrieves historical utilization data for the specified resource, metrics, and time span.

Get most recent 24-hour CPU Utilization & Frequency data for server USE7335NW3 (endDate should be present time):

Request

```
GET  https://{appl}/rest/server-hardware/USE7335NW3/utilization?fields=CpuUtilization&fields=CpuAverageFreq&filter=endDate=20120403T113000.000Z

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Get 24-hour data for server USE7335NW3 between two specified dates at one sample per hour resolution:

Request

```
GET  https://{appl}/rest/server-hardware/USE7335NW3/utilization?fields=CpuUtilization&view=hour&filter=startDate=20120401T202800.000Z&filter=endDate

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Get all temp data at one sample per day resolution for server USE7335NW3:

Request

```
GET  https://{appl}/rest/server-hardware/USE7335NW3/utilization?fields=AmbientTemperature&view=day

Auth: abcdefghijklmnopqrstuvwxyz012345
X-Api-Version: 8400
```

Authorization

The Auth request header must contain a valid session token, and a role of that session must grant the below Action to the Category. Access is not restricted by scope.

Action `Read`

Category `server-hardware`

Request Headers

`Accept-Language`

The language code requested in the response. If a suitable match to the requested language is not available, en-US or the appliance locale is used. string

`Auth`

Session authorization token obtained from logging in. If this header is not included or if the session-token is invalid, the response code will be 401 Unauthorized.

string

required

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

`If-None-Match`

The request is conditionally processed only if the current ETag for the resource does not match the ETag passed in this header. If the ETag specified in this header matches the resource's current ETag, the status code returned from the GET will be 304 Not Modified.

string

`X-Api-Version`

Specifies the version of the API to invoke. The behavior of a given API version remains the same. It is upward compatible from release to release. New versions of an API are created when new features or changes are introduced. To ensure expected behavior, always provide the X-Api-Version value.

integer

required

Query Parameters

`fields` Name of the metric(s) to be retrieved in the format *METRIC*[,*METRIC*]... Server hardware supports the following utilization metrics:

`AmbientTemperature`

Inlet air temperature in degrees Celsius during this sample interval.

`AveragePower`

Average power consumption in Watts during this sample interval.

`PeakPower`

Peak power consumption in Watts during this sample interval.

`PowerCap`

Dynamic power cap setting on the server hardware in Watts during this sample interval.

`CpuUtilization`

CPU utilization of all CPUs in percent during this sample interval.

`CpuAverageFreq`

Average CPU frequency in Mhz during this sample interval.

`SdflexCpuUtilization`

CPU utilization of all the CPUs of an nPartition in percent during this sample interval. This metric is supported only for Superdome Flex server types.

`SdflexMemoryUtilization`

Memory utilization of an nPartition in percent during this sample interval. This metric is supported only for Superdome Flex server types.

If unspecified, all metrics supported are returned.

array of string

`filter`

Provides an expression of the requested time range of data. One condition (`startDate`/`endDate`) is specified per filter specification as described below. The condition must be specified via the equals (`=`) operator.

`startDate`

Start date of requested starting time range in ISO 8601 format. If omitted, the `startDate` is determined by the `endDate` minus 24 hours.

`endDate`

End date of requested starting time range in ISO 8601 format. When omitted the `endDate` includes the latest data sample available.

If an excessive number of samples would otherwise be returned, the results will be segmented. The caller is responsible for comparing the returned `sliceStartTime` with the requested `startTime` in the response. If the `sliceStartTime` is greater than the `oldestSampleTime` and the requested start time, the caller is responsible for repeating the request with `endTime` set to `sliceStartTime` to obtain the next segment. This process is repeated until the full data set is retrieved.

If the resource has no data, the UtilizationData is still returned, but will contain no samples and `sliceStartTime`/`sliceEndTime` will be equal. `oldestSampleTime`/`newestSampleTime` will still be set appropriately (null if no data is available). If the filter just does not happen to overlap the data that a resource does have, then the metric history service will return null sample values for any missing samples.

array of string

`refresh`

Specifies that if necessary an additional r

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

data. To track the availability of the newly collected data, monitor the TaskResource identified by the `refreshTaskUri` property in the response. If null, no refresh was queued.
Boolean

Default false

view
Specifies the resolution interval length of the samples to be retrieved. This is reflected in the `resolution` in the returned response. Utilization data is automatically purged to stay within storage space constraints. Supported views are listed below.
`native`

Resolution of the samples returned will be one sample for each 5-minute time period. This is the default view and matches the resolution of the data returned by the iLO. Samples at this resolution are retained up to one year. For Superdome Flex server type, the resolution would be one sample for each 20-min time period.

`hour`

Resolution of the samples returned will be one sample for each 60-minute time period. Samples are calculated by averaging the available 5-minute data samples that occurred within the hour, except for `PeakPower` which is calculated by reporting the peak observed 5-minute sample value data during the hour. Samples at this resolution are retained up to three years. For Superdome Flex server type, the available 20-min samples that occured within the hour would be averaged into one sample for that hour.

`day`

Resolution of the samples returned will be one sample for each 24-hour time period. One day is a 24-hour period that starts at midnight GMT regardless of the time zone in which the appliance or client is located. Samples are calculated by averaging the available 5-minute data samples that occurred during the day, except for `PeakPower` which is calculated by reporting the peak observed 5-minute sample value data during the day. Samples at this resolution are retained up to three years. For Superdome Flex server type, the available 20-min samples that occured during the day would be averaged into one sample for that day.

string

Default native

Response Body UtilizationData

isFresh
The metric is considered fresh if the most recent available sample from the resource has already been collected and is included in the newestSampleTime. Boolean

metricList The list of information returned for each metric. It contains one entry per metric name requested for this resource. array of MetricData
required

metricCapacity The capacity (total amount available) of this metric (null if it does not apply or is not available) integer

metricName
The name of the metric described by this object. See the GET utilization method for a resource to determine the supported metrics for that resource. The list of metrics includes CpuUtilization, CpuAverageFreq, AmbientTemperature, AveragePower, PowerCap, PeakPower, RatedCapacity, DeratedCapacity. In addition, SdflexCpuUtilization and SdflexMemoryUtilization are the metrics exclusively supported by the Superdome Flex server types.
string
required

metricSamples
The set of utilization sample arrays keyed by metric name. Each sample element in the array is itself an array containing a time value (metricSamples[i][0]) followed by the value at that time (metricSamples[i][1])).The time value is represented as the number of milliseconds between the time and midnight January 1 1970. The samples are sorted in time order from most-recent to oldest. The value representation is dependent upon the metric selected.
array of any type

newestSampleTime The end time of the newest (most recent) sample of any metric for this resource. The format is an extended ISO 8601 String (as GMT) string

Format YYYY-MM-DDThh:mm:ss.sssZ Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

oldestSampleTime The oldest (earliest in time) sample of any metric for this resource. The format is an extended ISO 8601 String (as GMT) string

Format YYYY-MM-DDThh:mm:ss.sssZ Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

refreshTaskUri

(C) Copyright 2026 Hewlett Packard Enterprise Development LP

The uri of a task resource to track the collection of the most recent utilization data (null if no collection is required). When the task completes, repeat the request to obtain any newly collected data.
string

resolution
Time period (resolution) of each metric sample in milliseconds. Example resolution values include five minutes (300000), one hour (3600000), or one day (86400000).
integer

sliceEndTime The sample time immediately following the newest (most recent) sample in this response. The format is an extended ISO 8601 String (as GMT) string

Format YYYY-MM-DDThh:mm:ss.sssZ Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

sliceStartTime The oldest (earliest in time) sample returned in this response. The format is an extended ISO 8601 String (as GMT) string

Format YYYY-MM-DDThh:mm:ss.sssZ Pattern [1-2][0-9][0-9][0-9]-([0-1][0-9])-[0-3][0-9]T[0-2][0-9]:[0-5][0-9]:[0-5][0-9](.[0-9][0-9][0-9])?Z

uri The uri of the resource associated with this metric data. string

(C) Copyright 2026 Hewlett Packard Enterprise Development LP