Installation

Copy the RobustSim.ini file to your C:\users\XXX\Documents folder. The folders with the interfaces can be placed anywhere on your computer. In MacOS and Linux it must be placed either in the /home/user directory or in its documents directory.

Launch

If you are using the MATLAB “MainRobust.m” then launch robust_interface/Robust.exe file.

If you do not launch the proper interface, you will have weird results on screen, as the robot kinematics differ between the simulation (Matlab) and the rendering (the Unity interface).

How to move the camera

Pressing ‘END’ allows you to control the POV with the mouse.

W: forward
S: backward
A: left
D: right
Q: go up
E: go down

The initial robot position is below the initial camera position (it is near the pipeline)