

Northwind Solar - Installation Handbook

Section 1: Overview

The Northwind NS-400 is a residential rooftop solar array rated at 400 watts per panel. A standard household installation uses twelve panels for a combined output of 4.8 kilowatts.

Section 2: Site Requirements

Panels require a south-facing roof with a pitch between 15 and 40 degrees. The mounting rail must be anchored into rafters, never into sheathing alone. Minimum clearance from any roof edge is 300 mm.

Section 3: Electrical

Each string connects to the NS-Link inverter, which supports a maximum of sixteen panels. The inverter must be installed indoors, within three metres of the main consumer unit.

Section 4: Warranty

Panels carry a 25-year performance warranty guaranteeing at least 85 percent of rated output at year 25. The NS-Link inverter carries a separate 10-year warranty. Labour is covered for the first 2 years.

Section 5: Maintenance

Rinse panels with clean water twice per year. Do not use detergents or abrasive brushes, as these void the performance warranty. Inspect the mounting bolts annually and torque them to 18 newton metres.

Section 6: Support

Registered installers may contact technical support for diagnostics. Fault code E-14 indicates a string voltage mismatch and usually means one panel in the string has been shaded or wired in reverse.