

SERVICE MANUAL

EC180SX Injection Moulder

1. General

This manual describes the safe operation of the machine.

2. Troubleshooting

Error code E-104 indicates a servo overload on the injection axis.

Check the supply voltage is 24 VDC and the pressure is 3.5 bar.

Specification: M12 x 1.5 connector, PLC I/O X1-14.

3. Electrical Connections

The servo drive connects to the PLC I/O via X1-14.

ERR_204 indicates a communication loss between controller and drive.

WARNING: Disconnect power before servicing.

4. Maintenance

Inspect the hydraulic filter every 500 operating hours.

Replace the air filter annually.