
Expansion Testing Machine 2.0


Contents

1.Introduction:	2
2.TEST:	4
5.REPORTS:	5
List Reports:	
Print Report:	
Email Report:	
View –PDF Report:	
6.SETTING:	9
Setup-Email:	
7.CPU:	
8.CONTROLER DEVICE:	


1.Introduction:

Following is the block diagram for the expansion testing software.







2.TEST:




5.REPORTS:

List Reports:







Print Report:




Email Report:




View -PDF Report:




Add Remark:




6.SETTING:



Setup-Email:




How to Break App:




Click on "Config Test" button.


Manual Reboot:



Wifi setup:



Anydesk Id:



7.CPU:





8.CONTROLER DEVICE:



Hardware Connection Ports details:

Load Calibration sensor:










EXPANSION TESTING MACHINE

WIRING DETAILS.



INPUT-1					

INPUT-2						
		O/P	-V	+V		

Ex+: Loadcell Positive Excitation

Op+: Loadcell Positive Output

Op- : Loadcell Negative Output Ex+ : Loadcell Negative Excitation

O/P: Extensometer output -V: Negative (Com) for Extensometer

+V: Positive (+12V) voltage for Extensometer