PRODUCT USER GUIDE

Microphones, audio production and headphones | Website demonstration edition

Independent educational sample for a RØDE-inspired website. Not an official RØDE manual. Verify all connections and specifications against the manufacturer documentation for your exact model.

1. Before you begin

• Check the product model and inspect the device and cable for damage.

• Turn down recording or headphone volume before connecting equipment.

• Use compatible cables, mounts, and power supplies specified for the device.

2. VideoMicro II | On-camera microphone

• Mount the microphone securely using a compatible shock mount.

• Connect it to a compatible camera or mobile device with the correct cable or adapter.

• Select the external microphone input where required; record a short test and listen for distortion or handling noise.

• For outdoor recording, use a suitable windshield and keep the microphone pointed toward the sound source.

3. NT-USB+ | USB microphone

• Place the microphone on a stable stand and connect it to a compatible computer or device via USB.

• In the recording app or operating system, select the USB microphone as the input source.

• Set input level, speak at a consistent distance, and make a short test recording.

• Use headphones to monitor if supported, and avoid clipping by reducing recording gain.

4. RØDECaster Pro II | Audio production console

• Connect compatible microphones or audio sources to the appropriate inputs.

• Connect headphones or monitors and confirm output volume is low before playback.

• Configure input type, gain, routing and recording destination for your session.

• Record a brief test, confirm channel levels, and verify the saved file before a long session.

• For detailed routing, firmware and multitrack settings, consult the official device manual.

5. NTH-100 | Headphones

• Connect the headphone cable firmly to a compatible audio output.

• Start at low volume and increase only to a comfortable listening level.

• Adjust the headband for a secure fit and keep cables away from moving equipment.

• Wipe surfaces gently with a dry or slightly damp cloth; do not immerse in water.

6. Troubleshooting

• No audio: check cable seating, selected input/output device, mute settings and volume.

• Distorted audio: reduce input gain, move away from the microphone or lower playback level.

• Intermittent connection: inspect cables and ports; test with another compatible cable.

• Unclear recording: reduce room noise and position the microphone closer to the speaker.

• If the device becomes unusually hot, damaged or wet, disconnect it and seek qualified support.

7. Care and support

• Store devices in a dry, clean environment away from extreme heat and moisture.

• Avoid pulling cables by their wires; disconnect by the connector.

• For warranty, safety, compatibility and model-specific procedures, refer to the official RØDE documentation at rode.com.

Document purpose: demonstration downloadable user guide for a student website. No affiliation or endorsement by RØDE is implied.