
THE POWER BEHIND POWER.

Operating instructions
VACUTAP® VI. On-load tap-changer

7993270/03 EN



© All rights reserved by Maschinenfabrik Reinhausen
Dissemination and reproduction of this document and use and disclosure of its content are strictly prohibited unless expressly permitted.
Infringements will result in liability for compensation. All rights reserved in the event of the granting of patents, utility models or designs.
The product may have been altered since this document was published.
We reserve the right to change the technical data, design and scope of supply.
Generally the information provided and agreements made when processing the individual quotations and orders are binding.
The product is delivered in accordance with MR's technical specifications, which are based on information provided by the customer. The customer has a duty of care to ensure the compatibility of the specified product with the customer's planned scope of application.
The original operating instructions were written in German.

Table of contents

1 Introduction 4
1.1 Manufacturer 4
1.2 Completeness 4
1.3 Safekeeping 5
1.4 Notation conventions 5
1.4.1 Hazard communication system 5
1.4.2 Information system 6
1.4.3 Instruction system 6

2 Safety 8
2.1 Appropriate use 8
2.2 Inappropriate use 9
2.3 Fundamental safety instructions 9
2.4 Personnel qualification 10
2.5 Personal protective equipment 11

3 Product description 12
3.1 On-load tap-changer 12
3.1.1 Function description 12
3.1.2 Setup/models 12
3.1.3 Safety markings 14
3.1.4 Protective devices 14

4 Commissioning 15
4.1 Commissioning transformer at operating site 15
4.1.1 Commissioning the control cabinet 15
4.1.2 Checking the function of the Buchholz relay 15
4.1.3 Securing the motor cover with a padlock 16
4.1.4 Commissioning the transformer 16

5 Fault elimination 17
5.1 Tripping of the Buchholz relay 18
5.2 Operating the on-load tap-changer using the hand crank 19
5.3 Mounting the motor cover 21
5.4 Performing homing 23

6 Maintenance 24
6.1 Inspection 24
6.2 Maintenance intervals 25

7 Disposal 27
7.1 SVHC information in accordance with the REACH regulation 27

8 Technical data 28
8.1 On-load tap-changer properties 28
8.2 Permissible ambient conditions 29
8.3 Limit values for dielectric strength and water content of insulating fluids 30
8.4 Electrical properties 31
8.4.1 Step capacity diagram 31
8.4.2 Recovery voltage and breaking current 31
8.4.3 Insulation 33
8.4.4 Permitted voltage stresses 33

9 Drawings 37
9.1 10161739 38
9.2 10161741 39
9.3 10162433 40
9.4 10186374 42
9.5 10162405 47
9.6 10162430 48
9.7 10186369 51
9.8 10186372 54
9.9 10186373 55
9.10 10162713 56
9.11 10162466 57
9.12 10162434 58
9.13 10162441 59
9.14 10186367 60

1 Introduction

This technical file contains detailed descriptions for monitoring during operation, fault elimination, and maintenance.

It also includes safety instructions and general information about the product.

Information about installation can be found in the installation and commissioning instructions.

This technical file is intended solely for specially trained and authorized personnel.

1.1 Manufacturer

Maschinenfabrik Reinhausen GmbH
Falkensteinstraße 8
93059 Regensburg
Deutschland
+49 941 4090-0
sales@reinhausen.com
reinhausen.com

Customer portal

You can find additional information on this product in our customer portal at portal.reinhausen.com.



1.2 Completeness

This technical file is incomplete without the supporting documents.

The following documents are considered supporting documents:
- Unpacking instructions
- Supplement
- Routine test report
- Connection diagrams
- Dimensional drawings
- Order confirmation

1.3 Safekeeping

Keep this technical file and all supporting documents ready at hand and accessible for future use at all times.

1.4 Notation conventions

1.4.1 Hazard communication system

Warnings in this technical file are displayed as follows.

1.4.1.1 Warning relating to section

Warnings relating to sections refer to entire chapters or sections, sub-sections or several paragraphs within this technical file. Warnings relating to sections use the following format:

⚠ WARNING



Type of danger!
Source of the danger and outcome.
› Action
› Action

1.4.1.2 Embedded warning information

Embedded warnings refer to a particular part within a section. These warnings apply to smaller units of information than the warnings relating to sections. Embedded warnings use the following format:

⚠ DANGER! Instruction for avoiding a dangerous situation.

1.4.1.3 Signal words and pictograms

The following signal words are used:

Signal word	Definition
DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates measures to be taken to prevent damage to property.

Table 1: Signal words in warning notices

Pictograms warn of dangers:

Pictogram	Definition
	Warning of a danger point
	Warning of dangerous electrical voltage
	Warning of combustible substances
	Warning of danger of tipping
	Warning of danger of crushing

Table 2: Pictograms used in warning notices

1.4.2 Information system

Information is designed to simplify and improve understanding of particular procedures. In this technical file it is laid out as follows:

i Important information.

1.4.3 Instruction system

This technical file contains single-step and multi-step instructions.

Single-step instructions

Instructions which consist of only a single process step are structured as follows:

Aim of action
✓ Requirements (optional).
› Step 1 of 1.
  » Result of step (optional).
» Result of action (optional).

Multi-step instructions

Instructions which consist of several process steps are structured as follows:

Aim of action

✓ Requirements (optional).

1. Step 1.
   » Result of step (optional).
2. Step 2.
   » Result of step (optional).

» Result of action (optional).

2 Safety

- Read this technical file through to familiarize yourself with the product.
- This technical file is a part of the product.
- Read and observe the safety instructions provided in this chapter.
- Read and observe the warnings in this technical file in order to avoid function-related dangers.
- The product is manufactured on the basis of state-of-the-art technology. Nevertheless, risks to life and limb for the user or impairment of the product and other material assets due to the function may arise in the event of improper use.

2.1 Appropriate use

The product is an on-load tap-changer and adjusts the transmission ratio of transformers without interrupting the load flow. The product is designed solely for use in electrical energy systems and facilities. If used as intended and in compliance with the requirements and conditions specified in this technical file as well as the warning notices in this technical file and attached to the product, then the product does not present any danger to people, property or the environment. This applies throughout the service life of the product, from delivery, installation and operation to removal and disposal.

The following is considered intended use:

- Never actuate the on-load tap-changer with the hand crank if the transformer is energized. Only actuate the on-load tap-changer with the hand crank in emergency operation [▶Section 5.2, Page 19]. De-energize the transformer before using the hand crank.
- Only use the product with the transformer specified in the order.
- The serial numbers of the on-load tap-changer and control cabinet must match if the on-load tap-changer and control cabinet are supplied as a set for one order.
- You will find the standard valid for the product and the year of issue on the nameplate.
- Operate the product in accordance with this provided technical file, the agreed delivery conditions and the technical data.
- Ensure that all necessary work is performed by qualified personnel only.
- Only use the equipment and special tools included in the scope of delivery for the intended purpose and in accordance with the specifications of this technical document.
- The on-load tap-changer is not intended to be used with an oil filter unit.

Permitted electrical operating conditions

In addition to the design data in accordance with the order confirmation, observe the following limits for the through-current and the step voltage:

In the standard version, the on-load tap-changer is designed for sinusoidal 50/60 Hz alternating current with a curve form symmetrical to the zero axis and can switch 2 times the rated through-current I_r at its rated step voltage U_{ir}.

Exceeding the rated step voltage U_{ir} by up to 10% for a short period is permitted as long as the rated step capacity P_{StN} permissible for this step voltage is not exceeded.

2.2 Inappropriate use

Use is considered inappropriate if the product is used in a way other than as described in the "Appropriate use" section. In addition, observe the following:

Prohibited electrical operating conditions

All operating conditions that do not comply with the design data in accordance with the order confirmation are prohibited.

Prohibited operating conditions may arise due to short circuits as well as due to inrush current impulses when energizing transformers or other electrical machines. This applies to the affected transformer itself just as it does to transformers electrically connected in parallel or serially or other electrical machines.

Higher voltages may occur due to transformer overexcitation following load shedding, for example.

Operations outside of the permitted operating conditions can lead to injury to persons and damage to the product.

- Prevent any such operations outside of the permitted operating conditions by taking suitable measures.

2.3 Fundamental safety instructions

To prevent accidents, malfunctions and damage as well as unacceptable adverse effects on the environment, those responsible for transport, installation, operation, maintenance and disposal of the product or parts of the product must ensure the following:

Personal protective equipment

Loosely worn or unsuitable clothing increases the danger of becoming trapped or caught up in rotating parts and the danger of getting caught on protruding parts. This poses a danger to life and limb.

- Wear appropriate personal protective equipment such as a helmet, work gloves, etc. for the respective activity.
- Never wear damaged personal protective equipment.
- Never wear rings, necklaces, or other jewelry.
- If you have long hair, wear a hairnet.

Work area

Untidy and poorly lit work areas can lead to accidents.

- Keep the work area clean and tidy.
- Make sure that the work area is well lit.
- Observe the applicable laws for accident prevention in the relevant country.

Working during operation

The product may only be operated in a sound, operational condition. Otherwise it poses a danger to life and limb.

- Regularly check the operational reliability of safety equipment.
- Comply with the inspection work, maintenance work and maintenance intervals described in this technical file.

Explosion protection

Highly flammable or explosive gases, vapors and dusts can cause serious explosions and fire. This increases the danger to life and limb.

- Do not install, operate or perform maintenance work on the product in areas where a risk of explosion is present.

Safety markings

Warning signs and safety information plates are safety markings on the product. They are an important aspect of the safety concept.

- Observe all safety markings on the product.
- Make sure all safety markings on the product remain intact and legible.
- Replace safety markings that are damaged or missing.

Ambient conditions

To ensure reliable and safe operation, the product must only be operated under the ambient conditions specified in the technical data.

- Observe the specified operating conditions and requirements for the installation location.

Auxiliary materials and operating materials

Auxiliary materials and operating materials not approved by the manufacturer can lead to personal injury, damage to property and malfunctions of the product.

- Use insulating fluids that meet the requirements in accordance with IEC 60296.
- Only use conductive and grounded hoses, pipes, and pump equipment that are approved for flammable liquids.
- Only use lubricants and auxiliary materials approved by the manufacturer.
- Contact the manufacturer.

Modifications and conversions

Unauthorized or inappropriate changes to the product may lead to personal injury, material damage and operational faults.

- Only modify the product after consultation with Maschinenfabrik Reinhausen GmbH.

Spare parts

Spare parts not approved by Maschinenfabrik Reinhausen GmbH may lead to physical injury, damage to the product and malfunctions.

- Only use spare parts that have been approved by Maschinenfabrik Reinhausen GmbH.
- Contact Maschinenfabrik Reinhausen GmbH.

2.4 Personnel qualification

The person responsible for assembly, commissioning, operation, maintenance and inspection must ensure that the personnel are sufficiently qualified.

Electrically skilled person

The electrically skilled person has a technical qualification and therefore has the required knowledge and experience, and is also conversant with the applicable standards and regulations. The electrically skilled person is also proficient in the following:

- Can identify potential dangers independently and is able to avoid them.
- Is able to perform work on electrical systems.
- Is specially trained for the working environment in which (s)he works.

– Must satisfy the requirements of the applicable statutory regulations for accident prevention.

Electrically trained persons

An electrically trained person receives instruction and guidance from an electrically skilled person in relation to the tasks undertaken and the potential dangers in the event of inappropriate handling as well as the protective devices and safety measures. The electrically trained person works exclusively under the guidance and supervision of an electrically skilled person.

Operator

The operator uses and operates the product in line with this technical file. The operating company provides the operator with instruction and training on the specific tasks and the associated potential dangers arising from improper handling.

Technical Service

We strongly recommend having maintenance, repairs and retrofitting carried out by our Technical Service department. This ensures that all work is performed correctly. If maintenance is not carried out by our Technical Service department, please ensure that the personnel who carry out the maintenance are trained and authorized by Maschinenfabrik Reinhausen GmbH to carry out the work.

Authorized personnel

Authorized personnel are trained by Maschinenfabrik Reinhausen GmbH to carry out special maintenance.

2.5 Personal protective equipment

Personal protective equipment must be worn during work to minimize risks to health.

– Always wear the personal protective equipment required for the job at hand.
– Never wear damaged personal protective equipment.
– Observe information about personal protective equipment provided in the work area.

Protective clothing	Close-fitting work clothing with a low tearing strength, with tight sleeves and with no protruding parts. It mainly serves to protect the wearer against being caught by moving machine parts.
Safety shoes	To protect against falling heavy objects and slipping on slippery surfaces.
Safety glasses	To protect the eyes from flying parts and splashing liquids.
Visor	To protect the face from flying parts and splashing liquids or other dangerous substances.
Hard hat	To protect against falling and flying parts and materials.
Hearing protection	To protect against hearing damage.
Protective gloves	To protect against mechanical, thermal, and electrical hazards.

Table 3: Personal protective equipment

3 Product description

3.1 On-load tap-changer

3.1.1 Function description

On-load tap-changers are used to adjust the transmission ratio of transformers without interrupting the load flow. This makes it possible to compensate for aspects such as fluctuations in voltage occurring in the power transmission grid. For this purpose, on-load tap-changers are fitted in transformers and connected to the active part of the transformer.

A motor-drive unit which receives a control impulse from an electronic regulator changes the operating position of the on-load tap-changer, which adapts the transformer's transmission ratio to the prevailing operating requirements.




Figure 1: System overview of on-load tap-changer, drive system and transformer

1	Transformer tank	4	On-load tap-changer
2	Control cabinet	5	Active part
3	Motor		

3.1.2 Setup/models

The following drawings show the main components of the on-load tap-changer.

You will find a detailed drawing of the on-load tap-changer in the "Drawings [▶Section 9, Page 37]" chapter.

On-load tap-changer




Figure 2: On-load tap-changer

1	Motor cover	2	Motor cable
3	Sensor cable	4	Mounting flange
5	Security lug	6	Connection contacts

On-load tap-changer with AutoSync function (can be ordered as an option)

Homing is not necessary with on-load tap-changers that have the AutoSync function. The control system can automatically detect the position of the on-load tap-changer via the built-in sensor.




Figure 3: Overview with AutoSync function

1	Sensor cable, AutoSync function

3.1.3 Safety markings

The name plate with serial number is located on the motor cover.




Figure 4: Name plate

The following safety markings are used on the product:




Figure 5: Sealing module warning

1	Warning

3.1.4 Protective devices

The on-load tap-changer is situated in the oil room of the transformer without it's own oil compartment.

This eliminates the classic on-load tap-changer protection and the transformer protective devices take over the protection of the on-load tap-changer. The transformer manufacturer is responsible for the selection and dimensioning of the transformer protective devices. In this respect, it must be ensured that these protective devices are also effective in the event of on-load tap-changer errors and that no false tripping occurs.

To avoid false tripping, the response value must be greater than 0.65 m/s when using a Buchholz relay.

3.1.4.1 Security lug

The motor cover of the on-load tap-changer is fitted with a security lug for securing the motor cover with a padlock to prevent unauthorized access.

4 Commissioning

⚠ WARNING



Danger of explosion.

Explosive gases in the transformer, pipe system, oil conservator and at the dehydrating breather opening can deflagrate or explode and result in severe injury or death.

- Ensure that there are no ignition sources such as naked flame, hot surfaces or sparks (e.g. caused by the build-up of static charge) in the transformer's immediate surroundings during commissioning and that none occur.
- Do not operate any electrical devices (e.g. risk of sparks from impact wrench).
- Only use conductive and grounded hoses, pipes and pump equipment that are approved for flammable liquids.

⚠ WARNING



Danger of explosion!

Overloading the on-load tap-changer can lead to explosion and thus to death or serious injury.

- Ensure that the on-load tap-changer is not overloaded.
- Ensure use of the on-load tap-changer in accordance with section "Appropriate use".
- Prevent operations outside of the permitted operating conditions by taking suitable measures.
- The tap changer does not have an integrated protective device. The transformer manufacturer is responsible for the selection and dimensioning of the transformer protective devices. The protective devices must still function in the event of tap changer errors.

4.1 Commissioning transformer at operating site

4.1.1 Commissioning the control cabinet

A description of how to commission and test the control cabinet is given in the ETOS control cabinet operating instructions.

4.1.2 Checking the function of the Buchholz relay

Check that the Buchholz relay is functioning correctly in accordance with the corresponding operating instructions before commissioning the transformer

4.1.3 Securing the motor cover with a padlock

⚠ WARNING



Danger of explosion!

Operating the hand crank with the transformer energized can lead to death, serious injury and material damage due to overload of the on-load tap-changer.

- Never actuate the on-load tap-changer with the hand crank if the transformer is energized.
- De-energize the transformer before using the hand crank.
- Attach the padlock to prevent unauthorized opening. The padlock is not included in the MR scope of delivery.

- Secure the motor cover with a padlock before you commission the transformer.




Figure 6: Securing the motor cover with a padlock

4.1.4 Commissioning the transformer

- ✓ The signaling contact for falling below the minimum insulating fluid fill level in the transformer oil conservator is looped into the tripping circuit of the circuit breaker.
- ✓ The Buchholz relay and additional protective devices are looped into the circuit breaker's tripping circuit.
- ✓ The control cabinet and all protective devices are functioning correctly and are ready for use.
- ✓ The transformer is completely filled with insulating fluid.

⚠ WARNING



Electric shock

Remaining in the danger zone can result in death or severe injuries

- Ensure that nobody is in the danger zone when engaging the transformer circuit breaker.

1. Switch on the transformer.
2. *NOTICE!* Inrush current impulses can be significantly greater than the transformer rated current and may lead to current paths with asymmetrical or non-sinusoidal curve shapes and, as a result, overload the on-load tap-changer during the diverter switch operation. Only perform tap-change operations – whether under no load or under load conditions – once the inrush current impulse has subsided.

5 Fault elimination

⚠ WARNING



Danger of explosion.

Explosive gases under the sealing module can deflagrate or explode and result in severe injury or death.

- Ensure that there are no ignition sources such as open flames, hot surfaces or sparks (e.g. caused by the build-up of static charge) in the immediate surroundings and that none occur.
- De-energize all auxiliary circuits before removing the maintenance opening.
- Do not operate any electrical devices during the work (e.g. risk of sparks from impact wrench).

NOTICE

Damage to the on-load tap-changer and transformer.

If the transformer Buchholz relay or other protective devices trip, this can indicate damage to the on-load tap-changer and transformer. The transformer must not be energized without being inspected first.

- Check the on-load tap-changer and the transformer when the Buchholz relay or other protective devices have tripped.
- Do not use the equipment again until you are sure there is no damage to the on-load tap-changer or transformer.

NOTICE

Damage to the device!

Damage to the device due to condensate in the control cabinet.

- Always keep the control cabinet tightly closed.
- In the event of downtimes of more than 8 weeks prior to initial commissioning or an operational interruption of more than 2 weeks, connect and operate the anti-condensation heater in the control cabinet. If this is not possible, place a sufficient amount of desiccant (silicon-free) in the control cabinet.

The table below is intended to assist with detecting and, where possible, remedying faults.

For more information, please consult the operating instructions of the respective protective device.

In the event of faults on the on-load tap-changer and motor-drive unit which cannot be easily corrected on site or if the protective relay or additional protective devices have been tripped, please inform your authorized MR representative, the transformer manufacturer or contact MR directly.

Maschinenfabrik Reinhausen GmbH
Technical Service
Postfach 12 03 60
93025 Regensburg
Germany
Phone: +49 94140 90-0

Fax: +49 9 41 40 90-7001
E-mail: service@reinhausen.com
Internet: www.reinhausen.com

Fault description	Measure
On-load tap-changer not changing tap position (sluggishness, Raise keys / Lower keys not working, no audible diverter switch action)	Contact Maschinenfabrik Reinhausen.
No change in voltage on the transformer despite change in position on motor-drive unit	Contact Maschinenfabrik Reinhausen.
Tap position indicator on motor-drive unit and on-load tap-changer different	Carry out a homing operation in accordance with the control cabinet operating instructions.
Warning or tripping of Buchholz relay on transformer	Contact the transformer manufacturer and, if necessary, Maschinenfabrik Reinhausen.
Deviation from desired value when measuring winding resistance of the transformer	Contact the transformer manufacturer and, if necessary, Maschinenfabrik Reinhausen, and provide measured values.
Deviation from desired value during dissolved gas analysis (transformer oil)	Contact the transformer manufacturer and, if necessary, Maschinenfabrik Reinhausen, and provide measured values.
Deviation from desired value during transformer ratio test	Contact the transformer manufacturer and, if necessary, Maschinenfabrik Reinhausen, and provide measured values.
Deviation from limit value for insulating fluids	Change insulating fluid, check oil conservator breather.

Table 4: Fault elimination

5.1 Tripping of the Buchholz relay

⚠ WARNING



Danger of explosion.

Explosive gases in the Buchholz relay can deflagrate or explode and result in death or severe injuries.

- Wait 15 minutes after switching off the transformer before beginning further work on the Buchholz relay so that the gases can dissipate.
- Ensure that there are no ignition sources such as open flames, hot surfaces or sparks (e.g. caused by the build-up of static charge) in the immediate surroundings and that none occur.
- De-energize all auxiliary circuits before beginning work.
- Do not operate any electrical devices during the work (e.g. risk of sparks from impact wrench).

⚠ WARNING



Danger of death or serious injury!

Danger of severe injury or death if the on-load tap-changer and the transformer are insufficiently tested.

- It is imperative that you contact Maschinenfabrik Reinhausen to check the on-load tap-changer and the transformer if the Buchholz relay has tripped.
- Only use the equipment again when you are sure there is no damage to the on-load tap-changer or the transformer.

When the circuit breakers have been tripped by the Buchholz relay, proceed as follows:

1. Establish the time of tripping.
2. Determine the operating position of the on-load tap-changer.
3. Switch off the control cabinet via the supply fuse.
4. Check the on-load tap-changer. If insulating fluid is leaking, close the oil conservator stop valve immediately.

5. Read the Buchholz relay operating instructions.

5.2 Operating the on-load tap-changer using the hand crank

⚠ WARNING



Danger of explosion!

Operating the hand crank with the transformer energized can lead to death, serious injury and material damage due to overload of the on-load tap-changer.

- Never actuate the on-load tap-changer with the hand crank if the transformer is energized.
- De-energize the transformer before using the hand crank.

In error-free operation, the on-load tap-changer is only switched via the electronic control unit in the control cabinet.

However, if there is an urgent need to perform a tap-change operation while the electronic control unit is not functioning correctly, you can switch the on-load tap-changer using the hand crank.

1. De-energize and lock the transformer and the control cabinet to prevent unintentional restart.
2. Remove the padlock from the drive.




Figure 7: Removing the padlock

3. Remove the screws from the motor cover and mounting flange.




Figure 8: Removing the sealing module cover

4. Detach and remove the motor cover. To simplify removal of the motor cover, 4 tapped holes are provided in the motor cover. By screwing in screws, the motor can be pulled out evenly.




Figure 9: Pulling the motor cover off

5. Remove the hand crank adapter installed in the sealing module and insert it into the hand crank aperture.




Figure 10: Hand crank adapter

6. Turn the hand crank adapter using a suitable tool (wrench size 17) until the desired operating position is reached and the tap-change operation has been ended properly. *NOTICE!* If there is a blockage or the hand crank is difficult

to move, stop turning the hand crank adapter and contact Maschinenfabrik Reinhausen GmbH. When the tap-change operation has been properly completed, the positions of the feather key groove and the red triangle will match and the corresponding operating position will be indicated on the dial.

7. Remove the hand crank adapter and replace it in the mounting bracket.

5.3 Mounting the motor cover

1. Clean the sealing surface of the motor cover and the mounting flange. Check that the o-ring gasket sits cleanly in the motor cover.




Figure 11: Cleaning sealing surfaces

2. Align the motor shaft so that the feather key is in line with the triangle mark on the motor plate.




Figure 12: Triangle mark

3. When doing so, ensure that the shaft does not become damaged or scratched during alignment.




Figure 13: Aligning the motor shaft

4. Put the motor cover on so that the feather key on the drive shaft of the motor-drive unit slides into the keyway on the drive shaft of the on-load tap-changer in the sealing module and that at the same time the centering bolt in the motor plate engages in the locating hole provided for this in the sealing module. This ensures that the plugs of the micro-switch wiring in the motor cover and the sealing module are aligned.




Figure 14: Centering

5. Screw the motor cover to the mounting flange, tightening the screws crosswise. To do so, use the screws and washers provided by Maschinenfabrik Reinhausen.




Figure 15: Screwing on the drive

6. Secure the motor cover with a padlock to prevent unauthorized opening.




Figure 16: Securing the motor cover with a padlock

5.4 Performing homing

› Perform a homing operation in accordance with the ETOS® ID or the Tap Changer Control user guide.

i Homing is not necessary with on-load tap-changers that have the AutoSync function. The control system can automatically detect the position of the on-load tap-changer via the built-in sensor.

NOTICE

Damage to the on-load tap-changer.

Without homing, the on-load tap-changer may become damaged.

› After homing, do not separate the motor cover from the sealing module again.

› Repeat homing if the motor cover is separated from the sealing module.

6 Maintenance

⚠ DANGER



Electric shock!

An energized transformer could cause death or serious injuries.

- Switch off transformer on high and low-voltage side.
- Lock transformer to prevent unintentional restart.
- Ensure that everything is de-energized.
- Visibly connect all transformer terminals to ground (grounding leads, grounding disconnectors) and short circuit them.
- Cover or cordon off adjacent energized parts.

⚠ DANGER



Electric shock!

Working on the on-load tap-changer when on-load tap-changer components are energized can lead to death or serious injuries.

- De-energize all auxiliary circuits, such as the tap-change supervisory device, pressure relief device, pressure monitoring device.
- Make sure that everything is de-energized.

⚠ WARNING



Danger of explosion.

Explosive gases in the transformer, pipe system, oil conservator and at the dehydrating breather opening can deflagrate or explode and result in severe injury or death.

- Ensure that there are no ignition sources such as naked flames, hot surfaces or sparks (e.g. caused by the build-up of static charge) in the transformer's immediate surroundings and that none occur.
- Do not operate any electrical devices (e.g. risk of sparks from impact wrench).
- Only use conductive and grounded hoses, pipes and pump equipment that are approved for flammable liquids.

NOTICE

Damage to the control cabinet!

Damage to the control cabinet due to condensate.

- Always keep the control cabinet tightly closed.
- In the event of operation interruptions of more than 2 weeks, place a sufficient amount of desiccant in the control cabinet.

6.1 Inspection

Monitoring the on-load tap-changer and motor-drive unit/control cabinet is limited to occasional visual checks and monitoring the quality of the insulating fluid. For efficiency reasons, these visual inspections can be combined with the usual checks on the transformer.

Check the following:

Interval	Measure
Annually	Check the door seal, cable bushings, and ventilation of the motor-drive unit/control cabinet housing.
Annually	Check the sealing points on the motor cover and the on-load tap-changer sealing module.
Annually	Check the correct function of the installed electrical heater in the control cabinet housing.
Annually	Check the correct function of the transformer Buchholz relay and empty the gas collector.
Annually	Check the perfect condition of the breather (silica gel) for the transformer oil conservator.
Every 2 years	Check the quality of the insulating fluid of on-load tap-changers that are installed in positions other than the neutral point of windings (Class 2 in accordance with ICE 60214-1). 1. Take a sample of insulating fluid from the transformer. 2. Record the temperature of the sample (insulating fluid) immediately after the sample is taken. 3. Determine the dielectric strength and water content at an insulating fluid temperature of 20 °C ±5 °C. The dielectric strength and water content must comply with the limit values [▶Section 8.3, Page 30] specified in the technical data. 4. If the limit values are not complied with, change the insulating fluid.
Every 7 years	Check the quality of the insulating fluid of on-load tap-changers that are installed at the neutral point of windings (Class 1 in accordance with IEC 60214-1). 1. Take a sample of insulating fluid from the transformer. 2. Record the temperature of the sample (insulating fluid) immediately after the sample is taken. 3. Determine the dielectric strength and water content at an insulating fluid temperature of 20 °C ±5 °C. The dielectric strength and water content must comply with the limit values [▶Section 8.3, Page 30] specified in the technical data. 4. If the limit values are not complied with, change the insulating fluid.

Table 5: Inspection plan

6.2 Maintenance intervals

⚠ WARNING



Danger of explosion!

If pending maintenance work is not carried out immediately, this may lead to death or serious injury as a result of a progressive short circuit, for example.

› Adherence to the following maintenance intervals is mandatory.

Interval	Measure
After 500,000 operations or 300,000 electrical operations[1]	Maintenance of the on-load tap-changer. Contact Maschinenfabrik Reinhausen GmbH Technical Service [▶ Section 5, Page 17] for this.
After 1,000,000 operations or 600,000 electrical operations[1]	Replace the on-load tap-changer. Contact Maschinenfabrik Reinhausen GmbH about this.

Table 6: Maintenance plan

1 Due to pass-through positions, there may be switching operations without a voltage change, which are not counted as electrical switching operations. Please refer to the control cabinet maintenance progress indicator for details.

7 Disposal

For disposal, observe the national requirements applicable in the country of use.

If you have any questions about disassembly and disposal, please contact Maschinenfabrik Reinhausen GmbH's Technical Service department.

7.1 SVHC information in accordance with the REACH regulation

This product complies with the provisions of European Regulation 1907/2006/EC dated December 18, 2006 on the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH).

The following components of the product contain > 0.1% [w/w] of the SVHC substance lead (CAS no. 7439-92-1):

- Aluminum alloy
- Brass alloy
- Machining steel
- Standard parts with a low property class

8 Technical data

The key technical data for the on-load tap-changer is summarized in this chapter.

Further information on the selection of on-load tap-changers in general can be found in the chapters "Tap-changer designation", "Electrical properties" and "Selecting the on-load tap-changer" in the technical data TD61.

8.1 On-load tap-changer properties

On-load tap-changer	VI III 400 Y			VI III 400 D		
Number of phases and application	3, neutral point			3, at any point in the winding		
Maximum rated through-current I_{rm} [A]	400					
Rated short-time current [kA]	5					
Rated duration of short-circuits [s]	3					
Rated peak withstand current [kA]	12.5					
Maximum rated step voltage U_{irm} [V]	1500					
Step capacity P_{stm} [kVA]	600					
Rated frequency [Hz]	50...60					
Highest voltage for equipment U_m [kV] [1]	40 [2]	76 [3]	123	40 [2]	76 [3]	123/76
Rated lightning impulse withstand voltage [kV, 1.2|50 µs]	200	350	550	200	350	550
Rated short-duration power frequency withstand voltage [kV, 50 Hz, 1 min]	70	140	230	70	140	230

Table 7: Electrical data

[1] In accordance with IEC 60214-1: Highest effective value for phase-to-phase voltage in a three-phase system for which an on-load tap-changer is designed with respect to its insulation.

[2] Highest voltage for equipment Um 40 kV. Test voltages in accordance with IEC 60214-1:2014 for type series Um=36 kV.

[3] Highest voltage for equipment Um 76 kV. Test voltages in accordance with IEC 60214-1:2014 for type series Um=72.5 kV.

On-load tap-changer	VI III 400 Y	VI III 400 D
Max. number of operating positions	Without change-over selector: 14 With change-over selector: 27	
Weight without insulating fluid [kg]	Max. 150	
The on-load tap-changer is vacuum-tight		

Table 8: Mechanical data

8.2 Permissible ambient conditions

Air temperature during operation [°C]	- 25...+ 55
Transport temperature, storage temperature [°C]	- 40...+ 70
Max. drying temperature [°C]	+125
Insulating fluid	– Unused insulating oils derived from petroleum products[1] in accordance with IEC 60296 and ASTM D3487 (equivalent standards on request) – Unused insulating oils derived from other virgin hydrocarbons in accordance with IEC 60296, or blends of these oils with petroleum products[1] in accordance with IEC 60296, ASTM D3487 or equivalent standards on request – Alternative insulating fluids, such as natural and synthetic esters or silicone oils, on request [1] Gas-to-liquid oils (GTL oils) are understood in this context to be petroleum products
Temperature of the insulating fluid in operation	
– Mineral insulating oil (IEC 60296) [°C]	-25...+105 (up to +115 when the transformer is in emergency operation)[1]
– Synthetic ester fluid (IEC 61099) [°C]	On request
– Natural ester fluid (IEC 62770) [°C]	On request
Permissible absolute pressure during operation [bar]	0.7...1.5
Installation height of the oil conservator [m]	Max. 5
Installation altitude above sea level [m]	Max. 2,000[2]
Degree of protection	IP66 in accordance with IEC 60529

Table 9: Permissible ambient conditions

[1] Arctic version down to -40 °C available on request (fixed operation without switching operations)

[2] For altitudes >2,000 m, a minimum height must be observed for the oil conservator. (Further information is available in the "Installation altitude above sea level" chapter in the TD61 Technical Data.)

8.3 Limit values for dielectric strength and water content of insulating fluids

Limit values for insulating fluids in accordance with IEC 60296	U_d	H_2O
When commissioning the transformer for the first time	> 60 kV/2.5 mm	< 12 ppm
During operation	> 30 kV/2.5 mm	< 30 ppm
After maintenance	> 50 kV/2.5 mm	< 15 ppm

Table 10: Limit values for insulating fluids in accordance with IEC 60296, dielectric strength measured in accordance with IEC 60156, water content measured in accordance with IEC 60814

Limit values for natural esters in accordance with IEC 62770	U_d	H_2O
When commissioning the transformer for the first time	> 60 kV/2.5 mm	≤ 100 ppm
During operation	> 30 kV/2.5 mm	≤ 200 ppm
After maintenance	> 50 kV/2.5 mm	≤ 100 ppm

Table 11: Limit values for natural esters in accordance with IEC 62770, dielectric strength measured in accordance with IEC 60156, water content measured in accordance with IEC 60814

Limit values for synthetic esters in accordance with IEC 61099	U_d	H_2O
When commissioning the transformer for the first time	> 60 kV/2.5 mm	≤ 100 ppm
During operation	> 30 kV/2.5 mm	≤ 400 ppm
After maintenance	> 50 kV/2.5 mm	≤ 150 ppm

Table 12: Limit values for synthetic esters in accordance with IEC 61099, dielectric strength measured in accordance with IEC 60156, water content measured in accordance with IEC 60814

8.4 Electrical properties

This chapter contains information about the electrical properties.

8.4.1 Step capacity diagram




Figure 17: Step capacities (rated voltage Uir, rated through-current Ir)

8.4.2 Recovery voltage and breaking current

During its switching operation, the tap winding is briefly electrically isolated from the main winding by the reversing change-over selector or coarse change-over selector. It then adopts a potential resulting from the voltages of the adjacent windings and coupling capacity for these windings or grounded parts.

This potential shift of the tap winding produces corresponding voltages between the deactivating change-over selector contacts because one contact is always connected to the tap winding and the other contact is always connected to the main winding. This voltage is known as the recovery voltage U_W.

When separating the change-over selector contacts, a capacitive current has to be interrupted. This current depends on the aforementioned coupling capacities of the tapped winding. This current is known as the breaking current I_S.

The recovery voltage U_W and breaking current I_S may result in impermissible discharge events on the change-over selector. The permissible range of recovery voltage U_W and breaking current I_S can be seen in the following diagrams. For more information about recovery voltage and breaking current, see Technical Data TD61 – General Part.




Figure 18: Recovery voltage without tie-in resistor

1	Mineral insulating oil in accordance with IEC 60296
2	Alternative insulating fluids in accordance with IEC 61099 or IEC 62770

For versions with tie-in resistor, the tie-in resistor will be delivered separately. The transformer manufacturer is responsible for installation in the transformer and connection to the tap changer.




Figure 19: Recovery voltage with tie-in resistor

1	Mineral insulating oil in accordance with IEC 60296
2	Alternative insulating fluids in accordance with IEC 61099 or IEC 62770

8.4.3 Insulation

The stated rated withstand voltages for the insulation arrangement apply to new, perfectly dried insulation in prepared transformer oil (at an ambient temperature of at least 10 °C).

The following details are needed to select an on-load tap-changer:
- Maximum mains-frequency operating voltages
- Test AC voltages during transformer test
- Impulse voltages during transformer test (lightning surge, switching surge, wave isolated in back and wave isolated in front)

The transformer manufacturer is responsible for the correct choice of rated withstand voltages depending on insulation coordination at the operating site. The necessary rated withstand voltages should be observed for the various insulation distances:
- Insulation to ground
- With multi-phase types: Insulation between phases
- Insulation between a phase's contacts

The details required depend on the type of regulation (e.g. basic connection of tapped winding with on-load tap-changers) and the tap-changer type.

8.4.4 Permitted voltage stresses

This section describes the permissible voltage stress of the on-load tap-changer.

When selecting the on-load tap-changer, you must check that the highest stresses do not exceed the related rated withstand voltages at the insulation distances.




Figure 20: Insulation distances

a1	= between tap selector contacts of the winding of one tap position (connected or not connected)
a	= between the beginning and end of a tap winding and, for a model with a coarse winding, also between the beginning and end of a coarse winding. Note for coarse tap selector connection in the (-) change-over selector position: When stressed with impulse voltage, the permissible withstand voltage "a" between the end of a coarse winding connected with the K tap selector contact and the tap selector contact at the end of the tap winding of the same phase must be adhered to.
b	= between the tap selector contacts of different phases and between change-over selector contacts of different phases that are connected with the beginning/end of a step of the tap winding or with a tap selector contact The permissible voltages between the contacts for tap-changers for delta connections depend on the positions of the change-over selector and tap selector. The different permissible withstand voltages b1, b2 or b3 must therefore be noted for an insulation distance: b_1 = between selected contacts for different phases b_2 = from the selected contact of one phase to non-selected contacts of other phases b_3 = between non-selected contacts for different phases

f	= between tap selector contacts and (+) change-over selector contacts to ground Different values apply for the delta connection version: f_1 = between take-off lead and ground and in (+) position of the change-over selector between (+) change-over selector contacts and ground f_2 = between non-selected tap selector contacts and in (-) position of the change-over selector between (+) contacts and ground
Additionally for coarse tap selector connection in (+) position of the change-over selector:	
c1	= from one (-) change-over selector contact to the take-off lead of the same phase
c2	= between (-) change-over selector contacts of different phases and from one (-) change-over selector contact to one (+) change-over selector contact of another phase For tap-changers, different permissible values should be noted for the delta connection: $c2_1$ = between a (-) change-over selector contact and a (+) change-over selector contact of another phase $c2_2$ = between (-) change-over selector contacts of different phases

Voltage waveform	VI-Y Um=40kV				VI-D Um=40kV				VI-Y Um=76kV			
Insulation distances	LI	LIC	SI	AC	LI	LIC	SI	AC	LI	LIC	SI	AC
a1	100	110	80	20	100	110	80	20	100	110	80	20
a	200	220	160	50	200	220	160	50	200	220	160	50
b	200	220	160	85	-	-	-	-	200	220	160	85
b1	-	-	-	-	200	220	160	70	-	-	-	-
b2	-	-	-	-	250	275	200	80	-	-	-	-
b3	-	-	-	-	300	330	240	90	-	-	-	-
f1	200	220	160	70	200	220	160	70	350	385	280	140
f2	250	275	200	80	250	275	200	80	490	539	392	165
c1	400	440	320	100	400	440	320	100	400	440	320	100
c2	300	330	240	90	-	-	-	-	350	385	280	140
$c2_1$	-	-	-	-	250	275	200	80	-	-	-	-
$c2_2$	-	-	-	-	300	330	240	90	-	-	-	-

Table 13: Rated insulation level

Voltage waveform	VI-D Um=76kV				VI-Y Um=123kV				VI-D Um=123/76kV			
Insulation distances	LI	LIC	SI	AC	LI	LIC	SI	AC	LI	LIC	SI	AC
a1	100	110	80	20	100	110	80	20	100	110	80	20
a	200	220	160	50	200	220	160	50	200	220	160	50
b	-	-	-	-	200	220	160	85	-	-	-	-
b1	350	385	280	140	-	-	-	-	350	385	280	140
b2	490	539	392	165	-	-	-	-	490	539	392	165
b3	520	572	416	180	-	-	-	-	520	572	416	180
f1	350	385	280	140	550	605	460	230	550	605	460	230
f2	490	539	392	165	650	715	520	275	650	715	520	275
c1	400	440	320	100	400	440	320	100	400	440	320	100
c2	-	-	-	-	350	385	280	140	-	-	-	-

Voltage waveform	VI-D Um=76kV				VI-Y Um=123kV				VI-D Um=123/76kV			
Insulation distances	LI	LIC	SI	AC	LI	LIC	SI	AC	LI	LIC	SI	AC
$c2_1$	490	539	392	165	-	-	-	-	490	539	392	165
$c2_2$	520	572	416	180	-	-	-	-	520	572	416	180


Table 14: Rated insulation level


LI	Full wave lightning impulse (kV, 1.2/50 µs)
LIC	Chopped wave lightning impulse (kV, 1.2/50/3 µs)
SI	Switching impulse voltage (kV, 250/2500 µs)
AC	Applied voltage (kV, 50 Hz, 1 min)


Table 15: Abbreviations for the rated insulation level


9 Drawings


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.











Betriebsstellungen / SERVICE POSITIONS max. 27			
Um in kV	e	p	l
	Maße / DIMENSIONS in mm		
40 – Y	422	320	1240
40 – D	422	360	1320
76 – Y	532	320	1350
76 – D	532	420	1550
123 – Y	637	320	1455
123/76 – D	637	420	1655

(1) – Anschlusskontakt / TERMINAL

(A) – Ableitkontakt / OUTPUT TERMINAL

Gewicht max. ca. 150 kg
Verbindlich für die Bezeichnung der Anschlusskontakte und Phasen ist das für den Auftrag gültige Ausführungsschaltbild
WEIGHT MAX. APPROX 150 KG
THE CONNECTION DIAGRAM APPLICABLE TO THE ORDER IS BINDING FOR THE DESIGNATION OF THE TERMINALS AND PHASES.

	NAME	DATE
DFTR.	FELDMEIERS	10.02.2025
CHKD.	MUENZBERG	10.02.2025
STAND	KLEYN	11.02.2025


DOCUMENT NO. SED 11719280 000 00
CHANGE NO. 1133298
SCALE 1:10


DIMENSION IN mm EXCEPT AS NOTED


ON-LOAD TAP-CHANGER VACUTAP® VI
VI III 40-123kV WITH CHANGE-OVER SELECTOR
DIMENSION DRAWING

SERIAL NUMBER –
MATERIAL NUMBER 101617390M
SHEET 1 / 1
A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.








A–A
1:5



B–B
1:2



C–C
1:2

papierisoliert / PAPER INSULATED

Betriebsstellungen / SERVICE POSITIONS max. 14			
Um in kV	e	p	l
	Maße / DIMENSIONS in mm		
40 – Y	422	320	1240
40 – D	422	360	1320
76 – Y	532	320	1350
76 – D	532	420	1550
123 – Y	637	320	1455
123/76 – D	637	420	1655

(1) – Anschlusskontakt / TERMINAL

(A) – Ableitkontakt / OUTPUT TERMINAL

Gewicht max. ca. 150 kg
Verbindlich für die Bezeichnung der Anschlusskontakte und Phasen ist das für den Auftrag gültige Ausführungsschaltbild
WEIGHT MAX. APPROX 150 KG
THE CONNECTION DIAGRAM APPLICABLE TO THE ORDER IS BINDING FOR THE DESIGNATION OF THE TERMINALS AND PHASES.

	NAME	DATE
DFTR.	FELDMEIERS	10.02.2025
CHKD.	MUENZBERG	10.02.2025
STAND	KLEYN	11.02.2025

DOCUMENT NO. SED 11719198 000 00
CHANGE NO. 1133298
SCALE 1:10


DIMENSION IN mm EXCEPT AS NOTED

ON-LOAD TAP-CHANGER VACUTAP® VI
VI III 40-123kV WITHOUT CHANGE-OVER SELECTOR
DIMENSION DRAWING


SERIAL NUMBER –
MATERIAL NUMBER 101617410M
SHEET 1 / 1
A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Laststufenschalter /
ON-LOAD TAP-CHANGER




Laststufenschalter Kopf /
ON-LOAD TAP-CHANGER HEAD



1:5


Justiermarkierung /
ADJUSTMENT MARKING

Stellungsanzeige /
TAP POSITION INDICATOR



14140

Wählerebene mit Kundenanschluss /
SELECTOR PLANE WITH CUSTOMER CONNECTION



	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222200 000 01	
EHKO.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

(A) = Ableitkontakt / OUTPUT TERMINAL

(B) = Betriebsstellung 1 – Justierstellung / SERVICE POSITION 1 – ADJUSTMENT POSITION

alle Ansichten in Justierstellung dargestellt / ALL VIEWS ARE SHOWN IN ADJUSTMENT POSITION
Verbindungsbrücken optional bestellbar / CONNECTION BRIDGES AVAILABLE ON REQUEST

Verbindlich für die Bezeichnung der Anschlusskontakte und Phasen ist das für den Auftrag gültige Ausführungsschaltbild /
THE CONNECTION DIAGRAM APPLICABLE TO THE ORDER IS BINDING FOR THE DESIGNATION OF TERMINALS AND PHASES

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITHOUT CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–

MATERIAL NUMBER
101624330M


SHEET
1 / 2

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Ausführbare Schaltungen ohne Vorwähler / REALIZABLE CONNECTIONS WITHOUT CHANGE-OVER SELECTOR


14130




14120




14110




14100




14090



14080




14070



Schaltung / CONNECTION	Stufen der Regelwicklung / STEPS OF TAP WINDING
14140	13
14130	12
14120	11
14110	10
14100	9
14090	8
14080	7
14070	6

Beispielschaltbild für 14140 / EXAMPLE CONNECTION DIAGRAMM FOR 14140



	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222200 000 01	
CHKD.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITHOUT CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–


MATERIAL NUMBER
101624330M

SHEET
2 / 2


A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Laststufenschalter /
ON-LOAD TAP-CHANGER




Laststufenschalter Kopf /
ON-LOAD TAP-CHANGER HEAD



1:5


Justiermarkierung /
ADJUSTMENT MARKING

Stellungsanzeige /
TAP POSITION INDICATOR




Wählerebene mit Kundenanschluss /
SELECTOR PLANE WITH CUSTOMER CONNECTION

14271W / 14273W



14271G / 14273G



(A) = Ableitkontakt / OUTPUT TERMINAL

(B) = Betriebsstellung 1 – Justierstellung / SERVICE POSITION 1 – ADJUSTMENT POSITION

(3W) = 3W-Verbindungsbrücke nur bei 3W-Ausführung / 3W-CONNECTION BRIDGES ONLY FOR 3W-VERSIONS

(3G) = 3G-Verbindungsbrücke nur bei 3G-Ausführung / 3G-CONNECTION BRIDGES ONLY FOR 3G-VERSIONS

alle Ansichten in Justierstellung dargestellt / ALL VIEWS ARE SHOWN IN ADJUSTMENT POSITION
Verbindungsbrücken optional bestellbar / CONNECTION BRIDGES AVAILABLE ON REQUEST

Verbindlich für die Bezeichnung der Anschlusskontakte und Phasen ist das für den Auftrag gültige Ausführungsschaltbild /
THE CONNECTION DIAGRAM APPLICABLE TO THE ORDER IS BINDING FOR THE DESIGNATION OF TERMINALS AND PHASES

	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222223 000 01	
CHKD.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITH CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–

MATERIAL NUMBER
101863740M


SHEET
1 / 5

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Ausführbare Schaltungen mit Vorwähler / REALIZABLE CONNECTIONS WITH CHANGE-OVER SELECTOR


14251W / 14253W




14251G / 14253G




14231W / 14233W




14231G / 14233G




14211W / 14213W




14211G / 14213G



14191W / 14193W / 14181W* / 14183W*



14191G / 14193G / 14181G* / 14183G*



* Position 19 blockiert / POSITION 19 BLOCKED

	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222223 000 01	
CHKD.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITH CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–


MATERIAL NUMBER 101863740M

SHEET 2 / 5


A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


14171W / 14173W




14171G / 14173G




14151W



14151G



Beispielschaltbild für 14271W /
EXAMPLE CONNECTION DIAGRAMM FOR 14271W



	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222223 000 01	
EHKO.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITH CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–


MATERIAL NUMBER
101863740M

SHEET
3 / 5


A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Beispielschaltbild für 14273W /
EXAMPLE CONNECTION DIAGRAMM FOR 14273W



Beispielschaltbild für 14271G /
EXAMPLE CONNECTION DIAGRAMM FOR 14271G



Beispielschaltbild für 14273G /
EXAMPLE CONNECTION DIAGRAMM FOR 14273G



	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222223 000 01	
EHKO.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITH CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–

MATERIAL NUMBER 101863740M

SHEET 4 / 5

A3

Schaltung / CONNECTION	Stufen der Regelwicklung / STEPS OF TAP WINDING	Stufen der Grobstufen-Wicklung / STEPS OF COARSE STEP WINDING
14271W	14	
14251W	13	
14231W	12	
14211W	11	
14191W	10	
14181W	10	
14171W	9	
14151W	8	
14273W	12	
14253W	11	
14233W	10	
14213W	9	
14193W	8	
14183W	8	
14173W	7	
14271G	13	14
14251G	12	13
14231G	11	12
14211G	10	11
14191G	9	10
14181G	9	10
14171G	8	9
14151G	7	8
14273G	12	12
14253G	11	11
14233G	10	10
14213G	9	9
14193G	8	8
14183G	8	8
14173G	7	7

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

	DATE	NAME	DOCUMENT NO.	
DFTR.	15.07.2025	FELDMEIERS	SED 117222223 000 01	
EHKO.	15.07.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	16.07.2025	KLEYN	1121934	1:10


DIMENSION IN mm EXCEPT AS NOTED


MR

ON-LOAD TAP-CHANGER VACUTAP® VI
CONNECTIONS WITH CHANGE-OVER SELECTOR
ADJUSTMENT PLAN

SERIAL NUMBER
–
MATERIAL NUMBER 101863740M
SHEET 5 / 5
A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.





A–A

B–B



Werkstoff: Stahl (z.B. S235JR EN 10025-2) /
MATERIAL: STEEL (FOR EXAMPLE S235JR EN10025-2)

Tolerierung / TOLERANCING ISO 8015
Allgemeintoleranz / GENERAL TOLERANCE ISO 2768:1989 -mH
Oberflächenangaben / SURFACE INDICATION ISO 1302:2002
Werkstückkanten / WORKPIECE EDGES ISO 13715

+0,50 −0,50

Ra 6,3 | Ra 12,5 | Dichtfläche / SEALING SURFACE Ra 3,2

	DATE	NAME	DOCUMENT NO.	
DFTR.	13.02.2025	FELDMEIERS	SED 11884721 000 00	
CHKD.	13.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	13.02.2025	KLEYN	1133298	1:2

DIMENSION IN mm EXCEPT AS NOTED

ON-LOAD TAP-CHANGER VACUTAP® VI
DIMENSIONS MOUNTING FLANGE
DIMENSION DRAWING

SERIAL NUMBER –


MATERIAL NUMBER 101624050M


SHEET 1 / 1


A2

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Ausführung / DESIGN: 14130








Z


Z
1:1



Anschluss Trafoleitung /
CONNECTION TRANSFORMER LEAD

Befestigung Brücken schematische Darstellung / FASTENING BRIDGES SCHEMATIC VIEW

1:1



Befestigungsmaterial / FASTENING MATERIALS M8 (1)
Abschirmkappe / SCREENING CAP M8 (2)
Kontaktbrücke / CONTACT BRIDGE (2)
Anschlusskontakt / TERMINAL
Abschirmkappe / SCREENING CAP M8 (2)

(1) Befestigungsmaterial gehört nicht zum Lieferumfang. Jede Verschraubung durch geeignete Maßnahmen gegen Lösen und Setzen sichern. / FASTENING MATERIAL IS NOT INCLUDED IN THE SCOPE OF DELIVERY. TAKE SUITABLE MEASURES TO SECURE EACH SCREW CONNECTION AGAINST LOOSENING AND SETTING.

(2) auf Anfrage verfügbar / AVAILABLE ON REQUEST

Schraubenverbindungen nicht dargestellt, da nicht im Lieferumfang enthalten.
SCREW CONNECTIONS NOT PICTURED BECAUSE NOT INCLUDED IN THE SCOPE OF DELIVERY

	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117194.24 000 00	
EHKO.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR


ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITHOUT CHANGE-OVER SELECTOR
DIMENSION DRAWING


SERIAL NUMBER –
MATERIAL NUMBER 101624300M
SHEET 1 / 3

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Ausführung / DESIGN: 14120







Ausführung / DESIGN: 14110





Ausführung / DESIGN: 14100





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117719424 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITHOUT CHANGE-OVER SELECTOR
DIMENSION DRAWING

SERIAL NUMBER
–


MATERIAL NUMBER 101624300M


SHEET 2 / 3

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Ausführung / DESIGN: 14090







Ausführung / DESIGN: 14080





Ausführung / DESIGN: 14070





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 1117194.24 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITHOUT CHANGE-OVER SELECTOR
DIMENSION DRAWING

SERIAL NUMBER
–


MATERIAL NUMBER 101624300M


SHEET 3 / 3


A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Ausführung / DESIGN: 14251W / 14251G / 14253W / 14253G









Z

Z
1:1



Befestigung Brücken schematische Darstellung / FASTENING BRIDGES SCHEMATIC VIEW

1:1



(1) Befestigungsmaterial gehört nicht zum Lieferumfang. Jede Verschraubung durch geeignete Maßnahmen gegen Lösen und Setzen sichern. / FASTENING MATERIAL IS NOT INCLUDED IN THE SCOPE OF DELIVERY.
TAKE SUITABLE MEASURES TO SECURE EACH SCREW CONNECTION AGAINST LOOSENING AND SETTING.

(2) auf Anfrage verfügbar / AVAILABLE ON REQUEST

Schraubenverbindungen nicht dargestellt, da nicht im Lieferumfang enthalten.
SCREW CONNECTIONS NOT PICTURED BECAUSE NOT INCLUDED IN THE SCOPE OF DELIVERY

Verbindungsbrücken für Ausführung 3W (1/- und 13/+) sind nicht im Lieferumfang enthalten /
CONNECTING BRIDGES FOR DESIGN 3W (1/- und 13/+) ARE NOT INCLUDED IN THE SCOPE OF DELIVERY

	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117194577 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	133298	1:5

DIMENSION IN mm EXCEPT AS NOTED


ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITH CHANGE-OVER SELECTOR
DIMENSION DRAWING


SERIAL NUMBER
–
MATERIAL NUMBER 101863690M
SHEET 1 / 3

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Ausführung / DESIGN: 14231W / 14231G / 14233W / 14233G







Ausführung / DESIGN: 14211W / 14211G / 14213W / 14213G





Ausführung / DESIGN: 14191W / 14191G / 14193W / 14193G 14181W / 14181G / 14183W / 14183G





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117194577 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITH CHANGE-OVER SELECTOR
DIMENSION DRAWING

SERIAL NUMBER
–


MATERIAL NUMBER 101863690M


SHEET 2 / 3

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Ausführung / DESIGN:: 14171W / 14171G / 14173W / 14173G





Ausführung / DESIGN: 14151W / 14151G





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117194577 000 00	
EHKO.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
TAP SELECTOR BRIDGES WITH CHANGE-OVER SELECTOR
DIMENSION DRAWING

SERIAL NUMBER
–


MATERIAL NUMBER 101863690M


SHEET 3 / 3

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.


Ausführung / DESIGN: 1G






Ausführung / DESIGN: 3G





Befestigung Brücken schematische Darstellung / FASTENING BRIDGES SCHEMATIC VIEW



(1) Befestigungsmaterial gehört nicht zum Lieferumfang. Jede Verschraubung durch geeignete Maßnahmen gegen Lösen und Setzen sichern. / FASTENING MATERIAL IS NOT INCLUDED IN THE SCOPE OF DELIVERY.
TAKE SUITABLE MEASURES TO SECURE EACH SCREW CONNECTION AGAINST LOOSENING AND SETTING.

(2) auf Anfrage verfügbar / AVAILABLE ON REQUEST

Schraubenverbindungen nicht dargestellt, da nicht im Lieferumfang enthalten.
SCREW CONNECTIONS NOT PICTURED BECAUSE NOT INCLUDED IN THE SCOPE OF DELIVERY

	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117222167 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5


DIMENSION IN mm EXCEPT AS NOTED

MR


Laststufenschalter VACUTAP® VI
BRIDGES CHANGE-OVER SELECTOR 1G/3G
DIMENSION DRAWING

SERIAL NUMBER
–
MATERIAL NUMBER 101863720M
SHEET 1 / 1
A3

Ausführung / DESIGN: 1W/3W



Befestigung Brücken schematische Darstellung / FASTENING BRIDGES SCHEMATIC VIEW



(1) Befestigungsmaterial gehört nicht zum Lieferumfang. Jede Verschraubung durch geeignete Maßnahmen gegen Lösen und Setzen sichern. / FASTENING MATERIAL IS NOT INCLUDED IN THE SCOPE OF DELIVERY.
TAKE SUITABLE MEASURES TO SECURE EACH SCREW CONNECTION AGAINST LOOSENING AND SETTING.

(2) auf Anfrage verfügbar / AVAILABLE ON REQUEST

Schraubenverbindungen nicht dargestellt, da nicht im Lieferumfang enthalten.
SCREW CONNECTIONS NOT PICTURED BECAUSE NOT INCLUDED IN THE SCOPE OF DELIVERY

Verbindungsbrücken für Ausführung 3W (1/- und 13/+) sind nicht im Lieferumfang enthalten /
CONNECTING BRIDGES FOR DESIGN 3W (1/- und 13/+) ARE NOT INCLUDED IN THE SCOPE OF DELIVERY

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117722081 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5


DIMENSION IN mm EXCEPT AS NOTED


MR

ON-LOAD TAP-CHANGER VACUTAP® VI
BRIDGES CHANGE-OVER SELECTOR 1W/3W
DIMENSION DRAWING

SERIAL NUMBER
–
MATERIAL NUMBER 101863730M
SHEET 1 / 1
A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117223323 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND.	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
INSTALLATION STANDARD DESIGN
DIMENSION DRAWING


SERIAL NUMBER
–


MATERIAL NUMBER
101627130M

SHEET
1 / 1

A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.





	DATE	NAME	DOCUMENT NO.	
DFTR.	10.02.2025	FELDMEIERS	SED 117224430 000 00	
CHKD.	10.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
INSTALLATION BELL-TYPE TANK
DIMENSION DRAWING

SERIAL NUMBER
–


MATERIAL NUMBER
101624660M


SHEET
1 / 1

A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.

Empfohlene Mindestabmessungen für stirnseitige Zugangsöffnung /
RECOMMENDED MINIMUM DIMENSIONS FOR FRONTAL ACCESS OPENING





	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 117722532 000 00	
EHKO.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND.	11.02.2025	KLEYN	1133298	1:20

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
DIMENSIONS ACCESS OPENING
DIMENSION DRAWING


SERIAL NUMBER
–


MATERIAL NUMBER 101624340M


SHEET 1 / 1

A3


MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.







A–A
1:1



papierisoliert /
PAPER INSULATED

	DATE	NAME	DOCUMENT NO.	
DFTR.	11.02.2025	FELDMEIERS	SED 11723123 000 00	
CHKD.	11.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

MR

ON-LOAD TAP-CHANGER VACUTAP® VI
OPTIONAL TAKE-OFF LEAD IN FRONT
DIMENSION DRAWING


SERIAL NUMBER
–


MATERIAL NUMBER
101624410M

SHEET
1 / 1


A3

MASCHINENFABRIK REINHAUSEN GMBH COPYRIGHT RESERVED
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN.






A–A
1:1




Leitung kundenseitig /
LEAD PROVIDED BY CUSTOMER

Scheibe kundenseitig /
WASHER PROVIDED BY CUSTOMER


Erdungsschraube kundenseitig /
GROUNDING SCREW PROVIDED BY CUSTOMER



Vorhängeschloss
(nicht im MR-Lieferumfang enthalten) /
PADLOCK (NOT INCLUDED
IN THE MR-SCOPE OF DELIVERY)



Z
1:1



WARNUNG!
EXPLOSIONSGEFAHR!

Eine Betätigung der Handkurbel bei unter Spannung stehendem Transformator kann zu Tod, schweren Verletzungen und Sachschäden durch Überlastung des Laststufenschalters führen.

- **Niemals** diesen Laststufenschaltertyp bei unter Spannung stehendem Transformator
- mit der Handkurbel betätigen!
- Transformator vor Betätigung der Handkurbel spannungsfrei schalten!
  Vorhängeschloss zum Schutz vor unbefugtem Öffnen anbringen (Vorhängeschloss ist **nicht** im MR-Lieferumfang enthalten)

WARNING!
DANGER OF EXPLOSION!

OPERATING THE HAND CRANK WITH THE TRANSFORMER ENERGIZED CAN LEAD TO DEATH, SERIOUS INJURY AND MATERIAL DAMAGE DUE TO OVERLOAD OF THE ON-LOAD TAP-CHANGER

- **NEVER** ACTUATE THIS TYPE OF ON-LOAD TAP-CHANGER WITH THE HAND CRANK IF
- THE TRANSFORMER IS ENERGIZED!
- DE-ENERGIZE THE TRANSFORMER BEVORE USING THE HAND CRANK!
  ATTACH **PADLOCK** TO PROTECT AGAINST UNAUTHORIZED OPENING (PADLOCK IS **NOT** INCLUDED IN THE MR SCOPE OF DELIVERY)

	DATE	NAME	DOCUMENT NO.	
DFTR.	10.02.2025	FELDMEIERS	SED 11722515 000 00	
CHKD.	10.02.2025	MUENZBERG	CHANGE NO.	SCALE
STAND	11.02.2025	KLEYN	1133298	1:5

DIMENSION IN mm EXCEPT AS NOTED

ON-LOAD TAP-CHANGER VACUTAP® VI
PROTECTION / GROUNDING MOTOR COVER
DIMENSION DRAWING

SERIAL NUMBER
–

MATERIAL NUMBER
101863670M

SHEET
1 / 1

A3

Maschinenfabrik Reinhausen GmbH
Falkensteinstrasse 8
93059 Regensburg
Germany
+49 941 4090-0
info@reinhausen.com
reinhausen.com

Please note:
The data in our publications may differ from the data of the devices delivered.
We reserve the right to make changes without notice.
7993270/03 EN - VACUTAP® VI Operating instructions -
01/26
Maschinenfabrik Reinhausen GmbH 2026

THE POWER BEHIND POWER.