

Kindly follow the below procedure to Upgrade the RAM in the Server.

- 1 Inform all the crew to save their work after confirming.
- 2 Shut down the server.
- 3 Remove all the cables which are connected with the server kindly mark **the LAN cable from which port your removing connect back in the LAN cable in the SAME PORT.**
- 4 Open the side door of the SERVER.
- 5 Find the location of the RAM inside the server.



Above image is for your reference there will be TWO RAM inside the server each have 4 GB of capacity.

6 Insert RAM in below sequence

- Slot 1: 4GB (OLD RAM)
- Slot 1: 8GB (NEW RAM)
- Slot 1: 4GB (OLD RAM)
- Slot 1: 8GB (NEW RAM)

7 Once all the above done kindly box off the server and connect all the cables then start the Server.

Kindly send the image after RAM installed and confirm the working status of the server

PiscesER1 Marine Infotech Pvt. Ltd.

CIN U74999MH2016PTC274416

805, Vakratunda Corporate Park, Goregaon (E), Mumbai, 400063. Maharashtra, India. PIN 400063.

www.pisceser1marine.com. Email: operations@pisceser1marine.com, Voice: +91 22 62215299