SOP-CEN-002 Benchtop Centrifuge Operation

1. Balancing the Rotor
Always load tubes in opposing positions with matched volumes within 0.1 g. Use balance tubes filled with water w

2. Imbalance Error (IMB-01)
The IMB-01 error is displayed when the imbalance sensor detects excessive vibration; the run decelerates and s

3. Lid Lock Error (LID-12)
LID-12 indicates that the lid is not latched. Press the lid firmly at the centre until it clicks. Never attempt to overric

4. Aerosol Containment
Use sealed buckets for biological samples. Open sealed buckets inside the biosafety cabinet. If a tube breaks, le