

THE EMERGENCY CARD



Screenshot this page now — it works with no signal, in any booth, at 3am.

USB DEAD AT THE BOOTH — DO IN ORDER

- Reseat the drive. Wait 10 seconds. Re-insert firmly.
- Second USB slot → other player → wait 30s (big libraries mount slowly).
- Nobody playing? Power-cycle the player (USB STOP first).
- Still dead + laptop nearby → copy tracks off, format FAT32+MBR, copy back, play via FOLDER.
- No laptop → borrow a USB, play from phone via mixer, swap slots with next DJ. **Music first, pride later.**



THE SACRED SETTINGS

- Format: FAT32 · Scheme: MBR · Size: 32–64 GB
- Mac: Disk Utility → Show All Devices → select the DRIVE → MS-DOS (FAT) + Master Boot Record
- Music onto gig drives ONLY via Rekordbox EXPORT mode
- Eject from Rekordbox AND the player (USB STOP). Every time.



NEVER (under pressure)

- Never format a drive that still holds unrescued files.

- ◉ Never say YES when a computer offers to format your gig drive.
- ◉ Never keep re-plugging a drive that's failing — each mount can make recovery harder.
- ◉ Never leave home with one drive. **Two identical drives, two pockets.**

savemygig.com/emergency — the full guided rescue, free · Print this page: it's ink-friendly.