

AeroPulse Mini Earbuds - User Manual

Document date: 2026-04-06

Box Contents

Inside the box you will find:

- AeroPulse Mini Earbuds
- USB-C charging cable (1m)
- Carrying case
- Quick start guide
- Spare ear tips (3 sizes for earbud models)

Initial Setup

Charge the AeroPulse Mini Earbuds for at least 90 minutes before first use. The charging LED is red while charging and green when full. To turn on, press and hold the power button for 2 seconds. The first time you turn on the device, it enters pairing mode automatically.

Pairing with Devices

To pair with a new Bluetooth device:

1. Ensure the headphones are within 1 meter of the target device.
2. On the headphones, hold the power button for 5 seconds until the LED flashes blue rapidly.
3. On your phone or laptop, open Bluetooth settings and select the device name.
4. Confirm the pairing if prompted.

The device remembers up to 8 paired devices and can connect to 2 simultaneously.

Controls

****Single tap right earcup**:** Play/pause

****Double tap right earcup**:** Skip forward

****Triple tap right earcup**:** Skip back

****Single tap left earcup**:** Toggle noise cancellation (on models with ANC)

****Hold left earcup**:** Activate voice assistant

Volume is controlled via your source device.

Battery and Charging

Battery life: up to 30 hours with ANC off, 22 hours with ANC on. Full charge takes approximately 2 hours. A 10-minute quick charge provides 3 hours of playback.

Use only the included USB-C cable or a compliant USB-C charger rated 5V/1A or higher. Do not exceed 3A.

Care and Maintenance

Wipe the headphones with a soft, dry cloth. Do not submerge in water. The ear cushions are replaceable; replacement cushions are available at [marketsphere.example](#).

For earbud models, clean the mesh grilles gently with a soft brush. Do not insert objects into the speaker openings.

Troubleshooting

****Headphones won't turn on****: Charge for at least 30 minutes. If still not responsive, hold the power button for 15 seconds to perform a hard reset.

****Cannot pair****: Forget the device from your phone's Bluetooth list and try again. Reset the headphones to factory settings by holding power + volume down for 10 seconds.

****One side has no sound****: Check Bluetooth balance settings on source device. Try playing on a different source to isolate.

Warranty

This product carries a one-year manufacturer warranty against defects in materials and workmanship under normal use. The warranty does not cover damage from drops, liquid, or unauthorized modifications. To file a warranty claim, visit [marketsphere.example/warranty](#) or contact support.

Specifications

Driver size: 40mm (over-ear) / 10mm (earbud)

Frequency response: 20Hz - 20kHz

Impedance: 32 ohms

Bluetooth: 5.3

Weight: 250g (over-ear) / 5g per earbud

Ingress protection: IPX4 (sport models)