

HomeSense Smart Hub - User Manual

Document date: 2025-05-18

Box Contents

Your HomeSense Smart Hub box includes:

- Main device
- Installation hardware (mounting bracket, screws as needed)
- Power adapter or wiring kit (varies by product)
- Quick start guide
- Warranty card

Pre-Installation Checklist

Before installing:

- Verify you have a 2.4GHz Wi-Fi network (some HomeSense devices do not support 5GHz)
- Download the HomeSense app from your app store
- Have your Wi-Fi password ready
- For hardwired devices: confirm power is OFF at the breaker before working with electrical wiring
- For battery devices: charge or install batteries fully before mounting

Installation

Installation steps vary by device. Common patterns:

****Plug-in devices**** (plugs, hub): Plug in and follow app pairing instructions.

****Battery devices**** (some cameras, sensors): Insert batteries or charge built-in battery. Use the app to pair before mounting.

****Hardwired devices**** (doorbell, thermostat, lock): Read the wiring guide carefully. Most can be installed by homeowners with basic tools. For homes without existing wiring (e.g., installing a video doorbell on a home that doesn't have a doorbell wired), professional installation may be required.

****Light bulbs****: Install in any standard fixture (E26/E27 base in US models). Make sure the fixture's switch is on; bulbs are smart-controlled, not switch-controlled.

App Setup and Pairing

1. Open the HomeSense app and sign in or create an account.
2. Tap the + icon to add a device.
3. Select your device type from the list.
4. Follow the in-app prompts: typically scan a QR code on the device, then connect to its temporary Wi-Fi network, then your home Wi-Fi.
5. Name the device and assign to a room.

Devices typically take 30-60 seconds to pair fully.

Integrations

HomeSense devices integrate with:

- Amazon Alexa
- Google Home
- Apple HomeKit (select devices)
- IFTTT
- SmartThings

Enable integrations in the HomeSense app under Settings > Integrations. Voice control commands and routines are available once integrated.

Privacy and Security

Cameras and doorbells record only when motion is detected or manually triggered (configurable). Footage is stored:

- On the cloud with HomeSense subscription (last 30/60/90 days based on plan)
- Locally on optional microSD card in select models

All video and audio is encrypted in transit and at rest. You control who else can access your devices through the app's Family Sharing feature.

You can pause cameras at any time through the app or set schedules (e.g., automatically pause indoor cameras when you're home).

Troubleshooting

****Device shows offline****: Check that your Wi-Fi router is working. Power-cycle the device (unplug for 30 seconds and replug, or remove batteries and reinstall). If the issue persists, factory reset and re-pair.

****Motion alerts too frequent or too few****: Adjust motion sensitivity in the app. Set activity zones to exclude busy streets or areas with frequent movement.

****Camera image quality is poor****: Clean the lens with a soft cloth. Check Wi-Fi signal strength at the device's location; consider a Wi-Fi extender for distant rooms.

****Smart bulb won't connect****: Reset the bulb by toggling the power switch on-off 5 times in quick succession. The bulb will flash to indicate reset mode. Then pair through the app.

Warranty

HomeSense devices carry a 1-year limited warranty against defects in materials and workmanship. Outdoor and security-related devices include a 2-year warranty.

Not covered: damage from improper installation, surge events (use a surge protector for hardwired devices), modification, or use outside specified environmental conditions.

File a warranty claim at marketsphere.example/warranty.

Specifications

Wi-Fi: 2.4GHz 802.11 b/g/n

Bluetooth: 5.0 (used for initial pairing)

Operating temperature: -4°F to 122°F (varies by model)

Dimensions: see model-specific spec sheet

Power: see model-specific spec sheet

