

ChefPro Espresso Machine - User Manual

Document date: 2025-02-23

Box Contents

Your ChefPro Espresso Machine package includes:

- Main appliance unit
- All standard attachments (varies by model - see attachment list below)
- Power cord
- Instruction manual
- Recipe booklet
- Warranty card

Safety Warnings

****READ ALL SAFETY WARNINGS BEFORE USE****

- Place on a flat, stable, dry surface away from heat sources.
- Do not operate near water (sinks, wet counters).
- Keep cord away from heated surfaces.
- Do not immerse the base unit in water.
- Always unplug before cleaning or changing attachments.
- Not for use by children without adult supervision.
- Do not use outdoors.

First Use

Before first use, wash all removable parts in warm soapy water. Rinse thoroughly and dry completely before assembling.

Wipe the base unit with a damp cloth. Do not immerse the base in water.

Place on a stable surface. Plug into a grounded outlet. The unit is now ready for use.

Operating Instructions

1. Assemble the appliance per the assembly guide.
2. Add ingredients per your recipe (do not exceed the maximum fill line).
3. Select your desired setting from the control panel.
4. Press START to begin operation.
5. The unit will automatically stop at the end of the cycle or you can press STOP at any time.

For specific cooking programs, consult the included recipe booklet.

Cleaning

After each use:

1. Unplug the unit and allow to cool.
2. Remove all removable parts.

3. Wash removable parts in warm soapy water or dishwasher (top rack only for parts marked dishwasher-safe).
4. Wipe the base with a damp cloth. Do not immerse.
5. Allow all parts to dry fully before reassembly or storage.

For stuck-on food: soak parts in warm soapy water for 15-30 minutes.

Troubleshooting

****Unit will not turn on****: Verify the power cord is fully inserted at both ends. Try a different outlet. Check your home's circuit breaker.

****Unit shuts off mid-cycle****: This is usually thermal overload protection. Unplug, allow to cool for 30 minutes, then resume.

****Unusual noise or burning smell****: Stop use immediately. Unplug. Contact customer support.

****Leakage or seal failure****: Stop use. Contact customer support for replacement parts under warranty.

Warranty

Your appliance includes a 2-year limited manufacturer warranty covering defects in materials and workmanship under normal household use. The warranty does not cover:

- Damage from misuse, dropping, or unauthorized modification
- Cosmetic wear that does not affect operation
- Commercial use (we offer separate commercial warranties)
- Damage from non-recommended cleaning agents

To file a warranty claim, visit marketsphere.example/warranty or contact support with your order number.

Replacement Parts

Common replacement parts are available at marketsphere.example/parts:

- Replacement seals and gaskets
- Replacement attachments (whisk, paddle, dough hook)
- Replacement carafes and pitchers
- Replacement filters (where applicable)

Use only genuine ChefPro replacement parts. Third-party parts may void your warranty.

Specifications

Power: 1000W (varies by model)

Capacity: see model-specific section

Dimensions: see model-specific section

Weight: see model-specific section

Voltage: 120V AC, 60Hz (US models)