Problem	Analysis	Solution
No stop at upper and bottom positions	Incorrect connection of phases, and the position fails	Cut off power, check, adjust and change
Up only, or down only	Circuit contact fails, over low Voltage, Electromagnetic iron weak in attraction force	Polish contact or change relay, adjust voltage button contact, change magnet coil
No reaction	Button contact fails, position limiting switch contract fails, circuit cut off, without neutral wire connection	Adjust and change joggling switch and relay, connect neutral wire
Non-stop Operation	Relay contact fused, joggling switch out of control	Repair or change joggling switch and relay
Non-operation, only noise	Machine blocked, voltage too low	Remove block, adjust voltage
Shutter slide down after brake	Brake piece excess of abrasion	Check the spring of brake, add the shim.