OPERATION & MAINTENANCE MANUAL FOR MOTORISED CANTILEVER GATE

DOCUMENT NO – NIHVA/20-21/GATE001	
PREPARED BY	S.M.S.
CHECKED BY	A.K.
APPROVED BY	V.T.

DESIGNED, DEVELOPED & MARKETED BY

NIHVA

NIHVA Technologies Pvt. Ltd.

G-BLOCK, 1ST FLOOR, THERMAX CHOWK
MIDC, ABOVE RENAULT SHOWROOM
CHINCHWAD, PUNE-411019

TEL.NO: - +912066304033
EMAIL: -sales@nihva.com
www.nihva.com

INTRODUCTION

The Motorized Cantilever gate is the result of many years' experience in Door Automation Technologies & Industrial gate automation. "NIHVA" offers the best possible factor of safety with simple, easy to use controls. The high quality of manufacturing gives a robust construction and many years of useful life.

We take pride that our product & service range is offered with a high level of working safety, comfort, functionality and supported by services and added value solutions.

INDEX

1. DISPATCH & UNLOADING
2. ORDERING OF SPARES
3. EMERGENCY CONTACT DETAILS
4. DETAILS OF MOTORIZED CANTILEVER GATE
5. PRE-OPERATING INSTRUCTIONS
6. ROUTINE MAINTENANCE
7. TROUBLESHOOTING
8. PARTS LIST
9. GA DRAWING OF MOTORIZED CANTILEVER GATE

- **DISPATCH & UNLOADING**

1. Loading, for dispatch, will be our responsibility. On receipt of the gate at site, please check and ensure that there is no physical damage to the equipment.

2. While unloading the equipment from the transporting vehicle, please ensure to use slings with rated capacity higher than the gross weight of the Stationary lift in packed condition.

- **ORDERING OF SPARES**

1. When ordering for spare, please specify the following in your Purchase Order.

    - Gate Size
    - Part name / Description
    - Quantity required
    - Delivery period / time
    - Mode of dispatch

    This would avoid ambiguity and help us serve you better.

- **EMERGENCY CONTACT DETAILS: -**

    1) Service - 9168938333
    2) Projects- 8551008333

- **DETAILS OF MOTORISED CANTILEVER GATE:**

1. **GATE OPERATION MODE-** MOTOR OPERATED
2. **OPERATION CONTROL –** BY PUSH BUTTONS
3. **MATERIAL –** M.S.
4. **MOTOR –** DIRECT DRIVE
5. **MOTOR SUPPLY –** SINGLE /THREE PHASE
6. **CLEAR OPENING HEIGHT –** AS PER GA DRAWING
7. **CLEAR OPENING WIDTH –** AS PER GA DRAWING
8. **RAILING -** TRACK WELDED TO I-BEAM EMBEDDED IN FOUNDATION
9. **RAL SHADE-** AS PER CUSTOMER REQUIREMENT, REFER GA DRAWING.
10. **MOTOR CAPACITY –** AS PER SPECIFICATIONS

- **PRE – OPERATING INSTRUCTIONS: -**

1. There should be no obstacles within the operating path of the gate during operation.
2. Wrong operation may result in injury or even death to the user.
3. Wrong operation may result in injury or physical damage to the operator.
4. Installation and adjustment must be carried out according to the Installation Manual. Carelessness in installation and adjustment may result in accidents such as fire, electric shocks or fall off.
5. During the installation do not allow the pedestrians to pass through the automatic gate or approach the work site. Because any tools or parts fall off during the installation may result in injury to the pedestrians.
6. Don’t remodel the parts, otherwise fire, electric shocks or fall may occur.

7. Don't use the power beyond the stipulated voltage or frequency, otherwise fire or electric shocks may occur.
8. Do fix up auxiliary safety beam sensor to ensure the detecting range for the walking area of the gate leaf, otherwise the passers-by may be collided or squeezed by the gate leaf, causing injury.
9. Before carrying out any work on the system, turn off the electricity supply.
10. Do not allow children or other people to stand near any moving part of the gate while in operation.
11. The operator / owner shall read and be familiar with the Owner's manual, especially the Operating and Maintenance Instruction.
12. In the event of a malfunction, the operator shall consult the Owner's Manual and contact NIHVA.
13. Any repair or modifications by an unqualified technician will void the warranty.

- **ROUTINE MAINTENANCE**

These recommendations are applicable to the gate considering average daily usage of 15 to 20 times. If it is used more frequently, the same time intervals for the maintenance should be adjusted accordingly.

DAILY:

1. Check aldrop is open before operation.
2. Visual inspection for damages.
3. Check electrical connections for their proper working.

MONTHLY:

1. Check all Parts for wear out or damage. Check all fixing are secure.
2. Greasing to gear & bearing.
3. Check correct operations of control button.

- **TROUBLESHOOTING**

PROBLEM	ANALYSIS	SOLUTION
The gate will not open nor close.	• There is no power • The gearmotor is in release mode • The stop button is either stuck or broken • The opening/closing button	• Check that the power is up • Lock the gearmotor • Call assistance
The gate opens but will not close	• The photocells are engaged • Sensitive edge triggered if installed.	• Check that photocells are clean and in good working order • Call assistance
The gate closes but will not open	• Sensitive edge triggered if installed	• Call assistance
The flasher does not work	• The bulb is burnt	• Call assistance

PARTS LIST:

SR NO	ITEM DESCRIPTION
1	GATE LEAF
3	VERTICAL POST
4	NYLON ROLLER
5	CANTILEVER MECHANISM
6	CANTILEVER TRACK
7	GATE OPERATOR
8	RACK
9	PHOTOCELL
10	INDICATING LAMP