Docking Procedure

- Back up the vehicle with open tail-gate make sure that the vehicle is rest exactly in front of dock-leveler and cannot roil or drive away.
- PLATFORM UP
    - Keep “PLATFORM UP” button pressed, unit the platform raises to the fully up position and the lip folds out completely.
- Lip UP
    - Keep “LIP UP” button pressed, until the LIP raises to the fully up position.

Return To Original Position

- Lowering the dock leveler
    - After loading/unloading, the “PLATFORM UP” button is pressed again and the dock leveler will rise. The lip swings back. The “PLATFORM UP” button must be kept pressed until the lip has swung back. When the “PLATFORM UP” button is released, the dock leveler will return to original position automatically.
- Lip down
    - Lip down button pressed until lip fold in completely.
- Platform down
    - Keep platform down button pressed until down to its original testing position.

Safety notes

- While loading/unloading the lip has to lie firmly with a minimum of 100 mm and over its whole width on the vehicle bed.
- Make sure there are no persons or equipment in the working area of the dock leveler on top, below, in front and on both sides before you operate the dock leveler.
- When not in use the dock leveler shall be returned to its stored position immediately.
- Never exceed the permissible load capacity stated on the identification plate.
- The dock leveler must not be used outside the permitted gradient of ±10% (approx. ±6°) and the limitations of the docking vehicle in use.
- Before undertaking any electrical work the dock leveler must be disconnected and isolated.
- The dock leveler must only be operated by trained, authorized personnel.