



# 68K Programmer's Reference Manual Errata

by: Microcontroller Division

This errata document describes corrections to the *68K Programmer's Reference Manual*, order number M68000PRM. Please check our website at <http://www.freescale.com/> for the latest updates.

The current available version of the *68K Programmer's Reference Manual* is Revision 1.

**Contents**

|   |                             |   |
|---|-----------------------------|---|
| 1 | Errata for Revision 1 ..... | 2 |
| 2 | Revision History .....      | 2 |

# 1 Errata for Revision 1

**Table 1. M68000 RM Rev 1 Errata**

| Location  | Description                                                                                                                                                                                                                    |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Page 5-35 | In the Instruction Fields section of the FDBcc instruction summary, the displacement field description should be: "Specifies the branch distance (from the address of the instruction plus four) to the destination in bytes." |
| Page 5-71 | In the Instruction Format figure of the FMOD instruction summary, bits 6:0 of the second word should be 0100001 (matching the figure on page 8-33), not 0101101.                                                               |
| Page 5-78 | In the Instruction Format figure of the FMOVE instruction summary: <ul style="list-style-type: none"> <li>The COPROCESSOR ID field should be located in bits 9-11</li> <li>Bit 12 has a fixed value of 1</li> </ul>            |
| Page 6-12 | In the FRESTORE instruction summary, the description for the BUSY state frame should begin with "This state frame is 100 (\$64) bytes long in the MC68040..."                                                                  |

## 2 Revision History

[Table 2](#) provides a revision history for this document.

**Table 2. Revision History**

| Rev. Number | Substantive Changes                                                                                                                                                                                                                           | Date of Release |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| 0.1         | Initial release as text document.                                                                                                                                                                                                             | 07/2005         |
| 1           | <ul style="list-style-type: none"> <li>Converted errata from text document to standard Freescale format</li> <li>Added FMOD instruction errata to <a href="#">Table 1</a></li> <li>Light edit for grammar, punctuation, and format</li> </ul> | 03/2007         |

THIS PAGE IS INTENTIONALLY BLANK

## How to Reach Us:

### Home Page:

[www.freescale.com](http://www.freescale.com)

### Web Support:

<http://www.freescale.com/support>

### USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.  
Technical Information Center, EL516  
2100 East Elliot Road  
Tempe, Arizona 85284  
+1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

### Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH  
Technical Information Center  
Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

### Japan:

Freescale Semiconductor Japan Ltd.  
Headquarters  
ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064  
Japan  
0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

### Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.  
Technical Information Center  
2 Dai King Street  
Tai Po Industrial Estate  
Tai Po, N.T., Hong Kong  
+800 2666 8080  
[support.asia@freescale.com](mailto:support.asia@freescale.com)

### For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center  
P.O. Box 5405  
Denver, Colorado 80217  
1-800-441-2447 or 303-675-2140  
Fax: 303-675-2150  
[LDCForFreescaleSemiconductor@hibbertgroup.com](mailto:LDCForFreescaleSemiconductor@hibbertgroup.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-compliant and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.  
© Freescale Semiconductor, Inc. 2007. All rights reserved.