



Truck In / Out

Instruction Manual

BTEK


**February
2025**

~ 1 ~

Table of Contents

MAIN SCREEN	3
ADMIN PANEL.....	4
APPLICATION PAGE	4
APPLICATION CATEGORY SETUP PAGES.....	5
TRUCK PAGE	6
MAIN MENU PAGE.....	7
TICKET PAGE	8
DATABASE PAGE	9
SERVER PAGE.....	10
<i>DB Settings.....</i>	<i>11</i>
SHARING DATABASE	12
<i>Primary DD:.....</i>	<i>12</i>
<i>Setup Slave DD</i>	<i>13</i>
TECHNICIAN PANEL	14
REPORTS PAGE	14
<i>Export.....</i>	<i>15</i>
.....	15
<i>Email Report Configuration.....</i>	<i>15</i>
<i>Mail Server</i>	<i>16</i>
PRINTERS / TICKET.....	17
<i>Configure Header / Footer</i>	<i>18</i>
<i>Printer Configuration</i>	<i>19</i>
SYSTEM.....	20
SCALES	21
PASSWORDS	22
HARDWARE PAGE.....	23
<i>Card Reader Settings.....</i>	<i>24</i>
<i>Photo eyes.....</i>	<i>25</i>
<i>Traffic light.....</i>	<i>26</i>
I/O PAGE	27
<i>Interpreter.....</i>	<i>28</i>
<i>Transmits</i>	<i>29</i>
<i>Setpoints (Output).....</i>	<i>30</i>
<i>Setpoints (Input).....</i>	<i>31</i>
INBOUND PROCESS (MANUAL TRUCK / KEYED ID):	32
OUTBOUND PROCESS:.....	36
GROSS TICKET PROCESS:	38

MAIN SCREEN



“Gear Button” – Will bring pop-up the scale control (Image on Right).

“Zero Button” – Will zero the weight on the scale, zero percentage and timer can be set in the scales section (Page 8 of 11) in the Zero Button.

“lb Button” – Changes between primary and secondary unit of measure.

“Select Scale Button” – Will switch the weight displayed on the weight viewer if multiple scale cards are detected.

“About Button” – Displays the currently running application.

“Auto Tare Button” – Will set the current weight as the Tare for the scale. Also have manual tare and clear tare features.

“Weigh Truck Button” – Will Start the Truck I/O Process by bringing up a prompt asking for the Hauler and Truck ID.

“Update Tare Button” – Will prompt asking for the Hauler and Truck ID, then update the trucks tare with the current weight on the scale. Only useful when using gallery truck mode.

“Print Gross Button”- Will Print a Gross Ticket.


“Reprint Ticket Button”- Tickets from the current day transactions can be reprinted using the ticket number.

“Add Truck w/ Stored Tare” – Add truck to database with or without a keyed tare value. This is useful when using the indicator in gallery truck mode.

“BTEK Logo” – Holding this button will cause it to turn red, releasing it at this time will bring up a password screen. Pressing “2050” (default password) will take you into the ADMIN PANELS.

Admin Panel

Application page




Export – Export application to USB thumb drive.

Import – Import application from USB thumb drive.

Startup – Start imported application, or alternate application.

Application Category Setup Pages


Use the application pages to add, delete, and edit the database. Some fields can be turned on and off in the prompt button. When setting up a new system, start by adding a hauler if you want to sort trucks by hauler, then a truck to each hauler. Leave hauler empty if you only want to track truck ID's. Up to three free text custom prompts can be configured. Type in caption after enabling the prompt.



HAULER [Close]

ADD HAULER DELETE HAULER EDIT HAULER

Page 5 of 15




CUSTOMER [Close]

ADD CUSTOMER DELETE CUSTOMER EDIT CUSTOMER

PROMPT


Page 3 of 15



CARD [Close]

ADD CARD DELETE CARD EDIT CARD

Page 2 of 15




PRODUCT [Close]

ADD PRODUCT DELETE PRODUCT EDIT PRODUCT

PROMPT

Page 8 of 15

Prompt button disables or selects when to prompt on inbound or outbound transaction.




 **CUSTOMER_DIRECTION**

PLEASE SELECT AN OPTION BELOW

DISABLED INBOUND OUTBOUND

Truck Page



The truck screen has buttons to add, delete, and edit trucks.

Delete or Display Inbound – Display to view or Delete inbound transactions no longer needed.


Truck Mode – Select whether truck ID's will be manually key or selected from a gallery.

Truck Mode Options:

Keyed- Typical inbound / outbound application. Truck ID's will be cleared after the outbound transaction. When re-entered, a new inbound transaction will be performed. It is recommended to remove the update tare button on the main menu page when using this mode.

Gallery- Useful when the same trucks will be used, and a database of trucks is created. Update tare button will be used for trucks returning to recapture their inbound weight.

Main Menu Page



Add Truck w/ Stored Tare – Removes / adds the Add Truck w/ Stored Tare from the weighing screen.

Print Gross Ticket – Removes / adds the print gross ticket from the weighing screen.

Reprint Ticket – Removes / adds the reprint ticket button from the weighing screen.

Update Tare – Removes / adds the update tare button from the weighing screen.

Weigh Truck – Removes / adds the Weigh Truck button from the weighing screen.

Zero Scale – Removes / adds the Zero Scale button from the weighing screen.

Ticket Page

TICKET



PRINT INBOUND

REPRINT A TICKET

TICKET MODE



TICKET NUMBER



Page 14 of 15


Print Inbounds – Selects whether inbound or only outbound tickets will be printed

Reprint A Ticket – Tickets from the current days transactions can be reprinted

Ticket Mode – Selects whether inbound or outbound transaction will increment the ticket number

Ticket Number – Reset the ticket number, or enter 0 to remove from the ticket.


Database Page



Server – This will take you to the SERVER Screen.

Settings – This will take you to the SETTINGS Screen.

Server page



The image shows a software interface for configuring a server. At the top left is a small icon of a satellite. The title 'Server' is centered at the top in a large, bold, white font on a dark background. Below the title, there is a checkbox labeled 'Enable Data Server'. Underneath this, the text 'Port Number' is followed by a text box containing the value '8095'. Below that, the text 'Local IP Address' is followed by the value '192.168.1.10'. At the bottom of the screen, there are two buttons: 'OK' with a green checkmark icon and 'CANCEL' with a red circle and slash icon.

Server

☐ **Enable Data Server**

Port Number

8095

Local IP Address

192.168.1.10

OK CANCEL

****This Screen will be used if there is another device that will be connecting to the database on this device.****

-Clicking the “Enable Data Server” button will create the server on the Port Number specified and allow devices to connect to it.

-Clicking the Port Number will bring up a keyboard dialog allowing you to change the value.

DB Settings



Settings

Database Provider	Port Number
SQL CE	0
Data Source (Server)	Database Name
	STANDARD TRUCK.sdf
User ID	Password

Test Settings	
 OK  CANCEL	

****This screen is used to change the database for the data that the application generates. By default it will be set to SQL CE (stored on the machine).****


-If your application is connecting to a SQL Server Database, select "SQL Server" from the "Database Provider" list and enter all the connection information in their respective boxes.

-If your application is connecting to another DD device to store its data, select "Remote" from the "Database Provider" list and enter the Port Number Set up on the other device that it is listening on.


Sharing Database

Primary DD:

1. Under the Server page Check the box [X] Enable Data Server
2. Make note of the Port Number (Default is 8095)
3. Make note of the IP Address
 - a. If the network is DHCP then the indicator should be automatically assigned an address, however you will want to static set this address on the primary DD so that it doesn't change.
 - b. To statically set an address first obtain the address settings from the customer IT group or if you are using a crossover cable or your own network switch you can set one yourself.
 - i. In this example, we will use IP Address 192.168.1.10 for the primary indicator IP address.
 - c. To Set the address on the primary indicator
 - i. Navigate to the Start Menu -> Settings -> Network and Dial-Up Connections



- ii. DB-Click on the DM9CE1 (or AX88772B1 in Skynet) icon
 - iii. Mark the button the states Specify an IP Address and enter the address 192.168.1.10 and gateway address of 255.255.255.0




- iv. Click Ok to accept the changes and close the Network window
4. On Skynet Version, using mouse, open task bar, press start, scroll to programs, scroll to calibri tools, scroll and click on SaveReg, Click OK. IP is lost on reboot if skipped.
5. Close the Server window and tap on the Settings icon on the Database Page
6. Make a note of the Database Name field (default is STANDARD TRUCK.sdf)
7. Using mouse, open task bar, press start, scroll to programs, calibri tools, and click on SaveReg, then Click OK. Settings are lost on reboot if this is not done.
8. Close the Settings page and reboot the primary indicator.

Setup Slave DD

1. On the slave DD follow previous steps 3.I through 3.IV. However, this time set the slave DD IP Address to 192.168.1.20 and a gateway of 255.255.255.0
2. Under the Database Page tap the Settings icon
3. Under the Database provider, select Remote
4. Under Port Number enter 8095 (unless you changed it in step 2 of the primary setup)
5. Under Data Source enter the IP Address from the primary DD, in this example it is 192.168.1.10
6. Under Database Name enter the information collected in the primary setup step 5. (Default is STANDARD TRUCK.sdf)
7. Double check your settings and tap Ok Using mouse, open task bar,
8. For Skynet only: press start, scroll to programs, calibri tools, and click on SaveReg, then Click OK. Settings are lost on reboot if this is not done.
9. Reboot the slave device, it should now be sharing a database with the primary unit
 - a. You can add additional slave devices to the mix by incrementing the IP Address from step 1 of the slave setup and the rest of the setup.

Technician Panel

Reports Page



“Design Button”- Default reports will be listed. Use this button to modify, add, or delete reports.

“Export Button”- Insert USB thumb drive into one of the ports. Select Export, then report to export, then select whether you want to clear the database. .CSV file will be stored on the thumb drive. Daily E-mail reports can be scheduled by setting check box, time, and e-mail address.

“Mail Server Button”- Takes you to the Screen where you can configure the email server in which the email function will send emails through.

“Send”- By entering an e-mail address, a current report will be sent.

Export

TICKET EXPORT

Report Name

TICKET EXPORT



Table

TICKET

SQL Select

Edit SQL

Filter

COMPLETE=1

☒ Schedule Report

Hour

Min.

AM/PM

Send To

2

56

PM

BCARLTON@BSCALES.COM

OK

CANCEL

Email Report Configuration


Check the “Schedule Report” button, Set the time of day to process the report, then enter e-mail address of the recipient.

Mail Server

SERVER:	20.231.93.95	
USER NAME:	bcarlton	
PASSWORD:	*****	
FROM:	bcarlton@bscales.com	
PORT:	8196	SEND TEST E-MAIL
 OK CANCEL		

Configure this screen to match the settings provided by B-TEK. This will be the server the emails come from. Contact B-TEK to set up your account information, the first year of e-mail service is free with an annual service fee of \$100 each year after.

Printers / Ticket



Configure Header / Footer Button – This will take you to the CONFIGURE HEADER page where you can customize what appears on top or bottom of your printed tickets.

Printer / Aux Printer Configuration – This will take you to the PRINTER CONFIGURATION page where you can set up all the configurations associated with your printer.

Copies Button – This will take you to the Ticket Copies page where you can set the number of copies.

Configure Header / Footer

Header

B-TEK SCALES, LLC.
1510 METRIC AVE. SW
CANTON, OH 44706



**OK****CANCEL**

“Folder Button” – Uploads a text file to the edit page.

“Save Button” – Saves current text to a .txt file.

“Paper Button” – Clears the current information

Select the white page area to insert the curser, then open the keyboard on the task bar, or plug in usb keyboard to enter text.

****Will Print at the top of every ticket in the order it is in****

Printer Configuration

Model		
EpsonTM295		
Mode	Port	Host
COM	4	
Baud	Bits	Parity
9600	8	None
 OK		 CANCEL

****Please consult your printers manual for Baud Rate, Data Width, and Parity Settings. TCPIP or laser printers require additional configuration and setup please call support to find out more and schedule assistance****


Printer Type:

VKP80III – Is the type you will want to select if you are using a DD2050 with built in printer

EpsonTM295 – Is the type you will want to select for most Epson printers

Generic – Is the type you will want to select if you are not using either of the above

System




Date/Time: Will bring up the Computer's Date/Time Configuration allowing you to change these settings. Change and apply time zone first, then adjust time and date.

Network: Will bring up the Computer's Network Panel, allowing you to view connections and view IP Address of the device.

Reboot: Will reboot the device and restart the application.

Auto Reboot: Will reboot the device and restart the application at a set time each day.

Scales



Under the “2835” passcode there are additional options that should be managed by a scale service provider.

Zero Button – Will bring up options to adjust zero range and set a zero timer to give time to walk off the scale.

Tools – will bring up additional configuration’s options provided by the framework ** See DD Tech manual for additional information **


Diagnostics – Will shortcut the operator to additional options provided by the scale framework

Events – Will shortcut the operator to a list of events that can be printed (if a printer is available and configured in the Bilanciai framework) including locking and unlocking of the seal, load cell swaps and resets etc..

Metro – Will shortcut the operator to the scale configuration pages see “Adding a scale” in this manual

Status Monitoring – Enabling feature will disable the weigh screen while scale is in motion.

Passwords




Scale Menu Button: Sets an access password for the scale setup button on the weigh screen.

Tech Password Button: Changes the password to technical settings.

User Password Button: Changes the password to the admin settings.

*****Contact B-TEK Support to reset passwords to default.**

Hardware Page



Card Reader: Card reader configuration

Serial Transmission: Photo Eye Configuration

Traffic Light: Traffic Light Configuration

Card Reader Settings

Model

B-TEK

Mode

Port

Host

COM

0

Baud

Bits

Parity

9600

8

None

OK

CANCEL

Reader Model: HID, BTEK, TRES 900S, or Deister

Mode: The desired COM port the reader is connected too. Select Com, TCP Client, TCP Server

Baud Rate / Bits / Parity: settings in which the indicator should communicate with the reader on. These should be provided by the reader's manufacture.

Photo eyes

Photo Eyes

Entry Input	Normally	Message
OFF	OPEN	PLEASE PULL FORWARD
Exit Input	Normally	Message
OFF	OPEN	PLEASE PULL FORWARD


OK


CANCEL

**** See input / outputs section of this manual for cabling layout ****

Entry / Exit:

Input: Which IO to use for the entry photo eye

Normally: Select where the photo eye will be normally open or normally closed

Message: The message to display on screen when the photo eye is activated

**** A jumper wire might need added, or terminal strip removed if configuration / wiring is not correct.**

Traffic light

Traffic Light

Mode	Red Output	Green Output	
DOUBLE	1	2	
On Screen	Allow Toggle	Normally	
ON	ON	OPEN	
Scale	Threshold	Red	Green
A	1000	r	g



OK



CANCEL

Mode: Set **SINGLE**, **DOUBLE** relay, or **TL-280** Ethernet operation. Select **DOUBLE** if you're going to use a separate IO for both Red and Green lights and **SINGLE** if you're going to use only one IO for both lights

Red / Green I/O: Select of the IO port

On Screen: Inserts traffic light indication on the weigh screen


Allow Toggle: Allows manual control of the traffic light by pressing red or green light on screen.

Normally: Sets relay position to normally open or closed.

Threshold: Point at which the light switches from Green to Red and back again

Red / Green: Sets character in the weight data string to control light via serial communication.

I/O Page



Interpreters: Allows the program to interpret data from external device and activate processes.

Ports: Create / edit / delete serial port and TCP/IP port settings.


Remote Scale: Configures another scale's data stream and port to be displayed on the weigh screen.

Setpoints: Configure the input / output ports. See Setpoint setup section below.

Transmits: Create serial strings from communication ports.

Interpreter

Input interpreters are used to receive data from external devices such as moisture readers and bar code scanners.



DD1050X

192.168.60.4

Interpreter

Port	Name
TCP:2112	PRINT

Starts With	Ends With
	\x0d

Macro	Format
STEPS	P{TRUCK},{GROSS},{TARE},{NET}

OK CANCEL

Port: The communications port that will receive the data

Name: The name of the input interpreter

Starts With: The character(s) that mark the start of this input interpreter

Ends With: The character(s) that mark the end of this input interpreter

Macro: Macro commands to execute when the string is received

Format: The format of the characters to be received

Transmits

Select create, delete, or edit to configure

Edit Transmit

Cyclic	Transmit Name	Scale
ON	SCOREBOARD	A
Port	Start	End
COM6:	STX	CRLF
Output		
B-TEK		
Interval	Format	
250	Edit Format	


OK


CANCEL

Transmission: Tapping will Enable or Disable the transmission

Transmit Port: When tapped will bring up a screen allowing the operator to manually enter the serial port they desire to use

Start / End: If you want to put a carriage return or line feed you could add 010 013 using the ascii map to translate the codes

Transmission String: Contact BTEK for assistance building a custom string, or see Aurora technical manual.

Example: GROSS command: {GROSS("A", "00", 8, false)}

Setpoints (Output)

No.	Mode	Scale Name
1	Output	A
Delay	Active On	Weight
0	Above	0
Delay	Inactive On	
0	Never	
		Active Macro
		Steps
		Inactive Macro
		Steps


OK

CANCEL

**** See input / outputs section of this manual for cabling layout ****

No.: Output number

Mode: Selects Input or Output

Scale Name: Selects scale the output will activate from

Delay: Time delay for active on and inactive on

Active On: Setpoint active when setting is true. Values: Never, Motion, Stable, Above, Below, Between, Outside, and Always.

Inactive On: Setpoint inactive when setting is true. Values: Never, Motion, Stable, Above, Below, Between, Outside, and Always.

Active and Inactive Macro: Initiates selected macro step when setpoint is met.

Setpoints (Input)

No.	Mode	Remote Command
1	Input	Zero
Delay		Active Macro
0		Steps
Delay		Inactive Macro
0		Steps


OK

CANCEL

No.: Input number

Mode: Selects Input or Output

Remote Command: Select None, Zero, or Tare function

SEE PAGES 46-47 for Input / Output wiring and power requirements.

Inbound Process (manual truck / Keyed ID):

1. Click Weigh Truck which will take you to a screen to enter your Truck ID, or Hauler screen if sorting trucks by hauler.

TRUCK NUMBER											
1	2	3	4	5	6	7	8	9	0	BACKSPACE	
Q	W	E	R	T	Y	U	I	O	P	CANCEL	
A	S	D	F	G	H	J	K	L	.	ENTER	
Z	X	C	V	B	N	M	,	SYM	SPACE		

2. Enter Your Truck ID
 - a. If System finds the entered truck ID in the system, see the "INBOUND PROCESS WITH STORED TRUCK" Section for more details
 - b. If System finds the entered truck ID in the incomplete tickets table, it will start the OUTBOUND PROCESS
 - c. If the ID is left blank, the confirmation screen will appear, but will not process transaction.

3. Select Customer (If set to Inbound)

**CUSTOMER**

B-TEK

4. Select Product (If set to Inbound)

**PRODUCT**

Steel

5. Confirm or Cancel Ticket

PLEASE CONFIRM	
Caption	Value
TRUCK_NUMBER	123
CUSTOMER	B-TEK
PRODUCT	Steel
IN_WEIGHT	24000



OK


Cancel

6. This will save ticket to the database, as well as print to the printer if specified to print inbound ticket.

Inbound Process (stored truck / gallery mode):


1. Click Update Tare which will take you to a screen to enter your Truck ID, then capture the current weight on the scale to update your truck tare. Or click on Add Truck w/ Stored Tare to add new truck to database, and is optional to key in tare weight.



The screenshot displays the B-TEK SCALES LLC software interface. At the top left, there is a red and green indicator light. To its right are several small icons: a white box, a black box with a white 'M', a white box with a black 'A', a white box with a black 'G', and two empty white boxes. The top right corner features an orange folder icon and a grey gear icon. The central display shows the weight **40020lb**. Below the display is a grid of six buttons: **Weigh Truck**, **Update Tare**, **Print Gross Ticket**, **Reprint Ticket**, **Zero Scale**, and **Add Truck w/ Stored Tare**. The bottom right corner contains the B-TEK SCALES LLC logo and the BILANGIAI GROUP logo.

Outbound Process:

1. Click Weigh Truck which will take you to a screen to enter your Truck ID, or Hauler screen if sorting trucks by hauler.



2. If it finds an open ticket, it will go through the Customer/Product Prompts (Note: your prompt setting must be set to “Outbound” to select prompts with stored trucks).

3. Confirm Ticket

PLEASE CONFIRM	
Caption	Value
TRUCK	B-TEK
CUSTOMER	TEST CUSTOMER
PRODUCT	TEST PRODUCT
GROSS	40000
TARE	20000
NET_WEIGHT	20000
NET_TONS	10



OK




Cancel

4. When Confirmed, Completed ticket will be saved to the database and a ticket will be printed (if enabled).

Gross Ticket Process:

1. Press the Print Gross Ticket button and a Ticket Will be Printed (if enabled).



Example with Header and Footer:

