Rotating car tires

Once the car has been jacked up and is off the ground. You will need to determine where to start at the front or the back of the car. Next determine which tire to remove left or right side. Next remove one tire repeat for the next side. Next replace the first tire with the second tire. Repeat this step for the next set of tires. Until completed.

A=Front B=Back C=Left D=Right L=Left R=Right

