ASIST

Concern Details

Your Reference Number is: KM0717641

Logged Date 12-Mar-2009
Base Model CCEST

Concern Description

"offline" displays

Symptom

'OFFLINE' displays on the EST when using the Dearborn Protocol Adapter (DPA)

Resolution

Verify power to the Dearborn Protocol Adapter

'Comm Link Down' displayed in the lower right corner of the Electronic Service Tool (EST) indicates the Dearborn Protocol Adapter (DPA) is not being powered.

Ensure that the Power light on the DPA is on steady. If the Power light is not on, perform these troubleshooting steps:

1. Remove the 9- pin diagnostic connector from the vehicle and reconnect to the vehicle diagnostic connector. Cycle the key switch.
2. Check for pin and terminal fit at connectors. Cycle the key switch.
3. Check for voltage (approximately 12V at pins A to B) at the 9-pin diagnostic connector. If no voltage is detected between pins A and B, ensure that the diagnostic fuse is good.
4. Check the continuity of the J1939 vehicle interface cable.

   Part Number 380000099 (CAS2579A)

Diagnostic Connector Pin Assignment	BD-15 Connector Pin Assignment
Pin A - Ground	Pin 9 - Ground
Pin B - B+ Power	Pin 10 - B+ Power
Pin C - Vehicle Data Bus (High)	Pin 15 - Vehicle Data Bus (High)
Pin D - Vehicle Data Bus (Low)	Pin 14 - Vehicle Data Bus (Low)
Pin E - NEF Engine K-Line	Pin 1 - NEF Engine K-Line

   Part Number 380002880

   For an illustration, see the attachment 'DPA5 Connector Pin Outs'.

Diagnostic Connector Pin Assignment	25 pin Connector Assignment
Pin A - Ground	Pin 6 - Ground
Pin B - B+ Power	Pin 8 - B+ Power
Pin C - Vehicle Data Bus (High)	Pin 13 - Vehicle Data Bus (High)
Pin D - Vehicle Data Bus (Low)	Pin 12 - Vehicle Data Bus (Low)
Pin E - NEF Engine K-Line	Pin 1 - NEF Engine K-Line
Pin H - N/A	Pin 24 - N/A
Pin J - N/A	Pin 22 - N/A

5. Check continuity of the serial PC to adapter cable.

Part Number 380000602

PC Connector	DPA 3 Connector
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Part Number 380002883

For an illustration, see the attachment 'DPA5 Connector Pin Outs'.

PC Connector	DPA 5 Connector
1	1
2	2
3	3
4	4

6. Connect the EST and DPA to another machine. If the DPA power light does not illuminate on another machine and all steps above have been performed, service or replace the DPA.

WARRANTY: Standard warranty terms apply.

12-Mar-2009