Command ID	Command	DSPK v2.1 (IS206xGM/BM6x)	MSPK v1.0 (IS206xGM/BM6x)
0x00	Make_Call	●	●
0x01	Make_Extension_Call	●	●
0x02	MMI_Action	●	●
0x03	Event_Mask_Setting	●	●
0x04	Music Control	●	●
0x05	Change_Device_Name	●	●
0x06	Change_PIN_Code	●	●
0x07	BTM_Parameter_Setting	●	●
0x08	Read_BTM_Version	●	●
0x09	Get_PB_By_AT_Cmd		
0x0A	Vendor_AT_Command	●	●
0x0B	AVC_Specific_Cmd	●	●
0x0C	AVC_Group_Navigation	●	●
0x0D	Read_Link_Status	●	●
0x0E	Read_Paired_Device_Record	●	●
0x0F	Read_Local_BD_Address	●	●
0x10	Read_Local_Device_Name	●	●
0x11	Set_Access_PB_Method		
0x12	Send_SPP/iAP_Data	●	●
0x13	BTM_Utility_Function	●	●
0x14	Event_ACK	●	●
0x15	Additional_Profiles_Link_Setup	●	●
0x16	Read_Linked_Device_Information	●	●
0x17	Profiles_Link_Back	●	●
0x18	Disconnect	●	●
0x19	MCU_Status_Indication		
0x1A	User_Confirm_SPP_Req_Reply	●	●
0x1B	Set_HF_Gain_Level	●	●
0x1C	EQ_Mode_Setting	●	●
0x1D	DSP_NR_CTRL	●	●
0x1E	GPIO_Control	●	●
0x1F	MCU_UART_Rx_Buffer_Size	●	●
0x20	Voice_Prompt_Cmd	●	●
0x21	MAP_REQUEST		
0x22	Security_Bonding_Req	●	
0x23	Set_Overall_Gain	●	●
0x24	Read_BTM_Setting	●	●
0x25	Read_BTM_Batt_CHG_Status	●	●
0x26	MCU_Update_Cmd	●	●
0x27	REPORT_BATTERY_CAPACITY	●	●
0x28	LE_ANCS_Service_Cmd	●	●
0x29	LE_Signaling_Cmd	●	●
0x2A	nSPK Vendor Cmd		●
0x2B	Read_NSPK_Link_Status		●
0x2C	NSPK_Sync_Audio_Effect		●
0x2D	LE_GATT_Cmd	●	
0x2E	Reserve_NOT_USE		
0x2F	LE_APP_Cmd	●	
0x30	DSP_RUNTIME_PROGRAM	●	●
0x31	Read_Vendor_EEPROM_Data		●

0x32	Query IC version information	●	●
0x33	Voice_Prompt_Ind_Cmd		
0x34	Read_BTM_Link_Mode		
0x35	Configure_Vendor_Parameter		●
0x36	DSP_Dedicated_Cmd		
0x37	nSPK Exchange_Link_Info_Cmd		●
0x38	nSPK Set GIAC		●
0x39	READ_FEATURE_LIST		
0x3A	Personal_MSPK_GROUP_Control		
0x40	Reserver for internal test		

MSPK v1.1 (IS206xGM/BM6x)	MSPK v1.2 (IS206xGM/BM6x)	IS2064S/B
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●
●	●	●

●	●	●
●	●	●
●	●	●
●	●	●
●	●	
	●	

Value	Parameter Description
0x01	add/remove SCO link
0x02	force end active call
0x04	Accept an incoming call
0x05	Reject an incoming call
0x06	End call/ transfer audio to phone
0x07	Toggle microphone on/off
0x08	Mute microphone
0x09	Active microphone
0x0A	voice dial
0x0B	cancel voice dial
0x0C	last number redial
0x0D	Set the active call on hold and active the hold call
0x0E	switch voice between phone and headset
0x0F	Query call list information(CLCC)
0x10	three way call
0x11	release the waiting call or on hold call
0x12	accept the waiting call or active the on hold call and release the active call
0x16	initiate HF connection
0x17	disconnect HF link
0x18	Enable RX noise reduction when SCO ready
0x19	Disable RX noise reduction when SCO ready
0x1A	Switch RX noise reduction when SCO ready
0x1B	Enable TX noise reduction when SCO ready
0x1C	Disable TX noise reduction when SCO ready
0x1D	Switch TX noise reduction when SCO ready
0x1E	Enable AEC when SCO ready
0x1F	Disable AEC when SCO ready
0x20	Switch AEC enable/disable when SCO ready
0x21	Enable AEC RX noise reduction when SCO ready
0x22	Disable AEC RX noise reduction when SCO ready
0x23	Switch AEC RX noise reduction when SCO ready
0x24	increase microphone gain
0x25	decrease microphone gain
0x26	switch primary HF device and secondary HF device role
0x30	increase speaker gain
0x31	decrease speaker gain
0x32	Play/Pause music
0x33	Stop music
0x34	Next song
0x35	Previous song
0x36	Fast forward
0x37	Rewind
0x38	EQ mode up
0x39	EQ mode down
0x3A	Lock button
0x3B	Disconnect A2DP link
0x3C	next audio effect
0x3D	previous audio effect
0x3E	Toggle 3D effect
0x3F	report current EQ mode

0x40	report current audio effect status
0x50	enter pairing mode (from power off state)
0x51	power on button press
0x52	power on button release
0x53	power off button press
0x54	power off button release
0x55	Reverse panel
0x56	Reset some EEPROM setting to default setting
0x57	Force speaker gain toggle
0x58	Toggle button indication
0x59	Combine function 0
0x5A	Combine function 1
0x5B	Combine function 2
0x5C	Combine function 3
0x5D	fast enter pairing mode (from non-off mode)
0x5E	Switch power OFF
0x5F	Disable LED
0x60	Toggle buzzer
0x61	Disable buzzer
0x62	Enable buzzer
0x63	Change tone set (SPK module support two sets of tone)
0x64	Retrieve phonebook
0x65	Retrieve MCH
0x66	Retrieve ICH
0x67	Retrieve OCH
0x68	Retrieve CCH
0x69	Cancel access PBAP
0x6A	Indicate battery status
0x6B	Exit pairing mode
0x6C	link last device
0x6D	disconnect all link
0x6E	OHS event 1
0x6F	OHS event 2
0x70	OHS event 3
0x71	OHS event 4
0x72	SHS_SEND_USER_DATA_1 (for embedded application mode)
0x73	SHS_SEND_USER_DATA_2 (for embedded application mode)
0x74	SHS_SEND_USER_DATA_3 (for embedded application mode)
0x75	SHS_SEND_USER_DATA_4 (for embedded application mode)
0x76	SHS_SEND_USER_DATA_5 (for embedded application mode)
0x77	report current RX NR status
0x78	report current TX NR status
0x79	force buzzer alarm
0x7A	Cancel all BT paging
0x7B	OHS event 5
0x7C	OHS event 6
0x7D	Disconnect SPP
0xC0	OHS event 7 (for Unlimiter project)
0xC1	OHS event 8 (for Unlimiter project)
0xC2	OHS event 9 (for Unlimiter project)
0xC3	OHS event 10 (for Unlimiter project)
0xC4	OHS event 11 (for Unlimiter project)
0xC5	OHS event 12 (for Unlimiter project)

0xC6	OHS event 13 (for Unlimiter project)
0xC7	OHS event 14 (for Unlimiter project)
0xC8	OHS event 15 (for Unlimiter project)
0xC9	OHS event 16 (for Unlimiter project)
0xCA	OHS event 17 (for Unlimiter project)
0xCB	Switch DSP mode 2 or 3 (for Unlimiter project)
0xE0	Trigger NSPK Master
0xE1	Trigger NSPK Slave
0xE2	NSPK one key connect/disconnect
0xE3	Cancel NSPK creation
0xE4	Terminate NSPK link
0xE5	Terminate / Cancel NSPK connection
0xE6	NSPK Master enter Aux-in 44.1K PCM Encoder mode
0xE7	NSPK Master enter Aux-in 48K PCM Encoder mode
0xE8	NSPK Master exit Aux-in PCM Encoder mode
0xE9	NSPK Master enter Aux-in SBC Encoder mode
0xEA	NSPK Master exit Aux-in SBC Encoder mode
0xEB	NSPK dynamic creation
0xEC	NSPK switch channel
0xED	NSPK power off all speakers
0xEE	NSPK AFH SBCENCODING AUDIOSYNC
0xF0	NSPK MASTER PAGE SLAVE FOR NEW SLAVE
0xF1	NSPK SLAVE ENABLE PAGE SCAN FOR NEW MASTER
0xF2	NSPK SLAVE USE SLOW PAGE SCAN
0xF3	NSPK SLAVE USE FAST PAGE SCAN
0xF4	NSPK_ENTER_NSPK_MODE
0xF5	NSPK_ENTER_BROADCAST_MODE
0xF6	NSPK_ADD_THIRD_SPK
0xF7	NSPK_SOUND_SYNCHRONIZATION
0xF8	NSPK_CSB_CONNECTED_MODE_SWITCH
0xF9	NSPK back to last mode

dual mode SPK 2.0	multi-SPK Flash V1	multi-SPK Flash V1.1/V1.2	BT5506 104/105 ROM
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●

●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	●
●	●	●	

	●	●	●
	●	●	●
	●	●	●
	●	●	●
	●	●	●
	●	●	●
	●	●	
	●	●	
	●	●	
	●	●	
	●	●	
	●	●	●
	●	●	●
	●	●	●
	●	●	
	●	●	
	●	●	
	●	●	●
	●	●	
	●	●	

Event ID	Event	dual mode SPK 2.0	multi-SPK Flash V1
0x00	Command_ACK	●	●
0x01	BTM_Status	●	●
0x02	Call_Status	●	●
0x03	Caller_ID	●	●
0x04	SMS_Received_Indication	●	●
0x05	Missed_Call_Indication	●	●
0x06	Phone_Max_Battery_Level	●	●
0x07	Phone_Current_Battery_Level	●	●
0x08	Roaming_Status	●	●
0x09	Phone_Max_Signal_Strength_Level	●	●
0x0A	Phone_Current_Signal_Strength_Level	●	●
0x0B	Phone_Service_Status	●	●
0x0C	BTM_Battery_Status	●	●
0x0D	BTM_Charging_Status	●	●
0x0E	Reset_To_Default	●	●
0x0F	Report_HF_Gain_Level	●	●
0x10	EQ_Mode_Indication	●	●
0x11	PBAP_Missed_Call_History		
0x12	PBAP_Received_Call_History		
0x13	PBAP_Dialed_Call_History		
0x14	PBAP_Combine_Call_History		
0x15	Phonebook_Contacts		
0x16	PBAP_Access_Finish		
0x17	Read_Linked_Device_Information_Reply	●	●
0x18	Read_BTM_Version_Reply	●	●
0x19	Call_List_Report	●	●
0x1A	AVC_Specific_Rsp	●	●
0x1B	BTM_Utility_Req	●	●
0x1C	Vendor_AT_Cmd_Reply	●	●
0x1D	Report_Vendor_AT_Event	●	●
0x1E	Read_Link_Status_Reply	●	●
0x1F	Read_Paired_Device_Record_Reply	●	●
0x20	Read_Local_BD_Address_Reply	●	●
0x21	Read_Local_Device_Name_Reply	●	●
0x22	Report_SPP/iAP_Data	●	●
0x23	Report_Link_Back_Status	●	●
0x24	REPORT_RING_TONE_STATUS	●	●
0x25	User_Confrim_SSP_Req	●	●
0x26	Report_AVRCP_Vol_Ctrl	●	●
0x27	Report_Input_Signal_Level	●	●
0x28	Report_iAP_Info	●	●
0x29	REPORT_AVRCP_ABS_VOL_CTRL	●	●
0x2A	Report_Voice_Prompt_Status	●	●
0x2B	Report_MAP_Data		
0x2C	Security_Bonding_Res		
0x2D	Report_Type_Codec	●	●
0x2E	Report_Type_BTM_Setting	●	●
0x2F	Report_MCU_Update_Reply	●	●
0x30	Report_BTM_Initial_Status	●	●
0x31	LE_ANCS_Service_Event	●	●

0x32	LE_Signaling_Event	●	●
0x33	Report_nSPK_Link_Status		●
0x34	Report_nSPK_Vendor_Event		●
0x35	Report_nSPK_Audio_Setting		●
0x36	Report_Sound_Effect_Status	●	●
0x37	Report_Vendor_EEPROM_Data		●
0x38	REPORT_IC_VERSION_INFO	●	●
0x39	REPORT_LE_GATT_EVENT	●	
0x3A	Report_BTM_Link_Mode		
0x3B	DSP_Dedicated_Event		
0x3C	Report_nSPK_MISC_Event		
0x3D	Report_nSPK_Exchange_Link_Info		●
0x3E	Report Customized_Information		●
0x3F	Report_CSB_CLK		
0x40	Report_Read_Feature_List_Reply		
0x41	REPORT_TEST_RESULT_REPLY		
0x50	Reserver for internal test		

multi-SPK Flash V1.1/V1.2	BT5506 104/105 ROM
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●

●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	●
●	

Value	Parameter Description	dual mode SPK 2.0
0x00	To Handle NFC action	
0x01	To Enable/Disable in-built Aux Line In Function If in-built Aux Line In Function is enabled then once line in is detected , BTM will process built-in aux line-in detection procedure	
0x02	To generate the specific tone	
0x03	To make BTM inactive or active	
0x04	To indicate charger adaptor status	
0x05★	To indicate BTM that remote device supports TTS engine. The BTM shall disable internal TTS engine.	
0x06	To update partial EEPROM data which are related to part of audio configuration.	
0x07	Voice prompt for given version number	
0x08	For NSPK, MCU notifies the BTM current power condition	
0x09	To update vendor EEPROM data	
0x0A	For NSPK, To inform Master that certain status has been changed in Slave side	
0x0B	To Read Serial number .For this command, MCU will receive event Report_Vendor_EEPROM_Data with report data 16 bytes	
0x0C★	To switch audio channel	
0x0D★	Customized MCU report : MCU Report specified information the following parameter	
0x0E★	Customized MCU request : MCU request specified information by the following parameter. BTM replies the specified information by E3E	

★ Customize commands default are disable. Please check the firmware release note to identify which customize commands support.

multi-SPK Flash V1	BT5506 104/105 ROM
●	●
●	●
●	●
●	●
●	●
●	●
●	
●	●
●	●
●	●
●	