


MFLI User Manual



Zurich
Instruments

MFLI User Manual

Zurich Instruments AG

Revision 21.08

Copyright © 2008-2021 Zurich Instruments AG

The contents of this document are provided by Zurich Instruments AG (ZI), "as is". ZI makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication and reserves the right to make changes to specifications and product descriptions at any time without notice.

LabVIEW is a registered trademark of National Instruments Inc. MATLAB is a registered trademark of The MathWorks, Inc. All other trademarks are the property of their respective owners.

Table of Contents

| | |
|---|-----|
| What's New in the MFLI User Manual | V |
| Declaration of Conformity | VI |
| 1. Getting Started | 7 |
| 1.1. Quick Start Guide | 8 |
| 1.2. Inspect the Package Contents | 10 |
| 1.3. Handling and Safety Instructions | 12 |
| 1.4. Connecting to the MFLI Instrument | 15 |
| 1.5. Running LabOne on a Separate PC | 29 |
| 1.6. LabOne Software Start-up | 38 |
| 1.7. Using the LabOne Programming Interfaces | 44 |
| 1.8. Software Update | 46 |
| 1.9. Troubleshooting | 51 |
| 2. Functional Overview | 54 |
| 2.1. Features | 55 |
| 2.2. Front Panel Tour | 58 |
| 2.3. Back Panel Tour | 60 |
| 2.4. Ordering Guide | 61 |
| 2.5. Rack Mount | 63 |
| 3. Tutorials | 68 |
| 3.1. Simple Loop | 69 |
| 3.2. External Reference | 75 |
| 3.3. Sweeper | 80 |
| 3.4. Basic Impedance Measurement | 85 |
| 3.5. Advanced Impedance Measurements | 91 |
| 3.6. Compensation | 96 |
| 3.7. Phase-locked Loop | 100 |
| 3.8. Automatic Gain Control | 105 |
| 3.9. Imaging | 111 |
| 4. Functional Description LabOne User Interface | 115 |
| 4.1. User Interface Overview | 116 |
| 4.2. Saving and Loading Data | 130 |
| 4.3. Lock-in Tab | 149 |
| 4.4. Lock-in Tab (MF-MD option) | 160 |
| 4.5. Numeric Tab | 172 |
| 4.6. Plotter Tab | 174 |
| 4.7. Scope Tab | 176 |
| 4.8. Data Acquisition Tab | 189 |
| 4.9. Spectrum Analyzer Tab | 197 |
| 4.10. Sweeper Tab | 201 |
| 4.11. Auxiliary Tab | 210 |
| 4.12. Inputs/Outputs Tab | 213 |
| 4.13. DIO Tab | 214 |
| 4.14. Impedance Analyzer Tab | 217 |
| 4.15. Config Tab | 231 |
| 4.16. Device Tab | 237 |
| 4.17. File Manager Tab | 242 |
| 4.18. PID / PLL Tab | 244 |
| 4.19. Threshold Tab | 258 |
| 4.20. MOD Tab | 263 |
| 4.21. Multi Device Sync Tab | 267 |
| 4.22. ZI Labs Tab | 270 |
| 4.23. Upgrade Tab | 271 |
| 5. Specifications | 272 |
| 5.1. General Specifications | 273 |

| | |
|--|-----|
| 5.2. Performance Diagrams | 284 |
| 6. Signal Processing Basics | 288 |
| 6.1. Principles of Lock-in Detection | 289 |
| 6.2. Signal Bandwidth | 292 |
| 6.3. Discrete-Time Filters | 294 |
| 6.4. Full Range Sensitivity | 296 |
| 6.5. Sinc Filtering | 298 |
| 6.6. Zoom FFT | 301 |
| 7. Device Node Tree | 302 |
| 7.1. Introduction | 303 |
| 7.2. Reference Node Documentation | 307 |
| Glossary | 399 |
| Index | 405 |

What's New in the MFLI User Manual

Release 21.08

Release date: 31-Aug-2021

- User Manual: HTML version available in LabOne user interface and [online documentation](#).
- LabOne Software: Support for GNU/Linux and macOS on ARM64 and Apple M1 processors.
- Impedance Analyzer: Current Zone ranging feature to set the switching frequency limits for current input ranges.

Release 21.02

Release date: 28-Feb-2021

- LabOne API: Added online Programming Manual and Documentation.
- Sweeper: Simultaneous display of standard and X-Y plots to visualize Nyquist and Bode plots at the same time.
- Sweeper: Improved rendering of sweeps with more than 2000 points.

Release 20.07

Release date: 20-Aug-2020

- LabOne: Trends plots to track readings from the Math sub-tab over time.
- LabOne: Device Information report in Device tab.
- LabOne: Improved colormaps available for 2D plots.
- PID Advisor: clamp maximum advised bandwidth to hardware limits to guard against instability.

Release 20.01

Release date: 28-Feb-2020

- MD option: external reference mode is available for all demodulator paths.
- MOD option: enabled simultaneous demodulation of both sidebands when carrier and sideband frequencies are provided by external references.
- PID option: added control button to keep or reset the integrator value on stop and restart of PID controllers.
- LabOne: added linear fit to the Math sub-tab of Sweeper and DAQ tabs.
- LabOne: histogram data can be saved in CSV format.
- LabOne: added option to display a normal or Rice distribution fit of histogram in Plotter tab.
- LabOne: improved importing of saved SVG figures to main vector graphics editors.

Declaration of Conformity

The manufacturer

Zurich Instruments
Technoparkstrasse 1
8005 Zurich
Switzerland

declares that the product
MFLI Lock-in Amplifier , 500 kHz / 5 MHz, 60 MSa/s

fulfills the requirements of the European guidelines

- 2004/108/EC Electromagnetic Compatibility
- 2006/95/EC Low Voltage
- 2011/65/EU Restriction of Hazardous Substances (RoHS)
- 1907/2006/EC Registration, Evaluation, Authorization, and Restriction of Chemicals (REACH)

The assessment was performed using the directives according to [Table 1](#).

Table 1. Conformity table

| | |
|------------------------------|---|
| EN 61326-1:2006 | Emissions for industrial environments, immunity for industrial environments |
| EN 61000-6-4 | Emission standard for industrial environments |
| EN 61000-6-2 | Immunity for industrial environments |
| EN 55011 | Group 1, class A and B (the product was tested in typical configuration) |
| EN 61000-4-2 | CD 4 kV, AD 8 kV |
| EN 61000-4-3 | 10 V/m 80% AM 80 MHz - 1 GHz |
| | 3 V/m 80% AM 1 GHz - 2 GHz |
| | 1 V/m 80% AM 2 GHz - 2.7 GHz |
| EN 61000-4-4 | 2 kV power line |
| | 1 kV USB line |
| EN 61000-4-5 | 1 kV line-line, 2 kV line-earth |
| EN 61000-4-6 | 10 V 150 kHz - 80 MHz 80% AM, power line |
| EN 61000-4-11 | 100% dip (1 cycle), 30% dip (25 cycles), 60% dip (10 cycles), 100% short interruptions (250 cycles) |
| IEC 61010-1:2010 + AMD1:2016 | Safety requirements for electrical equipment for measurement, control and laboratory use |



Chapter 1. Getting Started

This first chapter guides you through the initial set-up of your MFLI Instrument in order to make your first measurements. This chapter comprises:

- A Quick Start Guide
- The package contents list
- Essential handling and safety instructions
- Instructions for connecting to the MFLI Instrument
- Instructions for running LabOne on a separate PC
- Instructions for getting started with the LabOne APIs
- Troubleshooting guidelines

This chapter is delivered as a hard copy with the instrument upon delivery. It is also the first chapter of the MFLI User Manual.

1.1. Quick Start Guide

This page addresses all the people who have been impatiently awaiting their new gem to arrive and want to see it up and running quickly. If the MFLI Instrument is to be integrated into a LAN with DHCP server, it is ready to go without further need of software installation. Please proceed along the following steps:

1. Inspect the package content. Besides the Instrument there should be a country-specific power cable, a USB cable, an Ethernet cable and a hard copy of the user manual [Chapter 1](#).
2. Check the Handling and Safety Instructions in [Section 1.3](#).
3. Connect the Instrument to the power line. Turn it on and connect it to a switch in the LAN using the Ethernet cable, or directly to the host computer with the USB cable. After flashing green for a short time, the front panel LED will show a steady blue color. If the LED remains flashing green, power-cycle the MFLI instrument again and wait for the LED to turn blue. If the LED does not turn blue, please contact Zurich Instruments for assistance.
4. **Ethernet:** open a web browser (Chrome, Edge, Firefox, Safari, or Opera) on a computer in the LAN and type the following text in the address bar:

[http://<instrument-serial>/](http://<instrument-serial>)

where **<instrument-serial>** is the serial number of the instrument that can be found on the instrument back panel. Using the **http://** prefix and trailing slash prevents the triggering of search engines. Examples for the browser address bar (left) and for the instrument serial sticker (right) are shown below. In this particular example the serial number is **MF-DEV3026**.



Alternative ways to address the instrument are: **<http://<instrument-serial>.<domain>/>** where **<domain>** is the network domain in which the instrument is running, **<http://<instrument-serial>.local/>** and, in case the IP address is known, e.g. **<http://192.168.11.2/>**.

USB (Windows): when connected via USB, the MFLI acts as a flash drive similar to a USB stick. Find the suitable USB driver for your operating system on that flash drive, and install it e.g. by double-clicking **MF-Device-Finder64.msi**. [Universal Serial Bus \(USB\) Connection](#) contains more detailed instructions. Under Windows 10, the installation of the driver will create a Start Menu entry¹ in **Start Menu → Zurich Instruments → MF Device Finder**. Click this link to open the MF Device Finder app which lists all available instruments. Double-click on the entry for your instrument to open the default web browser with the LabOne User Interface start-up screen.

USB (Linux/Mac): Linux computers usually don't require a USB driver installation. On Macintosh computers, install the USB driver according to the installations in [Universal Serial Bus \(USB\) Connection](#). Open a web browser and enter **<http://<instrument-serial>/>** into the address bar, where the instrument serial of the format **MF-DEV3026** is found on the back panel of your instrument.

5. The LabOne User Interface start-up screen will appear. Click the **Open** button on the lower right of the page. The default configuration will be loaded and the first measurements can be taken. If the user interface does not start up successfully, please refer to [Section 1.5](#).

¹Under Windows 7 and 8, the Start Menu entry is found in **Start Menu → All programs / All apps → Zurich Instruments → MF Device Finder**

If any problems occur whilst setting up the instrument and software please see the <[Section 1.9](#) at the end of this chapter. For turning off the instrument after use, it is recommended to use the soft power off functionality by clicking on the  button at the bottom left of the user interface screen before turning the power switch on the back panel of the instrument.

Once the Instrument is up and running we recommend going through some of the [Chapter 3](#). Moreover, [Chapter 2](#) provides a general introduction to the various tools and settings tabs with tables in each section providing a detailed description of every UI element as well. For specific application know-how the [blog section](#) of the Zurich Instruments web page will serve as a valuable resource that is constantly updated and expanded.



1.2. Inspect the Package Contents

If the shipping container appears to be damaged, keep the container until you have inspected the contents of the shipment and have performed basic functional tests.

Please verify:

- You have received 1 Zurich Instruments MFLI Instrument
- You have received 1 Zurich Instruments MFITF Impedance Test Fixture
- You have received 1 power cord with a power plug suited to your country
- You have received 1 USB cable and/or 1 LAN cable (category 5/6 required)
- You have received 1 WiFi USB adapter
- You have received 1 Getting Started booklet
- The "Next Calibration" sticker on the rear panel of the Instrument indicates approximately 2 years ahead in time. Zurich Instruments recommends calibration intervals of 2 years
- The MAC address and serial number of the instrument are displayed on a sticker on the back panel

Table 1.1. Package contents for the MFLI Instrument

| | | |
|--|--|---|
|  |  Power cord (example: EU norm) |  USB cable |
|--|--|---|

1.2. Inspect the Package Contents

| | |
|---|---|
|  |  |
| Power inlet with power switch and fuse holder | LAN / Ethernet cable (category 5/6 required) |
|  | |
| WiFi USB adapter | |
| S/N MF-DEV3026 MAC 80:2F:DE:00:07:EA   |  Next Calibration Apr 2022 |
| S/N and MAC address sticker on the back panel of the instrument | "Next Calibration" sticker on the back panel of the instrument |

The MFLI Instrument is equipped with a multi-mains switched power supply, and therefore can be connected to most power systems in the world. The fuse holder is integrated with the power inlet, and can be extracted by grabbing the holder with two small screwdrivers at the top and at the bottom at the same time. A spare fuse is contained in the fuse holder. The fuse description is mentioned in the specifications chapter.

Carefully inspect your Instrument. If there is mechanical damage or the instrument does not pass the basic tests, then you should immediately notify the Zurich Instruments support team at support@zhinst.com.

1.3. Handling and Safety Instructions

The MFLI Instrument is a sensitive piece of electronic equipment, and under no circumstances should its casing be opened, as there are high-voltage parts inside which may be harmful to human beings. There are no serviceable parts inside the instrument. Do not install substitute parts or perform any unauthorized modification to the product. Opening the instrument immediately voids the warranty provided by Zurich Instruments.

Do not use this product in any manner not specified by the manufacturer. The protective features of this product may be affected if it is used in a way not specified in the operating instructions.

The following general safety instructions must be observed during all phases of operation, service, and handling of the instrument. The disregard of these precautions and all specific warnings elsewhere in this manual may negatively affect the operation of the equipment and its lifetime.

Zurich Instruments assumes no liability for the user's failure to observe and comply with the instructions in this user manual.

Table 1.2. Safety Instructions

| | |
|--|--|
| Ground the instrument | The instrument chassis must be correctly connected to earth ground by means of the supplied power cord. The ground pin of the power cord set plug must be firmly connected to the electrical ground (safety ground) terminal at the mains power outlet. Interruption of the protective earth conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury and potential damage to the instrument. |
| Measurement category | This equipment is of measurement category I (CAT I). Do not use it for CAT II, III, or IV. Do not connect the measurement terminals to mains sockets. |
| Maximum ratings | The specified electrical ratings for the connectors of the instrument should not be exceeded at any time during operation. Please refer to the Chapter 5 for a comprehensive list of ratings. |
| Do not service or adjust anything yourself | There are no serviceable parts inside the instrument. |
| Software updates | Frequent software updates provide the user with many important improvements as well as new features. Only the last released software version is supported by Zurich Instruments. |
| Warnings | Instructions contained in any warning issued by the instrument, either by the software, the graphical user interface, the notes on the instrument or mentioned in this manual, must be followed. |
| Notes | Instructions contained in the notes of this user manual are of essential importance for correctly interpreting the acquired measurement data. |
| Floating shield connectors | The Signal Input connector shields are allowed to float relative to earth ground. These shields are connected to each other through internal circuitry. Attempting to drive them to a different potential can result in high currents that may damage your instrument. The Signal Input connector shields are only allowed to float relative to earth ground within a certain voltage range, please refer to the Chapter 5 . It is recommended to discharge the test device before |



| | |
|--|--|
| | connecting or to enable the floating Signal Input shields only after the signal source has been connected to the instrument. |
| High voltage transients due to inductive loads | When measuring devices with high inductance, take adequate measures to protect the Signal Input connectors against the high voltages of inductive load switching transients. These voltages can exceed the maximum voltage ratings of the Signal Inputs and lead to damage. |
| Location and ventilation | This instrument or system is intended for indoor use in an installation category II and pollution degree 2 environment as per IEC 61010-1. Do not operate or store the instrument outside the ambient conditions specified in the Chapter 5 section. Do not block the ventilator opening on the back or the air intake on the chassis side and allow a reasonable space for the air to flow. |
| Cleaning | To prevent electrical shock, disconnect the instrument from AC mains power and disconnect all test leads before cleaning. Clean the outside of the instrument using a soft, lint-free cloth slightly dampened with water. Do not use detergent or solvents. Do not attempt to clean internally. |
| AC power connection and mains line fuse | For continued protection against fire, replace the line fuse only with a fuse of the specified type and rating. Use only the power cord specified for this product and certified for the country of use. Always position the device so that its power switch and the power cord are easily accessible during operation. |
| Main power disconnect | Unplug product from wall outlet and remove power cord before servicing. Only qualified, service-trained personnel should remove the cover from the instrument. |
| Operation and storage | Do not operate or store the instrument outside the ambient conditions specified in the Chapter 5 section. |
| Handling | Handle with care. Do not drop the instrument. Do not store liquids on the device, as there is a chance of spillage resulting in damage. |
| Safety critical systems | Do not use this equipment in systems whose failure could result in loss of life, significant property damage or damage to the environment. |

When you notice any of the situations listed below, immediately stop the operation of the instrument, disconnect the power cord, and contact the support team at Zurich Instruments, either through the website form or by support@zhinst.com.

Table 1.3. Unusual Conditions

| | |
|---|--|
| Fan is not working properly or not at all | Switch off the instrument immediately to prevent overheating of sensitive electronic components. |
| Power cord or power plug on instrument is damaged | Switch off the instrument immediately to prevent overheating, electric shock, or fire. Please exchange the power cord only with one for this product and certified for the country of use. |
| Instrument emits abnormal noise, smell, or sparks | Switch off the instrument immediately to prevent further damage. |
| Instrument is damaged | Switch off the instrument immediately and ensure it is not used again until it has been repaired. |

Table 1.4. Symbols

| | |
|---|--|
|  | Earth ground |
|  | Chassis ground |
|  | Caution. Refer to accompanying documentation |
|  | DC (direct current) |

1.4. Connecting to the MFLI Instrument

The Zurich Instruments MFLI is designed to work out of the box with minimal effort on the part of the user. The Zurich Instruments LabOne software runs on an embedded PC in the MFLI instrument and is pre-installed before delivery. One of the programs running on the embedded PC is the LabOne Web Server, which can be connected to via a web browser once suitable physical and logical connections to the instrument have been established.

Note

The following web browsers are supported (latest versions)



There are two ways to physically connect to the instrument:

- Ethernet (no software installation required). Integrate the instrument into an existing local area network (LAN) by connecting the instrument to a switch in the LAN using an Ethernet cable. The instrument can then be accessed from a web browser running on any device in the same LAN. The Ethernet connection can also be point-to-point. This requires some adjustment of the network card settings of the host computer. Depending on the network configuration and the installed network card, one or the other connection scheme is better suited.
- Universal Serial Bus (USB). The USB connection is a point-to-point connection between the instrument and the host computer to which the USB cable is connected. This requires the installation of an RNDIS driver on the host computer. For PC users, this driver is available on the instrument flash memory which appears as a new drive in the File Explorer once the instrument is connected /by USB to your PC. The driver is available online for Mac users.




Figure 1.1. Connectivity

Figure 1.1 shows some examples of possible configurations of computer to instrument connectivity.

1.4.1. Ethernet TCP/IP Connection

The simplest connection method is to integrate the instrument into an existing LAN supporting the Domain Name System (DNS) and dynamic DNS update. In such a network the MFLI instrument can be addressed using its serial number instead of its IP address. Attach an Ethernet cable from the instrument to a LAN network switch. The LabOne User Interface can be started by typing the following text in the address bar of a web browser running on a computer in the LAN:

```
http://<instrument-serial>.<domain>/, or  
http://<instrument-serial>.local/, or  
http://<instrument-serial>/
```

where **<instrument-serial>** is the serial number of the instrument and **<domain>** is the network domain in which the instrument is running.

This approach uses DNS lookup to resolve the IP address of the instrument which is configured with this network name by default. It is possible that this approach fails due to special

network policies or for other reasons. In that case, there are other options to configure the TCP/IP connection to the instrument. These are described in [Section 1.4.4 Advanced TCP/IP Configuration](#).

With connection via LAN, multiple web browser and API client sessions have simultaneous access and control over the instrument. Therefore changes made to the settings of the instrument by say a Python program via the API will be seen by a web browser session connected to that instrument. The instrument data can be streamed to multiple client sessions simultaneously.




Figure 1.2. Simplest connection to MFLI instrument

1.4.2. Universal Serial Bus (USB) Connection

To control the instrument via USB, connect the instrument with the supplied USB cable to the PC you are using. Depending on the operating system you are using, it may be necessary to install a USB RNDIS device driver on the PC. The RNDIS provides a virtual Ethernet link to the instrument enabling it to be addressed using the normal IP address and host name mechanisms. The RNDIS driver installation procedure for various operating systems is described in the following.

USB RNDIS Device Driver Windows

Zurich Instruments provides a Microsoft MSI installer to simplify the Windows RNDIS driver installation. The MFLI Instrument is designed so that when the USB cable is plugged in, a flash disk partition appears with the label **MF-DRIVER**, containing the required Windows MSI installer for the USB RNDIS device driver, plus the instrument user manual in PDF form and a copy of this Getting Started chapter.

Proceed with the device driver installation as follows:

1. Log on to the PC as an administrator. Installing the USB RNDIS device driver requires administrator rights.
2. Ensure that the USB cable is connected from the PC to the MFLI Instrument.
3. Power cycle the MFLI Instrument and wait for approximately 20 seconds for the instrument initialization to complete. During this time an AutoPlay window will pop up showing the newly detected MFLI drive.
4. In the AutoPlay window, select Open folder to view files.
5. Two installers will be visible in Windows Explorer: Double click on the .msi installer appropriate for your operating system. This will be either

MF-Device-Finder64.msi for 64 bit operating systems, or

MF-Device-Finder32.msi for 32 bit operating systems.

1.4. Connecting to the MFLI Instrument




Figure 1.3. Read-only drive of the MFLI shown in the File Explorer

6. In the welcome screen click the Next button.




Figure 1.4. Installation welcome screen

7. After reading through the Zurich Instruments license agreement, check the "I accept the terms in the License Agreement" check box and click the Next button.




Figure 1.5. Installation license agreement

8. In the Custom Setup screen click the Next button.

1.4. Connecting to the MFLI Instrument




Figure 1.6. Custom setup screen

9. Click the Install button to start the installation.




Figure 1.7. Installation confirmation




Figure 1.8. Installation progress

If the User Account Control pop-up window appears, click Yes to allow the installation program to make changes to the computer.

1.4. Connecting to the MFLI Instrument

10. On Windows Server 2008 and Windows 7 it is required to confirm the installation of up to 2 drivers from the trusted publisher Zurich Instruments. Click on Install. You can also click the Always trust software from "Zurich Instruments AG" check box to prevent the message from appearing in the future.



Figure 1.9. Installation driver acceptance

11. Click the Finish button to complete the installation.




Figure 1.10. Installation complete

The installation of the driver will create a Windows Start Menu entry² in **Start Menu → Zurich Instruments → MF Device Finder**. This link will open the ZI MF Device Finder shown in [Figure 1.12](#). In the list of devices, identify your instrument by its serial number found on the back panel. Double-click on the entry for your instrument to open the default browser with the LabOne Device Connection dialog shown in [Figure 1.13](#). Click on Open on the bottom right of the screen to open a LabOne browser session with the default settings.




Figure 1.11. Windows Start Menu entry to start the Zurich Instruments MF Device Finder

²Under Windows 7 and 8, the Start Menu entry is found in **Start Menu → All programs / All apps → Zurich Instruments → MF Device Finder**

Note

The procedure described in this section works both for 1GbE and USB connections. In case you use 1GbE, you can also connect to the Instrument without software installation using just a web browser. To that end, follow the instructions in [Section 1.4.1](#).




Figure 1.12. MF Device Finder




Figure 1.13. Device Connection dialog after starting the LabOne User Interface

USB RNDIS Device Driver Linux

With an up-to-date version of a UBUNTU Linux distribution there is no special installation necessary, the USB connection works out of the box.

Other Linux distributions should also work but may require further installation steps. Detailed instructions cannot not given here due to the large number of Linux distributions available.

USB RNDIS Device Driver OS X

To install the required USB RNDIS device driver on a Macintosh computer, proceed as follows:




1. Open a web browser and go to <http://joshuawise.com/horndis> page and click the link to download the latest binary package. At the time of writing, this link leads to the file **HoRNDIS-re17.pkg**, which should be downloaded.

Downloading and installing HoRNDIS

HoRNDIS is available in source form from its [project page on GitHub](#), and in binary form [on this site](#). For quick start instructions:

- Download the latest binary package, and double-click on it in your Downloads folder. Follow the instructions in the installer.


2. Locate the downloaded file using the Finder. The file can typically be found in the Downloads folder. Double click the file to run the installer.
3. The installer will guide you through the installation process. Select the standard option in each dialog and click Continue to proceed with the installation.



4. Before the installer can finalize the installation, it will request administrator permissions. Supply the necessary credentials to finish the installation.





5. A summary of the installation will be shown once it completes.



6. At this point it is advisable to restart the computer.
7. Connect the MFLI Instrument to the computer using the USB cable and power it up. Wait until the blue LED on the front-panel of the MFLI Instrument illuminates.
8. To verify that the MFLI is correctly detected by the computer open the System Preferences and select the Network category.

1.4. Connecting to the MFLI Instrument



The MFLI device should now be shown in the interface list with a green icon and marked as **Connected**. When the interface is selected, the information in the right hand side pane should update to show that the interface uses DHCP and the IP address should take the form **192.168.x.x**.

9. It is now possible to connect to the device using a web browser either by entering the following in the address bar:

```
<instrument-serial>.local/
```

where **<instrument-serial>** is the serial number of the instrument of the form mf-dev3000.

Alternatively, the IP address of the instrument can be used. The IP address of the instrument is the IP address shown in the previous step, with 1 added to the right-most octet. So for instance, if the IP address shown is **192.168.47.57**, the instrument IP address to enter in the address bar would be **192.168.47.58**.

1.4.3. Wireless Connection

The MFLI can be controlled over a wireless network using the WiFi USB adapter supplied with the instrument. It's necessary to first connect to the instrument via 1GbE or USB in order to enable the wireless network, but once this is done, the instrument can be controlled via the wireless network alone. This can be useful when the instrument is frequently moved inside the laboratory, or used at places where connecting a cable is cumbersome. Also, controlling the instrument from mobile device can make a tutorial, lecture, or demonstration measurement more interactive and effective.

There are two ways of connecting to the instrument: Client mode and Access Point. In Access Point mode, the MFLI creates its own wireless network to which a mobile device can connect. In Client mode, both the MFLI and the host computer connect to an existing wireless network. For Access Point mode to work, the wireless network needs to be either open (without encryption) or WPA2-Personal encrypted (also known as WPA2-PSK), and it needs to support DNS name resolution.

Note

Instruments shipped prior to the 17.06 LabOne release were not supplied with a WiFi USB adapter. If you wish to use the wireless network functionality but your instrument was shipped without the WiFi USB adapter, please contact Zurich Instruments at support@zhinst.com for assistance.

Access point mode

1. Connect the WiFi USB adapter to one of the USB ports on the back panel of the instrument.
2. Connect to the instrument using 1GbE or USB using the Web Server running on the instrument as explained in [Section 1.4.1](#) and [Section 1.4.2](#), respectively.
3. Open the LabOne user interface by clicking the "Open" button in the Device Connection dialog.
4. In the Device tab, find the Wireless Network section. This section is collapsed by default. Expand it using the [+] button.
5. Set Mode to Access Point and select the Enable WiFi checkbox to enable the wireless network.
6. Optionally, click on the Program button to save the WiFi settings persistently on the device.
7. On your mobile device, connect to the wireless network of the MFLI instrument. The network's name (SSID) and password are displayed in the Device tab.
8. On your mobile device, open a browser window and enter the IP address **192.168.20.1** (without prefix **http://** and trailing **/**) to open the Device Connection dialog.
9. Click on "Open" to start the LabOne user interface.

Client mode

1. Connect the WiFi USB adapter to one of the USB ports on the back panel of the instrument.
2. Connect to the instrument using 1GbE or USB as explained in [Section 1.4.1](#) and [Section 1.4.2](#), respectively.
3. Open the LabOne user interface by clicking the "Open" button in the Device Connection dialog.
4. In the Device tab, find the Wireless Network section. This section is collapsed by default. Expand it using the [+] button.
5. Set Mode to Client. The available open or WPA2-Personal encrypted wireless networks should then appear as a drop-down list under SSID.

6. Select the network to which the host PC is connected, and enter the password if necessary. Select the Enable WiFi checkbox to join the wireless network.
7. Optionally, click on the Program button to save the WiFi settings persistently on the device.
8. Now the 1GbE or USB cable can be disconnected. On your host PC, open a browser window and enter the serial number of the device [http://<instrument-serial>/](http://<instrument-serial>) where <instrument-serial> is the serial number of the instrument of the form **MF-DEV3026** that can be found on the instrument back panel. Alternatively, the device IP address can be used directly. The IP address can be obtained by running the MF device finder utility that can be obtained from www.zhinst.com/downloads on a PC that is in the same network as the MFLI.
9. Click on "Open" to start the LabOne user interface.

1.4.4. Advanced TCP/IP Configuration

Various schemes are possible for logically connecting to the MFLI instrument via TCP/IP.

- DHCP (the simplest scheme for the user and the default)
- Static IP (the fallback if DHCP fails)
- Point-to-point (P2P)

DHCP is the simplest and preferred connection method. Other connection methods can become necessary when using network configurations that are in contradiction with the local policies.

DHCP

The most straightforward Ethernet connection method is to rely on a LAN configuration to recognize the MFLI Instrument. This is the MFLI Instrument's default configuration. By connecting the instrument in a LAN, a dynamic IP address is assigned to it like to any other PC by the DHCP server. In case of restricted networks, the network administrator may be required to register the instrument on the network by means of the MAC address. The MAC address is indicated on the back panel of the instrument. If the network configuration does not allow or does not support DHCP it is necessary to use a static IP setup as described below.

Static Instrument IP

The best way to assign the instrument a static IP address is to first connect via USB. This is especially necessary if DHCP is not available in the LAN.

1. Connect to the instrument via USB and start the Zurich Instruments - MF Device Finder as described in [Section 1.4.2](#).
2. Double-click on the list entry for your instrument to open the LabOne Device and Settings dialog. Click on Open in the bottom right corner to start the LabOne user interface.
3. Open the Device tab.
4. In the Communication section, set the desired IP4 address, mask, and gateway.
5. Enable the Static IP checkbox.
6. Click on the Program button to save the changed parameters.
7. Connect an Ethernet cable from a switch in the LAN to the 1GbE port on the back panel of the MFLI Instrument.
8. Power-cycle the MFLI instrument.
9. (Optional) To verify the connection between the host computer and the MFLI Instrument, open a DOS command window and ping the IP address entered above.

- Type the following in the address bar of a web browser on a computer within the LAN:

http://<Static IP Address>/

where **<Static IP Address>** is the static IP address entered above. The LabOne Device Connection dialog should now appear.

Requirements

- The chosen static IP address must be unique within the LAN.
- Needs network administrator support on networks with dynamic IP configuration (the static IP address will need to be reserved).

Point-to-Point (P2P)

Setting up a point-to-point network consisting only of the host computer and the MFLI avoids problems related to special network policies. Since it is nonetheless necessary to stay connected to the internet, it is recommended to install two network cards in your computer, one of them for network connectivity, the second one for connecting to the MFLI Instrument. Notebooks can generally profit from wireless LAN for internet connection.

- Use one of the network cards and set it to static IP in TCP/IPv4 using the IP address **192.168.1.n**, where **n=[2..9]** and the mask **255.255.255.0**, see [Figure 1.14](#) (go to **Control Panel → Internet Options → Network and Internet → Network and Sharing Center → Local Area Connection → Properties**).




Figure 1.14. Static IP configuration of PC

- Set the MFLI IP address to the static value **192.168.1.10** as described in the previous section. To connect to the MFLI Instrument and start the LabOne User Interface, type the following in the address bar of a web browser:

http://192.168.1.10/

Requirements

- Two networks cards needed for additional connection to internet
- Network adapter connected to the instrument must be in static IP4 configuration

Note

A power cycle of the MFLI Instrument is required if it was previously connected to a network that provided an IP address to the instrument and then the user decides to run in static IP configuration.

Note

Only IP v4 is currently supported. There is no support for IP v6.

Note

If the instrument is detected by LabOne but the connection can not be established, the reason can be the firewall blocking the connection. It is then recommended to change the P2P connection from Public to Private.

Warning

Changing the IP settings of your network adapters manually can interfere with its later use, as it can no longer be used for network connectivity until it is set again for dynamic IP.

1.5. Running LabOne on a Separate PC

By default the LabOne Web Server and the Data Server run on the embedded computer in the instrument. It can be advantageous to run both servers on a separate PC, especially when using high data transfer rates or recording high-resolution FFT spectra. The higher processing power of laptop and desktop computers improves UI responsiveness, allows for a higher number of frequency points in the Spectrum Analyzer tool, and reduces the probability of data loss.

To run the Data Server on a separate PC, the LabOne software must be installed on that PC. See [Section 1.5.1](#) for LabOne installation instructions. [software architecture](#) gives an overview of the LabOne software architecture that is particularly useful when using multi-instrument control or the programming interfaces .




Figure 1.15. LabOne Data Server and Web Server running on separate PC

1.5.1. Software Installation

The MFLI Instrument comes with the LabOne software pre-installed and is ready to work out of the box. The LabOne software can also be installed on Windows and Linux PCs. This can be advantageous for performance reasons, and is necessary to use the MATLAB, LabVIEW or Python APIs with the instrument. To install the LabOne software on a PC, administrator rights are required. In order to simply run the software later, a regular user account is sufficient. Instructions for downloading the correct version of the software packages from the Zurich Instruments website are described below in the platform-dependent sections. It is recommended to regularly update to the latest software version provided by Zurich Instruments. Thanks to the Automatic Update check feature, the update can be initiated with a single click from within the user interface, as shown in [Section 1.8](#).

Installing LabOne on Windows

This section describes how to additionally install the LabOne Software on Windows. This is only necessary if you wish to access the User Interface with a Web Server running on a PC instead of on the MFLI, itself, to use one of the LabOne APIs, or for multi-device synchronization. The installation packages for the Zurich Instruments LabOne software are available as Windows installer .msi packages. The software is available on the [Zurich Instruments Download Center](#). Please ensure that you have administrator rights for the PC on which the software is to be installed. See [LabOne compatibility](#) for a comprehensive list of supported Windows systems.

Windows LabOne Installation

1. The MFLI Instrument should not be connected to your computer during the LabOne software installation process.

2. Start the LabOne installer program with a name of the form **LabOne64-XX.XX.XXXXX.msi** by a double click and follow the instructions. Windows Administrator rights are required for installation. The installation proceeds as follows:
 - On the welcome screen click the **Next** button.




Figure 1.16. Installation welcome screen

- After reading through the Zurich Instruments license agreement, check the "I accept the terms in the License Agreement" check box and click the **Next** button.
- Review the features you want to have installed. For the MFLI Instrument the "MF Series Device, LabOne User Interface" and "LabOne APIs" features are required. Please install the features for other device classes as well, if required. To proceed click the **Next** button.




Figure 1.17. Custom setup screen

- Select whether the software should periodically check for updates. Note, the software will still not update automatically. This setting can later be changed in the user interface.

If you would like to install shortcuts on your desktop area, select "Create a shortcut for this program on the desktop". To proceed click the **Next** button.




Figure 1.18. Automatic update check

- Click the **Install** button to start the installation process.
- Windows may ask up to two times to reboot the computer if you are upgrading. Make sure you have no unsaved work on your computer.




Figure 1.19. Installation reboot request

- During the first installation of LabOne, it is required to confirm the installation of some drivers from the trusted publisher Zurich Instruments. Click on **Install**.




Figure 1.20. Installation driver acceptance

- Click OK on the following notification dialog.




Figure 1.21. Installation completion screen

- Click **Finish** to close the Zurich Instruments LabOne installer.
- You can now start the LabOne User Interface as described in Section 1.6 and choose an instrument to connect to via the Device Connection dialog shown in Device Connection dialog.

Warning

Do not install drivers from another source other than Zurich Instruments.

Installing LabOne on Linux

This section describes how to additionally install the LabOne Software on Linux. This is only necessary if you wish to run the Web Server on a PC rather than on the MFLI itself.

Requirements

Ensure that the following requirements are fulfilled before trying to install the LabOne software package:

- LabOne software supports typical modern GNU/Linux distributions (Ubuntu 14.04+, CentOS 7+, Debian 8+). The minimum requirements are glibc 2.17+ and kernel 3.10+.
- You have administrator rights for the system.
- The correct version of the LabOne installation package for your operating system and platform have been downloaded from the Zurich Instruments [Download Center](#):

```
LabOneLinux<arch>-<release>.<revision>.tar.gz,
```

Please ensure you download the correct architecture (x86-64 or arm64) of the LabOne installer. The **uname** command can be used in order to determine which architecture you are using, by running:

```
uname -m
```

in a command line terminal. If the command outputs **x86_64** the x86-64 version of the LabOne package is required, if it displays **aarch64** the ARM64 version is required.

Linux LabOne Installation

Proceed with the installation in a command line shell as follows:

1. Extract the LabOne tarball in a temporary directory:

```
tar xzvf LabOneLinux<arch>-<release>.<revision>.tar.gz
```

2. Navigate into the extracted directory.

```
cd LabOneLinux<arch>-<release>.<revision>
```

3. Run the install script with administrator rights and proceed through the guided installation, using the default installation path if possible:

```
sudo bash install.sh
```

The install script lets you choose between the following three modes:

- Type "a" to install the Data Server program, the Web Server program, documentation and APIs.
 - Type "u" to install **udev** support (only necessary if HF2 Instruments will be used with this LabOne installation and not relevant for other instrument classes).
 - Type "ENTER" to install both options "a" and "u".
4. Test your installation by running the software as described in the next section.

Running the Software on Linux

The following steps describe how to start the LabOne software in order to access and use your instrument in the User Interface.

1. Start the LabOne Data Server program at a command prompt:

```
$ ziDataServer
```

You should be able to access your instrument. In case of problems please consult the [Section 1.9](#) at the end of this chapter.

2. Start the Web Server program at a command prompt:

```
$ ziWebServer
```

3. Start an up-to-date web browser and enter the **127.0.0.1:8006** in the browser's address bar to access the Web Server program and start the LabOne User Interface. The LabOne Web Server installed on the PC listens by default on port number 8006 instead of 80 to minimize the probability of conflicts.

4. You can now start the LabOne User Interface as described in [Section 1.6](#) and choose an instrument to connect to via the Device Connection dialog shown in [Device Connection dialog](#).

Important

Do not use two Data Server instances running in parallel; only one instance may run at a time.

Uninstalling LabOne on Linux

The LabOne software package copies an uninstall script to the base installation path (the default installation directory is `/opt/zi/`). To uninstall the LabOne package please perform the following steps in a command line shell:

1. Navigate to the path where LabOne is installed, for example, if LabOne is installed in the default installation path:

```
$ cd /opt/zi/
```

2. Run the uninstall script with administrator rights and proceed through the guided steps:

```
$ sudo bash uninstall_LabOne<arch>-<release>-<revision>.sh
```

Start LabOne Manually on the Command Line

After installing the LabOne software, the Web and Data Server can be started manually using the command-line. The more common way to start LabOne under windows is described in [Section 1.6](#). The advantage of using the command line is being able to observe and change the behavior of the Web and Data Server. To start the Servers manually, open a command-line terminal (Command Prompt, PowerShell (Windows) or Bash (Linux)). For windows, the current working directory needs to be the installation directory of the Web and Data Server. They are installed in the Program Files Folder (usually: C:\Program Files) under \Zurich Instruments\LabOne in the WebServer or DataServer folder respectively. The Web and Data Servers (`ziDataServer`) are started by running the respective executable in each folder. Please be aware that only one instance of each Server may run at a time per computer. The behavior of the Server can be changed by providing command line arguments. For a detailed list of all arguments see the commandline help text:

```
$ ziWebServer --help
```

For the Data Server:

```
$ ziDataServer --help
```

1.5.2. LabOne Software Architecture

The Zurich Instruments LabOne software gives quick and easy access to the instrument. LabOne also supports advanced configurations with simultaneous access by multiple software clients (i.e., LabOne User Interface clients and/or API clients), and even simultaneous access by several users working on different computers. Here we give a brief overview of the architecture of the LabOne software. The information in this section is presented for the case when LabOne is run on a separate PC rather than on the embedded computer on the MFLI Instrument.

The software of Zurich Instruments equipment is server-based. The servers and other software components are organized in layers as shown in [Figure 1.22](#).

- The lowest layer running on the PC is the LabOne Data Server, which is the interface to the connected instrument.
- The middle layer contains the LabOne Web Server, which is the server for the browser-based LabOne User Interface.

- The graphical user interface, together with the programming user interfaces, are contained in the top layer.

The architecture with one central Data Server allows multiple clients to access a device with synchronized settings. The following sections explain the different layers and their functionality in more detail.




Figure 1.22. LabOne Software architecture

LabOne Data Server

The **LabOne Data Server** program is a dedicated server that is in charge of all communication to and from the device. The Data Server can control a single or also multiple instruments. It will distribute the measurement data from the instrument to all the clients that subscribe to it. It also ensures that settings changed by one client are communicated to other clients. The device settings are therefore synchronized on all clients. The Data Server is started automatically by a service when the PC is started. This service can be disabled if necessary, though the Data Server consumes only little resources when there is no active session. On a PC, only a single instance of a LabOne Data Server should be running.

LabOne Web Server

The LabOne Web Server is an application dedicated to serving up the web pages that constitute the LabOne user interface. The user interface can be opened with any device with a web browser. Since it is touch enabled, it is possible to work with the LabOne User Interface on a mobile device - like a tablet. The LabOne Web Server supports multiple clients simultaneously. This means that more than one session can be used to view data and to manipulate the instrument. A session could be running in a browser on the PC on which the LabOne software is installed. It could equally well be running in a browser on a remote machine.

With a LabOne Web Server running and accessing an instrument, a new session can be opened by typing in a network address and port number in a browser address bar. In case LabOne is run on the embedded computer of the Instrument, please refer to [Section 1.4](#) to learn what address to

use to access the Web Server. In case the Web Server runs on the **same** computer as the browser, the address is the localhost address (both are equivalent):

- **127.0.0.1:8006** (only valid when LabOne is running on a separate PC)
- **localhost:8006** (only valid when LabOne is running on a separate PC)

In case the Web Server runs on a **remote** computer, the address is the IP address or network name of the remote computer:

- **192.168.x.y:8006**
- **myPC.company.com:8006**

Note that the latter is technically equivalent to the case when the Web Server runs on the embedded computer on the Instrument. In that case the IP address of the Instrument is used. The most recent versions of the most popular browsers are supported: Chrome, Firefox, Edge, Safari and Opera.

LabOne API Layer

The instrument can also be controlled via the application program interfaces (APIs) provided by Zurich Instruments. APIs are provided in the form of DLLs for the following programming environments:


- MATLAB
- Python
- LabVIEW
- .NET
- C

The instrument can therefore be controlled by an external program, and the resulting data can be processed there. The device can be concurrently accessed via one or more of the APIs and via the user interface. This enables easy integration into larger laboratory setups. See the LabOne Programming Manual for further information. Using the APIs, the user has access to the same functionality that is available in the LabOne User Interface.

1.6. LabOne Software Start-up


This section describes the start-up of the LabOne User Interface, which is used to control the MFLI Instrument. The start-up is slightly different depending on whether the LabOne software is installed on the PC (see [Section 1.5](#)), or if the software on the Instrument is used. It's not required to install LabOne on the PC to operate the Instrument. In case you use the software on the instrument, the first steps to connect to the instrument and open a browser window with the LabOne start-up screen are explained in [Section 1.4](#).

In case you have installed LabOne on the PC, the LabOne User Interface start-up link can be found under the Windows 10 Start Menu (Under Windows 7 and 8, the LabOne User Interface start-up link can be found in **Start Menu → all programs / all apps → Zurich Instruments LabOne**). As shown in [Figure 1.23](#), click on **Start Menu → Zurich Instruments LabOne**. This will open the User Interface in a new tab in your default web browser and start the LabOne Data Server and LabOne Web Server programs in the background.



[Figure 1.23.](#) Link to the LabOne User Interface in the Windows 10 Start Menu (only when LabOne has been installed on the PC)

After starting LabOne, the Device Connection dialog [Figure 1.24](#) is shown to select the device for the session. The term "session" is used for an active connection between the user interface and the device. Such a session is defined by device settings and user interface settings. Several sessions can be started in parallel. The sessions run on a shared LabOne Web Server.



[Figure 1.24.](#) Device Connection dialog

The Device Connection dialog opens in the Basic view by default. In this view, all devices that are available for connection are represented by an icon with serial number and status information. If required, a button appears on the icon to perform a firmware upgrade. Otherwise, the device can be connected by a double click on the icon, or a click on the **Open** button at the bottom right of the dialog.

In some cases it's useful to switch to the Advanced view of the Device Connection dialog by clicking on the "Advanced" button. The Advanced view offers the possibility to select custom device and UI settings for the new session and gives further connectivity options that are particularly useful for multi-instrument setups.




Figure 1.25. Device Connection dialog (Advanced view)

The Advanced view consists of three parts:

- Data Server Connectivity
- Available Devices
- Saved Settings

The Available Devices table has a display filter, usually set to **Default Data Server**, that is accessible by a drop-down menu in the header row of the table. When changing this to **Local Data Servers**, the Available Devices table will show only connections via the Data Server on the host PC and will contain all instruments directly connected to the host PC via USB or to the local network via 1GbE. When using the **All Data Servers** filter, connections via Data Servers running on

other PCs in the network also become accessible. Once your instrument appears in the Available Devices table, perform the following steps to start a new session:

1. Select an instrument in the **Available Devices** table.
2. Select a setting file in the **Saved Settings** list unless you would like to use the Default Settings.
3. Start the session by clicking on **Open**

Note

By default, opening a new session will only load the UI settings (such as plot ranges), but not the device settings (such as signal amplitude) from the saved settings file. In order to include the device settings, enable the **Include Device Settings** checkbox. Note that this can affect existing sessions since the device settings are shared between them.

Note

In case devices from other Zurich Instruments series (UHF, HF2, MF, HDAWG, PQSC, or SHF) are used in parallel, the list in **Available Devices** section can contain those as well.

The following sections describe the functionality of the **Device Connection** dialog in detail.

1.6.1. Data Server Connectivity

The Device Connection dialog represents a Web Server. However, on start-up the Web Server is not yet connected to a LabOne Data Server. With the **Connect/Disconnect** button the connection to a Data Server can be opened and closed.

This functionality can usually be ignored when working with a single MFLI Instrument and a single host computer. Data Server Connectivity is important for users operating their instruments from a remote PC, i.e., from a PC different to the PC on which the Data Server is running or for users working with multiple instruments. The Data Server Connectivity function then gives the freedom to connect the Web Server to one of several accessible Data Servers. This includes Data Servers running on remote computers, and also Data Servers running on an MF Series instrument.

With the display filter set to "Local Data Server", all instruments accessible by a Data Server on the same computer and on an MFLI instrument connected to the PC are visible. With the filter set to "All Data Servers", all accessible Data Servers in the network are shown, including those running on other PCs.

Note

When using the filter "All Data Servers", take great care to connect to the right instrument, especially in larger local networks. Always identify your instrument based on its serial number in the form DEV0000, which can be found on the instrument back panel.

1.6.2. Available Devices

The Available Devices table gives an overview of the visible devices. A device is ready for use if either marked free or connected. The first column of the list holds the **Enable** button controlling the connection between the device and a Data Server. This button is greyed out until a Data Server

is connected to the LabOne Web Server using the **Connect** button. If a device is connected to a Data Server, no other Data Server running on another PC can access this device.

The second column indicates the serial number and the third column shows the instrument type. The fourth column shows the host name of the LabOne Data Server controlling the device. The next column shows the interface type. For MF Instruments the interfaces USB or 1GbE are available and are listed if physically connected. For MF series instruments the interface is indicated as PCIe in case the Data Server is running on the instrument, even if the physical connection between PC and instrument is USB or 1GbE. PCIe corresponds to the interface between the embedded PC and the measurement unit inside the MF instrument. The LabOne Data Server will scan for the available devices and interfaces every second. If a device has just been switched on or physically connected it may take up to 20 s before it becomes visible to the LabOne Data Server.

Table 1.5. Device Status Information

| | |
|--------------------------------------|---|
| Connected | The device is connected to a LabOne Data Server, either on the same PC (indicated as local) or on a remote PC (indicated by its IP address). The user can start a session to work with that device. |
| Free | The device is not in use by any LabOne Data Server and can be connected by clicking the Open button. |
| In Use | The device is in use by a LabOne Data Server. As a consequence the device cannot be accessed by the specified interface. To access the device, a disconnect is needed. Only applies to UHF Instruments. |
| Device FW upgrade required/available | The firmware of the device is out of date. Please first upgrade the firmware as described in Section 1.8 . |
| Device not yet ready | The device is visible and starting up. |

1.6.3. Saved Settings

Settings files can contain both UI and device settings. UI settings control the structure of the LabOne User Interface, e.g. the position and ordering of opened tabs. Device settings specify the set-up of a device. The device settings persist on the device until the next power cycle or until overwritten by loading another settings file.

The columns are described in [Table 1.6](#). The table rows can be sorted by clicking on the column header that should be sorted. The default sorting is by time. Therefore, the most recent settings are found on top. Sorting by the favorite marker or setting file name may be useful as well.

Table 1.6. Column Descriptions

| | |
|---|--|
|  | Allows favorite settings files to be grouped together. By activating the stars adjacent to a settings file and clicking on the column heading, the chosen files will be grouped together at the top or bottom of the list accordingly. The favorite marker is saved to the settings file. When the LabOne user interface is started next time, the row will be marked as favorite again. |
| Name | The name of the settings file. In the file system, the file name has the extension .xml. |
| Date | The date and time the settings file was last written. |
| Comment | Allows a comment to be stored in the settings file. By clicking on the comment field a text can be typed in which is subsequently stored in the settings file. This comment is useful to describe the specific conditions of a measurement. |

| | |
|-------------|--|
| Device Type | The instrument type with which this settings file was saved. |
|-------------|--|

Special Settings Files

Certain file names have the prefix "last_session_". Such files are created automatically by the LabOne Web Server when a session is terminated either explicitly by the user, or under critical error conditions, and save the current UI and device settings. The prefix is prepended to the name of the most recently used settings file. This allows any unsaved changes to be recovered upon starting a new session.

If a user loads such a last session settings file the "last_session_" prefix will be cut away from the file name. Otherwise, there is a risk that an auto-save will overwrite a setting which was saved explicitly by the user.

The settings file with the name "Default Settings" contains the default UI settings. See button description in [Table 1.7](#).

Table 1.7. Button Descriptions

| | |
|--------------------------------|---|
| Open | The settings contained in the selected settings file will be loaded. The button "Include Device Settings" controls whether only UI settings are loaded, or if device settings are included. |
| Include Device Settings | Controls which part of the selected settings file is loaded upon clicking on Open. If enabled, both the device and the UI settings are loaded. |
| Auto Start | Skips the session dialog at start-up if selected device is available. The default UI settings will be loaded with unchanged device settings. |

Note

The user setting files are saved to an application-specific folder in the directory structure. The best way to manage these files is using the File Manager tab.

Note

The factory default UI settings can be customized by saving a file with the name "default_ui" in the Config tab once the LabOne session has been started and the desired UI setup has been established. To use factory defaults again, the "default_ui" file must be removed from the user setting directory using the File Manager tab.

Note

Double clicking on a device row in the Available Devices table is a quick way of starting the default LabOne UI. This action is equivalent to selecting the desired device and clicking the **Open** button.

Double clicking on a row in the Saved Settings table is a quick way of loading the LabOne UI with those UI settings and, depending on the "Include Device Settings" checkbox, device settings. This action is equivalent to selecting the desired settings file and clicking the **Open** button.

1.6.4. Tray Icon

When LabOne is started, a tray icon appears by default in the bottom right corner of the screen, as shown in the figure below. By right-clicking on the icon, a new web server session can be opened

quickly, or the LabOne Web and Data Servers can be stopped by clicking on Exit. Double-clicking the icon also opens a new web server session, which is useful when setting up a connection to multiple instruments, for example.




Figure 1.26. LabOne Tray Icon in Windows 10

1.6.5. Messages

The LabOne Web Server will show additional messages in case of a missing component or a failure condition. These messages display information about the failure condition. The following paragraphs list these messages and give more information on the user actions needed to resolve the problem.

Lost Connection to the LabOne Web Server

In this case the browser is no longer able to connect to the LabOne Web Server. This can happen if the Web Server and Data Server run on different PCs and a network connection is interrupted. As long as the Web Server is running and the session did not yet time out, it is possible to just attach to the existing session and continue. Thus, within about 15 seconds it is possible with **Retry** to recover the old session connection. The **Reload** button opens the Device Connection dialog shown in [Figure 1.24](#). The figure below shows an example of the Connection Lost dialog.




Figure 1.27. Dialog: Connection Lost

Reloading...

If a session error cannot be handled, the LabOne Web Server will restart to show a new Device Connection dialog as shown in [Figure 1.24](#). During the restart a window is displayed indicating that the LabOne User Interface will reload. If reloading does not happen the same effect can be triggered by pressing F5 on the keyboard. The figure below shows an example of this dialog.




Figure 1.28. Dialog: Reloading

1.7. Using the LabOne Programming Interfaces

LabOne provides Application Programming Interfaces (APIs) for MATLAB, LabVIEW, Python, C, and .NET. These APIs require installation on the PC where they will be used as described in the following. The necessary installers are available on the Zurich Instruments download page, www.zhinst.com/downloads.




Figure 1.29. LabOne APIs installed on separate PC

The LabOne APIs communicate directly with the Data Server running on the MFLI Instrument via IP port 8004.

The device address can be `<instrument-serial>`, `mf-<instrument-serial>`, `mf-<instrument-serial>.<domain>`, or `<IP address>`. If the address is not fully qualified, means domain name is not added, the API will perform a network discovery with multicast to get the IP address. This ensures that devices connected by USB will be accessible by the same method as devices connected via 1GbE.

1.7.1. Using the MATLAB, LabVIEW APIs

There are two possibilities to install the MATLAB and LabVIEW APIs on a PC. The first option is to install the main LabOne package which includes these APIs. This is a good option if you would also like to run the Data Server on this PC as described in [Section 1.5](#). Installation of the main LabOne package is described in [software installation](#). The second option is to install only the required API package. Please refer to the LabOne Programming Manual for details on installing and using the MATLAB and LabVIEW APIs.

1.7.2. Using the Python API

To use the Python API, the separate Zurich Instruments LabOne Python package needs to be installed. Please refer to the LabOne Programming Manual for details on installing and getting started with the LabOne Python API.

1.7.3. Using the .NET and C APIs

To use the .NET and C APIs, the main LabOne package needs to be installed which includes these APIs along with those for MATLAB and LabVIEW. Installation of the main LabOne package is described in [software installation](#).

1.8. Software Update

1.8.1. Overview

It is recommended to regularly update the LabOne software on the MFLI Instrument to the latest version. In case the Instrument has access to the internet, this is a very simple task and can be done with a single click in the software itself, as shown in [Section 1.8.2](#). If there's no internet access or if the Automatic Update Check feature is disabled, the software can alternatively be updated by a drag-and-drop procedure, or by using a USB mass storage device (e.g. a memory stick). These methods are explained in [Section 1.8.3](#) and [Section 1.8.4](#).

If you use one of the LabOne APIs with a separate installer, don't forget to update this part of the software, too. In case LabOne is run on the PC (see [Section 1.5](#)), updating the software is done in two steps. First, LabOne is updated on the PC by downloading and installing the LabOne software from the Zurich Instruments downloads page as shown in [software installation](#). Second, the instrument firmware needs to be updated from the Device Connection dialog after starting up LabOne. This is shown in [Section 1.8.5](#).

Finally, if you use one of the LabOne APIs with a separate installer, don't forget to update this part of the software, too, as explained in [Section 1.7](#)

1.8.2. Updating LabOne using Automatic Update Check

Updating the software is done in two steps. First, LabOne is updated on the PC by downloading and installing the LabOne software from the Zurich Instruments downloads page . Second, the instrument firmware needs to be updated from the Device Connection dialog after starting up LabOne. This is shown in [Section 1.8.5](#). In case "Periodically check for updates" has been enabled during the LabOne installation and LabOne has access to the internet, a notification will appear on the Device Connection dialog whenever a new version of the software is available for download. This setting can later be changed in the Config tab of the LabOne user interface. In case automatic update check is disabled, the user can manually check for updates at any time by clicking on the button [Check For Update](#) in the Device Connection dialog. In case an update is found, clicking on the button "Update Available" shown in [Figure 1.30](#) will start a download and installation of the latest LabOne software on the MFLI instrument. In case the LabOne software runs on a separate PC (see [Section 1.5](#)), clicking on "Update Available" allows you to download the latest LabOne installer for Windows or Linux, see [Figure 1.31](#). After download, proceed as explained in [software installation](#) to update LabOne. Following this update, the instrument firmware also needs to be updated as described in [Section 1.8.5](#).



Figure 1.30. Device Connection dialog: LabOne update available



Figure 1.31. Download LabOne MSI using Automatic Update Check feature

1.8.3. LabOne Update by Drag-and-Drop

Note

Updating the LabOne software on the Instrument requires that the browser is connected to the Web Server running on the MFLI Instrument.

- Download the latest LabOne software version from the [Zurich Instruments Download Center](#). Choose the version for the MFLI Instrument. The file has the form **LabOneXX-00.00.00000.tar**.
- Open a Windows Explorer window and navigate to the location of the downloaded LabOne installation file (on Windows this is typically the Downloads folder). On Linux, the Files application or some other file manager utility supporting drag and drop can be used. We will use the term explorer window henceforth in this description.
- Start the LabOne User Interface in a web browser (connect to the Web Server running on the Instrument by typing the serial number in the address bar).
- Open the LabOne Config tab.
- Position/Re-size the explorer window and the web browser such that the dotted rectangle under the File Upload section of the Config tab is visible.




Figure 1.32. Config Tab showing drop zone for software update

- Drag and drop the downloaded LabOne installation file from the explorer window onto the dotted rectangle. An Upload pop-up window will appear indicating the progress of the upload.




Figure 1.33. Upload pop-up window

Once uploaded, The LabOne Software Update pop-up window will appear.



Figure 1.34. LabOne Software Update pop-up window

- Click **OK** in the LabOne Software Update pop-up window. This completes the software update.

The servers running on the instrument will now be restarted necessitating a reload of the LabOne User Interface. An Error pop-up window will appear containing the text "The connection with the LabOne Web Server is lost". * Reload the LabOne User Interface by clicking on the **Reload** button.

1.8.4. LabOne Update from a USB Stick

Note

Updating the LabOne software on the Instrument requires that the browser is connected to the Web Server running on the MFLI Instrument.

- Download the latest LabOne software version from the [Zurich Instruments Download Center](#) and copy it onto a USB mass storage device. Choose the version for the MFLI Instrument. The file has the form **LabOneMF-00.00.00000.tar**.
- Start the LabOne User Interface in a web browser (connect to the Web Server running on the Instrument by typing the serial number in the address bar).
- Insert the USB mass storage device into one of the USB sockets on the back of the MFLI Instrument.
- Open the LabOne File Manager tab.

- A folder labelled USB1 will be displayed in the File Manager tab, corresponding to the inserted USB device. Expand the USB1 branch to display its contents (double click on the folder icon).
- Right click the LabOne update .tar file and select **SW Update** to update the software.




Figure 1.35. File Manager tab

An Upload pop-up window will appear indicating the progress of the upload. Once uploaded, The LabOne Software Update pop-up window will appear.



Figure 1.36. LabOne Software Update pop-up window

- Click **OK** in the LabOne Software Update pop-up window. This completes the software update. The servers running on the instrument will now be restarted necessitating a reload of the LabOne User Interface. An Error pop-up window will appear containing the text "The connection with the LabOne Web Server is lost".
- Reload the LabOne User Interface by clicking on the **Reload** button.

1.8.5. Updating the Instrument Firmware

Even when running the LabOne software on a separate PC, a part of the software runs on the instrument. In order to distinguish between the two, the latter will be called firmware for the rest of this document. When upgrading to a new software release, it's also necessary to update the instrument firmware.

If the firmware needs an update, this is indicated in the Device Connection dialog of the LabOne user interface under Windows. In the Basic view of the dialog, there will be a button "Upgrade FW" appearing together with the instrument icon as shown in [Figure 1.37](#). In the Advanced view, there will be a link "Upgrade FW" in the Update column of the Available Devices table. Click on Upgrade

FW, respectively, to open the firmware update start-up dialog shown in Figure 1.38. The firmware upgrade takes approximately 2 minutes.




Figure 1.37. Device Connection dialog with available firmware update




Figure 1.38. Device Firmware Update start-up dialog

Important

Do not disconnect the USB or 1GbE cable to the Instrument or power-cycle the Instrument during a firmware update.

If you encounter any issues while upgrading the instrument firmware, please contact Zurich Instruments at support@zhinst.com.

1.9. Troubleshooting

This section aims to help the user solve and avoid problems while using the software and operating the instrument.

1.9.1. Common Problems

Your MFLI Instrument is an advanced piece of laboratory equipment which has many more features and capabilities than a traditional lock-in amplifier. In order to benefit from these, the user needs access to a large number of settings in the LabOne User Interface. The complexity of the settings might overwhelm a first-time user, and even expert users can get surprised by certain combinations of settings. To avoid problems, it's good to use the possibility to save and load settings in the Config Tab. This allows one to keep an overview by operating the instrument based on known configurations. This section provides an easy-to-follow checklist to solve the most common mishaps.

Table 1.8. Common Problems

| Problem | Check item |
|---|---|
| The software cannot be installed or uninstalled | Please verify you have administrator/root rights. |
| The software cannot be updated | Please use the Modify option in Windows Apps & Features functionality. In the software installer select Repair, then uninstall the old software version, and install the new version. |
| The Instrument does not turn on | Please verify the power supply connection and inspect the fuse. The fuse holder is integrated in the power connector on the back panel of the instrument. |
| The Instrument performs poorly in single-ended operation | the signal inputs of the instrument might be set to differential operation. Please ensure that differential input mode is turned off in the Lock-in Tab or In / Out Tab. |
| The Instrument has a high input noise floor (when connected to host computer by USB) | the USB cable connects the Instrument ground to computer ground, which might inject some unwanted noise to the measurements results. In this case it is recommended to use the Ethernet connection which is galvanically isolated using a UTP Cat 5 or 6 cable (UTP stands for "unshielded twisted pair"). |
| The Instrument performs poorly at low frequencies (below 100 Hz) : | the signal inputs of the instrument might be set to AC operation. Please verify to turn off the AC switch in the Lock-in Tab or In / Out Tab. |
| The Instrument performs poorly during operation | the demodulator filters might be set too wide (too much noise) or too narrow (slow response) for your application. Please verify if the demodulator filter settings match your frequency versus noise plan. |
| The Instrument performs poorly during operation | clipping of the input signal may be occurring. This is detectable by monitoring the red LEDs on the front panel of the instrument or the Input Overflow (OVI) flags on the STATUS_TAB of the user interface. It can be avoided by adding enough margin on the input range setting (for instance 50% to 70% of the maximum signal peak). |
| The Instrument performs strangely when working with | it is easily possible to turn on more signal generators than intended. Check the generated Signal Output with |

| Problem | Check item |
|---|---|
| the MF-MD Multi-demodulator Option | the integrated oscilloscope and check the number of simultaneously activated oscillator voltages. |
| The Instrument measurements are unpredictable | Please check the Status Tab to see if there is any active warning (red flag), or if one has occurred in the past (yellow flag). |
| The Instrument does not generate any output signal | verify that signal output switch has been activated in the Lock-in Tab or in the In / Out Tab. |
| The Instrument locks poorly using the digital I/O as reference | make sure that the digital input signal has a high slew rate and clean level crossings. |
| The Instrument locks poorly using the auxiliary analog inputs as reference | the input signal amplitude might be too small. Use proper gain setting of the input channel. |
| The sample stream from the Instrument to the host computer is not continuous | Check the communication (COM) flags in the status bar. The three flags indicate occasional sample loss, packet loss, or stall. Sample loss occurs when a sampling rate is set too high (the instrument sends more samples than the interface and the host computer can absorb). The packet loss indicates an important failure of the communications to the host computer and compromises the behavior of the instrument. Both problems are prevented by reducing the sample rate settings. The stall flag indicates that a setting was actively changed by the system to prevent UI crash. |
| The LabOne User Interface does not start (when running the LabOne on a PC) | Verify that the LabOne Data Server (<code>ziDataServer.exe</code>) and the LabOne Web Server (<code>ziWebServer.exe</code>) are running via the Windows Task Manager. The Data Server should be started automatically by <code>ziService.exe</code> and the Web Server should be started upon clicking "Zurich Instruments LabOne" in the Windows Start Menu. If both are running, but clicking the Start Menu does not open a new User Interface session in a new tab of your default browser then try to create a new session manually by entering 127.0.0.1:8006 in the address bar of your browser. |
| The user interface does not start or starts but remains idle | Verify that the Data Server has been started and is running on your host computer. |
| The user interface is slow and the web browser process consumes a lot of CPU power | Make sure that the hardware acceleration is enabled for the web browser that is used for LabOne. For the Windows operating system, the hardware acceleration can be enabled in Control Panel → Display → Screen Resolution . Go to Advanced Settings and then Trouble Shoot. In case you use a NVIDIA graphics card, you have to use the NVIDIA control panel. Go to Manage 3D Settings, then Program Settings and select the program that you want to customize. |

1.9.2. Location of the Log Files

The most recent log files of the LabOne Web and Data Server programs are most easily accessed by clicking on **Logs** in the **LabOne Device Connection dialog** of the user interface. The Device

Connection dialog opens on software start-up or upon clicking on **Session Manager** in the Config tab of the user interface.

In the case that the Web and/or Data Server are running on the MFLI device (and not on the PC) the log files are physically stored on the MFLI instrument and can be accessed through the [Section 4.17](#) of the LabOne User Interface in the **Log** folder. If the Web and/or Data Server are ran on a PC and not on the embedded computer of the MFLI (see [Section 1.5](#)) the log file locations on disk are given in the sections below.

Windows

If the Web and/or Data Server are running on a Windows PC, their log files can be found in the following directories.

- LabOne Data Server (**ziDataServer.exe**):

`C:\Windows\ServiceProfiles\LocalService\AppData\Local\Temp\Zurich Instruments\LabOne\ziDataServerLog`

- LabOne Web Server (**ziWebServer.exe**):

`C:\Users\[USER]\AppData\Local\Temp\Zurich Instruments\LabOne\ziWebServerLog`

Note

The `C:\Users\[USER]\AppData` folder is hidden by default under Windows. A quick way of accessing it is to enter `%AppData%\..` in the address bar of the Windows File Explorer.




Figure 1.39. Using the `%AppData%\..` shortcut in Windows Explorer to access the hidden folder.

Linux and macOS

If the Web and/or Data Server are running on Linux or macOS, their log files can be found in the following directories.

- LabOne Data Server (**ziDataServer**):

`/tmp/ziDataServerLog_[USER]`

- LabOne Web Server (**ziWebServer**):

`/tmp/ziWebServerLog_[USER]`

Chapter 2. Functional Overview

This chapter provides the overview of the features of the MFLI Instrument. The first section contains the graphical overview as well as the hardware and software feature list. The next sections detail the front panel and the back panel of the measurement instrument. The last section provides product selection and ordering support.

2.1. Features




Figure 2.1. MFLI Instrument Overview

Every MF Instrument (MFLI, MFIA) described on [Figure 2.1](#) consists of several internal units (light blue color) surrounded by several interface units (dark blue color) and the front panel on the left-hand side and the back panel on the right-hand side. The orange blocks are optional units that can be either ordered at the beginning or upgraded later in the field. The arrows between the panels and the interface units indicate the physical connections and the data direction flow. Only a small subset of internal connections is depicted.

The signal of interest is connected to the low-noise current or to the voltage input of the MF Instrument, where it is amplified to a defined range and digitized at very high speed. When the MF-MD option is installed, both inputs can be used simultaneously, enabling 4-terminal measurements for example. The resulting samples are fed into the digital signal processor consisting of up to 4 dual-phase demodulators. The demodulator output samples are further processed on the embedded processor that provides the LabOne web server, to which the user can connect from any device running a browser (PC, tablet or smart phone). No software installation is required. Both Ethernet and USB are supported. The demodulator samples are also available as analog signal on the auxiliary outputs on the front panel of the MF Instrument.

The numerical oscillators generate sine and cosine signal pairs that are used for the demodulation of the input samples and also for the generation of the MF output signals. When the MF-MD option is installed, the Output Adder can generate a linear combination of the oscillator outputs to generate a multi-frequency output signal: digital to analog conversion and signal scaling (range) are supported.

Hardware trigger and reference signals are used for various purposes inside the instrument, such as triggering demodulation, triggering oscilloscope data acquisition, or to generate external reference clocks or triggering signals to other equipment.

Lock-in Operating Modes

- Internal reference mode
- External reference mode
- Auto reference mode
- Impedance mode, measuring current input and voltage input simultaneously (optional)
- Multi-harmonic mode (optional, simultaneous measurement up to four harmonic frequencies)
- Arbitrary frequency mode (optional, simultaneous measurement at 4 arbitrary frequencies)

Medium Frequency Voltage Input

- 1 low-noise MF voltage input, single-ended or differential, 5 MHz bandwidth
- Variable input range
- Switchable input impedance
- Selectable AC/DC coupling
- Selectable instrument ground or floating

Medium Frequency Current Input

- 1 low-noise MF current input, single-ended, 5 MHz bandwidth
- Variable input range

Medium Frequency Signal Output

- Low-distortion MF outputs, single-ended, differential, 5 MHz bandwidth
- Variable output range
- Digital and analog offset

Demodulators & Reference

- Up to 4 dual-phase demodulators
- Up to 4 programmable numerical oscillators
- Up to 2 external reference signals
- Individually programmable demodulator filters
- 128-bit internal processing
- 64-bit resolution demodulator sample
- 48-bit internal reference resolution

Auxiliary Input, Outputs and Triggers

- 4 auxiliary outputs, user defined signals
- 2 auxiliary inputs, general purpose
- 2 input and 2 output trigger signals

High-speed Connectivity

- USB 2.0 Device high-speed 480 Mbit/s interface
- Dual USB 2.0 Host high-speed interface
- LAN 1 Gbit/s controller interface

- DIO: 32-bit digital input-output port
- Clock input connector (10 MHz)
- Clock output connector (10 MHz)

LabOne Toolset

- Sweeper
- Scope
- Numeric
- Spectrum
- Plotter
- Data Acquisition

Software Connectivity

- Data server with multi-client support
- API for C, LabVIEW, MATLAB, Python based instrument programming

2.2. Front Panel Tour

The front panel BNC connectors and control LEDs are arranged as shown in Figure 2.2 and listed in Table 2.1.

Note

Figure 2.2 shows the front panel of MF Instruments with **serial numbers MF-DEV3200 and higher** (see Section 1.2). On Instruments with smaller serial numbers, the +V and -V Diff connectors (C* and D*) are swapped and the spacing of several connectors is different.




Figure 2.2. MF Instrument front panel

Table 2.1. MF Instrument front panel description

| Position | Label / Name | Description |
|------------------------|---------------------------|---|
| A | Signal Input I | single-ended current input |
| B | Current Input Signal Over | this red LED indicates that the current input signal saturates the A/D converter and therefore the current input range must be increased or the signal must be attenuated |
| C* (serial above 3200) | Signal Input -V Diff | voltage input single-ended mode: internally shorted to ground differential mode: negative voltage input |
| D* (serial above 3200) | Signal Input +V | voltage input in single-ended mode: single-ended voltage input differential mode: positive voltage input |
| C* (serial below 3200) | Signal Input +V | voltage input single-ended mode: single-ended voltage input differential mode: positive voltage input |

| Position | Label / Name | Description |
|------------------------------|------------------------------|--|
| D* (serial below 3200) | Signal Input -V Diff | voltage input |
| | | single-ended mode: internally shorted to ground |
| | | differential mode: negative voltage input |
| E | Voltage Input Signal Over | this red LED indicates that the voltage input signal saturates the A/D converter and therefore the voltage input range must be increased or the signal must be attenuated |
| F | Signal Output +V | voltage output |
| | | single-ended mode: single-ended voltage output |
| | | differential mode: positive voltage output |
| G | Signal Output -V Diff | voltage output |
| | | single-ended mode: internally shorted to ground |
| | | differential mode: negative voltage output |
| H | Signal Output ON | this blue LED indicates that the signal output is actively driven by the instrument |
| I | Aux Input 2 Ref | auxiliary input 2, can be used as external reference input supporting the full bandwidth of the device |
| J | Aux Output 2 | auxiliary output 2, this connector provides a user defined signal, often used to output demodulated samples (X,Y) or (R,THETA) |
| K | Aux Output 4 | auxiliary output 4, this connector provides a user defined signal, often used to output demodulated samples (X,Y) or (R,THETA) |
| L | Power | this LED indicates that the instrument is powered |
| | | color blue: the device has an active connection to the LabOne data server and is ready for operation |
| | | color green blinking: the firmware is ready, waiting for LabOne data server connection. This process takes around 20 seconds. |
| | | color red: the device is not initialized respectively is performing the internal auto calibration process. |
| | | color purple blinking: a firmware update is in progress |
| | | color purple: the boot process failed |
| M | Aux Input 1 Ref | auxiliary input 1, can be used as external reference input supporting the full bandwidth of the instrument; the value of auxiliary input 1 can be added as offset to the signal output |
| N | Aux Output 1 | auxiliary output 1, this connector provides a user-defined signal, often used to output demodulated samples (X,Y) or (R,θ) |
| O | Aux Output 3 | auxiliary output 3, this connector provides a user-defined signal, often used to output demodulated samples (X,Y) or (R,θ) |

Please refer to the troubleshooting section for further information regarding the meaning of the Power LED colors.

2.3. Back Panel Tour

The back panel is the main interface for power, control, service and connectivity to other ZI instruments. Please refer to [Figure 2.3](#) and [Table 2.2](#) for the detailed description of the items.




Figure 2.3. MF Instrument back panel

Table 2.2. MF Instrument back panel description

| Position | Label / Name | Description |
|----------|----------------|---|
| A | DC In | DC external 12 V power supply |
| B | DIO | 32-bit digital input/output connector |
| C | USB 2.0 Host | universal serial bus host connector |
| D | USB 2.0 Device | universal serial bus device connector to computer |
| E | LAN 1GbE | 1 Gbit Ethernet LAN connector |
| F | Trigger In 2 | digital TTL trigger input 2 |
| G | Trigger Out 2 | digital TTL trigger output 2 |
| H | Clk 10 MHz In | clock input (10 MHz) to be used for synchronization from external instruments |
| I | Clk 10 MHz Out | clock output (10 MHz) to be used for synchronization of external instruments |
| J | Earth ground | 4 mm banana jack connector for earth ground, electrically connected to the chassis and the earth pin of the power inlet |
| K | USB 2.0 Host | universal serial bus host connector |
| L | Power inlet | power inlet with ON/OFF switch |
| M | Trigger In 1 | digital TTL trigger input 1 |
| N | Trigger Out 1 | digital TTL trigger output 1 |
| O | Cooling outlet | ventilator (important: keep clear from obstruction) |

2.4. Ordering Guide

[Table 2.3](#) provides an overview of the available MF products. Upgrade options can be purchased at any time without need to send the Instrument to Zurich Instruments.

Table 2.3. MF Instrument product codes for ordering

| Product code | Product name | Description | Upgrade in the field possible |
|--------------|--------------------------------|--|-------------------------------|
| MFLI 500 kHz | MFLI 500 kHz Lock-in Amplifier | base product | - |
| MFLI 5 MHz | MFLI 5 MHz Lock-in Amplifier | bundle | - |
| MF-MD | MF-MD Multi-demodulator | option | yes |
| MF-F5M | MF-F5M Frequency Extension | option | yes |
| MF-DIG | MF-DIG Digitizer | option | yes |
| MF-IA | MF-IA Impedance Analyzer | option (includes MFITF) | yes |
| MFITF | Impedance Test Fixture | accessory (included with the MFIA and MF-IA) | - |

The MF product line consists of the MFLI Lock-in Amplifier series and the MFIA Impedance Analyzer series. The combination MFLI 5 MHz + MF-IA is equivalent to the MFIA 5 MHz product, and the combination MFLI 500 kHz + MF-IA is equivalent to the MFIA 500 kHz product. The following table gives an overview of the features for the most important product configurations.

Table 2.4. Product selector

| Feature | MFLI | MFLI +MF-MD | MFLI +MF-F5M | MFLI +MF-MD +MF-F5M |
|---|------|-------------|--------------|---------------------|
| Internal reference mode | yes | yes | yes | yes |
| External reference mode | yes | yes | yes | yes |
| Auto reference mode | yes | yes | yes | yes |
| Impedance mode (independent measurement of voltage and current signal inputs) | - | yes | - | yes |
| Signal generators | 1 | 1 | 1 | 1 |
| Superposed output sinusoids per generator | 1 | up to 4 | 1 | up to 4 |
| Quad-harmonic mode | - | yes | - | yes |
| Multi-frequency mode | - | yes | - | yes |
| Arbitrary frequency mode | - | yes | - | yes |
| Number of demodulators | 1 | 4 | 1 | 4 |
| Simultaneous frequencies | 1 | 4 | 1 | 4 |
| Simultaneous harmonics | 1 | 4 | 1 | 4 |

2.4. Ordering Guide

| Feature | MFLI | MFLI +MF-MD | MFLI +MF-F5M | MFLI +MF-MD +MF-F5M |
|---------------------|---------|-------------|--------------|---------------------|
| External references | 1 | 2 | 1 | 2 |
| Dynamic reserve | 120 dB | 120 dB | 120 dB | 120 dB |
| Frequency range | 500 kHz | 500 kHz | 5 MHz | 5 MHz |
| USB 2.0 480 Mbit/s | yes | yes | yes | yes |
| Ethernet 1GbE | yes | yes | yes | yes |

2.5. Rack Mount


Parts for mounting the MFLI in a 19" rack are available from Zurich Instruments upon request under support@zhinst.com. Rack mount of a single MFLI as well as two MFLI instruments side-by-side is possible and explained in the following instructions.

2.5.1. Instructions for a Single Instrument


Table 2.5. Parts for rack mount of single instrument

| Description | Quantity | Unit |
|--|----------|------|
| 19" Corner bracket Magic 2U RAL 9003 | 1 | PCE |
| 19" Adapter Plate 2U RAL 9003 | 1 | PCE |
| Pan head screw M6 x 16 ISO 14583 A2 T30 | 4 | PCE |
| DIN 125 A 6.4 st. zinc plated washer | 4 | PCE |
| Cage nut KM 6 | 4 | PCE |
| Screw ISO 7380, M4x12, Torx, zinc plated | 2 | PCE |
| Washer DIN 9021 Ø 4.3 zinc plated | 2 | PCE |


1. Remove 4x screws M3x7
2. Remove 2x trim piece



3. Attach 2x 19" Corner bracket Magic 2U RAL 9003 using the screws which were removed in step 1



4. Attach 19"Adapter plate 2U RAL 9003 using 2x screw ISO 7380 M4x12 Torx and washer DIN 9021 Ø 4.3



5. Attach 4x washer DIN 125 A 6.4 and 4x screw ISO 14583 M6x16 Torx for rack mount
6. Attach 4x cage nuts KM6 to cabinet
7. Attach instrument to cabinet


2.5.2. Instructions for Two Instruments

Table 2.6. Parts for rack mount of two instrument


| Description | Quantity | Unit |
|---|----------|------|
| Connection Strap Magic 2U outside | 1 | PCE |
| Connection Strap Magic 2U inside | 1 | PCE |
| 19" Corner bracket Magic 2U RAL 9003 | 2 | PCE |
| Connection Strap Magic 2U backside | 1 | PCE |
| Screw sim. DIN 965 M2.5x10 A2 Torx lock | 2 | PCE |
| Screw sim. DIN 7985 M3x12 Torx A2 w. lock-tight | 2 | PCE |
| Pan head screw M6 x 16 ISO 14583 A2 T30 | 4 | PCE |
| DIN 125 A 6.4 st. zinc plated washer | 4 | PCE |
| Cage nut KM 6 | 4 | PCE |

Assembly Instructions: Left Chassis

1. Remove 2x screws M3x7 on the left side and remove left trim piece
2. Remove 2x screws M3x7 on the right side




3. Attach 19" Corner bracket Magic 2U RAL 9003 to the left side with 2x screw M3x7 removed in step 1
4. Attach Connection Strap Magic 2U outside to the right side with 2x DIN 7985 screw M3x12 Torx




Assembly Instructions: Right Chassis

1. Remove 2x screws M3x7 on the right side and remove right trim piece
2. Remove 2x screws M3x7 left side




3. Attach 19" Corner bracket Magic 2U RAL 9003 to the right side with 2x screw M3x7 removed in step 1
4. Attach Connection Strap Magic 2U inside to left the side with screw Cylinder head screw M3x12 Torx




Chassis Assembly


1. Attach both chassis together and fix with 2 screws DIN 965 M2.5x10 Torx through the connection strap



2. Remove 4x screws and 2x inner plastic covers



3. Attach the rear connection strap, using screws removed in step 2



4. Attach Cage nuts KM6 to cabinet

Chapter 3. Tutorials

The tutorials in this chapter have been created to allow users to become more familiar with the basic technique of lock-in amplification, the operation of host-based lock-in amplifiers, the LabOne web browser based user interface, as well as some more advanced lock-in measurement techniques. In order to successfully carry out the tutorials, users are required to have certain laboratory equipment and basic equipment handling knowledge. The equipment list is given below.

Note

For all tutorials, you must have LabOne installed as described in the [Chapter 1](#). We make use of a systematic nomenclature to describe the different controls and elements of the LabOne graphical user interface. This nomenclature is explained in [Section 4.1](#).

- 1 USB or LAN cable
- 5 BNC cables
- 1 oscilloscope (optional)
- 2 BNC T-pieces
- With MF-IA Option Only
 - 1 Kelvin probe cable set and through-hole resistors $1\ \Omega$ and $10\ \Omega$ (for the Compensation tutorial)
 - 1 $M\Omega$ through-hole resistor and soldering equipment (for the Advanced Impedance Measurement tutorial)

3.1. Simple Loop

Note

This tutorial is applicable to all MFLI Instruments. No specific options are required.

3.1.1. Goals and Requirements

This tutorial is for people with no or little prior experience with Zurich Instruments lock-in amplifiers. By using a very basic measurement setup, this tutorial shows the most fundamental working principles of the MFLI Instrument and the LabOne UI in a step-by-step hands-on approach.

There are no special requirements for this tutorial.

3.1.2. Preparation

In this tutorial, you are asked to generate a single-ended signal with the MFLI Instrument and measure that generated signal with the same instrument using an internal reference. This is done by connecting Signal Output +V to Signal Input +V with a short BNC cable (ideally < 30 cm). Alternatively, it is possible to connect the generated signal at Signal Output +V to an oscilloscope by using a T-piece and an additional BNC cable. [Figure 3.1](#) displays a sketch of the hardware setup.




Figure 3.1. Setup for the Simple Loop Tutorial (LAN connection shown)

Note

This tutorial is for all MFLI irrespective of which particular option set is installed. Some changes in the description apply if the MF-MD Multi-demodulator option is installed.

Connect the cables as described above. Make sure that the MFLI Instrument is powered on and then connect the MFLI directly by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address, the LabOne graphical user interface is opened. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).

3.1.3. Generate the Test Signal

Perform the following steps in order to generate a 300 kHz signal of 0.5 V peak amplitude on Signal Output +V. We work with the graphical Lock-in tab. Note that the control elements in this tab dynamically adapt their appearance to the web browser window size. Be sure to work in full screen size for this test.

1. In the Lock-in tab, select the sub-tab 1 on the left-hand side of the screen. In the Reference section, change the frequency value of oscillator 1 to 300 kHz: click on the field, enter 300000 or 300 k in short and press either <TAB> or <ENTER> on your keyboard to activate the setting.
2. In the Output Amplitudes section, set the amplitude to 500 mV (peak value) and enable the signal by clicking on the button labeled "En". A single green LED on top indicates the enabled signal.
3. In the Signal Output 1 section (right hand side on the Lock-in tab), set the Range pull-down to 1 V and the Offset to 0 V. Keep the Add and Diff buttons unchecked.
4. By default, all physical outputs of the MFLI are inactive to prevent damage to the MFLI or to the devices connected to it. Now it is time to turn on the main output by clicking on the button labelled "On".

Table 3.1 summarizes the instrument settings to be made. If you have an oscilloscope connected to the setup, you should now be able to see the generated sinusoidal signal with a peak-to-peak amplitude of 1 V. Be sure to choose a high input impedance on the oscilloscope. But you can easily spare the extra equipment, as the MFLI comes with a built-in oscilloscope. In [Section 3.1.4](#) we describe how to use it.

Table 3.1. Settings: generate the test signal

| Tab | Section | # | Label | Setting / Value / State |
|---------|------------|---|-----------|-------------------------|
| Lock-in | Oscillator | 1 | Frequency | 300 kHz |
| Lock-in | Output | 1 | Amplitude | 500 mV |
| Lock-in | Output | 1 | Offset | 0 V |
| Lock-in | Output | 1 | On | On |

3.1.4. Check the Test Input Signal

Next, we configure the signal input side of the MFLI from the Lock-in tab, and then visualize the input signal using the Scope tab. In the Signal Input section of the Lock-in tab, select Sig In 1 from the pull-down menu. Set the range to 1.0 V, and be sure to have the AC, 50 Ω, Diff and Float buttons unchecked.

The range setting ensures that the analog amplification on the Signal Input +V is set such that the resolution of the input analog-to-digital converter is used efficiently without clipping the signal. This optimizes the dynamic range.

The incoming signal can now be observed over time by using the Scope tab. A Scope view can be placed in the web browser by clicking on the icon in the left sidebar or by dragging the Scope Icon to one of the open tab rows. Choose the following settings on the Scope tab to display the signal entering Signal Input +V:

Table 3.2. Settings: check the test signal

| Tab | Section | # | Label | Setting / Value / State |
|---------|--------------|---|-------|-------------------------|
| Lock-in | Signal Input | 1 | Float | Off |
| Lock-in | Signal Input | 1 | Diff | Off |

| Tab | Section | # | Label | Setting / Value / State |
|---------|--------------|---|---------------|-------------------------|
| Lock-in | Signal Input | 1 | 50 Ω | Off |
| Lock-in | Signal Input | 1 | AC | Off |
| Scope | Horizontal | | Sampling Rate | 60 MHz |
| Scope | Horizontal | | Length | 4096 pts |
| Scope | Vertical | | Channel 1 | Signal Input 1 |
| Scope | Trigger | | Enable | On |
| Scope | Trigger | | Level | 0 V |

The Scope tool now displays single shots of Signal Input +V with a temporal distance given by the Hold off Time. The scales on the top and on the left of the graphs indicate the zoom level for orientation. The icons on the left and below the figure give access to the main scaling properties and allow one to store the measurement data as a SVG image file or plain data text file. Moreover, panning can be achieved by clicking and holding the left mouse button inside the graph while moving the mouse.

Note

Zooming in and out along the horizontal dimension can be achieved with the mouse wheel. For vertical zooming, the shift key needs to be pressed and again the mouse wheel can be used for adjustments. Another, quick way of zooming in is to hold down the shift key and to use the right mouse button to define a horizontal, vertical, or box-like inside the graph area.

Having set the Input Range to 1 V ensures that no signal clipping occurs. If you set the Input Range to 0.1 V, clipping can be seen immediately on the scope window accompanied by a red OVI error flag on the status bar on the bottom of the LabOne User Interface. At the same time, the LED next to the Signal Input +V BNC connector on the instrument's front panel will turn red.

The Scope is a very handy tool to quickly check the quality of the input signal and to adjust a suitable input range setting. For the full description of the Scope tool please refer to the [Section 4.7](#).




Figure 3.2. LabOne Scope showing the raw signal generated by the MFLI

3.1.5. Measure the Test Input Signal

Now, we are ready to use the MFLI to demodulate the input signal and measure its amplitude and phase. We will use two tools of the LabOne User Interface: the Numeric and the Plotter tab.

First, adjust the parameters listed in the following table on the graphical Lock-in tab for demodulator 1.

Table 3.3. Settings to measure the test input signal

| Tab | Section | # | Label | Setting / Value / State |
|---------|------------------|---|---------|---|
| Lock-in | Signal Input | 1 | | Signal Input 1 |
| Lock-in | Low-Pass Filter | 1 | Sinc | Off |
| Lock-in | Low-Pass Filter | 1 | Order | 3 (18 dB/Oct) |
| Lock-in | Low-Pass Filter | 1 | BW 3 dB | 10.6 Hz |
| Lock-in | PC Data Transfer | 1 | En | On |
| Lock-in | PC Data Transfer | 1 | Rate | 100 Sa/s (automatically adjusted to 104.6 Sa/s) |
| Lock-in | PC Data Transfer | 1 | Trigger | Continuous |

These above settings configure the demodulation filter to the third-order low-pass operation with a 10.6 Hz 3 dB filter bandwidth (BW 3dB). Alternatively, the corresponding noise-equivalent bandwidth (BW NEP) or the integration time constant (TC) can be displayed and entered. The output of the demodulator filter is read out at a rate of 104.6 Hz, implying that 104.6 data samples are sent to the internal MFLI computer per second with equidistant spacing. These samples can be viewed in the Numeric and the Plotter tool which we will examine now.

Note

1. The rate should be about 7 to 10 times higher than the filter bandwidth chosen in the Low-Pass Filter section. When entering a number in the Rate field, the new rate is automatically set to the closest available value - in this case 104.6 Sa/s.
2. If you don't see any signal in the Plotter, Numeric, Spectrum, DAQ, or Sweeper tab, the first thing to check is whether the corresponding data stream is enabled

The Numeric tool provides the space for 16 or more measurement panels. Each of the panels has the option to display the samples in the Cartesian (X,Y) or in the polar format (R,THETA) plus other quantities such as the Oscillator Frequencies and Auxiliary Inputs. The unit of the (X,Y,R) values are by default given in V_{RMS}. The scaling and the displayed unit can be altered in the Signal Input section of the Lock-in tab. The numerical values are supported by graphical bar scale indicators to achieve better readability, e.g. for alignment procedures. Certain users may observe rapidly changing digits. This is due to the fact that you are measuring thermal noise that is maybe in the μ V or even nV range depending on the filter settings. This provides a first glimpse of the level of measurement precision offered by your MFLI Instrument. If you wish to play around with the settings, you can now change the amplitude of the generated signal, and observe the effect on the demodulator output.

Next, we will have a look at the Plotter tool that allows users to observe the demodulator signals as a function of time. It is possible to adjust the scaling of the graph in both directions, or make detailed measurements with 2 cursors for each direction. You can find a variety of handy tools for immediate analysis in the Math sub-tab, allowing you to accurately measure noise amplitude,

peak positions and heights, signal background and many more. [Figure 3.3](#) shows the signal along with additional graphical elements that are dynamically added to the plot when e.g. using the histogram functionality from the Math sub-tab.

Signals of the same unit are automatically added to the same default y-axis group. This ensures that the axis scaling is identical. Signals can be moved between groups. More information on y-axis groups can be found in [Plot Functionality](#). Try zooming in along the time dimension using the mouse wheel or the icons below the plot to display about one second of the data stream. While zooming in, the mode in which the data are displayed will change from a min-max envelope plot to linear point interpolation. The LabOne Web Server makes this choice depending on the density of points along the horizontal axis as compared to the number of pixels available on the screen.




Figure 3.3. LabOne User Interface Plotter displaying demodulator results continuously over time (roll mode)

Data displayed in the Plotter can also be saved continuously to the instrument memory and easily transferred to the host computer. Please have a look at [Section 4.2](#) for a detailed description of the data saving and recording functionality. Instrument and user interface settings can be saved and loaded using the Config tab (Settings section).

Note

The MFLI is able to measure DC signals by setting the oscillator frequency to 0 Hz. The Demodulator R signal in this case differs by a factor of $\sqrt{2}$ from the actual DC voltage on the input, which needs to be taken into account. This may be systematically corrected by entering a scaling factor 0.7071 in the Signal Inputs section of the Lock-in tab.

3.1.6. Different Filter Settings

As next step in this tutorial you will learn to change the filter settings and see their effect on the measurement results. For this exercise, change the 3 dB bandwidth to 1 kHz.

Table 3.4. Settings: change the filter parameters

| Tab | Section | # | Label | Setting / Value / State |
|---------|-----------------|---|--------|-------------------------|
| Lock-in | Low-Pass Filter | 1 | Order | 3 (18 dB/Oct) |
| Lock-in | Low-Pass Filter | 1 | BW 3dB | 1 kHz |

3.1. Simple Loop

| Tab | Section | # | Label | Setting / Value / State |
|---------|------------------|---|-------|-------------------------|
| Lock-in | PC Data Transfer | 1 | Rate | 6.7 kSa/s |

Increasing the filter bandwidth reduces the integration time of the demodulators. This will increase available time resolution but in turn make the signal noisier, as can be nicely observed in the Plotter tab. Note that it is recommended to keep the sample rate 7 to 10 times the filter 3 dB bandwidth. The sample rate will be rounded off to the next available sampling frequency. For example, typing 7 k in the Rate field will result in 6.7 kSa/s which is sufficient to not only properly resolve the signal, but also to avoid aliasing effects.

Moreover, you may for instance "disturb" the demodulator with a change of test signal amplitude, for example from 0.5 V to 0.7 V and back. The plot will go out of the display range which can be re-adjusted by pressing the "Rescale" button




Figure 3.4. LabOne User Interface Plotter displaying demodulator results while changing the filter bandwidth from 10 Hz to 1 kHz

3.2. External Reference

Note

This tutorial is applicable to all MFLI Instruments. No specific options are required. The user interface has slight differences depending on whether the MF-MD Multi-demodulator option is installed or not. The tutorial provides separate instructions for both cases.

3.2.1. Goals and Requirements

This tutorial explains how to lock an internal oscillator to an external reference frequency, and then demodulate a measurement signal at a harmonic of this frequency. To follow this tutorial, you need an optical chopper as well as a standard optical detector/emitter pair. However, the tutorial applies to any comparable setup in which separate reference and signal channels are available. The reference channel should have a sufficiently large amplitude (e.g., TTL level) to allow for reliable locking.

3.2.2. Preparation

Connect the cables as shown in Figure 3.5. Make sure the MFLI is powered on, and then connect the MFLI through USB to your PC, or to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address, the LabOne graphical user interface is opened. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).




Figure 3.5. Setup for the external reference measurement with optical chopper, LED, and photo diode.

3.2.3. Activate the External Reference Mode

The reference signal is wired from the sync output of the optical chopper to the Aux Input 1/Ref of the MFLI. In our case, the reference signal is a square signal switching between 0 V and 5 V. We choose a base frequency of 80 Hz on the chopper. You can inspect the signal easily by going to the Scope tab and selecting Aux In 1 Ch 1 as the input signal.

Locking the internal oscillator to the external signal looks slightly different depending on the installed options, notably if the MF-MD Multi-demodulator option is installed or not. We therefore describe the required steps separately for both cases.

Without MF-MD Multi-demodulator option: Open the graphical Lock-in tab. In the Internal/External Reference section on the bottom row of that tab, the section label is actually a control which can be toggled between Internal Reference (default) and External Reference. Set it to External Reference. To the right of that control, you can now select the input signal. Select Aux In 1 as the input signal. These settings are also shown in [Figure 3.6](#). The frequency value displayed in the center of the reference section should quickly convert to the 80 Hz of the chopper. The Lock-in settings used to lock to the external reference without MF-MD Multi-demodulator option are shown in the following table.

Table 3.5. Settings: set up external reference mode (without MF-MD option)

| Tab | Section | # | Label | Setting / Value / State |
|---------|-----------------------------|---|-----------------------------|-------------------------|
| Lock-in | Internal/External Reference | 1 | Internal/External Reference | External Reference |
| Lock-in | Internal/External Reference | 1 | Internal/External Reference | Aux In 1 |




Figure 3.6. Lock-in tab with settings for external reference (without MF-MD option)

With MF-MD Multi-demodulator option: Open the graphical Lock-in tab of the second demodulator. We use this demodulator to establish the phase-locked loop (PLL) between the internal oscillator 1 and the external signal. In the Reference section at the bottom left of the Lock-in tab, select ExtRef in the Mode field and select oscillator number 1. In the Signal Input section top left, select Aux In 1 as the input signal. These settings are also shown in [Figure 3.7](#). The frequency of oscillator 1 displayed in the Reference section should quickly converge to the 80 Hz of the chopper. The Lock-in settings for enabling the lock to the external reference with MF-MD Multi-demodulator option are shown in [Table 3.6](#).

Table 3.6. Settings: set up external reference mode (with MF-MD option)

| Tab | Section | # | Label | Setting / Value / State |
|---------|--------------|---|--------|-------------------------|
| Lock-in | Reference | 2 | Mode | ExtRef |
| Lock-in | Reference | 2 | Osc | 1 |
| Lock-in | Signal Input | 2 | Signal | Aux In 1 |





Figure 3.7. Lock-in tab with settings for external reference (with MF-MD option)

At this point, it is worth noting that the external reference signal is never used directly for demodulation. Instead, the frequency and phase of the external reference signal are mapped onto one of the internal oscillators through an internal phase-locked loop. This internal oscillator can then serve as a reference for any of the demodulators.

This mapping procedure is implemented with an automatic bandwidth adjustment that ensures quick locking over the whole instrument bandwidth. It covers a large variety of signal qualities in terms of frequency stability and signal-to-noise ratio. Over the course of automatic adjustment, the Low-Pass Filter bandwidth of the associated demodulators 2 or 4 usually ramps down until a final value is reached after a few seconds. The indicated bandwidth also marks an upper limit to the bandwidth of the phase-locked loop that does the mapping of the external signal to the internal oscillator. [Figure 3.8](#) shows a typical result in the Plotter for the frequency tracking immediately after it is turned on. For such a measurement, open the Plotter tab and add the corresponding signal to the plot (Control sub-tab, Vertical Axis Groups, Frequency, Channel 1, Add Signal).

Note

With the MF-MD Multi-demodulator option installed, you can alternatively look at the phase error (Control sub-tab, Vertical Axis Groups, Demod Theta, Channel 2, Add Signal). Be sure to enable the corresponding data stream in the PC Data Transfer section of the corresponding Lock-in tab.



[Figure 3.8](#). Frequency of the internal oscillator over time with stepwise automatic bandwidth adjustment

3.2.4. Measure at a Harmonic of the Reference Frequency

For our optical demonstration measurement, we use a Vishay TCRT5000 infrared detector/emitter pair whose light is passed through the optical chopper. The detector is a photo diode, the emitter an LED, and both are biased directly by the Auxiliary Output 2 through a simple circuit as shown in [Figure 3.5](#). We current-bias the LED with 10 mA by applying 5 V across a $500\ \Omega$ resistor. The $1\ k\Omega$ resistor in series with the photo diode is merely a limiter. Note that the circuit by design can't exceed the damage threshold of the MFLI (5 V on the $50\ \Omega$ I input).

The current generated by the photo diode contains an offset contribution, typically due to ambient light, and a modulation contribution due to the chopper. Both are in the range of some μA in our case, allowing us to use the higher input sensitivity of $100\ \mu\text{A}$ instead of $10\ \text{mA}$ and thus improve the input noise. The chopper wheel used for this experiment has a multiplier of 10, so the optical signal is actually modulated at a frequency of 800 Hz. This places us further away from the 50/60 Hz utility frequency without having to use a high revolution speed of the chopper.

We will use the harmonics functionality to internally generate an 800 Hz demodulation reference from the 80 Hz external reference. Setting this up again presents slight difference depending on

the installed options, so we describe the required steps with and without installed MF-MD Multi-demodulator option.

Without MF-MD Multi-demodulator option: In the Signal Input section of the graphical Lock-in tab, select Current Input 1 and change the input range to 100 μ A. In the External Reference Section, set the Harmonic (Harm) to 10 / 1. Note that this setting is hidden by default. You can get access to this setting by expanding the section with a click on the + symbol on the top right of the section. You should now observe a numerical display of the demodulator reference frequency close to 800 Hz as shown in [Figure 3.9](#). Finally, set the Low-Pass Filter to 100 Hz (3rd order) and enable the data stream in the PC Data Transfer section.




Figure 3.9. Lock-in tab set up for measurement at 800 Hz (without MF-MD option)

Table 3.7. Settings: lock-in detection at a harmonic of the external reference frequency (without MF-MD option)

| Tab | Section | # | Label | Setting / Value / State |
|---------|--------------------|---|--------|-------------------------|
| Lock-in | External Reference | 1 | Harm | 10 / 1 |
| Lock-in | Signal Input | 1 | Signal | Current Input 1 |
| Lock-in | Signal Input | 1 | Range | 100 μ A |

*With MF-MD Multi-demodulator option:
*Open the graphical Lock-in tab of the first demodulator. We use this demodulator to perform the lock-in detection. In the Signal Input section of the graphical Lock-in tab, select Current Input 1 and change the input range to 100 μ A. In the Reference section, choose Oscillator 1 and set the Harmonic (Harm) to 10, cf. [Figure 3.10](#). In the circuit diagram of the graphical Lock-in tab, you should observe the numeric value of the demodulation frequency, 800 Hz. Set the Low-Pass Filter to 100 Hz (3rd order) and enable the data stream in the PC Data Transfer section.

Table 3.8. Settings: lock-in detection at a harmonic of the external reference frequency (with MF-MD option)

| Tab | Section | # | Label | Setting / Value / State |
|---------|--------------|---|--------|-------------------------|
| Lock-in | Reference | 1 | Harm | 10 |
| Lock-in | Signal Input | 1 | Signal | Current Input 1 |
| Lock-in | Signal Input | 1 | Range | 100 μ A |




Figure 3.10. Lock-in tab setup for measurement at 800 Hz (with MF-MD option)

Note

The filter bandwidth should be well below the modulation frequency OMEGA in order to suppress the 2 OMEGA signal component (see [Sinc Filtering](#)). Here we use a filter bandwidth of 100 Hz at a modulation frequency OMEGA of 800 Hz.

3.2.5. Plot the Measurement Results

Having set up the demodulation at 800 Hz, we are ready to check the measurement data. Open the Plotter tab. In the Control sub-tab, select the Enabled Demods R setting in the Presets list. [Figure 3.11](#) shows a plot of the photo diode current in which the light path between emitter and detector was manually intersected a number of times to show the measurement contrast. When the light path is open (except for the chopper wheel), we measure a constant rms current of about 15.5 μ A, and whenever we block the light path the current drops to zero.




Figure 3.11. Photo diode signal continuously plotted with the LabOne Plotter

3.3. Sweeper

Note

This tutorial is applicable to all MFLI Instruments with the MF-MD Multi-demodulator option installed. The MD option is required for four-terminal measurements with simultaneous detection of voltage and current.

3.3.1. Goals and Requirements

This tutorial explains how to use the LabOne Sweeper to perform measurements on a MOSFET (Metal-oxide-semiconductor field-effect transistor). The goal of the tutorial is to demonstrate typical steps in the work flow of a lock-in measurement using the LabOne toolset using the MOSFET as a demonstration system. To follow this tutorial, you need a MOSFET with specifications similar to those of the IRLML2502. However, many of the working steps have a generic character and can be adopted to a multitude of transport measurement situations.

The goal of the tutorial is not to provide instructions for MOSFET characterization. This is a sophisticated measurement task and lies beyond the scope of this tutorial.

3.3.2. Preparation

We perform these measurement on a IRLML2502 power MOSFET manufactured by International Rectifier, but many other MOSFETs allow similar measurements with certain adjustments to the parameters. Connect the cables as shown in [Figure 3.12](#). Make sure the MFLI is powered on, and then connect the MFLI through USB to your PC, or through an Ethernet cable to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address, the LabOne graphical user interface is opened in the browser. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).




Figure 3.12. Setup for the MOSFET measurements.

3.3.3. Tune the Gate–Source Voltage

We start by configuring the lock-in to detect the source current of the MOSFET. Open the Lock-in tab of the first demodulator. In the Reference section choose oscillator 1 and set the frequency to 1 kHz. In the Signal Input section, select Current Input 1 as the signal and set the range to 10 mA. In the Low-Pass Filter section, set the filter 3 dB bandwidth to 10 Hz.

We will operate the MOSFET with a negative drain–source offset voltage. On top of that, we apply a small alternating drain–source voltage. This is an unusual regime for the MOSFET. But it allows to operate the device in a configuration of linear response to the alternating drain–source voltage while having offset currents within the range of the MFLI Signal Input I.

In the Output Amplitudes section, set Amplitude 1 to 10 mVrms and enable the output. In the Signal Output section, set Offset to -100 mV and turn on the output. Finally, enable the data transfer of demodulator 1 in the PC Data Transfer section. The following table summarizes the settings to be made.

Table 3.9. Settings: MOSFET source current measurement

| Tab | Section | # | Label | Setting / Value / State |
|---------|-------------------|---|--------------|-------------------------|
| Lock-in | Reference | 1 | Osc | 1 |
| Lock-in | Reference | 1 | Freq | 1 kHz |
| Lock-in | Signal Input | 1 | Signal Input | Curr In 1 |
| Lock-in | Signal Input | 1 | Range | 10 mA |
| Lock-in | Low-Pass Filter | 1 | BW 3dB | 100 Hz |
| Lock-in | Output Amplitudes | 1 | Amp 1 (Vrms) | 100 mVrms |
| Lock-in | Output Amplitudes | 1 | En | On |
| Lock-in | Signal Output | 1 | Offset | -100 mV |
| Lock-in | Signal Output | 1 | On | On |
| Lock-in | PC Data Transfer | 1 | En | On |

The MOSFET gate is connected to the Auxiliary Output 1. Using the Aux tab, we can configure this output to generate a constant voltage. In the Aux Output section, set the Signal of the first Auxiliary Output to Manual. Now it is possible to output an arbitrary voltage using the Offset field. If you play around with that value while observing the MOSFET current in the Plotter or the Numeric tab, you can observe the behavior of the MOSFET as a tunable resistor. Our model is an n-channel device, therefore negative gate–source voltages lead to a suppression of the current and positive voltages of a few Volts open up the MOSFET channel. The following table summarizes the settings to be made.

Before we continue, let us shortly discuss the effect of series resistances in our measurement setup. Taking a quick glance at [Figure 3.12](#) keeping in mind that Signal Input I represents a virtual ground. We would conclude that the voltage on Signal Output +V is equal to the drain–source voltage of the MOSFET, and the voltage on Auxiliary Output 1 is equal to the gate–source voltage. In reality, this is not exact, since Signal Output +V, Signal Input I, and the Auxiliary Outputs have a $50\text{ }\Omega$ impedance connected in series internally. As soon as there is significant current flow on either of the three connectors, the actual potential at the corresponding MOSFET contact is altered. This correction is negligible for the gate contact which is essentially isolating, but it can be important for the source and drain contacts.

In the first part of the tutorial we will focus on the region with partially closed MOSFET channel. In this high-impedance configuration, we can make the assumption that currents and corrections are small. In the second part of the tutorial we will focus on the region with open MOSFET channel. In this low-impedance configuration, we instead use a four-terminal measurement to properly account for the corrections.

3.3.4. Sweep the Gate–Source Voltage

We will now set up a sweep of the MOSFET gate voltage. Open the Sweeper tab and in the Control sub-tab, choose Aux Out 1 Offset as Sweep Parameter. Enter Start and Stop values of 0 V and 1 V,

respectively, and set Length to 100 points. Disable the Log check box so the measurement points will be linearly distributed over the interval between 0 V and 1 V.

In a Sweeper measurement, some care has to be taken in choosing a sweep speed compatible with the measurement bandwidth. If the time per point is too short, systematic errors can occur due to insufficient settling of the measurement value. You can usually let the LabOne Sweeper take care of this. Choose Application Mode in the Filter field of the Settings sub-tab. The Sweeper then chooses useful sweep parameters and adjusts the demodulator filter settings for a number of pre-defined application cases. We select the general-purpose "Parameter Sweep Averaged" case in the Application field. Please refer to [Section 4.10](#) for further information.

Note

It may be that the measurement bandwidth is limited by the device under test and not by the demodulator filter. The Sweeper can not account for this, as it only knows the demodulator filter bandwidth but not the properties of the device. If you're unsure whether the sweep is too fast, check for hysteresis in the measurement by setting the Sweep Mode to Bidirectional in the Control sub-tab. If custom sweep settings appear necessary, you can access them in the Advanced Mode from the Settings sub-tab.

Table 3.10. Settings: MOSFET gate voltage sweep

| Tab | Section | # | Label | Setting / Value / State |
|---------|----------|---|-------------|--------------------------|
| Sweeper | Control | | Sweep Param | Aux Out 1 Offset |
| Sweeper | Control | | Start | 0 V |
| Sweeper | Control | | Stop | 1 V |
| Sweeper | Control | | Length | 100 points |
| Sweeper | Control | | Log | Off |
| Sweeper | Settings | | Filter | Application Mode |
| Sweeper | Settings | | Application | Parameter Sweep Averaged |




Figure 3.13. Gate voltage dependence of the MOSFET source current measured with the LabOne Sweeper

[Figure 3.13](#) shows the result of the gate voltage sweep. For gate voltages below about 0.5 V, we observe an exponential suppression of the drain current. For higher voltages, the current eventually saturates at about 0.1 mA. This value is determined by the Signal Output +V amplitude of 10 mV and the cumulated 100 Ω series resistance of the MFLI input and output impedances, two times 50 Ω . Note that in this plot, the signal amplitude goes down to about 10 nA, a level of about -120 dB relative to the input range of 10 mA! This gives you an impression of the accessible dynamic range of the MFLI Instrument.

3.3.5. Four-Terminal Resistance Measurement

In the measurements shown so far in this tutorial, we effectively employed a two-terminal method. As long as the device under test has a large impedance, like the MOSFET with a partly closed channel, this is adequate and has the benefit of being simple. In the opposite case of small device impedance, the effect of series impedances in the cabling and Signal Outputs and Inputs, can become increasingly dominant. It is then more appropriate to employ a four-terminal method.

In our case, we may be interested in the MOSFET properties in the On state, in which its channel resistance is well below 1 Ω . In order to measure this On-resistance, we continue to measure the alternating current as we did up to now. We add a measurement of the alternating voltage drop across the MOSFET channel using the differential Signal Input of the MFLI.

We configure the second demodulator to perform this voltage measurement. Open the Lock-in tab of the second demodulator. In the Reference section, select Oscillator 1. In the Signal Input section, select Signal Input 1 and enable differential measurement by enabling the check box labeled Diff. Set the range to 1 mV and enable the data transfer of demodulator 1 in the PC Data Transfer section. The following table summarizes the settings to be made.

Table 3.11. Settings: MOSFET gate voltage sweep

| Tab | Section | # | Label | Setting / Value / State |
|---------|------------------|---|-------|-------------------------|
| Lock-in | Signal Input | 2 | | Sig In 1 |
| Lock-in | Signal Input | 2 | Diff | ON |
| Lock-in | Signal Input | 2 | Range | 1 mV |
| Lock-in | Reference | 2 | Osc | 1 |
| Lock-in | PC Data Transfer | | En | ON |

In order to obtain a clean four-terminal measurement, the voltages probe on the MOSFET source and drain should be as close to the device under test as possible. The best is to use point probes directly on the MOSFET contacts to eliminate the effect of soldering joint resistances.

At a gate voltage (Aux Output 1) of 4 V and an excitation voltage of 100 mVrms (Signal Output 1), we can check the measurement data on the Numeric tab. We measure a source current of 1.00 mA and a source-drain voltage of 0.027 mV. This corresponds to an On-resistance of 27 m Ω in accordance with the device specifications. [Figure 3.14](#) and [Figure 3.15](#) show the source current and two-terminal drain–source voltage of the MOSFET over a larger gate voltage range.

3.3. Sweeper




Figure 3.14. Gate voltage dependence of the MOSFET source current measured with the LabOne Sweeper in a four-terminal setup




Figure 3.15. Gate voltage dependence of the MOSFET drain–source voltage measured with the LabOne Sweeper in a four-terminal setup

3.4. Basic Impedance Measurement

Note

This tutorial is applicable to all MFIA Instruments and to MFLI Instruments with the MF-IA Impedance Analyzer option installed.

3.4.1. Goals and Requirements

This tutorial is for people with no or little prior experience with Zurich Instruments impedance analyzers. By using a very basic measurement setup, this tutorial shows the fundamental working principles of the MFLI Instrument and the LabOne user interface in a step-by-step hands-on approach.

The tutorial requires the MFITF Impedance Test Fixture.

3.4.2. Preparation

This tutorial guides you through the basic steps to perform a simple measurement of the 1 k Ω test resistor delivered with the MFITF Impedance Test Fixture. Start by connecting the MFITF to the BNC connectors on the front panel of the MFLI, and plug the resistor labeled "1k 0.05%" into the 8-pin connector on the front of the test fixture. Figure 3.16 shows a diagram of the hardware setup.




Figure 3.16. Setup for the Impedance Measurement Tutorial

Make sure that the MFLI Instrument is powered on and then connect the MFLI directly by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address, the LabOne graphical user interface is opened. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).

3.4.3. Configure the Impedance Analyzer

The Impedance Analyzer tab shown in [Figure 3.17](#) provides you with the necessary settings to start measuring impedance. Open the tab by clicking on the corresponding icon on the left side of the user interface. For a quick measurement of the 1 k Ω device-under-test (DUT), the default settings are suitable. All we have to do is to click the Enable button on top left of the Impedance Analyzer tab in order to turn on the drive signal and start the measurement. This will override some of the

settings made in the Lock-in tab. Since automatic range control is enabled by default, the current and voltage input ranges will be adjusted within a few seconds and the measurement starts.




Figure 3.17. Impedance Analyzer tab (Application mode)

The measurement result is now shown in the Measurement Results section of the tab. As an alternative, the [Section 4.5](#) provides a more configurable display of the data. Open the tab by clicking on the corresponding icon on the left of the screen. Select the Impedance preset in the Presets sub-tab. The Numeric tab shown in [Figure 3.18](#) is organized in panels which display the impedance Z_{DUT} in Cartesian and in polar form and other parameters. You can add more panels using the Tree Selector on the right if you wish to monitor other quantities such as bias voltage. Every numerical value is supported by a graphical bar scale indicator for better readability. We read an impedance absolute value $Abs(Z)$ of 999.8 Ω , and a complex phase $Phase(Z)$ of nearly 0 degrees, nicely corresponding to the 1 k Ω DUT that we plugged in.



Figure 3.18. Numerical tab displaying measured impedance and circuit representation parameters

3.4.4. Measure Frequency Dependence

The frequency is a critical measurement parameter. The frequency can be changed manually by clicking on the Osc Frequency field, typing a value such as 1000 or 1k in short press either [**<TAB>**](#) or [**<ENTER>**](#) on your keyboard to apply the setting. For a more systematic measurement of the frequency dependence, we'll turn to the Sweeper tool introduced previously in [Section 3.3](#).


Open the Sweeper tab by clicking on the corresponding icon on the left side of the user interface. Select the Application Mode in the Settings sub-tab of the Sweeper, and Impedance as the Application. Add the measured absolute value of the impedance to the plot by selecting "IA Abs(Z)" as Signal Type clicking on "Add Signal". In the Control sub-tab you can configure the sweep parameter, the sweep range and resolution. Set the start and stop frequency to 1 kHz and 1 MHz. By default, the sweeper is set to divide this span into 100 points on a logarithmic grid. Both of these settings are configurable, as well as the Sweep Parameter. The following table summarizes the Sweeper settings we use.

Table 3.12. Settings: configure the Sweeper for frequency dependence measurement

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|----------|------------|---|--------------|-------------------------|
| Sweeper | Settings | | | Filter | Application Mode |
| Sweeper | Settings | | | Application | Impedance |
| Sweeper | Control | Horizontal | | Sweep Param | Osc 1 Frequency |
| Sweeper | Control | Horizontal | | Start / Stop | 1k / 1M |
| Sweeper | Control | Horizontal | | Length | 100 pts |

Start the frequency sweep by clicking on **Single**. The screenshot in [Figure 3.19](#) shows the measurement in the plot section of the Sweeper tab. It shows a perfectly flat curve for the real part of the impedance $\text{Abs}(Z)$ within 0.05% of $1\text{k}\Omega$ as is indicated with the cursor for the vertical axis. Whereas our $1\text{k}\Omega$ DUT has no notable frequency dependence between 1 Hz and 1 MHz, very large or small resistors will typically show a change in $\text{Abs}(Z)$ towards high frequencies due to the spurious capacitance or inductance.

The plot section features multi-trace and dual-plot functionalities for representing multiple curves with different units, such as Ohm (Ω) and Farad (F), or with very different magnitudes. The plot functionality in LabOne is described in more detail in [Plot Functionality](#). There you also find a description of the cursor and math functions for quick quantitative analysis of measurement data.

Figure 3.19. LabOne Sweeper showing the frequency dependence of a $1\text{k}\Omega$ DUT

3.4.5. Circuit Representation and Measurement Mode

There are two settings that any user should be aware of before continuing with own measurements: the Equivalent Circuit Mode, and the DUT Representation. These settings determine the currently active measurement configuration. The configuration is graphically represented by a dynamically updated circuit diagram in the Impedance Analyzer tab.

1. The Measurement Mode (either 2 Terminal or 4 Terminal) corresponds to the way the DUT is wired to the instrument connectors. This determines where the DUT voltage V is measured: on Signal Input $-V$ and Signal Input $+V$, or on Signal Output $+V$. The voltage measurement together with the measurement of the current I on Signal Input I constitutes a measurement of the impedance $Z=V/I$. For the $1\text{k}\Omega$ DUT, the measurement mode is 4 Terminal because all four connectors Signal Output $+V$, Signal Input I , Signal Input $+V$ and Signal Input $-V$ are wired to the DUT.

- The DUT Representation determines how the measured complex-valued impedance $Z_{DUT}=V/I$ is converted into DUT circuit parameters such as resistance and capacitance. For our $1\text{ k}\Omega$ resistor, a parallel resistor-capacitor representation $R_p \parallel C_p$ makes sense, even if the parallel capacitance is negligible.


The DUT representation parameters (in our case Representation Parameter 1 = R_p , and Representation Parameter 2 = C_p) are available for display elsewhere in the user interface, e.g. in the Numeric or in the Sweeper tab. In the Numeric tab shown in [Figure 3.18](#), the Model Parameter 1(R_p) reads $999.8\ \Omega$. The panel of the Model Parameter 2(C_p) shows no numerical reading but the message "Suppression" instead. This message of the LabOne Confidence Indicator informs you in situations when one of the Model Parameters cannot be determined reliably. In the present case, the current passing through the stray capacitance between the resistor electrodes is too small compared to the current through the resistor itself. Instead of displaying a calculated numeric value with no meaning, the "Suppression" warning prevents you from doing systematic measurement errors.

Apart from "Suppression", there are other Confidence Indicator warnings that can appear. The Confidence Indicator is for instance able to detect missing connections (e.g. when trying to measure a DUT in 4 Terminal mode when it is connected to 2 terminals only), or signal underflow and overflow conditions. The meanings of the different warnings are summarized in [List of warning messages provided by the Confidence Indicator](#) in the Functional Description chapter.

3.4.6. Time Dependence and Filtering

Next, we will have a look at the Plotter tab that allows users to observe measurement data as a function of time, e.g. to measure the long-term stability of a component impedance. Open the Plotter tab by clicking on the corresponding icon on the left, and choose the Impedance preset in the Control sub-tab in order to add a selection of useful quantities to the plot. For a good overview, disable all traces except the resistance (Impedance 1 Representation Parameter 1) using the checkboxes in the Vertical Axis Group section.

The Plotter is a good tool to observe the noise in the measurement. Noise can be efficiently eliminated by low-pass filtering. The MFLI offers automatic bandwidth control which usually provides good noise reduction without unnecessarily slowing down the measurement. Nonetheless it can sometimes be beneficial to optimize the filtering manually, for instance in situations with strong electrical noise. For manual adjustment, disable the Bandwidth Control button in the Impedance Analyzer tab. This setting is only visible in the lower half of the IA tab after setting Mode to Advanced in the Measurement Control section, see [Figure 3.20](#). The Low-Pass Filters section now changes from a disabled (greyed-out) state to an editable (white) state. Try different filter bandwidths, e.g. 1 Hz and 100 Hz, to see the live effect on the data as seen in [Figure 3.21](#). More information about filter parameters is found in the [Chapter 6](#).



[Figure 3.20. Impedance Analyzer tab \(Advanced mode\)](#)




Figure 3.21. LabOne Plotter showing a resistance measurement over time. Changing the filter setting manually leads to a change in noise.

The following table summarizes the Plotter settings we use.

Table 3.13. Settings: configure the Sweeper for frequency dependence measurement

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|---------------------|---|--------|-------------------------|
| Plotter | Control | Select a Preset | | | Impedance |
| IA | | Measurement Control | | Mode | Advanced |
| IA | | Bandwidth Control | | Auto | OFF |
| IA | | Low-Pass Filters | | BW 3dB | 1 Hz / 100 Hz |

3.4.7. Measurement Accuracy

The measurement accuracy is one of the key specifications of an impedance analyzer. It relates the measured and the real DUT impedance. The real impedance of the supplied 1 kΩ DUT is within 0.05% of an ideal 1 kΩ resistor in the frequency range of the MFLI, and is therefore suitable to judge the accuracy of the measurement result.

The measurement accuracy is not a universal number but depends on the frequency and on the absolute impedance $|Z_{DUT}|$. Figure 3.22 shows the accuracy across the full parameter space covered by the MFLI. This impedance accuracy chart is a handy tool not only to get the measurement accuracy, but also to quickly obtain the absolute impedance of a capacitance or inductance at a certain frequency. For 1 kΩ (vertical axis) and 1 kHz (horizontal axis), we land in a region with 0.05% accuracy.




Figure 3.22. Impedance Accuracy chart

Note

The relative accuracy specification of the instrument applies to the measured total impedance. Neither does it apply to the real or imaginary parts of the impedance individually, nor to the circuit representation parameters. A 30 minute warm-up time and a 300 mV test signal are required to reach the maximum accuracy.

3.5. Advanced Impedance Measurements

Note

This tutorial is applicable to all MFIA Instruments and to MFLI Instruments with the MF-IA Impedance Analyzer option installed.

3.5.1. Goals and Requirements

The goal of this tutorial is to show some more advanced features of the LabOne user interface by guiding you through a measurement of a frequency-dependent impedance. We introduce important practical aspects about impedance measurements such as the influence of parasitics, or the effect of parameter suppression.

This tutorial is for people with some starting experience with Zurich Instruments impedance analyzers. To follow this tutorial, you need a $1\text{ M}\Omega$ DUT fitting the MFITF Impedance Test Fixture. An easy way to get that is to solder a $1\text{ M}\Omega$ through-hole resistor onto one of the DUT carriers delivered with the MFITF.

3.5.2. Preparation

Start by connecting the MFITF Test Fixture to the BNC connectors on the front panel of the MFLI, and plug the DUT into the 8-pin connector on the front of the test fixture. Figure 3.23 shows a diagram of the hardware setup.




Figure 3.23. Setup for the Impedance Measurement Tutorial. The measured device is a resistor soldered onto one of the through-hole DUT carriers that come with the MFITF.

Make sure that the MFLI Instrument is powered on and then connect the MFLI directly by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address or through the MF Device Finder, the LabOne graphical user interface is opened. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).

3.5.3. Impedance and Representation Parameters

The real impedance of a DUT like the $1\text{ M}\Omega$ resistor is not necessarily equal to its nominal, or ideal, value. First of all, the DUT impedance value is only specified within some accuracy, e.g.

1%. In addition to that imperfection, there are spurious impedance components such as lead inductance, or parallel capacitance. For the given $1\text{ M}\Omega$ resistor, the real impedance is indeed close to that of a parallel $R_{\text{p}}||C_{\text{p}}$ circuit, with a parallel capacitor C_{p} of some hundreds of fF. This real impedance, including device imperfections, is what the MFLI measures.

In order to measure the $1\text{ M}\Omega$ DUT, we configure the Impedance Analyzer with a suitable Equivalent Circuit Representation of $R_{\text{p}}||C_{\text{p}}$. Since the DUT carrier we use is connected to 2 leads only, we change the measurement mode to 2 Terminal. Furthermore, we set the Range Control to Auto. This will set the input current and voltage ranges to suitable values.

[Table 3.14](#) summarizes the instrument settings we use.

Table 3.14. Settings: configure and enable the impedance analyzer

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|---------|---------------------|---|----------------|------------------------------|
| IA | | Equivalent Circuit | | Mode | 2 Terminal |
| IA | | Equivalent Circuit | | Representation | $R_{\text{p}} C_{\text{p}}$ |
| IA | | Measurement Control | | Osc Frequency | 1k |
| IA | | Measurement Control | | Enable | ON |
| IA | | Range Control | | Input Control | Auto |

3.5.4. Measure the Frequency Dependence

Open the Sweeper tab (Settings sub-tab), select the Application Mode, and Impedance as the Application. In the Control sub-tab you can configure the sweep parameter, the sweep range and resolution. We choose parameters for a logarithmic frequency sweep from 1 kHz to 1 MHz. We start with a measurement of the absolute impedance $|Z_{\text{DUT}}|$. Add this parameter to the plot by selecting "IA Abs(Z)" as a Signal Type, and click on "Add Signal". The following table summarizes the Sweeper settings we use.

Table 3.15. Settings: configure the Sweeper for frequency dependence measurement

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|----------|------------|---|--------------|-------------------------|
| Sweeper | Settings | | | Filter | Application Mode |
| Sweeper | Settings | | | Application | Impedance |
| Sweeper | Control | Horizontal | | Sweep Param | Osc 1 Frequency |
| Sweeper | Control | Horizontal | | Start / Stop | 1k / 1M |
| Sweeper | Control | Horizontal | | Length | 100 pts |

Start the frequency sweep by clicking on . Display the absolute impedance $|Z_{\text{DUT}}|$ by selecting "Impedance 1 Sample Abs(Z)" in the Vertical Axis Groups section. Naively we might expect this parameter to stay constant at $1\text{ M}\Omega$, but in fact it drops by about 50% at 500 kHz. The plot in [Figure 3.24](#) shows the measurement of $|Z_{\text{DUT}}|$ as the red curve in the plot section of the Sweeper tab. The drop of the absolute impedance is due to the spurious parallel capacitance. At high enough frequencies, this capacitance forms a bypass for the current and therefore leads to a reduction of the impedance.




Figure 3.24. Absolute Impedance $|Z_{DUT}|$ and replacement circuit resistance of a $1\text{ M}\Omega$ through-hole device measured with the LabOne Sweeper




Figure 3.25. Replacement circuit capacitance of a $1\text{ M}\Omega$ through-hole device measured with the LabOne Sweeper

The $R_p \parallel C_p$ circuit representation allows us to extract the parallel resistance R_p and capacitance C_p separately. Even after the Sweep has finished, we can add these signals to the plot by selecting IA Parameter 1 or IA Parameter 2 as Signal Type, and clicking on "Add Signal". Selecting the corresponding Impedance 1 Sample Rep Parameter 1 or 2 in the Vertical Axis Groups section will change the axis between a Farad (F) and an Ohm (Ω) scale.

Ideally, the resistance and capacitance are both frequency-independent. Looking at the blue curve in Figure 3.24 (R_p) and the green curve in Figure 3.25 (C_p), this is indeed mostly the case in the measurement: R_p stays flat at about $1\text{ M}\Omega$ up to a few 100 kHz, and C_p stays at about 0.5 pF . However, parts of both curves are tagged by the Confidence Indicator warning "Suppression". It shows that the capacitance measurement is most reliable at high frequencies, and the resistance measurement is most reliable at low frequencies.

3.5.5. Measure a Nyquist Plot

Instead of a conventional frequency dependence with the frequency on the horizontal axis and an impedance parameter on the vertical axis, the Sweeper also features measurement of Nyquist plots. A Nyquist plot is a parametric plot of the impedance as a function of frequency with the real part of the impedance (resistance) on the horizontal axis, and the imaginary part (reactance) on the vertical axis. To obtain a Nyquist plot, please follow the instructions below.

In the Control sub-tab of the Sweeper, select the desired start frequency and stop frequency. Set XY Mode to On - Invert and select Real(Z) as the X signal from the selection tree. Select the imaginary part of Z with IA Imag(Z) as a Signal Type in the Vertical Axis Groups and add it to the plot. Start the sweep by clicking on **Single**. Scale the vertical axis by setting the axis scaling mode on the left side of the plot to Auto, see [Plot Area Elements](#). The horizontal axis can be fixed to match the scale of the vertical axis by using the Track axis scaling mode instead of FS, Manual, or Auto. This ensures that a circle in the complex plane is displayed as a circle in the plot independent of the window aspect ratio.

The table below summarizes the settings necessary to obtain a Nyquist plot

Table 3.16. Settings: configure the Sweeper for frequency dependence measurement

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|----------------------|---|-------------------|---|
| Sweeper | Control | | | XY Mode | On - Invert |
| Sweeper | Control | | | X Signal | Impedances / Impedance 1 Sample / Real(Z) |
| Sweeper | Control | Vertical Axis Groups | | Signal Type | IA Imag(Z) |
| Sweeper | Control | Vertical Axis Groups | | Add Signal | Click |
| Sweeper | | Plot Area (left) | | Axis Scaling Mode | Auto |
| Sweeper | | Plot Area (bottom) | | Axis Scaling Mode | Track |

The 1 MΩ resistor connected as a DUT in the setup [Figure 3.23](#) for this tutorial has relatively unspectacular, linear Nyquist plot. To illustrate the characteristics of a Nyquist plot better, we show the measurement of an R-R-C circuit which has the shape of a semicircle. The measurement shown in [Figure 3.26](#) is easy to reproduce by soldering the sample from through-hole components as shown in [Figure 3.27](#) onto a through-hole DUT carrier. The components used here were $R_p = 6.8 \text{ k}\Omega$, $R_s = 2.2 \text{ k}\Omega$, and $C = 1 \mu\text{F}$.




Figure 3.26. Nyquist plot of an R-R-C sample




Figure 3.27. R-R-C sample circuit diagram

3.5.6. Saving and Exporting Data

Data acquired with the Sweeper can be easily saved to comma-separated value (CSV), MATLAB, and ZView format. Particularly the ZView format is attractive for further equivalent circuit modeling with specialized software tools. Such an analysis often enables precise characterization of the DUT circuit, going much beyond the extraction of a pair of representation parameters.

All past sweeps are listed in the History sub-tab of the Sweeper, up to a maximum number of list entry specified by the History Length parameter. Clicking on **Save** will store all the sweeps that are currently in the History list. The data are stored in a subfolder of the LabOne Data folder which can be conveniently accessed in the [Section 4.17](#). The Enable button next to each History entry controls the plot display, but not which sweeps are saved. Find more information, for instance on how to use the Reference feature, in [Section 4.10](#). Select your preferred file format from the drop-down list at the bottom of the History sub-tab of the Sweeper. This setting is global and also applies to the Plotter and the DAQ tabs.

Alternatively, the buttons and in the plot area of the Sweeper tab allow you to save the selected graphical traces as a text file or a vector graphics.

3.6. Compensation

Note

This tutorial is applicable to all MFIA Instruments and to MFLI Instruments with the MF-IA Impedance Analyzer option installed.

3.6.1. Goals and Requirements

The goal of this tutorial is to demonstrate a user compensation for impedance measurements with the MFLI instrument. A compensation improves the measurement accuracy when using a custom impedance fixture.

Some starting experience with Zurich Instruments impedance analyzers is required to follow the tutorial. You also need a Kelvin probe cable set and a $1\ \Omega$ through-hole resistor, a $10\ \Omega$ resistor, and a simple piece of wire. Instead of the Kelvin probe set, you can use a set of BNC cables and crocodile clamps.

3.6.2. Preparation

Start by connecting the Kelvin probe set to the BNC connectors on the front panel of the MFLI, paying attention not to mix up the connectors. One clamp should be electrically connected to Signal Output $+V$ and Signal Input $+V$, the other clamp to Signal Input I and Signal Input $-V$. Fix the $1\ \Omega$ resistor with the two clamps. Figure 3.28 shows a diagram of the hardware setup.




Figure 3.28. Setup for the Impedance Compensation Tutorial

Make sure that the MFLI Instrument is powered on and then connect the MFLI directly by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After connecting to your Instrument through the web browser using its address, the LabOne graphical user interface is opened. Check the [Chapter 1](#) for detailed instructions. The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (i.e. as is after pressing F5 in the browser).

3.6.3. Configure the Impedance Analyzer

A measurement fixture like the Kelvin probe set affects the impedance measurement through its electrical properties, such as its stray capacitance, or the delay caused by its cables. A carefully executed compensation can practically eliminate the negative influence and thus improve measurement accuracy.

To get an idea of the Kelvin probe's influence, let's first make a quick measurement without compensation. We'll select the Rs+Ls Representation in the Impedance Analyzer tab, which is a good choice for small-valued resistors. The two representation parameters can be read in the Numeric tab with activated Impedance preset. We furthermore relax the threshold of the Suppression warning by setting Suppression Ratio to 100 in the Impedance Analyzer tab. This setting becomes visible in the lower half of the tab after setting the Measurement Control Mode to Advanced. The relaxed condition is deemed sufficient for the level of accuracy that we can achieve with such a cable-based setup.

Let's start by reading some measurement values at different oscillator frequencies, which we change manually in the Impedance Analyzer tab.

Table 3.17. Measurement: 1 Ω through-hole resistor without compensation

| Frequency | Rep. parameter 1 (resistance Rs) | Rep. parameter 2 (inductance Ls) |
|----------------------|----------------------------------|----------------------------------|
| 1 kHz | 1.001 Ω | Suppression |
| 500 kHz | 0.986 Ω | 110 nH |
| 3 MHz | 0.738 Ω | 112 nH |
| 5 MHz (MF-5M option) | Suppression | 111 nH |

The resistance (Rep. parameter 1) at 1 kHz looks quite reasonable. The inductance (Rep. parameter 2) is not reliably measurable at this frequency and is flagged with the "Suppression" warning. At higher frequencies such as 500 kHz, the inductance is measurable, but it seems unexpectedly large: 110 nH would correspond to 10 to 15 cm of wire, but the resistor leads are much shorter. The spurious series inductance Ls of a through-hole component is typically of the order of 5 nH. At 3 MHz the measured resistance drops to 0.738 Ω which does not seem realistic. At the maximum frequency 5 MHz, the resistance measurement finally fails. The following table summarizes the settings we used.

Table 3.18. Settings: quick measurement with uncompensated Kelvin Probe set

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|---------|-----------------------|---|----------------|-------------------------|
| IA | | Equivalent Circuit | | Representation | Rs + Ls |
| IA | | Measurement Control | | Enable | ON |
| IA | | Measurement Control | | Mode | Advanced |
| IA | | Confidence Indicators | | Suppression | 100 |
| IA | | Measurement Control | | Osc Frequency | 1k, 500k, 3M, 5M |

3.6.4. Carry out the Compensation

Some of the apparent problems seen before can be attributed to the uncompensated Kelvin probe set. In order to do a compensation, open the Cal side-tab in the Impedance Analyzer tab and select the SOL (short-open-load) Compensation Sequence. It's necessary to specify the

parameters of the "load" DUT: $10\ \Omega$, and since we don't know precisely the stray capacitance, we'll enter a value of $0\ F$ as Load C. The three compensation steps can now be simply carried out by fixing the appropriate DUT (the wire for the S step, the $10\ \Omega$ resistor for the L step, or nothing for the O step) and clicking on the "Short", "Open", or "Load" button followed by "Compensate". For a precise calibration, try to keep the position of the clamps the same in all three steps and in the measurement itself. The spurious capacitance is very sensitive to the position of the clamps and the parts of the cables which are unshielded.




Figure 3.29. Impedance Analyzer tab: Cal side-tab

Each compensation step takes about a minute with the standard settings, and its progress and termination is reported in the text field below the "Compensate" button. The Status LEDs show which of the steps are completed. Once all three are done, the compensation data are transferred to the instrument. Compensation files can be saved and reloaded as necessary.

Table 3.19. Settings: perform a user compensation

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|---------|-----------------------|---|---------------------|-------------------------|
| IA | Cal | Compensation Sequence | | Mode | SOL (short-open-load) |
| IA | Cal | Compensation Sequence | | Load R (Ω) | 10 |
| IA | Cal | Compensation Sequence | | Load C (F) | 0 |
| IA | Cal | Compensation Sequence | | Step | Short / Open / Load |
| IA | Cal | Compensation Sequence | | Compensate | ON |

The left section of the Cal side-tab displays information and contains the enable button of the current user compensation and the internal calibration. The label User Compensation (or Internal Calibration) acts as a control to switch the display (the small black triangle to the bottom right of the label indicates the control). When switched to User Compensation, the compensation can easily be activated and deactivated with the Enable button. This has an immediate effect on the measurement data displayed in the Numeric, the Plotter, or the Sweeper tab.

Note

The internal calibration should normally be enabled at all times.

3.6.5. Measure with Compensation

In order to compare the results with and without compensation, we'll perform a sweep up to the maximum available frequency as shown in the previous tutorials. In the Sweeper tab, perform a linear frequency sweep from 1 kHz to 5 MHz. Repeat that once with and once without enabled compensation.

The plot in [Figure 3.30](#) We look at two selected quantities in the following plots. The Resistance (= Rep. Parameter 1) remains flat at 1.0 Ω with compensation (green), whereas it goes down below 0.4 Ω without compensation.




Figure 3.30. LabOne Sweeper showing the resistance of a 1 Ω DUT measured with compensation (green) and without (grey)

The Inductance (= Parameter 2) is relatively flat in frequency both with and without compensation, see [Figure 3.31](#). But its value is much too large without compensation. With compensation the measured value is less than 10 nH which is the expected order of magnitude, in any case it is too small to be measured with high precision and is flagged with the "Suppression" warning. Note that the lead inductance of the resistor is about 8 nH/cm. Clamping the DUT at a slightly different position and measuring again will show an effect on the measured inductance L_s, whereas the resistance R_s is largely insensitive to that.




Figure 3.31. LabOne Sweeper showing the serial inductance of a 1 Ω DUT measured with compensation (red) and without (grey)

3.7. Phase-locked Loop

Note

This tutorial is applicable to MF Instruments with the MF-PID Quad PID/PLL Controller option installed.

3.7.1. Goals and Requirements

This tutorial explains how to track the resonance frequency shift of a resonator using a phase-locked loop (PLL). To follow this tutorial, one needs to connect a resonator between Signal Output 1 and Signal Input 1.

3.7.2. Preparation

Connect the cables as shown in the figure below. Make sure that the MF Instrument is powered on and connected by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After starting LabOne the default web browser opens with the LabOne graphical user interface.




Figure 3.32. PLL connection with MF Instrument

The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (e.g. as is after pressing F5 in the browser).

3.7.3. Determine the Resonance of the Quartz

In this section you will learn first how to find the resonance of your resonator with the [Sweeper Tab](#) tool. In the Sweeper tab, one can start by defining a frequency sweep across the full instrument bandwidth and narrow down the range using multiple sweeps in order to find the resonance peak of interest. In our case, we know already that the resonance lies at around 1.8 MHz which saves us some time in finding the peak, knowing that its Q factor is rather high. The Sweeper tab and Lock-in tab settings are shown in the table below.

Note

The table below applies to instruments without the MF-MD Multi-demodulator option installed. With the option installed, the output amplitude needs to be configured in the Output Amplitudes section of the Lock-in tab.

Table 3.20. Settings: sweep the measurement frequency

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|----------------------|---|-----------------------|-------------------------|
| Lock-in | All | Signal Outputs | 1 | Amp (V) | 100.0 m / ON |
| Lock-in | All | Signal Outputs | 1 | Output 1 | ON |
| Lock-in | All | Signal Inputs | 1 | 50 Ω | ON |
| Lock-in | All | Signal Inputs | 1 | Diff | OFF |
| Lock-in | All | Demodulators | 1 | Osc | 1 |
| Lock-in | All | Demodulators | 1 | Input | Sig In 1 |
| Lock-in | All | Data Transfer | 1 | Enable | ON |
| Sweeper | Control | Horizontal | | Sweep Param. | Osc 1 Frequency |
| Sweeper | Control | Vertical Axis Groups | | Signal Type / Channel | Demod Θ / 1 |
| Sweeper | Control | Vertical Axis Groups | | Add Signal | click |
| Sweeper | Control | Vertical Axis Groups | | Signal Type / Channel | Demod R / 1 |
| Sweeper | Control | Vertical Axis Groups | | Add Signal | click |
| Sweeper | Control | Horizontal | | Start (Hz) | 1 M |
| Sweeper | Control | Horizontal | | Stop (Hz) | 3 M |
| Sweeper | History | | | Length | 2 |
| Sweeper | Control | Settings | | Dual Plot | ON |
| Sweeper | Control | Settings | | Run/Stop | ON |

We use demodulator 1 to generate the sweep signal and to demodulate the signal transmitted through the resonator. The Lock-in settings ensure that the oscillator used both for the generation and the measurement is the same (oscillator 1). In addition, the input must be set to Signal Input 1 in accordance with the connection diagram.

Once the Sweeper **Run/Stop** button is clicked, the Sweeper will repeatedly sweep the frequency response of the quartz oscillator. The History Length of 2 allows you to keep one previous sweep on the screen while adjusting the sweep range. You can use the zoom tools to get a higher resolution on the resonance peak. To redefine the start and stop frequencies for a finer sweeper range, just click the **Copy From Range** button. This will automatically paste the plot frequency range into the Start and Stop fields of the Sweeper frequency range.

Note

The sweep frequency resolution will get finer when zooming in horizontally using the **Copy From Range** button even without changing the number of points.

When a resonance peak has been found, you should get a measurement similar to the solid lines in the two figures below. The resonance fitting tool allows us to easily determine resonance parameters such as Q factor, center frequency, or peak amplitude. To use the tool, place the two X cursors to the left and right of the resonance, open the Math sub-tab of the Sweeper tab, select "Resonance" from the left drop-down menu, and click on **Add**. Repeat this operation, once with the demodulator amplitude as the active trace in the plot, and once with the demodulator phase (see Vertical Axis Groups). The tool will perform a least-squares fit to the response function of an LCR circuit. In the limit of large Q factors, this corresponds to a fit to the square root of a Lorentzian function for the amplitude, and to an inverse tangent for the phase. The exact fitting functions are documented in the section called "Cursors and Math".

The fitting curves are added as dashed lines to the plot as shown in [Figure 3.33](#) and [Figure 3.34](#). Since the two fits are independent, they may lead to different results if the resonance significantly deviates from a simple LCR circuit model, which often is the case if there is capacitive coupling between the leads. In this case, the fit to the phase curve which is clearly better than that to the amplitude curve yields a Q factor of about 12,800, and a center frequency of 1.8428 MHz.

The phase in [Figure 3.34](#) follows a typical resonator response going from +90° to -90° when passing through the resonance on a 50 Ω input. Directly at the resonance, the measured phase is close to 0°. We will use this value as a phase setpoint for the PLL. After having completed the Sweeper measurements, turn off sweeping by clicking on **Run/Stop**. This will release the oscillator frequency from the control by the Sweeper.




Figure 3.33. Amplitude of the resonator's frequency response measured with the LabOne Sweeper. Solid line are measurement data, dashed line is a fit to the response function of an LCR circuit model using the resonance fitting tool.






Figure 3.34. Phase of the resonator's frequency response measured with the LabOne Sweeper. Solid line are measurement data, dashed line is a fit to the response function of an LCR circuit model using the resonance fitting tool.

3.7.4. Resonance Tracking with the PLL

Now we know the resonance frequency and the phase measured at this frequency. We can track the drift in resonance frequency by locking on to this phase, hence the name phase-locked loop (PLL). The phase-locked loop is available in the PLL tab. There are four PID (proportional-integral-derivative) controllers in each MFLI instrument, and the first two have dual use as PLL controllers. For this tutorial, we will use PLL 1. We first set up the basic PLL 1 fields as shown in the table below, using the values from the previous measurement.

Table 3.21. Settings: set up the phase-locked loop

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|---------|---------|---|--------------------------|--------------------------|
| PLL | PLL | | 1 | Mode | PLL |
| PLL | PLL | | 1 | Auto Mode | PID Coeff |
| PLL | PLL | Input | 1 | Setpoint (deg) | 0.0 |
| PLL | PLL | Output | 1 | Output | Oscillator Frequency / 1 |
| PLL | PLL | Output | 1 | Center Freq (Hz) | 1.8428 M |
| PLL | PLL | Output | 1 | Lower / Upper Limit (Hz) | -10k / +10 k |

The upper and lower frequency (or range) relative to the Center Frequency should be chosen narrow enough so that the phase of the device follows a monotonous curve with a single crossing at the setpoint, else the feedback controller will fail to lock correctly. We select the 1st oscillator and demodulator 1 for the phase-locked loop operation. Now, we need to find suitable feedback gain parameters (P, I, D) which we do using the Advisor. Set the DUT Model to Resonator Frequency, the Target BW (Hz) to 1.0 kHz, and click on **To Advisor** to copy the Center Frequency to the resonance frequency field of the Advisor. The target bandwidth should be at least as large as the expected bandwidth of the frequency variations. In the present case, the resonator frequency is practically stable, so 1 kHz bandwidth is largely enough. Click on the **Advise** button to have the Advisor find a set of feedback gain parameters using a numerical optimization algorithm. Figure 3.35 shows a typical view of the PLL tab after the Advisor has finished. The Advisor tries to match or exceed the target bandwidth in its simulation. The achieved bandwidth

can be read from the BW (Hz) field, or directly from the 3 dB point of the simulated Bode plot on the right. The Phase Margin value of the simulation is displayed in the PM (deg) field and should exceed 45° to ensure stable feedback operation without oscillations. Once you are satisfied with the Advisor results, click on the **To PLL** button to transfer the feedback gain parameters to the physical PLL controller. To start PLL operation, click on the Enable button at the top of the PLL tab.

Table 3.22. Settings: set up and run the PID Advisor

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|---------|-----------|---|--------------------|-------------------------|
| PLL | Advisor | Advisor | 1 | Target BW (Hz) | 1 k |
| PLL | Advisor | DUT Model | 1 | DUT Model | Resonator Frequency |
| PLL | Advisor | DUT Model | 1 | Res Frequency (Hz) | 1.8 M |
| PLL | Advisor | DUT Model | 1 | Q | 12.8 k |
| PLL | Advisor | Advisor | 1 | Advise | click |




Figure 3.35. Settings and Advisor simulation in the PLL tab (typical – parameters may differ from the example)

When the PLL is locked, the green indicator next to the label Error/PLL Lock will be switched on. The actual frequency shift is shown in the field Freq Shift (Hz).

Note

At this point, it is recommended to adjust the signal input range by clicking the Auto Range button in the Lock-in tab. This often increases the signal-to-noise ratio which helps the PLL to lock to an input signal.

The easiest way to visualize the frequency drift is to use the Plotter tool. The frequency can be added to the display by using the Tree Selector to navigate to Demodulator 1 → Sample and selecting Frequency. The frequency noise increases with the PLL bandwidth, so for optimum noise performance the bandwidth should not be higher than what is required by the experiment. The frequency noise also scales inversely with the drive amplitude of the resonator.

3.8. Automatic Gain Control

Note

This tutorial is applicable to MF Instruments with the MF-PID Quad PID/PLL Controller option installed.

3.8.1. Goals and Requirements

This tutorial explains how to set up a PID controller for automatic gain control. We use the PID Advisor to simulate the step response of a feedback loop and the Data Acquisition tool to capture the physical step response of the loop. We perform the test using a quartz resonator between Signal Output 1 and Signal Input 1.

3.8.2. Preparation

Connect the cables as illustrated below. Make sure the MF Instrument is powered on, and then connect the MF Instrument through the USB to your PC, or to your local area network (LAN) where the host computer resides. After starting LabOne the default web browser opens with the LabOne graphical user interface.




Figure 3.36. PID connection with MF instrument

The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (e.g. as is after pressing F5 in the browser).

3.8.3. Automatic Gain Control

In this section you will learn how to control the output amplitude of your device under test with a PID controller. We will use a quartz resonator driven at its resonance frequency by the signal generator of the instrument, and measured with a demodulator.

If you are continuing from the [Section 3.7](#), then you can just leave the PLL enabled. Otherwise, you should know how to generate an excitation signal at the required frequency and how to measure the signal amplitude that you want to control. The device-under-test does not need to be a resonator.

As shown in the frequency response curve below, we are measuring an amplitude of about 4.0 mV at the peak of the resonance while driving with 100 mV_{pk}. The goal is to have this amplitude programmable by the user on the fly.


x10e

Figure 3.37. Amplitude of the resonator's frequency response measured with the LabOne Sweeper. Solid line are measurement data, dashed line is a fit to the response function of an LCR circuit model using the resonance fitting tool.

For setting up automatic gain control, open the PID / PLL tab in which the four available PID controllers are represented in different side-tabs. Since the first two controllers have a dual use as PLLs, we'll use PID 3 for this tutorial. We'll define the Input of the controller as the measured lock-in R signal, and the Output as the drive amplitude. The settings are shown in the table below.

Note

The table below applies to instruments without the MF-MD Multi-demodulator option installed. With the option installed, the Output 1 Amplitude channel needs to be set to the number of the demodulator used to generate the signal in the Output Amplitudes section of the Lock-in tab.

Table 3.23. Settings: Set up the PID controller

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----------|-----------|---------|---|-----------------------|-------------------------|
| PID / PLL | PID / PLL | | 3 | Mode | PID |
| PID / PLL | PID / PLL | Input | 3 | | Demod R / 1 |
| PID / PLL | PID / PLL | Input | 3 | Setpoint (V) | 10 m |
| PID / PLL | PID / PLL | Output | 3 | | Output 1 Amplitude / 1 |
| PID / PLL | PID / PLL | Output | 3 | Center (V) | 0.5 |
| PID / PLL | PID / PLL | Output | 3 | Lower/Upper Limit (V) | -0.5/+0.5 |
| PID / PLL | PID / PLL | Output | 3 | Range | 0.5 |

The next step is to select the proper feedback gain parameters (P, I, D). On the MF instrument we can do this with the help of the PID Advisor. Based on a set of mathematical models for the device under test (DUT), it can simulate the step response for a certain set of feedback gain values. The PID Advisor numerically optimizes the feedback gain parameters to obtain a step response that matches or exceeds a user-specified target bandwidth.

The list of available DUT models is found in [Section 4.18](#). In case your DUT is not well described by one of the models, the methods presented here are nonetheless useful to implement certain heuristic tuning method such as the Good Gain method (Finn Haugen, Telemark University College, Norway, 2010), as they enable measurement of the closed-loop step response.

The PID Advisor offers an efficient graphical tool for setting the feedback gain parameters manually. To access it, enable the Advanced Mode in the Display sub-tab and select PID from the Transfer Function menu. Three cursor lines will be added to the display section which represent the frequency dependence of the P, I, and D part of the PID controller transfer function. The cursors can be dragged, allowing you to define a target Bode plot. If you enable the Advisor Link button , the feedback gain parameters derived from the cursors are linked with the simulation parameters from the Advisor from where they can be transferred to the instrument.




Figure 3.38. Graphical setting of the PID parameters using the cursors. The three cursor lines with negative, zero, and positive slope correspond to the frequency dependence of the P, I, and D parts of the controller, respectively.

3.8.4. Simulating the Device Under Test

In the Advisor sub-tab, select "Resonator Amplitude" as the model of the DUT. This model is characterized by four parameters: delay, gain, center frequency, and Q. The latter two can easily be determined from a frequency response measurement in the Sweeper tab using the resonance fitting tool available in the [Math sub-tab](#) as described in [Determine the Resonance of the Quartz](#). We obtain a Q factor of ~12,800 and a center frequency of 1.8428 MHz. The delay value represents extra delays such as those coming from cables (typically 4 to 5 ns per meter). Since we use short cables these are negligible and we can leave the delay parameter at 0 s. The gain value parametrizes overall signal gain or attenuation between PID controller output and input, including unit conversion. In our case, measuring an R amplitude of 4.0 mV_{rms} on resonance while the drive amplitude is set to 100 mV_{pk}, we have a gain of 0.040.

With the Mode selector in the Advisor sub-tab, you can define which of the feedback gain parameters the Advisor uses for his optimization. E.g., when you select PI advise mode, P and I parameters are varied but D is fixed at the value presently set. In this way you can choose the most efficient way of using the Advisor: you can have everything be done by the Advisor, you can control some of the parameters manually and have the Advisor deal with the rest, or you do all the adjustments manually and use the Advisor only to simulate the outcome.

We leave the D parameter at 0 and let the Advisor run in PI mode. Enter a target BW of 1 kHz and click on the **Advise** button. The Advisor will suggest some values for P and I. The BW field indicates the bandwidth of the simulated loop, with a green lamp showing that the target bandwidth was reached or exceeded. The PM field shows the phase margin, with a green lamp indicating a stable feedback loop.

In the given example, the resonator has a bandwidth of about 140 Hz, so the target bandwidth of 1 kHz is just about within reach. However, in order to reach this value, the corresponding demodulator filter bandwidth may need adjustment. It should be larger than the target bandwidth, but not larger than necessary in order to avoid excessive noise. When enabling Auto Bandwidth (the checkbox next to the Filter BW field in the Demodulator Settings), the PID Advisor selects a suitable demodulator bandwidth which later will be transferred automatically to the demodulator.

The Bode plot on the right-hand side of the tab corresponds to the simulated closed-loop frequency response based on the P, I, and D gain values and the DUT model presently set in the Advisor sub-tab. In order to show the simulated closed-loop step response for our example as in Figure 3.39, set Display to Step Response in the Display sub-tab.

Note

In case a demodulator measurement is selected as the PID input, the Advisor will control the corresponding demodulator filter bandwidth, but not the filter order. If you encounter problems with oscillating feedback, bear in mind that low-order filters often lead to more stable feedback loop behavior because of their smaller delay.

Table 3.24. Settings: set up and run the PID Advisor

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----------|---------|----------------------|---|----------------------------|-------------------------|
| PID / PLL | Advisor | Advisor | 3 | Target BW (Hz) | 1 k |
| PID / PLL | Advisor | Advisor | 3 | Advise Mode | PI |
| PID / PLL | Advisor | Demodulator Settings | 3 | Filter BW / Auto Bandwidth | ON |
| PID / PLL | Advisor | DUT Model | 3 | DUT Model | Resonator Amplitude |
| PID / PLL | Advisor | DUT Model | 3 | Delay | 0.0 s |
| PID / PLL | Advisor | DUT Model | 3 | Gain | 0.040 |
| PID / PLL | Advisor | DUT Model | 3 | Center Frequency | 1.8 M |
| PID / PLL | Advisor | DUT Model | 3 | Q | 12.8 k |
| PID / PLL | Display | | 3 | Display | Step Response |
| PID / PLL | Advisor | Advisor | 3 | Advise | ON |






Figure 3.39. Closed-loop step response simulated with the PID Advisor

3.8.5. Measuring the Step Response

Once you are satisfied with the Advisor results, click on the **To PID** button to transfer the feedback gain parameters to the physical PID / PLL controller represented on the left. Enable the PID / PLL controller and check, e.g. using the [Section 4.6](#), whether demodulator 1 R has settled at the setpoint of 10 mV. Toggling the setpoint in the PID / PLL tab will then immediately be visible as a step in the Plotter. To capture the step response, the [Section 4.8](#) is the tool of choice. Open the DAQ tab and configure the trigger in the Settings and Grid sub-tabs according to the table below. .Settings: set up the Data Acquisition tool

Table 3.25. Settings: set up the Data Acquisition tool

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|----------|------------------|---|--------------------|-------------------------|
| DAQ | Settings | Trigger Settings | | Trigger Signal | Demod 1 R |
| DAQ | Settings | Trigger Settings | | Level (V) | 11 m |
| DAQ | Settings | Trigger Settings | | Hysteresis (V) | 0 |
| DAQ | Settings | Horizontal | | Delay (s) | -1 m |
| DAQ | Grid | Grid Settings | | Mode | Linear |
| DAQ | Grid | Grid Settings | | Duration (s) | 5 m |
| Lock-in | All | Data Transfer | 1 | Rate (Hz) / Enable | 100 k / ON |

We also increased the demodulator data transfer rate to get a high time resolution for this measurement. Start the Data Acquisition tool by clicking on **Run/Stop**. Any time you toggle the

setpoint across the Trigger Level (e.g. from 10 mV to 12 mV), a single trace will be recorded and displayed in the DAQ tab as shown in the figure below.




Figure 3.40. Closed-loop step response measured with the Data Acquisition tool

Comparing Figure 3.40 with Figure 3.39 demonstrates the excellent quantitative match between simulation and measurement.

3.9. Imaging

Note

This tutorial is applicable to all MF Instruments.

3.9.1. Goals and Requirements

This tutorial explains how to capture and display an imaging signal, i.e., a signal structured in lines and frames that can be built up to a 2-dimensional data set. To follow this tutorial, one will require a 3rd-party programmable arbitrary waveform generator to generate a realistic imaging signal with line triggers, or access to a real imaging signal including line triggers or EOL triggers e.g. from an atomic force microscope.

3.9.2. Preparation

Connect the cables as shown in the figure below. Make sure that the MF Instrument is powered on and connected by USB to your host computer or by Ethernet to your local area network (LAN) where the host computer resides. After starting LabOne the default web browser opens with the LabOne graphical user interface.




Figure 3.41. Setup for the imaging tutorial with MF Instrument

The tutorial can be started with the default instrument configuration (e.g. after a power cycle) and the default user interface settings (e.g. as is after pressing F5 in the browser).

3.9.3. Imaging Signal Properties

In this section we discuss the properties of the external signal used in this tutorial. It is most illustrative to discuss the imaging functionality based on a realistic signal generated by an arbitrary waveform generator (AWG), or even a real imaging signal. The imaging functionality of the instrument can also be tried out without external equipment, but it's not easily possible to generate a nicely structured imaging signal with the MF instrument alone. In order to facilitate the phase-locking between AWG and lock-in, an AWG with digital modulation capability and a possibility to output the phase reference signal separately from the AWG signal is helpful. Examples are the UHFAWG and the HDAWG from Zurich Instruments.

We will assume the following scanning parameters: a line scanning frequency of about 200 Hz and a line number of 256. We will furthermore assume that the imaging signal on the AWG signal output is an amplitude-modulated signal at a fixed carrier frequency of 300 kHz. This signal is wired to the Signal Input +V connector of the MF instrument. The carrier phase reference, a square wave at 300 kHz with about 1 V_{pk} amplitude, is generated on the AWG marker output 1 and is connected to the lock-in reference input Aux In 1. At the start of each line, the AWG generates a rising edge of a TTL signal generated on its marker output 2. This line trigger signal is connected to the Trigger In 1 connector of the MF instrument. The minimum trigger signal width required to correctly trigger the data acquisition is equal to the inverse demodulator sample rate used. The reason is that the state of the Trigger In 1 connector is transferred to the host computer together with the demodulator data which limits the time resolution and therefore the minimum trigger pulse width.

3.9.4. Measure the Imaging Signal

For this example, we programmed the AWG to generate a signal with an amplitude varying between 0 and about $0.6\text{ V}_{\text{rms}}$ which builds up to an image of the Zurich Instruments logo. We let the AWG run continuously, which means it will permanently generate this signal, the line trigger, and the phase reference signal. Here we will set up the lock-in amplifier with sufficiently high demodulator bandwidth and sampling rate in order to faithfully measure the imaging signal in external reference mode.

For locking to the external reference lock-in reference input, we need to select the reference input signal and change the lock-in amplifier to external reference mode. You can check in the [Section 4.13](#) whether the corresponding input connector shows a toggling signal. It may be necessary to adjust the threshold level of the input to match the TTL signal level generated by the AWG. Setting up a measurement in external reference mode is more generally described in [Section 3.2](#).

Table 3.26. Settings: enable external reference mode

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|--------------|---|--------|-------------------------|
| Lock-in | All | Demodulators | 2 | Signal | Aux In 1 |
| Lock-in | All | Demodulators | 2 | Mode | ExtRef |

We choose demodulator filter settings and sampling rate sufficiently high to measure the fast components in the signal up to several 10 kHz. You can find a more general description on selecting filter constants in [Section 3.1](#). The table below shows the settings to be made. Here we use a sampling rate of 200 kSa/s, which requires the 1GbE connection rather than USB due to its higher bandwidth.

Table 3.27. Settings: configure the demodulator

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|------------------|---|---------|-------------------------|
| Lock-in | All | Signal Input | 1 | Range | 1.2 V |
| Lock-in | All | Low-pass Filters | 1 | BW 3 dB | 30 kHz |
| Lock-in | All | Low-pass Filters | 1 | Order | 8 |
| Lock-in | All | Data Transfer | 1 | Rate | 220 kSa/s |
| Lock-in | All | Data Transfer | 1 | Enable | ON |

Now we can monitor the imaging signal as well as the line triggers in the [Section 4.6](#). Open the Plotter tab and add the demodulator R signal as well as Trigger In 1 to the plot.

Table 3.28. Settings: measure imaging signal and line trigger in the Plotter

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|---------|---------|----------------------|---|---------------|---------------------------------|
| Plotter | Control | Vertical Axis Groups | | Tree Selector | Demodulators/1/Sample/R |
| Plotter | Control | Vertical Axis Groups | | Tree Selector | Demodulators/1/Sample/Trig In 1 |
| Plotter | Control | | | Run / Stop | ON |

The Plotter should now display the continuously streamed imaging data. The figure below shows in blue the demodulator R signal, and in green the line trigger signal marking the beginning of each line. The cursors indicate a line repetition period of about 1.66 ms, and in the following, instead of displaying these data in a continuous stream in the Plotter, we would like to capture a full image frame.




Figure 3.42. Imaging signal (blue) and line trigger (green) displayed in the LabOne Plotter

3.9.5. Set up the Grid Mode

The [Section 4.8](#) with its Grid Mode is the suitable tool to capture images. In this section we go through the configuration of this tool.

The Data Acquisition tool in grid mode acquires 2-dimensional data sets with pre-defined rows and columns that are defined by a trigger timing for each line, a well-defined line number, and a well-defined line duration. The acquired data stream can be linearly interpolated to a well-defined number of data points (e.g. pixels) for each line, or it can be acquired exactly with the transfer rate of the demodulator in exact mode. It furthermore supports averaging over multiple frames.

Here we select the Trigger In 1 signal as trigger source in the Settings sub-tab. We set the hold-off time to 0 s to ensure that no triggers are lost in between successive lines. By changing the delay, we can compensate for a possible misalignment between trigger timing and line start, or to configure the Data Acquisition tool for a line end trigger, rather than line start trigger.

In the Grid sub-tab, we select a number of rows corresponding to what we have programmed on the AWG. In Exact (on-grid) mode, we select the number of columns such that the duration is sufficiently long to capture one line, but shorter than 1 line trigger period so the DAQ tool can re-arm for every new line. Here we select $N = 300$ columns, corresponding to a duration of $T = 1.36$ ms. The two numbers are related to the demodulator sampling rate $f_s = 220$ kSa/s by $T = N/f_s$.

Finally, we select the 2D display in the Control sub-tab, and we make sure to add demodulator 1 R as a displayed signal in the [Vertical Axis Groups](#) section. The DAQ tab also supports multi-channel acquisition as more signals, e.g. the phase or other demodulators can be recorded. The table below summarizes the settings.

Table 3.29. Settings: set up the grid mode

| Tab | Sub-tab | Section | # | Label | Setting / Value / State |
|-----|----------|------------------|---|----------------|-----------------------------------|
| DAQ | Settings | Trigger Settings | | Trigger Signal | Demod 1 Trig In 1 |
| DAQ | Settings | Horizontal | | Hold off time | 0 s |
| DAQ | Settings | Horizontal | | Delay | 0 s |
| DAQ | Grid | Grid Settings | | Mode | Exact (on-grid) |
| DAQ | Grid | Grid Settings | | Columns | 300 |
| DAQ | Grid | Grid Settings | | Duration | 1.36 ms (read-only in Exact mode) |
| DAQ | Grid | Grid Settings | | Rows | 256 |
| DAQ | Control | Time Domain | | Plot Type | 2D |

In order to capture one fresh frame, we shortly disable the AWG. We arm the Data Acquisition tool by clicking on **Single** to acquire a single frame with the exact number of rows specified before, and then restart the AWG. The figure below shows the captured image. The acquired data appear as an entry in the History sub-tab and can easily be saved from there.




Figure 3.43. 2D image captured by the LabOne Data Acquisition tool in Grid mode

Chapter 4. Functional Description LabOne User Interface

This chapter gives a detailed description of the functionality available in the LabOne User Interface (UI) for the Zurich Instruments MFLI. LabOne provides a data server and a web server to control the Instrument with any of the most common web browsers (e.g. Firefox, Chrome, Edge, etc.). This platform-independent architecture supports interaction with the Instrument using various devices (PCs, tablets, smartphones, etc.) even at the same time if needed.

On top of standard functionality like acquiring and saving data points, this UI provides a wide variety of measurement tools for time and frequency domain analysis of measurement data as well as for convenient servo loop implementation.

4.1. User Interface Overview

4.1.1. UI Nomenclature

This section provides an overview of the LabOne User Interface, its main elements and naming conventions. The LabOne User Interface is a browser-based UI provided as the primary interface to the MFLI instrument. Multiple browser sessions can access the instrument simultaneously and the user can have displays on multiple computer screens. Parallel to the UI the instrument can be controlled and read out by custom programs written in any of the supported languages (e.g. LabVIEW, MATLAB, Python, C) connecting through the LabOne APIs.




Figure 4.1. LabOne User Interface (default view)

The Figure 4.1[LabOne User Interface] automatically opens some tabs by default after a new UI session has been started. The UI is by default divided into two tab rows, each containing a tab structure that gives access to the different LabOne tools. Depending on display size and application, tab rows can be freely added and deleted with the control elements on the right-hand side of each tab bar. Similarly, the individual tabs can be deleted or added by selecting app icons from the side bar on the left. A click on an icon adds the corresponding tab to the display, alternatively the icon can be dragged and dropped into one of the tab rows. Moreover, tabs can be displaced by drag-and-drop within a row or across rows.

Table 4.1 gives brief descriptions and naming conventions for the most important UI items.

Table 4.1. LabOne User Interface features

| Item name | Position | Description | Contains |
|------------|--------------------------|--|--|
| side bar | left-hand side of the UI | contains app icons for each of the available tabs - a click on an icon adds or activates the corresponding tab in the active tab row | app icons |
| status bar | bottom of the UI | contains important status indicators, warning lamps, device and session information and access to the command log | status indicators |
| main area | center of the UI | accommodates all active tabs – new rows can be added and removed by using the control elements in the top right corner of each tab row | tab rows, each consisting of tab bar and the active tab area |
| tab area | inside of each tab | provides the active part of each tab consisting of settings, controls and measurement tools | sections, plots, sub-tabs, unit selections |

Further items are highlighted in Figure 4.2.




Figure 4.2. LabOne User Interface (more items)

4.1.2. Unique Set of Analysis Tools

All instruments feature a comprehensive tool set for time and frequency domain analysis for both raw signals and demodulated signals.

The app icons on the left side of the UI can be roughly divided into two categories: settings and tools.

Settings-related tabs are in direct connection of the instrument hardware allowing the user to control all the settings and instrument states.

Tools-related tabs place a focus on the display and analysis of gathered measurement data.

There is no strict distinction between settings and tools, e.g. will the Sweeper change certain demodulator settings while performing a frequency sweep. Within the tools one can often further discriminate between time domain and frequency domain analysis. Moreover, a distinction between the analysis of fast input signals - typical sampling rate of 60 MSa/s - and the measurement of orders of magnitude slower data - typical sampling rate of <200 kSa/s - derived for instance from demodulator outputs and auxiliary inputs. Table 4.2 provides a brief classification of the tools.

Table 4.2. Tools for time domain and frequency domain analysis

| | Time Domain | Frequency Domain |
|-------------------------|--------------------------|--------------------------|
| Fast signals (60 MSa/s) | Oscilloscope (Scope tab) | FFT Analyzer (Scope tab) |

| | Time Domain | Frequency Domain |
|---------------------------|------------------|----------------------------------|
| Slow signals (<200 kSa/s) | Numeric | Spectrum Analyzer (Spectrum tab) |
| | Plotter | Sweeper |
| | Data Acquisition | - |

The following table gives the overview of all app icons. Note that the selection of app icons may depend on the upgrade options installed on a given instrument.

Table 4.3. Overview of app icons and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| Lock-in | | Quick overview and access to all the settings and properties for signal generation and demodulation. |
| Lock-in MD | | Quick overview and access to all the settings and properties for signal generation and demodulation. |
| Files | | Access files on internal flash memory and USB drive. |
| Numeric | | Access to all continuously streamed measurement data as numerical values. |
| Plotter | | Displays various continuously streamed measurement data as traces over time (roll mode). |
| Scope | | Displays shots of data samples in time and frequency domain (FFT) representation. |
| DAQ | | Provides complex trigger functionality on all continuously streamed data samples and time domain display. |
| Spectrum | | Provides FFT functionality to all continuously streamed measurement data. |
| Sweeper | | Sweep frequencies, voltages, and other quantities over a defined range and display various response functions including statistical operations. |
| Aux | | Controls all settings regarding the auxiliary inputs and auxiliary outputs. |
| In/Out | | Gives access to all controls relevant for the Signal Inputs and Signal Outputs on the instrument's front. |
| DIO | | Gives access to all controls relevant for the digital inputs and outputs including the Ref/Trigger connectors. |
| Config | | Provides access to software configuration. |
| Device | | Provides instrument specific settings. |
| PID | | Features all control, analysis, and simulation capabilities of the PID controllers. |

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| MOD | | Control panel to enable (de)modulation at linear combinations of oscillator frequencies. |
| IA | | Quick overview and access to all the settings and properties for impedance measurements. |
| MDS | | Synchronize multiple instruments. |
| ZI Labs | | Experimental settings and controls. |

Table 4.4 provides a quick overview over the different status bar elements along with a short description.

Table 4.4. Status bar description

| Control/Tool | Option/Range | Description |
|--------------|-----------------|--|
| Shutdown | | Shuts down the instrument. |
| IA | grey/green | Impedance Analyzer - Green: indicates which of the impedance analyzer modules is enabled. |
| OVI | grey/yellow/red | Signal Input Overload - Red: present overload condition on the signal input also shown by the red front panel LED. Yellow: indicates an overload occurred in the past. |
| OVO | grey/yellow/red | Overload Signal Output - Red: present overload condition on the signal output. Yellow: indicates an overload occurred in the past. |
| COM | grey/red | Stall - Red: indicates that the sample transfer rates have been reset to default values to prevent severe communication failure. This is typically caused by high sample transfer rates on a slow host computer. |
| MOD | grey/green | MOD - Green: indicates which of the modulation kits is enabled. |
| PID | grey/green | PID - Green: indicates which of the PID units is enabled. Red: indicates PID unit is in PLL or ExtRef mode but is not locked. Yellow: indicates PID unit was not locked in the past. |
| PLL | grey/green | PLL - Green: indicates which of the PLLs is enabled. |
| Command log | last command | Shows the last command. A different formatting (Matlab, Python, ..) can be set in the config tab. The log is also saved in [User]\Documents\Zurich Instruments\LabOne\WebServer\Log |
| Show Log | | Show the command log history in a separate browser window. |
| Errors | Errors | Display system errors in separate browser tab. |

| Control/Tool | Option/Range | Description |
|-----------------|-----------------------|---|
| Device | devXXX | Indicates the device serial number. |
| Identify Device | | When active, device LED blinks |
| MDS | grey/green/red/yellow | Multiple device synchronization indicator. Grey: Nothing to synchronize - single device on the UI. Green: All devices on the UI are correctly synchronized. Yellow: MDS sync in progress or only a subset of the connected devices is synchronized. Red: Devices not synchronized or error during MDS sync. |
| REC | grey/red | A blinking red indicator shows ongoing data recording (related to global recording settings in the Config tab). |
| CF | grey/yellow/red | Clock Failure - Red: present malfunction of the external 10 MHz reference oscillator. Yellow: indicates a malfunction occurred in the past. |
| COM | grey/yellow/red | Packet Loss - Red: present loss of data between the device and the host PC. Yellow: indicates a loss occurred in the past. |
| COM | grey/yellow/red | Sample Loss - Red: present loss of sample data between the device and the host PC. Yellow: indicates a loss occurred in the past. |
| C | | Reset status flags: Clear the current state of the status flags |
| Full Screen | | Toggles the browser between full screen and normal mode. |

4.1.3. Plot Functionality

Several tools provide a graphical display of measurement data in the form of plots. These are multi-functional tools with zooming, panning and cursor capability. This section introduces some of the highlights.

Plot Area Elements

Plots consist of the plot area, the X range and the range controls. The X range (above the plot area) indicates which section of the wave is displayed by means of the blue zoom region indicators. The two ranges show the full scale of the plot which does not change when the plot area displays a zoomed view. The two axes of the plot area instead do change when zoom is applied.

The [mouse functionality](#) inside of a plot greatly simplifies and speeds up data viewing and navigation.

Table 4.5. Mouse functionality inside plots

| Name | Action | Description | Performed inside |
|-------------|--|-----------------------------|------------------|
| Panning | left click on any location and move around | moves the waveforms | plot area |
| Zoom X axis | mouse wheel | zooms in and out the X axis | plot area |

| Name | Action | Description | Performed inside |
|----------------------------|----------------------------------|--|--|
| Zoom Y axis | shift + mouse wheel | zooms in and out the Y axis | plot area |
| Window zoom | shift and left mouse area select | selects the area of the waveform to be zoomed in | plot area |
| Absolute jump of zoom area | left mouse click | moves the blue zoom range indicators | X and Y range, but outside of the blue zoom range indicators |
| Absolute move of zoom area | left mouse drag-and-drop | moves the blue zoom range indicators | X and Y range, inside of the blue range indicators |
| Full Scale | double click | set X and Y axis to full scale | plot area |

Each plot area contains a legend that lists all the shown signals in the respective color. The legend can be moved to any desired position by means of drag-and-drop.

The X range and Y range plot controls are described in [Table 4.6](#).

Note

Plot data can be conveniently exported to other applications such as Excel or Matlab by using LabOne's Net Link functionality, see [LabOne Net Link](#) for more information.

Table 4.6. Plot control description

| Control/Tool | Option/Range | Description |
|----------------------|--------------|--|
| Axis scaling mode | | Selects between automatic, full scale and manual axis scaling. |
| Axis mapping mode | | Select between linear, logarithmic and decibel axis mapping. |
| Axis zoom in | | Zooms the respective axis in by a factor of 2. |
| Axis zoom out | | Zooms the respective axis out by a factor of 2. |
| Rescale axis to data | | Rescale the foreground Y axis in the selected zoom area. |
| Save figure | | Generates PNG, JPG or SVG of the plot area or areas for dual plots to the local download folder. |
| Save data | | Generates a CSV file consisting of the displayed wave or histogram data (when histogram math operation is enabled). Select full scale to save the complete wave. The save data function only saves one shot at a time (the last displayed wave). |
| Cursor control | | Cursors can be switch On/Off and set to be moved both independently or one bound to the other one. |

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| Net Link | | Provides a LabOne Net Link to use displayed wave data in tools like Excel, Matlab, etc. |

Cursors and Math

The plot area provides two X and two Y cursors which appear as dashed lines inside of the plot area. The four cursors are selected and moved by means of the blue handles individually by means of drag-and-drop. For each axis, there is a primary cursor indicating its absolute position and a secondary cursor indicating both absolute and relative position to the primary cursor.

Cursors have an absolute position which does not change upon pan or zoom events. In case a cursor position moves out of the plot area, the corresponding handle is displayed at the edge of the plot area. Unless the handle is moved, the cursor keeps the current position. This functionality is very effective to measure large deltas with high precision (as the absolute position of the other cursors does not move).

The cursor data can also be used to define the input data for the mathematical operations performed on plotted data. This functionality is available in the Math sub-tab of each tool. The [Table 4.7](#) gives an overview of all the elements and their functionality. The chosen Signals and Operations are applied to the currently active trace only.

Note

Cursor data can be conveniently exported to other applications such as Excel or MATLAB by using LabOne's Net Link functionality, see [LabOne Net Link](#) for more information.

Table 4.7. Plot math description

| Control/Tool | Option/Range | Description |
|---------------|--------------|---|
| Source Select | | Select from a list of input sources for math operations. |
| | Cursor Loc | Cursor coordinates as input data. |
| | Cursor Area | Consider all data of the active trace inside the rectangle defined by the cursor positions as input for statistical functions (Min, Max, Avg, Std). |
| | Tracking | Display the value of the active trace at the position of the horizontal axis cursor X1 or X2. |
| | Plot Area | Consider all data of the active trace currently displayed in the plot as input for statistical functions (Min, Max, Avg, Std). |
| | Peak | Find positions and levels of up to 5 highest peaks in the data. |
| | Trough | Find positions and levels of up to 5 lowest troughs in the data. |
| | Histogram | Display a histogram of the active trace data within the x-axis range. The histogram is used as input to statistical functions (Avg, Std). Because of binning, the statistical functions typically yield different results than those under the selection Plot Area. |

| Control/Tool | Option/Range | Description |
|------------------|--|---|
| | Resonance | Display a curve fitted to a resonance. |
| | Linear Fit | Display a linear regression curve. |
| Operation Select | | Select from a list of mathematical operations to be performed on the selected source. Choice offered depends on the selected source. |
| | Cursor Loc: X1, X2, X2-X1, Y1, Y2, Y2-Y1, Y2 / Y1 | Cursors positions, their difference and ratio. |
| | Cursor Area: Min, Max, Avg, Std | Minimum, maximum value, average, and bias-corrected sample standard deviation for all samples between cursor X1 and X2. All values are shown in the plot as well. |
| | Tracking: Y(X1), Y(X2), ratioY, deltaY | Trace value at cursor positions X1 and X2, the ratio between these two Y values and their difference. |
| | Plot Area: Min, Max, Pk Pk, Avg, Std | Minimum, maximum value, difference between min and max, average, and bias-corrected sample standard deviation for all samples in the x axis range. |
| | Peak: Pos, Level | Position and level of the peak, starting with the highest one. The values are also shown in the plot to identify the peak. |
| | Histogram: Avg, Std, Bin Size, (Plotter tab only: SNR, Norm Fit, Rice Fit) | A histogram is generated from all samples within the x-axis range. The bin size is given by the resolution of the screen: 1 pixel = 1 bin. From this histogram, the average and bias-corrected sample standard deviation is calculated, essentially assuming all data points in a bin lie in the center of their respective bin. When used in the plotter tab with demodulator or boxcar signals, there additionally are the options of SNR estimation and fitting statistical distributions to the histogram (normal and rice distribution). |
| | Resonance: Q, BW, Center, Amp, Phase, Fit Error | A curve is fitted to a resonator. The fit boundaries are determined by the two cursors X1 and X2. Depending on the type of trace (Demod R or Demod Phase) either a Lorentzian or an inverse tangent function is fitted to the trace. The Q is the quality factor of the fitted curve. BW is the 3dB bandwidth (FWHM) of the fitted curve. Center is the center frequency. Amp gives the amplitude (Demod R only), whereas Phase returns the phase at the center frequency of the resonance (demod Phase only). The fit error is given by the normalized root-mean-square deviation. It is normalized by the range of the measured data. |
| | Linear Fit: Intercept, Slope, R ² | A simple linear least squares regression is performed using a QR decomposition routine. |

| Control/Tool | Option/Range | Description |
|----------------|------------------|--|
| | | The fit boundaries are determined by the two cursors X1 and X2. The parameter outputs are the Y-axis intercept, slope and the R ² -value, which is the coefficient of determination to determine the goodness-of-fit. |
| Add | Add | Add the selected math function to the result table below. |
| Add All | Add All | Add all operations for the selected signal to the result table below. |
| Clear Selected | Clear | Clear selected lines from the result table above. |
| Clear All | Clear All | Clear all lines from the result table above. |
| Copy | Copy | Copy selected row(s) to Clipboard as CSV |
| Unit Prefix | | Adds a suitable prefix to the SI units to allow for better readability and increase of significant digits displayed. |
| CSV | csv | Values of the current result table are saved as a text file into the download folder. |
| Net Link | Link | Provides a LabOne Net Link to use the data in tools like Excel, Matlab, etc. |
| Help | Help | Opens the LabOne User Interface help. |

Note

The standard deviation is calculated using the formula $\sqrt{\frac{1}{N-1} \sum_{i=1}^N (x_i - \bar{x})^2}$ for the unbiased estimator of the sample standard deviation with a total of N samples x_i and an arithmetic average \bar{x} . The above formula is used as is to calculate the standard deviation for the Histogram Plot Math tool. For large number of points (Cursor Area and Plot Area tools), the more accurate pairwise algorithm is used (Chan et al., "Algorithms for Computing the Sample Variance: Analysis and Recommendations", The American Statistician 37 (1983), 242-247).

Note

The fitting functions used in the Resonance Plot Math tool depend on the selected signal source. The demodulator R signal is fitted with the following function:

$$\begin{aligned} \text{R}(f) = & C + A \frac{f}{\sqrt{f^2 + \left(\frac{Q}{f_0}\right)^2}} \end{aligned}$$

where C accounts for a possible offset in the output, A is the amplitude, Q is the quality factor and f_0 is the center frequency. The demodulator ϕ signal is fitted with the following function:

$$\begin{aligned} \phi(f) = & \tan^{-1} \left(\frac{1 - \left(\frac{f}{f_0} \right)^2}{\sqrt{1 + \left(\frac{Q}{f_0} \right)^2}} \right) \end{aligned}$$

using the same parameters as above.

Tree Selector

The Tree selector allows one to access streamed measurement data in a hierarchical structure by checking the boxes of the signal that should be displayed. The tree selector also supports data selection from multiple instruments, where available. Depending on the tool, the Tree selector is either displayed in a separate Tree sub-tab, or it is accessible by a click on the  button.




Figure 4.3. Tree selector with Display drop-down menu

Vertical Axis Groups

Vertical Axis groups are available as part of the plot functionality in many of the LabOne tools. Their purpose is to handle signals with different axis properties within the same plot. Signals with different units naturally have independent vertical scales even if they are displayed in the same plot. However, signals with the same unit should preferably share one scaling to enable quantitative comparison. To this end, the signals are assigned to specific axis group. Each axis group has its own axis system. This default behavior can be changed by moving one or more signals into a new group.




Figure 4.4. Vertical Axis Group in Plotter tool

The tick labels of only one axis group can be shown at once. This is the foreground axis group. To define the foreground group click on one of the group names in the Vertical Axis Groups box. The current foreground group gets a high contrast color.

- | | |
|--|--|
| Select foreground group | Click on a signal name or group name inside the Vertical Axis Groups. If a group is empty the selection is not performed. |
| Split the default vertical axis group | Use drag-and-drop to move one signal on the field *[Drop signal here to add a new group]_. This signal will now have its own axis system. |
| Change vertical axis group of a signal | Use drag-and-drop to move a signal from one group into another group that has the same unit. |
| Group separation | In case a group hosts multiple signals and the unit of some of these signals changes, the group will be split in several groups according to the different new units. |
| Remove a signal from the group | In order to remove a signal from a group drag-and-drop the signal to a place outside of the Vertical Axis Groups box. |
| Remove a vertical axis group | A group is removed as soon as the last signal of a custom group is removed. Default groups will remain active until they are explicitly removed by drag-and-drop. If a new signal is added that matches the group properties it will be added again to this default group. This ensures that settings of default groups are not lost, unless explicitly removed. |
| Rename a vertical axis group | New groups get a default name "Group of ...". This name can be changed by double-clicking on the group name. |
| Hide/show a signal | Uncheck/check the check box of the signal. This is faster than fetching a signal from a tree again. |




Figure 4.5. Vertical Axis Group typical drag and drop moves.

Table 4.8. Vertical Axis Groups description

| Control/Tool | Option/Range | Description |
|---------------------|----------------------|---|
| Vertical Axis Group | | Manages signal groups sharing a common vertical axis. Show or hide signals by changing the check box state. Split a group by dropping signals to the field [Drop signal here to add new group]. Remove signals by dragging them on a free area. Rename group names by editing the group label. Axis tick labels of the selected group are shown in the plot. Cursor elements of the active wave (selected) are added in the cursor math tab. |
| Signal Type | Demod X, Y, R, Theta | Select signal types for the Vertical Axis Group. |
| | Frequency | |
| | Aux Input 1, 2 | |
| | HW Trigger | |
| Channel | integer value | Selects a channel to be added. |
| Add Signal | Add Signal | Adds a signal to the plot. The signal will be added to its default group. It may be moved by drag and drop to its own group. All signals within a group share a common y-axis. Select a group to bring its axis to the foreground and display its labels. |
| Window Length | 2 s to 12 h | Window memory depth. Values larger than 10 s may cause excessive memory consumption for signals with high sampling rates. Auto scale or pan causes a refresh of the display for which only data within the defined window length are considered. |

Trends

The Trends tool lets the user monitor the temporal evolution of signal features such as minimum and maximum values, or mean and standard deviation. This feature is available for the Scope , Spectrum, Plotter, and DAQ tab. Using the Trends feature, one can monitor all the parameters obtained in the [Math sub-tab](#) of the corresponding tab.

The Trends tool allows the user to analyze recorded data on a different and adjustable time scale much longer than the fast acquisition of measured signals. It saves time by avoiding post-

processing of recorded signals and it facilitates fine-tuning of experimental parameters as it extracts and shows the measurement outcome in real time.

To activate the Trends plot, enable the Trends button in the Control sub-tab of the corresponding main tab. Various signal features can be added to the plot from the Trends sub-tab in the [the section called “Vertical Axis Groups”](#). The vertical axis group of Trends has its own Run/Stop button and Length setting independent from the main plot of the tab. Since the Math quantities are derived from the raw signals in the main plot, the Trends plot is only shown together with the main plot. The Trends feature is only available in the LabOne user interface and not at the API level.




Figure 4.6. Top: main plot of the Scope tab showing the signal trace. Bottom: corresponding Trends plot tracking an average, standard deviation, and difference signal derived from the cursor positions in the main plot. The example shown is part of the HF2LI user interface. The controls of the Trends feature and their layout are very similar in all tabs and product platforms where this feature is available.

4.2. Saving and Loading Data

4.2.1. Overview

In this section we discuss how to save and record measurement data with the MFLI Instrument using the LabOne user interface. In the LabOne user interface, there are 3 ways to save data:

- Saving the data that is currently displayed in a plot
- Continuously recording data in the background
- Saving trace data in the History sub-tab

Furthermore, the History sub-tab supports loading data. In the following, we will explain these methods.

4.2.2. Saving Data from Plots

A quick way of save data from any plot is to click on the Save CSV icon  at the bottom of the plot to store the currently displayed curves as a comma-separated value (CSV) file to the download folder of your web browser. Clicking on  will save a graphics file instead.

4.2.3. Recording Data

The recording functionality allows you to store measurement data continuously, as well as to track instrument settings over time. The [Section 4.15](#) gives you access to the main settings for this function. The Format selector defines which format is used: HDF5, CSV, or MATLAB. The CSV delimiter character can be changed in the User Preferences section. The default option is Semicolon. The Time Zone setting allows you to adjust the time stamps of the saved data.

The node tree display of the Record Data section allows you to browse through the different measurement data and instrument settings, and to select the ones you would like to record. For instance, the demodulator 1 measurement data is accessible under the path of the form **Device 0000/Demodulators/Demod 1/Sample**. An example for an instrument setting would be the filter time constant, accessible under the path **Device 0000/Demodulators/Demod 1/Filter Time Constant**.

The storage location is selected in the Drive drop-down menu of the Record section. The default location is the internal flash memory of the MFLI. Alternatively, you can plug an external USB drive into one of the USB Device ports on the back panel of the MFLI. If you do so, an additional option USB 1 or USB 2 appears in the Drive drop-down menu. If you'd like to save data directly to the host computer, you can install and run the LabOne Web Server on the host computer as described in [Section 1.5](#).

Note

Storing data on the internal flash memory is only recommended for occasional use, and for storing small amounts of data. The reason is that flash memories such as the one used in the instrument support only a finite number of write cycles and may wear out under heavy use. Storing data on the host computer (see [Section 1.5](#)) or on an external USB hard drive is the safer alternative for such cases, and also offers higher speed.

Clicking on the Record checkbox will initiate the recording to the selected location. In case of demodulator and boxcar data, ensure that the corresponding data stream is enabled, as otherwise no data will be saved.




Figure 4.7. Browsing and inspecting files in the LabOne File Manager tab

In case HDF5 or MATLAB is selected as the file format, LabOne creates a single file containing the data for all selected nodes. For the CSV format, at least one file for each of the selected nodes is created from the start. At a configurable time interval, new data files are created, but the maximum size is capped at about 1 GB for easier data handling. The storage location is indicated in the Folder field of the Record Data section.

The [Section 4.17](#) is a good place to inspect CSV data files. The file browser on the left of the tab allows you to navigate to the location of the data files and offers functionalities for managing files on the drive of the MF Instrument (or your computer's drive in case you run the Web Server on the host computer). In addition, you can conveniently transfer files between the MFLI and the download folder on your host computer using the Upload/Download buttons. The file viewer on the right side of the tab displays the contents of text files up to a certain size limit. [Figure 4.7](#) shows the Files tab after recording Demodulator Sample and Filter Time Constant for a few seconds. The file viewer shows the contents of the demodulator data file.

Note

The structure of files containing instrument settings and of those containing streamed data is the same. Streaming data files contain one line per sampling period, whereas in the case of instrument settings, the file usually only contains a few lines, one for each change in the settings. More information on the file structure can be found in the LabOne Programming Manual.

4.2.4. History List

Tabs with a history list such as [Section 4.10](#), [Section 4.8](#), [Section 4.7](#), [Section 4.9](#) support feature saving, autosaving, and loading functionality. By default, the plot area in those tools displays the last 100 measurements (i.e., depending on the tool, sweep traces, scope shots, DAQ data sets, or spectra), and each measurement is represented in as a list entry in the History sub-tab. The button to the left of each list entry controls the visibility of the corresponding trace in the plot; the button to the right controls the color of the trace.¹ Double-clicking on a list entry allows you to rename it. All measurements in the history list can be saved with **Save All**. Clicking on the **Save Sel** button (note the dropdown button ▾) saves only those traces that were selected by a mouse click. Use the Control or Shift button together with a mouse click to select multiple traces. The

¹Among the mentioned tools, the Scope is exceptional: it displays the most recent acquisition, and its display color is fixed. However, the Persistence feature represents a more specialized functionality for multi-trace display.

file location can be accessed by the Open Folder button . Figure 4.8 illustrates some of these features. Figure 4.8 illustrates the data loading feature.




Figure 4.8. History sub-tab features. The entries "My measurement 1" etc. were renamed by the user. Measurement 1, 2, 3, 4 are currently displayed in the plot because their respective the left-hand-side button is enabled. Clicking on Save Sel would save "My measurement 3" and "My measurement 4" to a file, because these entries were selected (gray overlay) by a Control key + mouse click action.

Which quantities are saved depends on which signals have been added to the Vertical Axis Groups section in the **Control** sub-tab. Only data from demodulators with enabled Data Transfer in the Lock-in tab can be included in the files.

The history sub-tab supports an **autosave** functionality to store measurement results continuously while the tool is running. Autosave directories are differentiated from normal saved directories by the text "autosave" in the name, e.g. sweep_autosave_000. When running a tool continuously (button) with Autosave activated, after the current measurement (history entry) is complete, all measurements in the history are saved. The same file is overwritten each time, which means that old measurements will be lost once the limit defined by the history Length setting has been reached. When performing single measurements (button) with Autosave activated, after each measurement, the elements in the history list are saved in a new directory with an incrementing count, e.g. **sweep_autosave_001**, **sweep_autosave_002**.

Data which was saved in HDF5 file format can be loaded back into the history list. Loaded traces are marked by a prefix "loaded " that is added to the history entry name in the user interface. The **createdtimestamp** information in the header data marks the time at which the data were measured.

- Only files created by the Save button in the History sub-tab can be loaded.
- Loading a file will add all history items saved in the file to the history list. Previous entries are kept in the list.

- Data from the file is only displayed in the plot if it matches the current settings in the Vertical Axis Group section the tool. Loading e.g. PID data in the Sweeper will not be shown, unless it is selected in the Control sub-tab.
- Files can only be loaded if the devices saving and loading data are of the same product family. The data path will be set according to the device ID loading the data.

Figure 4.9 illustrates the data loading feature.




Figure 4.9. History data loading feature. Here, the file sweep_00000.h5 is loaded by drag-and-drop. The loaded data are added to the measurements in the history list.

4.2.5. Supported File Formats

HDF5

Hierarchical Data File 5 (HDF5) is a widespread memory-efficient, structured, binary, open file format. Data in this format can be inspected using the dedicated viewer [HDFview](#). HDF5 libraries or import tools are available for Python, MATLAB, LabVIEW, C, R, Octave, Origin, Igor Pro, and others. The following example illustrates how to access demodulator data from a sweep using the h5py library in Python:

```
import h5py
filename = 'sweep_00000.h5'
f = h5py.File(filename, 'r')
x = f['000/dev3025/demods/0/sample/frequency']
```

The data loading feature of LabOne supports HDF5 files, while it is unavailable for other formats.

MATLAB

The MATLAB File Format (.mat) is a proprietary file format from MathWorks based on the open HDF5 file format. It has thus similar properties as the HDF5 format, but the support for importing .mat files into third-party software other than MATLAB is usually less good than that for importing HDF5 files.

SXM

SXM is a proprietary file format by Nanonis used for SPM measurements.

ZView

ZView is a comma-separated value format adapted for impedance analysis and supported by the analysis software with the same name by Scribner Associates. Since there are many variants of this structure in use by other impedance modeling software tools, LabOne allows you to adapt the ZView format to your preferred standard using a template file. Proceed as follows:

- In the [Section 4.15](#), select ZView as Format setting for data recording.
- Enable and disable the Record checkbox. This step is only needed the first time you use the ZView format and creates a default template file.
- Open the [Section 4.17](#) and look for the file **savefile_template.txt** in the Setting folder. Use the Download button to transfer it to your PC, and modify it according to your needs (see below).
- Use the Upload button to transfer the modified file (with the same name **savefile_template.txt**) back into the Setting folder.

Any successive data recording in ZView format will adhere to this new template. The last line of the template file defines the data row format of the saved data file and is repeated for each sample. Everything above the last line defines the data file header and is written to the data file a single time. Both in the header part and in the last line, keywords of the form `${variable}` are replaced by the respective quantity or setting. Any other text in the template file is written verbatim to the data file.

The following tables list the keywords supported in the header part and in the last line of the template file.

Table 4.9. Keywords supported in the header part of the ZView template file

| Keyword | Datum |
|---|---|
| <code> \${year}, \${month}, \${day}, \${hours}, \${minutes}, \${seconds}</code> | Respective component of the current time stamp |
| <code> \${month_str}</code> | Abbreviated month name (Jan, Feb, Mar, ...) |
| <code> \${numpoints}</code> | Number of recorded data samples |
| <code> \${filename}</code> | File name |
| <code> \${grid_columns}</code> | Number of columns in Section 4.8 |
| <code> \${grid_rows}</code> | Number of rows in Section 4.8 |
| <code> \${grid_mode}</code> | Mode setting in Section 4.8 (nearest, linear, Lanczos) |
| <code> \${grid_operation}</code> | Operation setting in Section 4.8 (replace, average) |
| <code> \${grid_scan_direction}</code> | Scan direction in Section 4.8 (forward, reverse, bidirectional) |
| <code> \${grid_repetitions}</code> | Repetitions setting in Section 4.8 |

Table 4.10. Keywords supported in the last line of the ZView template file

| Keyword | Datum |
|-----------------------------|-----------------------|
| <code> \${frequency}</code> | Measurement frequency |

| Keyword | Datum |
|-----------------------------|---|
| <code> \${phasez}</code> | Impedance complex phase |
| <code> \${absz}</code> | Impedance absolute value |
| <code> \${realz}</code> | Impedance real part |
| <code> \${imagz}</code> | Impedance imaginary part |
| <code> \${param0}</code> | Representation parameter 1 |
| <code> \${param1}</code> | Representation parameter 2 |
| <code> \${drive}</code> | Drive voltage amplitude |
| <code> \${bias}</code> | DC bias voltage |
| <code> \${timestamp}</code> | Measurement time in units of the instrument clock period |
| <code> \${time_sec}</code> | Time in seconds relative to first sample |
| <code> \${count}</code> | Successive sample count |
| <code> \${flags}</code> | Integer containing bit flags for confidence indicators and device state information (see Table 4.11) |

Table 4.11. Bit assignment in `${flags}` data column

| Bit number | Condition |
|------------|--|
| 0 | Internal calibration is enabled |
| 1 | User compensation is enabled |
| 2...3 | Reserved |
| 4 | Confidence indicator: overflow on voltage signal input |
| 5 | Confidence indicator: overflow on current signal input |
| 6 | Confidence indicator: underflow on voltage signal input |
| 7 | Confidence indicator: underflow on current signal input |
| 8...10 | Reserved |
| 11 | Confidence indicator: Z too low for 2-terminal |
| 12 | Confidence indicator: suppression of first representation parameter (PARAM0) |
| 13 | Confidence indicator: suppression of second representation parameter (PARAM1) |
| 14 | Reserved |
| 15 | Confidence indicator: frequency limit of current input exceeded |
| 16 | Confidence indicator: strong compensation detected on first representation parameter (PARAM0) |
| 17 | Confidence indicator: strong compensation detected on second representation parameter (PARAM1) |
| 18...23 | Reserved |
| 24 | Confidence indicator: open detected |
| 25...31 | Reserved |

4.2.6. LabOne Net Link

Measurement and cursor data can be downloaded from the browser as CSV data. This allows for further processing in any application that supports CSV file formats. As the data is stored

internally on the web server it can be read by direct server access from other applications. Most up-to-date software supports data import from web pages or CSV files over the internet. This allows for automatic import and refresh of data sets in many applications. To perform the import the application needs to know the address from where to load the data. This link is supplied by the LabOne User Interface. The following chapter lists examples of how to import data into some commonly used applications.

The CSV data sent to the application is a snap-shot of the data set on the web server at the time of the request. Many applications support either manual or periodic refresh functionality.

Since tabs can be instantiated several times within the same user interface, the link is specific to the tab that it is taken from. Changing the session on the LabOne User Interface or removing tabs may invalidate the link.


Supported applications:

- the section called “Excel”
- the section called “MATLAB”
- the section called “Python”
- the section called “C#.NET”
- the section called “Igor Pro”
- the section called “Origin”


Excel

These instructions are for Excel 2010 (English). The procedure for other versions may differ.


1. In Excel, click on the cell where the data is to be placed. From the Data ribbon, click the "From Text" icon. The "Import Text File" dialog will appear.




2. In LabOne, click the "Link" button of the appropriate Math tab. Copy the selected text from the "LabOne Net Link" dialog to the clipboard (either with Ctrl-C or by right clicking and selecting "Copy").




3. In Excel, paste the link into the "File name" entry field of the "Import Text File" dialog and click the "Open" button. This will start the text import wizard. Ensure that the "Delimited" button is checked before clicking the "Next" button.



4. In the next dialog, select the delimiter character corresponding to that selected in LabOne (this can be found in the "Sessions" section of the Config tab). The default is semicolon. Click the "Next" button.




- In the next dialog, click on "Finish" and then "OK" in the "Import Data" dialog. The data from the Math tab will now appear in the Excel sheet.




4.2. Saving and Loading Data

6. The data in the sheet can be updated by clicking the "Refresh All" icon. To make updating the data easier, the "Import text file" dialog can be suppressed by clicking on "Properties".



| A | B | C | D | E | F | G |
|--|-----------|--------------|------|------|---|-----------------|
| 1 % Module: Math, ID: c0p1t6p1cfplotmath | | | | | | |
| 2 % Device: dev2009 | | | | | | |
| 3 % Time: 2014/03/19 16:29:22 | | | | | | |
| 4 Signal | Operation | Value | Unit | # | Description | Node |
| 5 Cursor Loc | X1 | | 0 | s | 1 Position of cursor X1 | Scope Channel 1 |
| 6 Cursor Loc | X2 | | 0 | s | 1 Position of cursor X2 | Scope Channel 1 |
| 7 Cursor Loc | X2 - X1 | | 0 | s | 1 Difference between vertical cursors X2 and X1 | Scope Channel 1 |
| 8 Cursor Loc | Y1 | | 0 | V | 1 Position of cursor Y1 | Scope Channel 1 |
| 9 Cursor Loc | Y2 | | 0 | V | 1 Position of cursor Y2 | Scope Channel 1 |
| 10 Cursor Loc | Y2 - Y1 | | 0 | V | 1 Difference between horizontal cursors Y2 and Y1 | Scope Channel 1 |
| 11 Wave | Min | -0.010742188 | V | 2560 | Minimum | Scope Channel 1 |
| 12 Wave | Max | 0.015136719 | V | 2560 | Maximum | Scope Channel 1 |
| 13 Wave | Avg | 0.002365303 | V | 2560 | Average | Scope Channel 1 |
| 14 Wave | Std | 0.003113134 | V | 2560 | Standard Deviation | Scope Channel 1 |
| 15 Wave | Int | 6.73E-09 | Vs | 2560 | Integral | Scope Channel 1 |
| 16 | | | | | | |
| 17 | | | | | | |
| 18 | | | | | | |
| 19 | | | | | | |
| 20 | | | | | | |

7. Deactivate the check box "Prompt for file name on refresh".



MATLAB

By copying the link text from the "LabOne Net Link" dialog to the clipboard, the following code snippet can be used in MATLAB to read the data.

```
textscan(urlread(clipboard('paste')),'%s%s%f%s%d%s%', 'Headerlines',
        4,'Delimiter', ';')
```

Python

The following code snippet can be used in Python 2 to read the LabOne Net Link data, where "url" is assigned to the text copied from the "LabOne Net Link" dialog.

```
import csv
import urllib2
url = "http://127.0.0.1:8006/netlink?id=c0p5t6p1cfplotmath&ziSessionId=0"
webpage = urllib2.urlopen(url)
datareader = csv.reader(webpage)
data = []
for row in datareader:
    data.append(row)
```

C#.NET

The .NET Framework offers a WebClient object which can be used to send web requests to the LabOne WebServer and download LabOne Net Link data. The string with comma separated content can be parsed by splitting the data at comma borders.


```
using System;
using System.Text;
using System.Net;

namespace ExampleCSV
{
    class Program
    {
        static void Main(string[] args)
        {
            try
            {
                WebClient wc = new WebClient();
                byte[] buffer = wc.DownloadData("http://127.0.0.1:8006/netlink?
id=c0p1t6p1cfplotmath&ziSessionId=0");
                String doc = Encoding.ASCII.GetString(buffer);
                // Parse here CSV lines and extract data
                // ...
                Console.WriteLine(doc);
            } catch (Exception e) {
                Console.WriteLine("Caught exception: " + e.Message);
            }
        }
    }
}
```


Igor Pro

These instructions are for Igor Pro 6.34A English. The procedure for other versions may differ.


1. For Igor Pro, the CSV separator has to be the comma. Set this in the LabOne Config tab as follows:




2. In Igor Pro, select the menu "Data→Load Waves→Load Waves...".




3. In the "Load Waves" dialog, click the "File..." button and paste the link text from the "LabOne Net Link" dialog into the entry field. Then click the "Tweaks..." button to open the "Load Data Tweaks" dialog.



4. Adjust values as highlighted below and click "Return". The "Loading Delimited Data" dialog will appear.



5. Click the "Load" button to read the data.




6. The data will appear in the Igor Pro main window.

| R0 Cursor Loc | | | | | | | |
|---------------|------------|-----------|-------------|------|------|--------------------|-----------------|
| Point | Signal | Operation | Value | Unit | XW | Description | Node |
| 0 | Cursor Loc | X1 | 0 | s | 1 | Position of cursor | Scope Channel 1 |
| 1 | Cursor Loc | X2 | 0 | s | 1 | Position of cursor | Scope Channel 1 |
| 2 | Cursor Loc | X2 - X1 | 0 | s | 1 | Difference between | Scope Channel 1 |
| 3 | Cursor Loc | Y1 | 0 | V | 1 | Position of cursor | Scope Channel 1 |
| 4 | Cursor Loc | Y2 | 0 | V | 1 | Position of cursor | Scope Channel 1 |
| 5 | Cursor Loc | Y2 - Y1 | 0 | V | 1 | Difference between | Scope Channel 1 |
| 6 | Wave | Min | -0.00830078 | V | 2560 | Minimum | Scope Channel 1 |
| 7 | Wave | Max | 0.012207 | V | 2560 | Maximum | Scope Channel 1 |
| 8 | Wave | Avg | 0.00209904 | V | 2560 | Average | Scope Channel 1 |
| 9 | Wave | Std | 0.00311325 | V | 2560 | Standard Deviation | Scope Channel 1 |
| 10 | Wave | Int | 5.96625e-09 | Vs | 2560 | Integral | Scope Channel 1 |
| 11 | | | | | | | |


Origin

These instructions are for Origin 9.1 English. The procedure for other versions may differ.


1. Open the import wizard by clicking on the icon highlighted below.




2. Ensure that the ASCII button is selected. Click the "..." button. See screenshot below. The "Import Multiple ASCII" dialog will appear.




3. Paste the link text from the "LabOne Net Link" dialog into the entry field highlighted below. Then click "Add File(s)" followed by "OK".



4. Back in the "Import Wizard - Source" dialog click "Finish".



5. The data will appear in the Origin main window.



4.3. Lock-in Tab

This tab is the main lock-in amplifier control panel. Users with instruments with MF-MD Multi-demodulator option installed are kindly referred to Section 4.4

4.3.1. Features

- Functional block diagram with access to main input, output and demodulator controls
- Parameter table with main input, output and demodulator controls
- Control elements for 1 configurable demodulator
- Auto ranging, scaling, arbitrary input units for both input channels
- Control for 1 oscillator
- Settings for main signal inputs and signal outputs
- Flexible choice of reference source, trigger options and data transfer rates

4.3.2. Description

The Lock-in tab is the main control center of the instrument and open after start up by default. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.12. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Lock-in | | Quick overview and access to all the settings and properties for signal generation and demodulation. |

The default view of the Lock-in tab is the parameter table view. It is accessible under the side tab labeled All and provides controls for all demodulators in the instrument. Moreover, for each individual demodulator there is a functional block diagram available. It is accessible under the side tab labeled with the corresponding demodulator number.

Parameter Table

The parameter table (see Figure 4.10) consists of 4 sections: Signal Inputs, Oscillators, Demodulators and Signal Outputs. The Demodulator section consists of two rows where the upper row offers access to all the settings of the dual phase demodulator, the second row represents the phase detector for the PLL used for external reference. The user can obtain and change the filter settings but not transfer the data to the data server.



Figure 4.10. LabOne User Interface Lock-in tab - Parameter table (All)

The **Signal Inputs section** allows the user to define all relevant settings specific to the signal entered as for example input coupling, range, etc. Some of the available options like phase

adjustment and the trigger functionality are collapsed by default. It takes one mouse click on the "+" icon in order to expand those controls. On the right-hand side of the Lock-in tab the Signal Outputs section allows defining signal amplitudes, offsets and range values.

The Scaling field below the Range field can be used to multiply the Signal Input data for instance to account for the gain of an external amplifier. In case there is a transimpedance gain of 10 V/A applied to the input signal externally, then the Scaling field can be set to 0.1 and the Units field can be set to A in order to show the actual current readings through the entire user interface. Below the Scaling field there is the AC/DC button and the $50\ \Omega$ / $10\ M\Omega$. The AC/DC button sets the coupling type: AC coupling has a high-pass cutoff frequency that can be used to block large DC signal components to prevent input signal saturation during amplification. The $50\ \Omega$ / $10\ M\Omega$ button toggles the input impedance between low ($50\ \Omega$) and high (approx. $10\ M\Omega$) input impedance. With $50\ \Omega$ input impedance, one will expect a reduction of a factor of 2 in the measured signal if the signal source also has an output impedance of $50\ \Omega$.

Note

The Signal Inputs can be set to float which means that the BNC connector shield is no longer connected to the instrument ground. This setting affects both the current input and the voltage input. It is recommended to discharge the test device before connecting or to enable this setting only after the signal source has been connected to the Signal Input in grounded mode.

The **Oscillator section** indicates the frequency of the internal oscillator. Where the Mode indicator shows Manual, the user can define the oscillator frequency manually defined by typing a frequency value in the field. In case the oscillator is referenced to an external source, the Mode indicator will show ExtRef and the frequency field is set to read-only. External reference requires a PLL to do the frequency mapping onto an internal oscillator. Successful locking is indicated by a green light right next to the frequency field.

In the following, we discuss the **Demodulators settings** in more detail. The block diagram displayed in [Figure 4.11](#) indicates the main demodulator components and their interconnection. The understanding of the wiring is essential for successfully operating the instrument.




Figure 4.11. Demodulator block diagram without MF-MD Multi-demodulator option.

The first line in the Demodulators section represents the demodulator available for measurements. The Mode column is read-only set to internal reference (Demod). The second line

represents an additional Demodulator that is reserved for the exclusive use as a phase detector when the mode is switched to external reference (ExtRef). The user can select from a number of different inputs to be used as external reference signals and the filter settings provide the user with an idea of the PLL speed. However, this second demodulator does not produce any output data that could be used for measurements. In the Input Signal column one defines the signal that is taken as input for a given demodulator. A wide choice of signals can be selected: Signal Inputs, the Trigger Inputs, the Auxiliary Inputs and Auxiliary Outputs. This allows using the instrument for many different measurement topologies. For each demodulator an additional phase shift can be introduced to the associated oscillator by entering the phase offset in the Phase column. This phase is added both to the reference channel and to the output of the demodulator. Hence, when the frequency is generated and detected using the same demodulator, signal phase and reference phase change by the same amount and no change will be visible in the demodulation result. Demodulation of frequencies that are integer multiples of any of the oscillator frequencies is achieved by entering the desired factor in the Harm column. The result of the demodulation, i.e. the amplitude and phase can be read e.g. using the Numeric tab which is described in [Section 4.5](#).

In the middle of the Lock-in tab is the Low-Pass Filters section where the filter order can be selected in the drop-down list for each demodulator and the filter bandwidth (BW 3dB) can be chosen by typing a numerical value. Alternatively, the time constant of the filter (TC) or the noise equivalent power filter bandwidth (BW NEP) can be chosen by clicking on the column's header. For example, setting the filter order to 4 corresponds to a roll off of 24 dB/oct or 80 dB/dec i.e. an attenuation of 10^4 for a tenfold frequency increase. If the Low-Pass Filter bandwidth is comparable to or larger than the demodulation frequency, the demodulator output may contain frequency components at the frequency of demodulation and its higher harmonics. In this case, the additional Sinc Filter should be enabled. It attenuates those unwanted harmonic components in the demodulator output. The Sinc Filter is useful when measuring at low frequencies, since it allows one to apply a Low-Pass Filter bandwidth closer to the demodulation frequency, thus speeding up the measurement time.

The data transfer of demodulator outputs is activated by the En button in the Data Transfer section where also the sampling rate (Rate) for each demodulator can be defined.

The Trigger section next to the Data Transfer allows for setting trigger conditions in order to control and initiate data transfer from the Instrument to the host PC by the application of logic signals (e.g. TTL) to either Trigger Input 1 or 2 on the instrument back panel.

In the **Signal Outputs section** the On buttons are used to activate the Signal Output. The Range drop-down list is used to select the proper output range setting. On the Signal Output an offset voltage (Offset) can be defined. The maximum output signal permitted is PLUSMINUS10 V.

Block Diagram

The block diagram view of the main instrument functions is also sometimes called the "Graphical Lock-in Tab". A set of indexed side tabs in the Lock-in Tab give access to a block diagram for each demodulator. The block diagrams are fully functional and provide the user with a visual feedback of what is going on inside the instrument. All control elements that are available in the Parameter Table detailed in the previous section are also present in the graphical representation.

The block diagram in [Figure 4.12](#) shows the signal path through the instrument for the case when the internal oscillator is used as reference. The Signal Inputs and Reference/Internal Frequency are shown on the left-hand side. The actual demodulation, i.e. the mixing and low-pass filtering is represented in the center of the tab. On the bottom right the user can set Signal Output parameters. On the top right there are the settings related to the output of the measurement data, either by digital means (PC Data Transfer) or by analog means (Auxiliary Outputs 1 to 4).

4.3. Lock-in Tab




Figure 4.12. LabOne User Interface Lock-in tab - Graphical Lock-in tab in Internal Reference mode

The block diagram in Figure 4.13 shows the signal path through the instrument for the case when an external reference is used. The Signal Input is described on the left side, the core of demodulation with the mixer and low-pass filter as well as the External Reference is located in the center of the tab and the Signal Outputs, the Auxiliary Outputs as well as the data transfer to the PC is sketched on the right.

Note

In order to switch between Internal Reference Mode and External Reference Mode click on the section label. The "+" symbol next to the label provides access to the phase settings of the reference.




Figure 4.13. LabOne User Interface Lock-in tab - Graphical Lock-in tab in External Reference mode

4.3.3. Functional Elements

Table 4.13. Lock-in tab

| Control/Tool | Option/Range | Description |
|--------------|--------------------|--|
| 50 Ω | OFF: 10 MΩ | Switches between 50 Ω (ON) and 10 MΩ (OFF). |
| | ON: 50 Ω | |
| Float | ON: Floating | Switches between floating (ON) and connected grounds (OFF). This setting applies both to the voltage and the current input. It is recommended to discharge the test device before connecting or to enable this |
| | OFF: GND connected | |

| Control/Tool | Option/Range | Description |
|------------------|--|--|
| | | setting only after the signal source has been connected to the Signal Input in grounded mode. |
| Range | 3.0 mV, 10 mV, 30 mV, 100 mV, 300 mV, 1 V, 3.0 V | Defines the gain of the analog input amplifier. The range should exceed the incoming signal by roughly a factor two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used. |
| On | ON / OFF | Enable Signal Input. |
| Auto | | Automatic adjustment of the Range to about two times the maximum signal input amplitude measured over about 100 ms. |
| Scaling | numeric value | Applies an arbitrary scale factor to the input signal. |
| Measurement Unit | unit acronym | Defines the physical unit of the input signal. Use *, / and ^ operators, e.g., m or m/s^2. The value in this field modifies the readout of all measurement tools in the user interface. Typical uses of this field is to make measurements in the unit before the sensor/transducer, e.g. to take an transimpedance amplifier into account and to directly read results in Ampere instead of Volts. |
| AC | ON: AC coupling | Defines the input coupling for the Signal Inputs. AC coupling inserts a high-pass filter. |
| | OFF: DC coupling | |
| Diff | OFF: Single ended voltage input | Switches between single ended (OFF) and differential (ON) measurements. |
| | ON: Differential voltage input | |
| Range | 1 nA (*) | Defines the gain of the current input amplifier. The range should exceed the incoming signal by roughly a factor two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used. Ranges marked with an asterisk (*) are only available on instruments with serial numbers MF-DEV3200 and higher. |
| | 10 nA | |
| | 100 nA (*) | |
| | 1 μA | |
| | 10 μA (*) | |
| | 100 μA | |
| | 1 mA (*) | |
| | 10 mA | |

| Control/Tool | Option/Range | Description |
|------------------|----------------|--|
| Auto | | Automatic adjustment of the Range to about two times the maximum current input amplitude measured over about 100 ms. |
| Scaling | numeric value | Applies an arbitrary scale factor to the current input. |
| Measurement Unit | unit acronym | Defines the physical unit of the current input. Use *, / and ^ operators, e.g., m or m/s^2 The value in this field modifies the readout of all measurement tools in the user interface. |
| Mode | | Indicates how the frequency of the corresponding oscillator is controlled (manual, external reference). Read only flag. |
| | Manual | The user setting defines the oscillator frequency. |
| | ExtRef | An external reference is mapped onto the oscillator frequency. |
| Frequency (Hz) | 0 to 5 MHz | Frequency control for each oscillator. |
| Locked | ON / OFF | Oscillator locked to external reference when turned on. |
| Harm | 1 to 1023 | Divides the demodulator's reference frequency by an integer factor in external reference mode. |
| Mode | | Select the reference mode (manual or external reference) or indicate the unit that uses the demodulator (e.g. PLL). |
| | ExtRef Low BW | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The demodulator bandwidth is fixed at low value. Use when automatic bandwidth adjustment interferes with a stable lock at a fixed frequency. |
| | ExtRef High BW | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The demodulator bandwidth is fixed at a high value. Use when automatic bandwidth adjustment interferes with tracking a strongly fluctuating frequency. |
| | PLL | The demodulator is used in PLL mode for frequency tracking of the signal. This function requires the MF-PID option. |
| | IA | The demodulator is used by the impedance analyzer. |
| | Manual | Default lock-in operating mode with manually set reference frequency. |
| | ExtRef | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The |

| Control/Tool | Option/Range | Description |
|-----------------|---|---|
| | | demodulator bandwidth is set automatically to adapt to the signal properties. |
| Osc | oscillator index | Connects the selected oscillator with the demodulator corresponding to this line. Number of available oscillators depends on the installed options. |
| Harm | 1 to 1023 | <p>Multiplies the demodulator's reference frequency with the integer factor defined by this field.</p> <p>If the demodulator is used as a phase detector in external reference mode (PLL), the effect is that the internal oscillator locks to the external frequency divided by the integer factor.</p> |
| Demod Freq (Hz) | 0 to 5 MHz | <p>Indicates the frequency used for demodulation and for output generation.</p> <p>The demodulation frequency is calculated with oscillator frequency times the harmonic factor. When the MF-MOD option is used linear combinations of oscillator frequencies including the harmonic factors define the demodulation frequencies.</p> |
| Phase (deg) | -180° to 180° | Phase shift applied to the reference input of the demodulator. |
| Zero |  | <p>Adjust the phase of the demodulator reference automatically in order to read zero degrees at the demodulator output.</p> <p>This action maximizes the X output, zeros the Y output, zeros the Θ output, and leaves the R output unchanged.</p> |
| Signal | | Selects the signal source to be associated to the demodulator. |
| | Curr In 1 | Current Input 1 is connected to the corresponding demodulator. |
| | Trigger 1 | Trigger 1 is connected to the corresponding demodulator. |
| | Trigger 2 | Trigger 2 is connected to the corresponding demodulator. |
| | Aux Out 1 | Auxiliary Output 1 is connected to the corresponding demodulator. |
| | Aux Out 2 | Auxiliary Output 2 is connected to the corresponding demodulator. |
| | Aux Out 3 | Auxiliary Output 3 is connected to the corresponding demodulator. |
| | Aux Out 4 | Auxiliary Output 4 is connected to the corresponding demodulator. |

| Control/Tool | Option/Range | Description |
|--------------|---------------|--|
| | Aux In 1 | Auxiliary Input 1 is connected to the corresponding demodulator. |
| | Aux In 2 | Auxiliary Input 2 is connected to the corresponding demodulator. |
| | Constant | Demodulate a constant input. This results in a sine wave of the frequency specified by the demodulator's oscillator with an amplitude of 1 (at lower frequencies; higher frequencies will be attenuated). The maximum possible frequency is limited by the demodulator sampling rate and bandwidth; use demodulator order 1 for the least attenuation in demodulator output. This signal may be used with the auxiliary outputs, PID and Threshold Unit for advanced measurement and control tasks. When the demodulator output is written to an auxiliary output, the resulting signal can also be used as a second output channel (for low frequencies). |
| | Sig In 1 | Signal Input 1 is connected to the corresponding demodulator. |
| Order | | Selects the filter roll off between 6 dB/oct and 48 dB/oct. |
| | 1 | 1st order filter 6 dB/oct |
| | 2 | 2nd order filter 12 dB/oct |
| | 3 | 3rd order filter 18 dB/oct |
| | 4 | 4th order filter 24 dB/oct |
| | 5 | 5th order filter 30 dB/oct |
| | 6 | 6th order filter 36 dB/oct |
| | 7 | 7th order filter 42 dB/oct |
| | 8 | 8th order filter 48 dB/oct |
| TC/BW Select | | Defines the display unit of the low-pass filters: time constant (TC) in seconds, noise equivalent power bandwidth (BW NEP) in Hz, 3 dB bandwidth (BW 3 dB) in Hz. |
| | TC | Defines the low-pass filter characteristic using time constant (s) of the filter. |
| | BW NEP | Defines the low-pass filter characteristic using the noise equivalent power bandwidth (Hz) of the filter. |
| | BW 3 dB | Defines the low-pass filter characteristic using the 3 dB cut-off frequency (Hz) of the filter. |
| TC/BW Value | numeric value | Defines the low-pass filter characteristic in the unit defined above. |
| Sinc | ON / OFF | Enables the sinc filter. |

| Control/Tool | Option/Range | Description |
|--------------------------------|---|--|
| | | When the filter bandwidth is comparable to or larger than the demodulation frequency, the demodulator output may contain frequency components at the frequency of demodulation and its higher harmonics. The sinc is an additional filter that attenuates these unwanted components in the demodulator output. |
| Filter Lock |  | Makes all demodulator filter settings equal (order, time constant, bandwidth). Enabling the lock copies the settings from demodulator 1 to all other demodulators. With locked filters, any modification to a filter setting is applied to all other filters, too. Releasing the lock does not change any setting. |
| Enable Streaming | ON / OFF | Enables the data acquisition and streaming of demodulated samples to the host computer for the corresponding demodulator. The streaming rate is defined in the field on the right hand side. Enabling a stream activates a corresponding element in the numeric tab and allows for demodulated samples to be visualized and analyzed in any of the LabOne measurement tools. Note: increasing number of active demodulators increases load on physical connection to the host computer. |
| Rate (Sa/s) | 0.056 Sa/s to 857 kSa/s | Defines the demodulator sampling rate, the number of samples that are sent to the host computer per second. A rate of about 7-10 higher as compared to the filter bandwidth usually provides sufficient aliasing suppression. This is also the rate of data received by LabOne Data Server and saved to the computer hard disk. This setting has no impact on the sample rate on the auxiliary outputs connectors. Note: the value inserted by the user may be approximated to the nearest value supported by the instrument. |
| Demodulator Sampling Rate Lock |  | Makes all demodulator sampling rates equal. Enabling the lock copies the settings from demodulator 1 to all other demodulators. With locked sampling rates, any modification to a sampling rate is applied to all other sampling rate fields, too. Releasing the lock does not change any setting. |
| Trigger | | Selects the acquisition mode of demodulated samples. Continuous trigger means data are streamed to the host computer at the Rate indicated. |

| Control/Tool | Option/Range | Description |
|--------------|----------------|--|
| | Trigger 1 | Selects external triggering by means of the Trigger 1 connector. Demodulated samples are sent to the host computer for each event defined in the Trig Mode field. When edge trigger is selected the rate field is greyed out and has no meaning. |
| | Trigger 2 | Selects external triggering by means of the Trigger 2 connector. Demodulated samples are sent to the host computer for each event defined in the Trig Mode field. When edge trigger is selected the rate field is greyed out and has no meaning. |
| | Trigger 1 2 | Same functionality as above, but triggering is based on a logical OR function of Trigger 1 and Trigger 2. |
| | Continuous | Selects continuous data acquisition mode. The demodulated samples are streamed to the host computer at the Rate indicated on the left hand side. In continuous mode the numerical and plotter tools are continuously receiving and display new values. |
| Trig Mode | | Defines the edge or level trigger mode for the selected Trigger input. Note: this field only appears when a non-continuous trigger is selected in the Trigger field. |
| | Rising | Selects triggered sample acquisition mode on rising edge of the selected Trigger input. |
| | Falling | Selects triggered sample acquisition mode on falling edge of the selected Trigger input. |
| | Both | Selects triggered sample acquisition mode on both edges of the selected Trigger input. |
| | High | Selects continuous sample acquisition mode on high level of the selected Trigger input. In this selection, the sample rate field determines the frequency in which demodulated samples are sent to the host computer. |
| | Low | Selects continuous sample acquisition mode on low level of the selected Trigger input. In this selection, the sample rate field determines the frequency in which demodulated samples are sent to the host computer. |
| | Vpk, Vrms, dBm | Select the unit of the displayed amplitude value. The dBm value is only valid for a system with 50 Ω termination. |
| Amp Mode | | Indicates the type or source of the waveform being generated. 'Sine' indicates a sinusoidal waveform from the internal oscillator. |
| Amp Enable | ON / OFF | Enables individual output signal amplitude. |

| Control/Tool | Option/Range | Description |
|-----------------|---|---|
| | | When the MF-MD option is used, it is possible to generate signals being the linear combination of the available demodulator frequencies. |
| 50Ω | ON / OFF | Select the load impedance between 50Ω and HiZ. The impedance of the output is always 50Ω. For a load impedance of 50Ω the displayed voltage is half the output voltage to reflect the voltage seen at the load. |
| Auto Range |   | Selects the most suited output range automatically. |
| Output Clipping | grey/red | Indicates that the specified output amplitude(s) exceeds the range setting. Signal clipping occurs and the output signal quality is degraded. Adjustment of the range or the output amplitudes is required. |
| Offset | -range to range | Defines the DC voltage that is added to the dynamic part of the output signal. |
| Add | ON / OFF | The signal supplied to the Aux Input 1 is added to the signal output. For differential output the added signal is a common mode offset. |
| Diff | ON / OFF | Switch between single-ended output (OFF) and differential output (ON). In differential mode the signal swing is defined between Signal Output +V / -V. |
| On | ON / OFF | Main switch for the Signal Output corresponding to the blue LED indicator on the instrument front panel. |
| Range | | <p>Defines the maximum output voltage that is generated by the corresponding Signal Output. This includes the potential multiple Signal Amplitudes and Offsets summed up. Select the smallest range possible to optimize signal quality.</p> <p>This setting ensures that no levels or peaks above the setting are generated, and therefore it limits the values that can be entered as output amplitudes. Therefore selected output amplitudes are clipped to the defined range and the clipping indicator turns on. If 50 Ω target source or differential output is enabled the possible maximal output range will be half.</p> |
| | 10 mV | Selects output range $\pm 10 \text{ mV}$. |
| | 100 mV | Selects output range $\pm 100 \text{ mV}$. |
| | 1 V | Selects output range $\pm 1 \text{ V}$. |
| | 10 V | Selects output range $\pm 10 \text{ V}$. |
| Output | -range to range | Defines the output amplitude as rms or peak-to-peak value. A negative amplitude value is equivalent to a phase change of 180 degree. |

4.4. Lock-in Tab (MF-MD option)

This tab is the main lock-in amplifier control panel for MFLI Instruments with the MF-MD Multi-demodulator option installed. Users with instruments without this option installed are kindly referred to [Section 4.3](#).

4.4.1. Features

- Functional block diagram with access to main input, output and demodulator controls
- Parameter table with main input, output and demodulator controls
- Controls for 4 individually configurable demodulators
- Auto ranging, scaling, arbitrary input units for both input channels
- Control for 4 oscillators
- Settings for main signal inputs and signal outputs
- Choice of reference source, trigger options and data transfer rates

4.4.2. Description

The Lock-in tab is the main control center of the instrument and open after start up by default. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.14. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Lock-in MD | | Quick overview and access to all the settings and properties for signal generation and demodulation. |

The default view of the Lock-in tab is the parameter table view. It is accessible under the side tab labeled All and provides controls for all demodulators in the instrument. Moreover, for each individual demodulator there is a functional block diagram available. It is accessible under the side tab labeled with the corresponding demodulator number.

Parameter Table

The parameter table (see [Figure 4.14](#)) consists of 5 sections: Signal Inputs, Oscillators, Demodulators, Output Amplitudes and Signal Outputs. The Demodulator section contains 4 rows each of them providing access to the settings of one dual phase demodulator. Demodulators 2 and 4 can be used for external referencing. Every demodulator can be connected to any of the possible inputs and oscillators.




Figure 4.14. LabOne User Interface Lock-in tab with MF-MD Multi-demodulator option.

The **Signal Inputs section** allows the user to define all relevant settings specific to the signal entered as for example input coupling, range, etc. Some of the available options like phase adjustment and the trigger functionality are collapsed by default. It takes one mouse click on the "+" icon in order to expand those controls. On the right-hand side of the Lock-in tab the Signal Outputs section allows to define signal amplitudes, offsets and range values.

The Scaling field below the Range field can be used to multiply the Signal Input data for instance to account for the gain of an external amplifier. In case there is a transimpedance gain of 10 V/A applied to the input signal externally, then the Scaling field can be set to 0.1 and the Units field can be set to A in order to show the actual current readings through the entire user interface.

There are two buttons below the Scaling field that can be toggled: the AC/DC button and the $50\ \Omega/10\ M\Omega$. The AC/DC button sets the coupling type: AC coupling has a high-pass cutoff frequency that can be used to block large DC signal components to prevent input signal saturation during amplification. The $50\ \Omega/10\ M\Omega$ button toggles the input impedance between low ($50\ \Omega$) and high (approx. $10\ M\Omega$) input impedance. With $50\ \Omega$ input impedance, one will expect a reduction of a factor of 2 in the measured signal if the signal source also has an output impedance of $50\ \Omega$.

Note

The Signal Inputs can be set to float which means that the BNC connector shield is no longer connected to the instrument ground. This setting affects both the current input and the voltage input. It is recommended to discharge the test device before connecting or to enable this setting only after the signal source has been connected to the Signal Input in grounded mode.

The **Oscillator section** indicates the frequency of the 4 internal oscillators . Where the Mode indicator shows Manual the user can define the oscillator frequency manually defined by typing a frequency value in the field. In case the oscillator is referenced to an external source the Mode indicator will show ExtRef and the frequency field is set to read-only. External reference requires a PLL to do the frequency mapping onto an internal oscillator. Successful locking is indicated by a green light right next to the frequency field.

The next section contains the **Demodulators settings**. The block diagram displayed in Figure 4.15 indicates the main demodulator components and their interconnection. The understanding of the wiring is essential for successfully operating the instrument.




Figure 4.15. Demodulator block diagram with MF-MD Multi-demodulator option.

Every line in the Demodulators section represents one demodulator. The Mode column is read-only for all demodulators except 2 and 4, which can be set to either internal reference (Demod) or external reference mode (ExtRef). When internal reference mode is selected, it is possible to demodulate the input signal with 4 demodulators simultaneously at 4 independent frequencies and using different filter settings. For external reference mode, one demodulator is used for the reference recovery and a few settings are greyed-out, and therefore 3 demodulators remain for simultaneous measurements. In the Input Signal column one defines the signal that is taken as input for the demodulator. A wide choice of signals can be selected: Signal Inputs, the Trigger Inputs, the Auxiliary Inputs and Auxiliary Outputs. This allows to use the instrument for many different measurement topologies.

For each demodulator an additional phase shift can be introduced to the associated oscillator by entering the phase offset in the Phase column. This phase is added both, to the reference channel and the output of the demodulator. Hence, when the frequency is generated and detected using the same demodulator, signal phase and reference phase change by the same amount and no change will be visible in the demodulation result. Demodulation of frequencies that are integer multiples of any of the oscillator frequencies is achieved by entering the desired factor in the Harm column. The demodulator readout can be obtained using the Numeric tab which is described in [Section 4.5](#).

In the middle of the Lock-in tab is the Low-Pass Filters section where the filter order can be selected in the drop down list for each demodulator and the filter bandwidth (BW 3dB) can chosen by typing a numerical value. Alternatively the time constant of the filter (TC) or the noise equivalent power filter bandwidth (BW NEP) can be chosen by clicking on the column's header. For example, setting the filter order to 4 corresponds to a roll off of 24 dB/oct or 80 dB/dec i.e. an attenuation of 10^4 for a tenfold frequency increase. If the Low-Pass Filter bandwidth is comparable to or larger than the demodulation frequency, the demodulator output may contain frequency components at the frequency of demodulation and its higher harmonics. In this case, the additional Sinc Filter can be enabled. It attenuates those unwanted harmonic components in the demodulator output. The Sinc Filter is also useful when measuring at low frequencies, since it allows to apply a Low-Pass Filter bandwidth closer to the demodulation frequency, thus speeding up the measurement time.

The data transfer of demodulator outputs is activated by the En button in the Data Transfer section where also the sampling rate (Rate) for each demodulator can be defined.

The Trigger section next to the Data Transfer allows for setting trigger conditions in order to control and initiate data transfer from the Instrument to the host PC by the application of logic signals (e.g. TTL) to either Trigger Input 1 or 2 on the back panel.

The **Output Amplitudes section** is only available for Instruments with the MF-MD option installed and allows for the flexible adjustment of output amplitudes of different demodulators and their summation on the Signal Output. In order to avoid signal clipping the sum of amplitudes of each signal output needs to be smaller than the range defined in the Signal Outputs section on the right. By clicking the headline of each column one can switch between amplitude definitions in terms of root mean square values, peak-to-peak values or even units of dBm, when the $50\ \Omega$ option in the Signal Output section is activated. In the **Signal Outputs section** the On buttons allow to activate the Signal Output of the front panel. The Range drop down list is used to select the proper output range setting. On the Signal Output a digital offset voltage (Offset) can be defined. The maximum output signal permitted is PLUSMINUS10 V.

Block Diagram

The block diagram view of the main instrument functions is also sometimes called the "Graphical Lock-in Tab". Depending on how many demodulators are available in the instrument a set of numbered side tabs are available giving access to a Graphical Lock-in Tab for each demodulator. The block diagrams are fully functional and provide the user with a visual feedback of what is

going on inside the instrument. All control elements that are available in the Parameter Table detailed in the previous section are also present in the graphical representation.

The block diagram in Figure 4.16 describes the signal path throughout the instrument for the case when the internal oscillator is used as reference. The Signal Inputs and Reference/Internal Frequency are described on the left side, the core of demodulation with the mixer and low-pass filter is located in the center of the tab and the Signal Outputs, the Auxiliary Outputs as well as the data transfer to the PC is sketched on the right.




Figure 4.16. LabOne User Interface Lock-in tab - Graphical Lock-in tab in Internal Reference mode

The block diagram in Figure 4.17 describes the signal path throughout the instrument for the case when an external reference is used. This setting is only available for demodulator 2/4. In order to map an external frequency to any of the oscillators, go to the Reference section of demodulator 2/4 and change the mode to ExtRef. This demodulator will then be used as a phase detector within the phase-locked loop. The software will choose the appropriate filter settings according to the frequency and properties of the reference signal. Once a demodulator is used to map an external frequency on to one of the internal oscillators, it is no longer available for other measurements.




Figure 4.17. LabOne User Interface Lock-in tab - Graphical Lock-in tab in External Reference mode

4.4.3. Functional Elements

Table 4.15. Lock-in MF tab

| Control/Tool | Option/Range | Description |
|--------------|--------------------|--|
| 50 Ω | OFF: 10 MΩ | Switches between 50 Ω (ON) and 10 MΩ (OFF). |
| | ON: 50 Ω | |
| Float | ON: Floating | Switches between floating (ON) and connected grounds (OFF). This setting applies both to the voltage and the current input. It is recommended to discharge the test device before connecting or to enable this setting only after the signal source has been |
| | OFF: GND connected | |

| Control/Tool | Option/Range | Description |
|------------------|---|--|
| | | connected to the Signal Input in grounded mode. |
| Range | 3.0 mV, 10 mV, 30 mV, 100 mV, 300 mV, 1 V, 3.0 V | Defines the gain of the analog input amplifier. The range should exceed the incoming signal by roughly a factor two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used. |
| On | ON / OFF | Enable Signal Input. |
| Auto | | Automatic adjustment of the Range to about two times the maximum signal input amplitude measured over about 100 ms. |
| Scaling | numeric value | Applies an arbitrary scale factor to the input signal. |
| Measurement Unit | unit acronym | Defines the physical unit of the input signal. Use *, / and ^ operators, e.g., m or m/s^2. The value in this field modifies the readout of all measurement tools in the user interface. Typical uses of this field is to make measurements in the unit before the sensor/transducer, e.g. to take an transimpedance amplifier into account and to directly read results in Ampere instead of Volts. |
| AC | ON: AC coupling OFF: DC coupling | Defines the input coupling for the Signal Inputs. AC coupling inserts a high-pass filter. |
| Diff | OFF: Single ended voltage input ON: Differential voltage input | Switches between single ended (OFF) and differential (ON) measurements. |
| Range | 1 nA (*) 10 nA 100 nA (*) 1 μA 10 μA (*) 100 μA 1 mA (*) 10 mA | Defines the gain of the current input amplifier. The range should exceed the incoming signal by roughly a factor two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used. Ranges marked with an asterisk (*) are only available on instruments with serial numbers MF-DEV3200 and higher. |
| Auto | | Automatic adjustment of the Range to about two times the maximum current input amplitude measured over about 100 ms. |

| Control/Tool | Option/Range | Description |
|------------------|----------------|--|
| Scaling | numeric value | Applies an arbitrary scale factor to the current input. |
| Measurement Unit | unit acronym | Defines the physical unit of the current input. Use *, / and ^ operators, e.g., m or m/s^2 The value in this field modifies the readout of all measurement tools in the user interface. |
| Mode | | Indicates how the frequency of the corresponding oscillator is controlled (manual, external reference). Read only flag. |
| | Manual | The user setting defines the oscillator frequency. |
| | ExtRef | An external reference is mapped onto the oscillator frequency. |
| Frequency (Hz) | 0 to 5 MHz | Frequency control for each oscillator. |
| Locked | ON / OFF | Oscillator locked to external reference when turned on. |
| Harm | 1 to 1023 | Divides the demodulator's reference frequency by an integer factor in external reference mode. |
| Mode | | Select the reference mode (manual or external reference) or indicate the unit that uses the demodulator (e.g. PLL). |
| | ExtRef Low BW | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The demodulator bandwidth is fixed at low value. Use when automatic bandwidth adjustment interferes with a stable lock at a fixed frequency. |
| | ExtRef High BW | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The demodulator bandwidth is fixed at a high value. Use when automatic bandwidth adjustment interferes with tracking a strongly fluctuating frequency. |
| | PLL | The demodulator is used in PLL mode for frequency tracking of the signal. This function requires the MF-PID option. |
| | IA | The demodulator is used by the impedance analyzer. |
| | Manual | Default lock-in operating mode with manually set reference frequency. |
| | ExtRef | The demodulator is used for external reference mode and tracks the frequency of the selected reference input. The demodulator bandwidth is set automatically to adapt to the signal properties. |

| Control/Tool | Option/Range | Description |
|-----------------|---|---|
| Osc | oscillator index | Connects the selected oscillator with the demodulator corresponding to this line. Number of available oscillators depends on the installed options. |
| Harm | 1 to 1023 | <p>Multiplies the demodulator's reference frequency with the integer factor defined by this field.</p> <p>If the demodulator is used as a phase detector in external reference mode (PLL), the effect is that the internal oscillator locks to the external frequency divided by the integer factor.</p> |
| Demod Freq (Hz) | 0 to 5 MHz | <p>Indicates the frequency used for demodulation and for output generation.</p> <p>The demodulation frequency is calculated with oscillator frequency times the harmonic factor. When the MF-MOD option is used linear combinations of oscillator frequencies including the harmonic factors define the demodulation frequencies.</p> |
| Phase (deg) | -180° to 180° | Phase shift applied to the reference input of the demodulator. |
| Zero |  | <p>Adjust the phase of the demodulator reference automatically in order to read zero degrees at the demodulator output.</p> <p>This action maximizes the X output, zeros the Y output, zeros the Θ output, and leaves the R output unchanged.</p> |
| Signal | | Selects the signal source to be associated to the demodulator. |
| | Curr In 1 | Current Input 1 is connected to the corresponding demodulator. |
| | Trigger 1 | Trigger 1 is connected to the corresponding demodulator. |
| | Trigger 2 | Trigger 2 is connected to the corresponding demodulator. |
| | Aux Out 1 | Auxiliary Output 1 is connected to the corresponding demodulator. |
| | Aux Out 2 | Auxiliary Output 2 is connected to the corresponding demodulator. |
| | Aux Out 3 | Auxiliary Output 3 is connected to the corresponding demodulator. |
| | Aux Out 4 | Auxiliary Output 4 is connected to the corresponding demodulator. |
| | Aux In 1 | Auxiliary Input 1 is connected to the corresponding demodulator. |

| Control/Tool | Option/Range | Description |
|--------------|---------------|--|
| | Aux In 2 | Auxiliary Input 2 is connected to the corresponding demodulator. |
| | Constant | Demodulate a constant input. This results in a sine wave of the frequency specified by the demodulator's oscillator with an amplitude of 1 (at lower frequencies; higher frequencies will be attenuated). The maximum possible frequency is limited by the demodulator sampling rate and bandwidth; use demodulator order 1 for the least attenuation in demodulator output. This signal may be used with the auxiliary outputs, PID and Threshold Unit for advanced measurement and control tasks. When the demodulator output is written to an auxiliary output, the resulting signal can also be used as a second output channel (for low frequencies). |
| | Sig In 1 | Signal Input 1 is connected to the corresponding demodulator. |
| Order | | Selects the filter roll off between 6 dB/oct and 48 dB/oct. |
| | 1 | 1st order filter 6 dB/oct |
| | 2 | 2nd order filter 12 dB/oct |
| | 3 | 3rd order filter 18 dB/oct |
| | 4 | 4th order filter 24 dB/oct |
| | 5 | 5th order filter 30 dB/oct |
| | 6 | 6th order filter 36 dB/oct |
| | 7 | 7th order filter 42 dB/oct |
| | 8 | 8th order filter 48 dB/oct |
| TC/BW Select | | Defines the display unit of the low-pass filters: time constant (TC) in seconds, noise equivalent power bandwidth (BW NEP) in Hz, 3 dB bandwidth (BW 3 dB) in Hz. |
| | TC | Defines the low-pass filter characteristic using time constant (s) of the filter. |
| | BW NEP | Defines the low-pass filter characteristic using the noise equivalent power bandwidth (Hz) of the filter. |
| | BW 3 dB | Defines the low-pass filter characteristic using the 3 dB cut-off frequency (Hz) of the filter. |
| TC/BW Value | numeric value | Defines the low-pass filter characteristic in the unit defined above. |
| Sinc | ON / OFF | Enables the sinc filter. When the filter bandwidth is comparable to or larger than the demodulation frequency, the demodulator output may contain frequency components at the frequency of |

| Control/Tool | Option/Range | Description |
|--------------------------------|---|--|
| | | demodulation and its higher harmonics. The sinc is an additional filter that attenuates these unwanted components in the demodulator output. |
| Filter Lock |  | Makes all demodulator filter settings equal (order, time constant, bandwidth). Enabling the lock copies the settings from demodulator 1 to all other demodulators. With locked filters, any modification to a filter setting is applied to all other filters, too. Releasing the lock does not change any setting. |
| Enable Streaming | ON / OFF | Enables the data acquisition and streaming of demodulated samples to the host computer for the corresponding demodulator. The streaming rate is defined in the field on the right hand side. Enabling a stream activates a corresponding element in the numeric tab and allows for demodulated samples to be visualized and analyzed in any of the LabOne measurement tools. Note: increasing number of active demodulators increases load on physical connection to the host computer. |
| Rate (Sa/s) | 0.056 Sa/s to 857 kSa/s | Defines the demodulator sampling rate, the number of samples that are sent to the host computer per second. A rate of about 7-10 higher as compared to the filter bandwidth usually provides sufficient aliasing suppression. This is also the rate of data received by LabOne Data Server and saved to the computer hard disk. This setting has no impact on the sample rate on the auxiliary outputs connectors. Note: the value inserted by the user may be approximated to the nearest value supported by the instrument. |
| Demodulator Sampling Rate Lock |  | Makes all demodulator sampling rates equal. Enabling the lock copies the settings from demodulator 1 to all other demodulators. With locked sampling rates, any modification to a sampling rate is applied to all other sampling rate fields, too. Releasing the lock does not change any setting. |
| Trigger | | Selects the acquisition mode of demodulated samples. Continuous trigger means data are streamed to the host computer at the Rate indicated. |
| | Trigger 1 | Selects external triggering by means of the Trigger 1 connector. Demodulated samples are sent to the host computer for each event |

| Control/Tool | Option/Range | Description |
|----------------|----------------|--|
| | | defined in the Trig Mode field. When edge trigger is selected the rate field is greyed out and has no meaning. |
| | Trigger 2 | Selects external triggering by means of the Trigger 2 connector. Demodulated samples are sent to the host computer for each event defined in the Trig Mode field. When edge trigger is selected the rate field is greyed out and has no meaning. |
| | Trigger 1 2 | Same functionality as above, but triggering is based on a logical OR function of Trigger 1 and Trigger 2. |
| | Continuous | Selects continuous data acquisition mode. The demodulated samples are streamed to the host computer at the Rate indicated on the left hand side. In continuous mode the numerical and plotter tools are continuously receiving and display new values. |
| Trig Mode | | Defines the edge or level trigger mode for the selected Trigger input. Note: this field only appears when a non-continuous trigger is selected in the Trigger field. |
| | Rising | Selects triggered sample acquisition mode on rising edge of the selected Trigger input. |
| | Falling | Selects triggered sample acquisition mode on falling edge of the selected Trigger input. |
| | Both | Selects triggered sample acquisition mode on both edges of the selected Trigger input. |
| | High | Selects continuous sample acquisition mode on high level of the selected Trigger input. In this selection, the sample rate field determines the frequency in which demodulated samples are sent to the host computer. |
| | Low | Selects continuous sample acquisition mode on low level of the selected Trigger input. In this selection, the sample rate field determines the frequency in which demodulated samples are sent to the host computer. |
| Amplitude Unit | Vpk, Vrms, dBm | Select the unit of the displayed amplitude value. The dBm value is only valid for a system with 50 Ω termination. |
| Amp Mode | | Indicates the type or source of the waveform being generated. 'Sine' indicates a sinusoidal waveform from the internal oscillator. |
| Amp Enable | ON / OFF | Enables individual output signal amplitude. When the MF-MD option is used, it is possible to generate signals being the linear |

| Control/Tool | Option/Range | Description |
|-----------------|-----------------|---|
| | | combination of the available demodulator frequencies. |
| Amp (V) | -range to range | <p>Defines the output amplitude for each demodulator frequency as rms or peak-to-peak value.</p> <p>A negative amplitude value is equivalent to a phase change of 180 degree. Linear combination of multiple amplitude settings on the same output are clipped to the range setting. Note: the value inserted by the user may be approximated to the nearest value supported by the Instrument.</p> |
| 50Ω | ON / OFF | Select the load impedance between 50Ω and HiZ. The impedance of the output is always 50Ω. For a load impedance of 50Ω the displayed voltage is half the output voltage to reflect the voltage seen at the load. |
| Auto Range | | Selects the most suited output range automatically. |
| Output Clipping | grey/red | Indicates that the specified output amplitude(s) exceeds the range setting. Signal clipping occurs and the output signal quality is degraded. Adjustment of the range or the output amplitudes is required. |
| Offset | -range to range | Defines the DC voltage that is added to the dynamic part of the output signal. |
| Add | ON / OFF | The signal supplied to the Aux Input 1 is added to the signal output. For differential output the added signal is a common mode offset. |
| Diff | ON / OFF | Switch between single-ended output (OFF) and differential output (ON). In differential mode the signal swing is defined between Signal Output +V / -V. |
| On | ON / OFF | Main switch for the Signal Output corresponding to the blue LED indicator on the instrument front panel. |
| Range | | <p>Defines the maximum output voltage that is generated by the corresponding Signal Output. This includes the potential multiple Signal Amplitudes and Offsets summed up. Select the smallest range possible to optimize signal quality.</p> <p>This setting ensures that no levels or peaks above the setting are generated, and therefore it limits the values that can be entered as output amplitudes. Therefore selected output amplitudes are clipped to the defined range and the clipping indicator turns on. If 50 Ω target source or differential output is enabled the possible maximal output range will be half.</p> |

4.4. Lock-in Tab (MF-MD option)

| Control/Tool | Option/Range | Description |
|--------------|--------------|------------------------------------|
| | 10 mV | Selects output range ± 10 mV. |
| | 100 mV | Selects output range ± 100 mV. |
| | 1 V | Selects output range ± 1 V. |
| | 10 V | Selects output range ± 10 V. |

4.5. Numeric Tab

The Numeric tab provides a powerful time domain based measurement display as introduced in [Unique Set of Analysis Tools](#). It is available on all MFLI instruments.

4.5.1. Features

- Display of demodulator output data and other streamed data, e.g. auxiliary inputs, demodulator frequencies
- Graphical and numerical range indicators
- Polar and Cartesian formats
- Support for Input Scaling and Input Units

4.5.2. Description

The Numeric tab serves as the main numeric overview display of multiple measurement data. The display can be configured by both choosing the values displayed and also rearrange the display tiles by drag-and-drop. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.16. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| Numeric |  | Access to all continuously streamed measurement data as numerical values. |

The numeric tab (see [Figure 4.18](#)) is divided into a display section on the left and a configuration section on the right. The configuration section is further divided into a number of sub-tabs.




Figure 4.18. LabOne UI: Numeric tab

The numeric tab can be deployed to display the demodulated signal, phase, frequency as well as the signal levels at the auxiliary inputs. By default, the user can display the demodulated data either in polar coordinates (R, Θ) or in Cartesian coordinates (X, Y) which can be toggled using the presets. To display other measurement quantities as available from any of the presets simply click on the tree tab next to the preset tab. The desired display fields can be selected under each demodulator's directory tree structure.

4.5.3. Functional Elements

Table 4.17. Numeric tab: Presets sub-tab

| Control/Tool | Option/Range | Description |
|-----------------|--------------------------|---|
| Select a Preset | | Select numerical view based on a preset. Alternatively, the displayed value may also selected based on tree elements. |
| | Enabled Impedances | Shows impedance, model parameters, and frequency. |
| | PID Errors | Shows error of all PID. |
| | Demods Polar | Shows R and Phase of all demodulators. |
| | Enabled Demods Polar | Shows R and Phase of enabled demodulators. |
| | Demods Cartesian | Shows X and Y of all demodulators. |
| | Enabled Demods Cartesian | Shows X and Y of enabled demodulators. |
| | Demods R | Shows R of all demodulators. |
| | Unpopulated | Shows no signals. |
| | Manual | If additional signals are added or removed the active preset gets manual. |

For the Tree sub-tab please see the section called "Tree Selector".

Table 4.18. Numeric tab: Settings sub-tab

| Control/Tool | Option/Range | Description |
|----------------|---|---|
| Name | text label | Name of the selected plot(s). The default name can be changed to reflect the measured signal. |
| Mapping | | Mapping of the selected plot(s) |
| | Lin | Enable linear mapping. |
| | Log | Enable logarithmic mapping. |
| | dB | Enable logarithmic mapping in dB. |
| Scaling | Manual/Full Scale | Scaling of the selected plot(s) |
| Zoom To Limits |  | Adjust the zoom to the current limits of the displayed histogram data. |
| Start Value | numeric value | Start value of the selected plot(s). Only visible for manual scaling. |
| Stop Value | numeric value | Stop value of the selected plot(s). Only visible for manual scaling. |

4.6. Plotter Tab

The Plotter is one of the powerful time domain measurement tools as introduced in [Unique Set of Analysis Tools](#) and is available on all MFLI instruments.

4.6.1. Features

- Vertical axis grouping for flexible axis scaling
- Polar and Cartesian data format
- Histogram and Math functionality for data analysis
- 4 cursors for data analysis
- Support for Input Scaling and Input Units

4.6.2. Description

The Plotter serves as graphical display for time domain data in a roll mode, i.e. continuously without triggering. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.19. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Plotter | | Displays various continuously streamed measurement data as traces over time (roll mode). |

The Plotter tab (see [Figure 4.19](#)) is divided into a display section on the left and a configuration section on the right.




Figure 4.19. LabOne UI: Plotter tab

The Plotter can be used to monitor the evolution of demodulated data and other streamed data continuously over time. Just as in the numeric tab any continuously streamed quantity can be displayed, for instance R , Θ , X , Y , frequency, and others. New signals can be added by either using the presets in the Control sub-tab or by going through the tree and selecting the signals of interest in the tree structure. The vertical and horizontal axis can be displayed in Lin, Log or dB scale. The Plotter display can be zoomed in and out with the magnifier symbols, or through Man (Manual), Auto (Automatic) and FS (Full Scale) button settings (see also [Plot Functionality](#)). The maximum duration data is kept in the memory can be defined as window length parameter

in the Settings sub-tab. The window length also determines the file size for the Record Data functionality.

Note

Setting the window length to large values when operating at high sampling rates can lead to memory problems at the computer hosting the data server.

The sampling rate of the demodulator data is determined by the Rate value in Sa/s set in the Lock-in tab . The Plotter data can be continuously saved to disk by clicking the record button in the Config tab which will be indicated by a green Recording (REC) LED in the status bar. See [Section 4.2](#) for more information on data saving.

4.6.3. Functional Elements

Table 4.20. Plotter tab: Control sub-tab

| Control/Tool | Option/Range | Description |
|-----------------|--------------------------|---|
| Run/Stop | Run/Stop | Start and stop continuous data plotting (roll mode) |
| Select a Preset | | Select a pre-defined group signals. A signal group is defined by a common unit and signal type. They should have the same scaling behavior as they share a y-axis. Split a group if the signals have different scaling properties. |
| | Enabled Impedances | Shows impedance, model parameters, and frequency. |
| | PID Errors | Selects the error of all PID. |
| | Enabled Demods R | Selects the amplitude of all enabled demodulators. |
| | Enabled Demods Cartesian | Selects X and Y of all enabled demodulators. |
| | Enabled Demods Polar | Selects amplitude and phase of all enabled demodulators. |
| | Unpopulated | Shows no signals. |
| | Manual | Selects the signals as defined in the tree sub-tab. |

For the Vertical Axis Groups, please see [the table "Vertical Axis Groups description"](#) in the section called "[Vertical Axis Groups](#)".

For the Math sub-tab please see [the table "Plot math description"](#) in the section called "[Cursors and Math](#)".

4.7. Scope Tab

The Scope is a powerful time domain and frequency domain measurement tool as introduced in [Unique Set of Analysis Tools](#) and is available on all MFLI instruments.

4.7.1. Features

- One input channel with 16 kSa of memory; upgradable to two channels with 2.5 MSa memory per channel (MF-DIG option)
- 16 bit nominal resolution
- Segmented recording (requires MF-DIG option)
- Colorscale display for imaging (requires MF-DIG option)
- 24 bit high-definition mode (MF-DIG option)
- Fast Fourier Transform (FFT): up to 60 MHz span, spectral density and power conversion, choice of window functions
- Sampling rates from 1.83 kSa/s to 60 MSa/s; up to 270 μ s acquisition time at 60 MSa/s or 8.9 s at 1.83 kSa/s
- 8 signal sources including Signal Inputs (I/V) and Trigger Inputs; up to 8 trigger sources and 2 trigger methods
- Independent hold-off, hysteresis, pre-trigger and trigger level settings
- Support for Input Scaling and Input Units

4.7.2. Description

The Scope tab serves as the graphical display for time domain data. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.21. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| Scope |  | Displays shots of data samples in time and frequency domain (FFT) representation. |




Figure 4.20. LabOne UI: Scope tab - Time domain

The Scope tab consists of a plot section on the left and a configuration section on the right. The configuration section is further divided into a number of sub-tabs. It gives access to a single-

channel oscilloscope that can be used to monitor a choice of signals in the time or frequency domain. Hence the X axis of the plot area is time (for time domain display, [Figure 4.20](#)) or frequency (for frequency domain display, [Figure 4.22](#)). It is possible to display the time trace and the associated FFT simultaneously by opening a second instance of the Scope tab. The Y axis displays the selected signal that can be modified and scaled using the arbitrary input unit feature found in the Lock-in tab.

The Scope records data from a single channel at up to 60 MSa/s. The channel can be selected among the two Signal Inputs, Auxiliary Inputs, Trigger Inputs and Demodulator Oscillator Phase. The Scope records data sets of up to 16 kSa samples in the standard configuration, which corresponds to an acquisition time of 270 μ s at the highest sampling rate.

The product of the inverse sampling rate and the number of acquired points (Length) determines the total recording time for each shot. Hence, longer time intervals can be captured by reducing the sampling rate. The Scope can perform sampling rate reduction either using decimation or BW Limitation as illustrated in [Figure 4.21](#). BW Limitation is activated by default, but it can be deactivated in the Advanced sub-tab. The figure shows an example of an input signal at the top, followed by the Scope output when the highest sample rate of 60 MSa/s is used. The next signal shows the Scope output when a rate reduction by a factor of 4 (i.e. 15 MSa/s) is configured and the rate reduction method of decimation is used. For decimation, a rate reduction by a factor of N is performed by only keeping every Nth sample and discarding the rest. The advantage to this method is its simplicity, but the disadvantage is that the signal is undersampled because the input filter bandwidth of the MFLI instrument is fixed at 7 MHz. As a consequence, the Nyquist sampling criterion is no longer satisfied and aliasing effects may be observed. The default rate reduction mechanism of BW Limitation is illustrated by the lowermost signal in the figure. BW Limitation means that for a rate reduction by a factor of N, each sample produced by the Scope is computed as the average of N samples acquired at the maximum sampling rate. The effective signal bandwidth is thereby reduced and aliasing effects are largely suppressed. As can be seen from the figure, with a rate reduction by a factor of 4, every output sample is simply computed as the average of 4 consecutive samples acquired at 60 MSa/s.




Figure 4.21. Illustration of how the Scope output is generated in BW Limitation and decimation mode when the sampling rate is reduced from the default of 60 MSa/s to 15 MSa/s

The frequency domain representation is activated in the Control sub-tab by selecting Freq Domain FFT as the Horizontal Mode. It allows the user to observe the spectrum of the acquired shots of samples. All controls and settings are shared between the time domain and frequency domain representations.

The Scope supports averaging over multiple shots. The functionality is implemented by means of an exponential moving average filter with configurable filter depth. Averaging helps to suppress noise components that are uncorrelated with the main signal. It is particularly useful in combination with the Frequency Domain FFT mode where it can help to reveal harmonic signals and disturbances that might otherwise be hidden below the noise floor.




Figure 4.22. LabOne UI: Scope tab - Frequency domain

The Trigger sub-tab offers all the controls necessary for triggering on different signal sources. When the trigger is enabled, then oscilloscope shots are acquired whenever the trigger conditions are met. Trigger and Hysteresis levels can be indicated graphically in the plot. A disabled trigger is equivalent to continuous oscilloscope shot acquisition.

Digitizer upgrade option

The MF-DIG Digitizer option greatly enhances the performance of the Scope with the addition of the following features

- Simultaneous recording of two Scope channels
- Memory depth of 5 MSa for both Scope channels
- Additional input signal sources (Demodulator X, Y, R, and Θ)
- Segmented recording
- Imaging support with colorscale display
- XY display of two channels
- Trigger gating
- Resolution increase up to 24 bit with high-definition (HD) mode
- Additional trigger input sources that allow for cross-domain triggering
- Additional trigger/marker output sources based on the state of the Scope
- Continuous scope data streaming

This additional functionality can be enabled on any MFLI instrument with an option key. Please contact Zurich Instruments to get more information. The following sections explain the Digitizer features in more detail.

Two channels and extended memory depth

The MF-DIG option enables simultaneous dual-channel recording. This allows for very exact relative timing measurements. With the XY display, it's possible to plot two signals against each other, e.g. for quick visualization of phase offsets or characteristic curves. Each channel can be assigned a different signal source. Trigger settings, sampling rate, and recording length settings are shared between both channels. An increased shot length of up to 5 MSa compared to the standard 16 kSa allows for longer recording times and FFTs with finer frequency resolution for the same frequency span.

Additional input sources

Besides the Signal Input, Trigger Input, Auxiliary Input, and Oscillator Phase the MF-DIG option also allows for recording of Demodulator X, Y, R, and Θ signals. This functionality is very powerful in that it allows short bursts to be recorded with very high sampling rates. In order to optimally use the vertical resolution, the upper and lower limit of these input signals should be chosen appropriately. Before sampling, a scaling and an offset are applied to the input signal in order to get 16 bit resolution between the lower and upper limit. The applied scaling and offset values are transferred together with the scope data, which allows for recovery of the original physical signal strength in absolute values. For directly sampled input signals like the Signal Inputs or Trigger Inputs, the limits are read-only values and reflect the selected input range.

Segmented data recording and imaging

The segmented data recording mode allows for intermediate storage of a burst of up to 1024 scope shots, called segments, in the scope memory. In this way, the Scope does not have to wait after each shot until the data transfer from the scope memory to the internal computer is completed. In segmented data recording mode, the Scope provides a two-dimensional color scale display of the data particularly useful for imaging applications. When used over the API, the data of each shot will contain information on the segment number.

High-definition mode

Sampling rate reduction with BW Limitation brings the advantage of increasing the available vertical resolution beyond the 16 bit resolution of the ADC effectively up to 23.5 bit (high-definition mode). [Table 4.22](#) shows the nominal scope resolution depending on the sampling rate.

Table 4.22. Scope resolution increase with MF-DIG Digitizer option

| Scope Sampling Frequency | Scope vertical resolution (with MF-DIG option) |
|--------------------------|--|
| 60 MSa/s | 16 bits |
| 30 MSa/s | 16.5 bits |
| 15 MSa/s | 17 bits |
| 7.5 MSa/s | 17.5 bits |
| 3.75 MSa/s | 18 bits |
| 1.88 MSa/s | 18.5 bits |
| 938 kSa/s | 19 bits |
| 469 kSa/s | 19.5 bits |
| 234 kSa/s | 20 bits |
| 117 kSa/s | 20.5 bits |
| 58.6 kSa/s | 21 bits |
| 29.3 kSa/s | 21.5 bits |
| 14.6 kSa/s | 22 bits |
| 7.32 kSa/s | 22.5 bits |
| 3.66 kSa/s | 23 bits |
| 1.83 kSa/s | 23.5 bits |

Trigger gating

With the MF-DIG option installed the user can make full use of the Trigger Engine. If trigger gating is enabled, a trigger event will only be accepted if the gating input is active.

Additional trigger input sources

By using a Demodulator signal as trigger source, the Scope can be used in a cross-domain triggering mode. This allows, for example, for time domain signals to be recorded in a synchronous fashion triggered by the result from analyzing a signal in the frequency domain by means of a demodulator.

Note

Choose a negative delay (pre-trigger) to compensate for the delay introduced by the Demodulator.

Scope state output on Trigger Output

The MF-DIG option extends the list of available Trigger Outputs by the six elements: Scope Trigger, Scope Armed, Scope Active and their logically inverse signals. The Trigger Output signals are controlled on the DIO tab ([Section 4.13](#)). [Figure 4.23](#) shows an illustration of the signal that will be generated on the Trigger Output when one of the six new Scope-related sources is selected. An example input signal is shown at the top of the figure. It is assumed that the Scope is configured to trigger on this input signal on a rising edge crossing the level indicated by the stippled line.




Figure 4.23. Illustration of the signal that will appear on the Trigger Output when one of the six Scope related sources is selected.

The Scope can be thought of as having a state, which changes over time. The state is shown below the input signal in the figure. When the Scope is completely inactive, it is said to be in the Idle state. When the user then activates the Scope, it will transition into a Buffer state. In this state the Scope will start to record the input signal. It will remain in this state until sufficient data has been recorded to fulfill the user requirement for recording data prior to the trigger point as controlled by the trigger Reference and Delay fields in the user interface. Once sufficient data has been recorded, the Scope will transition to the Armed state. In this state the Scope is ready to accept the trigger signal. Note that the Scope will continue to record data for as long as it is in the Armed state, and that if no trigger is defined, the Scope will simply pass straight through the Armed state. Once the input signal passes the Trigger level the Scope will trigger, and at the same time its state will change from Armed to Active. The Scope will remain in the Active state, where it also records data, until sufficient data has been recorded to fulfill the Length requirement configured in the user interface. Once enough data has been acquired, the Scope will transition back into the Idle state where it will wait for the time configured with the Hold-off time before it either starts the next measurement automatically (in case Run is active) or waits for the user to reactivate it.

The trigger source selector allows information about the Scope state to be reproduced on the Trigger Output in a number of ways. The signal that will appear on the output is shown with the six bottommost traces in the figure. Note that these traces are shown as digital signals with symbolic values of logic 0 and 1. These values will of course be actual voltages when measured on the device itself.

First, if Scope Trigger is selected then the trigger output will have a signal that is asserted, which means that it goes high, when the scope triggers, i.e. changes from the Armed to the Active state. The signal will normally have a very short duration and, therefore, it is shown with an arrow in the

figure. The duration can be increased by means of the Width input field, which can be found next to the Output Signal selector on the DIO tab. If Scope/Trigger is selected, then the same signal will appear on the output, but it will simply be inverted logically.

Next, if the Scope Armed source is selected, the trigger output will be asserted as long as the Scope is in the Armed state. Again, this means that the Scope has recorded enough data to proceed with the acquisition and is waiting for the trigger condition to become satisfied. In this example, since a rising edge trigger is defined, the trigger condition becomes satisfied when the input signal goes from below the trigger level to above the trigger level.

Similarly, if Scope /Armed is selected, the trigger output will be asserted (i.e. at logic 1) whenever the Scope is in a state different from the Armed state. The same explanation holds for the remaining two configuration options, except here the trigger output is asserted when the Scope is in the Active state or when it is not in the Active state.

4.7.3. Functional Elements

Table 4.23. Scope tab: Control sub-tab

| Control/Tool | Option/Range | Description |
|------------------------------|---|---|
| Single | Single | Acquires a single shot of samples. |
| Force | Force | Force a trigger event. |
| Length Mode | | Switches between length and duration display. |
| | Length (pts) | The scope shot length is defined in number of samples. The duration is given by the number of samples divided by the sampling rate. The MF-DIG option greatly increases the available length. |
| | Duration (s) | The scope shot length is defined as a duration. The number of samples is given by the duration times the sampling rate. |
| Length (pts) or Duration (s) | numeric value | Defines the length of the recorded scope shot. Use the Length Mode to switch between length and duration display. |
| Channel 1/2 |  | Selects the signal source for the corresponding scope channel. Navigate through the tree view that appears and click on the required signal. Note: Channel 2 requires the DIG option. |
| Min | numeric value | Lower limit of the scope full scale range. For demodulator, PID, Boxcar, and AU signals the limit should be adjusted so that the signal covers the specified range to achieve optimal resolution. |
| Max | numeric value | Upper limit of the scope full scale range. For demodulator, PID, Boxcar, and AU signals the limit should be adjusted so that the signal covers the specified range to achieve optimal resolution. |
| Enable | ON / OFF | Activates the display of the corresponding scope channel. Note: Channel 2 requires the DIG option. |

| Control/Tool | Option/Range | Description |
|----------------|----------------------------|---|
| Run/Stop | Run/Stop | Runs the scope/FFT continuously. |
| Mode | Time Domain | Switches between time and frequency domain display. |
| | Freq Domain (FFT) | |
| Sampling Rate | 916 Sa/s to 60 MSa/s | Defines the sampling rate of the scope. The numeric values are rounded for display purposes. The exact values are equal to the base sampling rate divided by 2^n , where n is an integer. |
| Average Filter | | Enable Exponential Moving Average (EMA) filter that is applied when the average of several scope shots is computed and displayed. |
| | Off | Averaging is turned off. |
| | Exponential Moving Average | Consecutive scope shots are averaged with an exponential weight. |
| Averages | integer value | The number of shots required to reach 63% settling. Twice the number of shots yields 86% settling. |
| Reset | R | Resets the averaging filter. |

For the Vertical Axis Groups, please see [the table "Vertical Axis Groups description" in the section called "Vertical Axis Groups"](#).

Table 4.24. Scope tab: Trigger sub-tab

| Control/Tool | Option/Range | Description |
|-----------------|---|---|
| Enable | ON / OFF | When triggering is enabled scope data are acquired every time the defined trigger condition is met. If disabled, scope shots are acquired continuously. |
| Signal |  | Selects the trigger source signal. Navigate through the tree view that appears and click on the required signal. |
| Level (V) | trigger signal range (negative values permitted) | Defines the trigger level. |
| Hysteresis Mode | | Selects the mode to define the hysteresis strength. The relative mode will work best over the full input range as long as the analog input signal does not suffer from excessive noise. |
| | Hysteresis (V) | Selects absolute hysteresis. |
| | Hysteresis (%) | Selects a hysteresis relative to the adjusted full scale signal input range. |
| Hysteresis (V) | trigger signal range (positive values only) | Defines the voltage the source signal must deviate from the trigger level before the trigger is rearmed again. Set to 0 to turn it off. The sign is defined by the Edge setting. |

| Control/Tool | Option/Range | Description |
|-----------------------|---|---|
| Hysteresis (%) | numeric percentage value (positive values only) | Hysteresis relative to the adjusted full scale signal input range. A hysteresis value larger than 100% is allowed. |
| Show Level | ON / OFF | If enabled shows the trigger level as grey line in the plot. The hysteresis is indicated by a grey box. The trigger level can be adjusted by drag and drop of the grey line. |
| Trigger Gating | | Select the signal source used for trigger gating if gating is enabled. This feature requires the MF-DIG option. |
| | Trigger In 1 High | Only trigger if the Trigger Input 1 is at high level. |
| | Trigger In 1 Low | Only trigger if the Trigger Input 1 is at low level. |
| | Trigger In 2 High | Only trigger if the Trigger Input 2 is at high level. |
| | Trigger In 2 Low | Only trigger if the Trigger Input 2 is at low level. |
| Trigger Gating Enable | ON / OFF | If enabled the trigger will be gated by the trigger gating input signal. This feature requires the MF-DIG option. |
| Holdoff Mode | | Selects the holdoff mode. |
| | Holdoff (s) | Holdoff is defined as time. |
| | Holdoff (events) | Holdoff is defined as number of events. |
| Holdoff (events) | 1 to 1048575 | Defines the trigger event number that will trigger the next recording after a recording event. A value one will start a recording for each trigger event. |
| Reference (%) | percent value | Trigger reference position relative to the plot window. Default is 50% which results in a reference point in the middle of the acquired data. |
| Delay (s) | numeric value | Trigger position relative to reference. A positive delay results in less data being acquired before the trigger point, a negative delay results in more data being acquired before the trigger point. |
| Enable | ON / OFF | Enable segmented scope recording. This allows for full bandwidth recording of scope shots with a minimum dead time between individual shots. This functionality requires the DIG option. |
| Segments | 1 to 32768 | Specifies the number of segments to be recorded in device memory. The maximum scope shot size is given by the available memory divided by the number of segments. This functionality requires the DIG option. |
| Shown Trigger | integer value | Displays the number of triggered events since last start. |
| Trigger | grey/green/yellow | When flashing, indicates that new scope shots are being captured and displayed in the plot |

| Control/Tool | Option/Range | Description |
|------------------|--------------------------------|---|
| | | area. The Trigger must not necessarily be enabled for this indicator to flash. A disabled trigger is equivalent to continuous acquisition. Scope shots with data loss are indicated by yellow. Such an invalid scope shot is not processed. |
| Slope | None | Select the signal edge that should activate the trigger. |
| | Rising or falling edge trigger | |
| | Rising edge trigger | |
| | Falling edge trigger | |
| Holdoff (s) | numeric value | Defines the time before the trigger is rearmed after a recording event. |
| Plot Type | | Select the plot type. |
| | None | No plot displayed. |
| | 2D | Display defined number of grid rows as one 2D plot. |
| | Row | Display only the trace of index defined in the Active Row field. |
| | 2D + Row | Display 2D and row plots. |
| Active Row | integer value | Set the row index to be displayed in the Row plot. |
| Track Active Row | ON / OFF | If enabled, the active row marker will track with the last recorded row. The active row control field is read-only if enabled. |
| Palette | Viridis | Select the colormap for the current plot. |
| | Inferno | |
| | Balance | |
| | Turbo | |
| | Grey | |
| | Solar | |
| Colorscale | ON / OFF | Enable/disable the colorscale bar display in the 2D plot. |
| Mapping | | Mapping of colorscale. |
| | Lin | Enable linear mapping. |
| | Log | Enable logarithmic mapping. |
| | dB | Enable logarithmic mapping in dB. |
| Scaling | Full Scale/Manual/Auto | Scaling of colorscale. |
| Clamp To Color | ON / OFF | When enabled, grid values that are outside of defined Min or Max region are painted with Min or Max color equivalents. When disabled, Grid values that are outside of defined Min or Max values are left transparent. |
| Start | numeric value | Lower limit of colorscale. |

| Control/Tool | Option/Range | Description |
|--------------|---------------|--|
| | | Only visible for manual scaling. |
| Stop | numeric value | Upper limit of colorscale. Only visible for manual scaling. |
| | | |

Table 4.25. Scope tab: Advanced sub-tab

| Control/Tool | Option/Range | Description |
|------------------|----------------------------|--|
| BW Limit | | Selects between sample decimation and sample averaging. Averaging avoids aliasing, but may conceal signal peaks. Channel 2 requires the DIG option. |
| | OFF | Selects sample decimation for sample rates lower than the maximal available sampling rate. |
| | ON | Selects sample averaging for sample rates lower than the maximal available sampling rate. |
| Enable | ON / OFF | Enable scope streaming for the specified channel. This allows for continuous recording of scope data on the plotter and streaming to disk. Note: scope streaming requires the DIG option. |
| X Axis | | Select the x-axis for xy-plot display mode. |
| | Time/Freq | The xy-plot mode is off. The x-axis is either time or frequency. |
| | Channel 1 | The xy-plot is enabled with the first channel used for the x-axis. |
| | Channel 2 | The xy-plot is enabled with the second channel used for the x-axis. |
| FFT Window | Rectangular | Seven different FFT windows to choose from. Each window function results in a different trade-off between amplitude accuracy and spectral leakage. Please check the literature to find the window function that best suits your needs. |
| | Hann | |
| | Hamming | |
| | Blackman Harris | |
| | Exponential (ring-down) | |
| | Cosine (ring-down) | |
| | Cosine squared (ring-down) | |
| Resolution (Hz) | mHz to Hz | Spectral resolution defined by the reciprocal acquisition time (sample rate, number of samples recorded). |
| Spectral Density | ON / OFF | Calculate and show the spectral density. If power is enabled the power spectral density value is calculated. The spectral density is used to analyze noise. |
| Power | ON / OFF | Calculate and show the power value. To extract power spectral density (PSD) this |

| Control/Tool | Option/Range | Description |
|--------------|----------------------|--|
| | | button should be enabled together with Spectral Density. |
| Persistence | ON / OFF | Keeps previous scope shots in the display. The color scheme visualizes the number of occurrences at certain positions in time and amplitude by a multi-color scheme. |
| Rate | 1.83 kHz to 3.75 MHz | Streaming rate of the scope channels. The streaming rate can be adjusted independent from the scope sampling rate. The maximum rate depends on the interface used for transfer. Note: scope streaming requires the DIG option. |

Table 4.26. Scope tab: History sub-tab

| Control/Tool | Option/Range | Description |
|--------------|------------------|---|
| History | History | Each entry in the list corresponds to a single trace in the history. The number of traces displayed in the plot is limited to 20. Use the toggle buttons to hide or show individual traces. Use the color picker to change the color of a trace in the plot. Double click on a list entry to edit its name. |
| Length | integer value | Maximum number of records in the history. The number of entries displayed in the list is limited to the 100 most recent ones. |
| Clear All | Clear All | Remove all records from the history list. |
| Clear | Clear | Remove selected records from the history list. |
| Load file | | Load data from a file into the history. Loading does not change the data type and range displayed in the plot, this has to be adapted manually if data is not shown. |
| Name | | Enter a name which is used as a folder name to save the history into. An additional three digit counter is added to the folder name to identify consecutive saves into the same folder name. |
| Auto Save | | Activate autosaving. When activated, any measurements already in the history are saved. Each subsequent measurement is then also saved. The autosave directory is identified by the text "autosave" in the name, e.g. "sweep_autosave_001". If autosave is active during continuous running of the module, each successive measurement is saved to the same directory. For single shot operation, a new directory is created containing all measurements in the history. Depending on the file format, the measurements are either appended to the same file, or saved in |

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| | | individual files. For HDF5 and ZView formats, measurements are appended to the same file. For MATLAB and SXM formats, each measurement is saved in a separate file. |
| File Format | | Select the file format in which to save the data. |
| Save | Save | Save the traces in the history to a file accessible in the File Manager tab. The file contains the signals in the Vertical Axis Groups of the Control sub-tab. The data that is saved depends on the selection from the pull-down list. Save All: All traces are saved. Save Sel: The selected traces are saved. |

For the Math sub-tab please see [the table "Plot math description"](#) in the section called "Cursors and Math".

4.8. Data Acquisition Tab

The Data Acquisition tool is one of the powerful time domain measurement tools as introduced in [Unique Set of Analysis Tools](#) and is available on all MFLI instruments . This tab used to be named Software Trigger tab in previous versions of the LabOne software.

4.8.1. Features

- Time-domain and frequency domain display for all continuously streamed data
- Capture and color scale display of imaging data
- Frame averaging and pixel interpolation
- Automatic trigger level determination
- Display of multiple traces
- Adjustable record history
- Mathematical toolkit for signal analysis

4.8.2. Description

The Data Acquisition tab features display and recording of shot-wise and imaging data sets upon a trigger event. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.27. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| DAQ | | Provides complex trigger functionality on all continuously streamed data samples and time domain display. |

The Data Acquisition tab (see [Figure 4.24](#)) is divided into a display section on the left and a configuration section on the right. The configuration section is further divided into a number of sub-tabs.




Figure 4.24. LabOne UI: Data Acquisition tab

The Data Acquisition tool brings the trigger functionality of a scope with FFT capability to the demodulator signals and other streamed data. The user can choose between a variety of different trigger and display options in the time and frequency domain.

Use the **Control** sub-tab to configure which signals are measured, both in time and in frequency domain. Measurement signals can be added to the Vertical Axis Groups section as described in [Vertical Axis Groups](#). There is one vertical axis group for each the time domain and the frequency domain data.

The trigger condition is configured in the **Settings** sub-tab. Among the selection of Trigger Types provided here, Edge and Pulse are applicable to analog trigger sources such as demodulator data, auxiliary voltages, or oscillator frequencies. The trigger time resolution is enhanced above the sampling rate of the analog data by using interpolation. Instead of manually setting a Trigger Level, you can click on **Find** to have LabOne find a value by analyzing the data stream. In case of noisy trigger sources, both the Bandwidth and the Hysteresis setting can help preventing false trigger events. The Bandwidth setting provides a configurable low-pass filter applied to the trigger source. When enabling this function, be sure to choose a sufficiently high bandwidth to resolve the signal feature that should be triggered upon, i.e., the signal edge or pulse. The Bandwidth setting does not affect the recorded data.

For trigger sources with a slowly varying offset, the Tracking Edge and Tracking Pulse Trigger Types provide continuous adjustment of the Level and Hysteresis. In Tracking mode, the Bandwidth setting plays a different role than for the Edge and Pulse trigger types. Here, the Bandwidth should be chosen sufficiently low to filter out all fast features and only let pass the slow offset.

The Horizontal section of the Settings sub-tab contains the settings for shot Duration and Delay (negative delays correspond to pre-trigger time). Also minimum and maximum pulse width for the Pulse and Tracking Pulse trigger types are defined here.

The **Grid** sub-tab provides imaging functionality to capture and display two-dimensional data sets organized in frames consisting of rows and columns. By default, the number of rows is 1, which means the Data Acquisition tool operates similar to a scope. With a Rows setting larger than 1, every newly captured shot of data is assigned to a row until the number of rows is reached and the frame is complete. After completion of a full frame, the new data either replace the old or averaging is performed, according to the selected Operation and Repetitions setting. On the horizontal axis, the Duration of a shot is divided into a number of samples specified with the Columns setting. The Mode settings provides the functionality for post-processing of the streamed data for interpolation, resampling, and alignment with the trigger event. This is particularly helpful when capturing data from several sources, e.g. demodulators and PID controllers. As illustrated in [Figure 4.25](#), in such situation the streamed data don't lie on the same temporal grid by default. This can be changed by setting Mode to Linear or Nearest. In these modes, the streams from several sources will be upsampled to match the sampling rate and temporal grid of the fastest data stream. This means data processing after saving becomes more convenient, however note that the actual streamed data rate is not increased, and the data don't gain in time resolution. A two-dimensional color scale image of the data can be enabled and controlled in the Display section. The display features configurable scaling, range, and color scale.

With enabled grid mode, the data of a completed frame after averaging appear as a list entry in the **History** sub-tab. See [History List](#) for more details on how data in the history list can be managed and stored.




Figure 4.25. Samples from different sources configured with different rates: demodulator 1 at 2N kSa/s, demodulator 2 at N kSa/s and PID Error 1 at M kSa/s (N not divisible by M). Although each stream consists of equidistantly spaced samples in time, the sample timestamps from different streams are not necessarily aligned due to the different sampling rates

4.8.3. Functional Elements

Table 4.28. DAQ tab: Control sub-tab

| Control/Tool | Option/Range | Description |
|--------------|-----------------|---|
| Run/Stop | Run/Stop | Start and stop the Data Acquisition tool |
| Single | Single | Run the Data Acquisition tool once (record Count trigger events) |
| Force | Force | Forces a single trigger event. |
| Triggered | grey/green | When green, indicates that new trigger shots are being captured and displayed in the plot area. |

For the Vertical Axis Groups, please see [the table "Vertical Axis Groups description"](#) in the section called "Vertical Axis Groups".

Table 4.29. DAQ tab: Settings sub-tab

| Control/Tool | Option/Range | Description |
|----------------|--------------|--|
| Trigger Signal | | Source signal for trigger condition. Navigate through the tree view that appears and click on the required signal. |
| Trigger Type | | Select the type of trigger to use. Selectable options depend on the selected trigger signal. |
| | Continuous | Continuous triggering. |
| | Edge | Analog edge triggering based on high and low level. Hysteresis on the levels and low-pass filtering can be used to reduce the risk of wrong trigger for noisy trigger signals. |
| | Digital | Digital triggering on the 32-bit DIO lines. The bit value defines the trigger condition. The bit mask controls the bits that are used for trigger evaluation. When using a Positive Edge |

| Control/Tool | Option/Range | Description |
|--------------|----------------------------|--|
| | | trigger setting, a trigger event occurs as soon as the equality (DIO Value)AND(Bit Mask) = (Bits)AND(Bit Mask) is fulfilled (and was not previously fulfilled). In order to trigger on DIO0 set bit value to 1 and bit mask to 1; to trigger on DIO1 set bit value to 2 and bit mask to 2. |
| | Pulse | Triggers if a pulse on an analog signal is within the min and max pulse width. Pulses can be defined as either low to high then high to low (positive), the reverse (negative) or both. |
| | Tracking Edge | Edge triggering with automatic adjustment of trigger levels to compensate for drifts. The tracking speed is controlled by the bandwidth of the low-pass filter. For this filter noise rejection can only be achieved by level hysteresis. |
| | HW Trigger | Trigger on one of the four trigger inputs. Ensure that the trigger level and the trigger coupling is correctly adjusted. The trigger input state can be monitored on the plotter. |
| | Tracking Pulse | Pulse triggering with automatic adjustment of trigger levels to compensate for drifts. The tracking speed is controlled by the bandwidth of the low-pass filter. For this filter noise rejection can only be achieved by level hysteresis. |
| Pulse Type | Positive/Negative/ Both | Select between negative, positive or both pulse forms in the signal to trigger on. |
| Trigger Edge | Positive/Negative/ Both | Triggers when the trigger input signal is crossing the trigger level from either high to low, low to high or both. This field is only displayed for trigger type Edge, Tracking Edge and Event Count. |
| Bits | 0 to $2^{32}-1$ | Specify the value of the DIO to trigger on. All specified bits have to be set in order to trigger. This field is only displayed for trigger type Digital. |
| Bit Mask | 0 to $2^{32}-1$ | Specify a bit mask for the DIO trigger value. The trigger value is bits AND bit mask (bitwise). This field is only displayed for trigger type Digital. |
| Level | full signal range | Specify the trigger level value. |
| Find | Find | Automatically find the trigger level based on the current signal. |
| Hysteresis | full signal range | The hysteresis is important to trigger on the correct edge in the presence of noise. The hysteresis is applied below the trigger level for positive trigger edge selection. It is applied above for negative trigger edge selection, and on both sides for triggering on both edges. |

| Control/Tool | Option/Range | Description |
|--------------------|--|--|
| Count | integer number | Number of trigger events to record (in Single mode) |
| Trigger progress | 0% to 100% | The percentage of triggers already acquired (in Single mode) |
| Bandwidth (Hz) | 0 to 0.5 * Sampling Rate | Bandwidth of the low-pass filter applied to the trigger signal. For edge and pulse trigger use a bandwidth larger than the signal sampling rate divided by 20 to keep the phase delay. For tracking filter use a bandwidth smaller than signal sampling frequency divided by 100 to just track slow signal components like drifts. |
| Enable | ON / OFF | Enable low-pass filtering of the trigger signal. |
| Hold Off Time (s) | positive numeric value | Hold off time before the trigger is rearmed. A hold off time smaller than the duration will lead to overlapping trigger frames. |
| Hold Off Count | integer value | Number of skipped triggers until the next trigger is recorded again. |
| Delay (s) | -Duration to Duration | Time delay of trigger frame position (left side) relative to the trigger edge. For delays smaller than 0, trigger edge inside trigger frame (pre trigger). For delays greater than 0, trigger edge before trigger frame (post trigger) |
| Refresh Rate | 100 mHz to 10 Hz | Set the maximum refresh rate for plot updates. The actual refresh rate depends on other factors such as the hold-off time and duration. |
| Pulse Min (s) | 0 to Duration | Minimum pulse width to trigger on. |
| Pulse Max (s) | 0 to Duration | Maximum pulse width to trigger on. |
| Window | Rectangular Hann Hamming Blackman Harris Exponential (ring-down) Cosine (ring-down) Cosine squared (ring-down) | Seven different FFT windows to choose from. Depending on the application it makes a huge difference which of the provided window function is used. Please check the literature to find out the best trade off for your needs. |
| Absolute Frequency | ON / OFF | Shifts x-axis labeling to show the demodulation frequency in the center as opposed to 0 Hz, when turned off. |
| Spectral Density | ON / OFF | Calculate and show the spectral density. If power is enabled the power spectral density value is calculated. The spectral density is used to analyze noise. |

Table 4.30. DAQ tab: Grid sub-tab

| Control/Tool | Option/Range | Description |
|---------------------|-----------------|--|
| Mode | | Select resampling method for two-dimensional data recording. |
| | Off | Two-dimensional data recording is disabled. |
| | Nearest | Resampling is performed using substitution by closest data point. |
| | Linear | Resampling is performed using linear interpolation. |
| | Exact (on-grid) | Adjust the duration so that the grid distance matches the maximal sampling rate of the selected signals. This allows for on-grid sampling of measurement data. If a signal uses lower sampling rate it will be up-sampled by linear interpolation. |
| On Grid Sampling | Green or yellow | When green, indicates that all the captured data is aligned to the grid. When yellow, indicates that some data is not aligned to the grid and is interpolated. This can happen when one or more data sources have different sampling rates, or when a sampling rate changes. |
| Operation | | Select row update method. |
| | Replace | New row replaces old row. |
| | Average | The data for each row is averaged over a number of repetitions. |
| | Std | The data for each row is the standard deviation over a number of repetitions. |
| Columns | numeric value | Number of columns. The data along the horizontal axis are resampled to a number of samples defined by this setting. |
| Duration | up to 1000 s | Recording length for each triggered data set. In exact sampling mode the duration is a read-only field. The duration is then defined by the maximal sampling rate and column size. |
| Rows | numeric value | Number of rows |
| Scan Direction | | Select the scan direction and mode |
| | Forward | Scan direction from left to right |
| | Reverse | Scan direction from right to left |
| | Bidirectional | Alternate scanning in both directions |
| Repetitions | numeric value | Number of repetitions used for averaging |
| Row-wise repetition | ON / OFF | Enable row-wise repetition. With row-wise repetition, each row is calculated from successive repetitions before starting the next row. With grid-wise repetition, the entire grid is calculated with each repetition. |
| Waterfall | ON / OFF | Enable to show the 2D plot in waterfall mode. It will always update the last line. |

| Control/Tool | Option/Range | Description |
|------------------|------------------------|---|
| Overwrite | ON / OFF | Enable to overwrite the grid in continuous mode. History will not be collected. A history element will only be created when the analysis is stopped. |
| Plot Type | | Select the plot type. |
| | None | No plot displayed. |
| | 2D | Display defined number of grid rows as one 2D plot. |
| | Row | Display only the trace of index defined in the Active Row field. |
| | 2D + Row | Display 2D and row plots. |
| Active Row | integer value | Set the row index to be displayed in the Row plot. |
| Track Active Row | ON / OFF | If enabled, the active row marker will track with the last recorded row. The active row control field is read-only if enabled. |
| Palette | Viridis | Select the colormap for the current plot. |
| | Inferno | |
| | Balance | |
| | Turbo | |
| | Grey | |
| | Solar | |
| Colorscale | ON / OFF | Enable/disable the colorscale bar display in the 2D plot. |
| Mapping | | Mapping of colorscale. |
| | Lin | Enable linear mapping. |
| | Log | Enable logarithmic mapping. |
| | dB | Enable logarithmic mapping in dB. |
| Scaling | Full Scale/Manual/Auto | Scaling of colorscale. |
| Clamp To Color | ON / OFF | When enabled, grid values that are outside of defined Min or Max region are painted with Min or Max color equivalents. When disabled, Grid values that are outside of defined Min or Max values are left transparent. |
| Start | numeric value | Lower limit of colorscale. Only visible for manual scaling. |
| Stop | numeric value | Upper limit of colorscale. Only visible for manual scaling. |

Table 4.31. DAQ tab: History sub-tab

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| History | History | Each entry in the list corresponds to a single trace in the history. The number of traces |

| Control/Tool | Option/Range | Description |
|--------------|------------------|---|
| | | displayed in the plot is limited to 20. Use the toggle buttons to hide or show individual traces. Use the color picker to change the color of a trace in the plot. Double click on a list entry to edit its name. |
| Length | integer value | Maximum number of records in the history. The number of entries displayed in the list is limited to the 100 most recent ones. |
| Clear All | Clear All | Remove all records from the history list. |
| Clear | Clear | Remove selected records from the history list. |
| Load file | | Load data from a file into the history. Loading does not change the data type and range displayed in the plot, this has to be adapted manually if data is not shown. |
| Name | | Enter a name which is used as a folder name to save the history into. An additional three digit counter is added to the folder name to identify consecutive saves into the same folder name. |
| Auto Save | | Activate autosaving. When activated, any measurements already in the history are saved. Each subsequent measurement is then also saved. The autosave directory is identified by the text "autosave" in the name, e.g. "sweep_autosave_001". If autosave is active during continuous running of the module, each successive measurement is saved to the same directory. For single shot operation, a new directory is created containing all measurements in the history. Depending on the file format, the measurements are either appended to the same file, or saved in individual files. For HDF5 and ZView formats, measurements are appended to the same file. For MATLAB and SXM formats, each measurement is saved in a separate file. |
| File Format | | Select the file format in which to save the data. |
| Save | Save | Save the traces in the history to a file accessible in the File Manager tab. The file contains the signals in the Vertical Axis Groups of the Control sub-tab. The data that is saved depends on the selection from the pull-down list. Save All: All traces are saved. Save Sel: The selected traces are saved. |

For the Math sub-tab please see the table "Plot math description" in the section called "Cursors and Math".

4.9. Spectrum Analyzer Tab

The Spectrum Analyzer is one of the powerful frequency domain measurement tools as introduced in Unique Set of Analysis Tools and is available on all MFLI instruments.

4.9.1. Features

- Fast, high-resolution FFT spectrum analyzer
- Signals: demodulated data ($X+iY$, R , Θ , f and $d\Theta/dt/(2\pi)$), PID, Boxcar, Auxiliary Inputs, and more
- Variable center frequency, frequency resolution and frequency span
- Auto bandwidth
- Waterfall display
- Choice of 4 different FFT window functions
- Continuous and block-wise acquisition with different types of averaging
- Detailed noise power analysis
- Support for Input Scaling and Input Units
- Mathematical toolbox for signal analysis

4.9.2. Description

The Spectrum Analyzer provides frequency domain analysis of demodulator data. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.32. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| Spectrum |  | Provides FFT functionality to all continuously streamed measurement data. |

The Spectrum tab (see Figure 4.26) is divided into a display section on the left and a configuration section on the right. The configuration section is further divided into a number of sub-tabs.




Figure 4.26. LabOne UI: Spectrum analyzer tab

The Spectrum Analyzer allows for spectral analysis of all the demodulator data by performing the fast Fourier transform (FFT) on the complex demodulator data samples $X+iY$ (with i as the imaginary unit). The result of this FFT is a spectrum centered around the demodulation frequency,

whereas applying a FFT directly on the raw input data would produce a spectrum centered around zero frequency. The latter procedure corresponds to the Frequency Domain operation in the [Section 4.7](#). The main difference between the two is that the Spectrum Analyzer tool can acquire data for a much longer periods of time and therefore can achieve very high frequency resolution around the demodulation frequency. By default, the spectrum is displayed centered around zero. Sometimes however it is convenient to shift the frequency axis by the demodulation frequency which allows one to identify the frequencies on the horizontal axis with the physical frequencies at the signal inputs. This can be done by activating Absolute Frequency on the Settings sub-tab.

By default, the display section contains a line plot of the spectrum together with a color waterfall plot of the last few acquired spectra. The waterfall plot makes it easier to see the evolution of the spectrum over time. The display layout as well as the number of rows in the color plot can be configured in the Settings sub-tab.

Data shown in the Spectrum tab have passed a low-pass filter with a well-defined order and bandwidth. This is most clearly noted by the shape of the noise floor. One has to take care that the selected frequency span, which equals the demodulator sampling rate, is 5 to 10 times higher than the filter bandwidth in order to prevent measurement errors due to aliasing. The Auto

Bandwidth button **A** adjusts the sampling rate so that it suits the filter settings. The Spectrum tab features FFT display of a selection of data available in the Signal Type drop-down list in addition to the complex demodulator samples $X+iY$. Looking at the FFT of polar demodulator values R and Theta allows one to discriminate between phase noise components and amplitude noise components in the signal. The FFT of the phase derivative $d\theta/dt$ provides a quantitative view of the spectrum of demodulator frequencies. That is particularly useful in conjunction with the PLL or the ExtRef functionalities. The FFT of the frequency samples then provide a quantitative view of what frequency noise components are present in the reference signal and also helps to find the optimal PLL bandwidth to track the signal. Note that many of the signals in the Signal Type list are real-valued, rather than complex-valued. Their spectra are single-sided with minimum frequency of 0 Hz.

4.9.3. Functional Elements

Table 4.33. Spectrum tab: Settings sub-tab

| Control/Tool | Option/Range | Description |
|----------------------|-----------------|--|
| Run/Stop | Run/Stop | Run the FFT spectrum analysis continuously |
| Single | Single | Run the FFT spectrum analysis once |
| Center Freq (Hz) | numeric value | Demodulation frequency of the selected demodulator used as input for the spectrum. For complex FFT($X+iY$) the demodulation frequency defines the center frequency of the displayed FFT. |
| Frequency Span (Hz) | numeric value | Set the frequency span of interest for the complex FFT. A FFT based on real input data will display half of the frequency span up to the Nyquist frequency. |
| Auto Bandwidth | A | Automatic adjustment of the demodulator bandwidths to obtain optimal alias rejection for the selected frequency span which is equivalent to the sampling rate. The functionality is only available if the spectrum is enabled. |
| Start Frequency (Hz) | numeric value | Indicates the start frequency of the FFT. |

| Control/Tool | Option/Range | Description |
|---------------------|--|---|
| Stop Frequency (Hz) | numeric value | Indicates the end frequency of the FFT. |
| Refresh Rate (Hz) | numeric value | Set the maximum plot refresh rate. The actual refresh rate also depends on other parameters such as FFT length. In overlapped mode the refresh rate defines the amount of overlapping. |
| Overlapped FFT | ON / OFF | Enable overlapped FFTs. If disabled, FFTs are performed on distinct abutting data sets. If enabled, the data sets of successive FFTs overlap based on the defined refresh rate. |
| Power | ON / OFF | Calculate and show the power value. To extract power spectral density (PSD) this button should be enabled together with spectral density. |
| Spectral Density | ON / OFF | Calculate and show the spectral density. If power is enabled the power spectral density value is calculated. The spectral density is used to analyze noise. |
| Filter Compensation | ON / OFF | Spectrum is corrected by demodulator filter transfer function. Allows for quantitative comparison of amplitudes of different parts of the spectrum. |
| Absolute Frequency | ON / OFF | Shifts x-axis labeling to show the demodulation frequency in the center as opposed to 0 Hz, when turned off. |
| FFT length | numeric value | The number of samples used for the FFT. Values entered that are not a binary power are truncated to the nearest power of 2. |
| Sampling Progress | 0% to 100% | The percentage of the FFT buffer already acquired. The progress includes the number of rows and averages. |
| FFT Duration (s) | numeric value | Indicates the length in time of the samples used for a single FFT. |
| Window | Rectangular Hann Hamming Blackman Harris Exponential (ring-down) Cosine (ring-down) Cosine squared (ring-down) | Seven different FFT windows to choose from. Depending on the application it makes a huge difference which of the provided window function is used. Please check the literature to find out the best trade off for your needs. |
| Resolution (Hz) | mHz to Hz | Spectral resolution defined by the reciprocal acquisition time (sample rate, number of samples recorded). |
| Rows | numeric value | Number of rows |
| Averages | numeric value | Number of FFT averaged for each row. Setting the value to 1 will disable any averaging. |

| Control/Tool | Option/Range | Description |
|------------------|------------------------|---|
| Waterfall | ON / OFF | Enable to show the 2D plot in waterfall mode. It will always update the lowest line. |
| Overwrite | ON / OFF | Enable to overwrite the grid in continuous mode. History will not be collected. A history element will only be created when the analysis is stopped. |
| Plot Type | | Select the plot type. |
| | None | No plot displayed. |
| | 2D | Display defined number of grid rows as one 2D plot. |
| | Row | Display only the trace of index defined in the Active Row field. |
| | 2D + Row | Display 2D and row plots. |
| Active Row | integer value | Set the row index to be displayed in the Row plot. |
| Track Active Row | ON / OFF | If enabled, the active row marker will track with the last recorded row. The active row control field is read-only if enabled. |
| Palette | Viridis | Select the colormap for the current plot. |
| | Inferno | |
| | Balance | |
| | Turbo | |
| | Grey | |
| | Solar | |
| Colorscale | ON / OFF | Enable/disable the colorscale bar display in the 2D plot. |
| Mapping | | Mapping of colorscale. |
| | Lin | Enable linear mapping. |
| | Log | Enable logarithmic mapping. |
| | dB | Enable logarithmic mapping in dB. |
| Scaling | Full Scale/Manual/Auto | Scaling of colorscale. |
| Clamp To Color | ON / OFF | When enabled, grid values that are outside of defined Min or Max region are painted with Min or Max color equivalents. When disabled, Grid values that are outside of defined Min or Max values are left transparent. |
| Start | numeric value | Lower limit of colorscale. Only visible for manual scaling. |
| Stop | numeric value | Upper limit of colorscale. Only visible for manual scaling. |

For the Math sub-tab please see the table "Plot math description" in the section called "Cursors and Math".

4.10. Sweeper Tab

The Sweeper is a highly versatile measurement tool available on all MFLI instruments. The Sweeper enables scans of an instrument parameter over a defined range and simultaneous measurement of a selection of continuously streamed data. In the special case where the sweep parameter is an oscillator frequency, the Sweeper offers the functionality of a frequency response analyzer (FRA), a well-known class of instruments.

4.10.1. Features

- Full-featured parametric sweep tool for frequency, phase shift, output amplitude, DC output voltages, etc.
- Simultaneous display of data from different sources (Demodulators, PIDs, auxiliary inputs, and others)
- Different application modes, e.g. Frequency response analyzer (Bode plots), noise amplitude sweeps, etc.
- Different sweep types: single, continuous (run / stop), bidirectional, binary
- Persistent display of previous sweep results
- XY Mode for Nyquist plots or I-V curves
- Normalization of sweeps
- Auto bandwidth, averaging and display normalization
- Support for Input Scaling and Input Units
- Phase unwrap
- Full support of sinc filter

4.10.2. Description

The Sweeper supports a variety of experiments where a parameter is changed stepwise and numerous measurement data can be graphically displayed. Open the tool by clicking the corresponding icon in the UI side bar. The Sweeper tab (see [Figure 4.27](#)) is divided into a plot section on the left and a configuration section on the right. The configuration section is further divided into a number of sub-tabs.

Table 4.34. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| Sweeper | | Sweep frequencies, voltages, and other quantities over a defined range and display various response functions including statistical operations. |




Figure 4.27. LabOne UI: Sweeper tab

The **Control** sub-tab holds the basic measurement settings such as Sweep Parameter, Start/Stop values, and number of points (Length) in the Horizontal section. Measurement signals can be added in the Vertical Axis Groups section. A typical use of the Sweeper is to perform a frequency sweep and measure the response of the device under test in the form of a Bode plot. As an example, AFM and MEMS users require to determine the resonance frequency and the phase delay of their oscillators. The Sweeper can also be used to sweep parameters other than frequency, for instance signal amplitudes and DC offset voltages. A sweep of the Auxiliary Output offset can for instance be used to measure current-voltage (I-V) characteristics. The XY Mode allows one to use a measured signal, rather than the sweep parameter, on the horizontal axis. This is useful to obtain Nyquist plots in impedance measurements, or to display an I-V curve in a four-probe measurement of a nonlinear device.

For frequency sweeps, the sweep points are distributed logarithmically, rather than linearly, between the start and stop values by default. This feature is particularly useful for sweeps over several decades and can be disabled with the Log checkbox. The Sweep Mode setting is useful for identifying measurement problems caused by hysteretic sample behavior or too fast sweeping speed. Such problems would cause non-overlapping curves in a bidirectional sweep.

Note

The Sweeper actively modifies the main settings of the demodulators and oscillators. So in particular for situations where multiple experiments are served maybe even from different control computers great care needs to be taken so that the parameters altered by the sweeper module do not have unwanted effects elsewhere.

The Sweeper offers two operation modes differing in the level of detail of the accessible settings: the Application Mode and the Advanced Mode. Both of them are accessible in the **Settings** sub-tab. The Application Mode provides the choice between six measurement approaches that should help to quickly obtain correct measurement results for a large range of applications. Users who like to be in control of all the settings can access them by switching to the Advanced Mode.

In the Statistics section of the Advanced Mode one can control how data is averaged at each sweep point: either by specifying the Sample count, or by specifying the number of filter time constants (TC). The actual measurement time is determined by the larger of the two settings, taking into account the demodulator sample rate and filter settings. The Algorithm settings determines the statistics calculated from the measured data: the average for general purposes, the deviation for noise measurements, or the mean square for power measurements. The Phase Unwrap features ensures continuity of a phase measurement curve across the PM180 degree boundary. Enabling the Sinc Filter setting means that the demodulator Sinc Filter gets activated

for sweep points below 50 Hz in Auto and Fixed mode. This speeds up measurements at small frequencies as explained in the [Sinc Filtering](#).

In the Settling section one can control the waiting time between a parameter setting and the first measurement. Similarly to the Statistics setting, one has the choice between two different representations of this waiting time. The actual settling time is the maximum of the values set in units of absolute time and a time derived from the demodulator filter and a desired inaccuracy (e.g. 1 m for 0.1%). Let's consider an example. For a 4th order filter and a 3 dB bandwidth of 100 Hz we obtain a step response that attains 90% after about 4.5 ms. This can be easily measured by using the Data Acquisition tool as indicated in [Figure 4.28](#). It is also explained in [Discrete-Time Filters](#). In case the full range is set to 1V this means a measurement has a maximum error caused by imperfect settling of about 0.1 V. However, for most measurements the neighboring values are close compared to the full range and hence the real error caused is usually much smaller.

In the Filter section of the Advanced mode, the Bandwidth Mode setting determines how the filters of the activated demodulators are configured. In Manual mode, the current setting (in the Lock-in tab) remains unchanged by the Sweeper. In Fixed mode, the filter settings can be controlled from within the Sweeper tab. In Auto mode, the Sweeper determines the filter bandwidth for each sweep point based on a desired ω suppression. The ω suppression depends on the measurement frequency and the filter steepness. For frequency sweeps, the bandwidth will be adjusted for every sweep point within the bound set by the Max Bandwidth setting. The Auto mode is particularly useful for frequency sweeps over several decades, because the continuous adjustment of the bandwidth considerably reduces the overall measurement time.




Figure 4.28. Demodulator settling time and inaccuracy: measurement carried out with the Data Acquisition tool to illustrate the settling time for a 4th-order filter with a 3 dB bandwidth of 100 Hz.

By default the plot area keeps the memory and display of the last 100 sweeps represented in a list in the [History](#) sub-tab. See [History List](#) for more details on how data in the history list can be managed and stored. With the Reference feature, it is possible to divide all measurements in the history by a reference measurement. This is useful for instance to eliminate spurious effects in a frequency response sweep. To define a certain measurement as the reference, mark it in the list and click on [Reference](#). Then enable the Reference mode with the checkbox below the list to update the plot display. Note that the Reference setting does not affect data saving: saved files always contain raw data.

Note

The Sweeper can get stuck whenever it does not receive any data. A common mistake is to select to display demodulator data without enabling the data transfer of the associated demodulator in the Lock-in tab.

Note

Once a sweep is performed the sweeper stores all data from the enabled demodulators and auxiliary inputs even when they are not displayed immediately in the plot area. These data can be accessed at a later point in time simply by choosing the corresponding signal display settings (Input Channel).

4.10.3. Functional Elements

Table 4.35. Sweeper tab: Control sub-tab

| Control/Tool | Option/Range | Description |
|-----------------|---|---|
| Run/Stop | Run/Stop | Runs the sweeper continuously. |
| Single | Single | Runs the sweeper once. |
| Copy From Range | Copy From Range | Takes over start and stop value from the plot area. |
| Start (unit) | numeric value | Start value of the sweep parameter. The unit adapts according to the selected sweep parameter. |
| Stop (unit) | numeric value | Stop value of the sweep parameter. The unit adapts according to the selected sweep parameter. |
| Length | integer value | Sets the number of measurement points. |
| Progress | 0 to 100% | Reports the sweep progress as ratio of points recorded. |
| Sweep Param |  | Selects the parameter to be swept. Navigate through the tree view that appears and click on the required parameter. The available selection depends on the configuration of the device. |
| Sweep Mode | | Select the scanning type, default is sequential (incremental scanning from start to stop value) |
| | Sequential | Sequential sweep from Start to Stop value |
| | Binary | Non-sequential sweep continues increase of resolution over entire range |
| | Bidirectional | Sequential sweep from Start to Stop value and back to Start again |
| | Reverse | Reverse sweep from Stop to Start value |

| Control/Tool | Option/Range | Description |
|----------------|---|---|
| X Distribution | Linear / Logarithmic | Selects between linear and logarithmic distribution of the sweep parameter. |
| Remaining | numeric value | Reporting of the remaining time of the current sweep. A valid number is only displayed once the sweeper has been started. An undefined sweep time is indicated as NaN. |
| Invert Y Axis | ON / OFF | The xy-plot is displayed with inverted y-axis. This mode is used for Nyquist plots that allow for displaying -imag(z) on the y-axis and real(z) on the x-axis. |
| X Signal |  | Selects the signal that defines the x-axis for xy-plots. The available selection depends on the configuration of the device. Displaying the selected signal source will result in a diagonal straight line. |

For the Vertical Axis Groups, please see [the table "Vertical Axis Groups description" in the section called "Vertical Axis Groups"](#).

Table 4.36. Sweeper tab: Settings sub-tab

| Control/Tool | Option/Range | Description |
|--------------|--------------------------|--|
| Filter | | Application Mode: preset configuration. Advanced Mode: manual configuration. |
| | Application Mode | The sweeper sets the filters and other parameters automatically. |
| | Advanced Mode | The sweeper uses manually configured parameters. |
| Application | | Select the sweep application mode |
| | Parameter Sweep | Only one data sample is acquired per sweeper point. |
| | Parameter Sweep Averaged | Multiple data samples are acquired per sweeper point of which the average value is displayed. |
| | Noise Amplitude Sweep | Multiple data samples are acquired per sweeper point of which the standard deviation is displayed (e.g. to determine input noise). |
| | Freq Response Analyzer | Narrow band frequency response analysis. Averaging is enabled. |
| | 3-Omega Sweep | Optimized parameters for 3-omega application. Averaging is enabled. |
| | FRA (Sinc Filter) | The sinc filter helps to speed up measurements for frequencies below 50 Hz in FRA mode. For higher frequencies it is automatically disabled. Averaging is off. |
| | Impedance | This application mode uses narrow bandwidth filter settings to achieve high calibration accuracy. |

| Control/Tool | Option/Range | Description |
|------------------------------------|------------------------|---|
| Precision | | Choose between a high speed scan speed or high precision and accuracy. |
| | Low → fast sweep | Medium accuracy/precision is optimized for sweep speed. |
| | High → standard speed | Medium accuracy/precision takes more measurement time. |
| | Very high → slow sweep | High accuracy/precision takes more measurement time. |
| Bandwidth Mode | | Automatically is recommended in particular for logarithmic sweeps and assures the whole spectrum is covered. |
| | Auto | All bandwidth settings of the chosen demodulators are automatically adjusted. For logarithmic sweeps the measurement bandwidth is adjusted throughout the measurement. |
| | Fixed | Define a certain bandwidth which is taken for all chosen demodulators for the course of the measurement. |
| | Manual | The sweeper module leaves the demodulator bandwidth settings entirely untouched. |
| Time Constant/ Bandwidth Select | | Defines the display unit of the low-pass filter to use for the sweep in fixed bandwidth mode: time constant (TC), noise equivalent power bandwidth (NEP), 3 dB bandwidth (3 dB). |
| | TC | Defines the low-pass filter characteristic using time constant of the filter. |
| | Bandwidth NEP | Defines the low-pass filter characteristic using the noise equivalent power bandwidth of the filter. |
| | Bandwidth 3 dB | Defines the low-pass filter characteristic using the cut-off frequency of the filter. |
| Time Constant/ Bandwidth | numeric value | Defines the measurement bandwidth for Fixed bandwidth sweep mode, and corresponds to either noise equivalent power bandwidth (NEP), time constant (TC) or 3 dB bandwidth (3 dB) depending on selection. |
| Order | numeric value | Selects the filter roll off to use for the sweep in fixed bandwidth mode. Range between 6 dB/oct and 48 dB/oct. |
| Max Bandwidth (Hz) | numeric value | Maximal bandwidth used in auto bandwidth mode. The effective bandwidth will be calculated based on this max value, the frequency step size, and the omega suppression. |
| BW Overlap | ON / OFF | If enabled the bandwidth of a sweep point may overlap with the frequency of neighboring sweep points. The effective bandwidth is only limited by the maximal bandwidth setting |

| Control/Tool | Option/Range | Description |
|------------------------|--------------------|--|
| | | and omega suppression. As a result, the bandwidth is independent of the number of sweep points. For frequency response analysis bandwidth overlap should be enabled to achieve maximal sweep speed. |
| Omega Suppression (dB) | numeric value | Suppression of the omega and 2-omega components. Large suppression will have a significant impact on sweep time especially for low filter orders. |
| Min Settling Time (s) | numeric value | Minimum wait time in seconds between a sweep parameter change and the recording of the next sweep point. This parameter can be used to define the required settling time of the experimental setup. The effective wait time is the maximum of this value and the demodulator filter settling time determined from the Inaccuracy value specified. |
| Inaccuracy | numeric value | Demodulator filter settling inaccuracy defining the wait time between a sweep parameter change and recording of the next sweep point. The settling time is calculated as the time required to attain the specified remaining proportion [1e-13, 0.1] of an incoming step function. Typical inaccuracy values: 10 m for highest sweep speed for large signals, 100 u for precise amplitude measurements, 100 n for precise noise measurements. Depending on the order the settling accuracy will define the number of filter time constants the sweeper has to wait. The maximum between this value and the settling time is taken as wait time until the next sweep point is recorded. |
| Settling Time (TC) | numeric value | Calculated wait time expressed in time constants defined by the specified filter settling inaccuracy. |
| Algorithm | | Selects the measurement method. |
| | Averaging | Calculates the average on each data set. |
| | Standard Deviation | Calculates the standard deviation on each data set. |
| | Average Power | Calculates the electric power based on a 50 Ω input impedance. |
| Count (Sa) | integer number | Sets the number of data samples per sweeper parameter point that is considered in the measurement. The maximum between samples, time and number of time constants is taken as effective calculation time. |
| Count (s) | numeric value | Sets the time during which data samples are processed. The maximum between samples, time and number of time constants is taken as effective calculation time. |

| Control/Tool | Option/Range | Description |
|------------------|------------------|---|
| Count (TC) | 0/5/15/50/100 TC | Sets the effective measurement time per sweeper parameter point that is considered in the measurement. The maximum between samples, time and number of time constants is taken as effective calculation time. |
| Phase Unwrap | ON / OFF | Allows for unwrapping of slowly changing phase evolutions around the +/-180 degree boundary. |
| Spectral Density | ON / OFF | Selects whether the result of the measurement is normalized versus the demodulation bandwidth. |
| Sinc Filter | ON / OFF | Enables sinc filter if sweep frequency is below 50 Hz. Will improve the sweep speed at low frequencies as omega components do not need to be suppressed by the normal low-pass filter. |

Table 4.37. Sweeper tab: History sub-tab

| Control/Tool | Option/Range | Description |
|--------------|------------------|---|
| History | History | Each entry in the list corresponds to a single trace in the history. The number of traces displayed in the plot is limited to 20. Use the toggle buttons to hide or show individual traces. Use the color picker to change the color of a trace in the plot. Double click on a list entry to edit its name. |
| Length | integer value | Maximum number of records in the history. The number of entries displayed in the list is limited to the 100 most recent ones. |
| Clear All | Clear All | Remove all records from the history list. |
| Clear | Clear | Remove selected records from the history list. |
| Load file | | Load data from a file into the history. Loading does not change the data type and range displayed in the plot, this has to be adapted manually if data is not shown. |
| Name | | Enter a name which is used as a folder name to save the history into. An additional three digit counter is added to the folder name to identify consecutive saves into the same folder name. |
| Auto Save | | Activate autosaving. When activated, any measurements already in the history are saved. Each subsequent measurement is then also saved. The autosave directory is identified by the text "autosave" in the name, e.g. "sweep_autosave_001". If autosave is active during continuous running of the module, each successive measurement is saved to the same directory. For single shot operation, |

| Control/Tool | Option/Range | Description |
|----------------|------------------|---|
| | | a new directory is created containing all measurements in the history. Depending on the file format, the measurements are either appended to the same file, or saved in individual files. For HDF5 and ZView formats, measurements are appended to the same file. For MATLAB and SXM formats, each measurement is saved in a separate file. |
| File Format | | Select the file format in which to save the data. |
| Save | Save | Save the traces in the history to a file accessible in the File Manager tab. The file contains the signals in the Vertical Axis Groups of the Control sub-tab. The data that is saved depends on the selection from the pull-down list. Save All: All traces are saved. Save Sel: The selected traces are saved. |
| Reference | Reference | Use the selected trace as reference for all active traces. |
| Reference On | ON / OFF | Enable/disable the reference mode. |
| Reference name | name | Name of the reference trace used. |

For the Math sub-tab please see the table "Plot math description" in the section called "Cursors and Math".

4.11. Auxiliary Tab

The Auxiliary tab provides access to the settings of the Auxiliary Inputs and Auxiliary Outputs; it is available on all MFLI instruments.

4.11.1. Features

- Monitor signal levels of auxiliary input connectors
- Monitor signal levels of auxiliary output connectors
- Auxiliary output signal sources: Demodulators and manual setting
- Define Offsets and Scaling for auxiliary output values
- Control auxiliary output range limitations

4.11.2. Description

The Auxiliary tab serves mainly as a monitor and control of the auxiliary inputs and outputs. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.38. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| Aux | | Controls all settings regarding the auxiliary inputs and auxiliary outputs. |

The Auxiliary tab (see [Figure 4.29](#)) is divided into three sections. The Aux Input section gives two graphical and two numerical monitors for the signal amplitude applied to the auxiliary inputs on the back panel. In the middle of the tab the Aux Output section allows to associate any of the measured signals to one of the 4 auxiliary outputs on the instrument front panel. With the action buttons next to the Preoffset and Offset values the effective voltage on the auxiliary outputs can be automatically set to zero. The analog output voltages can be limited to a certain range in order to avoid damaging the parts connected to the outputs.

Note

Please note the change of units of the scaling factor depending on what measurement signal is chosen.

Two Aux Output Levels on the right provides 4 graphical and 4 numerical indicators to monitor the voltages currently set on the auxiliary outputs.




Figure 4.29. LabOne UI: Auxiliary tab

4.11.3. Functional Elements

Table 4.39. Auxiliary tab

| Control/Tool | Option/Range | Description |
|-------------------------|---|---|
| Preoffset | numerical value in signal units | Add a pre-offset to the signal before scaling is applied. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset |
| Auto-zero |  | Automatically adjusts the Pre-offset to set the Auxiliary Output Value to zero. |
| Scale | numerical value | Multiplication factor to scale the signal. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset |
| Offset | numerical value in Volts | Add the specified offset voltage to the signal after scaling. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset |
| Lower Limit | -10 V to 10 V | Lower limit for the signal at the Auxiliary Output. A smaller value will be clipped. |
| Upper Limit | -10 V to 10 V | Upper limit for the signal at the Auxiliary Output. A larger value will be clipped. |
| Value | -10 V to 10 V | Voltage present on the Auxiliary Output. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset |
| Auxiliary Input Voltage | -10 V to 10 V | Voltage measured at the Auxiliary Input. |
| Signal | | Select the signal source to be represented on the Auxiliary Output. |
| | PID Out | Select one of the PID controllers output. MF-PID option needs to be installed. |
| | PID Shift | Select one of the PID controllers' shift signal. MF-PID option needs to be installed. |
| | PID Error | Select one of the PID controllers' error signal. MF-PID option needs to be installed. |
| | TU Filtered Value | Select one of the Threshold unit input signals after filtering for auxiliary output. |
| | TU Output Value | Select one of the Threshold unit output signals for auxiliary output. |
| | X | Select the demodulator X component for auxiliary output. |
| | Y | Select the demodulator Y component for auxiliary output. |
| | R | Select the demodulator magnitude component for auxiliary output. |
| | Θ | Select the demodulator phase component for auxiliary output. |
| Channel | Manual | Manually define an auxiliary output voltage using the offset field. |
| | index | Select the channel according to the selected signal source. |

4.11. Auxiliary Tab

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| Auto-zero |  | Automatically adjusts the Offset to set the Auxiliary Output Value to zero. |

4.12. Inputs/Outputs Tab

The In / Out tab provides access to the settings of the Instrument's main Signal Inputs and Signal Outputs. It is available on all MFLI instruments.

4.12.1. Features

- Signal input configuration
- Signal output configuration

4.12.2. Description

The In / Out tab gives access to the same settings as do the left-most and the right-most sections of the Lock-in tab. It is mainly intended to be used on small screens that can not show the entire the Lock-in tab at once. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.40. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| In/Out |  | Gives access to all controls relevant for the Signal Inputs and Signal Outputs on the instrument's front. |

The In / Out tab contains one section for the signal inputs and one for the signal outputs. All of the corresponding connectors are placed on the instrument front panel. The In / Out tab looks differently depending on whether the MF-MD Multi-demodulator option is installed or not.




Figure 4.30. LabOne UI: Inputs/Outputs tab (base configuration)




Figure 4.31. LabOne UI: Inputs/Outputs tab (with MF-MD Multi-demodulator option)

4.12.3. Functional Elements

All functional elements are equivalent to the ones on the Lock-in tab. See [the Lock-in Tab](#) or [Lock-in MF Tab](#) for a detailed description of the functional elements.

4.13. DIO Tab

The DIO tab provides access to the settings and controls of the digital I/O as well as the Trigger channels and is available on all MFLI instruments.

4.13.1. Features

- Monitor and control of digital I/O connectors
- Control settings for external reference and triggering

4.13.2. Description

The DIO tab is the main panel to control the digital inputs and outputs as well as the trigger levels and external reference channels . Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.41. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| DIO | | Gives access to all controls relevant for the digital inputs and outputs including the Ref/Trigger connectors. |




Figure 4.32. LabOne UI: DIO tab

The Digital I/O section provides numerical monitors to observe the states of the digital inputs and outputs. Moreover, with the values set in the Output column and the Drive button activated the states can also be actively set in different numerical formats.

The Trigger section shows the settings for the 2 trigger inputs and 2 trigger outputs on the instrument back panel. The trigger outputs can be referenced to the demodulator frequencies and output a TTL signal with a 50% duty cycle.

Note

The Input Level determines the trigger threshold for trigger state discrimination. Also a 100 mV hysteresis is applied that cannot be adjusted such that a minimum amplitude of more than 100 mV is needed for the Trigger inputs to work reliably.

4.13.3. Functional Elements

Table 4.42. Digital input and output channels, reference and trigger

| Control/Tool | Option/Range | Description |
|---------------------------|--|--|
| DIO mode | | Select DIO mode |
| | Threshold outputs | Enables setting of DIO output values by the threshold unit. |
| | Manual | Enables manual control of the DIO output bits. |
| QA Result Overflow | grey/yellow/red | Red: present overflow condition on the DIO interface during readout. Yellow: indicates an overflow occurred in the past. An overflow can happen if readouts are triggered faster than the maximum possible data-rate of the DIO interface. |
| DIO bits | label | Partitioning of the 32 bits of the DIO into 4 buses of 8 bits each. Each bus can be used as an input or output. |
| DIO input | numeric value in either Hex or Binary format | Current digital values at the DIO input port. |
| DIO output | numeric value in either hexadecimal or binary format | Digital output values. Enable drive to apply the signals to the output. |
| DIO drive | ON / OFF | When on, the corresponding 8-bit bus is in output mode. When off, it is in input mode. |
| Format | | Select DIO view format. |
| | Hexadecimal | DIO view format is hexadecimal. |
| | Binary | DIO view format is binary. |
| Clock | | Select DIO internal or external clocking. |
| | Internal 60 MHz | The DIO is internally clocked with a fixed frequency of 60 MHz. |
| | Clk Pin 68 | The DIO is externally clocked with a clock signal connected to DIO Pin 68. Available frequency range 1 Hz to 60 MHz. |
| Trigger level | -5 V to 5 V | Trigger voltage level at which the trigger input toggles between low and high. Use 50% amplitude for digital input and consider the trigger hysteresis. |
| Auto Threshold | Press once | Automatically adjust the trigger threshold. The level is adjusted to fall in the center of the applied transitions. |
| Trigger Input Low status | | Indicates the current low level trigger state. |
| | Off | A low state is not being triggered. |
| | On | A low state is being triggered. |
| Trigger Input High status | | Indicates the current high level trigger state. |
| | Off | A high state is not being triggered. |
| | On | A high state is being triggered. |

| Control/Tool | Option/Range | Description |
|-----------------------|---------------------|---|
| Trigger output signal | | Select the signal assigned to the trigger output. |
| | Off | The output trigger is disabled. |
| | Osc Phase Demod 2/4 | Oscillator phase of demod 2 (trigger output channel 1) or demod 4 (trigger output channel 2). Trigger event is output for each zero crossing of the oscillator phase. |
| | Scope Trigger | Trigger output is asserted when the scope trigger condition is satisfied. |
| | Scope /Trigger | Trigger output is deasserted when the scope trigger condition is satisfied. |
| | Scope Armed | Trigger output is asserted when the scope is waiting for the trigger condition to become satisfied. |
| | Scope /Armed | Trigger output is deasserted when the scope is waiting for the trigger condition to become satisfied. |
| | Scope Active | Trigger output is asserted when the scope has triggered and is recording data. |
| | Scope /Active | Trigger output is deasserted when the scope has triggered and is recording data. |
| | Threshold 1 | Threshold Logic Unit 1 output. |
| | Threshold 2 | Threshold Logic Unit 2 output. |
| | Threshold 3 | Threshold Logic Unit 3 output. |
| | Threshold 4 | Threshold Logic Unit 4 output. |
| | MDS Sync Out | Trigger output is driven by the multi-device synchronisation signal. |
| Width | 0 s to 0.149 s | Defines the minimal pulse width for the case of Scope events written to the trigger outputs of the device. |

4.14. Impedance Analyzer Tab

The Impedance Analyzer tab is available on MFIA Impedance Analyzer instruments and on MFLI Lock-in Amplifier instruments with installed MF-IA Impedance Analyzer option (see Information section in the Device tab).

4.14.1. Features

- Control for impedance analyzer unit (2 units with MF-MD option)
- Auto ranging and auto bandwidth
- Graphical display of measurement mode: 2- and 4-terminal configuration
- Graphical display of DUT representation: $R_p \parallel C_p$, $R_s + C_s$, $L_s + R_s$, C , D , ...
- 0.05 % basic accuracy
- 1 mΩ to 10 GΩ measurement range
- 20 ms measurement speed for basic accuracy
- Compensation Advisor for SOL and other compensation procedures
- Confidence Indicator
- Independent current and voltage measurement
- One-period averaging for low frequency impedance measurements

4.14.2. Description

The Impedance Analyzer tab is the main control panel for impedance measurements. On MFIA Impedance Analyzer instruments, the tab is open by default. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.43. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|--|
| IA |  | Quick overview and access to all the settings and properties for impedance measurements. |

The Impedance Analyzer tab consists of one side tab for each impedance analyzer unit, and the Cal side tab giving access to the Compensation Advisor. The numbered side-tab(s) for the impedance analyzer units (see [Figure 4.33](#)) are the main measurement interface. The main settings are accessible in the Measurement Control section on the left. The Equivalent Circuit section holds the controls for configuring the circuit representation visualized by a graphical circuit diagram. With the Mode setting, the user selects between a 2- and a 4-terminal setup which has to correspond to the physical wiring of the device-under-test (DUT). The Representation setting allows the user to convert the measured impedance Z into a parameter pair of a DUT circuit representation, such as parallel resistance and capacitance ($R_p \parallel C_p$), or serial resistance and inductance ($R_s + L_s$). The data are displayed in the Measurement Results section on the right. The equivalent circuit parameters appear as Representation Parameter 1 and 2 elsewhere in Measurement the UI, e.g. in the [Section 4.5](#) or the [Section 4.6](#) tab. The Enable button at the top left initiates the measurement by turning on the drive voltage and starting the current and voltage measurement.




Figure 4.33. LabOne UI: Impedance Analyzer tab (Application mode)

The Measurement Control section of the tab contains settings related to measurement range, frequency, and output drive amplitude. By default, all of those parameters are under automatic control of the Impedance Analyzer providing suitable settings for most situations. Manual control is available for some more advanced cases. E.g., disabling automatic Range Control by setting it to Manual or Impedance can help preventing range changes in sweeper measurements. Manual Bandwidth Control can be advantageous in conditions with strong noise. The measurement bandwidth should then be chosen as a compromise between speed and precision. In auto bandwidth mode, the instrument selects an appropriate bandwidth for the desired Ω suppression (see [Sinc Filtering](#)). Disabling automatic Drive Control allows the user to specify the drive amplitude when measuring an electrically sensitive DUT, for example. The numeric controls for bandwidth and drive amplitude are accessible in the [Section 4.3](#) tab.

More advanced controls for signal bandwidth, digital data transfer, and more. become accessible in the lower half of the tab after switching Mode from Application to Advanced in the Measurement Control section, see [Figure 4.34](#). The Confidence Indicators offer control of a number of features assisting in the measurement. The Indicators provide warning messages in the [Section 4.10](#), [Section 4.6](#), and [Section 4.5](#) tab that prevent misinterpretation of measurement data. The different warning messages are explained in the table below. All Indicators can be individually enabled or disabled, and the numeric settings provide fine-tuning of the error thresholds. The Discard Samples feature allows the user to disregard outlier measurements using thresholds.

For impedance measurements at low frequency, the one-period averaging feature (located in the Measurement Control sub-tab) can be enabled. Once enabled, the one-period averaging feature will automatically be active below a frequency threshold (defined by the data transfer rate), and the standard measurement mode will be used above this threshold. The active state is indicated by a green LED next to the enable switch. One-period averaging uses an alternative method to calculate impedance compared with the standard measurement mode. Current and voltage are measured for one period and subsequently divided to calculate the impedance, this technique suppresses the unwanted omega components by averaging over one full period. This is in contrast to the standard measurement mode of the MFIA, where unwanted omega components are filtered out using a low pass filter. The advantage of one-period averaging is the increased measurement speed for low frequencies, as more relaxed (faster) filter settings can be used.

During one-period averaging, the Demod signals will contain significant omega components and therefore do not return reliable values. If the Demod streams are required, switch off one-period averaging. Both [Section 4.10](#) and [Section 4.6](#) can be used with one-period averaging to calculate impedance. Please note, during the first period of the measurement, no data is transferred as no valid result is available during this time.

4.14. Impedance Analyzer Tab




Figure 4.34. LabOne UI: Impedance Analyzer tab (Advanced mode)

Table 4.44. List of warning messages provided by the Confidence Indicator.

| Confidence Indicator | Warning message | Situation | Corrective action |
|----------------------|--------------------------------------|--|--|
| Suppression | Suppression | The DUT is characterized by strongly differing impedance components. The calculation of the flagged Representation Parameter is unreliable. | Change measurement frequency, select appropriate representation corresponding to the DUT |
| Compensation | Strong Compensation | A measurement is carried out in a parameter range in which the user compensation enforces a large correction, making the measurement unreliable. | Check whether the test fixture is suitable for the measured impedance range and frequency. Check that the chosen compensation method is suitable for the impedance range. Consider including a "load" step with a load close to the measurement range. |
| Open Detect | Open Detected | One of the terminals in a four-terminal is disconnected | Check the correct wiring of the DUT (e.g. 2-terminal DUT in a 4-terminal measurement). Check for broken connections. |
| Underflow Detect | Current Underflow, Voltage Underflow | Voltage or current reading is close to zero | Check for open connections. If connections are correctly closed, check if the selected Range is suitable for the measured impedance when using the |

| Confidence Indicator | Warning message | Situation | Corrective action |
|--------------------------|------------------------------------|---|--|
| | | | Range Modes Manual and Impedance. |
| Overflow Detect | Current Overflow, Voltage Overflow | Voltage or current reading is close to the input range or exceeding it | Check if the selected Range is suitable for the measured impedance when using the Range Modes Manual and Impedance. |
| Frequency Limit | Freq Limit | Measurement frequency is higher than the bandwidth of the selected current input range | Select a larger current range in the range control settings or set Range Control to Auto. |
| Negative Q/D | Negative Q/D | The measured Q or D factor, or any measurement contributing to the displayed average, is negative | Check whether the chosen Representation corresponds well to the connected DUT, evaluate the quality of the applied compensation, and check for presence of strong noise. A negative Q or D factor mean the measured impedance can not be physically mapped to the chosen Representation. |
| Z too low for 2-terminal | Low DUT 2T | The measured Z is lower than the defined threshold for 2-terminal measurements | For low impedance measurements, 4-terminal measurements are recommended. The threshold for this confidence indicator can be manually adjusted or disabled in the advance section of the Impedance Tab |
| Different representation | Different representation | This flag highlights traces within the displayed data set which were acquired using an equivalent circuit representation other than the last set representation | Remove these traces from the recorded data using the history tab, or restart the data with the required representation |

4.14.3. Compensation

The Cal side-tab (see [Figure 4.35](#)) provides user guidance through a compensation procedure. Compensation reduces the effect of test fixture parasitics and thus improves measurement accuracy. It requires a measurement of one or more reference devices under test (DUTs) with precisely known impedance values in a certain frequency range. The available compensation methods are combinations of measurements of short ("S", DUT with zero impedance), open ("O", DUT with infinite impedance), and load ("L", DUT with known impedance of arbitrary value). Please

have a look at the Signal Processing chapter of the MFIA Impedance Analyzer user manual to learn more about the background and practicalities of the compensation, and at the Tutorial section in this document for step-by-step instructions for a specific example. The MFIA User Manual is available on the Zurich Instruments website. To prepare a compensation, select the appropriate Mode, connect the reference DUT and click on




Figure 4.35. LabOne UI: Impedance Analyzer tab (Cal side tab)

4.14.4. Functional Elements

Table 4.45. Impedance Analyzer tab: Control sub-tab

| Control/Tool | Option/Range | Description |
|----------------------------|--------------|--|
| Enable | ON / OFF | Enable impedance calculation for demodulator data. |
| One-Period Averaging | ON / OFF | Enables one-period averaging for low frequency impedance measurements. |
| One-Period Averaging | grey/green | The LED is green when one-period averaging is active. |
| Lower Frequency Limit (Hz) | | Lower frequency limit where the current input range will be enabled. |
| Upper Frequency Limit (Hz) | | Upper frequency limit where the current input range will be enabled. |
| Cable Length | | One way length of RG58 cables used in measurement set up. This setting corrects for the phase shift introduced by an ideal cable. |
| Representation | | Representation of the complex impedance value Z by two real values accessible as Parameter 1 and Parameter 2 on all user interface displays. |
| | Rp Cp | Impedance value Z is represented by a resistive element Rp in parallel with a capacitive element Cp. |
| | Rs + Cs | Impedance value Z is represented by a resistive element Rs in series with a capacitive element Cs. |
| | Rs + Ls | Impedance value Z is represented by a resistive element Rs in series with a inductive element Ls. |

| Control/Tool | Option/Range | Description |
|--------------|---------------|--|
| | G B | Impedance value Z is represented by conductance G = Real(Y) and Susceptance B = Imag(Y) of the admittance Y = 1/Z. |
| | D Cs | Impedance value Z is represented by a dissipation factor D = -Real(Z)/Imag(Z) (loss tangent) and a capacitive element. |
| | Q Cs | Impedance value Z is represented by a quality factor Q = -Imag(Z)/Real(Z) and a capacitive element. |
| | D Ls | Impedance value Z is represented by a dissipation factor D = Real(Z)/Imag(Z) (loss tangent) and an inductive element. |
| | Q Ls | Impedance value Z is represented by a quality factor Q = Imag(Z)/Real(Z) and an inductive element. |
| | Rp Lp | Impedance value Z is represented by a resistive element Rp in parallel with a inductive element Lp. |
| | D Cp | Impedance value Z is represented by a dissipation factor D = -Real(Z)/Imag(Z) (loss tangent) and a capacitive element. |
| | Real(Z) | Real part of the measured impedance Z. |
| | Imag(Z) | Imaginary part of the measured impedance Z. |
| | Abs(Z) | Absolute value of the measured impedance Z. |
| | Phase(Z) | Phase of the measured impedance Z. |
| | Frequency | Frequency at which the current impedance is measured. |
| | Parameter 1 | Currently active representation parameter 1 and the corresponding measured value. A representation is based on the measured impedance and the frequency. Representations are only valid within a specific frequency or impedance region. |
| | Parameter 2 | Currently active representation parameter 2 and the corresponding measured value. A representation is based on the measured impedance and the frequency. Representations are only valid within a specific frequency or impedance region. |
| | Osc Frequency | Frequency control for the oscillator used for impedance measurement. |
| | Range Control | Select input range control mode. |
| | Manual | In manual mode the current and voltage input ranges are adjusted manually and separately. Use this mode with care as overload will result in inaccurate impedance results. |
| | Auto | Dynamically adjust the input range according to the measured input signal strength. This |

| Control/Tool | Option/Range | Description |
|---------------------------|--|---|
| | | optimizes the dynamic range and precision of impedance measurements. |
| | Current Zone | This ranging option allows you to manually set the switching frequency limits for all eight current input ranges. |
| Range Control Override | ON / OFF | Indicates disabled periodic auto range control. A running sweeper module takes over the range control and thus disables the periodic range checks. |
| Current Range | 100 nA, 1 µA, 10 µA, 100 µA, 1 mA, 10 mA | Input current range used for the impedance measurement. Small current input range have a reduced bandwidth. In the Range Control modes "Auto" and "Impedance", the current range is switched automatically to a higher range if the frequency is too high. |
| Voltage Range | 10 mV, 30 mV, 100 mV, 300 mV, 1 V, 3.0 V | Input voltage range used for the impedance measurement. |
| Drive Control | ON / OFF | If enabled, the drive voltage amplitude is controlled by the device. If disabled it can be set manually. |
| Test Signal (V) | numeric value | Drive amplitude on the Signal Output. |
| Bandwidth Control | ON / OFF | Enable automatic bandwidth control. If enabled the optimum bandwidth is calculated based on the frequency and measurement data. |
| Max Bandwidth (Hz) | positive numeric value | Limit of the maximum bandwidth used on the demodulator filter. Values above 1 kHz can heavily diminish measurement accuracy in the high-frequency region where the amplitude is no more constant over frequency. |
| ω Suppression (dB) | positive numeric value | Suppression of the omega and 2-omega components. Small omega suppression can diminish measurements of very low or high impedance because the DC component can become dominant. Large omega suppression will have a significant impact on sweep time especially for low filter orders. |
| Suppression Ratio | 1 to 10000 | Error amplification limit for which a secondary parameter is marked unreliable. Larger gain values mean larger warning tolerances. A gain value between 10 and 100 is best. |
| Suppression Enable | ON / OFF | The Suppression Confidence Indicator indicates if one of the two parameters of a circuit representation cannot be calculated reliably from the measured impedance. This is the case if a small variation in one (dominant) representation parameter creates a strong variation of the other (suppressed) representation parameter. Such an error amplification indicates that the measurement of the secondary parameter is unreliable. |

| Control/Tool | Option/Range | Description |
|-------------------------|------------------------|--|
| Compensation | positive numeric value | Strength of the compensation that will trigger the strong compensation warning. |
| Compensation Enable | ON / OFF | Enables the indication of strong compensation in the plots. A strong compensation diminishes the measurement accuracy of the parameter. |
| Low DUT | positive numeric value | The maximum DUT impedance for which a 2T measurement is marked unreliable. |
| Low DUT Enable | ON / OFF | Enables the detection of small DUTs when doing 2 terminal measurements. Use 4 terminal mode for low impedance measurements. |
| Open Detect | positive numeric value | Open terminal detection ratio. An open terminal is reported if the excitation calculated from current and voltage drop differs more than the specified factor from the driving voltage. |
| Open Detect Enable | ON / OFF | Enables the open terminal detection for 4-terminal measurements. If enabled, an open terminal is indicated in the numeric tab and in plots. |
| Underflow Detect | positive numeric value | The underflow condition is met if the measured amplitude is lower than the specified ratio relative to full scale. |
| Underflow Detect Enable | ON / OFF | Enables the underflow detection for current and voltage. If enabled, an underflow will be shown in the numeric tab and in plots. |
| Overload Detect Enable | ON / OFF | Enables the overload detection for current and voltage. If enabled, an overload will be shown in the numeric tab and in plots. |
| Frequency Limit Enable | ON / OFF | Enables the frequency limit detection based on the used current input range. It is shown in the numeric tab and in plots. Only relevant when Range Control is set to Manual. |
| Negative Q/D Enable | ON / OFF | Enables the detection of negative Q or D factors. Negative Q or D factors mean the measured impedance does not correspond to the chosen Representation. This can be due to an erroneous compensation, a bad choice of the Representation, or noise. A message will be shown in the numeric tab and in plots. |
| Invalid One-period | ON / OFF | Enables the detection of unreliable data points where data sample loss leads to an invalid one-period average. Try reducing the data transfer rate. |

Table 4.46. Impedance Analyzer tab: Settings sub-tab

| Control/Tool | Option/Range | Description |
|----------------------------------|---------------------------|---|
| Mode | | Switch between application-based or manually configured impedance settings. A parameter set given by an Application mode can be fine-tuned by changing to Advanced mode. Changing back to Application mode will reset the parameters. |
| | Application | The impedance settings are adjusted to fit best the selected application. |
| | Advanced | The impedance settings are manually configured. |
| Application | | Select the Impedance application |
| | LCR Impedance Measurement | General-purpose settings for measuring components at finite frequency |
| | DC Impedance Measurement | Settings for measuring resistance at zero frequency. |
| Precision | | Select the Impedance precision and measurement speed by automatically adjusting the filter bandwidth. If the sweeper module is in impedance application mode the precision setting will also control the sweeper measurement speed. |
| | Low → fast settling | Medium accuracy/precision is optimized for fast response. |
| | High → medium settling | High accuracy/precision takes more settling time. |
| | Very high → slow settling | Very high accuracy/precision uses long settling time due to very low bandwidth. |
| Show Advanced | ON / OFF | Display the advanced settings. |
| Bias Control (V) | -3 V to 3 V | DC bias voltage applied across the device under test. Both positive and negative bias voltages are supported. In a 4-terminal measurement, the bias voltage is limited by the maximum common voltage input range of the device. In a 2-terminal measurement, the bias voltage can be larger because the voltage inputs are not connected. |
| Bias Control Enable | ON / OFF | Enables bias control. The bias is generated by the additional offset applied on the output. |
| Current Input | Current Input 1 | Select the current input used for two- and four-terminal impedance measurements. |
| Current Invert Enable | ON / OFF | If enabled, the current input signal is inverted. This is useful to switch the polarity of an input signal which can be caused by additional current amplifiers. |
| Scaling factor for current input | numeric value | The value measured at the current input will be scaled by this value. |
| Voltage Input | Voltage Input 1 | Select the voltage input used for a four-terminal impedance measurement. |

| Control/Tool | Option/Range | Description |
|----------------------------------|---------------------------------|---|
| Voltage Invert Enable | ON / OFF | If enabled, the voltage input signal is inverted. |
| Scaling factor for voltage input | numeric value | The value measured at the voltage input will be scaled by this value. |
| AC | ON / OFF | Defines the input coupling for the Signal Inputs. AC coupling inserts a high-pass filter. |
| Current Demodulator | demodulator index | Demodulator used for current demodulation. |
| Voltage Demodulator | demodulator index | Demodulator used for voltage measurement in case of a four-terminal impedance measurement. |
| Output Demodulator | demodulator index | Demodulator unit used to generate the excitation voltage on the Signal Output. |
| Interpolation | | Select the interpolation method of the compensation data. The interpolation method is particularly important if the derivative changes strongly e.g at cut-off frequencies. |
| | Linear | The linear interpolation is fastest but may create compensation errors in between the frequency points used for compensation. |
| | Piecewise Cubic Hermite (PCHIP) | The piecewise cubic Hermite interpolation will result in very accurate results but requires more calculation power. |
| Osc | oscillator index | Oscillator used to generate the frequency of the excitation voltage on the Hcur (+V) connector. |
| Harm | 1 to 1023 | Multiplies the demodulator's reference frequency with the integer factor defined by this field. |
| Order | | Select the filter roll-off between 6 dB/oct and 48 dB/oct. High filter orders are beneficial for impedance measurements as they help to suppress DC offsets. |
| | 1 | 1st order filter 6 dB/oct |
| | 2 | 2nd order filter 12 dB/oct |
| | 3 | 3rd order filter 18 dB/oct |
| | 4 | 4th order filter 24 dB/oct |
| | 5 | 5th order filter 30 dB/oct |
| | 6 | 6th order filter 36 dB/oct |
| | 7 | 7th order filter 42 dB/oct |
| | 8 | 8th order filter 48 dB/oct |
| TC/BW Select | | Define the display unit of the low-pass filters: time constant (TC), noise-equivalent power bandwidth (BW NEP), 3 dB bandwidth (BW 3 dB). |
| | TC | Define the low-pass filter characteristic using time constant of the filter. |

| Control/Tool | Option/Range | Description |
|--------------|-------------------------|---|
| | BW NEP | Define the low-pass filter characteristic using the noise-equivalent power bandwidth of the filter. |
| | BW 3 dB | Define the low-pass filter characteristic using the cut-off frequency of the filter. |
| TC/BW Value | numeric value | Defines the low-pass filter characteristic in the unit defined above. |
| Sinc | ON / OFF | Enables the sinc filter. |
| Rate | 0.056 Sa/s to 857 kSa/s | Impedance data streaming rate. The same data rate is applied to the demodulators that are used for the impedance measurement. |
| On | ON / OFF | Main switch for the Signal Output corresponding to the blue LED indicator on the instrument front panel. |
| Range | | Defines the maximum output voltage that is generated by the corresponding Signal Output. This includes the potential multiple Signal Amplitudes and Offsets summed up. Select the smallest range possible to optimize signal quality. |
| | 10 mV | Selects output range ± 10 mV. |
| | 100 mV | Selects output range ± 100 mV. |
| | 1 V | Selects output range ± 1 V. |
| | 10 V | Selects output range ± 10 V. |
| Enable | ON / OFF | Discarding impedance samples outside the indicated range. |
| Minimum | ON / OFF | Threshold for $\text{abs}(Z)$ below which the impedance samples are discarded. |
| Maximum | ON / OFF | Threshold for $\text{abs}(Z)$ above which the impedance samples are discarded. |

Table 4.47. Impedance Analyzer tab: Compensation sub-tab

| Control/Tool | Option/Range | Description |
|--------------------------|----------------------|--|
| Compensation Type Select | | Displays information on either internal calibration or user compensation. |
| | Internal Calibration | The internal calibration matches all voltage and current ranges over the frequency range in order to achieve a high dynamic impedance range. The internal calibration is performed at Zurich instruments. |
| | User Compensation | The user compensation will correct for measurement setup influences like capacitive or inductive parasitics. It is applied on top of the internal calibration. |
| Internal | ON / OFF | Enables the internal calibration. This ensures that the input range gains match over the |

| Control/Tool | Option/Range | Description |
|---------------------------------|-----------------------|---|
| | | full frequency range. With enabled internal calibration the device fulfills the impedance accuracy specification. The internal calibration is a prerequisite to apply a user compensation. |
| Active | grey/green | Indicates if the internal calibration is applied to the measurement data. |
| Smooth Internal Data | ON / OFF | Smoothing of internal calibration data. |
| Internal Calibration Info | | Display of meta data saved together with the internal impedance calibration data. |
| User | ON / OFF | Enables the compensation of the impedance data. The user compensation is correcting parasitics and delays caused by the external setup. The user compensation is applied on top of the internal impedance calibration. |
| Active | grey/green | Indicates that a valid compensation is active. If active the impedance data streams deliver amplitude and phase corrected data based on the impedance compensation. |
| Smooth User Data | ON / OFF | Smoothing of user compensation data. Smoothing is only possible if the compensation data contains at least 21 points. |
| User Compensation Info | | Display of meta data saved together with the user compensation. |
| File Name for User Compensation | | Enter a new file name to save the current user compensation to a file or select an existing file to load a user compensation. |
| Save User Compensation | | Save the current user compensation to a file. |
| Load User Compensation | | Load a user compensation from a file. |
| Mode | | Select the user compensation sequence. If the sequence involves a short or open condition, it is essential to keep the noise small by using auto range on the voltage and current inputs. |
| | None | No compensation is performed. |
| | SOL (Short-Open-Load) | Compensation of user setup using a short-open-load condition. This compensation method results in very accurate results over the whole impedance range under the condition of low-noise open and short compensation. Thus, this compensation should always be used with enabled auto range. |
| | OL (Open-Load) | The open-load compensation is suited for measuring high impedance. Use auto range to reduce the influence of noise for the open compensation step. |
| | SL (Short-Load) | The short-load compensation is suited for measuring low impedance. |

| Control/Tool | Option/Range | Description |
|-----------------------------|----------------------|---|
| | L (Load) | Compensation performed with a single load. This compensation is useful if the measured DUT is close to the load used for compensation. |
| | SO (Short-Open) | The short-open compensation corrects for inductive and capacitive parasitics of the user setup. This compensation method is suited if no load is available for the compensation. It will not correct gain errors. |
| | LLL (Load-Load-Load) | The compensation based on three load values results in very accurate results for a restricted impedance range. Use this method if the noise on the open or short condition is too strong. |
| Load R | numeric value | Resistance value of the compensation load. |
| Load C | numeric value | Capacitance value of the compensation load. In case of a resistor load the capacitance value is equivalent to its capacitive parasitics. |
| Step | Short, Open, Load | Compensation step to record. The sequence of the steps can be freely selected. Before starting the correct device needs to be connected to the setup. |
| Compensation Step Short | ON / OF | Select to do a short measurement. This compensates for parasitics that are in series with your DUT. |
| Compensation Step Open | ON / OF | Select to do an open measurement. This compensates for parasitics that are in parallel with your DUT. |
| Compensation Step Load | ON / OF | Select to do a load measurement. This compensates for additional gains in your measurement setup. |
| Compensation Step High Load | ON / OF | Select to do a high load measurement. This compensates for additional gains in your measurement setup. |
| Status | grey/green | Indicates a successful compensation step. If the status indicator does not indicate green after a compensation step, check the message box to learn more about the failure. |
| Compensate | Compensate | Start the compensation measurement for the selected condition. If a compensation measurement is completed successfully, the next pending condition is automatically selected. The message box will contain information on the quality of the completed compensation and failure messages in case of a fail. The progress of the currently active compensation run will be shown in the message box. |
| Message | string | The message pane displays information related to compensation. In case of a failed compensation, information on the root cause is reported. In case of successful |

| Control/Tool | Option/Range | Description |
|---------------|------------------------|---|
| | | compensation, representative parameters are reported to judge the quality of the compensation and measurement setup. |
| Comment | string | User comment that will be saved together with the compensation data. The comment string can also be changed between the different compensation steps. |
| Validation | ON / OFF | Perform a sanity check of the compensation result to detect outlier measurement results, overload, or other error conditions. Validation should only be disabled for compensations performed in special conditions. |
| High Z Load | ON / OFF | Two different loads are measured during user compensation. Improves compensation data. |
| Auto Transfer | ON / OFF | If enabled, a successful compensation will be immediately transferred to the device, activated, and stored permanently. If automatic transfer is disabled, the transfer needs to be initiated manually. |
| On Device | On Device | Transfer and activate the recorded compensation manually. |
| Persistent | Persistent | Store the compensation data persistently on the device. The compensation will be loaded automatically on every power-up. |
| Start (Hz) | 0 to 5 MHz | Lower frequency limit used for calibration. For measurements at lower frequencies than this value, an extrapolation is performed. |
| Stop (Hz) | 0 to 5 MHz | Upper frequency limit used for calibration. This upper limit is essential for correct measurements. |
| Points | positive integer value | Number of frequency points used for compensation. For frequencies between two compensation frequencies the data will be interpolated. |
| Precision | | Precision of measurement during compensation. Using high precision can improve the quality of the compensation data in case the measurement is limited by noise. |
| | Standard | Standard filter and averaging settings are applied during compensation measurement |
| | High | Lower filter bandwidth and more averaging are used during compensation measurement |

4.15. Config Tab

The Config tab provides access to all major LabOne settings and is available on all MFLI instruments.

4.15.1. Features

- define instrument connection parameters
- browser session control
- define UI appearance (grids, theme, etc.)
- store and load instrument settings and UI settings
- configure data recording

4.15.2. Description

The Config tab serves as a control panel for all general LabOne settings and is opened by default on start-up. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.48. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Config | | Provides access to software configuration. |

The Config tab (see [Figure 4.36](#)) is divided into five sections to control connections, sessions, settings, user interface appearance and data recording.




Figure 4.36. LabOne UI: Config tab

The **Connection** section provides information about connection and server versions. Access from remote locations can be restricted with the connectivity setting.

The **Session** section provides the session number which is also displayed in the status bar. Clicking on Session Dialog opens the session dialog window (same as start up screen) that allows one to load different settings files as well as to connect to other instruments.

The **Settings** section allows one to load and save instrument and UI settings. The saved settings are later available in the session dialog.

The **User Preferences** section contains the settings that are continuously stored and automatically reloaded the next time an MFLI instrument is used from the same computer account.

For low ambient light conditions the use of the dark display theme is recommended (see [Figure 4.37](#)).




Figure 4.37. LabOne UI: Config tab - dark theme

The **Record Data** section contains all settings necessary to obtain hard copies of measurement data. The tree structure (see [Tree Selector](#) section) provides access to a large number of signals and instrument settings. Use the View Filter in order to reduce the tree structure to the most commonly used nodes such as the demodulator sample nodes. Whenever the Record button is enabled, all selected nodes get saved continuously in MATLAB, comma-separated value (CSV), or other supported file formats. For each selected node at least one file gets generated, but the data may be distributed over several files during long recordings. The files are normally saved to the internal storage of the MFLI or on a mass storage device connected to one of the instrument's USB ports. In order to save data directly on the host computer, please install and run the LabOne Web Server on the host computer as described in [Section 1.5](#). See [Section 4.2](#) for more information on data saving. The quickest way to inspect the files after recording is to use the File Manager tab described in [Section 4.17](#). Apart from the numerical data and settings, the files contain timestamps. These integer numbers encode the measurement time in units of the instrument clock period 1/(60 MHz). The timestamps are universal within one instrument and can be used to align the data from different files.

4.15.3. Functional Elements

Table 4.49. Config tab

| Control/Tool | Option/Range | Description |
|----------------------------------|---------------------------------|--|
| About | About | Get information about LabOne software. |
| Web Server Version and Revision | string | Web Server version and revision number |
| Host | default is localhost: 127.0.0.1 | IP-Address of the LabOne Web Server |
| Port | 4 digit integer | LabOne Web Server TCP/IP port |
| Data Server Version and Revision | string | Data Server version and revision number |
| Host | default is localhost: 127.0.0.1 | IP-Address of the LabOne Data Server |
| Port | default is 8004 | TCP/IP port used to connect to the LabOne Data Server. |
| Connect/Disconnect | | Connect/disconnect the LabOne Data Server of the currently selected device. If a LabOne Data Server is connected only devices that are visible to that specific server are shown in the device list. |
| Status | grey/green | Indicates whether the LabOne User Interface is connected to the selected LabOne data server. Grey: no connection. Green: connected. |

| Control/Tool | Option/Range | Description |
|-----------------|--|--|
| Connectivity | Localhost Only | Forbid/Allow to connect to this Data Server from other computers. |
| | From Everywhere | |
| File Upload | drop area | Drag and drop files in this box to upload files. Clicking on the box opens a file dialog for file upload. Supported files: Settings (.xml), software update (LabOne.tar) . Uploading software updates will automatically trigger the update process if the file is valid and has a different revision than the currently installed software. |
| Load From USB | Load From USB | Load public SSH keys from the USB mass storage connected to the device. Uploading of SSH keys enables SSH access to the device. |
| Delete All | Delete All | Delete all public SSH keys on the device. |
| Time Zone | Timezone offset from UTC (Coordinated Universal Time). | Select the time zone in which the device is used. Settings, data and log files receive timestamps from this time zone. Requires a power cycle for changes to become effective. |
| Session Id | integer number | Session identifier. A session is a connection between a client and LabOne Data Server. |
| Session Manager | Session Manager | Open the session manager dialog. This allows for device or session change. The current session can be continued by pressing cancel. |
| File Name | selection of available file names | Save/load the device and user interface settings to/from the selected file on the internal flash drive. The setting files can be downloaded/uploaded using the Files tab. |
| Include | | Enable Save/Load of particular settings. |
| | No Include Settings | Please enable settings type to be included during Save/Load. |
| | Include Device | Enable Save/Load of Device settings. |
| | Include UI | Enable Save/Load of User Interface settings. |
| | Include UI and Device | Enable Save/Load of User Interface and Device settings. |
| | Include Preferences | Enable loading of User Preferences from settings file. |
| | Include UI, Device and Preferences | Enable Save/Load of User Interface, Device and User Preferences. |
| Save | Save | Save the user interface and device setting to a file. |
| Load | Load | Load the user interface and device setting from a file. |
| Language | | Choose the language for the tooltips. |
| Display Theme | Light | Choose theme of the user interface. |
| | Dark | |

| Control/Tool | Option/Range | Description |
|-------------------|---------------------|---|
| Plot Print Theme | Light | Choose theme for printing SVG plots. |
| | Dark | |
| Plot Grid | Dashed | Select active grid setting for all SVG plots. |
| | Solid | |
| Plot Rendering | | Select rendering hint about what tradeoffs to make as the browser renders SVG plots. The setting has impact on rendering speed and plot display for both displayed and saved plots. |
| | Auto | Indicates that the browser shall make appropriate tradeoffs to balance speed, crisp edges and geometric precision, but with geometric precision given more importance than speed and crisp edges. |
| | Optimize Speed | The browser shall emphasize rendering speed over geometric precision and crisp edges. This option will sometimes cause the browser to turn off shape anti-aliasing. |
| | Crisp Edges | Indicates that the browser shall attempt to emphasize the contrast between clean edges of artwork over rendering speed and geometric precision. To achieve crisp edges, the user agent might turn off anti-aliasing for all lines and curves or possibly just for straight lines which are close to vertical or horizontal. |
| | Geometric Precision | Indicates that the browser shall emphasize geometric precision over speed and crisp edges. |
| Resampling Method | | Select the resampling interpolation method. Resampling corrects for sample misalignment in subsequent scope shots. This is important when using reduced sample rates with a time resolution below that of the trigger. |
| | Linear | Linear interpolation |
| | PCHIP | Piecewise Cubic Hermite Interpolating Polynomial |
| Show Shortcuts | ON / OFF | Displays a list of keyboard and mouse wheel shortcuts for manipulating plots. |
| Dynamic Tabs | ON / OFF | If enabled, sections inside the application tabs are collapsed automatically depending on the window width. |
| Graphical Mode | Auto | Select the display mode for the graphical elements. Auto format will select the format which fits best the current window width. |
| | Expanded | |
| | Collapsed | |
| Log Format | Telnet | Choose the command log format. See status bar and [User]\Documents\Zurich Instruments\LabOne\WebServer\Log |
| | Matlab | |

| Control/Tool | Option/Range | Description |
|-----------------|--|---|
| CSV Delimiter | Python | Select which delimiter to insert for CSV files. |
| | .NET | |
| | Comma | |
| CSV Locale | Semicolon | Select the locale used for defining the decimal point and digit grouping symbols in numeric values in CSV files. The default locale uses dot for the decimal point and no digit grouping, e.g. 1005.07. The system locale uses the symbols set in the language and region settings of the computer. |
| | Tab | |
| HDF5 Saving | Default locale. Dot for the decimal point and no digit grouping, e.g. 1005.07 | For HDF5 file format only: Select whether each measurement should be stored in a separate file, or whether all measurements should be saved in a single file. |
| | System locale. Use the symbols set in the language and region settings of the computer | |
| Auto Start | ON / OFF | <p>Skip session manager dialog at start-up if selected device is available.</p> <p>In case of an error or disconnected device the session manager will be reactivated.</p> |
| Update Reminder | ON / OFF | Display a reminder on start-up if the LabOne software wasn't updated in 180 days. |
| Update Check | ON / OFF | Periodically check for new LabOne software over the internet. |
| Drive | | Select the drive for data saving. |
| | MF Flash Drive | Internal flash mass storage device of the MFLI/MFIA. |
| | USB 1/2 | Mass storage device connected on USB. |
| Format | ZView | File format of recorded and saved data. |
| | Matlab | |
| | CSV | |
| | SXM (Nanonis) | |
| Open Folder | | Open recorded data in the system File Explorer. |
| Folder | path indicating file location | Folder containing the recorded data. |
| Save Interval | Time in seconds | Time between saves to disk. A shorter interval means less system memory consumption, but for certain file formats (e.g. MATLAB) many small files on disk. A longer interval means more system memory consumption, but for |

| Control/Tool | Option/Range | Description |
|--------------|------------------------------|---|
| | | certain file formats (e.g. MATLAB) fewer, larger files on disk. |
| Queue | integer number | Number of data chunks not yet written to disk. |
| Size | integer number | Accumulated size of saved data in the current session. |
| Record | ON / OFF | Start and stop saving data to disk as defined in the selection filter. Length of the files is determined by the Window Length setting in the Plotter tab. |
| Writing | grey/green | Indicates whether data is currently written to disk. |
| Display | filter or regular expression | Display specific tree branches using one of the preset view filters or a custom regular expression. |
| Tree | ON / OFF | Click on a tree node to activate it. |
| All | | Select all tree elements. |
| None | | Deselect all tree elements. |

For more information on the tree functionality in the Record Data section, please see [Tree Selector](#).

4.16. Device Tab

The Device tab is the main settings tab for the connected instrument and is available on all MFLI instruments.

4.16.1. Features

- Option and upgrade management
- External clock referencing (10 MHz)
- Instrument connectivity parameters
- Device monitor


4.16.2. Description

The **Device tab** serves mainly as a control panel for all settings specific to the instrument that is controlled by LabOne in this particular session. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.50. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--|--|
| Device |  | Provides instrument specific settings. |

The Device tab (see [Figure 4.38](#)) is divided into five sections: general instrument information, configuration, communication parameters, device presets, and a device monitor.



The screenshot shows the LabOne User Interface (UI) with the 'Device' tab selected. The interface is divided into several sections:

- Information:** Displays device details like ID, serial number, type, and installed options (MD, PID, MOD, DIG, FSM, IA). It also includes sections for revisions (FPGA, Digital Board, Firmware), and buttons for 'Install', 'More info', and 'Upgrade'.
- Configuration:** Allows changing the clock source between 'Internal' and '10MHz'. It also includes a 'Settings' section for clock source.
- Presets:** Manages instrument start-up configurations. It lists 'Active Preset' (Factory default) and 'Presets' (0-6). Buttons for 'Load', 'Save', and 'Erase' are available. A 'Default' button is also present.
- Communication:** Shows current configuration (Interface: PCIe, MAC Address: 80:2F:DE:00:0B:6B, IPv4 Address: 10.42.2.115) and network configuration (1GbE, Jumbo Frames, Static IP: 192.168.1.10, IPv4 Mask: 255.255.255.0, IPv4 Gateway: 0.0.0.0). It also includes a 'Program' button.
- Statistics:** Provides an overview of command communication (Pending: 15, Processing: 1, Packet Loss: 0, Bandwidth: 0.032 Mbit/s) and data communication (Pending: 15, Processing: 1, Packet Loss: 0, Bandwidth: 1.79 Mbit/s).

Figure 4.38. LabOne UI: Device tab

The **Information** section provides details about the instrument hardware and indicates the installed upgrade options. This is also the place where new options can be added by entering the provided option key.

The **Configuration** section allows one to change the reference from the internal clock to an external 10 MHz reference. The reference is to be connected to the Clock Input on the instrument back panel.

The **Presets** section allows you to define a custom instrument start-up configuration different from the factory default. This configuration is stored in the instrument itself and are applied independently of the control PC. This saves time in cases where the control PC is not routinely needed, for instance when using only analog interfaces the instrument configuration is fixed.

The **Communication** section offers access to the instruments TCP/IP settings.

The **Statistics** section gives an overview on communication statistics. In particular the current data rate (Bandwidth) that is consumed.

Note

Packet loss on data streaming over UDP or USB: data packets may be lost if total bandwidth exceeds the available physical interface bandwidth. Data may also be lost if the host computer is not able to handle high-bandwidth data.

Note

Packet loss on command streaming over TCP or USB: command packets should never be lost as it creates an invalid state.

The **Wireless Network** section controls the wireless device access using the WiFi USB adapter delivered with the instrument. See [wireless connection](#) for instructions how to connect to the instrument via wireless network.

The **Device Monitor** section is collapsed by default and generally only needed for servicing. It displays vitality signals of some of the instrument's hardware components.

4.16.3. Functional Elements

Table 4.51. Device tab

| Control/Tool | Option/Range | Description |
|------------------------|-----------------------------|--|
| FPGA | integer number | HDL firmware revision. |
| Digital Board | version number | Hardware revision of the FPGA base board. |
| Firmware | integer number | Revision of the device internal controller software. |
| Serial | 1-4 digit number | Device serial number |
| Type | string | Device type |
| Installed Options | short names for each option | Options that are installed on this device. |
| Install | Install | Click to install options on this device. Requires a unique feature code and a power cycle after entry. |
| More Information | | Display additional device information in a separate browser tab. |
| Upgrade Device Options | | Display available upgrade options. |
| Clock Source | | 10MHz reference clock source. |
| | Internal | The internal 10MHz clock is used as the frequency and time base reference. |
| | Clk 10MHz | An external 10MHz clock is intended to be used as the frequency and time base reference. Provide a clean and stable 10MHz reference to the appropriate back panel connector. |
| Index | | Select between factory preset or presets stored in internal flash memory. |

| Control/Tool | Option/Range | Description |
|--------------|----------------------|--|
| | Factory | Select factory preset. |
| | Flash 1-6 | Select one of the presets stored in internal flash memory 1-6. |
| Load | Load | Load the selected preset. |
| Save | Save | Save the actual setting as preset. |
| Erase | Erase | Erase the selected preset. |
| Busy | grey/green | Indicates that the device is busy with either loading, saving or erasing a preset. |
| Error | | Returns a 0 if the last preset operation was successfully completed or 1 if the last preset operation was illegal. |
| | 0 | Last preset operation was successfully completed. |
| | 1 | Last preset operation was illegal. |
| Error LED | grey/red | Turns red if the last operation was illegal. |
| Valid LED | grey/green | Turns green if a valid preset is stored at the respective location. |
| Presets | | Shows a list of available presets including factory preset. |
| | 0 | Factory default preset. The name of the factory default preset is given and can not be edited. |
| | 1 | Flash preset 1. The name of this preset can be edited. |
| | 2 | Flash preset 2. The name of this preset can be edited. |
| | 3 | Flash preset 3. The name of this preset can be edited. |
| | 4 | Flash preset 4. The name of this preset can be edited. |
| | 5 | Flash preset 5. The name of this preset can be edited. |
| | 6 | Flash preset 6. The name of this preset can be edited. |
| Default | | Indicates the preset which is used as default preset at start-up of the device. |
| | Factory | Select factory preset as default preset. |
| | Flash 1-6 | Select one of the presets stored in internal flash memory 1-6 as default preset. |
| MAC Address | 80:2F:DE:xx:xx:xx | MAC address of the device. The MAC address is defined statically, cannot be changed and is unique for each device. |
| IPv4 Address | default 192.168.1.10 | Current IP address of the device. This IP address is assigned dynamically by a DHCP server, defined statically, or is a fall-back IP |

| Control/Tool | Option/Range | Description |
|------------------------|-----------------------|---|
| | | address if the DHCP server could not be found (for point to point connections). |
| Jumbo Frames | ON / OFF | Enable jumbo frames for this device and interface as default. |
| Static IP | ON / OFF | Enable this flag if the device is used in a network with fixed IP assignment without a DHCP server. |
| IPv4 Address | default 192.168.1.10 | Static IP address to be written to the device. |
| IPv4 Mask | default 255.255.255.0 | Static IP mask to be written to the device. |
| Gateway | default 192.168.1.1 | Static IP gateway |
| Program | Program | Click to program the specified IPv4 address, IPv4 Mask and Gateway to the device. |
| Pending | integer value | Number of buffers ready for receiving command packets from the device. |
| Processing | integer value | Number of buffers being processed for command packets. Small values indicate proper performance. For a TCP/IP interface, command packets are sent using the TCP protocol. |
| Packet Loss | integer value | Number of command packets lost since device start. Command packets contain device settings that are sent to and received from the device. |
| Bandwidth | numeric value | Command streaming bandwidth usage on the physical network connection between device and data server. |
| Pending | integer value | Number of buffers ready for receiving data packets from the device. |
| Processing | integer value | Number of buffers being processed for data packets. Small values indicate proper performance. For a TCP/IP interface, data packets are sent using the UDP protocol. |
| Packet Loss | integer value | Number of data packets lost since device start. Data packets contain measurement data. |
| Bandwidth | numeric value | Data streaming bandwidth usage on the physical network connection between device and data server. |
| WiFi Available LED | grey/green | Turns green if a supported WiFi USB adapter is connected to the device. |
| WiFi Mode | | Select the WiFi operation mode |
| | Disabled | WiFi operation is disabled. |
| | Access Point | Create a new WiFi network and operate the device as an access point. |
| | Client | Join an existing WiFi network as a client. |
| Advanced WiFi Settings | ON / OFF | Enables manual selection of WiFi settings. |

| Control/Tool | Option/Range | Description |
|-----------------|----------------------|--|
| WiFi SSID | default: device ID | Set the SSID of the network to create (in access point mode) or join (in client mode). |
| WiFi Password | default: password123 | Set the password of the network to create (in access point mode) or join (in client mode). In access point mode the password must be between 8 and 63 characters long. |
| WiFi Channel | | Select the WiFi channel of the network to create (in access point mode). |
| | Channel 1 | WiFi channel 1 (2.412 GHz) |
| | Channel 6 | WiFi channel 6 (2.437 GHz) |
| | Channel 11 | WiFi channel 11 (2.462 GHz) |
| Enable WiFi | ON / OFF | Enable/disable WiFi network with given settings. In access point mode, the device will be reachable via the IP address 192.168.20.1 |
| Program | Program | Program the specified WiFi settings to the device. |
| FW Load | numeric value | Indicates the CPU load on the processor where the firmware is running. |
| CPU Load | numeric value | Indicates the total CPU load on the machine where the data server is running. |
| CPU Temperature | numeric value | Indicates the temperature of the MF-internal CPU where the data server is running. |
| Memory Usage | numeric value | Indicates the total memory usage of the machine where the data server is running. |
| Interface | 1. PCIe | Active interface between device and data server. In case multiple options are available, the priority as indicated on the left applies. |

4.17. File Manager Tab

The File Manager tab provides a quick access to the files stored on the instrument flash drive as well as any mass storage attached to one of the USB connectors.

4.17.1. Features

- Download measurement data, instruments settings and log files to a local device
- Manage file structure (browse, copy, rename, delete) on instrument flash drive and attached USB mass storage devices
- Update instrument from USB mass storage
- File preview for settings files and log files

4.17.2. Description

The File Manager tab provides standard tools to see and organize the files on the instrument flash drive as well as on attached USB storage devices. Files can be conveniently copied, renamed, downloaded and deleted. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.52. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|--|
| Files |  | Access files on internal flash memory and USB drive. |

The Files tab (see [Figure 4.39](#)) provides three windows for exploring. The left window allows one to browse through the directory structure, the center window shows the files of the folder selected in the left window, and the right window displays the content of the file selected in the center window, e.g. a settings file or log file.




Figure 4.39. LabOne UI: File Manager tab

4.17.3. Functional Elements

Table 4.53. File tab

| Control/Tool | Option/Range | Description |
|--------------|-------------------|--|
| New Folder | New Folder | Create new folder at current location. |
| Rename | Rename | Rename selected file or folder. |

4.17. File Manager Tab

| Control/Tool | Option/Range | Description |
|--------------|-----------------|--|
| Delete | Delete | Delete selected file(s) and/or folder(s). |
| Copy | Copy | Copy selected file(s) and/or folder(s) to Clipboard. |
| Cut | Cut | Cut selected file(s) and/or folder(s) to Clipboard. |
| Paste | Paste | Paste file(s) and/or folder(s) from Clipboard to the selected directory. |
| Upload | Upload | Upload file(s) and/or folder(s) to the selected directory. |
| Download | Download | Download selected file(s) and/or folder(s). |

4.18. PID / PLL Tab

The PID / PLL tab is only available if the MF-PID Quad PID/PLL Controller option is installed on the MFLI Instrument (the installed options are displayed in the Device tab).

Note

The feedback controllers provide general-purpose PID functionality, phase-locked loop (PLL) functionality, and External Reference functionality. When the user sets one of the demodulators to ExtRef mode (see Lock-in tab, Demodulators section, Mode column), one of the PID controllers will be reserved for that purpose.

Note

Some settings in the PID / PLL tab are interdependent with settings that are accessible from other tabs. If the PID output controls a certain variable, e.g. Signal Output Offset, this variable will be shown as read-only where it appears in other tabs (i.e. in the Lock-in tab for this case).

4.18.1. Features

- Four fully programmable proportional, integral, derivative (PID) controllers
- Two fully programmable 5 MHz / 500 kHz phased-locked loops
- PID / PLL Advisor with multiple DUT models, transfer function, and step function modeling
- Auto Tune: Automatic minimization of the amplitude of the PID error signal
- High speed operation with up to 50 kHz loop filter bandwidth
- Input parameters: demodulator data, auxiliary inputs, auxiliary outputs
- Output parameters: output amplitudes, oscillator frequencies, demodulator phase, auxiliary outputs, signal output offsets
- Phase unwrap for demodulator Θ data ($\pm 1024 \pi$), e.g. for optical phase-locked loops
- Bandwidth limit for the derivative (D) feedback component
- Programmable PLL center frequency and phase setpoint
- Programmable PLL phase detector filter settings
- Auto-zero functions for PLL center frequency and setpoint
- Generation of sub-multiple frequencies by use of harmonic multiplication factor

4.18.2. Description

The PID / PLL tab is the main control center for the feedback loop controllers in the instrument. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.54. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| PID | | Features all control, analysis, and simulation capabilities of the PID controllers. |

The PID / PLL tab (see Figure 4.40) consists of four identical side-tabs, each of them providing access to the functionality of one of the four PID / PLL controllers and the associated PID Advisor.




Figure 4.40. LabOne UI: PID / PLL tab

With their variety of different input and output connections, the LabOne PID controllers are extremely versatile and can be used in a wide range of different applications including laser locking or high-speed SPM. Figure 4.41 shows a block diagram of all PID controller components, their interconnections and the variables to be specified by the user.




Figure 4.41. PID controller block diagram

Setting up a Control Loop

Depending on the application there are a number of ways to set up a control loop. Let's consider a few different approaches and see how the Advisor can help to reduce the effort and improve on the result and understanding of the setup.

Manual Setup

In cases where the transfer function of the device under test (DUT) is unknown and only little noise couples into the system from the environment, a manual approach is often the quickest

way to get going. For manual configuration of a new control loop it is recommended to start with a small value for P and set the other parameters (I, D, D Limit) to zero. By enabling the controller one will then immediately see if the sign of P is correct and if the feedback is acting on the correct output parameter for instance by checking the numbers (Error, Shift, Out) displayed in the PID / PLL tab. A stepwise increase of the integral gain I will then help to zero the PID error signal completely. Enabling the derivative gain D can increase the speed of the feedback loop, but it can also cause an unstable feedback loop behavior. Monitoring the PID error in the [Section 4.6](#) in parallel can be a great help at this stage. The math tools offered by the Plotter allow us to display the standard deviation and the average value of the error. These values should be minimized by tweaking the PID parameters and the associated histogram should have a symmetric (ideally Gaussian) envelope.

In order to characterize the feedback loop quantitatively, you can measure the step response in the [Section 4.8](#). To do that measurement, change the PID setpoint manually after you have configured the DAQ Trigger level half way in between the old and new setpoint. DAQ Delay and Duration are chosen to roughly match the expected bandwidth. For a step response curve with fine time resolution, the PID data rate should be high enough.

PID Advisor

For many experimental situations the external device or DUT can be well approximated by a simple model. The LabOne PID Advisor allows you to simulate the behavior of a number of different DUT types in a feedback loop and choose feedback gain parameters based on the simulation. The DUTs are characterized by a model function with a number of parameters found on the Advisor sub-tab. All models include a setting for the delay that occurs outside the instrument. Depending on the targeted servo bandwidth, the external delay can often be the limiting factor and should be sensibly chosen.

Note

The delay specified for each model is the earliest possible response to a stepwise change of the instrument output to be seen on the instrument input. It describes the causality of the system and does not affect the shape of the DUT transfer function. Standard coaxial cables cause a signal delay of about 5 ns/m.

The most simple approach to modeling is to assume a DUT with a unity transfer function by using All Pass. The low-pass filters allow for limiting the bandwidth, to set an overall gain and a damping for the second order filter. With a Gain set to 1 and a Delay set to 0, All Pass can be used to model the PID controller independent of the external device. Resonator Frequency is a model that applies well in situations with a passive external component, e.g. a AFM cantilever or a quartz resonator, whose frequency should be tracked by a PLL over time. In cases where the amplitude of the resonator signal needs to be stabilized with a second control loop (automatic gain control), the Resonator Amplitude model is the right choice. Setting the resonance frequency and the Q factor, both can be obtained before by a frequency scan over the resonance using the [Section 4.10](#), allows the Advisor to estimate the gain and low-pass behavior of the resonator. Internal PLL is used whenever an external oscillating signal is provided that shall be followed by one of the internal oscillators. The VCO setting describes a situation where the input variable of the DUT is a voltage and the output is a frequency. The gain parameter specifies how much voltage change on the input causes how much frequency shift on the VCO output. In case the frequency of the VCO can be tracked by using the external reference mode, one can easily measure this gain with the [Section 4.10](#) by scanning the Auxiliary Output voltage and displaying the resulting oscillator frequency. The gain is given by the slope of the resulting line at the frequency of interest.

With a model and parameters set to best describe the actual measurement situation, one can now continue by defining a target bandwidth for the entire control loop and the Advise Mode, i.e.

the feedback gain parameters that shall be used for the control operation. Whenever the input signal is derived from one of the demodulators it is convenient to activate the box next to target bandwidth. With that in place the Advisor algorithm will automatically adjust the demodulator bandwidth to a value about 5 times higher than the target bandwidth in order to avoid to be limited by demodulation speed. The Advisor algorithm will now calculate a target step response function that it will try to achieve by adjusting the feedback gain parameters in the next step. Before doing so in case of a newly set up DUT model, the algorithm will first try to estimate the PID parameters by using the Ziegler-Nichols method. When there has been a previous run, the user can also change the parameters in the model manually which will be used as new start parameters of the next Advisor run. Starting from the initial parameters, the Advisor will then perform a numerical optimization in order to achieve a least-squares fit of the calculated step response to a target step response determined from the Target Bandwidth. The result is numerically characterized by an achieved bandwidth (BW) and a phase margin (PM). Moreover, the large plot area on the right can be used to characterize the result by displaying transfer functions, magnitude and phase, and step responses between different signal nodes inside the loop. Once the modeling is completed one can copy the resulting parameters to the physical PID by clicking on [To PID](#).

Table 4.55. DUT transfer functions

| Name | Function | Parameters |
|---------------------|--|--|
| All pass | $H(s)=g$ | 1. Gain g |
| Low-pass 1st | $H(s)=g\frac{1}{t_c s + 1} = g\frac{\omega_n}{s + \omega_n}$ | 1. Gain g 2. Filter bandwidth (BW) $f_{-3dB} = \omega_n/2\pi$ |
| Low-pass 2nd | $H(s)=g\frac{\omega_n^2}{s^2+2\omega_n\zeta s+\omega_n^2}$ | 1. Gain g 2. Resonance frequency $f_{res}=\omega_n/2\pi$ 3. Damping ratio ζ with $f_{-3dB}=2\zeta f_{res}$ |
| Resonator frequency | $H(s) = -360^\circ \frac{1}{t_c s + 1}$ with $t_c = \frac{2\pi BW}{f_{res}} = \frac{2Q}{2\pi f_{res}}$ | 1. Resonance frequency f_{res} 2. Quality factor Q |
| Resonator amplitude | $H(s)=g\frac{\omega_n}{(2Q)s+\omega_n/(2Q)}$ with $\omega_n=2\pi f_{res}$ | 1. Gain g 2. Resonance frequency f_{res} 3. Quality factor Q |
| Internal PLL | $H_8s=-\frac{360^\circ}{s}$ | |
| VCO | $H(s)=g\frac{360^\circ}{s(t_c s + 1)}$ with $t_c = \frac{1}{2\pi f_{res}}$ | 1. Gain g (Hz/V) 2. Bandwidth (BW) f_{-3dB} |

Note

It is recommended to use the Advisor in a stepwise approach where one increases the free parameters from P to PI, to PID . This can save time because it prevents optimizing into local

minima. Also it can be quite illustrative to see which of the feedback parameters leads to which effect in the feedback behavior.

Note

The low-pass filter in the differential part is implemented as an exponential moving average filter described by $y_t = (1 - \alpha) \cdot y_{t-1} + \alpha x_t$ with $\alpha = 2^{-dshift}$, x_t the filter input, and y_t the filter output. The default value for dshift is 0 which corresponds to a disabled filter. On the UI the filter properties can be changed in units of bandwidth or a time constant.

In case the feedback output is a voltage applied to sensitive external equipment it is recommended to make use of the center value and the upper and lower limit values. This will guarantee that the output stays in the defined range even when the lock fails and the integrator goes into saturation.

Auto Tune

The Auto Tune feature found on the Tuner sub-tab can now help to minimize the residual error signal. Auto Tune will vary the feedback gain parameters, as selected in the Advise Mode field in the Advisor sub-tab, in order to minimize the root mean square of the PID error signal. Being based on measurement, Auto Tune can often improve on the results of the model-based PID Advisor because it can take into account the real experimental noise and device transfer function. For Auto Tune to deliver good results, it should be applied in the actual operating conditions of the PID loop, as otherwise the PID bandwidth may end up too low. E.g. it makes no sense to apply Auto Tune to a PLL on a lifted AFM cantilever when the PLL later is used to track the cantilever during scanning.

The transfer function of the chosen PID settings can always be checked by copying the values to the Advisor by clicking the **To Advisor** button and selecting the Advanced Mode in the Display sub-tab. With the Response In set to Setpoint, the Response Out set to PID Output and with Closed-Loop deactivated one can visualize the Bode Magnitude of the PID controller's transfer function. This graph is what is usually shown in textbooks and is independent of the model function chosen in the DUT section. However, in order to simulate step responses or to calculate a bandwidth, a suitable model for the entire loop is required.

Setting up a phase-locked loop (PLL)

The PID controllers 1 and 2 can be set to PLL mode which the Mode selector. Changing to PLL mode sets the PID controller input to a demodulator phase, the PID controller output to the frequency of an internal oscillator, and changes some of the parameters to appropriate default values. [Figure 4.42](#) shows a block diagram of a PLL with its components, their interconnections and the variables to be specified by the user. The demodulator and the PID controller are slightly simplified for this sketch. Their full detailed block diagrams are given in [Demodulator block diagram without MF-MD Multi-demodulator option.](#), [Demodulator block diagram with MF-MD Multi-demodulator option.](#), and [Figure 4.41](#) respectively.

Phase-Locked Loop




Figure 4.42. Phase-Locked Loop block diagram (components simplified)

In a typical procedure to set up a PLL one would first define the center frequency, frequency limits, and the phase setpoint in the left section. If the frequency is not known beforehand, it can often be determined using the Sweeper or Spectrum tool. Then one would set a target bandwidth in the Advisor section and click on the Advise button. The feedback parameters calculated by the Advisor will be shown in the fields just below. A graphical representation of the calculated transfer function is shown in the plot on the right-hand side. Once satisfied with the result, one can transfer the values to the instrument by clicking the **To PID** button, and then enable the PLL. If the Error/PLL Lock field now displays very small values, the phase lock was successful. One can now iterate the process and e.g. play with the target bandwidth in the PLL Advisor to calculate a new set of feedback parameters. Displaying the oscillator frequency in the Plotter along with a Histogram and Math function (e.g. standard deviation) can help to quantify the residual phase error and further improve the lock performance by manual tweaking.

Note

The span set by the PLL frequency limits should exceed the target bandwidth by a factor of 5 to 10 or more.

Note

In the PID/PLL tab you select which of the demodulators you use as a phase detector. Open the Lock-in tab to check if the right Signal Input is associated with the demodulator in use.

4.18.3. Functional Elements

Table 4.56. PID tab: PID section

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Mode | | Operation mode of the PID module. |
| | PID | The PID is used for a general application. |
| | PLL | The PID is used to control an internal oscillator. |

| Control/Tool | Option/Range | Description |
|--------------------|----------------------------------|---|
| | ExtRef | The PID is used by the external reference to control an internal oscillator. |
| Auto Mode | | This defines the type of automatic adaption of parameters in the PID. |
| | Off | No automatic adaption. |
| | PID Coeff | The coefficients of the PID controller are automatically set. |
| | Coeff + BW (low) | The PID coefficients, the filter bandwidth and the output limits are automatically set using a low bandwidth. |
| | Coeff + BW (high) | The PID coefficients, the filter bandwidth and the output limits are automatically set using a high bandwidth. |
| | Adaptive | All parameters of the PID including the center frequency are adapted. |
| Phase Unwrap | ON / OFF | Enables the phase unwrapping to track phase errors past the +/-180 degree boundary and increase PLL bandwidth. |
| Center | numeric value | After adding the Center value to the PID output, the signal is clamped to Center + Lower Limit and Center + Upper Limit. |
| Lower Limit | numeric value | After adding the Center value to the PID output, the signal is clamped to Center + Lower Limit and Center + Upper Limit. |
| Upper Limit | numeric value | After adding the Center value to the PID output, the signal is clamped to Center + Lower Limit and Center + Upper Limit. |
| D Limit TC/BW 3 dB | 673 ns to 15 ms/10 Hz to 236 kHz | The cutoff of the low-pass filter for the D limitation, shown as either the filter time constant or the 3 dB cutoff frequency, depending on the selected TC mode. When set to 0, the low-pass filter is disabled. |
| Lock LED | grey/green | Indicates when the PID (configured as PLL) is locked. The PLL error is sampled at 5 Sa/s and its absolute value is calculated. If the result is smaller than 5 degrees the loop is considered locked. Only works if mode is PLL or ExtRef. |
| Value | numeric value | Current output value |
| Enable | ON / OFF | Enable the PID controller |
| Input | | Select input source of PID controller |
| | Demodulator X | Demodulator cartesian X component |
| | Demodulator Y | Demodulator cartesian Y component |
| | Demodulator R | Demodulator magnitude component |
| | Demodulator Theta | Demodulator phase |
| | Aux Input | Auxiliary Input |

| Control/Tool | Option/Range | Description |
|----------------|----------------------|--|
| | Aux Output | Auxiliary output |
| Input Channel | index | Select input channel of PID controller. |
| Setpoint | numeric value | PID controller setpoint |
| Filter BW | numeric value | Bandwidth of the demodulator filter used as an input. |
| Filter Order | | Selects the filter roll off between 6 dB/oct and 48 dB/oct of the current demodulator. |
| | 1 | 1st order filter 6 dB/oct |
| | 2 | 2nd order filter 12 dB/oct |
| | 3 | 3rd order filter 18 dB/oct |
| | 4 | 4th order filter 24 dB/oct |
| | 5 | 5th order filter 30 dB/oct |
| | 6 | 6th order filter 36 dB/oct |
| | 7 | 7th order filter 42 dB/oct |
| | 8 | 8th order filter 48 dB/oct |
| Harmonic | 1 to 1023 | Multiplier of the for the reference frequency of the current demodulator. |
| Output | | Select output of the PID controller |
| | Sig Out 1 Amplitude | Feedback to the main signal output amplitude 1 |
| | Sig Out 2 Amplitude | Feedback to the main signal output amplitude 2 |
| | Oscillator Frequency | Feedback to any of the internal oscillator frequencies |
| | Demodulator Phase | Feedback to any of the 8 demodulator phase set points |
| | Aux Output Offset | Feedback to any of the 4 Auxiliary Output's Offset |
| | Signal Output Offset | Feedback to the main Signal Output offset adjustment |
| Output Channel | index | Select output channel of PID controller. |
| P (Hz/deg) | numeric value | PID proportional gain P |
| I (Hz/deg/s) | numeric value | PID integral gain I |
| D (Hz/deg*s) | numeric value | PID derivative gain D |
| Rate | 3.7 Hz to 469 kHz | <p>PID sampling rate and update rate of PID outputs. Needs to be set substantially higher than the targeted loop filter bandwidth.</p> <p>The numerical precision of the controller is influenced by the loop filter sampling rate. If the target bandwidth is below 1 kHz it starts to make sense to adjust this rate to a value of about 100 to 500 times the target bandwidth. If the rate is set to high for low bandwidth applications, integration inaccuracies can lead to non linear behavior.</p> |

| Control/Tool | Option/Range | Description |
|--------------|-------------------|--|
| Error | numeric value | Error = Set point - PID Input |
| Shift | numeric value | Difference between the current output value Out and the Center. Shift = P*Error + I*Int(Error, dt) + D*dError/dt |
| To Advisor | To Advisor | Copy the current PID settings to the PID Advisor. |

Table 4.57. PID tab: Advisor sub-tab

| Control/Tool | Option/Range | Description |
|--------------------|-------------------|--|
| D Limit TC/BW 3 dB | numeric value | The cutoff of the low-pass filter for the D limitation, shown as either the filter time constant or the 3 dB cutoff frequency, depending on the selected TC mode. When set to 0, the low-pass filter is disabled. |
| Rate | 3.7 Hz to 469 kHz | PID sampling rate used for simulation. The advisor will update the rate to match with the specified target bandwidth. A sampling rate close to the target bandwidth and excessive higher bandwidth will result in a simulation mismatch. |
| Advise | Advise | Calculate the PID coefficients based on the used DUT model and the given target bandwidth. If optimized values can be found the coefficients are updated and the response curve is updated on the plot. Only PID coefficients specified with the advise mode are optimized. The Advise mode can be used incremental, means current coefficients are used as starting point for the optimization unless other model parameters are changed in-between. |
| Target BW (Hz) | numeric value | Target bandwidth for the closed loop feedback system which is used for the advising of the PID parameters. This bandwidth defines the trade-off between PID speed and noise. |
| Advise Mode | | Select the PID coefficients that are optimized. The other PID coefficients remain unchanged but are used during optimization. This enables keeping selected coefficients at a fixed value while optimizing the rest. The advise time will increase significantly with the number of parameters to be optimized. |
| | PIDF | Optimize the proportional, integral, and derivative gains. Also the derivative gain bandwidth will be optimized. |
| | P | Only optimize the proportional gain. |
| | I | Only optimize the integral gain. |

| Control/Tool | Option/Range | Description |
|----------------|---------------------|---|
| | PI | Only optimize the proportional and the integral gain. |
| | PID | Optimize the proportional, integral, and derivative gains. |
| Filter BW | numeric Value | Defines the low-pass filter characteristic of the selected demodulator input. |
| Auto Bandwidth | ON / OFF | Adjusts the demodulator bandwidth to fit best to the specified target bandwidth of the full system. If disabled, a demodulator bandwidth too close to the target bandwidth may cause overshoot and instability. In special cases the demodulator bandwidth can also be selected smaller than the target bandwidth. |
| Filter Order | | Selects the filter roll off between 6 dB/oct and 48 dB/oct of the modelled demodulator. |
| | 1 | 1st order filter 6 dB/oct |
| | 2 | 2nd order filter 12 dB/oct |
| | 3 | 3rd order filter 18 dB/oct |
| | 4 | 4th order filter 24 dB/oct |
| | 5 | 5th order filter 30 dB/oct |
| | 6 | 6th order filter 36 dB/oct |
| | 7 | 7th order filter 42 dB/oct |
| | 8 | 8th order filter 48 dB/oct |
| Harmonic | 1 to 1023 | Multiplier of the for the reference frequency of the modelled demodulator. |
| DUT Model | | Type of model used for the external device to be controlled by the PID. A detailed description of the transfer function for each model is found in the previous section. |
| | All Pass | The external device is modelled by an all pass filter. Parameters to be configured are delay and gain. |
| | LP 1st | The external device is modelled by a first-order low-pass filter. Parameters to be configured are delay, gain and filter bandwidth. |
| | LP 2nd | The external device is modelled by a second-order low-pass filter. Parameters to be configured are delay, gain, resonance frequency and damping ratio. |
| | Resonator Frequency | The external device is modelled by a resonator. Parameters to be configured are delay, center frequency and quality factor. |

| Control/Tool | Option/Range | Description |
|---------------|---------------------|--|
| | Internal PLL | The DUT is the internal oscillator locked to an external signal through a phase-locked loop. The parameter to be configured is the delay. |
| | VCO | The external device is modelled by a voltage controlled oscillator. Parameters to be configured are delay, gain and bandwidth. |
| | Resonator Amplitude | The external device is modelled by a resonator. Parameters to be configured are delay, gain, center frequency and quality factor. |
| Delay | numeric value | Parameter that determines the earliest response for a step change. This parameter does not affect the shape of the DUT transfer function. |
| Gain | numeric value | Parameter that determines the gain of the DUT transfer function. |
| BW (Hz) | numeric value | Parameter that determines the bandwidth of the first-order low-pass filter respectively the bandwidth of the VCO. |
| Damping Ratio | numeric value | Parameter that determines the damping ratio of the second-order low-pass filter. |
| Res Freq | numeric value | Parameter that determines the resonance frequency of the of the modelled resonator. |
| Q | numeric value | Parameter that determines the quality factor of the modelled resonator. |
| P (Hz/deg) | numeric value | Proportional gain P coefficient used for calculation of the response of the PID model. The parameter can be optimized with PID advise or changed manually. The parameter only gets active on the PID after pressing the button To PLL. |
| I (Hz/deg/s) | numeric value | Integral gain I coefficient used for calculation of the response of the PID model. The parameter can be optimized with PID advise or changed manually. The parameter only gets active on the PID after pressing the button To PLL. |
| D (Hz/deg*s) | numeric value | Derivative gain D coefficient used for calculation of the response of the PID model. The parameter can be optimized with PID advise or changed manually. The parameter only gets active on the PID after pressing the button To PLL. |
| BW (Hz) | numeric value | Simulated bandwidth of the full close loop model with the current PID settings. This value should be larger than the target bandwidth. |
| Target BW LED | green/red | Green indicates that the target bandwidth can be achieved. For very high PID bandwidth the target bandwidth might be only achieved using marginal stable PID settings. In this case, try |

| Control/Tool | Option/Range | Description |
|--------------|---------------|---|
| | | to lower the bandwidth or optimize the loop delays of the PID system. |
| PM (deg) | numeric value | Simulated phase margin of the PID with the current settings. The phase margin should be greater than 45 deg for internal PLL and 60 deg for all other DUT for stable conditions. An Infinite value is shown if no unity gain crossing is available to determine a phase margin. |
| Stable LED | green/red | Green indicates that the phase margin is fulfilled and the PID system should be stable. |
| To PID | To PID | Copy the PID Advisor settings to the PID. |

Table 4.58. PID tab: Tuner sub-tab

| Control/Tool | Option/Range | Description |
|----------------|-----------------|--|
| Auto Tune | Run/Stop | Optimize the PID parameters so that the noise of the closed-loop system gets minimized. The tuning method needs a proper starting point for optimization (away from the limits). The tuning process can be interrupted and restarted. The tuning will try to match the PID bandwidth with the loop bandwidth of the DUT, signal input (demodulator), and signal output. |
| Enable | ON / OFF | Enables the setpoint toggle |
| Alt Setpoint | numeric Value | Defines the second setpoint used for the setpoint toggle. |
| Toggle Rate | numeric Value | Defines the rate of setpoint toggling. Note that possible values are logarithmically spaced with a factor of 4 between values. |
| Mode | | Select the PID coefficients that are optimized. The other PID coefficients remain unchanged but are used during optimization. This allows to force coefficients to a value while optimizing the rest. |
| | PIDF | Optimize the proportional, integral, and derivative gains. Also the derivative gain bandwidth will be optimized. |
| | P | Only optimize the proportional gain. |
| | I | Only optimize the integral gain. |
| | PI | Only optimize the proportional and the integral gain. |
| | PID | Optimize the proportional, integral, and derivative gains. |
| Advanced Mode | ON / OFF | Enables manual selection of tuner averaging and setpoint toggling. |
| Iteration Time | numeric Value | Set the length for a tuner optimization iteration. |

Table 4.59. PID tab: Display sub-tab

| Control/Tool | Option/Range | Description |
|----------------------------|----------------|--|
| Max Rate (Sa/s) | 1 to 469 kSa/s | Target Rate for PID output data sent to PC. This value defines the applied decimation for sending data to the PC. It does not affect any other place where PID data are used. |
| Rate (Sa/s) | | Current rate of the PID stream data sent to PC. Defined based on Max Rate. |
| Stream Overflow Indicator | | Indicates an overflow in the stream. |
| Advanced Mode | ON / OFF | Enables manual selection of display and advice properties. If disabled the display and advise settings are automatically with optimized default values. |
| Display | | Select the display mode used for rendering the system frequency or time response. |
| | Bode Magnitude | Display the Bode magnitude plot. |
| | Bode Phase | Display the Bode phase plot. |
| | Step Resp | Display the step response plot. |
| Start (Hz) | numeric value | Start frequency for Bode plot display. For disabled advanced mode the start value is automatically derived from the system properties and the input field is read-only. |
| Stop (Hz) | numeric value | Stop frequency for Bode plot display. For disabled advanced mode the stop value is automatically derived from the system properties and the input field is read-only. |
| Start (s) | numeric value | Start time for step response display. For disabled advanced mode the start value is zero and the field is read-only. |
| Stop (s) | numeric value | Stop time for step response display. For disabled advanced mode the stop value is automatically derived from the system properties and the input field is read-only. |
| Transfer Function Selector | | Selection of the displayed transfer function of the loop. 2 presets and a manual selection are possible. In closed loop configuration all elements from output to input will be included as feedback elements. |
| | System | From Setpoint to System Output. |
| | PID | From Setpoint to PID Output. |
| | Manual | Any transfer function in the open or closed loop can be visualized. |
| Response In | | Start point for the plant response simulation for open or closed loops. In closed loop configuration all elements from output to input will be included as feedback elements. |
| | Demod Input | Start point is at the demodulator input. |

| Control/Tool | Option/Range | Description |
|--------------|---|---|
| | Setpoint | Start point is at the setpoint in front of the PID. |
| | PID Output | Start point is at PID output. |
| | Instrument Output | Start point is at the instrument output. |
| | DUT Output | Start point is at the DUT output and instrument input. |
| Response Out | | End point for the plant response simulation for open or closed loops. In closed loop configuration all elements from output to input will be included as feedback elements. |
| | PID Output | End point is at PID output. |
| | Instrument Output | End point is at the instrument output. |
| | DUT Output | End point is at the DUT output and instrument input. |
| | Demod Input | End point is at the demodulator input. |
| | System Output | End point is at the output of the controlled system. |
| Closed-Loop | ON / OFF | Switch the display of the system response between closed or open loop. |
| TC Mode | ON / OFF | Enables time constant representation of PID parameters. |
| Set Limits | ON / OFF | Switch the writing of PID limits when 'To PID' is pressed. Only applies in case of internal PLL. |
| Advisor Link |  | Automatically copy cursor values displayed below to the PID advisor. To enable cursor helpers, switch Advanced Mode on and set Display to Bode Magnitude with PID Transfer Function. Cursors will be displayed in Log and dB axis scale combinations. |
| P | | Cursor value representing PID proportional gain P. Drag the plot cursor with the mouse pointer or directly insert numerical value here. |
| I | | Cursor value representing PID integral gain I. Drag the plot cursor with the mouse pointer or directly insert numerical value here. |
| D | | Cursor value representing PID derivative gain D. Drag the plot cursor with the mouse pointer or directly insert numerical value here. |

4.19. Threshold Tab

The Threshold Unit tab allows the user to define discrimination conditions and logical operations on a selection of input signals and output the result as TTL signals in real time. This functionality and tab is available on all MF instruments.

4.19.1. Features

- 4 threshold units for state detection
- analog input signals: demodulator data (X, Y, R, Θ), PID data (error, output, shift; requires MF-PID Quad PID/PLL Controller option option)
- digital input signals: 32 DIO channels, input and output overflows, etc.
- threshold detection: above, below, inside, outside, rising edge, falling edge
- absolute value and low-pass filtering can be applied prior to threshold detection
- configurable activation and deactivation times
- combination of up to 3 logical signals on one output with NOT, AND, OR, and XOR operation
- minimum length, hold, and invert functionality

4.19.2. Description

The Threshold tab enables real-time logical analysis of measurement data in order to detect special conditions or failures, and trigger a reaction via a TTL output. Typical applications are AFM tip protection or microfluidics cell sorting. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.60. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|---|
| Threshold | | Configure the threshold unit and the logical combinations to generate digital output signals. |

The Threshold tab (see Figure 4.43) is divided in a Thresholds section on the left, and a Logic units section on the right. The rows in the Thresholds section represent the input signals of the unit and the discretization action that converts them into logical signals. The rows in the Logic units section represent the output signals of the unit and the logical operations performed to generate these signals.




Figure 4.43. LabOne UI: Threshold tab

The available input signals include analog signals such as demodulator R, but also digital inputs or error flags of the instrument such as Signal Input overload. An analog input signal can be

low-pass filtered which helps to avoid false alarms when short glitches occur. After filtering the signal is discretized by comparing it to a user-defined threshold or range. Configurable minimum activation times after crossing a threshold allow further tuning of the time-domain behavior. The filtered threshold signal can be displayed in the [Section 4.7](#) which helps in defining meaningful threshold conditions. When digital signals are selected as inputs, the activation and deactivation times can be set the same way as for the analog signals. The figures below illustrate and detail the signal processing in the Threshold Unit using flow diagrams and signal graphs.

In order to output these signals on the Trigger outputs, the [Section 4.13](#) Mode setting needs to be set to Threshold units, and the Trigger output Drive needs to be enabled. By default, the four logical signals are routed as is to the four Trigger outputs. To set up more complex state detection, up to three input signals can be combined on one output using logical operations. The configuration of the logical operations in the Logic units section is collapsed by default. Base logical operators (AND, OR, XOR) as well as logical inversion (NOT) are available and grouping of the operations is indicated by brackets in the user interface.

Thresholds




Figure 4.44. Flow diagram representing the Thresholds section of the Threshold tab.

Guard timer




Figure 4.45. Signal graph showing an example of the signal processing that occurs in the Guard Timer. The Guard Timer block corresponds to the Enable/Disable settings in the Thresholds section of the Threshold tab and is represented in [Figure 4.44](#).

Logic Units




Figure 4.46. Flow diagram for the Logic Units section of the Threshold tab.

Hold and Width functionality




Figure 4.47. Signal graph showing an example of the signal processing by the Hold and Width functionality of the Threshold Unit. The represented signals 1 to 5 are indicated in Figure 4.46.

4.19.3. Functional Elements

Table 4.61. Threshold tab

| Control/Tool | Option/Range | Description |
|--------------|--------------|--|
| Signal | | Select the signal source to be used in the threshold unit. |
| | X | Select the demodulator X component as input. |
| | Y | Select the demodulator Y component as input. |
| | R | Select the demodulator magnitude component as input. |
| | Θ | Select the demodulator phase component as input. |
| | PID Out | Use the PID controller's output signal as input. PID option needs to be installed. |
| | PID Shift | Use the PID controller's shift signal. PID option needs to be installed. |
| | PID Error | Use the PID controller's error as input. PID option needs to be installed. |

| Control/Tool | Option/Range | Description |
|--------------|-----------------------|---|
| | DIO | Select one of the DIO channels as input. |
| | Trigger In | Select a trigger input as input. |
| | Trigger Out | Select a trigger output as input. |
| | Input Overload (V) | Use voltage input overload as input. |
| | Input Overload (I) | Use current input overload as input. |
| | Output Overload | Use signal output overload as input. |
| | Aux Input Overload | Use aux input overload as input. |
| | Aux Output Overload | Use aux output overload as input. |
| | PID Output Overload | Use PID output overload as input. |
| | TU Output Value | Use TU output value as input. |
| Channel | index | Select the channel according to the selected signal source. |
| Abs | ON / OFF | Takes the absolute value of an analog input signal. |
| TC/BW Value | numeric value | Defines the characteristic time constant of a low-pass filter applied to an analog input signal. |
| Value | numeric value | Shows the value after the low-pass filter. |
| Mode | | Selects the analysis mode defining the output signal. |
| | Above | Enable if the Signal is above Upper Threshold. |
| | Below | Enable if the Signal is below Lower Threshold. |
| | Outside | Enable if the Signal is outside the range [Lower Threshold, Upper Threshold]. |
| | Rising Edge | Enable if the Signal crosses Upper Threshold from below Lower Threshold. The difference between Upper and Lower Threshold defines the threshold hysteresis. |
| | Falling Edge | Enable if the Signal crosses Lower Threshold from above Upper Threshold. The difference between Upper and Lower Threshold defines the threshold hysteresis. |
| Lower | numeric value | Lower threshold used to generate the output. In Rising Edge mode, this parameter defines the hysteretic behavior as the output state is reset only when the signal crosses Lower Threshold from above. |
| Upper | numeric value | Upper threshold used to generate the output. In Falling Edge mode, this parameter defines the hysteretic behavior as the output state is reset only when the signal crosses Upper Threshold from below. |
| State | low / high / toggling | Indicates the current output of the threshold unit before the Minimum Time analysis. |

| Control/Tool | Option/Range | Description |
|--------------|-----------------------|--|
| Enable | numeric value | Minimum duration of threshold violation needed before the output is activated. This can be used as a glitch filter. |
| Disable | numeric value | Minimum duration of threshold compliance needed before the output is deactivated. |
| State | low / high / toggling | Indicates the current output of the threshold after the Minimum Time analysis. |
| Not | ON / OFF | Inverts the input signal. |
| In | index | Selects threshold channel to be used as input. |
| Op | | Logical operation applied to the signals to the left and right of the control. |
| | none | No logical operation selected. No additional signals will be used to generate the output. |
| | AND | Use a logical AND operation. |
| | OR | Use a logical OR operation. |
| | XOR | Use a logical XOR operation. |
| State | low / high / toggling | Indicates the current output of the threshold after the logical combination. |
| Width | numeric value | Select a minimum pulse width for the generated output signal. The width of pulses shorter than this time will be extended. |
| Hold | ON / OFF | Hold the output state indefinitely once it has changed to the activated state. |
| Inv | ON / OFF | Changes the output signal to low-active. |
| State | low / high / toggling | Final output state. |

4.20. MOD Tab

The MOD tab provides access to the settings of the amplitude and frequency modulation units. This tab is only available when the MF-MOD AM/FM Modulation option is installed on the Instrument (see Information section in the Device tab).

Note

The MF-MOD AM/FM Modulation option requires the MF-MD Multi-demodulator option.

4.20.1. Features

- Phase coherently add and subtract oscillator frequencies and their multiples
- Control for AM and FM demodulation
- Control for AM and narrow-band FM generation
- Direct analysis of higher order carrier frequencies and sidebands

4.20.2. Description

The MOD tab offers control in order to phase coherently add and subtract the frequencies of multiple numerical oscillators. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.62. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|--|
| MOD |  | Control panel to enable (de)modulation at linear combinations of oscillator frequencies. |

The MOD tab (see [Figure 4.48](#)) is divided into two horizontal sections, one for each modulation unit.




Figure 4.48. LabOne UI: MOD tab

The modulation units are designed for experiments involving multiple frequencies. For many of such experiments the associated spectrum reveals a dominant center frequency, often called the carrier, and one or multiple sidebands symmetrically placed around the carrier. Typical examples are amplitude modulated (AM) signals with one carrier and two sidebands separated from the carrier by the AM modulation frequency. Another example is frequency modulation (FM) where multiple sidebands to the left and right of the carrier can appear. The relative amplitude of the

sideband for both AM and FM depends on the modulation depth, which is often expressed by the modulation index.


The classical approach of analyzing such signals (in particular when only analog instruments are available) is to use a configuration called tandem demodulation. This is essentially the serial cascading of lock-in amplifiers. The first device is referenced to the carrier frequency and outputs the in-phase component. This is then fed into the subsequent lock-in amplifiers in order to extract the different sideband components. There are several downsides to this scheme:

- The quadrature component of the first lock-in tuned to the carrier has to be continuously zeroed out by adjusting the reference phase. Otherwise a serious part of the signal power is lost for the analysis which usually leads to a drop in SNR.
- The scheme scales badly in terms of the hardware resources needed, in particular if multiple sideband frequencies need to be extracted.
- Every time a signal enters or exits an instrument the SNR gets smaller (e.g. due to the instrument inputs noise). Multiple such steps can deteriorate signal quality significantly.

All these shortcomings are nicely overcome by providing the ability to generate linear combinations of oscillator frequencies and use these combinations as demodulation references.

The MOD unit is linked to demodulators 1, 2, and 3. It can make use of up to 3 oscillators, which can be even referenced to an external source by using ExtRef or a PLL. [Figure 4.49](#) gives an overview of the different components involved and their interconnections.

MF-MOD Option



[Figure 4.49](#). Modulation Option block diagram

For convenience the UI provides access to presets for AM and FM in the Mode column. In Manual Mode all settings can be chosen freely.

Note

Whenever a MOD unit is enabled, all the settings in the Lock-in tab that are controlled by this unit will be set to read-only.

On top of signal analysis the MF-MOD AM/FM Modulation option can also be utilized for signal generation. The Generation section provides all the necessary controls to adjust the carrier and sideband amplitudes.

Note

FM signals are generated by coherent superposition of the carrier signal with two sideband frequencies on either side that have the same amplitudes but opposite phases. The phase shift is achieved by using negative amplitudes as displayed in the Lock-in tab. This FM generation method approximates true FM as long as the modulation index is well below 1, i.e. higher-order sidebands can be neglected. For a modulation index of 1 true FM provides more than 13% of signal power in the second and higher order sidebands.

More details regarding AM and FM signal analysis and generation can be found on the Zurich Instruments web page, e.g. <https://blogs.zhinst.com/sadik/2014/02/sideband-analysis/>.

4.20.3. Functional Elements

Table 4.63. MOD tab

| Control/Tool | Option/Range | Description |
|----------------------|----------------|---|
| SG Channels | | Select SG Channel to display corresponding set of oscillator frequencies. |
| Frequency (Hz) | | Oscillator frequency. |
| Oscillator Select | | Selection of the oscillator used for the generated sine signal. |
| Harmonic | | Multiplies the oscillator's reference frequency with the integer factor defined by this field. |
| Frequency (Hz) | | Frequency of the selected oscillator. |
| Phase Shift (deg) | | Sets the phase of the sine signal. |
| I Sin Amplitude | | Sets the amplitude of the sine signal sent to the I input of the digital mixer. |
| I Cos Amplitude | | Sets the amplitude of the cosine signal sent to the I input of the digital mixer. |
| I Enable | ON / OFF | Enables the I input of the digital mixer. |
| Q Sin Amplitude | | Sets the amplitude of the sine signal sent to the Q input of the digital mixer. |
| Q Cos Amplitude | | Sets the amplitude of the cosine signal sent to the Q input of the digital mixer. |
| Q Enable | ON / OFF | Enables the Q input of the digital mixer. |
| Run/Stop | Run/Stop | Runs the AWG sequencer. |
| Sequencer Status | grey/green/red | Displays the status of the sequencer on the instrument. Off: Ready, not running. Green: Running, not waiting for any trigger event. Yellow: Running, waiting for a trigger event. Red: Not ready (e.g., pending elf download, no elf download). |
| Modulation Enable | ON / OFF | Enables digital modulation of the waveforms generated by the AWG. |
| AWG Output Amplitude | | Sets the amplitude of the first AWG output. |

| Control/Tool | Option/Range | Description |
|---------------------------|--------------|--|
| AWG Output Amplitude | | Sets the amplitude of the second AWG output. |
| Hold | ON / OFF | Keep the last sample (constant) on the outputs even after the waveform program finishes. It is recommended to use only AWG waveforms with lengths equal to a multiple of 16 together with this functionality. Waveforms with other lengths are automatically padded with zeros at the end by the AWG compiler. |
| AWG Output Gain Amplitude | | Sets the amplitude scaling factor of the given AWG channel. The amplitude is a dimensionless scaling factor applied to the digital signal. |
| AWG Output Gain Enable | ON / OFF | Indicates the routing of the AWG signal (row) to the digital mixer inputs (column). |

4.21. Multi Device Sync Tab

The Multi Device Sync (MDS) tab gives access to the automatic timing synchronization of measurement data from multiple MF instruments. This functionality and tab is available on all MF instruments.

4.21.1. Features

- Automatic timing synchronization across instruments
- Periodic check of synchronization
- Selectable instrument subgroup
- Status display

4.21.2. Description

The Multi Device Sync tab contains the controls and status information for synchronized measurements on multiple instruments. Whenever the tab is closed or an additional one of the same type is needed, clicking the following icon will open a new instance of the tab.

Table 4.64. App icon and short description

| Control/Tool | Option/Range | Description |
|--------------|--------------|-----------------------------------|
| MDS | | Synchronize multiple instruments. |

The Multi Device Sync tab shown in Figure 4.50 consists of the Available Devices section, a Status section, and a wiring diagram.




Figure 4.50. LabOne UI: Multi Device Sync tab

The Multi Device Synchronization feature provides an automated functionality to remove the clock offset of separate MF instruments. This enables a correct simultaneous display of their data in the [Section 4.6](#) and helps when analyzing recorded data. In multi-channel applications that require sub-microsecond timing precision, the user can therefore benefit from having synchronized data from the start, rather than having to manually measure and compensate the clock offset in post-processing.


The first prerequisite for automatic synchronization is that all instruments are connected to the same LabOne Data Server (see [Section 1.6](#)). This is only possible when running the LabOne software on a separate PC as explained in [Section 1.5](#).

To make these connections, click on **Session Manager** in the [Section 4.15](#) to open the Device Connection dialog. Go to the Advanced view of this dialog and click on the Enable checkbox next to the corresponding entries in the Available Devices list. Once all instruments are connected, they are selectable in the **Tree Selector** of a newly opened Plotter tab allowing you to visualize their data simultaneously, though by default these data are not synchronized yet. The settings of multiple instruments can be accessed in parallel by opening a new Web Server session for each of them. This is done by opening a new browser tab and connecting to **localhost:8006** or **127.0.0.1:8006**, respectively, and then double-clicking the respective instrument entry in the Available Devices list. With multiple instruments connected to the same Data Server, tabs that are available for several instruments will feature a device selector as shown in [Figure 4.51](#).



[Figure 4.51. Example of the device selector for the Device tab](#)

The second prerequisite for automatic synchronization is correct cabling of the instruments explained in the diagram in [Figure 4.52](#). The instruments should share the same 10 MHz reference clock and communicate via the Ref / Trigger connectors for absolute timing synchronization. The 10 MHz clock signal is distributed in a daisy chain arrangement, where Clock 10 MHz Out of a leading instrument is connected to Clock 10 MHz In of the next instrument, and so forth. On all following instruments, the Clock Source in the [Section 4.16](#) needs to be set to Clk 10 MHz rather than Internal. The Trigger Out 1 signal of the leading instrument should be distributed to the Trigger In 1 connector of all following instruments **and** of the leading instrument. This star-shaped connection should be made with a 1-to-N power divider and cables of equal length.



[Figure 4.52. Cabling for automatic synchronization of multiple MF instruments](#)

Once the cabling and the connectivity is set up correctly, automatic synchronization is started in the Multi Device Sync tab by checking the Enable button on the instruments in the Available Devices list, and then clicking on **Start/Stop Sync**. The sequence assignment of the instruments (Leader, Follower 1, Follower 2,...) can be defined by the order in which the Enable button is clicked. This assignment has to agree with the way the cabling is made. The sequence is also

relevant for addressing the instruments in an AWG sequence program. The Message display on the right will then report on the progress, and the Sync Status LED will turn green if the synchronization was successful. In that case, visualizing a time-dependent measurement of multiple instruments in the Plotter will demonstrate the timing synchronization.

4.21.3. Functional Elements

Table 4.65. Multi Device Sync tab

| Control/Tool | Option/Range | Description |
|-----------------------|---|--|
| Start Sync | Start/Stop Sync | Start the automatic synchronization of the selected devices. |
| Sync Status | | Indicates the status of the synchronization within this group. Green: synchronization successful. Yellow: synchronization in progress. Red: error (see message). |
| Message | | Displays a status message of the synchronization group. |
| Cabling | | This image shows how to connect the devices for device synchronization. |
| Phase Synchronization | | Reset phases of all oscillators on all synchronized devices. |
| Identify Device |  | Make device's front LED blink |

4.22. ZI Labs Tab

The ZI Labs tab contains experimental LabOne functionalities added by the ZI development team. The settings found here are often relevant to special applications, but have not yet found their definitive place in one of the other LabOne tabs. Naturally this tab is subject to frequent changes, and the documentation of the individual features would go beyond the scope of this user manual. Clicking the following icon will open a new instance of the tab.

Table 4.66. App Icon and short description

| Control/Tool | Option/Range | Description |
|--------------|---|-------------------------------------|
| ZI Labs |  | Experimental settings and controls. |

4.23. Upgrade Tab

The Upgrade tab serves as a source of information about the possible upgrade options for the instrument in use. The tab has no functional purpose but provides the user with a quick link to further information about the upgrade options online.

Chapter 5. Specifications

Important

Unless otherwise stated, all specifications apply after 30 minutes of instrument warm-up.

Important

Changes in the specification parameters are explicitly mentioned in the revision history of this document.

Important

Some specifications depend on the installed options. The options installed on a given instrument are listed in the Device tab of the LabOne user interface.

5.1. General Specifications

Table 5.1. General specifications

| Parameter | Description |
|----------------------------------|---|
| Storage temperature | +5°C to +65°C |
| Storage relative humidity | < 95%, non-condensing |
| Operating environment | IEC61010, indoor location, installation category II, pollution degree 2 |
| Operating altitude | up to 2000 meters |
| Operating temperature | +5°C to +40°C |
| Operating relative humidity | < 90%, non-condensing |
| Specification temperature | +18°C to +28°C |
| Power consumption | <40 W |
| DC power inlet | 12 V, 2 A Connector: Switchcraft 760BK, ID 2.5 mm, OD 5.5 mm |
| Power supply AC line | 100–240 V ($\pm 10\%$), 50/60 Hz |
| Line power fuse | 250 V, 2 A, fast, 5 x 20 mm, F 2 A L 250 V |
| Dimensions including bumper | 28.3 x 23.2 x 10.2 cm 11.1 x 9.1 x 4.0 inch Rack mount on request |
| Weight including bumper | 3.8 kg |
| Recommended calibration interval | 2 years (see sticker on back panel) |
| Warranty | 1 year, extensible |

Table 5.2. Demodulators

| Parameter | Description |
|---|---|
| Frequency range | DC to 500 kHz DC to 5 MHz, requires MF-F5M option |
| Number of demodulators | 1 dual-phase (X, Y, R, Θ) 4 dual-phase, requires MF-MD option |
| Demodulator inputs | Signal Inputs (V/I), Auxiliary Inputs, Auxiliary Outputs, Trigger Inputs |
| Filter time constant | 336 ns to 83 s |
| Filter bandwidth (-3 dB) | 276 µHz – 206 kHz (4th order filter) |
| Harmonics | 1 – 1023 |
| Filter slope | 6, 12, 18, 24, 30, 36, 42, 48 dB/oct |
| Additional filtering | Sinc filter |
| Phase resolution | 10 µdeg |
| Frequency resolution | 1 µHz |
| Output sample rate on Auxiliary Outputs | 612 kSa/s (for each auxiliary output), 18 bit, ±10 V |
| Maximum transfer rate over 1 GbE | 200 kSa/s (all demodulators), 48-bit full range |

| Parameter | Description |
|--|--|
| Maximum rate to store on local USB drive | 50 kSa/s (all demodulators), 48-bit full range |
| Trigger modes for data transfer | Continuous, edge, gated |

Table 5.3. Reference frequencies

| Parameter | Description |
|------------------------------------|---|
| External reference frequency range | 1 Hz to 500 kHz 1 Hz to 5 MHz, requires MF-F5M option |
| External reference input | Auxiliary Inputs, Trigger Inputs, Auxiliary Outputs, Current Signal Input, Voltage Signal Input |
| Lock time for external reference | Typically less than max(100 cycles, 1.2 ms) |
| Number of external references | 1; 2, requires MF-MD option |
| Internal reference frequency range | 0 to 500 kHz 0 to 5 MHz, requires MF-F5M option |

Table 5.4. Scope

| Parameter | Description |
|--|--|
| Input channels | Signal Inputs (V,I), Auxiliary Inputs, Auxiliary Outputs, Trigger Inputs, Trigger Outputs, Signal Output, Oscillator Phase. Demodulator R, Theta, X, Y, requires MF-DIG option |
| Scope modes | Time domain, frequency domain (FFT) |
| Number display channels | 1; 2, requires MF-DIG option |
| Trigger channels | Signal Inputs (V,I), Auxiliary Inputs, Auxiliary Outputs, Trigger Inputs, Trigger Outputs. Demodulator R, Theta, X, Y, requires MF-DIG option |
| Trigger modes | Edge |
| Trigger hysteresis | Full input range |
| Pre-trigger | Full sample range |
| Sampling rates | 1.8 kSa/s to 60 MSa/s |
| Vertical resolution | 16 bit |
| Maximum number of samples per shot | 16 kSa; 5 MSa, requires MF-DIG option |
| Minimum hold time | 1 ms |
| Bandwidth limit mode, vertical resolution increase | Downsampling by averaging; increase vertical resolution up to 24 bit, requires MF-DIG option |
| Cursor math | Location, Area, Wave, Peak, Tracking, Histogram |

Table 5.5. Spectrum

| Parameter | Description |
|------------------------|--|
| Center frequency range | 0 to 500 kHz 0 to 5 MHz, requires MF-F5M option |

| Parameter | Description |
|--|---|
| Spectrum modes | FFT(X+iY), FFT®, FFT(Θ), FFT(f) and FFT((d Θ /dt)/2 π) |
| Statistical options | Amplitude, Spectral density, Power |
| Averaging modes | None, Exponential moving average |
| Maximum number of samples per spectrum | 8 kSa |
| Maximum span | 58 kHz |
| Window functions | Rectangular, Hann, Hamming, Blackman Harris |
| Cursor math | Location, Area, Tracking, Wave, Peak, Histogram |

Table 5.6. Sweeper

| Parameter | Description |
|----------------------------|--|
| Sweep parameters | Oscillator frequency, Demodulator phase, Auxiliary Offset, Signal Output Offset, etc. |
| Parameter sweep ranges | Full range, Linear and Logarithmic |
| Parameter sweep resolution | Arbitrary, defined by start/stop value and number of sweep points |
| Display parameters | Demodulator Output (X, Y, R, Θ , f), Auxiliary Input |
| Display options | Single Plot, Dual Plot (e.g. Bode Plot), Multi-trace |
| Statistical options | Amplitude, Spectral density, Power |
| Preset measurement modes | Parameter sweep, Noise amplitude measurement, Frequency response analyzer, 3-Omega-Sweep |

Table 5.7. MF-IA Impedance Analyzer option

| Parameter | Description |
|---|---|
| Frequency range | DC to 500 kHz DC to 5 MHz, requires MF-F5M option |
| Basic accuracy | 0.05% (1 mHz to 500 kHz) |
| Basic temperature stability | <200 ppm/K |
| Test signal level | 0 to 2.1 V _{rms} with monitoring |
| Bandwidth | 276 μ Hz to 206 kHz |
| DC bias signal level | \pm 10 V (2 Terminal); \pm 3 V (4 Terminal) |
| Compensation methods | SO, SOL, LLL, SL, L, OL |
| Impedance Z: range; basic accuracy | 1 m Ω to 1 T Ω ; 0.05% |
| Admittance Y: range; basic accuracy | 1 pS to 1 kS; 0.05% |
| Resistance Rs, Rp: range; basic accuracy | 1 m Ω to 10 G Ω ; max(10 μ Ω , 0.05%) ² |
| Capacitance Cs, Cp: range; basic accuracy | 10 fF to 1 F; max(10 fF, 0.05%) ² |
| Inductance Ls, Lp: range; basic accuracy | 100 nH to 1 H; max(10 nH, 0.05%) ² |

| Parameter | Description |
|--|----------------------------------|
| DC Resistance R_{DC} : range; basic accuracy | 1 mΩ to 10 GΩ; 2% |
| Reactance X: range; basic accuracy | 1 mΩ to 10 GΩ; 0.05% |
| Conductance G: range; basic accuracy | 1 nS to 1 kS; max(100 nS, 0.05%) |
| Susceptance B: range; basic accuracy | 1 nS to 1 kS; max(100 nS, 0.05%) |
| Loss coefficient D: range | 10^{-4} to 10^4 |
| Q factor: range | 10^{-4} to 10^4 |

² Accuracy valid if parameter is the dominant value of the circuit representation.

Table 5.8. Voltage Signal Inputs

| Parameter | Description |
|--|--|
| Connectors | 2 BNC on front panel, single-ended or differential |
| Shield connectivity | Floating or ground |
| Maximum float voltage versus ground | ± 1 V |
| Input impedance | 50 Ω and 10 MΩ 27 pF for range ≥ 300 mV; 40 pF for range ≤ 100 mV |
| Input frequency range | DC to 500 kHz; DC to 5 MHz, requires MF-F5M option |
| Input A/D conversion | 16 bit, 60 MSa/s |
| Input noise amplitude | 2.5 nV/ $\sqrt{\text{Hz}}$ for frequencies > 1 kHz 7 nV/ $\sqrt{\text{Hz}}$ at 10 Hz 40 nV/ $\sqrt{\text{Hz}}$ at 1 Hz 3.3 mV input range; shorting cap on input |
| Input noise corner frequency | Typically 100 Hz for range ≤ 10 mV |
| Input bias current | Typically ± 10 pA, max ± 200 pA |
| Input full range sensitivity (10 V lock-in amplifier output) | 1 nV to 3 V |
| Input AC ranges | ± 1 mV, \pm mV, ± 10 mV, ± 30 mV, ± 100 mV, ± 300 mV, ± 1 V, ± 3 V |
| AC coupling cutoff frequency | 1.6 Hz |
| Maximum DC offset for AC coupling | ± 10 V |
| Input DC ranges | ± 1 mV, \pm mV, ± 10 mV, ± 30 mV, ± 100 mV, ± 300 mV, ± 1 V, ± 3 V |
| Input gain inaccuracy | < 1% (< 2 MHz); for higher frequencies limited by analog input filter |
| Analog input filter (anti-aliasing) | 1 dB suppression at 5 MHz, 3 dB at 12 MHz; 3rd order roll-off |
| Input amplitude stability | 0.1%/°C |
| Input offset amplitude | < max(0.5 mV, 1% of range) |
| Dynamic reserve | Up to 120 dB |
| Harmonic distortion | 80 dBc for frequencies ≤ 100 kHz 65 dBc for frequencies ≤ 5 MHz carrier amplitude 1 dBFS |

| Parameter | Description |
|-----------------|---|
| Coherent pickup | < -140 dB for frequencies \leq 5 MHz and 50 Ω input impedance; < -180 dB for frequencies \leq 100 kHz and 50 Ω input impedance |

Table 5.9. Current Signal Input

| Parameter | Description |
|--|--|
| Connector | BNC on front panel, float/ground |
| Shield connectivity | Floating or ground |
| Maximum float voltage versus ground | ± 1 V |
| Input impedance | see Table 5.10 |
| Input frequency range | 0 to 500 kHz 0 to 5 MHz, requires MF-F5M option |
| Input A/D conversion | 16 bit, 60 MSa/s |
| Input leakage current | ± 10 pA |
| Input full range sensitivity (10 V lock-in amplifier output) | 10 fA to 10 mA |
| Input gain inaccuracy | < 1% (for frequencies below 10% of the input bandwidth) |
| Input offset amplitude | 1% of range |
| Input offset voltage | ± 2.2 mV max; to shield of current input BNC connector |
| Dynamic reserve | up to 120 dB |
| Coherent pickup | < 90 G Ω for frequencies \leq 5 MHz and 100 μ A input range < 140 T Ω for frequencies \leq 100 kHz and 10 nA input range |

Table 5.10. Current Signal Input: input ranges, transimpedance gain, bandwidth, input impedance, noise

| Current input range | Transimpedance gain | Bandwidth (-3 dB) | Input impedance at DC | Input noise |
|-------------------------|---------------------|-------------------|-----------------------|---------------------------------------|
| 10 mA | 100 V/A | 5 MHz | 50 Ω | 300 pA/ $\sqrt{\text{Hz}}$ at 100 kHz |
| 1 mA ¹ | 1 kV/A | 5 MHz | 50 Ω | 200 pA/ $\sqrt{\text{Hz}}$ at 100 kHz |
| 100 μ A | 10 kV/A | 5 MHz | 60 Ω | 3.5 pA/ $\sqrt{\text{Hz}}$ at 100 kHz |
| 10 μ A ¹ | 100 kV/A | 5 MHz | 60 Ω | 2.5 pA/ $\sqrt{\text{Hz}}$ at 100 kHz |
| 1 μ A | 1 MV/A | 450 kHz | 1 k Ω | 200 fA/ $\sqrt{\text{Hz}}$ at 1 kHz |
| 100 nA ¹ | 10 MV/A | 450 kHz | 1 k Ω | 150 fA/ $\sqrt{\text{Hz}}$ at 1 kHz |
| 10 nA | 100 MV/A | 2 kHz | 160 k Ω | 20 fA/ $\sqrt{\text{Hz}}$ at 100 Hz |
| 1 nA ¹ | 1 GV/A | 2 kHz | 160 k Ω | 15 fA/ $\sqrt{\text{Hz}}$ at 100 Hz |

¹ Range only available on MF Instruments with serial numbers MF-DEV3200 and higher.

Table 5.11. Signal Output

| Parameter | Description |
|------------------|---|
| Connectors | 2 BNC on front panel, single ended and differential |
| Output impedance | 50 Ω |

| Parameter | Description |
|------------------------------|--|
| Output frequency range | DC to 500 kHz DC to 5 MHz (with MF-F5M option) |
| Output frequency resolution | 1 µHz |
| Output phase range | ±180° |
| Output phase resolution | 10 µdeg |
| Differential outputs | Sine waves shifted by 180° |
| Output D/A conversion | 16 bit, 60 MSa/s |
| Output amplitude ranges | ±10 mV, ±100 mV, ±1 V, ±10 V (single ended into high impedance) |
| Output DC offset range | ±10 mV to ±10 V, equal to the set output amplitude range |
| Output power | 24 dBm (±10 V, 250 mW), for each BNC |
| Output gain inaccuracy | < 1% at 100 kHz for all output ranges |
| Maximum output drive current | 100 mA |
| Output offset amplitude | ±1 mV or 1% of range, whichever is bigger |
| Harmonic distortion | 85 dBc for f < 100 kHz, 60 dBc for f < 5 MHz; for output ranges ≤ 1 V; 80 dBc for f < 100 kHz, 50 dBc for f < 5 MHz; for output range 10 V; carrier amplitude 1 dBFS |
| Analog adder | Auxiliary Input 1 can be added to the signal output, ±10 V, DC-2 MHz |

Table 5.12. Signal Output: voltage noise, ranges

| Output range | Output noise density (high load impedance setting) | RMS output noise at 12 MHz bandwidth |
|--------------|--|--------------------------------------|
| 10 mV | 43 nV/√Hz | 145 µVRms |
| 100 mV | 43 nV/√Hz | 145 µVRms |
| 1 V | 48 nV/√Hz | 161 µVRms |
| 10 V | 104 nV/√Hz | 310 µVRms |

Table 5.13. Auxiliary Inputs

| Parameter | Description |
|-----------------------|---------------------------------|
| Connectors | 2 BNC on the front panel |
| A/D converter | 16 bit, 15 MSa/s |
| A/D analog bandwidth | 5 MHz |
| Input impedance | 1 MΩ |
| Amplitude | ±10 V |
| Input noise amplitude | 430 nV/√Hz; frequency > 100 kHz |
| Resolution | 0.335 mV |

Table 5.14. Auxiliary Outputs

| Parameter | Description |
|------------|--------------------------|
| Connectors | 4 BNC on the front panel |

| Parameter | Description |
|----------------------|---|
| D/A converter | 18 bit, 612 kSa/s |
| D/A analog bandwidth | 200 kHz |
| Output impedance | 50 Ω |
| Amplitude | ±10 V |
| Resolution | < 85 μV |
| Drive current | 20 mA |
| Noise density | 210 nV/√Hz into high-impedance load; frequency > 1 kHz |
| RMS noise | 90 μV _{rms} into high-impedance load; measurement bandwidth 12 MHz |

Table 5.15. Trigger Inputs

| Parameter | Description |
|------------------------------------|---|
| Connectors | 2 BNC on the back panel |
| Trigger input impedance | 1 kΩ |
| Frequency range external reference | 1 Hz to 500 kHz; 1 Hz to 5 MHz, requires MF-F5M option |
| Trigger amplitude range | ±5 V |
| Minimum pulse width | 35 ns |
| Trigger level | ±5 V, 3.66 mV resolution |
| Trigger hysteresis | < 20 mV |

Table 5.16. Trigger Outputs

| Parameter | Description |
|------------------------------------|---|
| Connectors | 2 BNC on the back panel |
| Trigger output impedance | 50 Ω |
| Frequency range external reference | 1 μHz to 500 kHz; 1 μHz to 5 MHz, requires MF-F5M option |
| Trigger amplitude | 5 V |

Table 5.17. 10 MHz clock synchronization

| Parameter | Description |
|-------------------------------|--|
| Connectors | 2 BNC, 10 MHz clock input and output on the back panel |
| 10 MHz input, impedance | 50 Ω |
| 10 MHz input, frequency range | 9.98 to 10.02 MHz |
| 10 MHz input, amplitude range | 200 mV to 3 V |
| 10 MHz output, impedance | 50 Ω |
| 10 MHz output, amplitude | Typically 1 Vpp into 50 Ω, sinusoidal |

Table 5.18. Internal frequency reference

| Parameter | Description |
|-----------|-------------|
| Type | TCXO |

| Parameter | Description |
|------------------------------|----------------------------|
| Initial accuracy | < ±1.5 ppm |
| Long term accuracy/aging | < ±1 ppm in the first year |
| Short term stability (0.1 s) | < 2·10 ⁻¹⁰ |
| Temperature coefficient | 0.05 ppm/°C (@23°C) |
| Phase noise at 1 kHz | -140 dBc/Hz |
| Phase noise at 10 kHz | -150 dBc/Hz |

Table 5.19. Connectivity and others

| Parameter | Description |
|--------------------------------------|--|
| Host connection | LAN, 1GbE; USB 2.0, 480 Mbit/s |
| Internal drive data storage capacity | 4.5 GB |
| USB host | 2 connectors on the back panel for mass storage or WLAN modules |
| DIO, digital I/O | 4 x 8 bit, general purpose digital input/output port, 3.3 V TTL VHDCI 68 pin female connector |

Table 5.20. Maximum ratings

| Parameter | Lower | Upper |
|---|-------|-------|
| Damage threshold Current Signal Input I | -5 V | +5 V |
| Damage threshold Voltage Input +V/-V Diff | -12 V | +12 V |
| Damage threshold Signal Output +V/-V | -12 V | +12 V |
| Damage threshold Aux Input 1,2 | -12 V | +12 V |
| Damage threshold Aux Outputs 1,2,3,4 | -12 V | +12 V |
| Damage threshold Clock 10 MHz In/Out | -5 V | +5 V |
| Damage threshold Trigger Out 1,2 | -1 V | +6 V |
| Damage threshold Trigger In 1,2 | -8 V | +8 V |
| Damage threshold DIO 32 bit | -1 V | +6 V |
| Damage threshold DC In | 0 V | 26 V |


Table 5.21. LabOne UI requirements

| Parameter | Description |
|-------------------|--|
| Operating systems | Any, web browser based |
| Input device | Touch screen, keyboard, mouse |
| CPU | 2+ cores, hardware accelerated rendering on browser |
| Browser | Internet Explorer 10+, Firefox 27+, Chrome 36+, Safari 6+, Opera 23+ |
| Connectivity | 1 GbE, 100 MbE, USB 2.0 |

Table 5.22. LabOne API requirements

| Parameter | Description |
|---------------------|--|
| Operating systems | Windows 10 (x64), Windows 8.1 (x64), Windows 7 (i386, x64), Linux Ubuntu 14.04 LTS (AMD64), 16.04 LTS (AMD64), Mac OS X |
| CPU | AMD K8 (Athlon 64, Sempron 64, Turion 64, etc.), AMD Phenom, Intel Pentium 4, Xeon, Celeron, Celeron D, Pentium M, Celeron M, Core, Core 2, Core i5, Core i7, Atom |
| RAM | 4 GB+ |
| Connectivity | 1 GbE, 100 MbE, USB 2.0 |
| Supported languages | LabVIEW 2009 (i386, x64) and later; Python 2.7, 3.5 (i386, AMD64); MATLAB 2009 (Windows) / MATLAB 2014 (Linux) and later; C/C++ |

The DIO port is a VHDCI 68 pin connector as introduced by the SPI-3 document of the SCSI-3 specification. It is a female connector that requires a 32 mm wide male connector. The DIO port features 32 bits that can be configured byte-wise as inputs or outputs.

**Figure 5.1.** DIO HD 68 pin connector**Table 5.23.** DIO pin assignment

| Pin | Name | Description | Range specification |
|-------|------------|--|---------------------|
| 68 | CLKI | clock input, used to latch signals at the digital input ports - can also be used to retrieve digital signals from the output port using an external sampling clock | 3.3 V LVCMOS/TTL |
| 67 | DOL | DIO output latch, 60 MHz clock signal, the digital outputs are synchronized to the falling edge of this signal | 3.3 V LVCMOS/TTL |
| 66-59 | DI[31:24] | digital input or output (set by user) | 3.3 V LVCMOS/TTL |
| 58-51 | DIO[23:16] | digital input or output (set by user) | 3.3 V LVCMOS/TTL |

| Pin | Name | Description | Range specification |
|-------|-----------|---------------------------------------|---------------------|
| 50-43 | DIO[15:8] | digital input or output (set by user) | 3.3 V LVCMOS/TTL |
| 42-35 | DIO[7:0] | digital input or output (set by user) | 3.3 V LVCMOS/TTL |
| 34-30 | - | do not connect, for internal use only | - |
| 29-1 | GND | digital ground | - |

The figure below shows the architecture of the DIO input/output. The DIO port features 32 bits that can be configured byte-wise as inputs or outputs by means of a drive signal. The digital output data is latched synchronously with the falling edge of the internal clock, which is running at 60 MHz. The internal sampling clock is available at the DOL pin of the DIO connector. Digital input data can either be sampled by the internal clock or by an external clock provided through the CLKI pin. A decimated version of the input clock is used to sample the input data. The Decimation unit counts the clocks to decimation and then latches the input data. The default decimation is 3e6, corresponding to a digital input sampling rate of 20 samples per second.




Figure 5.2. DIO input/output architecture

5.2. Performance Diagrams

Input noise amplitude depends on several parameters, and in particular on the frequency and on the input range setting. The input noise is lower for smaller input ranges, and it is recommended to use small ranges especially for noise measurements. Figure 5.3 shows the noise density of the voltage input with DC coupling. The input noise with AC coupling is the same as long as the frequency is higher than the AC cutoff frequency (see Table 5.8). The noise is independent of the input impedance setting, $50\ \Omega$ or $10\ M\Omega$. The corner frequency of the $1/f$ noise is in the range of 100 Hz and the white-noise floor is typically $2.5\ nV/\sqrt{Hz}$ for the smallest input ranges.




Figure 5.3. MFLI Voltage Input noise density

A note on input voltage noise and AC coupling. The input voltage noise will increase at low frequencies, when using AC coupling at the signal input of the MFLI. For example, the input voltage noise of the 10 mV input range is around $10\ nV/\sqrt{Hz}$ at a frequency of 10 Hz, as shown in the figure above. When switching on AC coupling, the noise increases to around $75\ nV/\sqrt{Hz}$. The reason is that the 10nF AC coupling capacitor has an impedance of $1.6\ M\Omega$ at 10 Hz. Together with the $10\ M\Omega$ input bias resistor of the MFLI input amplifier, you get the increased noise density. To work around this problem, use DC coupling for the signal input. An external large capacitor may be employed if AC coupling must be used.

Figure 5.4 shows the noise density of the current input. The frequency range of the measurements for the smaller input ranges is limited by the bandwidth of these ranges as specified in Table 5.10.




Figure 5.4. MFLI Current Input current noise density

[UHF phase noise](#) shows the SSB phase noise measured at the signal output. For this measurement, the signal output was connected to a phase noise analyzer and the output amplitude was set to 5 V. The measured phase noise at 5 MHz and 10 kHz offset is around -153 dBc/Hz.




Figure 5.5. MFLI phase noise

Figure 5.6 shows the noise density of the voltage output into $50\ \Omega$. For high-impedance loads, the voltage noise levels in the figure need to be doubled. The output noise was measured with no signal and 0 V offset. For the ranges 10 mV and 100 mV, the voltage noise is basically identical with a flat-band noise level of 14.5 nV/ $\sqrt{\text{Hz}}$ at 100 kHz into $50\ \Omega$. For high-impedance loads, the value would be around 29 nV/ $\sqrt{\text{Hz}}$. The 10 V range shows the largest noise with 34.5 nV/ $\sqrt{\text{Hz}}$ at 100 kHz. The corner frequency of the 1/f noise is in the range of 10 to 20 kHz.




Figure 5.6. MFLI Signal Output voltage noise density

Chapter 6. Signal Processing Basics

This chapter provides insights about several lock-in amplifier principles not necessarily linked to a specific instrument from Zurich Instruments. Since the appearance of the first valve-based lock-in amplifiers in the 1930s the physics have not changed, but the implementation and the performance have evolved greatly. Many good lock-in amplifier primers have appeared in the past decades, and some of them appear outdated now because they were written with analog instruments in mind. This section does not aim to replace any existing primer, but to complete them with a preferred emphasis on digital lock-in amplifiers. The first subsection describes the principles of lock-in amplification, followed by the description of the function of discrete-time filters. After, we discuss the definition of the full range sensitivity, a specification parameter particularly important for analog lock-in amplifiers but with somewhat reduced importance for digital instruments. In the following, we describe the function and use of sinc filtering in particular for low-frequency lock-in measurements. The last section is dedicated to the zoom FFT feature. Innovative in the context of lock-in amplifiers, zoom FFT offers a fast and high-resolution spectral analysis around the lock-in operation frequency.

6.1. Principles of Lock-in Detection

Lock-in demodulation is a technique to measure the amplitude A_s and the phase θ of a periodic signal with the frequency $\omega_s = 2\pi f_s$ by comparing the signal to a reference signal. This technique is also called phase-sensitive detection. By averaging over time the signal-to-noise ratio (SNR) of a signal can be increased by orders of magnitude, allowing very small signals to be detected with a high accuracy making the lock-in amplifier a tool often used for signal recovery. For both signal recovery and phase-sensitive detection, the signal of interest is isolated with narrow band-pass filtering therefore reducing the impact of noise in the measured signal.

Figure 6.1 shows a basic measurement setup: a reference $V_r(t)$ signal is fed to the device under test. This reference signal is modified by the generally non-linear device with attenuation, amplification, phase shifting, and distortion, resulting in a signal $V_s(t) = A_s \cos(\omega_s t + \theta)$ plus harmonic components.




Figure 6.1. Basic measurement setup incorporating a lock-in amplifier

For practical reasons, most lock-in amplifiers implement the band-pass filter with a mixer and a low-pass filter (depicted in Figure 6.2): the mixer shifts the signal of interest into the baseband, ideally to DC, and the low-pass filter cuts all unwanted higher frequencies.




Figure 6.2. Mixing and low-pass filtering performed by the lock-in amplifier

The input signal $V_s(t)$ is multiplied by the reference signal $V_r(t) = \sqrt{2}e^{-i\omega_r t}$, where $\omega_r = 2\pi f_r$ is the demodulation frequency and i is the imaginary unit. This is the complex representation of a sine and cosine signal (phase shift 90°) forming the components of a quadrature demodulator, capable of measuring both the amplitude and the phase of the signal of interest. In principle it is possible to multiply the signal of interest with any frequency, resulting in a heterodyne operation. However the objective of the lock-in amplifier is to shift the signal as close as possible to DC, therefore the frequency of the reference and the signal is chosen similar. In literature this is called homodyne detection, synchrodyne detection, or zero-IF direct conversion.

The result of the multiplication is the signal

$$\begin{aligned} V_s(t) \cdot V_r(t) &= V_s(t) \cdot \sqrt{2}e^{-i\omega_r t} = \frac{A_s}{\sqrt{2}}e^{i[\omega_s - \omega_r]t + \theta} + \frac{A_s}{\sqrt{2}}e^{-i[\omega_s + \omega_r]t - \theta} \end{aligned}$$

It consists of a slow component with frequency $\omega_s - \omega_r$ and a fast component with frequency $\omega_s + \omega_r$.

The demodulated signal is then low-pass filtered with an infinite impulse response (IIR) RC filter, indicated by the symbol $\langle \cdot \rangle$. The frequency response of the filter $F(\omega)$ will let pass the low frequencies $F(\omega_s - \omega_r)$ while considerably attenuating the higher frequencies $F(\omega_s + \omega_r)$. Another way to consider the low-pass filter is an averager.

$$\begin{aligned} X+iY = \langle V_s(t) \cdot \sqrt{2} e^{-i\omega_r t} \rangle \approx F(\omega_s - \omega_r) \frac{A_s}{\sqrt{2}} e^{i[(\omega_s - \omega_r)t + \theta]} \end{aligned}$$

The result after the low-pass filter is the demodulated signal $X+iY$, where X is the real and Y is the imaginary part of a signal depicted on the complex plane. These components are also called in-phase and quadrature components. The transformation of X and Y into the amplitude R and phase θ information of $V_s(t)$ can be performed with trigonometric operations.

It is interesting to note that the value of the measured signal corresponds to the RMS value of the signal, which is equivalent to $R = A_s / \sqrt{2}$.

Most lock-in amplifiers output the values (X, Y) and (R, θ) encoded in a range of -10 V to $+10$ V of the auxiliary output signals.

6.1.1. Lock-in Amplifier Applications

Lock-in amplifiers are employed in a large variety of applications. In some cases the objective is measuring a signal with good signal-to-noise ratio, and then that signal could be measured even with large filter settings. In this context the word phase sensitive detection is appropriate. In other applications, the signal is very weak and overwhelmed by noise, which forces to measure with very narrow filters. In this context the lock-in amplifier is employed for signal recovery. Also, in another context, a signal modulated on a very high frequency (GHz or THz) that cannot be measured with standard approaches, is mixed to a lower frequency that fits into the measurement band of the lock-in amplifier.

One example for measuring a small, stationary or slowly varying signal which is completely buried in the $1/f$ noise, the power line noise, and slow drifts. For this purpose a weak signal is modulated to a higher frequency, away from these sources of noise. Such signal can be efficiently mixed back and measured in the baseband using a lock-in amplifier. In Figure 6.3 this process is depicted. Many optical applications perform the up-mixing with a chopper, an electro-optical modulator, or an acousto-optical modulator. The advantage of this procedure is that the desired signal is measured in a spectral region with comparatively little noise. This is more efficient than just low-pass filtering the DC signal.




Figure 6.3. Lock-in measurement of a noisy DC signal

6.2. Signal Bandwidth

The signal bandwidth (BW) theoretically corresponds to the highest frequency components of interest in a signal. In practical signals, the bandwidth is usually quantified by the cut-off frequency. It is the frequency at which the transfer function of a system shows 3 dB attenuation relative to DC ($BW = f_{\text{cut-off}} = f_{-3\text{dB}}$); that is, the signal power at $f_{-3\text{dB}}$ is half the power at DC. The bandwidth, equivalent to cut-off frequency, is used in the context of dynamic behavior of a signals or separation of different signals. This is for instance the case for fast-changing amplitudes or phase values like in a PLL or in imaging applications, or when signals closely spaced in frequency need to be separated.

The noise equivalent power bandwidth (NEPBW) is also a useful figure, and it is distinct from the signal bandwidth. This unit is typically used for noise measurements: in this case one is interested in the total amount of power that passes through a low-pass filter, equivalent to the area under the solid curve in [Figure 6.4](#). For practical reasons, one defines an ideal brick-wall filter that lets pass the same amount of power under the assumption that the noise has a flat (white) spectral density. This brick-wall filter has transmission 1 from DC to f_{NEPBW} . The orange and blue areas in [Figure 6.4](#) then are exactly equal in a linear scale.




Figure 6.4. Signal bandwidth and noise equivalent power bandwidth

It is possible to establish a simple relation between the $f_{\text{cut-off}}$ and the f_{NEPBW} that only depends on the slope (or roll-off) of the filter. As the filter slope actually depends on the time constant (TC) defined for the filter, it is possible to establish the relation also to the time constant. It is intuitive to understand that for higher filter orders, the $f_{\text{cut-off}}$ is closer to the f_{NEPBW} than for smaller orders.

The time constant is a parameter used to interpret the filter response in the time domain, and relates to the time it takes to reach a defined percentage of the final value. The time constant of a low-pass filter relates to the bandwidth according to the formula

$$\text{TC} = \frac{\text{FO}}{2\pi f_{\text{cut-off}}}$$

where FO is said factor that depends on the filter slope. This factor, along with other useful conversion factors between different filter parameters, can be read from the following table.

Table 6.1. Summary of conversion factors for bandwidth definitions

| filter order | filter roll-off | FO | $f_{\text{cut-off}}$ | f_{NEPBW} | $f_{\text{NEPBW}} / f_{\text{cut-off}}$ |
|-----------------|-----------------|--------|----------------------|----------------------|---|
| 1 st | 6 dB/oct | 1.0000 | $0.1592 / \text{TC}$ | $0.2500 / \text{TC}$ | 1.5708 |
| 2 nd | 12 dB/oct | 0.6436 | $0.1024 / \text{TC}$ | $0.1250 / \text{TC}$ | 1.2203 |
| 3 rd | 18 dB/oct | 0.5098 | $0.0811 / \text{TC}$ | $0.0937 / \text{TC}$ | 1.1554 |
| 4 th | 24 dB/oct | 0.4350 | $0.0692 / \text{TC}$ | $0.0781 / \text{TC}$ | 1.1285 |

6.2. Signal Bandwidth

| filter order | filter roll-off | FO | $f_{\text{cut-off}}$ | f_{NEPBW} | $f_{\text{NEPBW}} / f_{\text{cut-off}}$ |
|-----------------|-----------------|--------|----------------------|--------------------|---|
| 5 th | 30 dB/oct | 0.3856 | 0.0614 / TC | 0.0684 / TC | 1.1138 |
| 6 th | 36 dB/oct | 0.3499 | 0.0557 / TC | 0.0615 / TC | 1.1046 |
| 7 th | 42 dB/oct | 0.3226 | 0.0513 / TC | 0.0564 / TC | 1.0983 |
| 8 th | 48 dB/oct | 0.3008 | 0.0479 / TC | 0.0524 / TC | 1.0937 |

6.3. Discrete-Time Filters

6.3.1. Discrete-Time RC Filter

There are many options how to implement digital low-pass filters. One common filter type is the exponential running average filter. Its characteristics are very close to those of an analog resistor-capacitor RC filter, which is why this filter is sometimes called a discrete-time RC filter. The exponential running average filter has the time constant $TC = \tau_N$ as its only adjustable parameter. It operates on an input signal $X_{in}[n]$ defined at discrete times $n T_s$, $(n+1)T_s$, $(n+2)T_s$, etc., spaced at the sampling time T_s . Its output $X_{out}[n, T_s]$ can be calculated using the following recursive formula,

$$\begin{aligned} X_{out}[n, T_s] &= e^{-T_s/\tau_N} X_{out}[n-1, T_s] + (1 - e^{-T_s/\tau_N}) X_{in}[n, T_s] \end{aligned}$$

The response of that filter in the frequency domain is well approximated by the formula

$$H_1(\omega) = \frac{1}{1 + i\omega\tau_N}$$

The exponential filter is a first-order filter. Higher-order filters can easily be implemented by cascading several filters. For instance the 4th order filter is implemented by chaining 4 filters with the same time constant $TC = \tau_N$ one after the other so that the output of one filter stage is the input of the next one. The transfer function of such a cascaded filter is simply the product of the transfer functions of the individual filter stages. For an n-th order filter, we therefore have

$$H_n(\omega) = \frac{1}{(1 + i\omega\tau_N)^n}$$

The attenuation and phase shift of the filters can be obtained from this formula. Namely, the filter attenuation is given by the absolute value squared $|H_n(\omega)|^2$. The filter transmission phase is given by the complex argument $\arg(H_n(\omega))$.

6.3.2. Filter Settling Time

The low-pass filters after the demodulator cause a delay to measured signals depending on the filter order and time constant $TC = \tau_N$. After a change in the signal, it will therefore take some time before the lock-in output reaches the correct measurement value. This is depicted in Figure 6.5 where the response of cascaded filters to a step input signal this is shown.




Figure 6.5. Time domain step response of the RC low-pass filters

More quantitative information on the settling time can be obtained from [Table 6.2](#). In this table, you find settling times in units of the filter time constant τ_n for all filter orders available with the MFLI Lock-in Amplifier. The values tell the time you need to wait for the filtered demodulator signal to reach 5%, 95% and 99% of the final value. This can help in making a quantitatively correct choice of filter parameters for example in a measurement involving a parameter sweep.

Table 6.2. Summary of Filter Rise Times

| filter order | Setting time to | | |
|-----------------|------------------|----------------|----------------|
| 1 st | $0.025 \cdot TC$ | $3.0 \cdot TC$ | $4.6 \cdot TC$ |
| 2 nd | $0.36 \cdot TC$ | $4.7 \cdot TC$ | $6.6 \cdot TC$ |
| 3 rd | $0.82 \cdot TC$ | $6.3 \cdot TC$ | $8.4 \cdot TC$ |
| 4 th | $1.4 \cdot TC$ | $7.8 \cdot TC$ | $10 \cdot TC$ |
| 5 th | $2.0 \cdot TC$ | $9.2 \cdot TC$ | $12 \cdot TC$ |
| 6 th | $2.6 \cdot TC$ | $11 \cdot TC$ | $12 \cdot TC$ |
| 7 th | $3.3 \cdot TC$ | $12 \cdot TC$ | $15 \cdot TC$ |
| 8 th | $4.0 \cdot TC$ | $13 \cdot TC$ | $16 \cdot TC$ |

6.4. Full Range Sensitivity

The sensitivity of the lock-in amplifier is the RMS value of an input sine that is demodulated and results in a full scale analog output. Traditionally the X, Y, or R components are mapped onto the 10 V full scale analog output. In such a case, the overall gain from input to output of the lock-in amplifier is composed of the input and output amplifier stages. Many lock-in amplifiers specify a sensitivity between 1 nV and 1 V. In other words the instrument permits an input signal between 1 nV and 1 V to be amplified to the 10 V full range output.

Analog Lock-in Amplifiers:



Digital Lock-in Amplifiers:



Figure 6.6. Sensitivity from signal input to signal output

In analog lock-in amplifiers the sensitivity is simple to understand. It is the sum of the analog amplification stages between the input and the output of the instrument: in particular the input amplifier and the output amplifier.

In digital lock-in amplifiers the sensitivity less straightforward to understand. Analog-to-digital converters (ADC) operate with a fixed input range (e.g. 1 V) and thus require a variable-gain amplifier to amplify the input signal to the range given by the ADC. This variable-gain amplifier must be in the analog domain and its capability determines the minimum input range of the instrument. A practical analog input amplifier provides a factor 1000 amplification, thus 1 V divided by 1000 is the minimum input range of the instrument.

The input range is the maximum signal amplitude that is permitted for a given range setting. The signal is internally amplified with the suited factor, e.g. (1 mV) · 1000 to result in a full swing signal at the ADC. For signals larger than the range, the ADC saturates and the signal is distorted – the measurement result becomes useless. Thus the signal should never exceed the range setting.

But the input range is not the same as the sensitivity. In digital lock-in amplifiers the sensitivity is only determined by the output amplifier, which is an entirely digital signal processing unit which performs a numerical multiplication of the demodulator output with the scaling factor. The digital output of this unit is then fed to the output digital-to-analog converter (DAC) with a fixed range of 10 V. It is this scaling factor that can be retrofitted to specify a sensitivity as known from the analog lock-in amplifiers. A large scaling factor, and thus a high sensitivity, comes at a relatively small expense for digital amplification.

One interesting aspect of digital lock-in amplifiers is the connection between input resolution and sensitivity. As the ADC operates with a finite resolution, for instance 14 bits, the minimum signal that can be detected and digitized is for instance 1 mV divided by the resolution of the ADC. With 14 bits the minimum level that can be digitized would be 122 nV. How is it possible to reach 1 nV sensitivity without using a 21 bit analog-to-digital converter? In a world without noise it is not possible. Inversely, thanks to noise and current digital technology it is possible to achieve a sensitivity even below 1 nV.

Most sources of broadband noise, including the input amplifier, can be considered as Gaussian noise sources. Gaussian noise is equally distributed in a signal, and thus generates equally

distributed disturbances. The noise itself can be filtered by the lock-in amplifier down to a level where it does not impact the measurement. Still, in the interplay with the signal, the noise does have an effect on the measurement. The input of the ADC is the sum of the noise and the signal amplitude. Every now and then, the signal amplitude on top of the large noise will be able to toggle the least significant bits even for very small signals, as low as 1 nV and below. The resulting digital signal has a component at the signal frequency and can be detected by the lock-in amplifier.

There is a similar example from biology. Rod cells in the human eye permit humans to see in very low light conditions. The sensitivity of rod cells in the human eye is as low as a single photon. This sensitivity is achieved in low light conditions by a sort of pre-charging of the cell to be sensitive to the single photon that triggers the cell to fire an impulse. In a condition with more surround light, rod cells are less sensitive and need more photons to fire.

To summarize, in digital lock-in amplifiers the full range sensitivity is only determined by the scaling factor capability of the digital output amplifier. As the scaling can be arbitrary big, 1 nV minimum full range sensitivity is achievable without a problem. Further, digital lock-in amplifiers exploit the input noise to heavily increase the sensitivity without impacting the accuracy of the measurement.

6.5. Sinc Filtering

As explained in [Section 6.1](#), the demodulated signal in an ideal lock-in amplifier has a signal component at DC and a spurious component at twice the demodulation frequency. The components at twice the demodulation frequency (called the 2ω component) is effectively removed by regular low-pass filtering. By selecting filters with small bandwidth and faster roll-offs, the 2ω component can easily be attenuated by 100 dB or more. The problem arises at low demodulation frequencies, because this forces the user to select long integration times (e.g. >60 ms for a demodulation frequency of 20 Hz) in order to achieve the same level of 2ω attenuation.

In practice, the lock-in amplifier will modulate DC offsets and non-linearities at the signal input with the demodulation frequency, resulting in a signal at the demodulation frequency (called ω component). This component is also effectively removed by the regular low-pass filters at frequencies higher than 1 kHz.

At low demodulation frequencies, and especially for applications with demodulation frequencies close to the filter bandwidth, the ω and 2ω components can affect the measurement result. Sinc filtering allows for strong attenuation of the ω and 2ω components. Technically the sinc filter is a comb filter with notches at integer multiples of the demodulation frequency (ω , 2ω , 3ω , etc.). It removes the ω component with a suppression factor of around 80 dB. The amount of 2ω component that gets removed depends on the input signal. It can vary from entirely (e.g. 80 dB) to slightly (e.g. 5 dB). This variation is not due to the sinc filter performance but depends on the bandwidth of the input signal.




Figure 6.7. Effect of sinc filtering

Table 6.3. Artifacts in the demodulation signal

| Input signal | Demodulation result before low-pass filter | Result |
|--------------------|--|--|
| Signal at ω | DC component | Amplitude and phase information (wanted signal) |
| | 2ω component | Unwanted component (can additionally be attenuated by sinc filter) |

| Input signal | Demodulation result before low-pass filter | Result |
|--------------|--|---|
| DC offset | ω component | Unwanted component (can additionally be attenuated by sinc filter) |

We can observe the effect of the sinc filter by using the Spectrum Analyzer Tool of the MFLI Lock-in Amplifier. As an example, consider a 30 Hz signal with an amplitude of 0.1 V that demodulated using a filter bandwidth of 100 Hz and a filter order 8. In addition 0.1V offset is added to the signal so that we get a significant ω component.

Figure 6.8 shows a spectrum with the sinc filter disabled, whereas for Figure 6.9 the sinc filter is enabled. The comparison of the two clearly shows how the sinc options dampens both the ω and 2ω components by about 100 dB.




Figure 6.8. Spectrum of a demodulated 30 Hz signal without sinc filter




Figure 6.9. Spectrum of a demodulated 30 Hz signal with sinc filter

Note

In order to put the notches of the digital filter to ω and 2ω , the sampling rate of the filter would have to be precisely adjusted to the signal frequency. As this is technically not feasible, the generated signal frequency is adjusted instead by a very small amount.

6.6. Zoom FFT

The concept of zoom FFT allows the user to analyze the spectrum of the input signal around a particular frequency by zooming in on a narrow frequency portion of the spectrum. This is done by performing a Fourier transform of the demodulated in-phase and quadrature (X and Y) components or more precisely, on the complex quantity $X+iY$, where i is the imaginary unit. In the LabOne user interface, this functionality is available in the Spectrum tab.

In normal FFT, the sampling rate determines the frequency span and the total acquisition time determines the frequency resolution. Having a large span and a fine resolution at the same time then requires long acquisition times at high sample rates. This means that a lot of data needs to be acquired, stored, and processed, only to retain a small portion of the spectrum and discard most of it in the end. In zoom FFT, the lock-in demodulation is used to down-shift the signal frequency, thereby allowing one to use both a much lower sampling rate and sample number to achieve the same frequency resolution. Typically, to achieve a 1 Hz frequency resolution at 1 MHz, FFT would require to collect and process approximately 10^6 points, while zoom FFT only processes 10^3 points. (Of course the high rate sampling is done by the lock-in during the demodulation stage, so the zoom FFT still needs to implicitly rely on a fast ADC.)

In order to illustrate why this is so and what benefits this measurement tool brings to the user, it is useful to remind that at the end of the demodulation of the input signal $V_s(t)=A_s \cos(\omega_s t + \tau)$, the output signal is $X+iY=F(\omega_s - \omega_r)(A_s/\sqrt{2})e^{i[\omega_s - \omega_r]t - \tau}$ where $F(\omega)$ is the frequency response of the filters.

Since the demodulated signal has only one component at frequency $\omega_s - \omega_r$, its power spectrum (Fourier transform modulus squared) has a peak of height $(|A_s|^2/2) \cdot |F(\omega_r - \omega_s)|^2$ at $\omega_s - \omega_r$: this tells us the spectral power distribution of the input signal at frequencies close to ω_r within the demodulation bandwidth set by the filters $F(\omega)$.

Note that:

- the ability of distinguishing between positive and negative frequencies works only if the Fourier transform is done on $X+iY$. Had we taken X for instance, the positive and negative frequencies of its power spectrum would be equal. The symmetry relation $G(-\omega)=G^*(\omega)$ holds for the Fourier transform $G(\omega)$ of a real function $g(t)$ and two identical peaks would appear at $\pm|\omega_s - \omega_r|$.
- one can extract the amplitude of the input signal by dividing the power spectrum by $|F(\omega)|^2$, the operation being limited by the numerical precision. This is implemented in LabOne and is activated by the Filter Compensation button: with the Filter Compensation enabled, the background noise appears white; without it, the effect of the filter roll-off becomes apparent.

The case of an input signal containing a single frequency component can be generalized to the case of multiple frequencies. In that case the power spectrum would display all the frequency components weighted by the filter transfer function, or normalized if the Filter Compensation is enabled.

When dealing with discrete-time signal processing, one has to be careful about aliasing which occurs when the signal frequencies higher than the sampling rate ω are not sufficiently suppressed. Remember that ω is the user settable readout rate, not the 60 MSa/s sampling rate of the MFLI input. Since the discrete-time Fourier transform extends between $-\omega/2$ and $+\omega/2$, the user has to make sure that at $\pm\omega/2$ the filters provide the desired attenuation: this can be done either by increasing the sampling rate or resolving to measure a smaller frequency spectrum (i.e. with a smaller filter bandwidth).

Similarly to the continuous case, in which the acquisition time determines the maximum frequency resolution ($2\pi/T$ if T is the acquisition time), the resolution of the zoom FFT can be increased by increasing the number of recorded data points. If N data points are collected at a sampling rate ω , the discrete Fourier transform has a frequency resolution of ω/N .

Chapter 7. Device Node Tree

This chapter contains reference documentation for the settings and measurement data available on MFLI Instruments. Whilst [Chapter 4](#) describes many of these settings in terms of the features available in the LabOne User Interface, this chapter describes them on the device level and provides a hierarchically organized and comprehensive list of device functionality.

Since these settings and data streams may be written and read using the LabOne APIs (Application Programming Interfaces) this chapter is of particular interest to users who would like to perform measurements programmatically via LabVIEW, Python, MATLAB, .NET or C.

Please see:

- [Section 7.1](#) for an introduction of how the instrument's settings and measurement data are organized hierarchically in the Data Server's so-called "Node Tree".
- [Section 7.2](#) for a reference list of the settings and measurement data available on MFLI Instruments, organized by branch in the Node Tree.

7.1. Introduction

This section provides an overview of how an instrument's configuration and output is organized by the Data Server.

All communication with an instrument occurs via the Data Server program the instrument is connected to (see [LabOne Software Architecture](#) for an overview of LabOne's software components). Although the instrument's settings are stored locally on the device, it is the Data Server's task to ensure it maintains the values of the current settings and makes these settings (and any subscribed data) available to all its current clients. A client may be the LabOne User Interface or a user's own program implemented using one of the LabOne Application Programming Interfaces, e.g., Python.

The instrument's settings and data are organized by the Data Server in a file-system-like hierarchical structure called the node tree. When an instrument is connected to a Data Server, its device ID becomes a top-level branch in the Data Server's node tree. The features of the instrument are organized as branches underneath the top-level device branch and the individual instrument settings are leaves of these branches.

For example, the auxiliary outputs of the instrument with device ID "dev2006" are located in the tree in the branch:

```
/DEV2006/AUXOUTS/
```

In turn, each individual auxiliary output channel has its own branch underneath the "AUXOUTS" branch.

```
/DEV2006/AUXOUTS/0/  
/DEV2006/AUXOUTS/1/  
/DEV2006/AUXOUTS/2/  
/DEV2006/AUXOUTS/3/
```

Whilst the auxiliary outputs and other channels are labelled on the instrument's panels and the User Interface using 1-based indexing, the Data Server's node tree uses 0-based indexing. Individual settings (and data) of an auxiliary output are available as leaves underneath the corresponding channel's branch:

```
/DEV2006/AUXOUTS/0/DEMODOSELECT  
/DEV2006/AUXOUTS/0/LIMITLOWER  
/DEV2006/AUXOUTS/0/LIMITUPPER  
/DEV2006/AUXOUTS/0/OFFSET  
/DEV2006/AUXOUTS/0/OUTPUTSELECT  
/DEV2006/AUXOUTS/0/PREOFFSET  
/DEV2006/AUXOUTS/0/SCALE  
/DEV2006/AUXOUTS/0(VALUE
```

These are all individual node paths in the node tree; the lowest-level nodes which represent a single instrument setting or data stream. Whether the node is an instrument setting or data-stream and which type of data it contains or provides is well-defined and documented on a per-node basis in the Reference Node Documentation section in the relevant instrument-specific user manual. The different properties and types are explained in [Section 7.1.1](#).

For instrument settings, a Data Server client modifies the node's value by specifying the appropriate path and a value to the Data Server as a (path, value) pair. When an instrument's setting is changed in the LabOne User Interface, the path and the value of the node that was changed are displayed in the Status Bar in the bottom of the Window. This is described in more detail in [Section 7.1.2](#).

Module Parameters

LabOne Core Modules, such as the Sweeper, also use a similar tree-like structure to organize their parameters. Please note, however, that module nodes are not visible in the Data Server's node tree; they are local to the instance of the module created in a LabOne client and are not synchronized between clients.

7.1.1. Node Properties and Data Types

A node may have one or more of the following properties:

| | |
|-----------|--|
| Read | Data can be read from the node. |
| Write | Data can be written to the node. |
| Setting | A node with write attribute corresponding to an instrument configuration. The data in these nodes will be saved to and loaded from LabOne XML settings files. |
| Streaming | A node with the read attribute that provides instrument data, typically at a user-configured rate. The data is usually a more complex data type, for example demodulator data is returned as ZIDemodSample . A full list of streaming nodes is available in the Programming Manual in the Chapter Instrument Communication Their availability depends on the device class (e.g. MF) and the option set installed on the device. |

A node may contain data of the following types:

| | |
|----------------------|--|
| Integer | Integer data. |
| Double | Double precision floating point data. |
| String | A string array. |
| Enumerated (integer) | As for Integer, but the node only allows certain values. |
| Composite data type | For example, ZIDemodSample . These custom data types are structures whose fields contain the instrument output, a timestamp and other relevant instrument settings such as the demodulator oscillator frequency. Documentation of custom data types is available in |

7.1.2. Exploring the Node Tree

In the LabOne User Interface

A convenient method to learn which node is responsible for a specific instrument setting is to check the Command Log history in the bottom of the LabOne User Interface. The command in the Status Bar gets updated every time a configuration change is made. [Figure 7.1](#) shows how the equivalent Matlab command is displayed after modifying the value of the auxiliary output 1's offset. The format of the LabOne UI's command history can be configured in the Config Tab (Matlab, Python and .NET are available). The entire history generated in the current UI session can be viewed by clicking the "Show Log" button.




Figure 7.1. When a device's configuration is modified in the LabOne User Interface, the Status Bar displays the equivalent command to perform the same configuration via a LabOne programming interface. Here, the Matlab code to modify auxiliary output 1's offset value is provided. When "Show Log" is clicked the entire configuration history is displayed in a new browser tab.

In a LabOne Programming Interface

A list of nodes (under a specific branch) can be requested from the Data Server in an API client using the `listNodes` command (Matlab, Python, .NET) or `ziAPIListNodes()` function (C API). Please see each API's command reference for more help using the `listNodes` command. To obtain a list of all the nodes that provide data from an instrument at a high rate, so-called streaming nodes, the `streamingonly` flag can be provided to `listNodes`. More information on data streaming and streaming nodes is available in the LabOne Programming Manual).

The detailed descriptions of nodes that is provided in Section 7.2 is accessible directly in the LabOne Matlab or Python programming interfaces using the "help" command. The `help` command is `daq.help(path)` in Python and `ziDAQ('help', path)` in Matlab. The command returns a description of the instrument node including access properties, data type, units and available options. The "help" command also handles wildcards to return a detailed description of all nodes matching the path. An example is provided below.

```
daq = zhinst.ziPython.ziDAQServer('localhost', 8004, 6)
daq.help('/dev2006/auxouts/0/offset')
# Out:
# /DEV2006/AUXOUTS/0/OFFSET#
# Add the specified offset voltage to the signal after scaling. Auxiliary Output
# Value = (Signal+Preoffset)*Scale + Offset
# Properties: Read, Write, Setting
# Type: Double
# Unit: V
```

7.1.3. Data Server Nodes

The Data Server has nodes in the node tree available under the top-level /ZI/ branch. These nodes give information about the version and state of the Data Server the client is connected to. For example, the nodes:

- /ZI/ABOUT/VERSION
- /ZI/ABOUT/REVISION

are read-only nodes that contain information about the release version and revision of the Data Server. The nodes under the /ZI/DEVICES/ list which devices are connected, discoverable and visible to the Data Server.

The nodes:

- /ZI/CONFIG/OPEN

- /ZI/CONFIG/PORT

are settings nodes that can be used to configure which port the Data Server listens to for incoming client connections and whether it may accept connections from clients on hosts other than the localhost.

Nodes that are of particular use to programmers are:

- /ZI/DEBUG/LOGPATH - the location of the Data Server's log in the PC's file system,
- /ZI/DEBUG/LEVEL - the current log-level of the Data Server (configurable; has the Write attribute),
- /ZI/DEBUG/LOG - the last Data Server log entries as a string array.

For documentation of all Data Server nodes see the /ZI/ section in the Reference Node Documentation section in the instrument-specific user manual.

7.2. Reference Node Documentation

This section describes all the nodes in the data server's node tree organized by branch. See [Node Properties and Data Types](#) for an explanation of node properties and types.

7.2.1. AUXINS

/DEV..../AUXINS/n/AVERAGING

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Defines the number of samples on the input to average as a power of two. Possible values are in the range [0, 16]. A value of 0 corresponds to the sampling rate of the auxiliary input's ADC.

/DEV..../AUXINS/n/SAMPLE

Properties: Read, Stream

Type: ZIAuxInSample

Unit: V

Voltage measured at the Auxiliary Input after averaging. The data rate depends on the averaging value. Note, if the instrument has demodulator functionality, the auxiliary input values are available as fields in a demodulator sample and are aligned by timestamp with the demodulator output.

/DEV..../AUXINS/n/VALUES/n

Properties: Read

Type: Double

Unit: V

Voltage measured at the Auxiliary Input after averaging. The value of this node is updated at a low rate (50 Hz); the streaming node auxins/n/sample is updated at a high rate defined by the averaging.

7.2.2. AUXOUTS

/DEV..../AUXOUTS/n/DEMODOSELECT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Select the channel number of the selected signal source.

/DEV..../AUXOUTS/n/LIMITLOWER

Properties: Read, Write, Setting

Type: Double

Unit: V

Lower limit for the signal at the Auxiliary Output. A smaller value will be clipped.

/DEV..../AUXOUTS/n/LIMITUPPER

Properties: Read, Write, Setting

Type: Double

Unit: V

Upper limit for the signal at the Auxiliary Output. A larger value will be clipped.

/DEV..../AUXOUTS/n/OFFSET

Properties: Read, Write, Setting

Type: Double

Unit: V

Add the specified offset voltage to the signal after scaling. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset

/DEV..../AUXOUTS/n/OUTPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the signal source to be represented on the Auxiliary Output.

-1 **manual**

Select Manual as the output option.

0 **demod_x**

Select Demod X as the output option.

1 **demod_y**

Select Demod Y as the output option.

2 **demod_r**

Select Demod R as the output option.

3 **demod_theta**

Select Demod Theta as the output option.

5 **pid**

- 9 Select PID Out as the output option.
- 9 **pid_shift**
Select PID Shift as the output option.
- 10 **pid_error**
Select PID Error as the output option.
- 11 **tu_filtered**
Select TU Filtered Value as the output option.
- 13 **tu_output**
Select TU Output Value as the output option.

/DEV..../AUXOUTS/n/PREOFFSET

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Add a pre-offset to the signal before scaling is applied. Auxiliary Output Value = (Signal +Preoffset)*Scale + Offset

/DEV..../AUXOUTS/n/SCALE

Properties: Read, Write, Setting

Type: Double

Unit: None

Multiplication factor to scale the signal. Auxiliary Output Value = (Signal+Preoffset)*Scale + Offset

/DEV..../AUXOUTS/n(VALUE

Properties: Read

Type: Double

Unit: V

Voltage present on the Auxiliary Output. Auxiliary Output Value = (Signal+Preoffset)*Scale + Offset

7.2.3. CLOCKBASE

/DEV..../CLOCKBASE

Properties: Read

Type: Double

Unit: Hz

Returns the internal clock frequency of the device.

7.2.4. CURRINS

/DEV..../CURRINS/n/AUTORANGE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Automatic adjustment of the Range to about two times the maximum current input amplitude measured over about 100 ms.

/DEV..../CURRINS/n/FLOAT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Switches the input between floating (ON) and connected grounds (OFF). This setting applies both to the voltage and the current input. It is recommended to discharge the test device before connecting or to enable this setting only after the signal source has been connected to the Signal Input in grounded mode.

0 **off**

OFF: GND connected

1 **on**

ON: Floating

/DEV..../CURRINS/n/MAX

Properties: Read, Write

Type: Double

Unit: None

Gives the maximum measured input current (peak value) normalized to input range.

/DEV..../CURRINS/n/MIN

Properties: Read, Write

Type: Double

Unit: None

Gives the minimum measured input current (peak value) normalized to input range.

/DEV..../CURRINS/n/ON

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the current input.

/DEV..../CURRINS/n/RANGE

Properties: Read, Write, Setting

Type: Double

Unit: A

Defines the gain of the current input amplifier. The range should exceed the incoming signal by roughly a factor of two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used.

/DEV..../CURRINS/n/SCALING

Properties: Read, Write, Setting

Type: Double

Unit: None

Applies the given scale factor to the current input.

/DEV..../CURRINS/n/RANGESTEP/TRIGGER

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Switches to the next appropriate input range such that the range fits best with the measured input current.

7.2.5. DEMODS

/DEV..../DEMODY/n/ADCSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the input signal for the demodulator.

| | |
|-----|---|
| 0 | sigin0, signal_input0 Sig In 1 |
| 1 | currin0, current_input0 Curr In 1 |
| 2 | trigin0, trigger_input0 Trigger Input 1 |
| 3 | trigin1, trigger_input1 Trigger Input 2 |
| 4 | auxout0, auxiliary_output0 Aux Out 1 |
| 5 | auxout1, auxiliary_output1 Aux Out 2 |
| 6 | auxout2, auxiliary_output2 Aux Out 3 |
| 7 | auxout3, auxiliary_output3 Aux Out 4 |
| 8 | auxin0, auxiliary_input0 Aux In 1 |
| 9 | auxin1, auxiliary_input1 Aux In 2 |
| 174 | demod_constant_input |

Demodulate a constant input. This results in a sine wave of the frequency specified by the demodulator's oscillator with an amplitude of 1 (at lower frequencies; higher frequencies will be attenuated). The maximum possible frequency is limited by the demodulator sampling rate and bandwidth; use demodulator order 1 for the least attenuation in demodulator output. This signal may be used with the auxiliary outputs, PID and Threshold Unit for advanced measurement and control tasks. When the demodulator output is written to an auxiliary output, the resulting signal can also be used as a second output channel (for low frequencies).

/DEV..../DEMOS/n/BYPASS

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Allows to bypass the demodulator low-pass filter, thus increasing the bandwidth.

/DEV..../DEMOS/n/ENABLE

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Enables the data acquisition for the corresponding demodulator. Note: increasing number of active demodulators increases load on the physical connection to the host computer.

| | |
|---|---------------------------|
| 0 | off |
| | OFF: demodulator inactive |
| 1 | on |
| | ON: demodulator active |

/DEV..../DEMOSD/n/FREQ

Properties: Read

Type: Double

Unit: Hz

Indicates the frequency used for demodulation and for output generation. The demodulation frequency is calculated with oscillator frequency times the harmonic factor. When the MOD option is used linear combinations of oscillator frequencies including the harmonic factors define the demodulation frequencies.

/DEV..../DEMOSD/n/HARMONIC

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Multiplies the demodulator's reference frequency by an integer factor. If the demodulator is used as a phase detector in external reference mode (PLL), the effect is that the internal oscillator locks to the external frequency divided by the integer factor.

/DEV..../DEMOSD/n/ORDER

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the filter roll off between 6 dB/oct and 48 dB/oct.

| | |
|---|----------------------------|
| 1 | 1st order filter 6 dB/oct |
| 2 | 2nd order filter 12 dB/oct |
| 3 | 3rd order filter 18 dB/oct |
| 4 | 4th order filter 24 dB/oct |
| 5 | 5th order filter 30 dB/oct |
| 6 | 6th order filter 36 dB/oct |
| 7 | 7th order filter 42 dB/oct |
| 8 | 8th order filter 48 dB/oct |

/DEV..../DEMOSD/n/OSCSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Connects the demodulator with the supplied oscillator. Number of available oscillators depends on the installed options.

0 Oscillator 1

1 Oscillator 2

2 Oscillator 3

3 Oscillator 4

/DEV..../DEMOSD/n/PHASEADJUST

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Adjust the demodulator phase automatically in order to read 0 degrees.

/DEV..../DEMOSD/n/PHASESHIFT

Properties: Read, Write, Setting

Type: Double

Unit: deg

Phase shift applied to the reference input of the demodulator.

/DEV..../DEMOSD/n/RATE

Properties: Read, Write, Setting

Type: Double

Unit: 1/s

Defines the demodulator sampling rate, the number of samples that are sent to the host computer per second. A rate of about 7-10 higher as compared to the filter bandwidth usually provides sufficient aliasing suppression. This is also the rate of data received by LabOne Data Server and saved to the computer hard disk. This setting has no impact on the sample rate on the auxiliary outputs connectors. Note: the value inserted by the user may be approximated to the nearest value supported by the instrument.

/DEV..../DEMOSD/n/SAMPLE

Properties: Read, Stream

Type: ZIDemodSample
Unit: Dependent

Contains streamed demodulator samples with sample interval defined by the demodulator data rate.

/DEV..../DEMOSD/n/SINC

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the sinc filter. When the filter bandwidth is comparable to or larger than the demodulation frequency, the demodulator output may contain frequency components at the frequency of demodulation and its higher harmonics. The sinc is an additional filter that attenuates these unwanted components in the demodulator output.

/DEV..../DEMOSD/n/TIMECONSTANT

Properties: Read, Write, Setting
Type: Double
Unit: s

Sets the integration time constant or in other words, the cutoff frequency of the demodulator low pass filter.

/DEV..../DEMOSD/n/TRIGGER

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Selects the acquisition mode (i.e. triggering) or the demodulator.

- 0 **continuous**
Continuous: demodulator data is continuously streamed to the host computer.
- 1 **trigin0_rising, trigger_input0_rising**
Trigger Input 1: rising edge triggered.
- 2 **trigin0_falling, trigger_input0_falling**
Trigger Input 1: falling edge triggered.
- 3 **trigin0_both, trigger_input0_both**
Trigger Input 1: triggering on both rising and falling edge.
- 4 **trigin1_rising, trigger_input1_rising**
Trigger Input 2: rising edge triggered.
- 5 **trigin0or1_rising, trigger_input0or1_rising**
Trigger Input 1 or 2: rising edge triggered on either input.
- 8 **trigin1_falling, trigger_input1_falling**

| | |
|-----|--|
| | Trigger Input 2: falling edge triggered. |
| 10 | trigin0or1_falling, trigger_input0or1_falling Trigger Input 1 or 2: falling edge triggered on either input. |
| 12 | trigin1_both, trigger_input1_both Trigger Input 2: triggering on both rising and falling edge. |
| 15 | trigin0or1_both, trigger_input0or1_both Trigger Input 1 or 2: triggering on both rising and falling edge or either trigger input. |
| 16 | trigin0_low, trigger_input0_low Trigger Input 1: demodulator data is streamed to the host computer when the level is low (TTL). |
| 32 | trigin0_high, trigger_input0_high Trigger Input 1 for MF: demodulator data is streamed to the host computer when the level is high (TTL). |
| 64 | trigin1_low, trigger_input1_low Trigger Input 2: demodulator data is streamed to the host computer when the level is low (TTL). |
| 80 | trigin0or1_low, trigger_input0or1_low Trigger Input 1 or 2: demodulator data is streamed to the host computer when either level is low (TTL). |
| 128 | trigin1_high, trigger_input1_high Trigger Input 2: demodulator data is streamed to the host computer when the level is high (TTL). |
| 160 | trigin0or1_high, trigger_input0or1_high Trigger Input 1 or 2: demodulator data is streamed to the host computer when either level is high (TTL). |

7.2.6. DIOS (Digital I/O)

/DEV..../DIOS/n/AUXDRIVE

Properties: Read
Type: Integer (64 bit)
Unit: None

Not used. Reserved for future use.

/DEV..../DIOS/n/DECIMATION

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Sets the decimation factor for DIO data streamed to the host computer.

/DEV..../DIOS/n/DRIVE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

When on (1), the corresponding 8-bit bus is in output mode. When off (0), it is in input mode. Bit 0 corresponds to the least significant byte. For example, the value 1 drives the least significant byte, the value 8 drives the most significant byte.

/DEV..../DIOS/n/EXTCLK

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select DIO internal or external clocking.

0 **internal**

The DIO is internally clocked with a fixed frequency of 60 MHz.

1 **external**

The DIO is externally clocked with a clock signal connected to DIO Pin 68. The available range is from 1 Hz up to the internal clock frequency.

/DEV..../DIOS/n/INPUT

Properties: Read, Stream

Type: ZIDIOSample

Unit: None

Gives the value of the DIO input for those bytes where drive is disabled.

/DEV..../DIOS/n/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select DIO mode

0 **manual**

Enables manual control of the DIO output bits.

3 **threshold_unit**

Enables setting of DIO output values by the threshold unit.

/DEV..../DIOS/n/OUTPUT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Sets the value of the DIO output for those bytes where 'drive' is enabled.

7.2.7. EXTREFS

/DEV..../EXTREFS/n/ADCSELECT

Properties: Read

Type: Integer (enumerated)

Unit: None

Indicates the input signal selection for the selected demodulator.

0 **sigin0, signal_input0**

Signal Input 1 is connected to the corresponding demodulator.

1 **currin0, current_input0**

Current Input 1 is connected to the corresponding demodulator.

2 **trigin0, trigger_input0**

Trigger Input 1 is connected to the corresponding demodulator.

3 **trigin1, trigger_input1**

Trigger Input 2 is connected to the corresponding demodulator.

4 **auxout0, auxiliary_output0**

Auxiliary Output 1 is connected to the corresponding demodulator.

5 **auxout1, auxiliary_output1**

Auxiliary Output 2 is connected to the corresponding demodulator.

6 **auxout2, auxiliary_output2**

Auxiliary Output 3 is connected to the corresponding demodulator.

7 **auxout3, auxiliary_output3**

Auxiliary Output 4 is connected to the corresponding demodulator.

8 **auxin0, auxiliary_input0**

Auxiliary Input 1 is connected to the corresponding demodulator.

9 **auxin1, auxiliary_input1**

Auxiliary Input 2 is connected to the corresponding demodulator.

/DEV..../EXTREFS/n/AUTOMODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

This defines the type of automatic adaptation of parameters in the PID used for Ext Ref.

0 **off**

No automatic adaption.

1 **coefficients_only**

The coefficients of the PID controller are automatically set.

2 **low_bandwidth**

The PID coefficients, the filter bandwidth and the output limits are automatically set using a low bandwidth.

3 **high_bandwidth**

The PID coefficients, the filter bandwidth and the output limits are automatically set using a high bandwidth.

4 **all**

All parameters of the PID including the center frequency are adapted.

/DEV..../EXTREFS/n/DEMODOSELECT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Indicates the demodulator connected to the extref channel.

/DEV..../EXTREFS/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the external reference.

/DEV..../EXTREFS/n/LOCKED

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates whether the external reference is locked.

/DEV..../EXTREFS/n/OSCSELECT

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates which oscillator is being locked to the external reference.

7.2.8. FEATURES

/DEV..../FEATURES/CODE

Properties: Read, Write

Type: String

Unit: None

Node providing a mechanism to write feature codes.

/DEV..../FEATURES/DEVTYPE

Properties: Read

Type: String

Unit: None

Returns the device type.

/DEV..../FEATURES/OPTIONS

Properties: Read

Type: String

Unit: None

Returns enabled options.

/DEV..../FEATURES/SERIAL

Properties: Read

Type: String

Unit: None

Device serial number.

7.2.9. IMPS (Impedance)

/DEV..../IMPS/n/AC

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Defines the input coupling for the Signal Inputs. AC coupling inserts a high-pass filter.

/DEV..../IMPS/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable impedance calculation for demodulator data.

/DEV..../IMPS/n/FREQ

Properties: Read, Write, Setting

Type: Double

Unit: Hz

Frequency control for the oscillator used for impedance measurement.

/DEV..../IMPS/n/INTERPOLATION

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the interpolation method of the compensation data. The interpolation method is particularly important if the derivative changes strongly e.g at cut-off frequencies.

0 **linear**

Linear: The linear interpolation is fastest but may create compensation errors in between the frequency points used for compensation.

1 **pchip**

Piecewise Cubic Hermite (PCHIP): The piecewise cubic Hermite interpolation will result in very accurate results but requires more calculation power.

/DEV..../IMPS/n/MAXBANDWIDTH

Properties: Read, Write, Setting

Type: Double

Unit: Hz

Limit of the maximum bandwidth used on the demodulator filter. Values above 1 kHz can heavily diminish measurement accuracy in the high-frequency region where the amplitude is no more constant over frequency.

/DEV..../IMPS/n/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)
Unit: None

Select impedance measurement mode.

0 4 Terminal

This method uses the current and the voltage drop across the DUT to calculate the DUT impedance. This method results in very accurate measurements as influences of series resistors on the output and current input are excluded.

1 2 Terminal

This method uses the driving voltage and the measured current to calculate the DUT impedance. The 2 Terminal method can be beneficial when measuring very high impedance where the parasitics of the voltage measurement are limiting the frequency range.

/DEV..../IMPS/n/MODEL

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Representation of the complex impedance value Z by two real values accessible as Parameter 1 and Parameter 2 on all user interface displays.

0 **r_c_parallel**

R_p

C_p: Impedance value Z is represented by a resistive element R_p in parallel with a capacitive element C_p.

1 **r_c_series**

R_s + C_s: Impedance value Z is represented by a resistive element R_s in series with a capacitive element C_s.

2 **r_l_series**

R_s + L_s: Impedance value Z is represented by a resistive element R_s in series with an inductive element L_s.

3 **g_b_parallel, admittance**

G B: Impedance value Z is represented by conductance G = Real(Y) and Susceptance B = Imag(Y) of the admittance Y = 1/Z.

4 **d_c_series**

D C_s: Impedance value Z is represented by a dissipation factor D = -Real(Z)/Imag(Z) (loss tangent) and a series capacitive element.

5 **q_c_series**

Q C_s: Impedance value Z is represented by a quality factor Q = -Imag(Z)/Real(Z) and a series capacitive element.

6 **d_l_series**

D L_s: Impedance value Z is represented by a dissipation factor D = Real(Z)/Imag(Z) (loss tangent) and a series inductive element.

7 **q_l_series**

Q Ls: Impedance value Z is represented by a quality factor Q = Imag(Z)/Real(Z) and a series inductive element.

8 **r_l_parallel**

Rp

Lp: Impedance value Z is represented by a resistive element Rp in parallel with an inductive element Lp.

9 **d_c_parallel**

D Cp: Impedance value Z is represented by a dissipation factor D = Real(Z)/Imag(Z) (loss tangent) and a parallel capacitive element Cp.

/DEV..../IMPS/n/OMEGASUPPRESSION

Properties: Read, Write, Setting

Type: Double

Unit: dB

Suppression of the omega and 2-omega components. Small omega suppression can diminish measurements of very low or high impedance because the DC component can become dominant. Large omega suppression will have a significant impact on sweep time especially for low filter orders.

/DEV..../IMPS/n/SAMPLE

Properties: Read, Stream

Type: ZIImpedanceSample

Unit: None

Streaming node containing the impedance measurement sample data.

/DEV..../IMPS/n/AUTO/BW

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable automatic bandwidth control. If enabled the optimum bandwidth is calculated based on the frequency and measurement data.

/DEV..../IMPS/n/AUTO/INPUTRANGE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select input range control mode.

0 Manual

In manual mode the current and voltage input ranges are adjusted manually and separately. Use this mode with care as overload will result in inaccurate impedance results.

1 Auto

Dynamically adjust the input range according to the measured input signal strength. This optimizes the dynamic range and precision of impedance measurements.

2 Zone

This ranging option allows you to manually set the switching frequency limits for all eight current input ranges.

/DEV..../IMPS/n/AUTO/OUTPUT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

If enabled, the drive voltage amplitude is controlled by the device. If disabled it can be set manually.

/DEV..../IMPS/n/AUTO/SUPPRESS

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates disabled periodic auto range control. A running sweeper module takes over the range control and thus disables the periodic range checks.

/DEV..../IMPS/n/BIAS/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the DC bias voltage.

/DEV..../IMPS/n/BIAS/VALUE

Properties: Read, Write, Setting

Type: Double

Unit: V

DC bias voltage applied across the device under test. Both positive and negative bias voltages are supported. In a 4-terminal measurement, the bias voltage is limited by the maximum common voltage input range of the device. In a 2-terminal measurement, the bias voltage can be larger because the voltage inputs are not connected.

/DEV..../IMPS/n/CURRENT/DEMODOSELECT

Properties: Read

Type: Integer (64 bit)

Unit: None

Demodulator used for current demodulation.

/DEV..../IMPS/n/CURRENT/INPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the current input used for two- and four-terminal impedance measurements.

0 currin0, current_input0

Current Input 1

8 auxin0, auxiliary_input0

Aux In 1

9 auxin1, auxiliary_input1

Aux In 2

/DEV..../IMPS/n/CURRENT/INVERT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

If enabled, the current input signal is inverted. This is useful to switch the polarity of an input signal which can be caused by additional current amplifiers.

/DEV..../IMPS/n/CURRENT/RANGE

Properties: Read, Write, Setting

Type: Double

Unit: A

Input current range used for the impedance measurement. Small current input ranges have a reduced bandwidth. In the Range Control modes 'Auto' and 'Impedance', the current range is switched automatically to a higher range if the frequency is too high.

/DEV..../IMPS/n/CURRENT/SCALING

Properties: Read, Write, Setting

Type: Double
Unit: A/V

The scaling factor will be applied to the current measurement done with an Aux In input.

/DEV..../IMPS/n/DEMOD/HARMONIC

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Multiplies the demodulator's reference frequency with the integer factor defined by this field.

/DEV..../IMPS/n/DEMOD/ORDER

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Selects the filter roll off between 6 dB/oct and 48 dB/oct of the current demodulator.

- 1 1st order filter 6 dB/oct
- 2 2nd order filter 12 dB/oct
- 3 3rd order filter 18 dB/oct
- 4 4th order filter 24 dB/oct
- 5 5th order filter 30 dB/oct
- 6 6th order filter 36 dB/oct
- 7 7th order filter 42 dB/oct
- 8 8th order filter 48 dB/oct

/DEV..../IMPS/n/DEMOD/OSCSELECT

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Oscillator used to generate the frequency of the excitation voltage on the Hcur (+V) connector.

- 0 Oscillator 1
- 1 Oscillator 2
- 2 Oscillator 3
- 3 Oscillator 4

/DEV..../IMPS/n/DEMOD/RATE

Properties: Read, Write, Setting

Type: Double
Unit: 1/s

Impedance data streaming rate. The same data rate is applied to the demodulators that are used for the impedance measurement.

/DEV..../IMPS/n/DEMOD/SINC

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the sinc filter.

/DEV..../IMPS/n/DEMOD/TIMECONSTANT

Properties: Read, Write, Setting
Type: Double
Unit: s

Defines low pass filter time constant.

/DEV..../IMPS/n/DISCARD/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Discarding impedance samples outside the indicated range.

/DEV..../IMPS/n/DISCARD/LIMITLOWER

Properties: Read, Write, Setting
Type: Double
Unit: None

Threshold for $\text{abs}(Z)$ below which the impedance samples are discarded.

/DEV..../IMPS/n/DISCARD/LIMITUPPER

Properties: Read, Write, Setting
Type: Double
Unit: None

Threshold for $\text{abs}(Z)$ above which the impedance samples are discarded.

/DEV..../IMPS/n/ONEPERIOD/ACTIVE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables one-period averaging for low frequency impedance measurements. The LED is green when active.

/DEV..../IMPS/n/ONEPERIOD/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables one-period averaging for low frequency impedance measurements. The LED is green when active.

/DEV..../IMPS/n/OUTPUT/AMPLITUDE

Properties: Read, Write, Setting

Type: Double

Unit: V

Drive amplitude on the Signal Output.

/DEV..../IMPS/n/OUTPUT/DEMOD

Properties: Read

Type: Integer (64 bit)

Unit: None

Demodulator unit used to generate the excitation voltage on the Signal Output.

/DEV..../IMPS/n/OUTPUT/ON

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Main switch for the Signal Output corresponding to the blue LED indicator on the instrument front panel.

/DEV..../IMPS/n/OUTPUT/RANGE

Properties: Read, Write, Setting

Type: Double
Unit: V

Selects the output voltage range.

/DEV..../IMPS/n/OUTPUT/SELECT

Properties: Read
Type: Integer (enumerated)
Unit: None

Selects the output channel that the excitation voltage drives.

0 **sigout0, signal_output0**
 Signal Output 1

/DEV..../IMPS/n/VOLTAGE/DEMODOSELECT

Properties: Read
Type: Integer (64 bit)
Unit: None

Demodulator used for voltage measurement in case of a four-terminal impedance measurement.

/DEV..../IMPS/n/VOLTAGE/INPUTSELECT

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Select the voltage input used for a four-terminal impedance measurement.

0 **voltage_input0**
 Voltage Input 1
8 **auxin0, auxiliary_input0**
 Aux In 1
9 **auxin1, auxiliary_input1**
 Aux In 2

/DEV..../IMPS/n/VOLTAGE/INVERT

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

If enabled, the voltage input signal is inverted.

/DEV..../IMPS/n/VOLTAGE/RANGE

Properties: Read, Write, Setting

Type: Double

Unit: V

Input voltage range for the impedance measurement.

/DEV..../IMPS/n/VOLTAGE/SCALING

Properties: Read, Write, Setting

Type: Double

Unit: V/V

The scaling factor will be applied to the voltage measurement done with an Aux In input.

/DEV..../IMPS/n/CALIB/INTERNAL/ACTIVE

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates if the internal calibration is applied to the measurement data.

/DEV..../IMPS/n/CALIB/INTERNAL/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the internal calibration. This ensures that the input range gains match over the full frequency range. With enabled internal calibration the device fulfills the impedance accuracy specification. The internal calibration is a prerequisite to apply a user compensation.

/DEV..../IMPS/n/CALIB/INTERNAL/SMOOTH

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables smoothing of the internal calibration data. This results in lower noise in the measured data.

/DEV..../IMPS/n/CALIB/USER/ACTIVE

Properties: Read

Type: Integer (64 bit)
Unit: None

Indicates that a valid user compensation is active. If active the impedance data streams deliver amplitude and phase corrected data based on the impedance user compensation.

/DEV..../IMPS/n/CALIB/USER/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the user compensation of the impedance data. The user compensation is correcting parasitics and delays caused by the external setup. The user compensation is applied on top of the internal impedance calibration.

/DEV..../IMPS/n/CALIB/USER/SMOOTH

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables smoothing of the compensation data. This results in lower noise in the measured data.

/DEV..../IMPS/n/CONFIDENCE/COMPENSATION/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the indication of strong compensation in the plots. A strong compensation diminishes the measurement accuracy of the parameter.

/DEV..../IMPS/n/CONFIDENCE/COMPENSATION/RATIO

Properties: Read, Write, Setting
Type: Double
Unit: None

Strength of the compensation that will trigger the strong compensation warning.

/DEV..../IMPS/n/CONFIDENCE/FREQLIMIT/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the frequency limit detection based on the used current input range. Only relevant when Range Control is set to Manual.

/DEV..../IMPS/n/CONFIDENCE/LOWDUT2T/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables a warning when measuring a low impedance (100k) with a 2 point contact.

/DEV..../IMPS/n/CONFIDENCE/LOWDUT2T/RATIO

Properties: Read, Write, Setting
Type: Double
Unit: None

When measuring with 2 point contacts, too low impedance of DUT will trigger the Low DUT 2T warning.

/DEV..../IMPS/n/CONFIDENCE/ONEPERIOD/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the detection of unreliable data points where data sample loss leads to an invalid one-period average. Try reducing the data transfer rate.

/DEV..../IMPS/n/CONFIDENCE/OPENDECT/ENABLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the open terminal detection for 4-terminal measurements.

/DEV..../IMPS/n/CONFIDENCE/OPENDECT/RATIO

Properties: Read, Write, Setting
Type: Double
Unit: None

Open terminal detection ratio. An open terminal is reported if the excitation calculated from current and voltage drop differs more than the specified factor from the driving voltage.

/DEV..../IMPS/n/CONFIDENCE/OVERFLOW/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the overload detection for current and voltage.

/DEV..../IMPS/n/CONFIDENCE/QFACTOR/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the detection of negative Q or D factors. Negative Q or D factors mean the measured impedance does not correspond to the chosen Representation. This can be due to an erroneous compensation, a bad choice of the Representation, or noise.

/DEV..../IMPS/n/CONFIDENCE/SUPPRESSION/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

The Suppression Confidence Indicator indicates if one of the two parameters of a circuit representation cannot be calculated reliably from the measured impedance. This is the case if a small variation in one (dominant) representation parameter creates a strong variation of the other (suppressed) representation parameter. Such an error amplification indicates that the measurement of the secondary parameter is unreliable.

/DEV..../IMPS/n/CONFIDENCE/SUPPRESSION/RATIO

Properties: Read, Write, Setting

Type: Double

Unit: None

Error amplification limit for which a secondary parameter is marked unreliable. Larger gain values mean larger warning tolerances. A gain value between 10 and 100 is best.

/DEV..../IMPS/n/CONFIDENCE/UNDERFLOW/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the underflow detection for current and voltage.

/DEV..../IMPS/n/CONFIDENCE/UNDERFLOW/RATIO

Properties: Read, Write, Setting

Type: Double

Unit: None

The underflow condition is met if the measured amplitude is lower than the specified ratio relative to full scale.

/DEV..../IMPS/n/CURRENT/PID/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

If enabled, the PID value is used for the impedance calculation instead of the measured value at the current input.

7.2.10. MODS (Modulation)

/DEV..../MODS/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the modulation.

/DEV..../MODS/n/FREQDEV

Properties: Read, Write, Setting

Type: Double

Unit: Hz

FM mode peak deviation value.

/DEV..../MODS/n/FREQDEVENABLE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

In FM mode, choose to work with either modulation index or peak deviation. The modulation index equals peak deviation divided by modulation frequency.

- 0 **modulation_index**
 Use modulation index.
- 1 **peak_deviation**
 Use peak deviation.

/DEV..../MODS/n/INDEX

Properties: Read, Write, Setting
Type: Double
Unit: None

FM modulation index: The modulation index equals peak deviation divided by modulation frequency.

/DEV..../MODS/n/MODE

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Select the modulation mode.

- 0 **am**
 AM Modulation
- 1 **fm**
 FM Modulation
- 2 **manual**
 Manual

/DEV..../MODS/n/OUTPUT

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Select Signal Output.

- 0 **none**
 None
- 1 **sigout0, signal_output0**
 Signal Output 1

/DEV..../MODS/n/CARRIER/AMPLITUDE

Properties: Read, Write, Setting
Type: Double

Unit: V

Set the carrier amplitude

/DEV..../MODS/n/CARRIER/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable the modulation

/DEV..../MODS/n/CARRIER/HARMONIC

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Set the harmonic of the carrier frequency. 1 = Fundamental

/DEV..../MODS/n/CARRIER/INPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select Signal Input for the carrier demodulation

| | | |
|---|---|--|
| 0 | <code>sigin0, signal_input0</code> | |
| | Sig In 1 | |
| 1 | <code>currin0, current_input0</code> | |
| | Curr In 1 | |
| 2 | <code>trigin0, trigger_input0</code> | |
| | Trigger Input 1 | |
| 3 | <code>trigin1, trigger_input1</code> | |
| | Trigger Input 2 | |
| 4 | <code>auxout0, auxiliary_output0</code> | |
| | Aux Out 1 | |
| 5 | <code>auxout1, auxiliary_output1</code> | |
| | Aux Out 2 | |
| 6 | <code>auxout2, auxiliary_output2</code> | |
| | Aux Out 3 | |
| 7 | <code>auxout3, auxiliary_output3</code> | |
| | Aux Out 4 | |
| 8 | <code>auxin0, auxiliary_input0</code> | |
| | Aux In 1 | |

9 **auxin1, auxiliary_input1**

Aux In 2

174 **demod_constant_input**

Demodulate a constant input. This results in a sine wave of the frequency specified by the demodulator's oscillator with an amplitude of 1 (at lower frequencies; higher frequencies will be attenuated). The maximum possible frequency is limited by the demodulator sampling rate and bandwidth; use demodulator order 1 for the least attenuation in demodulator output. This signal may be used with the auxiliary outputs, PID and Threshold Unit for advanced measurement and control tasks. When the demodulator output is written to an auxiliary output, the resulting signal can also be used as a second output channel (for low frequencies).

/DEV..../MODS/n/CARRIER/ORDER

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Filter order used for carrier demodulation

1 1st order filter 6 dB/oct

2 2nd order filter 12 dB/oct

3 3rd order filter 18 dB/oct

4 4th order filter 24 dB/oct

5 5th order filter 30 dB/oct

6 6th order filter 36 dB/oct

7 7th order filter 42 dB/oct

8 8th order filter 48 dB/oct

/DEV..../MODS/n/CARRIER/OSCSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the oscillator for the carrier signal.

0 Oscillator 1

1 Oscillator 2

2 Oscillator 3

3 Oscillator 4

/DEV..../MODS/n/CARRIER/PHASESHIFT

Properties: Read, Write, Setting

Type: Double

Unit: degree

Phase shift applied to the reference input of the carrier demodulator and also to the carrier signal on the Signal Outputs

/DEV..../MODS/n/CARRIER/TIMECONSTANT

Properties: Read, Write, Setting

Type: Double

Unit: s

Sets the integration time constant or in other words, the cutoff frequency of the low-pass filter for the carrier demodulation.

/DEV..../MODS/n/SIDEBOARDS/n/AMPLITUDE

Properties: Read, Write, Setting

Type: Double

Unit: V

Set the amplitude of the sideband components.

/DEV..../MODS/n/SIDEBOARDS/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable the signal generation for the respective sideband

/DEV..../MODS/n/SIDEBOARDS/n/HARMONIC

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Set harmonic of the sideband frequencies. 1 = fundamental

/DEV..../MODS/n/SIDEBOARDS/n/INPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select Signal Input for the sideband demodulation

0 `sigin0, signal_input0`

Sig In 1

```
1 currin0, current_input0
  Curr In 1
2 trigin0, trigger_input0
  Trigger Input 1
3 trigin1, trigger_input1
  Trigger Input 2
4 auxout0, auxiliary_output0
  Aux Out 1
5 auxout1, auxiliary_output1
  Aux Out 2
6 auxout2, auxiliary_output2
  Aux Out 3
7 auxout3, auxiliary_output3
  Aux Out 4
8 auxin0, auxiliary_input0
  Aux In 1
9 auxin1, auxiliary_input1
  Aux In 2
174 demod_constant_input
```

Demodulate a constant input. This results in a sine wave of the frequency specified by the demodulator's oscillator with an amplitude of 1 (at lower frequencies; higher frequencies will be attenuated). The maximum possible frequency is limited by the demodulator sampling rate and bandwidth; use demodulator order 1 for the least attenuation in demodulator output. This signal may be used with the auxiliary outputs, PID and Threshold Unit for advanced measurement and control tasks. When the demodulator output is written to an auxiliary output, the resulting signal can also be used as a second output channel (for low frequencies).

/DEV..../MODS/n/SIDEBANDS/n/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Enabling of the first sideband and selection of the position of the sideband relative to the carrier frequency for manual mode.

```
0 off
  Off: First sideband is disabled. The sideband demodulator behaves like a normal
        demodulator.
1 upper
  C + M: First sideband to the right of the carrier
2 lower
  C - M: First sideband to the left of the carrier
```

/DEV..../MODS/n/SIDEBANDS/n/ORDER

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Filter order used for sideband demodulation

- 1 1st order filter 6 dB/oct
- 2 2nd order filter 12 dB/oct
- 3 3rd order filter 18 dB/oct
- 4 4th order filter 24 dB/oct
- 5 5th order filter 30 dB/oct
- 6 6th order filter 36 dB/oct
- 7 7th order filter 42 dB/oct
- 8 8th order filter 48 dB/oct

/DEV..../MODS/n/SIDEBANDS/n/OSCSELECT

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Select the oscillator for the second sideband.

- 0 Oscillator 1
- 1 Oscillator 2
- 2 Oscillator 3
- 3 Oscillator 4

/DEV..../MODS/n/SIDEBANDS/n/PHASESHIFT

Properties: Read, Write, Setting
Type: Double
Unit: degree

Phase shift applied to the reference input of the sideband demodulator and also to the sideband signal on the Signal Outputs

/DEV..../MODS/n/SIDEBANDS/n/TIMECONSTANT

Properties: Read, Write, Setting
Type: Double
Unit: s

Sets the integration time constant or in other words, the cutoff frequency of the low-pass filter for the sideband demodulation.

7.2.11. OSCE (Oscillators)

/DEV..../OSCS/n/FREQ

Properties: Read, Write, Setting

Type: Double

Unit: Hz

Frequency control for each oscillator.

7.2.12. PIDS

/DEV..../PIDS/n/CENTER

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Sets the center value for the PID output. After adding the Center value, the signal is clamped to Center + Lower Limit and Center + Upper Limit.

/DEV..../PIDS/n/D

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

PID derivative gain.

/DEV..../PIDS/n/DLIMITTIMECONSTANT

Properties: Read, Write, Setting

Type: Double

Unit: s

The cutoff of the low-pass filter for the D limitation given as time constant. When set to 0, the low-pass filter is disabled.

/DEV..../PIDS/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable the PID controller.

/DEV..../PIDS/n/ERROR

Properties: Read

Type: Double

Unit: Dependent

Error = Set point - PID Input.

/DEV..../PIDS/n/I

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

PID integral gain I.

/DEV..../PIDS/n/INPUT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select input source of PID controller.

| | | |
|---|---------------------------------|-------------------|
| 0 | demod_x | Demodulator X |
| 1 | demod_y | Demodulator Y |
| 2 | demod_r | Demodulator R |
| 3 | demod_theta | Demodulator Theta |
| 4 | auxin, auxiliary_input | Aux Input |
| 5 | auxout, auxiliary_output | Aux Output |

/DEV..../PIDS/n/INPUTCHANNEL

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Select input channel of PID controller.

/DEV..../PIDS/n/KEEPINT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: Dependent

If enabled, the accumulated integral error is maintained upon restart of the PID. If is disabled, the integral error is set to zero when the PID is disabled.

/DEV..../PIDS/n/LIMITLOWER

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Sets the lower limit for the PID output. After adding the Center value, the signal is clamped to Center + Lower Limit and Center + Upper Limit.

/DEV..../PIDS/n/LIMITUPPER

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Sets the upper limit for the PID output. After adding the Center value, the signal is clamped to Center + Lower Limit and Center + Upper Limit.

/DEV..../PIDS/n/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Sets the operation mode of the PID module.

- | | |
|---|-----------------------------|
| 0 | pid |
| | PID |
| 1 | pll |
| | PLL (phase locked loop) |
| 2 | extref |
| | ExtRef (external reference) |

/DEV..../PIDS/n/OUTPUT

Properties: Read, Write, Setting

Type: Integer (enumerated)
Unit: None

Select output of the PID controller.

- 0 **sigout, signal_output**
Feedback to the main signal output amplitudes
- 1 **oscillator_frequency**
Feedback to any of the internal oscillator frequencies
- 2 **demod_phase**
Feedback to any of the 8 demodulator phase set points
- 3 **auxout_offset, auxiliary_output_offset**
Feedback to any of the 4 Auxiliary Output's Offset
- 4 **sigout_offset, signal_output_offset**
Feedback to the main Signal Output offset adjustment

/DEV..../PIDS/n/OUTPUTCHANNEL

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Select the output channel of the driven output of PID controller.

/DEV..../PIDS/n/P

Properties: Read, Write, Setting
Type: Double
Unit: Dependent

PID Proportional gain P.

/DEV..../PIDS/n/PHASEUNWRAP

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Enables the phase unwrapping to track phase errors past the +/-180 degree boundary and increase PLL bandwidth.

/DEV..../PIDS/n/RATE

Properties: Read, Write, Setting
Type: Double

Unit: 1/s

PID sampling rate and update rate of PID outputs. Needs to be set substantially higher than the targeted loop filter bandwidth.

/DEV..../PIDS/n/SETPOINT

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

PID controller setpoint

/DEV..../PIDS/n/SHIFT

Properties: Read

Type: Double

Unit: Dependent

Difference between the current output value Out and the Center. Shift = P*Error + I*Int(Error, dt) + D*dError/dt

/DEV..../PIDS/n(VALUE

Properties: Read

Type: Double

Unit: Dependent

Gives the current PID output value.

/DEV..../PIDS/n/DEMOD/ADCSELECT

Properties: Read

Type: Integer (enumerated)

Unit: None

Indicates the signal source which is connected to the chosen input demodulator channel.

0 **sigin0, signal_input0**

Signal Input 1 is connected to the corresponding demodulator.

1 **currin0, current_input0**

Current Input 1 is connected to the corresponding demodulator.

2 **trigin0, trigger_input0**

Trigger Input 1 is connected to the corresponding demodulator.

3 **trigin1, trigger_input1**

- Trigger Input 2 is connected to the corresponding demodulator.
- 4 **auxout0, auxiliary_output0**
Auxiliary Output 1 is connected to the corresponding demodulator.
- 5 **auxout1, auxiliary_output1**
Auxiliary Output 2 is connected to the corresponding demodulator.
- 6 **auxout2, auxiliary_output2**
Auxiliary Output 3 is connected to the corresponding demodulator.
- 7 **auxout3, auxiliary_output3**
Auxiliary Output 4 is connected to the corresponding demodulator.
- 8 **auxin0, auxiliary_input0**
Auxiliary Input 1 is connected to the corresponding demodulator.
- 9 **auxin1, auxiliary_input1**
Auxiliary Input 2 is connected to the corresponding demodulator.

/DEV..../PIDS/n/DEMOD/HARMONIC

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Multiplier of the for the reference frequency of the current demodulator.

/DEV..../PIDS/n/DEMOD/ORDER

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Selects the filter roll off between 6 dB/oct and 48 dB/oct of the current demodulator.

- 1 1st order filter 6 dB/oct
2 2nd order filter 12 dB/oct
3 3rd order filter 18 dB/oct
4 4th order filter 24 dB/oct
5 5th order filter 30 dB/oct
6 6th order filter 36 dB/oct
7 7th order filter 42 dB/oct
8 8th order filter 48 dB/oct

/DEV..../PIDS/n/DEMOD/TIMECONSTANT

Properties: Read, Write, Setting
Type: Double

Unit: s

Defines the characteristic time constant (cut off) of the demodulator filter used as an input.

/DEV..../PIDS/n/PLL/AUTOMODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

This defines the type of automatic adaptation of parameters in the PID.

0 **no_adaption**

No automatic adaption.

1 **pid_coeffs**

The coefficients of the PID controller are automatically set.

2 **pid_coeffs_filter_low_bw**

The PID coefficients, the filter bandwidth and the output limits are automatically set using a low bandwidth.

3 **pid_coeffs_filter_high_bw**

The PID coefficients, the filter bandwidth and the output limits are automatically set using a high bandwidth.

4 **pid_all**

All parameters of the PID including the center frequency are adapted.

/DEV..../PIDS/n/PLL/LOCKED

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates when the PID, configured as PLL, is locked.

/DEV..../PIDS/n/SETPOINTTOGGLE/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the setpoint toggle.

/DEV..../PIDS/n/SETPOINTTOGGLE/RATE

Properties: Read, Write, Setting

Type: Double

Unit: Hz

Defines the rate of setpoint toggling. Note that possible values are logarithmically spaced with a factor of 4 between values.

/DEV..../PIDS/n/SETPOINTTOGGLE/SETPOINT

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Defines the setpoint value used for setpoint toggle.

/DEV..../PIDS/n/STREAM/EFFECTIVERATE

Properties: Read

Type: Double

Unit: 1/s

Current rate of the PID stream data sent to PC. Defined based on Max Rate.

/DEV..../PIDS/n/STREAM/ERROR

Properties: Read, Stream

Type: Double

Unit: Dependent

PID Error = Set point - PID Input.

/DEV..../PIDS/n/STREAM/OVERFLOW

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates the streaming fifo overflow state. 0 = OK, 1 = overflow.

/DEV..../PIDS/n/STREAM/RATE

Properties: Read, Write, Setting

Type: Double

Unit: 1/s

Target Rate for PID output data sent to PC. This value defines the applied decimation for sending data to the PC. It does not affect any other place where PID data are used.

/DEV..../PIDS/n/STREAM/SHIFT

Properties: Read, Stream

Type: Double

Unit: Dependent

Gives the difference between the current output value and the center value. Shift = P*Error + I*Int(Error, dt) + D*dError/dt

/DEV..../PIDS/n/STREAM/VALUE

Properties: Read, Stream

Type: Double

Unit: Dependent

Gives the current PID output value.

7.2.13. SCOPES

/DEV..../SCOPES/n/CHANNEL

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Activates the scope channels.

1 Only channel 1 is active.

2 Only channel 2 is active.

3 **both**

Both, channel 1 and 2 are active.

/DEV..../SCOPES/n/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the acquisition of scope shots.

/DEV..../SCOPES/n/LENGTH

Properties: Read, Write, Setting

Type: Integer (64 bit)
Unit: None

Defines the length of the recorded Scope shot in number of samples.

/DEV..../SCOPES/n/SINGLE

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

Puts the Scope into single shot mode.

/DEV..../SCOPES/n/TIME

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Defines the time base of the scope from the divider exponent of the instrument's clock base. The resulting sampling time is $2^n/\text{clockbase}$.

| | |
|----|----------|
| 0 | 60 MHz |
| 1 | 30 MHz |
| 2 | 15 MHz |
| 3 | 7.5 MHz |
| 4 | 3.75 MHz |
| 5 | 1.88 MHz |
| 6 | 938 kHz |
| 7 | 469 kHz |
| 8 | 234 kHz |
| 9 | 117 kHz |
| 10 | 58.6 kHz |
| 11 | 29.3 kHz |
| 12 | 14.6 kHz |
| 13 | 7.32 kHz |
| 14 | 3.66 kHz |
| 15 | 1.83 kHz |

/DEV..../SCOPES/n/TRIGCHANNEL

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Selects the trigger source signal.

| | |
|----|---|
| 0 | sigin0, signal_input0 |
| | Signal Input 1 |
| 1 | currin0, current_input0 |
| | Current Input 1 |
| 2 | trigin0, trigger_input0 |
| | Trigger Input 1 |
| 3 | trigin1, trigger_input1 |
| | Trigger Input 2 |
| 4 | auxout0, auxiliary_output0 |
| | Aux Output 1. Requires an installed digitizer (DIG) option. |
| 5 | auxout1, auxiliary_output1 |
| | Aux Output 2. Requires an installed digitizer (DIG) option. |
| 6 | auxout2, auxiliary_output2 |
| | Aux Output 3. Requires an installed digitizer (DIG) option. |
| 7 | auxout3, auxiliary_output3 |
| | Aux Output 4. Requires an installed digitizer (DIG) option. |
| 8 | auxin0, auxiliary_input0 |
| | Aux Input 1 |
| 9 | auxin1, auxiliary_input1 |
| | Aux Input 2 |
| 10 | demod1 |
| | Osc φ Demod 2 |
| 11 | demod3 |
| | Osc φ Demod 4 |
| 14 | trigout0, trigger_output0 |
| | Trigger Output 1 |
| 15 | trigout1, trigger_output1 |
| | Trigger Output 2 |
| 16 | demod0_x |
| | Demod 1 X. Requires an installed digitizer (DIG) option. |
| 17 | demod1_x |
| | Demod 2 X. Requires an installed digitizer (DIG) option. |
| 18 | demod2_x |
| | Demod 3 X. Requires an installed digitizer (DIG) option. |
| 19 | demod3_x |
| | Demod 4 X. Requires an installed digitizer (DIG) option. |
| 32 | demod0_y |
| | Demod 1 Y. Requires an installed digitizer (DIG) option. |
| 33 | demod1_y |
| | Demod 2 Y. Requires an installed digitizer (DIG) option. |
| 34 | demod2_y |

Demod 3 Y. Requires an installed digitizer (DIG) option.
35 **demod3_y**
Demod 4 Y. Requires an installed digitizer (DIG) option.
48 **demod0_r**
Demod 1 R. Requires an installed digitizer (DIG) option.
49 **demod1_r**
Demod 2 R. Requires an installed digitizer (DIG) option.
50 **demod2_r**
Demod 3 R. Requires an installed digitizer (DIG) option.
51 **demod3_r**
Demod 4 R. Requires an installed digitizer (DIG) option.
64 **demod0_theta**
Demod 1 θ. Requires an installed digitizer (DIG) option.
65 **demod1_theta**
Demod 2 θ. Requires an installed digitizer (DIG) option.
66 **demod2_theta**
Demod 3 θ. Requires an installed digitizer (DIG) option.
67 **demod3_theta**
Demod 4 θ. Requires an installed digitizer (DIG) option.
80 **pid0_value**
PID 1 value. Requires an installed digitizer (DIG) option.
81 **pid1_value**
PID 2 value. Requires an installed digitizer (DIG) option.
82 **pid2_value**
PID 3 value. Requires an installed digitizer (DIG) option.
83 **pid3_value**
PID 4 value. Requires an installed digitizer (DIG) option.
144 **pid0_shift**
PID 1 Shift. Requires an installed digitizer (DIG) option.
145 **pid1_shift**
PID 2 Shift. Requires an installed digitizer (DIG) option.
146 **pid2_shift**
PID 3 Shift. Requires an installed digitizer (DIG) option.
147 **pid3_shift**
PID 4 Shift. Requires an installed digitizer (DIG) option.
208 **pid0_error**
PID 1 Error. Requires an installed digitizer (DIG) option.
209 **pid1_error**
PID 2 Error. Requires an installed digitizer (DIG) option.
210 **pid2_error**
PID 3 Error. Requires an installed digitizer (DIG) option.
211 **pid3_error**

| | |
|-----|--|
| | PID 4 Error. Requires an installed digitizer (DIG) option. |
| 224 | tu0_filtered |
| | TU 1 Filtered Value. Requires an installed digitizer (DIG) option. |
| 225 | tu1_filtered |
| | TU 2 Filtered Value. Requires an installed digitizer (DIG) option. |
| 226 | tu2_filtered |
| | TU 3 Filtered Value. Requires an installed digitizer (DIG) option. |
| 227 | tu3_filtered |
| | TU 4 Filtered Value. Requires an installed digitizer (DIG) option. |

/DEV..../SCOPES/n/TRIGDELAY

Properties: Read, Write, Setting

Type: Double

Unit: s

Trigger position relative to reference. A positive delay results in less data being acquired before the trigger point, a negative delay results in more data being acquired before the trigger point.

/DEV..../SCOPES/n/TRIGENABLE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

When triggering is enabled scope data are acquired every time the defined trigger condition is met.

| | |
|---|--|
| 0 | on |
| | ON: Trigger based scope shot acquisition |
| 1 | off |
| | OFF: Continuous scope shot acquisition |

/DEV..../SCOPES/n/TRIGFALLING

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

When set (1), enables falling edge triggering. This setting is synchronized with the settings done in the /TRIGSLOPE node.

/DEV..../SCOPES/n/TRIGFORCE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Forces a trigger event.

/DEV..../SCOPES/n/TRIGHOLDOFF

Properties: Read, Write, Setting

Type: Double

Unit: s

Defines the time before the trigger is rearmed after a recording event.

/DEV..../SCOPES/n/TRIGHOLDOFFCOUNT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Defines the trigger event number that will trigger the next recording after a recording event. A value of '1' will start a recording for each trigger event.

/DEV..../SCOPES/n/TRIGHOLDOFFMODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the holdoff mode.

0 **time**

Holdoff is defined as time (s).

1 **number_of_events**

Holdoff is defined as number of events.

/DEV..../SCOPES/n/TRIGLEVEL

Properties: Read, Write, Setting

Type: Double

Unit: V

Defines the trigger level.

/DEV..../SCOPES/n/TRIGREFERENCE

Properties: Read, Write, Setting

Type: Double

Unit: None

Trigger reference position relative to the acquired data. Default is 50% (0.5) which results in a reference point in the middle of the acquired data.

/DEV..../SCOPES/n/TRIGRISING

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

When set (1), enables rising edge triggering. This setting is synchronized with the settings done in the /TRIGFALLING node.

/DEV..../SCOPES/n/TRIGSLOPE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Sets on which slope of the trigger signal the scope should trigger. This setting is synchronized with the settings done in the /TRIGFALLING and /TRIGRISING nodes.

| | |
|---|---|
| 0 | none |
| | None |
| 1 | rising |
| | Rising edge triggered. |
| 2 | falling |
| | Falling edge triggered. |
| 3 | both |
| | Triggers on both the rising and falling edge. |

/DEV..../SCOPES/n/TRIGSTATE

Properties: Read

Type: Integer (64 bit)

Unit: None

When 1, indicates that the trigger signal satisfies the conditions of the trigger.

/DEV..../SCOPES/n/WAVE

Properties: Read, Stream

Type: ZIScopeWave

Unit: None

Contains the scope shot data.

/DEV..../SCOPES/n/SEGMENTS/COUNT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Specifies the number of segments to be recorded in device memory. The maximum scope shot size is given by the available memory divided by the number of segments. This functionality requires the DIG option.

/DEV..../SCOPES/n/SEGMENTS/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable segmented scope recording. This allows for full bandwidth recording of scope shots with a minimum dead time between individual shots. This functionality requires the DIG option.

/DEV..../SCOPES/n/STREAM/RATE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: Hz

Streaming Rate of the scope channels. The streaming rate can be adjusted independent from the scope sampling rate. The maximum rate depends on the interface used for transfer. Note: scope streaming requires the DIG option.

4 **3.75_MHz**

3.75 MHz

5 **1.88_MHz**

1.88 MHz

6 **938_kHz**

938 kHz

7 **469_kHz**

469 kHz

8 **234_kHz**

234 kHz

9 **117_kHz**

117 kHz

10 **58.6_kHz**

58.6 kHz

11 **29.3_kHz**

29.3 kHz

12 **14.6_kHz**

| | |
|----|-----------------|
| | 14.6 kHz |
| 13 | 7.32_kHz |
| | 7.32 kHz |
| 14 | 3.66_kHz |
| | 3.66 kHz |
| 15 | 1.83_kHz |
| | 1.83 kHz |

/DEV..../SCOPES/n/STREAM/SAMPLE

Properties: Read, Stream

Type: ZIScopeWave

Unit: None

Streaming node containing scope sample data. Note: scope streaming requires the DIG option.

/DEV..../SCOPES/n/TRIGGATE/ENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

If enabled the trigger will be gated by the trigger gating input signal. This feature requires the DIG option.

/DEV..../SCOPES/n/TRIGGATE/INPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the signal source used for trigger gating if gating is enabled. This feature requires the DIG option.

| | |
|---|---|
| 0 | trigin0_high,trigger_input0_high |
| | Only trigger if the Trigger Input 1 is at high level. |
| 1 | trigin0_low,trigger_input0_low |
| | Only trigger if the Trigger Input 1 is at low level. |
| 2 | trigin1_high,trigger_input1_high |
| | Only trigger if the Trigger Input 2 is at high level. |
| 3 | trigin1_low,trigger_input1_low |
| | Only trigger if the Trigger Input 2 is at low level. |

/DEV..../SCOPES/n/TRIGHYSTERESIS/ABSOLUTE

Properties: Read, Write, Setting

Type: Double

Unit: V

Defines the voltage the source signal must deviate from the trigger level before the trigger is rearmed again. Set to 0 to turn it off. The sign is defined by the Edge setting.

/DEV..../SCOPES/n/TRIGHYSTERESIS/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the mode to define the hysteresis strength. The relative mode will work best over the full input range as long as the analog input signal does not suffer from excessive noise.

0 **absolute**

Selects absolute hysteresis.

1 **relative**

Selects a hysteresis relative to the adjusted full scale signal input range.

/DEV..../SCOPES/n/TRIGHYSTERESIS/RELATIVE

Properties: Read, Write, Setting

Type: Double

Unit: None

Hysteresis relative to the adjusted full scale signal input range. A hysteresis value larger than 1 (100%) is allowed.

/DEV..../SCOPES/n/CHANNELS/n/BWLIMIT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects between sample decimation and sample averaging. Averaging avoids aliasing, but may conceal signal peaks.

0 **on**

On: Selects sample averaging for sample rates lower than the maximal available sampling rate.

1 **off**

OFF: Selects sample decimation for sample rates lower than the maximal available sampling rate.

/DEV..../SCOPES/n/CHANNELS/n/FULLSCALE

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Indicates the full scale value of the scope channel.

/DEV..../SCOPES/n/CHANNELS/n/INPUTSELECT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the scope input signal.

| | |
|----|--|
| 0 | sigin0, signal_input0 Signal Input 1 |
| 1 | currin0, current_input0 Current Input 1 |
| 2 | trigin0, trigger_input0 Trigger Input 1 |
| 3 | trigin1, trigger_input1 Trigger Input 2 |
| 4 | auxout0, auxiliary_output0 Aux Output 1. Requires an installed digitizer (DIG) option. |
| 5 | auxout1, auxiliary_output1 Aux Output 2. Requires an installed digitizer (DIG) option. |
| 6 | auxout2, auxiliary_output2 Aux Output 3. Requires an installed digitizer (DIG) option. |
| 7 | auxout3, auxiliary_output3 Aux Output 4. Requires an installed digitizer (DIG) option. |
| 8 | auxin0, auxiliary_input0 Aux Input 1 |
| 9 | auxin1, auxiliary_input1 Aux Input 2 |
| 10 | demod1 Osc φ Demod 2 |
| 11 | demod3 Osc φ Demod 4 |
| 14 | trigout0, trigger_output0 Trigger Output 1 |
| 15 | trigout1, trigger_output1 Trigger Output 2 |
| 16 | demod0_x Demod 1 X. Requires an installed digitizer (DIG) option. |
| 17 | demod1_x Demod 2 X. Requires an installed digitizer (DIG) option. |
| 18 | demod2_x Demod 3 X. Requires an installed digitizer (DIG) option. |

```
19   demod3_x
    Demod 4 X. Requires an installed digitizer (DIG) option.
32   demod0_y
    Demod 1 Y. Requires an installed digitizer (DIG) option.
33   demod1_y
    Demod 2 Y. Requires an installed digitizer (DIG) option.
34   demod2_y
    Demod 3 Y. Requires an installed digitizer (DIG) option.
35   demod3_y
    Demod 4 Y. Requires an installed digitizer (DIG) option.
48   demod0_r
    Demod 1 R. Requires an installed digitizer (DIG) option.
49   demod1_r
    Demod 2 R. Requires an installed digitizer (DIG) option.
50   demod2_r
    Demod 3 R. Requires an installed digitizer (DIG) option.
51   demod3_r
    Demod 4 R. Requires an installed digitizer (DIG) option.
64   demod0_theta
    Demod 1 θ. Requires an installed digitizer (DIG) option.
65   demod1_theta
    Demod 2 θ. Requires an installed digitizer (DIG) option.
66   demod2_theta
    Demod 3 θ. Requires an installed digitizer (DIG) option.
67   demod3_theta
    Demod 4 θ. Requires an installed digitizer (DIG) option.
80   pid0_value
    PID 1 value. Requires an installed digitizer (DIG) option.
81   pid1_value
    PID 2 value. Requires an installed digitizer (DIG) option.
82   pid2_value
    PID 3 value. Requires an installed digitizer (DIG) option.
83   pid3_value
    PID 4 value. Requires an installed digitizer (DIG) option.
144  pid0_shift
    PID 1 Shift. Requires an installed digitizer (DIG) option.
145  pid1_shift
    PID 2 Shift. Requires an installed digitizer (DIG) option.
146  pid2_shift
    PID 3 Shift. Requires an installed digitizer (DIG) option.
147  pid3_shift
    PID 4 Shift. Requires an installed digitizer (DIG) option.
```

160 Reserved for future use.
161 Reserved for future use.
208 **pid0_error**
PID 1 Error. Requires an installed digitizer (DIG) option.
209 **pid1_error**
PID 2 Error. Requires an installed digitizer (DIG) option.
210 **pid2_error**
PID 3 Error. Requires an installed digitizer (DIG) option.
211 **pid3_error**
PID 4 Error. Requires an installed digitizer (DIG) option.
240 Reserved for future use.
241 Reserved for future use.
242 Reserved for future use.
243 Reserved for future use.

/DEV..../SCOPES/n/CHANNELS/n/LIMITLOWER

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Lower limit of the scope full scale range. For demodulator, PID, Boxcar, and AU signals the limit should be adjusted so that the signal covers the specified range to achieve optimal resolution.

/DEV..../SCOPES/n/CHANNELS/n/LIMITUPPER

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Upper limit of the scope full scale range. For demodulator, PID, Boxcar, and AU signals the limit should be adjusted so that the signal covers the specified range to achieve optimal resolution.

/DEV..../SCOPES/n/CHANNELS/n/OFFSET

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Indicates the offset value of the scope channel.

/DEV..../SCOPES/n/STREAM/ENABLES/n

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enable scope streaming for the specified channel. This allows for continuous recording of scope data on the plotter and streaming to disk. Note: scope streaming requires the DIG option.

7.2.14. SIGINS

/DEV..../SIGINS/n/AC

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Defines the input coupling for the Signal Inputs. AC coupling inserts a high-pass filter.

0 **dc**

OFF: DC coupling

1 **ac**

ON: AC coupling

/DEV..../SIGINS/n/AUTORANGE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Automatic adjustment of the Range to about two times the maximum signal input amplitude measured over about 100 ms.

/DEV..../SIGINS/n/DIFF

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Switches between single ended (OFF) and differential (ON) measurements.

0 **off**

OFF: Single ended voltage input

1 **on**

ON: Differential voltage input

/DEV..../SIGINS/n/FLOAT

Properties: Read, Write, Setting

Type: Integer (enumerated)
Unit: None

Switches the input between floating (ON) and connected to ground (OFF). This setting applies both to the voltage and the current input. It is recommended to discharge the test device before connecting or to enable this setting only after the signal source has been connected to the Signal Input in grounded mode.

0 **off**
 OFF: GND connected
1 **on**
 ON: Floating

/DEV..../SIGINS/n/IMP50

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Switches between 50 Ohm (ON) and 10 M Ohm (OFF).

0 **10_MOhm**
 OFF: 10 M Ohm
1 **50_Ohm**
 ON: 50 Ohm

/DEV..../SIGINS/n/MAX

Properties: Read, Write
Type: Double
Unit: None

Indicates the maximum measured value at the input normalized to input range.

/DEV..../SIGINS/n/MIN

Properties: Read, Write
Type: Double
Unit: None

Indicates the minimum measured value at the input normalized to input range.

/DEV..../SIGINS/n/ON

Properties: Read, Write, Setting

Type: Integer (64 bit)
Unit: None

Enables the signal input.

/DEV..../SIGINS/n/RANGE

Properties: Read, Write, Setting
Type: Double
Unit: V

Defines the gain of the analog input amplifier. The range should exceed the incoming signal by roughly a factor two including a potential DC offset. The instrument selects the next higher available range relative to a value inserted by the user. A suitable choice of this setting optimizes the accuracy and signal-to-noise ratio by ensuring that the full dynamic range of the input ADC is used.

/DEV..../SIGINS/n/SCALING

Properties: Read, Write, Setting
Type: Double
Unit: None

Applies the given scaling factor to the input signal.

/DEV..../SIGINS/n/RANGESTEP/TRIGGER

Properties: Read, Write
Type: Integer (64 bit)
Unit: None

Switches to the next appropriate input range such that the range fits best with the measured input signal amplitude.

7.2.15. SIGOUTS

/DEV..../SIGOUTS/n/ADD

Properties: Read, Write, Setting
Type: Integer (64 bit)
Unit: None

The signal supplied to the Aux Input 1 is added to the signal output. For differential output the added signal is a common mode offset.

/DEV..../SIGOUTS/n/AUTORANGE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

If enabled, selects the most suited output range automatically.

/DEV..../SIGOUTS/n/DIFF

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Switch between single-ended output (OFF) and differential output (ON). In differential mode the signal swing is defined between Signal Output +V / -V.

/DEV..../SIGOUTS/n/IMP50

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the load impedance between 50 Ohm and HiZ. The impedance of the output is always 50 Ohm. For a load impedance of 50 Ohm the displayed voltage is half the output voltage to reflect the voltage seen at the load.

| | |
|---|-----------------------|
| 0 | high_impedance |
| | HiZ |
| 1 | 50_Ohm |
| | 50 Ohm |

/DEV..../SIGOUTS/n/OFFSET

Properties: Read, Write, Setting

Type: Double

Unit: V

Defines the DC voltage that is added to the dynamic part of the output signal.

/DEV..../SIGOUTS/n/ON

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enabling/Disabling the Signal Output. Corresponds to the blue LED indicator on the instrument front panel.

/DEV..../SIGOUTS/n/OVER

Properties: Read

Type: Integer (64 bit)

Unit: None

Indicates that the signal output is overloaded.

/DEV..../SIGOUTS/n/RANGE

Properties: Read, Write, Setting

Type: Double

Unit: V

Sets the output voltage range. The instrument selects the next higher available range.

/DEV..../SIGOUTS/n/AMPLITUDES/n

Properties: Read, Write, Setting

Type: Double

Unit: V

Sets the peak amplitude that the oscillator assigned to the given demodulation channel contributes to the signal output.

/DEV..../SIGOUTS/n/ENABLES/n

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: V

Enables individual output signal amplitude. When the MD option is used, it is possible to generate signals being the linear combination of the available demodulator frequencies.

7.2.16. STATS

/DEV..../STATS/CPULOAD

Properties: Read

Type: Double

Unit: %

Indicates the total CPU load on the machine where the data server is running.

/DEV..../STATS/DATASERVERCPULOAD

Properties: Read

Type: Double

Unit: %

Indicates the CPU load of the data server.

/DEV..../STATS/DATASERVERMEMLOAD

Properties: Read

Type: Double

Unit: %

Indicates the memory usage of the data server.

/DEV..../STATS/MEMLOAD

Properties: Read

Type: Double

Unit: %

Indicates the total memory usage of the machine where the data server is running.

/DEV..../STATS/CMDSTREAM/BANDWIDTH

Properties: Read

Type: Double

Unit: Mbit/s

Command streaming bandwidth usage on the physical network connection between device and data server.

/DEV..../STATS/CMDSTREAM/BYTESRECEIVED

Properties: Read

Type: Integer (64 bit)

Unit: B

Number of bytes received on the command stream from the device since session start.

/DEV..../STATS/CMDSTREAM/BYTESSENT

Properties: Read

Type: Integer (64 bit)

Unit: B

Number of bytes sent on the command stream from the device since session start.

/DEV..../STATS/CMDSTREAM/PACKETSLOST

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of command packets lost since device start. Command packets contain device settings that are sent to and received from the device.

/DEV..../STATS/CMDSTREAM/PACKETSRECEIVED

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of packets received on the command stream from the device since session start.

/DEV..../STATS/CMDSTREAM/PACKETSSENT

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of packets sent on the command stream to the device since session start.

/DEV..../STATS/CMDSTREAM/PENDING

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of buffers ready for receiving command packets from the device.

/DEV..../STATS/CMDSTREAM/PROCESSING

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of buffers being processed for command packets. Small values indicate proper performance. For a TCP/IP interface, command packets are sent using the TCP protocol.

/DEV..../STATS/DATASTREAM/BANDWIDTH

Properties: Read

Type: Double

Unit: Mbit/s

Data streaming bandwidth usage on the physical network connection between device and data server.

/DEV..../STATS/DATASTREAM/BYTESRECEIVED

Properties: Read

Type: Integer (64 bit)

Unit: B

Number of bytes received on the data stream from the device since session start.

/DEV..../STATS/DATASTREAM/PACKETSLOST

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of data packets lost since device start. Data packets contain measurement data.

/DEV..../STATS/DATASTREAM/PACKETSRECEIVED

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of packets received on the data stream from the device since session start.

/DEV..../STATS/DATASTREAM/PENDING

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of buffers ready for receiving data packets from the device.

/DEV..../STATS/DATASTREAM/PROCESSING

Properties: Read

Type: Integer (64 bit)

Unit: None

Number of buffers being processed for data packets. Small values indicate proper performance. For a TCP/IP interface, data packets are sent using the UDP protocol.

/DEV..../STATS/PHYSICAL/FANSPEED

Properties: Read

Type: Double

Unit: RPM

Speed of the internal cooling fan.

/DEV..../STATS/PHYSICAL/OVERTEMPERATURE

Properties: Read

Type: Integer (64 bit)

Unit: None

This flag is set to 1 if the temperature of the FPGA exceeds 85°C. It will be reset to 0 after a restart of the device.

/DEV..../STATS/PHYSICAL/FPGA/AUX

Properties: Read

Type: Double

Unit: V

Supply voltage of the FPGA.

/DEV..../STATS/PHYSICAL/FPGA/CORE

Properties: Read

Type: Double

Unit: V

Core voltage of the FPGA.

/DEV..../STATS/PHYSICAL/FPGA/TEMP

Properties: Read

Type: Double
Unit: °C

Internal temperature of the FPGA.

/DEV..../STATS/PHYSICAL/TEMPERATURES/n

Properties: Read
Type: Double
Unit: °C

Internal temperature measurements.

/DEV..../STATS/PHYSICAL/VOLTAGES/n

Properties: Read
Type: Double
Unit: V

Internal voltage measurements.

7.2.17. STATUS

/DEV..../STATUS/ADC0MAX

Properties: Read
Type: Integer (64 bit)
Unit: None

The maximum value on Signal Input 1 (ADC0) during 100 ms.

/DEV..../STATUS/ADC0MIN

Properties: Read
Type: Integer (64 bit)
Unit: None

The minimum value on Signal Input 1 (ADC0) during 100 ms

/DEV..../STATUS/ADC1MAX

Properties: Read
Type: Integer (64 bit)
Unit: None

The maximum value on Signal Input 2 (ADC1) during 100 ms.

/DEV..../STATUS/ADC1MIN

Properties: Read

Type: Integer (64 bit)

Unit: None

The minimum value on Signal Input 2 (ADC1) during 100 ms

/DEV..../STATUS/FIFOLEVEL

Properties: Read

Type: Double

Unit: None

USB FIFO level: Indicates the USB FIFO fill level inside the device. When 100%, data is lost

/DEV..../STATUS/TIME

Properties: Read

Type: Integer (64 bit)

Unit: None

The current timestamp.

/DEV..../STATUS/FLAGS/BINARY

Properties: Read

Type: Integer (64 bit)

Unit: None

A set of binary flags giving an indication of the state of various parts of the device. Bit 0: Signal Input 1 overflow, Bit 1: Current Input 1 overflow, Bit 2: Analog PLL fail, Bit 3: Output 1 DAC OK, Bit 4: Output 2 DAC OK, Bit 5: Signal Output 1 clipping, Bit 6: Signal Output 2 clipping, Bit 7: Ext Ref 1 Locked, Bit 8: Ext Ref 2 Locked, Bit 9: Ext Ref 3 Locked, Bit 10: Ext Ref 4 Locked, Bit 11: Sample Loss, Bits 12 - 13: Trigger In 1, Bits 14 - 15: Trigger In 2, Bits 16 - 17: Trigger In 3, Bits 18 - 19: Trigger In 4, Bit 20: PLL 1 locked, Bit 21: PLL 2 locked, Bit 22: PLL 3 locked, Bit 23: PLL 4 locked, Bit 24: Rubidium clock locked, Bit 25: AU Cartesian 1 Overflow, Bit 26: AU Cartesian 2 Overflow, Bit 27: AU Polar 1 Overflow, Bit 28: AU Polar 2 Overflow.

/DEV..../STATUS/FLAGS/PACKETLOSSTCP

Properties: Read

Type: Integer (64 bit)

Unit: None

Flag indicating if tcp packages have been lost.

/DEV..../STATUS/FLAGS/PACKETLOSSUDP

Properties: Read

Type: Integer (64 bit)

Unit: None

Flag indicating if udp packages have been lost.

7.2.18. SYSTEM

/DEV..../SYSTEM/ACTIVEINTERFACE

Properties: Read

Type: String

Unit: None

Currently active interface of the device.

/DEV..../SYSTEM/EXTCLK

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

10 MHz reference clock source.

0 **internal**

Internal 10 MHz clock is used as the frequency and time base reference.

1 **external**

An external 10 MHz clock is used as the frequency and time base reference. Provide a clean and stable 10 MHz reference to the appropriate back panel connector.

/DEV..../SYSTEM/FPGAREVISION

Properties: Read

Type: Integer (64 bit)

Unit: None

HDL firmware revision.

/DEV..../SYSTEM/fwlog

Properties: Read

Type: String

Unit: None

Returns log output of the firmware.

/DEV..../SYSTEM/FWLOGENABLE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Enables logging to the fwlog node.

/DEV..../SYSTEM/FWREVISION

Properties: Read

Type: Integer (64 bit)

Unit: None

Revision of the device-internal controller software.

/DEV..../SYSTEM/IDENTIFY

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Setting this node to 1 will cause the device to blink the power led for a few seconds.

/DEV..../SYSTEM/INTERFACESPEED

Properties: Read

Type: String

Unit: None

Speed of the currently active interface (USB only).

/DEV..../SYSTEM/JUMBO

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Enables jumbo frames (4k) on the TCP/IP interface. This will reduce the load on the PC and is required to achieve maximal throughput. Make sure that jumbo frames (4k) are enabled on the network card as well. If one of the devices on the network is not able to work with jumbo frames, the connection will fail.

/DEV..../SYSTEM/OWNER

Properties: Read

Type: String

Unit: None

Returns the current owner of the device (IP).

/DEV..../SYSTEM/PORTTCP

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Returns the current TCP port used for communication to the dataserver.

/DEV..../SYSTEM/PORTUDP

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Returns the current UDP port used for communication to the dataserver.

/DEV..../SYSTEM/PREAMPENABLE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Enables the preamplifier.

/DEV..../SYSTEM/SAVEPORTS

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Flag indicating that the TCP and UDP ports should be saved.

/DEV..../SYSTEM/SHUTDOWN

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Sending a '1' to this node initiates a shutdown of the operating system on the MFLI device. It is recommended to trigger this shutdown before switching the device off with the hardware switch at the back side of the device.

/DEV..../SYSTEM/STALL

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates if the network connection is stalled.

/DEV..../SYSTEM/BOARDREVISIONS/n

Properties: Read

Type: String

Unit: None

Hardware revision of the FPGA base board

/DEV..../SYSTEM/COMPDELAY/CALIBRATE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Perform automatic calibration of the input delay compensation.

/DEV..../SYSTEM/IMPEDANCE/APPLICATION

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the Impedance application

0 **lcr**

LCR Impedance Measurement: General-purpose settings for measuring components at finite frequency.

1 **dc**

DC Impedance Measurement: Settings for measuring resistance at zero frequency.

/DEV..../SYSTEM/IMPEDANCE/FILTER

Properties: Read, Write, Setting

Type: Integer (enumerated)
Unit: None

Switch between application-based or manually configured impedance settings. A parameter set given by an Application mode can be fine-tuned by changing to Advanced mode. Changing back to Application mode will reset the parameters.

- 0 **application**
Application: The impedance settings are adjusted to fit best the selected application.
- 1 **advanced**
Advanced: The impedance settings are manually configured.

/DEV..../SYSTEM/IMPEDANCE/PRECISION

Properties: Read, Write, Setting
Type: Integer (enumerated)
Unit: None

Select the Impedance precision and measurement speed by automatically adjusting the filter bandwidth. If the sweeper module is in impedance application mode the precision setting will also control the sweeper measurement speed.

- 0 **low**
Low → fast settling: Medium accuracy/precision is optimized for fast response.
- 1 **high**
High → medium settling: High accuracy/precision takes more settling time.
- 2 **very_high**
Very high → slow settling: Very high accuracy/precision uses long settling time due to very low bandwidth.

/DEV..../SYSTEM/PRESET/BUSY

Properties: Read
Type: Integer (64 bit)
Unit: None

Indicates if presets are currently loaded.

/DEV..../SYSTEM/PRESET/DEFAULT

Properties: Read, Write
Type: Integer (enumerated)
Unit: None

Indicates the preset which is used as default preset at start-up of the device.

- 0 **factory**

- Select factory preset as default preset.
- 1 Select the preset stored in internal flash memory at position 1 as default preset.
 - 2 Select the preset stored in internal flash memory at position 2 as default preset.
 - 3 Select the preset stored in internal flash memory at position 3 as default preset.
 - 4 Select the preset stored in internal flash memory at position 4 as default preset.
 - 5 Select the preset stored in internal flash memory at position 5 as default preset.
 - 6 Select the preset stored in internal flash memory at position 6 as default preset.

/DEV..../SYSTEM/PRESET/ERASE

Properties: Read, Write
Type: Integer (64 bit)
Unit: None

Erase the selected preset.

/DEV..../SYSTEM/PRESET/ERROR

Properties: Read
Type: Integer (64 bit)
Unit: None

Indicates if the last operation was illegal. Successful: 0, Error: 1.

/DEV..../SYSTEM/PRESET/INDEX

Properties: Read, Write
Type: Integer (enumerated)
Unit: None

Select between factory preset or presets stored in internal flash memory.

- 0 **factory**
Select factory preset.
- 1 Select the preset stored in internal flash memory at position 1.
- 2 Select the preset stored in internal flash memory at position 2.
- 3 Select the preset stored in internal flash memory at position 3.
- 4 Select the preset stored in internal flash memory at position 4.
- 5 Select the preset stored in internal flash memory at position 5.
- 6 Select the preset stored in internal flash memory at position 6.

/DEV..../SYSTEM/PRESET/LOAD

Properties: Read, Write

Type: Integer (64 bit)
Unit: None

Load the selected preset.

/DEV..../SYSTEM/PRESET/SAVE

Properties: Read, Write
Type: Integer (64 bit)
Unit: None

Save the actual setting as preset.

/DEV..../SYSTEM/PROPERTIES/FREQRESOLUTION

Properties: Read
Type: Integer (64 bit)
Unit: None

The number of bits used to represent a frequency.

/DEV..../SYSTEM/PROPERTIES/FREQSCALING

Properties: Read
Type: Double
Unit: None

The scale factor to use to convert a frequency represented as a freqresolution-bit integer to a floating point value.

/DEV..../SYSTEM/PROPERTIES/MAXFREQ

Properties: Read
Type: Double
Unit: None

The maximum oscillator frequency that can be set.

/DEV..../SYSTEM/PROPERTIES/MAXTIMECONSTANT

Properties: Read
Type: Double
Unit: None

The maximum demodulator time constant that can be set.

/DEV..../SYSTEM/PROPERTIES/MINFREQ

Properties: Read
Type: Double
Unit: None

The minimum oscillator frequency that can be set.

/DEV..../SYSTEM/PROPERTIES/MINTIMECONSTANT

Properties: Read
Type: Double
Unit: None

The minimum demodulator time constant that can be set.

/DEV..../SYSTEM/PROPERTIES/NEGATIVEFREQ

Properties: Read
Type: Integer (64 bit)
Unit: None

Indicates whether negative frequencies are supported.

/DEV..../SYSTEM/PROPERTIES/TIMEBASE

Properties: Read
Type: Double
Unit: s

Minimal time difference between two timestamps. The value is equal to 1/(maximum sampling rate).

/DEV..../SYSTEM/COMPDELAY/DELAYS/n

Properties: Read, Write
Type: Integer (64 bit)
Unit: None

Current values of the compensation delays. 0: Signal Input 0, 1: Signal Input 1, 2: Aux Inputs, 3: Trigger Inputs, 4: Loopbacks

/DEV..../SYSTEM/IMPEDANCE/CALIB/CABLELENGTH

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Length of cables (One way) used in measurement set up.

0 off

Off: cable length compensation is turned off.

1 1_m

Cable length is set to 1 m.

2 2_m

Cable length is set to 2 m.

3 3_m

Cable length is set to 3 m.

/DEV..../SYSTEM/NICS/n/DEFAULTGATEWAY

Properties: Read, Write

Type: String

Unit: None

Default gateway configuration for the network connection.

/DEV..../SYSTEM/NICS/n/DEFAULTIP4

Properties: Read, Write

Type: String

Unit: None

IPv4 address of the device to use if static IP is enabled.

/DEV..../SYSTEM/NICS/n/DEFAULTMASK

Properties: Read, Write

Type: String

Unit: None

IPv4 mask in case of static IP.

/DEV..../SYSTEM/NICS/n/GATEWAY

Properties: Read

Type: String

Unit: None

Current network gateway.

/DEV..../SYSTEM/NICS/n/IP4

Properties: Read

Type: String

Unit: None

Current IPv4 of the device.

/DEV..../SYSTEM/NICS/n/JUMBO

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Stored setting for jumbo frames. Will be applied after reboot.

/DEV..../SYSTEM/NICS/n/MAC

Properties: Read

Type: String

Unit: None

Current MAC address of the device network interface.

/DEV..../SYSTEM/NICS/n/MASK

Properties: Read

Type: String

Unit: None

Current network mask.

/DEV..../SYSTEM/NICS/n/SAVEIP

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

If written, this action will program the defined static IP address to the device.

/DEV..../SYSTEM/NICS/n/STATIC

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Enable this flag if the device is used in a network with fixed IP assignment without a DHCP server.

/DEV..../SYSTEM/UPDATE/LABONE/BUSY

Properties: Read

Type: Integer (64 bit)

Unit: None

Device is updating.

/DEV..../SYSTEM/UPDATE/LABONE/DATA

Properties: Read, Write

Type: ZIVectorData

Unit: None

Node which accepts the Binary file to update the device.

/DEV..../SYSTEM/UPDATE/LABONE/DONE

Properties: Read

Type: Integer (64 bit)

Unit: None

Updating has finished.

/DEV..../SYSTEM/UPDATE/LABONE/ERROR

Properties: Read

Type: Integer (64 bit)

Unit: None

An error occurred during the update.

/DEV..../SYSTEM/UPDATE/LABONE/PROGRESS

Properties: Read

Type: Double

Unit: None

A value between 0 and 1 indicating the update progress.

/DEV..../SYSTEM/UPDATE/LABONE/START

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

If set to 1 the device starts the update.

/DEV...

./SYSTEM/IMPEDANCE/CALIB/INTERNAL/ALLOWSMOOTHING

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates whether smoothing can be applied to the device internal compensation data.

/DEV..../SYSTEM/IMPEDANCE/CALIB/INTERNAL/DATA

Properties: Read, Write

Type: ZIVectorData

Unit: None

Contains the user compensation data in binary form.

/DEV..../SYSTEM/IMPEDANCE/CALIB/INTERNAL/INFO

Properties: Read

Type: String

Unit: None

Contains general information about the device internal compensation data.

/DEV..../SYSTEM/IMPEDANCE/CALIB/INTERNAL/STORE

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Store the compensation data persistently on the device. The compensation will be loaded automatically on every power-up.

/DEV..../SYSTEM/IMPEDANCE/CALIB/INTERNAL/VALID

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates whether the device internal calibration data is valid (1 = valid, 0 = invalid).

/DEV..../SYSTEM/IMPEDANCE/CALIB/USER/ALLOWSMOOTHING

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates whether smoothing can be applied to the user calibration data.

/DEV..../SYSTEM/IMPEDANCE/CALIB/USER/DATA

Properties: Read, Write

Type: ZIVectorData

Unit: None

Contains the user compensation data in binary form.

/DEV..../SYSTEM/IMPEDANCE/CALIB/USER/INFO

Properties: Read

Type: String

Unit: None

Contains general information about the user compensation data.

/DEV..../SYSTEM/IMPEDANCE/CALIB/USER/VALID

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Indicates whether the user compensation data is valid (1 = valid, 0 = invalid).

/DEV..../SYSTEM/IMPEDANCE/FREQLIMIT2T/n/FREQ

Properties: Read

Type: Double

Unit: None

Indicates the limit of a frequency range for 2-terminal impedance measurements.

/DEV..../SYSTEM/IMPEDANCE/FREQLIMIT2T/n/RANGE

Properties: Read

Type: Double

Unit: None

Indicates the minimum input current range that can be used at frequencies at or above the value in the corresponding freq node for 2-terminal impedance measurements.

/DEV..../SYSTEM/IMPEDANCE/FREQLIMIT4T/n/FREQ

Properties: Read

Type: Double

Unit: None

Indicates the limit of a frequency range for 4-terminal impedance measurements.

/DEV..../SYSTEM/IMPEDANCE/FREQLIMIT4T/n/RANGE

Properties: Read

Type: Double

Unit: None

Indicates the minimum input current range that can be used at frequencies at or above the value in the corresponding freq node for 4-terminal impedance measurements.

/DEV..../SYSTEM/PRESET/RECORDS/n/FEATURES

Properties: Read

Type: Integer (64 bit)

Unit: None

Properties of the preset.

/DEV..../SYSTEM/PRESET/RECORDS/n/LABEL

Properties: Read, Write

Type: String

Unit: None

Name of this preset.

/DEV..../SYSTEM/PRESET/RECORDS/n/TIMESTAMP

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Not used.

/DEV..../SYSTEM/PRESET/RECORDS/n/VALID

Properties: Read

Type: Integer (64 bit)

Unit: None

True if a valid preset is stored.

7.2.19. TRIGGERS

/DEV..../TRIGGERS/IN/n/AUTOTHRESHOLD

Properties: Read, Write

Type: Integer (64 bit)

Unit: None

Automatically adjust the trigger threshold. The level is adjusted to fall in the center of the applied transitions.

/DEV..../TRIGGERS/IN/n/LEVEL

Properties: Read, Write, Setting

Type: Double

Unit: V

Trigger voltage level at which the trigger input toggles between low and high. Use 50% amplitude for digital input and consider the trigger hysteresis.

/DEV..../TRIGGERS/OUT/n/PULSEWIDTH

Properties: Read, Write, Setting

Type: Double

Unit: s

Defines the minimal pulse width for the case of Scope events written to the trigger outputs of the device.

/DEV..../TRIGGERS/OUT/n/SOURCE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the signal assigned to the trigger output.

| | |
|----|---|
| 0 | disabled |
| | The output trigger is disabled. |
| 1 | demod1_phase |
| | Oscillator phase of demod 2 (trigger output channel 1) or demod 4 (trigger output channel 2). |
| 2 | scope_trigger |
| | Scope Trigger. Requires the DIG Option. |
| 3 | scope_not_trigger |
| | Scope /Trigger. Requires the DIG Option. |
| 4 | scope_armed |
| | Scope Armed. Requires the DIG Option. |
| 5 | scope_not_armed |
| | Scope /Armed. Requires the DIG Option. |
| 6 | scope_active |
| | Scope Active. Requires the DIG Option. |
| 7 | scope_not_active |
| | Scope /Active. Requires the DIG Option. |
| 36 | th_logic_unit0_out |
| | Threshold Logic Unit 1 output. |
| 37 | th_logic_unit1_out |
| | Threshold Logic Unit 2 output. |
| 38 | th_logic_unit2_out |
| | Threshold Logic Unit 3 output. |
| 39 | th_logic_unit3_out |
| | Threshold Logic Unit 4 output. |
| 52 | mds_sync_out |
| | MDS Sync Out. |

7.2.20. TU (Threshold Unit)

/DEV..../TU/LOGICUNITS/n/INTERNALVALUE

Properties: Read

Type: Integer (64 bit)

Unit: None

Show the value after logical combination but before output settings. The value integrated over some time. Values are 1: low, 2: high, 3: was low and high in the period.

/DEV..../TU/LOGICUNITS/n/INVERT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Changes the output signal to low-active.

/DEV..../TU/LOGICUNITS/n/KEEP

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Hold the output state indefinitely once it has changed to the activated state.

/DEV..../TU/LOGICUNITS/n/PULSEWIDTH

Properties: Read, Write, Setting

Type: Double

Unit: s

Minimum pulse width for the generated output signal. The width of pulses shorter than this time will be extended.

/DEV..../TU/LOGICUNITS/n(VALUE

Properties: Read

Type: Integer (64 bit)

Unit: None

Shows the output value of the logic unit. The value integrated over some time. Values are 1: low, 2: high, 3: was low and high in the period.

/DEV..../TU/THRESHOLDS/n/ACTIVATIONTIME

Properties: Read, Write, Setting

Type: Double

Unit: s

Minimum duration of threshold violation needed before the output is activated. This can be used as a glitch filter.

/DEV..../TU/THRESHOLDS/n/DEACTIVATIONTIME

Properties: Read, Write, Setting

Type: Double

Unit: s

Minimum duration of threshold compliance needed before the output is deactivated.

/DEV..../TU/THRESHOLDS/n/INPUT

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Select the signal source to be used in the threshold unit.

| | |
|----|--|
| 0 | demod_x Demod X |
| 1 | demod_y Demod Y |
| 2 | demod_r Demod R |
| 3 | demod_theta Demod Theta |
| 5 | pid_out PID Out |
| 6 | boxcar Boxcar |
| 7 | au_cartesian AU Cartesian |
| 8 | au_polar AU Polar |
| 9 | pid_shift PID Shift |
| 10 | pid_error PID Error |
| 50 | dio DIO |
| 51 | trigin,trigger_input Trigger In |
| 52 | trigout,trigger_output Trigger Out |
| 53 | input_overload_v Input Overload (V) |
| 54 | input_overload_i Input Overload (I) |
| 55 | output_overload Output Overload |
| 56 | auxin_overload,auxiliary_input_overload Aux input Overload |
| 57 | auxout_overload,auxiliary_output_overload |

| | |
|----|----------------------------|
| | Aux Output Overload |
| 58 | pid_output_overload |
| | PID Output Overload |
| 59 | tu_output |
| | TU Output Value |

/DEV..../TU/THRESHOLDS/n/INPUTCHANNEL

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Select the channel according to the selected signal source.

/DEV..../TU/THRESHOLDS/n/INTERNALVALUE

Properties: Read

Type: Integer (64 bit)

Unit: Dependent

Shows the value after threshold but before minimum time. The value integrated over some time. Values are 1: low, 2: high, 3: was low and high in the period.

/DEV..../TU/THRESHOLDS/n(VALUE

Properties: Read

Type: Integer (64 bit)

Unit: Dependent

Shows the threshold value at the threshold output. The value integrated over some time. Values are 1: low, 2: high, 3: was low and high in the period.

/DEV..../TU/LOGICUNITS/n/INPUTS/n/CHANNEL

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Selects threshold channel to be used as input.

/DEV..../TU/LOGICUNITS/n/INPUTS/n/NOT

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Inverts the input signal.

/DEV..../TU/LOGICUNITS/n/OPS/n(VALUE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Logical operation applied to the signals to the left and right of the control.

0 **off**

No logical operation selected. No additional signals will be used to generate the output.

1 **and**

Use a logical AND operation.

2 **or**

Use a logical OR operation.

3 **xor**

Use a logical XOR operation.

/DEV..../TU/THRESHOLDS/n/FILTER/ABS

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Takes the absolute value of an analog input signal.

/DEV..../TU/THRESHOLDS/n/FILTER/ENABLE

Properties: Read

Type: Integer (64 bit)

Unit: None

Enables the low-pass filter applied to the analog input signal

/DEV..../TU/THRESHOLDS/n/FILTER/FILTEREDVALUE

Properties: Read

Type: Double

Unit: Dependent

Shows the value after the low-pass filter.

/DEV..../TU/THRESHOLDS/n/FILTER/MODE

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Selects the analysis mode defining the output signal.

0 **above_upper**

Enable if the Signal is above Upper Threshold.

1 **below_lower**

Enable if the Signal is below Lower Threshold.

2 **outside_range**

Enable if the Signal is outside the range [Lower Threshold, Upper Threshold].

3 **crossing_both_rising**

Enable if the Signal crosses Upper Threshold from below Lower Threshold. The difference between Upper and Lower Threshold defines the threshold hysteresis.

4 **crossing_both_falling**

Enable if the Signal crosses Lower Threshold from above Upper Threshold. The difference between Upper and Lower Threshold defines the threshold hysteresis.

/DEV..../TU/THRESHOLDS/n/FILTER/THRESHOLDHIGH

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Upper threshold used to generate the output. In Falling Edge mode, this parameter defines the hysteretic behavior as the output state is reset only when the signal crosses Upper Threshold from below.

/DEV..../TU/THRESHOLDS/n/FILTER/THRESHOLDLOW

Properties: Read, Write, Setting

Type: Double

Unit: Dependent

Lower threshold used to generate the output. In Rising Edge mode, this parameter defines the hysteretic behavior as the output state is reset only when the signal crosses Lower Threshold from above.

/DEV..../TU/THRESHOLDS/n/FILTER/TIMECONSTANT

Properties: Read, Write, Setting

Type: Double

Unit: s

Defines the characteristic time constant (cut off) of the low-pass filter applied to the analog input signal.

7.2.21. ZI (LabOne Data Server Nodes)

/ZI/ABOUT/COMMIT

Properties: Read

Type: String

Unit: None

Contains the commit hash of the source code used to build this version of the LabOne software.

/ZI/ABOUT/COPYRIGHT

Properties: Read

Type: String

Unit: None

Holds the copyright notice.

/ZI/ABOUT/DATASERVER

Properties: Read

Type: String

Unit: None

Contains information about the Zurich Instruments Data Server.

/ZI/ABOUT/fwrevision

Properties: Read

Type: Integer (64 bit)

Unit: None

Contains the revision of the device firmware.

/ZI/ABOUT/revision

Properties: Read

Type: Integer (64 bit)

Unit: None

Contains the revision number of the Zurich Instruments Data Server.

/ZI/ABOUT/VERSION

Properties: Read

Type: String

Unit: None

Contains the version of the LabOne software.

/ZI/CLOCKBASE

Properties: Read

Type: Double

Unit: None

A fallback clock frequency that can be used by clients for calculating time bases when no other is available.

/ZI/CONFIG/OPEN

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Enable communication with the LabOne Data Server from other computers in the network.

0 **local**

Communication only possible with the local machine.

1 **network**

Communication possible with other machines in the network.

/ZI/CONFIG/PORT

Properties: Read

Type: Integer (64 bit)

Unit: None

The IP port on which the LabOne Data Server listens.

/ZI/DEBUG/LEVEL

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Set the logging level (amount of detail) of the LabOne Data Server.

| | |
|---|--|
| 0 | trace |
| | Trace. Messages designated as traces are logged. |
| 1 | debug |
| | Debug. Messages designated as debugging info are logged. |
| 2 | info |
| | Info. Messages designated as informational are logged. |
| 3 | status |
| | Status. Messages designated as status info are logged. |
| 4 | warning |
| | Warning. Messages designated as warnings are logged. |
| 5 | error |
| | Error. Messages designated as errors are logged. |
| 6 | fatal |
| | Fatal. Messages designated as fatal errors are logged. |

/ZI/DEBUG/LOG

Properties: Read

Type: String

Unit: None

Returns the logfile text of the LabOne Data Server.

/ZI/DEBUG/LOGPATH

Properties: Read

Type: String

Unit: None

Returns the path of the log directory.

/ZI/DEVICES/CONNECTED

Properties: Read

Type: String

Unit: None

Contains a list of devices connected to the LabOne Data Server.

/ZI/DEVICES/DISCOVER

Properties: Read, Write

Type: String

Unit: None

Not used.

/ZI/DEVICES/VISIBLE

Properties: Read

Type: String

Unit: None

Contains a list of devices in the network visible to the LabOne Data Server.

/ZI/MDS/GROUPS/n/DEVICES

Properties: Read, Write, Setting

Type: String

Unit: None

Contains a list of devices in this synchronization group.

/ZI/MDS/GROUPS/n/KEEPALIVE

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Set by the MDS module to indicate control over this synchronization group.

/ZI/MDS/GROUPS/n/LOCKED

Properties: Read, Write, Setting

Type: Integer (64 bit)

Unit: None

Indicates whether the device group is locked by a MDS module.

/ZI/MDS/GROUPS/n/STATUS

Properties: Read, Write, Setting

Type: Integer (enumerated)

Unit: None

Indicates the status the synchronization group.

-1 Error. An error occurred in the synchronization process.

0 New

1 Sync
2 Alive

/ZI/SYSTEM/USAGEDATA

Properties: Read

Type: String

Unit: None

Contains a JSON formatted string giving usage information about the LabOne Software (which tabs/modules used, error conditions).

Glossary

This glossary provides easy to understand descriptions for many terms related to measurement instrumentation including the abbreviations used inside this user manual.

A

| | |
|-------------------------------------|--|
| A/D | Analog to Digital. See also ADC . |
| AC | Alternate Current |
| ADC | Analog to Digital Converter |
| AM | Amplitude Modulation |
| Amplitude Modulated AFM (AM-AFM) | AFM mode where the amplitude change between drive and measured signal encodes the topography or the measured AFM variable. See also Atomic Force Microscope . |
| API | Application Programming Interface |
| ASCII | American Standard Code for Information Interchange |
| Atomic Force Microscope (AFM) | Microscope that scans surfaces by means an oscillating mechanical structure (e.g. cantilever, tuning fork) whose oscillating tip gets so close to the surface to enter in interaction because of electrostatic, chemical, magnetic or other forces. With an AFM it is possible to produce images with atomic resolution. See also Amplitude Modulated AFM , Frequency Modulated AFM , Phase Modulated AFM . |
| AVAR | Allen Variance |

B

| | |
|----------------|--|
| Bandwidth (BW) | The signal bandwidth represents the highest frequency components of interest in a signal. For filters the signal bandwidth is the cut-off point, where the transfer function of a system shows 3 dB attenuation versus DC. In this context the bandwidth is a synonym of cut-off frequency $f_{\text{cut-off}}$ or 3dB frequency $f_{-3\text{dB}}$. The concept of bandwidth is used when the dynamic behavior of a signal is important or separation of different signals is required. In the context of a open-loop or closed-loop system, the bandwidth can be used to indicate the fastest speed of the system, or the highest signal update change rate that is possible with the system. Sometimes the term bandwidth is erroneously used as synonym of frequency range. See also Noise Equivalent Power Bandwidth . |
| BNC | Bayonet Neill-Concelman Connector |

C

| | |
|----|---|
| CF | Clock Fail (internal processor clock missing) |
|----|---|

Common Mode Rejection Ratio (CMRR) Specification of a differential amplifier (or other device) indicating the ability of an amplifier to obtain the difference between two inputs while rejecting the components that do not differ from the signal (common mode). A high CMRR is important in applications where the signal of interest is represented by a small voltage fluctuation superimposed on a (possibly large) voltage offset, or when relevant information is contained in the voltage difference between two signals. The simplest mathematical definition of common-mode rejection ratio is: $CMRR = 20 * \log(differential\ gain / common\ mode\ gain)$.

CSV Comma Separated Values

D

| | |
|----------------------|---|
| D/A | Digital to Analog |
| DAC | Digital to Analog Converter |
| DC | Direct Current |
| DDS | Direct Digital Synthesis |
| DHCP | Dynamic Host Configuration Protocol |
| DIO | Digital Input/Output |
| DNS | Domain Name Server |
| DSP | Digital Signal Processor |
| DUT | Device Under Test |
| Dynamic Reserve (DR) | The measure of a lock-in amplifier's capability to withstand the disturbing signals and noise at non-reference frequencies, while maintaining the specified measurement accuracy within the signal bandwidth. |

E

XML Extensible Markup Language.
See also [XML](#).

F

| | |
|----------------------------------|--|
| FFT | Fast Fourier Transform |
| FIFO | First In First Out |
| FM | Frequency Modulation |
| Frequency Accuracy (FA) | Measure of an instrument's ability to faithfully indicate the correct frequency versus a traceable standard. |
| Frequency Modulated AFM (FM-AFM) | AFM mode where the frequency change between drive and measured signal encodes the topography or the measured AFM variable. See also Atomic Force Microscope . |
| Frequency Response Analyzer | Instrument capable to stimulate a device under test and plot the frequency response over a selectable frequency range with a fine granularity. |

Frequency Sweeper See also [Frequency Response Analyzer](#).

G

Gain Phase Meter See also [Vector Network Analyzer](#).

GPIB General Purpose Interface Bus

GUI Graphical User Interface

I

I/O Input / Output

Impedance Spectroscope (IS) Instrument suited to stimulate a device under test and to measure the impedance (by means of a current measurement) at a selectable frequency and its amplitude and phase change over time. The output is both amplitude and phase information referred to the stimulus signal.

Input Amplitude Accuracy (IAA) Measure of instrument's capability to faithfully indicate the signal amplitude at the input channel versus a traceable standard.

Input voltage noise Total noise generated by the instrument and referred to the signal input, thus expressed as additional source of noise for the measured signal.

IP Internet Protocol

L

LAN Local Area Network

LED Light Emitting Diode

Lock-in Amplifier (LI, LIA) Instrument suited for the acquisition of small signals in noisy environments, or quickly changing signal with good signal to noise ratio - lock-in amplifiers recover the signal of interest knowing the frequency of the signal by demodulation with the suited reference frequency - the result of the demodulation are amplitude and phase of the signal compared to the reference: these are value pairs in the complex plane (X, Y), (R, Θ).

M

Media Access Control address (MAC address) Refers to the unique identifier assigned to network adapters for physical network communication.

Multi-frequency (MF) Refers to the simultaneous measurement of signals modulated at arbitrary frequencies. The objective of multi-frequency is to increase the information that can be derived from a measurement which is particularly important for one-time, non-repeating events, and to increase the speed of a measurement since different frequencies do not have to be applied one after the other.
See also [Multi-harmonic](#).

Multi-harmonic (MH) Refers to the simultaneous measurement of modulated signals at various harmonic frequencies. The objective of multi-frequency is to increase the information that can be derived from a measurement which is particularly

important for one-time, non-repeating events, and to increase the speed of a measurement since different frequencies do not have to be applied one after the other.

See also [Multi-frequency](#).

N

Noise Equivalent Power Bandwidth (NEPBW)

Effective bandwidth considering the area below the transfer function of a low-pass filter in the frequency spectrum. NEPBW is used when the amount of power within a certain bandwidth is important, such as noise measurements. This unit corresponds to a perfect filter with infinite steepness at the equivalent frequency.

See also [Bandwidth](#).

Nyquist Frequency (NF)

For sampled analog signals, the Nyquist frequency corresponds to two times the highest frequency component that is being correctly represented after the signal conversion.

O

Output Amplitude Accuracy (OAA)

Measure of an instrument's ability to faithfully output a set voltage at a given frequency versus a traceable standard.

OV

Over Volt (signal input saturation and clipping of signal)

P

PC

Personal Computer

PD

Phase Detector

Phase-locked Loop (PLL)

Electronic circuit that serves to track and control a defined frequency. For this purpose a copy of the external signal is generated such that it is in phase with the original signal, but with usually better spectral characteristics. It can act as frequency stabilization, frequency multiplication, or as frequency recovery. In both analog and digital implementations it consists of a phase detector, a loop filter, a controller, and an oscillator.

Phase modulation AFM (PM-AFM)

AFM mode where the phase between drive and measured signal encodes the topography or the measured AFM variable.

See also [Atomic Force Microscope](#).

PID

Proportional-Integral-Derivative

PL

Packet Loss (loss of packets of data between the instruments and the host computer)

R

RISC

Reduced Instruction Set Computer

Root Mean Square (RMS)

Statistical measure of the magnitude of a varying quantity. It is especially useful when variates are positive and negative, e.g., sinusoids, sawtooth, square waves. For a sine wave the following relation holds between the

amplitude and the RMS value: $U_{\text{RMS}} = U_{\text{PK}} / \sqrt{2} = U_{\text{PK}} / 1.41$. The RMS is also called quadratic mean.

| | |
|----|-----------|
| RT | Real-time |
|----|-----------|

S

| | |
|-------------------------------|---|
| Scalar Network Analyzer (SNA) | Instrument that measures the voltage of an analog input signal providing just the amplitude (gain) information. See also Spectrum Analyzer , Vector Network Analyzer . |
| SL | Sample Loss (loss of samples between the instrument and the host computer) |
| Spectrum Analyzer (SA) | Instrument that measures the voltage of an analog input signal providing just the amplitude (gain) information over a defined spectrum. See also Scalar Network Analyzer . |
| SSH | Secure Shell |

T

| | |
|---------------------------------|--|
| TC | Time Constant |
| TCP/IP | Transmission Control Protocol / Internet Protocol |
| Thread | An independent sequence of instructions to be executed by a processor. |
| Total Harmonic Distortion (THD) | Measure of the non-linearity of signal channels (input and output) |
| TTL | Transistor to Transistor Logic level |

U

| | |
|-----|----------------------|
| UHF | Ultra-High Frequency |
| UHS | Ultra-High Stability |
| USB | Universal Serial Bus |

V

| | |
|-------------------------------|---|
| VCO | Voltage Controlled Oscillator |
| Vector Network Analyzer (VNA) | Instrument that measures the network parameters of electrical networks, commonly expressed as s-parameters. For this purpose it measures the voltage of an input signal providing both amplitude (gain) and phase information. For this characteristic an older name was gain phase meter. See also Gain Phase Meter , Scalar Network Analyzer . |

X

| | |
|-----|--|
| XML | Extensible Markup Language: Markup language that defines a set of rules for encoding documents in a format that is both human-readable and machine-readable. |
|-----|--|

Z

| | |
|---------|--|
| ZCtrl | Zurich Instruments Control bus |
| ZoomFFT | This technique performs FFT processing on demodulated samples, for instance after a lock-in amplifier. Since the resolution of an FFT depends on the number of point acquired and the spanned time (not the sample rate), it is possible to obtain very highly resolution spectral analysis. |
| ZSync | Zurich Instruments Synchronization bus |

Index

Symbols

1GbE

Back panel, 60

A

Autosave, 131, 131

Auxiliary Input

Front panel, 59

Auxiliary Output

Front panel, 59

Auxiliary tab, 210

B

Back panel, 60

Bandwidth, 292

C

Calibration, 10

factory, 10

Clock

10 MHz

Back panel, 60

Command-Line, 35

Config tab, 231

Connection

1 Gbit/s Ethernet, 16

USB, 17

Wireless, 25

Coupling

AC, 150, 161

Current Input Signal LED

Front panel, 58

Cursors

Description, 123

Cut-off frequency, 292

D

DAQ tab, 189

Data Server

Node, 303

DC In

Back panel, 60

Demodulator

Block diagram, 150, 161

Demodulator settling time, 203

Device tab, 237

DIO

Back panel, 60

DIO tab, 214

E

Earth

ground

Back panel, 60

External reference

Tutorial, 75

F

File formats, 133

Files tab, 242

Filter, 294

Compensation, 301

Settling time, 294, 294

Sinc, 203, 298

Front panel, 58

Full range sensitivity, 296

H

History, 131, 131

I

Impedance

Input, 150, 161

Impedance Analyzer Tab, 217

Inputs/Outputs tab, 213

Installation

Linux, 33

Windows, 29

L

Linux

Software installation, 33

Lock-in

Principal, 289

Lock-in Tab, 149

With Multi-demodulator (MF-MD) Option, 160

Log files, 52

M

Math sub-tab

Description, 123

MOD tab, 263

Modulation option

Block diagram, 264

Mouse functionality

Description, 121

Multi Device Sync tab, 267

N

NEPBW, 292

Node

Leaf, 303

Listing Nodes, 304

Properties, 304

Server node, 305

Types, 304

Noise

1/f, 290
Numeric tab, 172

O

Ordering guide, 61

P

Package Contents, 10
Performance diagrams, 284
Phase Lock Loop
 PLL
 Tutorial, 100, 111

PID
 Block diagram, 245
PID Advisor
 Tutorial, 105
PID tab, 244

PLL
 Block diagram, 248
Plotter tab, 174
Power inlet
 Back panel, 60
Power LED
 Front panel, 59
Programming
 .NET, 45
 C, 45
 LabVIEW, 44
 MATLAB, 44
 Python, 45

Q

Quadrature, 289

R

Reference signal, 289
RMS value, 290

S

Saving Data, 130
Scope tab, 176
Sensitivity
 Full range sensitivity, 296
Signal Input I
 Front panel, 58
Software Installation
 Command-line, 35
 Linux, 33
 Requirements
 Linux, 33
 Supported versions of Linux, 33
 Windows, 29
Software start-up, 38
Spectrum Analyzer tab, 197
Status bar
 Description, 120

Sweeper
 Tutorial, 80
Sweeper tab, 201

T

Threshold tab, 258
Tool-set
 Description, 118
Tree selector
 Description, 126
Trends
 Description, 128
Trigger In
 Back panel, 60
Trigger Out
 Back panel, 60

U

Update
 Firmware, 49
 LabOne, 46
USB
 Back panel, 60
USB driver
 Linux, 21
 Macintosh, 21
 Windows, 17
User Interface
 Description, 116

V

Vertical axis groups
 Description, 126
Voltage Input Signal LED
 Front panel, 59

W

Windows
 Software installation, 29

Z

ZoomFFT, 301