

entry / DreamMachineOn exit / Unplug return Active ChooseToPlayRadio ChooseToClockSetting ChooseToAlarmSetting Return Return ClockSetting entry / ChooseToClockSetting exit / DreamMachineOff AlarmSetting PlayRadio entry / ChooseToAlarmSetting exit / DreamMachineOff entry / ChooseToPlayRadio exit / DreamMachineOff PressClockThreeSeconds TurnOnFirstTime PressRadioOn ChooseSettingSleepTimer ChooseSettingAlarm SettingClockFirstTime SettingClockAndDate entry / TurnOnFirstTime exit / PressClockThreeSeconds entry / PressClockThreeSeconds exit / DreamMachineOff RadionOn SelectBand SettingSleepTimer SettingAlarm entry / ChooseSettingSleepTimer exit / DreamMachineOff entry / ChooseSettingAlarm exit / DreamMachineOff PressClock BandSelected PressTimeZone SetAlarmMode AdjustVolume TimeSet PressSleep Tunning AlarmMode +/-→ TimeZone PressClock TuneIntoStation RadioOn PressTimeZone(1-7) **>**BuzzerMode RadioMode < AdjustVolume SleepTimer(1-5) DateSet RadioOff/AlarmReset/S AlarmTimeSet AlartTimeSet AlarmMode SleepTimerActive +/-SetAdditionalSleepTimer