

CryptoAuthLib

v3.2.3

7 IP Protection with Symmetric Authentication  8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX)  9 app directory - Purpose  10 Secure boot using ATECC608  11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.2 atca_execute_command  18.1.2.3 atcab_ofg_discover  18.1.2.4 atcab_ogt_addr	License	1
4 HAL Directory - Purpose 5 mbedtls directory - Purpose 6 openssI directory - Purpose 7 IP Protection with Symmetric Authentication 8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX) 9 app directory - Purpose 10 Secure boot using ATECC608 11 TNG Functions 12 CryptoAuthLib - Microchip CryptoAuthentication Library 13 Deprecated List 14 Todo List 15 Module Index 15.1 Modules 16.1 Data Structure Index 16.1 Data Structures 17.1 File List 18 Module Documentation 18.1 Basic Crypto API methods (atcab_) 18.1.1 Detailed Description 18.1.2 Atca AES_GCM_IV_STD_LENGTH 18.1.2.2 atca _execute_command 18.1.2.3 atcab_clg_discover 18.1.2.4 atcab_get_addr	calib directory - Purpose	3
5 mbedtls directory - Purpose 6 opensal directory - Purpose 7 IP Protection with Symmetric Authentication 8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX) 9 app directory - Purpose 10 Secure boot using ATECC608 11 TNG Functions 12 CryptoAuthLib - Microchip CryptoAuthentication Library 13 Deprecated List 14 Todo List 15 Module Index 15.1 Modules 16.1 Data Structure Index 16.1 Data Structures 17 File Index 17.1 File List 18 Module Documentation 18.1 Basic Crypto API methods (atcab_) 18.1.1 Detailed Description 18.1.2 Macro Definition Documentation 18.1.2 Macro Definition Documentation 18.1.2.2 atca_execute_command 18.1.2.3 atcab_cfg_discover 18.1.2.4 atcab_get_addr	crypto directory - Purpose	5
6 opensal directory - Purpose 7 IP Protection with Symmetric Authentication 8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX) 9 app directory - Purpose 10 Secure boot using ATECC608 11 TNG Functions 12 CryptoAuthLib - Microchip CryptoAuthentication Library 13 Deprecated List 14 Todo List 15 Module Index 15.1 Modules 16 Data Structure Index 16.1 Data Structures 17 File Index 17.1 File List 18 Module Documentation 18.1 Basic Crypto API methods (atcab_) 18.1.1 Detailed Description 18.1.2 Macro Definition Documentation 18.1.2.2 atca_execute_command 18.1.2.3 atcab_cfg_discover 18.1.2.4 atcab_get_addr	HAL Directory - Purpose	7
7 IP Protection with Symmetric Authentication  8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX)  9 app directory - Purpose  10 Secure boot using ATECC608  11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16.1 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.2 atca_execute_command  18.1.2.3 atcab_ofg_discover  18.1.2.4 atcab_get_addr	mbedtls directory - Purpose	9
8 Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX)  9 app directory - Purpose  10 Secure boot using ATECC608  11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16.1 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr	openssI directory - Purpose	11
9 app directory - Purpose  10 Secure boot using ATECC608  11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.3 atcab_ctg_discover  18.1.2.4 atcab_get_addr	IP Protection with Symmetric Authentication	13
10 Secure boot using ATECC608  11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr	Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX)	15
11 TNG Functions  12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_ofg_discover  18.1.2.4 atcab_get_addr	app directory - Purpose	21
12 CryptoAuthLib - Microchip CryptoAuthentication Library  13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr	0 Secure boot using ATECC608	23
13 Deprecated List  14 Todo List  15 Module Index  15.1 Modules  16 Data Structure Index  16.1 Data Structures  17 File Index  17.1 File List  18 Module Documentation  18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr	1 TNG Functions	25
14 Todo List       :         15 Module Index       :         15.1 Modules       :         16 Data Structure Index       :         16.1 Data Structures       :         17 File Index       :         17.1 File List       :         18 Module Documentation       !         18.1 Basic Crypto API methods (atcab_)       !         18.1.1 Detailed Description       !         18.1.2 Macro Definition Documentation       !         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       !         18.1.2.2 atca_execute_command       !         18.1.2.3 atcab_cfg_discover       !         18.1.2.4 atcab_get_addr       !	2 CryptoAuthLib - Microchip CryptoAuthentication Library	27
15 Module Index 15.1 Modules  16 Data Structure Index 16.1 Data Structures  17 File Index 17.1 File List  18 Module Documentation 18.1 Basic Crypto API methods (atcab_) 18.1.1 Detailed Description 18.1.2 Macro Definition Documentation 18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH 18.1.2.2 atca_execute_command 18.1.2.3 atcab_cfg_discover 18.1.2.4 atcab_get_addr	3 Deprecated List	33
15.1 Modules       (2)         16 Data Structure Index       (3)         16.1 Data Structures       (2)         17 File Index       (4)         17.1 File List       (4)         18 Module Documentation       (5)         18.1 Basic Crypto API methods (atcab_)       (6)         18.1.1 Detailed Description       (6)         18.1.2 Macro Definition Documentation       (6)         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       (6)         18.1.2.2 atca_execute_command       (6)         18.1.2.3 atcab_cfg_discover       (7)         18.1.2.4 atcab_get_addr       (8)	4 Todo List	35
16 Data Structure Index       16.1 Data Structures         17 File Index       4         17.1 File List       4         18 Module Documentation       8         18.1 Basic Crypto API methods (atcab_)       8         18.1.1 Detailed Description       8         18.1.2 Macro Definition Documentation       8         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       8         18.1.2.2 atca_execute_command       8         18.1.2.3 atcab_cfg_discover       8         18.1.2.4 atcab_get_addr       8		37
16.1 Data Structures       3         17 File Index       4         17.1 File List       4         18 Module Documentation       8         18.1 Basic Crypto API methods (atcab_)       8         18.1.1 Detailed Description       8         18.1.2 Macro Definition Documentation       8         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       8         18.1.2.2 atca_execute_command       8         18.1.2.3 atcab_cfg_discover       8         18.1.2.4 atcab_get_addr       8		37
17 File Index       4         17.1 File List       4         18 Module Documentation       9         18.1 Basic Crypto API methods (atcab_)       1         18.1.1 Detailed Description       9         18.1.2 Macro Definition Documentation       1         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       1         18.1.2.2 atca_execute_command       1         18.1.2.3 atcab_cfg_discover       1         18.1.2.4 atcab_get_addr       6		39
17.1 File List       4         18 Module Documentation       8         18.1 Basic Crypto API methods (atcab_)       8         18.1.1 Detailed Description       18.1.2 Macro Definition Documentation         18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       18.1.2.2 atca_execute_command         18.1.2.2 atca_execute_command       18.1.2.3 atcab_cfg_discover         18.1.2.4 atcab_get_addr       8	16.1 Data Structures	39
18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr		<b>43</b> 43
18.1 Basic Crypto API methods (atcab_)  18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH  18.1.2.2 atca_execute_command  18.1.2.3 atcab_cfg_discover  18.1.2.4 atcab_get_addr	O Madula Desumentation	51
18.1.1 Detailed Description		51 51
18.1.2 Macro Definition Documentation	2 2 2 3 7 1 2 2 2 2 3 4 2 3 2 3 3 3 3 3 3 3 3 3 3 3	59
18.1.2.1 ATCA_AES_GCM_IV_STD_LENGTH       8         18.1.2.2 atca_execute_command       8         18.1.2.3 atcab_cfg_discover       8         18.1.2.4 atcab_get_addr       8		59
18.1.2.2 atca_execute_command       8         18.1.2.3 atcab_cfg_discover       8         18.1.2.4 atcab_get_addr       8		59
18.1.2.3 atcab_cfg_discover		59
18.1.2.4 atcab_get_addr		59
		59
18.1.2.5 SHA CUNTEXT MAX SIZE		59
		59
		60
18.1.4 Function Documentation	18.1.4 Function Documentation	60

i

18.1.4.1 _atcab_exit()
18.1.4.2 atcab_aes()
18.1.4.3 atcab_aes_cbc_decrypt_block()
18.1.4.4 atcab_aes_cbc_encrypt_block() 6
18.1.4.5 atcab_aes_cbc_encrypt_block_ext() 6
18.1.4.6 atcab_aes_cbc_init()
18.1.4.7 atcab_aes_cbc_init_ext()
18.1.4.8 atcab_aes_cmac_finish()
18.1.4.9 atcab_aes_cmac_init()
18.1.4.10 atcab_aes_cmac_init_ext()
18.1.4.11 atcab_aes_cmac_update()
18.1.4.12 atcab_aes_ctr_block()
18.1.4.13 atcab_aes_ctr_decrypt_block()
18.1.4.14 atcab_aes_ctr_encrypt_block()
18.1.4.15 atcab_aes_ctr_increment()
18.1.4.16 atcab_aes_ctr_init()
18.1.4.17 atcab_aes_ctr_init_ext()
18.1.4.18 atcab_aes_ctr_init_rand()
18.1.4.19 atcab_aes_ctr_init_rand_ext()
18.1.4.20 atcab_aes_decrypt()
18.1.4.21 atcab_aes_decrypt_ext()
18.1.4.22 atcab_aes_encrypt()
18.1.4.23 atcab_aes_encrypt_ext()
18.1.4.24 atcab_aes_gcm_aad_update()
18.1.4.25 atcab_aes_gcm_decrypt_finish()
18.1.4.26 atcab_aes_gcm_decrypt_update()
18.1.4.27 atcab_aes_gcm_encrypt_finish()
18.1.4.28 atcab_aes_gcm_encrypt_update()
18.1.4.29 atcab_aes_gcm_init()
18.1.4.30 atcab_aes_gcm_init_rand()
18.1.4.31 atcab_aes_gfm()
18.1.4.32 atcab_challenge()
18.1.4.33 atcab_challenge_seed_update()
18.1.4.34 atcab_checkmac()
18.1.4.35 atcab_cmp_config_zone()
18.1.4.36 atcab_counter()
18.1.4.37 atcab_counter_increment()
18.1.4.38 atcab_counter_read()
18.1.4.39 atcab_derivekey()
18.1.4.40 atcab_ecdh()
18.1.4.41 atcab_ecdh_base()
18.1.4.42 atcab_ecdh_enc()

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3

18.1.4.43 atcab_ecdh_ioenc()	79
18.1.4.44 atcab_ecdh_tempkey()	79
18.1.4.45 atcab_ecdh_tempkey_ioenc()	80
18.1.4.46 atcab_gendig()	80
18.1.4.47 atcab_genkey()	81
18.1.4.48 atcab_genkey_base()	81
18.1.4.49 atcab_get_device()	82
18.1.4.50 atcab_get_device_type()	82
18.1.4.51 atcab_get_device_type_ext()	82
18.1.4.52 atcab_get_pubkey()	82
18.1.4.53 atcab_get_zone_size()	83
18.1.4.54 atcab_hmac()	83
18.1.4.55 atcab_hw_sha2_256()	84
18.1.4.56 atcab_hw_sha2_256_finish()	84
18.1.4.57 atcab_hw_sha2_256_init()	84
18.1.4.58 atcab_hw_sha2_256_update()	85
18.1.4.59 atcab_idle()	85
18.1.4.60 atcab_info()	85
18.1.4.61 atcab_info_base()	86
18.1.4.62 atcab_info_get_latch()	86
18.1.4.63 atcab_info_set_latch()	87
18.1.4.64 atcab_init()	87
18.1.4.65 atcab_init_device()	87
18.1.4.66 atcab_init_ext()	88
18.1.4.67 atcab_is_ca_device()	88
18.1.4.68 atcab_is_config_locked()	88
18.1.4.69 atcab_is_data_locked()	89
18.1.4.70 atcab_is_locked()	89
18.1.4.71 atcab_is_slot_locked()	89
18.1.4.72 atcab_is_ta_device()	90
18.1.4.73 atcab_kdf()	90
18.1.4.74 atcab_lock()	91
18.1.4.75 atcab_lock_config_zone()	91
18.1.4.76 atcab_lock_config_zone_crc()	91
18.1.4.77 atcab_lock_data_slot()	92
18.1.4.78 atcab_lock_data_zone()	92
18.1.4.79 atcab_lock_data_zone_crc()	92
18.1.4.80 atcab_mac()	93
18.1.4.81 atcab_nonce()	93
18.1.4.82 atcab_nonce_base()	94
18.1.4.83 atcab_nonce_load()	94
18.1.4.84 atcab_nonce_rand()	95

18.1.4.85 atcab_printbin()
18.1.4.86 atcab_priv_write()
18.1.4.87 atcab_random()
18.1.4.88 atcab_random_ext()
18.1.4.89 atcab_read_bytes_zone()
18.1.4.90 atcab_read_config_zone()
18.1.4.91 atcab_read_enc()
18.1.4.92 atcab_read_pubkey()
18.1.4.93 atcab_read_serial_number()
18.1.4.94 atcab_read_sig()
18.1.4.95 atcab_read_zone()
18.1.4.96 atcab_release()
18.1.4.97 atcab_release_ext()
18.1.4.98 atcab_secureboot()
18.1.4.99 atcab_secureboot_mac()
18.1.4.100 atcab_selftest()
18.1.4.101 atcab_sha()
18.1.4.102 atcab_sha_base()
18.1.4.103 atcab_sha_end()
18.1.4.104 atcab_sha_hmac()
18.1.4.105 atcab_sha_hmac_finish()
18.1.4.106 atcab_sha_hmac_init()
18.1.4.107 atcab_sha_hmac_update()
18.1.4.108 atcab_sha_read_context()
18.1.4.109 atcab_sha_start()
18.1.4.110 atcab_sha_update()
18.1.4.111 atcab_sha_write_context()
18.1.4.112 atcab_sign()
18.1.4.113 atcab_sign_base()
18.1.4.114 atcab_sign_internal()
18.1.4.115 atcab_sleep()
18.1.4.116 atcab_updateextra()
18.1.4.117 atcab_verify()
18.1.4.118 atcab_verify_extern()
18.1.4.119 atcab_verify_extern_mac()
18.1.4.120 atcab_verify_invalidate()
18.1.4.121 atcab_verify_stored()
18.1.4.122 atcab_verify_stored_mac()
18.1.4.123 atcab_verify_validate()
18.1.4.124 atcab_version()
18.1.4.125 atcab_wakeup()
18.1.4.126 atcab_write()

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

iν

18.1.4.127 atcab_write_bytes_zone()	113
18.1.4.128 atcab_write_config_counter()	114
18.1.4.129 atcab_write_config_zone()	114
18.1.4.130 atcab_write_enc()	115
18.1.4.131 atcab_write_pubkey()	115
18.1.4.132 atcab_write_zone()	116
18.1.4.133 calib_aes_gcm_aad_update()	116
18.1.4.134 calib_aes_gcm_decrypt_finish()	117
18.1.4.135 calib_aes_gcm_decrypt_update()	117
18.1.4.136 calib_aes_gcm_encrypt_finish()	118
18.1.4.137 calib_aes_gcm_encrypt_update()	118
18.1.4.138 calib_aes_gcm_init()	119
18.1.4.139 calib_aes_gcm_init_rand()	119
18.1.5 Variable Documentation	120
18.1.5.1 _gDevice	120
18.1.5.2 atca_basic_aes_gcm_version	120
18.2 Configuration (cfg_)	121
18.3 ATCACommand (atca_)	122
18.3.1 Detailed Description	122
18.3.2 Typedef Documentation	122
18.3.2.1 ATCACommand	122
18.3.3 Function Documentation	122
18.3.3.1 deleteATCACommand()	122
18.3.3.2 initATCACommand()	123
18.3.3.3 newATCACommand()	123
18.4 ATCADevice (atca_)	124
18.4.1 Detailed Description	127
18.4.2 Macro Definition Documentation	127
18.4.2.1 ATCA_AES_ENABLE_EN_MASK	127
18.4.2.2 ATCA_AES_ENABLE_EN_SHIFT	127
18.4.2.3 ATCA_CHIP_MODE_CLK_DIV	127
18.4.2.4 ATCA_CHIP_MODE_CLK_DIV_MASK	127
18.4.2.5 ATCA_CHIP_MODE_CLK_DIV_SHIFT	127
18.4.2.6 ATCA_CHIP_MODE_I2C_EXTRA_MASK	127
18.4.2.7 ATCA_CHIP_MODE_I2C_EXTRA_SHIFT	128
18.4.2.8 ATCA_CHIP_MODE_TTL_EN_MASK	128
18.4.2.9 ATCA_CHIP_MODE_TTL_EN_SHIFT	128
18.4.2.10 ATCA_CHIP_MODE_WDG_LONG_MASK	128
18.4.2.11 ATCA_CHIP_MODE_WDG_LONG_SHIFT	128
18.4.2.12 ATCA_CHIP_OPT_ECDH_PROT	128
18.4.2.13 ATCA_CHIP_OPT_ECDH_PROT_MASK	128
18.4.2.14 ATCA_CHIP_OPT_ECDH_PROT_SHIFT	129

 $@\ 2020\ {\rm Microchip\ Technology\ Inc}$ 

18.4.2.15 ALCA_CHIP_OPT_IO_PROT_EN_MASK
18.4.2.16 ATCA_CHIP_OPT_IO_PROT_EN_SHIFT
18.4.2.17 ATCA_CHIP_OPT_IO_PROT_KEY
18.4.2.18 ATCA_CHIP_OPT_IO_PROT_KEY_MASK
18.4.2.19 ATCA_CHIP_OPT_IO_PROT_KEY_SHIFT
18.4.2.20 ATCA_CHIP_OPT_KDF_AES_EN_MASK
18.4.2.21 ATCA_CHIP_OPT_KDF_AES_EN_SHIFT
18.4.2.22 ATCA_CHIP_OPT_KDF_PROT
18.4.2.23 ATCA_CHIP_OPT_KDF_PROT_MASK
18.4.2.24 ATCA_CHIP_OPT_KDF_PROT_SHIFT
18.4.2.25 ATCA_CHIP_OPT_POST_EN_MASK
18.4.2.26 ATCA_CHIP_OPT_POST_EN_SHIFT
18.4.2.27 ATCA_COUNTER_MATCH_EN_MASK
18.4.2.28 ATCA_COUNTER_MATCH_EN_SHIFT
18.4.2.29 ATCA_COUNTER_MATCH_KEY
18.4.2.30 ATCA_COUNTER_MATCH_KEY_MASK
18.4.2.31 ATCA_COUNTER_MATCH_KEY_SHIFT
18.4.2.32 ATCA_I2C_ENABLE_EN_MASK
18.4.2.33 ATCA_I2C_ENABLE_EN_SHIFT
18.4.2.34 ATCA_KEY_CONFIG_AUTH_KEY
18.4.2.35 ATCA_KEY_CONFIG_AUTH_KEY_MASK
18.4.2.36 ATCA_KEY_CONFIG_AUTH_KEY_SHIFT
18.4.2.37 ATCA_KEY_CONFIG_KEY_TYPE
18.4.2.38 ATCA_KEY_CONFIG_KEY_TYPE_MASK
18.4.2.39 ATCA_KEY_CONFIG_KEY_TYPE_SHIFT
18.4.2.40 ATCA_KEY_CONFIG_LOCKABLE_MASK
18.4.2.41 ATCA_KEY_CONFIG_LOCKABLE_SHIFT
18.4.2.42 ATCA_KEY_CONFIG_PERSIST_DISABLE_MASK
18.4.2.43 ATCA_KEY_CONFIG_PERSIST_DISABLE_SHIFT
18.4.2.44 ATCA_KEY_CONFIG_PRIVATE_MASK
18.4.2.45 ATCA_KEY_CONFIG_PRIVATE_SHIFT
18.4.2.46 ATCA_KEY_CONFIG_PUB_INFO_MASK
18.4.2.47 ATCA_KEY_CONFIG_PUB_INFO_SHIFT
18.4.2.48 ATCA_KEY_CONFIG_REQ_AUTH_MASK
18.4.2.49 ATCA_KEY_CONFIG_REQ_AUTH_SHIFT
18.4.2.50 ATCA_KEY_CONFIG_REQ_RANDOM_MASK
18.4.2.51 ATCA_KEY_CONFIG_REQ_RANDOM_SHIFT
18.4.2.52 ATCA_KEY_CONFIG_RFU_MASK
18.4.2.53 ATCA_KEY_CONFIG_RFU_SHIFT
18.4.2.54 ATCA_KEY_CONFIG_X509_ID
18.4.2.55 ATCA_KEY_CONFIG_X509_ID_MASK
18.4.2.56 ATCA_KEY_CONFIG_X509_ID_SHIFT

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Vİ

18.4.2.57 ATCA_PACKED
18.4.2.58 ATCA_SECURE_BOOT_DIGEST
18.4.2.59 ATCA_SECURE_BOOT_DIGEST_MASK
18.4.2.60 ATCA_SECURE_BOOT_DIGEST_SHIFT
18.4.2.61 ATCA_SECURE_BOOT_MODE
18.4.2.62 ATCA_SECURE_BOOT_MODE_MASK
18.4.2.63 ATCA_SECURE_BOOT_MODE_SHIFT
18.4.2.64 ATCA_SECURE_BOOT_PERSIST_EN_MASK
18.4.2.65 ATCA_SECURE_BOOT_PERSIST_EN_SHIFT
18.4.2.66 ATCA_SECURE_BOOT_PUB_KEY
18.4.2.67 ATCA_SECURE_BOOT_PUB_KEY_MASK
18.4.2.68 ATCA_SECURE_BOOT_PUB_KEY_SHIFT
18.4.2.69 ATCA_SECURE_BOOT_RAND_NONCE_MASK
18.4.2.70 ATCA_SECURE_BOOT_RAND_NONCE_SHIFT
18.4.2.71 ATCA_SLOT_CONFIG_ECDH_MASK
18.4.2.72 ATCA_SLOT_CONFIG_ECDH_SHIFT
18.4.2.73 ATCA_SLOT_CONFIG_ENCRYPTED_READ_MASK
18.4.2.74 ATCA_SLOT_CONFIG_ENCRYPTED_READ_SHIFT
18.4.2.75 ATCA_SLOT_CONFIG_EXT_SIG_MASK
18.4.2.76 ATCA_SLOT_CONFIG_EXT_SIG_SHIFT
18.4.2.77 ATCA_SLOT_CONFIG_GEN_KEY_MASK
18.4.2.78 ATCA_SLOT_CONFIG_GEN_KEY_SHIFT
18.4.2.79 ATCA_SLOT_CONFIG_INT_SIG_MASK
18.4.2.80 ATCA_SLOT_CONFIG_INT_SIG_SHIFT
18.4.2.81 ATCA_SLOT_CONFIG_IS_SECRET_MASK
18.4.2.82 ATCA_SLOT_CONFIG_IS_SECRET_SHIFT
18.4.2.83 ATCA_SLOT_CONFIG_LIMITED_USE_MASK
18.4.2.84 ATCA_SLOT_CONFIG_LIMITED_USE_SHIFT
18.4.2.85 ATCA_SLOT_CONFIG_NOMAC_MASK
18.4.2.86 ATCA_SLOT_CONFIG_NOMAC_SHIFT
18.4.2.87 ATCA_SLOT_CONFIG_PRIV_WRITE_MASK
18.4.2.88 ATCA_SLOT_CONFIG_PRIV_WRITE_SHIFT
18.4.2.89 ATCA_SLOT_CONFIG_READKEY
18.4.2.90 ATCA_SLOT_CONFIG_READKEY_MASK
18.4.2.91 ATCA_SLOT_CONFIG_READKEY_SHIFT
18.4.2.92 ATCA_SLOT_CONFIG_WRITE_CONFIG
18.4.2.93 ATCA_SLOT_CONFIG_WRITE_CONFIG_MASK
18.4.2.94 ATCA_SLOT_CONFIG_WRITE_CONFIG_SHIFT
18.4.2.95 ATCA_SLOT_CONFIG_WRITE_ECDH_MASK
18.4.2.96 ATCA_SLOT_CONFIG_WRITE_ECDH_SHIFT
18.4.2.97 ATCA_SLOT_CONFIG_WRITE_KEY
18.4.2.98 ATCA_SLOT_CONFIG_WRITE_KEY_MASK

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Vİİ

18.4.2.99 ATCA_SLOT_CONFIG_WRITE_KEY_SHIFT	140
18.4.2.100 ATCA_SLOT_LOCKED	140
18.4.2.101 ATCA_USE_LOCK_ENABLE_MASK	141
18.4.2.102 ATCA_USE_LOCK_ENABLE_SHIFT	141
18.4.2.103 ATCA_USE_LOCK_KEY_MASK	141
18.4.2.104 ATCA_USE_LOCK_KEY_SHIFT	141
18.4.2.105 ATCA_VOL_KEY_PERM_EN_MASK	141
18.4.2.106 ATCA_VOL_KEY_PERM_EN_SHIFT	141
18.4.2.107 ATCA_VOL_KEY_PERM_SLOT	141
18.4.2.108 ATCA_VOL_KEY_PERM_SLOT_MASK	142
18.4.2.109 ATCA_VOL_KEY_PERM_SLOT_SHIFT	142
18.4.3 Typedef Documentation	142
18.4.3.1 ATCADevice	142
18.4.3.2 atecc508a_config_t	142
18.4.3.3 atecc608_config_t	142
18.4.3.4 atsha204a_config_t	142
18.4.4 Enumeration Type Documentation	142
18.4.4.1 ATCADeviceType	142
18.4.5 Function Documentation	143
18.4.5.1 atGetCommands()	143
18.4.5.2 atGetIFace()	143
18.4.5.3 deleteATCADevice()	144
18.4.5.4 initATCADevice()	144
18.4.5.5 newATCADevice()	144
18.4.5.6 releaseATCADevice()	145
18.5 ATCAlface (atca_)	146
18.5.1 Detailed Description	147
18.5.2 Typedef Documentation	147
18.5.2.1 ATCAlface	147
18.5.3 Enumeration Type Documentation	147
18.5.3.1 ATCAlfaceType	147
18.5.3.2 ATCAKitType	147
18.5.4 Function Documentation	148
18.5.4.1 atgetifacecfg()	148
18.5.4.2 atgetifacehaldat()	148
18.5.4.3 atidle()	148
18.5.4.4 atinit()	149
18.5.4.5 atpostinit()	149
18.5.4.6 atreceive()	149
18.5.4.7 atsend()	150
18.5.4.8 atsleep()	150
18.5.4.9 atwake()	151

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 VIII

18.5.4.10 deleteATCAlface()	151
18.5.4.11 initATCAlface()	151
18.5.4.12 newATCAlface()	152
18.5.4.13 releaseATCAlface()	152
18.6 Certificate manipulation methods (atcacert_)	153
18.6.1 Detailed Description	158
18.6.2 Macro Definition Documentation	158
18.6.2.1 ATCA_PACKED	158
18.6.2.2 ATCACERT_DATE_FORMAT_SIZES_COUNT	158
18.6.2.3 ATCACERT_E_BAD_CERT	159
18.6.2.4 ATCACERT_E_BAD_PARAMS	159
18.6.2.5 ATCACERT_E_BUFFER_TOO_SMALL	159
18.6.2.6 ATCACERT_E_DECODING_ERROR	159
18.6.2.7 ATCACERT_E_ELEM_MISSING	159
18.6.2.8 ATCACERT_E_ELEM_OUT_OF_BOUNDS	159
18.6.2.9 ATCACERT_E_ERROR	160
18.6.2.10 ATCACERT_E_INVALID_DATE	160
18.6.2.11 ATCACERT_E_INVALID_TRANSFORM	160
18.6.2.12 ATCACERT_E_SUCCESS	160
18.6.2.13 ATCACERT_E_UNEXPECTED_ELEM_SIZE	160
18.6.2.14 ATCACERT_E_UNIMPLEMENTED	160
18.6.2.15 ATCACERT_E_VERIFY_FAILED	161
18.6.2.16 ATCACERT_E_WRONG_CERT_DEF	161
18.6.2.17 DATEFMT_ISO8601_SEP_SIZE	161
18.6.2.18 DATEFMT_MAX_SIZE	161
18.6.2.19 DATEFMT_POSIX_UINT32_BE_SIZE	161
18.6.2.20 DATEFMT_POSIX_UINT32_LE_SIZE	161
18.6.2.21 DATEFMT_RFC5280_GEN_SIZE	161
18.6.2.22 DATEFMT_RFC5280_UTC_SIZE	162
18.6.2.23 FALSE	162
<b>18.6.2.24 TRUE</b>	162
18.6.3 Typedef Documentation	162
18.6.3.1 atcacert_build_state_t	162
18.6.3.2 atcacert_cert_element_t	162
18.6.3.3 atcacert_cert_loc_t	162
18.6.3.4 atcacert_cert_sn_src_t	162
18.6.3.5 atcacert_cert_type_t	163
18.6.3.6 atcacert_date_format_t	163
18.6.3.7 atcacert_def_t	163
18.6.3.8 atcacert_device_loc_t	163
18.6.3.9 atcacert_device_zone_t	163
18.6.3.10 atcacert std cert element t	163

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 İX

18.6.3.11 atcacert_tm_utc_t	3
18.6.3.12 atcacert_transform_t	4
18.6.4 Enumeration Type Documentation	4
18.6.4.1 atcacert_cert_sn_src_e	4
18.6.4.2 atcacert_cert_type_e	5
18.6.4.3 atcacert_date_format_e	5
18.6.4.4 atcacert_device_zone_e	6
18.6.4.5 atcacert_std_cert_element_e	6
18.6.4.6 atcacert_transform_e	6
18.6.5 Function Documentation	8
18.6.5.1 atcacert_cert_build_finish()	8
18.6.5.2 atcacert_cert_build_process()	8
18.6.5.3 atcacert_cert_build_start()	9
18.6.5.4 atcacert_create_csr()	9
18.6.5.5 atcacert_create_csr_pem()	0
18.6.5.6 atcacert_date_dec()	0
18.6.5.7 atcacert_date_dec_compcert()	1
18.6.5.8 atcacert_date_dec_iso8601_sep()	1
18.6.5.9 atcacert_date_dec_posix_uint32_be()	2
18.6.5.10 atcacert_date_dec_posix_uint32_le()	2
18.6.5.11 atcacert_date_dec_rfc5280_gen()	2
18.6.5.12 atcacert_date_dec_rfc5280_utc()	2
18.6.5.13 atcacert_date_enc()	2
18.6.5.14 atcacert_date_enc_compcert()	3
18.6.5.15 atcacert_date_enc_iso8601_sep()	3
18.6.5.16 atcacert_date_enc_posix_uint32_be()	3
18.6.5.17 atcacert_date_enc_posix_uint32_le()	3
18.6.5.18 atcacert_date_enc_rfc5280_gen()	4
18.6.5.19 atcacert_date_enc_rfc5280_utc()	4
18.6.5.20 atcacert_date_get_max_date()	4
18.6.5.21 atcacert_der_adjust_length()	4
18.6.5.22 atcacert_der_dec_ecdsa_sig_value()	5
18.6.5.23 atcacert_der_dec_integer()	5
18.6.5.24 atcacert_der_dec_length()	6
18.6.5.25 atcacert_der_enc_ecdsa_sig_value()	6
18.6.5.26 atcacert_der_enc_integer()	7
18.6.5.27 atcacert_der_enc_length()	7
18.6.5.28 atcacert_gen_cert_sn()	8
18.6.5.29 atcacert_gen_challenge_hw()	8
18.6.5.30 atcacert_gen_challenge_sw()	
18.6.5.31 atcacert_get_auth_key_id()	9
18.6.5.32 atcacert get cert element()	9

 $@\ 2020\ {\rm Microchip\ Technology\ Inc}$ 

18.6.5.33 atcacert_get_cert_sn()	30
18.6.5.34 atcacert_get_comp_cert()	31
18.6.5.35 atcacert_get_device_data()	31
18.6.5.36 atcacert_get_device_locs()	32
18.6.5.37 atcacert_get_expire_date()	32
18.6.5.38 atcacert_get_issue_date()	33
18.6.5.39 atcacert_get_key_id()	33
18.6.5.40 atcacert_get_response()	34
18.6.5.41 atcacert_get_signature()	34
18.6.5.42 atcacert_get_signer_id()	35
18.6.5.43 atcacert_get_subj_key_id()	35
18.6.5.44 atcacert_get_subj_public_key()	36
18.6.5.45 atcacert_get_tbs()	36
18.6.5.46 atcacert_get_tbs_digest()	37
18.6.5.47 atcacert_is_device_loc_overlap()	37
18.6.5.48 atcacert_max_cert_size()	38
18.6.5.49 atcacert_merge_device_loc()	38
18.6.5.50 atcacert_public_key_add_padding()	39
18.6.5.51 atcacert_public_key_remove_padding()	39
18.6.5.52 atcacert_read_cert()	39
18.6.5.53 atcacert_read_cert_size()	)1
18.6.5.54 atcacert_read_device_loc()	)1
18.6.5.55 atcacert_read_subj_key_id()	)2
18.6.5.56 atcacert_set_auth_key_id()	)2
18.6.5.57 atcacert_set_auth_key_id_raw()	3
18.6.5.58 atcacert_set_cert_element()	)3
18.6.5.59 atcacert_set_cert_sn()	)4
18.6.5.60 atcacert_set_comp_cert()	<del>)</del> 4
18.6.5.61 atcacert_set_expire_date()	<del>)</del> 5
18.6.5.62 atcacert_set_issue_date()	<del>)</del> 5
18.6.5.63 atcacert_set_signature()	96
18.6.5.64 atcacert_set_signer_id()	96
18.6.5.65 atcacert_set_subj_public_key()	<del>)</del> 7
18.6.5.66 atcacert_transform_data()	<del>)</del> 7
18.6.5.67 atcacert_verify_cert_hw()	98
18.6.5.68 atcacert_verify_cert_sw()	98
18.6.5.69 atcacert_verify_response_hw()	9
18.6.5.70 atcacert_verify_response_sw()	9
18.6.5.71 atcacert_write_cert()	)0
18.6.6 Variable Documentation	)0
18.6.6.1 ATCACERT_DATE_FORMAT_SIZES	)0
18.7 Basic Crypto API methods for CryptoAuth Devices (calib_)	)1

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 Xİ

18.7.1 Detailed Description
18.7.2 Typedef Documentation
18.7.2.1 atca_hmac_sha256_ctx_t
18.7.2.2 atca_sha256_ctx_t
18.7.3 Function Documentation
18.7.3.1 _calib_exit()
18.7.3.2 calib_aes()
18.7.3.3 calib_aes_decrypt()
18.7.3.4 calib_aes_encrypt()
18.7.3.5 calib_aes_gfm()
18.7.3.6 calib_cfg_discover()
18.7.3.7 calib_challenge()
18.7.3.8 calib_challenge_seed_update()
18.7.3.9 calib_checkmac()
18.7.3.10 calib_cmp_config_zone()
18.7.3.11 calib_counter()
18.7.3.12 calib_counter_increment()
18.7.3.13 calib_counter_read()
18.7.3.14 calib_derivekey()
18.7.3.15 calib_ecdh()
18.7.3.16 calib_ecdh_base()
18.7.3.17 calib_ecdh_enc()
18.7.3.18 calib_ecdh_ioenc()
18.7.3.19 calib_ecdh_tempkey()
18.7.3.20 calib_ecdh_tempkey_ioenc()
18.7.3.21 calib_gendig()
18.7.3.22 calib_genkey()
18.7.3.23 calib_genkey_base()
18.7.3.24 calib_get_addr()
18.7.3.25 calib_get_pubkey()
18.7.3.26 calib_get_zone_size()
18.7.3.27 calib_hmac()
18.7.3.28 calib_hw_sha2_256()
18.7.3.29 calib_hw_sha2_256_finish()
18.7.3.30 calib_hw_sha2_256_init()
18.7.3.31 calib_hw_sha2_256_update()
18.7.3.32 calib_idle()
18.7.3.33 calib_info()
18.7.3.34 calib_info_base()
18.7.3.35 calib_info_get_latch()
18.7.3.36 calib_info_set_latch()
18 7 3 37 calib is locked()

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Xİİ

18.7.3.38 calib_is_slot_locked()	223
18.7.3.39 calib_kdf()	224
18.7.3.40 calib_lock()	224
18.7.3.41 calib_lock_config_zone()	225
18.7.3.42 calib_lock_config_zone_crc()	225
18.7.3.43 calib_lock_data_slot()	225
18.7.3.44 calib_lock_data_zone()	226
18.7.3.45 calib_lock_data_zone_crc()	226
18.7.3.46 calib_mac()	227
18.7.3.47 calib_nonce()	227
18.7.3.48 calib_nonce_base()	228
18.7.3.49 calib_nonce_load()	228
18.7.3.50 calib_nonce_rand()	229
18.7.3.51 calib_priv_write()	229
18.7.3.52 calib_random()	229
18.7.3.53 calib_read_bytes_zone()	230
18.7.3.54 calib_read_config_zone()	230
18.7.3.55 calib_read_enc()	231
18.7.3.56 calib_read_pubkey()	231
18.7.3.57 calib_read_serial_number()	232
18.7.3.58 calib_read_sig()	232
18.7.3.59 calib_read_zone()	232
18.7.3.60 calib_secureboot()	233
18.7.3.61 calib_secureboot_mac()	234
18.7.3.62 calib_selftest()	234
18.7.3.63 calib_sha()	235
18.7.3.64 calib_sha_base()	235
18.7.3.65 calib_sha_end()	236
18.7.3.66 calib_sha_hmac()	236
18.7.3.67 calib_sha_hmac_finish()	237
18.7.3.68 calib_sha_hmac_init()	237
18.7.3.69 calib_sha_hmac_update()	238
18.7.3.70 calib_sha_read_context()	238
18.7.3.71 calib_sha_start()	239
18.7.3.72 calib_sha_update()	239
18.7.3.73 calib_sha_write_context()	239
18.7.3.74 calib_sign()	240
18.7.3.75 calib_sign_base()	240
18.7.3.76 calib_sign_internal()	241
18.7.3.77 calib_sleep()	241
18.7.3.78 calib_updateextra()	242
18.7.3.79 calib_verify()	242

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XIII

18.7.3.80 calib_verify_extern()	243
18.7.3.81 calib_verify_extern_mac()	244
18.7.3.82 calib_verify_invalidate()	244
18.7.3.83 calib_verify_stored()	245
18.7.3.84 calib_verify_stored_mac()	245
18.7.3.85 calib_verify_validate()	246
18.7.3.86 calib_wakeup()	246
18.7.3.87 calib_write()	247
18.7.3.88 calib_write_bytes_zone()	247
18.7.3.89 calib_write_config_counter()	248
18.7.3.90 calib_write_config_zone()	248
18.7.3.91 calib_write_enc()	249
18.7.3.92 calib_write_pubkey()	249
18.7.3.93 calib_write_zone()	249
18.7.4 Variable Documentation	250
18.7.4.1 atca_basic_aes_gcm_version	250
18.8 Software crypto methods (atcac_)	251
18.8.1 Detailed Description	251
18.8.2 Macro Definition Documentation	251
18.8.2.1 ATCA_ECC_P256_FIELD_SIZE	252
18.8.2.2 ATCA_ECC_P256_PRIVATE_KEY_SIZE	252
18.8.2.3 ATCA_ECC_P256_PUBLIC_KEY_SIZE	252
18.8.2.4 ATCA_ECC_P256_SIGNATURE_SIZE	252
18.8.3 Function Documentation	252
18.8.3.1 atcac_sha256_hmac_finish()	252
18.8.3.2 atcac_sha256_hmac_init()	253
18.8.3.3 atcac_sha256_hmac_update()	253
18.8.3.4 atcac_sw_ecdsa_verify_p256()	253
18.8.3.5 atcac_sw_random()	254
18.8.3.6 atcac_sw_sha1()	254
18.8.3.7 atcac_sw_sha1_finish()	254
18.8.3.8 atcac_sw_sha1_init()	254
18.8.3.9 atcac_sw_sha1_update()	255
18.8.3.10 atcac_sw_sha2_256()	255
18.8.3.11 atcac_sw_sha2_256_finish()	255
18.8.3.12 atcac_sw_sha2_256_init()	256
18.8.3.13 atcac_sw_sha2_256_update()	256
18.9 Hardware abstraction layer (hal_)	257
18.9.1 Detailed Description	261
18.9.2 Macro Definition Documentation	262
18.9.2.1 ATCA_POLLING_FREQUENCY_TIME_MSEC	262
18 9 2 2 ATCA POLLING INIT TIME MSEC	262

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XİV

18.9.2.3 ATCA_POLLING_MAX_TIME_MSEC	 . 262
18.9.2.4 DEBUG_PIN_1	 . 262
18.9.2.5 DEBUG_PIN_2	 . 262
18.9.2.6 hal_memset_s	 . 262
18.9.2.7 HID_PACKET_MAX	 . 262
18.9.2.8 KIT_MAX_SCAN_COUNT	 . 263
18.9.2.9 KIT_MAX_TX_BUF	 . 263
18.9.2.10 KIT_MSG_SIZE	 . 263
18.9.2.11 KIT_RX_WRAP_SIZE	 . 263
18.9.2.12 KIT_TX_WRAP_SIZE	 . 263
18.9.2.13 MAX_I2C_BUSES [1/2]	 . 263
<b>18.9.2.14 MAX_I2C_BUSES</b> [2/2]	 . 263
18.9.2.15 MAX_SPI_BUSES	 . 263
<b>18.9.2.16 MAX_SWI_BUSES</b> [1/2]	 . 264
<b>18.9.2.17 MAX_SWI_BUSES</b> [2/2]	 . 264
18.9.2.18 RECEIVE_MODE [1/2]	 . 264
18.9.2.19 RECEIVE_MODE [2/2]	 . 264
18.9.2.20 RX_DELAY [1/2]	 . 264
18.9.2.21 RX_DELAY [2/2]	 . 264
18.9.2.22 SWI_FLAG_CMD	 . 265
18.9.2.23 SWI_FLAG_IDLE	 . 265
18.9.2.24 SWI_FLAG_SLEEP	 . 265
18.9.2.25 SWI_FLAG_TX	 . 265
18.9.2.26 SWI_WAKE_TOKEN	 . 265
18.9.2.27 TRANSMIT_MODE [1/2]	 . 265
<b>18.9.2.28 TRANSMIT_MODE</b> [2/2]	 . 266
18.9.2.29 TX_DELAY [1/2]	 . 266
18.9.2.30 TX_DELAY [2/2]	 . 266
18.9.3 Typedef Documentation	 . 266
18.9.3.1 ATCAI2CMaster_t [1/2]	 . 266
18.9.3.2 ATCAI2CMaster_t [2/2]	 . 266
18.9.3.3 ATCASPIMaster_t	 . 266
18.9.3.4 ATCASWIMaster_t [1/2]	 . 266
18.9.3.5 ATCASWIMaster_t [2/2]	 . 267
18.9.3.6 i2c_sam_instance_t	 . 267
18.9.3.7 i2c_start_instance_t	 . 267
18.9.3.8 sam_change_baudrate	 . 267
18.9.3.9 start_change_baudrate	 . 267
18.9.4 Function Documentation	 . 267
18.9.4.1 atca_delay_10us()	 . 267
18.9.4.2 atca_delay_ms()	 . 268
18.9.4.3 atca_delay_us()	 . 268

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

χV

18.9.4.4 change_i2c_speed()
18.9.4.5 hal_check_wake()
18.9.4.6 hal_create_mutex()
18.9.4.7 hal_delay_10us()
18.9.4.8 hal_delay_ms()
18.9.4.9 hal_delay_us()
18.9.4.10 hal_destroy_mutex()
18.9.4.11 hal_free()
18.9.4.12 hal_i2c_discover_buses()
18.9.4.13 hal_i2c_discover_devices()
18.9.4.14 hal_i2c_idle()
18.9.4.15 hal_i2c_init()
18.9.4.16 hal_i2c_post_init()
18.9.4.17 hal_i2c_receive()
18.9.4.18 hal_i2c_release()
18.9.4.19 hal_i2c_send()
18.9.4.20 hal_i2c_sleep()
18.9.4.21 hal_i2c_wake()
18.9.4.22 hal_iface_init()
18.9.4.23 hal_iface_register_hal()
18.9.4.24 hal_iface_release()
18.9.4.25 hal_kit_hid_discover_buses()
18.9.4.26 hal_kit_hid_discover_devices()
18.9.4.27 hal_kit_hid_idle()
18.9.4.28 hal_kit_hid_init()
18.9.4.29 hal_kit_hid_post_init()
18.9.4.30 hal_kit_hid_receive()
18.9.4.31 hal_kit_hid_release()
18.9.4.32 hal_kit_hid_send()
18.9.4.33 hal_kit_hid_sleep()
18.9.4.34 hal_kit_hid_wake()
18.9.4.35 hal_lock_mutex()
18.9.4.36 hal_malloc()
18.9.4.37 hal_rtos_delay_ms()
18.9.4.38 hal_spi_discover_buses()
18.9.4.39 hal_spi_discover_devices()
18.9.4.40 hal_spi_idle()
18.9.4.41 hal_spi_init()
18.9.4.42 hal_spi_post_init()
18.9.4.43 hal_spi_receive()
18.9.4.44 hal_spi_release()
18.9.4.45 hal_spi_send()

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XVİ

18.9.4.46 hal_spi_sleep()	287
18.9.4.47 hal_spi_wake()	289
18.9.4.48 hal_swi_discover_buses()	289
18.9.4.49 hal_swi_discover_devices()	290
18.9.4.50 hal_swi_idle()	290
18.9.4.51 hal_swi_init()	290
18.9.4.52 hal_swi_post_init()	291
18.9.4.53 hal_swi_receive()	291
18.9.4.54 hal_swi_release()	292
18.9.4.55 hal_swi_send()	292
18.9.4.56 hal_swi_send_flag()	292
18.9.4.57 hal_swi_sleep()	293
18.9.4.58 hal_swi_wake()	293
18.9.4.59 hal_unlock_mutex()	294
18.9.4.60 kit_id_from_devtype()	294
18.9.4.61 kit_idle()	294
18.9.4.62 kit_init()	294
18.9.4.63 kit_interface_from_kittype()	295
18.9.4.64 kit_parse_rsp()	295
18.9.4.65 kit_phy_num_found()	295
18.9.4.66 kit_phy_receive() [1/2]	296
18.9.4.67 kit_phy_receive() [2/2]	296
18.9.4.68 kit_phy_send() [1/2]	296
18.9.4.69 kit_phy_send() [2/2]	296
18.9.4.70 kit_receive()	297
18.9.4.71 kit_send()	297
18.9.4.72 kit_sleep()	298
18.9.4.73 kit_wake()	298
18.9.4.74 kit_wrap_cmd()	298
18.9.4.75 strnchr()	299
18.9.4.76 swi_uart_deinit()	299
18.9.4.77 swi_uart_discover_buses()	300
18.9.4.78 swi_uart_init()	300
18.9.4.79 swi_uart_mode()	301
18.9.4.80 swi_uart_receive_byte()	301
18.9.4.81 swi_uart_send_byte()	301
18.9.4.82 swi_uart_setbaud()	302
18.9.5 Variable Documentation	302
18.9.5.1 pin_conf	302
18.10 Host side crypto methods (atcah_)	303
18.10.1 Detailed Description	307
18.10.2 Macro Definition Documentation	307

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XVİİ

18.10.2.1 ATCA_COMMAND_HEADER_SIZE	
18.10.2.2 ATCA_DERIVE_KEY_ZEROS_SIZE	
18.10.2.3 ATCA_GENDIG_ZEROS_SIZE	
18.10.2.4 ATCA_HMAC_BLOCK_SIZE	
18.10.2.5 ATCA_MSG_SIZE_DERIVE_KEY	
18.10.2.6 ATCA_MSG_SIZE_DERIVE_KEY_MAC .	
18.10.2.7 ATCA_MSG_SIZE_ENCRYPT_MAC	
18.10.2.8 ATCA_MSG_SIZE_GEN_DIG	
18.10.2.9 ATCA_MSG_SIZE_HMAC	
18.10.2.10 ATCA_MSG_SIZE_MAC	
18.10.2.11 ATCA_MSG_SIZE_NONCE	
18.10.2.12 ATCA_MSG_SIZE_PRIVWRITE_MAC .	
18.10.2.13 ATCA_PRIVWRITE_MAC_ZEROS_SIZE	
18.10.2.14 ATCA_PRIVWRITE_PLAIN_TEXT_SIZE	
18.10.2.15 ATCA_SN_0_DEF	
18.10.2.16 ATCA_SN_1_DEF	
18.10.2.17 ATCA_SN_8_DEF	
18.10.2.18 ATCA_WRITE_MAC_ZEROS_SIZE	
18.10.2.19 ENCRYPTION_KEY_SIZE	
18.10.2.20 MAC_MODE_USE_TEMPKEY_MASK .	
18.10.3 Typedef Documentation	
18.10.3.1 atca_check_mac_in_out_t	
18.10.3.2 atca_gen_dig_in_out_t	
18.10.3.3 atca_gen_key_in_out_t	
18.10.3.4 atca_io_decrypt_in_out_t	
18.10.3.5 atca_mac_in_out_t	
18.10.3.6 atca_nonce_in_out_t	
18.10.3.7 atca_secureboot_enc_in_out_t	
18.10.3.8 atca_secureboot_mac_in_out_t	
18.10.3.9 atca_sign_internal_in_out_t	
18.10.3.10 atca_temp_key_t	
18.10.3.11 atca_verify_in_out_t	
18.10.3.12 atca_verify_mac_in_out_t	
18.10.3.13 atca_write_mac_in_out_t	
18.10.4 Function Documentation	
18.10.4.1 atcah_check_mac()	
18.10.4.2 atcah_config_to_sign_internal()	
18.10.4.3 atcah_decrypt()	
18.10.4.4 atcah_derive_key()	
18.10.4.5 atcah_derive_key_mac()	
18.10.4.6 atcah_encode_counter_match()	
18.10.4.7 atcah_gen_dig()	

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XVIII

18.10.4.8 atcah_gen_key_msg()	315
18.10.4.9 atcah_gen_mac()	316
18.10.4.10 atcah_hmac()	316
18.10.4.11 atcah_include_data()	317
18.10.4.12 atcah_io_decrypt()	317
18.10.4.13 atcah_mac()	317
18.10.4.14 atcah_nonce()	318
18.10.4.15 atcah_privwrite_auth_mac()	318
18.10.4.16 atcah_secureboot_enc()	318
18.10.4.17 atcah_secureboot_mac()	319
18.10.4.18 atcah_sha256()	319
18.10.4.19 atcah_sign_internal_msg()	320
18.10.4.20 atcah_verify_mac()	320
18.10.4.21 atcah_write_auth_mac()	320
18.10.5 Variable Documentation	321
18.10.5.1 challenge	321
18.10.5.2 crypto_data	321
18.10.5.3 curve_type	321
18.10.5.4 key [1/2]	321
18.10.5.5 key [2/2]	322
<b>18.10.5.6 key_id</b> [1/2]	322
18.10.5.7 key_id [2/2]	322
18.10.5.8 mode [1/3]	322
18.10.5.9 mode [2/3]	322
<b>18.10.5.10 mode</b> [3/3]	322
18.10.5.11 num_in	323
18.10.5.12 otp [1/3]	323
18.10.5.13 otp [2/3]	323
<b>18.10.5.14 otp</b> [3/3]	323
18.10.5.15 p_temp	323
18.10.5.16 public_key	323
18.10.5.17 rand_out	324
18.10.5.18 response [1/2]	324
<b>18.10.5.19 response</b> [2/2]	324
18.10.5.20 signature	324
18.10.5.21 sn [1/3]	324
18.10.5.22 sn [2/3]	324
<b>18.10.5.23 sn</b> [3/3]	325
<b>18.10.5.24 temp_key</b> [1/5]	325
<b>18.10.5.25 temp_key</b> [2/5]	325
<b>18.10.5.26 temp_key</b> [3/5]	325
18 10 5 27 temp. key. [4/5]	325

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XİX

<b>18.10.5.28 temp_key</b> [5/5]	325
18.10.5.29 zero	325
18.11 JSON Web Token (JWT) methods (atca_jwt_)	326
18.11.1 Detailed Description	326
18.11.2 Function Documentation	326
18.11.2.1 atca_jwt_add_claim_numeric()	326
18.11.2.2 atca_jwt_add_claim_string()	327
18.11.2.3 atca_jwt_check_payload_start()	327
18.11.2.4 atca_jwt_finalize()	327
18.11.2.5 atca_jwt_init()	327
18.11.2.6 atca_jwt_verify()	327
18.12 mbedTLS Wrapper methods (atca_mbedtls_)	328
18.12.1 Detailed Description	328
18.12.2 Function Documentation	328
18.12.2.1 atca_mbedtls_cert_add()	328
18.12.2.2 atca_mbedtls_ecdh_ioprot_cb()	328
18.12.2.3 atca_mbedtls_ecdh_slot_cb()	329
18.12.2.4 atca_mbedtls_pk_init()	329
18.13 Attributes (pkcs11_attrib_)	330
18.13.1 Detailed Description	337
18.13.2 Macro Definition Documentation	337
18.13.2.1 PCKS11_MECH_ECC508_EC_CAPABILITY	337
18.13.2.2 TABLE_SIZE	337
18.13.3 Typedef Documentation	337
18.13.3.1 pcks11_mech_table_e	337
18.13.3.2 pcks11_mech_table_ptr	338
18.13.4 Function Documentation	338
18.13.4.1 C_CancelFunction()	338
18.13.4.2 C_CloseAllSessions()	338
18.13.4.3 C_CloseSession()	338
18.13.4.4 C_CopyObject()	338
18.13.4.5 C_CreateObject()	339
18.13.4.6 C_Decrypt()	339
18.13.4.7 C_DecryptDigestUpdate()	339
18.13.4.8 C_DecryptFinal()	339
18.13.4.9 C_DecryptInit()	340
18.13.4.10 C_DecryptUpdate()	340
18.13.4.11 C_DecryptVerifyUpdate()	340
18.13.4.12 C_DeriveKey()	340
18.13.4.13 C_DestroyObject()	341
18.13.4.14 C_Digest()	341
18.13.4.15 C_DigestEncryptUpdate()	341

 $@\ 2020\ {\rm Microchip\ Technology\ Inc}$ 

18.13.4.16 C_DigestFinal()	341
18.13.4.17 C_DigestInit()	342
18.13.4.18 C_DigestKey()	342
18.13.4.19 C_DigestUpdate()	342
18.13.4.20 C_Encrypt()	342
18.13.4.21 C_EncryptFinal()	342
18.13.4.22 C_EncryptInit()	343
18.13.4.23 C_EncryptUpdate()	343
18.13.4.24 C_Finalize()	343
18.13.4.25 C_FindObjects()	343
18.13.4.26 C_FindObjectsFinal()	343
18.13.4.27 C_FindObjectsInit()	344
18.13.4.28 C_GenerateKey()	344
18.13.4.29 C_GenerateKeyPair()	344
18.13.4.30 C_GenerateRandom()	344
18.13.4.31 C_GetAttributeValue()	345
18.13.4.32 C_GetFunctionList()	345
18.13.4.33 C_GetFunctionStatus()	345
18.13.4.34 C_GetInfo()	345
18.13.4.35 C_GetMechanismInfo()	345
18.13.4.36 C_GetMechanismList()	346
18.13.4.37 C_GetObjectSize()	346
18.13.4.38 C_GetOperationState()	346
18.13.4.39 C_GetSessionInfo()	346
18.13.4.40 C_GetSlotInfo()	346
18.13.4.41 C_GetSlotList()	347
18.13.4.42 C_GetTokenInfo()	347
18.13.4.43 C_Initialize()	347
18.13.4.44 C_InitPIN()	347
18.13.4.45 C_InitToken()	347
18.13.4.46 C_Login()	348
18.13.4.47 C_Logout()	348
18.13.4.48 C_OpenSession()	348
18.13.4.49 C_SeedRandom()	348
18.13.4.50 C_SetAttributeValue()	349
18.13.4.51 C_SetOperationState()	349
18.13.4.52 C_SetPIN()	349
18.13.4.53 C_Sign()	349
18.13.4.54 C_SignEncryptUpdate()	350
18.13.4.55 C_SignFinal()	350
18.13.4.56 C_SignInit()	350
18.13.4.57 C_SignRecover()	350

18.13.4.58 C_SignRecoverInit()	351
18.13.4.59 C_SignUpdate()	351
18.13.4.60 C_UnwrapKey()	351
18.13.4.61 C_Verify()	351
18.13.4.62 C_VerifyFinal()	352
18.13.4.63 C_VerifyInit()	352
18.13.4.64 C_VerifyRecover()	352
18.13.4.65 C_VerifyRecoverInit()	352
18.13.4.66 C_VerifyUpdate()	352
18.13.4.67 C_WaitForSlotEvent()	353
18.13.4.68 C_WrapKey()	353
18.13.4.69 pkcs11_attrib_empty()	353
18.13.4.70 pkcs11_attrib_false()	353
18.13.4.71 pkcs11_attrib_fill()	353
18.13.4.72 pkcs11_attrib_true()	354
18.13.4.73 pkcs11_attrib_value()	354
18.13.4.74 pkcs11_cert_get_authority_key_id()	354
18.13.4.75 pkcs11_cert_get_encoded()	354
18.13.4.76 pkcs11_cert_get_subject()	354
18.13.4.77 pkcs11_cert_get_subject_key_id()	354
18.13.4.78 pkcs11_cert_get_trusted_flag()	355
18.13.4.79 pkcs11_cert_get_type()	355
18.13.4.80 pkcs11_cert_x509_write()	355
18.13.4.81 pkcs11_config_cert()	355
18.13.4.82 pkcs11_config_init_cert()	355
18.13.4.83 pkcs11_config_init_private()	355
18.13.4.84 pkcs11_config_init_public()	356
18.13.4.85 pkcs11_config_key()	356
18.13.4.86 pkcs11_config_load()	356
18.13.4.87 pkcs11_config_load_objects()	356
18.13.4.88 pkcs11_config_remove_object()	356
18.13.4.89 pkcs11_deinit()	356
18.13.4.90 pkcs11_find_continue()	357
18.13.4.91 pkcs11_find_finish()	357
18.13.4.92 pkcs11_find_get_attribute()	357
18.13.4.93 pkcs11_find_init()	357
18.13.4.94 pkcs11_get_context()	357
18.13.4.95 pkcs11_get_lib_info()	357
18.13.4.96 pkcs11_get_session_context()	358
18.13.4.97 pkcs11_init()	358
18.13.4.98 pkcs11_init_check()	358
18.13.4.99 pkcs11_key_derive()	358

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXİİ

18.13.4.100 pkcs11_key_generate_pair()
18.13.4.101 pkcs11_key_write()
18.13.4.102 pkcs11_lock_context()
18.13.4.103 pkcs11_mech_get_list()
18.13.4.104 pkcs11_object_alloc()
18.13.4.105 pkcs11_object_check()
18.13.4.106 pkcs11_object_create()
18.13.4.107 pkcs11_object_deinit()
18.13.4.108 pkcs11_object_destroy()
18.13.4.109 pkcs11_object_find()
18.13.4.110 pkcs11_object_free()
18.13.4.111 pkcs11_object_get_class()
18.13.4.112 pkcs11_object_get_destroyable()
18.13.4.113 pkcs11_object_get_handle()
18.13.4.114 pkcs11_object_get_name()
18.13.4.115 pkcs11_object_get_size()
18.13.4.116 pkcs11_object_get_type()
18.13.4.117 pkcs11_object_load_handle_info()
18.13.4.118 pkcs11_os_create_mutex()
18.13.4.119 pkcs11_os_destroy_mutex()
18.13.4.120 pkcs11_os_lock_mutex()
18.13.4.121 pkcs11_os_unlock_mutex()
18.13.4.122 pkcs11_session_check()
18.13.4.123 pkcs11_session_close()
18.13.4.124 pkcs11_session_closeall()
18.13.4.125 pkcs11_session_get_info()
18.13.4.126 pkcs11_session_login()
18.13.4.127 pkcs11_session_logout()
18.13.4.128 pkcs11_session_open()
18.13.4.129 pkcs11_signature_sign()
18.13.4.130 pkcs11_signature_sign_continue()
18.13.4.131 pkcs11_signature_sign_finish()
18.13.4.132 pkcs11_signature_sign_init()
18.13.4.133 pkcs11_signature_verify()
18.13.4.134 pkcs11_signature_verify_continue()
18.13.4.135 pkcs11_signature_verify_finish()
18.13.4.136 pkcs11_signature_verify_init()
18.13.4.137 pkcs11_slot_config()
18.13.4.138 pkcs11_slot_get_context()
18.13.4.139 pkcs11_slot_get_info()
18.13.4.140 pkcs11_slot_get_list()
18.13.4.141 pkcs11_slot_init()

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXIII

18.13.4.142 pkcs11_slot_initslots()	 . 366
18.13.4.143 pkcs11_token_convert_pin_to_key()	 . 366
18.13.4.144 pkcs11_token_get_access_type()	 . 367
18.13.4.145 pkcs11_token_get_info()	 . 367
18.13.4.146 pkcs11_token_get_storage()	 . 367
18.13.4.147 pkcs11_token_get_writable()	 . 367
18.13.4.148 pkcs11_token_init()	 . 367
18.13.4.149 pkcs11_token_random()	 . 367
18.13.4.150 pkcs11_token_set_pin()	 . 368
18.13.4.151 pkcs11_unlock_context()	 . 368
18.13.4.152 pkcs11_util_convert_rv()	 . 368
18.13.4.153 pkcs11_util_escape_string()	 . 368
18.13.4.154 pkcs11_util_memset()	 . 368
18.13.4.155 pkcs_mech_get_info()	 . 368
18.13.5 Variable Documentation	 . 369
18.13.5.1 pkcs11_cert_wtlspublic_attributes	 . 369
18.13.5.2 pkcs11_cert_wtlspublic_attributes_count	 . 369
18.13.5.3 pkcs11_cert_x509_attributes	 . 369
18.13.5.4 pkcs11_cert_x509_attributes_count	 . 369
18.13.5.5 pkcs11_cert_x509public_attributes	 . 369
18.13.5.6 pkcs11_cert_x509public_attributes_count	 . 369
18.13.5.7 pkcs11_key_ec_private_attributes	 . 370
18.13.5.8 pkcs11_key_ec_public_attributes	 . 370
18.13.5.9 pkcs11_key_private_attributes	 . 370
18.13.5.10 pkcs11_key_private_attributes_count	 . 370
18.13.5.11 pkcs11_key_public_attributes	 . 370
18.13.5.12 pkcs11_key_public_attributes_count	 . 370
18.13.5.13 pkcs11_key_rsa_private_attributes	 . 371
18.13.5.14 pkcs11_key_secret_attributes	 . 371
18.13.5.15 pkcs11_key_secret_attributes_count	 . 371
18.13.5.16 pkcs11_lib_description	 . 371
18.13.5.17 pkcs11_lib_manufacturer_id	 . 371
18.13.5.18 pkcs11_object_cache	 . 371
18.13.5.19 pkcs11_object_monotonic_attributes	 . 372
18.13.5.20 pkcs11_object_monotonic_attributes_count	 . 372
18.14 TNG API (tng_)	 . 373
18.14.1 Detailed Description	 . 374
18.14.2 Macro Definition Documentation	 . 374
18.14.2.1 CRYPTOAUTH_ROOT_CA_002_PUBLIC_KEY_OFFSET	 . 374
18.14.2.2 TNGLORA_CERT_TEMPLATE_4_DEVICE_SIZE	 . 374
18.14.2.3 TNGTLS_CERT_ELEMENTS_2_DEVICE_COUNT	 . 374
18.14.2.4 TNGTLS_CERT_TEMPLATE_1_SIGNER_SIZE	 . 374

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXİV

18.14.2.5 TNGTLS_CERT_TEMPLATE_2_DEVICE_SIZE	374
18.14.2.6 TNGTLS_CERT_TEMPLATE_3_DEVICE_SIZE	374
18.14.3 Function Documentation	374
18.14.3.1 tng_atcacert_device_public_key()	374
18.14.3.2 tng_atcacert_max_device_cert_size()	375
18.14.3.3 tng_atcacert_max_signer_cert_size()	375
18.14.3.4 tng_atcacert_read_device_cert()	376
18.14.3.5 tng_atcacert_read_signer_cert()	376
18.14.3.6 tng_atcacert_root_cert()	376
18.14.3.7 tng_atcacert_root_cert_size()	377
18.14.3.8 tng_atcacert_root_public_key()	377
18.14.3.9 tng_atcacert_signer_public_key()	378
18.14.3.10 tng_get_device_cert_def()	378
18.14.3.11 tng_get_device_pubkey()	378
18.14.3.12 tng_map_get_device_cert_def()	379
18.14.4 Variable Documentation	379
18.14.4.1 g_cryptoauth_root_ca_002_cert	379
18.14.4.2 g_cryptoauth_root_ca_002_cert_size	379
18.14.4.3 g_tflxtls_cert_def_4_device	379
18.14.4.4 g_tnglora_cert_def_1_signer	379
18.14.4.5 g_tnglora_cert_def_2_device	380
18.14.4.6 g_tnglora_cert_def_4_device	380
18.14.4.7 g_tngtls_cert_def_1_signer	380
18.14.4.8 g_tngtls_cert_def_2_device	380
18.14.4.9 g_tngtls_cert_def_3_device	380
19 Data Structure Documentation	381
19.1 _atecc508a_config Struct Reference	
19.1.1 Field Documentation	
19.1.1.1 ChipMode	382
19.1.1.2 Counter0	
19.1.1.3 Counter1	382
19.1.1.4 I2C_Address	382
19.1.1.5 I2C_Enable	
19.1.1.6 KeyConfig	382
19.1.1.7 LastKeyUse	382
19.1.1.8 LockConfig	382
19.1.1.9 LockValue	383
19.1.1.10 OTPmode	383
19.1.1.11 Reserved0	383
19.1.1.12 Reserved1	383
19.1.1.13 Reserved2	383

 $@\ 2020\ {\rm Microchip\ Technology\ Inc}$ 

19.1.1.14 RevNum	 383
19.1.1.15 RFU	 383
19.1.1.16 Selector	 383
19.1.1.17 SlotConfig	 384
19.1.1.18 SlotLocked	 384
19.1.1.19 SN03	 384
19.1.1.20 SN47	 384
19.1.1.21 SN8	 384
19.1.1.22 UserExtra	 384
19.1.1.23 X509format	 384
19.2 _atecc608_config Struct Reference	 384
19.2.1 Field Documentation	 385
19.2.1.1 AES_Enable	 385
19.2.1.2 ChipMode	 385
19.2.1.3 ChipOptions	 386
19.2.1.4 Counter0	 386
19.2.1.5 Counter1	 386
19.2.1.6 CountMatch	 386
19.2.1.7 I2C_Address	 386
19.2.1.8 I2C_Enable	 386
19.2.1.9 KdflvLoc	 386
19.2.1.10 KdflvStr	 386
19.2.1.11 KeyConfig	 387
19.2.1.12 LockConfig	 387
19.2.1.13 LockValue	 387
19.2.1.14 Reserved1	 387
19.2.1.15 Reserved2	 387
19.2.1.16 Reserved3	 387
19.2.1.17 RevNum	 387
19.2.1.18 SecureBoot	 387
19.2.1.19 SlotConfig	 388
19.2.1.20 SlotLocked	 388
19.2.1.21 SN03	 388
19.2.1.22 SN47	 388
19.2.1.23 SN8	 388
19.2.1.24 UseLock	 388
19.2.1.25 UserExtra	 388
19.2.1.26 UserExtraAdd	 388
19.2.1.27 VolatileKeyPermission	 389
19.2.1.28 X509format	 389
19.3 _atsha204a_config Struct Reference	 389
19.3.1 Field Documentation	389

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXVİ

19.3.1.1 ChipMode	 . 389
19.3.1.2 Counter	 . 390
19.3.1.3 I2C_Address	 . 390
19.3.1.4 I2C_Enable	 . 390
19.3.1.5 LastKeyUse	 . 390
19.3.1.6 LockConfig	 . 390
19.3.1.7 LockValue	 . 390
19.3.1.8 OTPmode	 . 390
19.3.1.9 Reserved0	 . 390
19.3.1.10 Reserved1	 . 391
19.3.1.11 Reserved2	 . 391
19.3.1.12 RevNum	 . 391
19.3.1.13 Selector	 . 391
19.3.1.14 SlotConfig	 . 391
19.3.1.15 SN03	 . 391
19.3.1.16 SN47	 . 391
19.3.1.17 SN8	 . 391
19.3.1.18 UserExtra	 . 392
19.4 _pcks11_mech_table_e Struct Reference	 . 392
19.4.1 Field Documentation	 . 392
19.4.1.1 info	 . 392
19.4.1.2 type	 . 392
19.5 _pkcs11_attrib_model Struct Reference	 . 392
19.5.1 Field Documentation	 . 392
19.5.1.1 func	 . 392
19.5.1.2 type	 . 393
19.6 _pkcs11_lib_ctx Struct Reference	 . 393
19.6.1 Detailed Description	 . 393
19.6.2 Field Documentation	 . 393
19.6.2.1 config_path	 . 393
19.6.2.2 create_mutex	 . 393
19.6.2.3 destroy_mutex	 . 393
19.6.2.4 initialized	 . 394
19.6.2.5 lock_mutex	 . 394
19.6.2.6 mutex	 . 394
19.6.2.7 slot_cnt	 . 394
19.6.2.8 slots	 . 394
19.6.2.9 unlock_mutex	 . 394
19.7 _pkcs11_object Struct Reference	 . 394
19.7.1 Field Documentation	 . 395
19.7.1.1 attributes	 . 395
19.7.1.2 class_id	 . 395

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXVII

19.7.1.3 class_type	395
19.7.1.4 config	395
19.7.1.5 count	395
19.7.1.6 data	396
19.7.1.7 flags	396
19.7.1.8 handle_info	396
19.7.1.9 name	396
19.7.1.10 size	396
19.7.1.11 slot	396
19.8 _pkcs11_object_cache_t Struct Reference	396
19.8.1 Field Documentation	397
19.8.1.1 handle	397
19.8.1.2 object	397
19.9 _pkcs11_session_ctx Struct Reference	397
19.9.1 Detailed Description	397
19.9.2 Field Documentation	397
19.9.2.1 active_object	398
19.9.2.2 attrib_count	398
19.9.2.3 attrib_list	398
19.9.2.4 error	398
19.9.2.5 handle	398
19.9.2.6 initialized	398
19.9.2.7 logged_in	398
19.9.2.8 object_count	398
19.9.2.9 object_index	399
19.9.2.10 read_key	399
19.9.2.11 slot	399
19.9.2.12 state	399
19.10 _pkcs11_slot_ctx Struct Reference	399
19.10.1 Detailed Description	399
19.10.2 Field Documentation	400
19.10.2.1 cfg_zone	400
19.10.2.2 device_ctx	400
19.10.2.3 flags	400
19.10.2.4 initialized	400
19.10.2.5 interface_config	400
19.10.2.6 label	400
19.10.2.7 session	400
19.10.2.8 slot_id	401
19.10.2.9 so_pin_handle	401
19.10.2.10 user_pin_handle	401
19.11 atca_aes_cbc_ctx Struct Reference	401

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXVIII

19.11.1 Field Documentation	. 401
19.11.1.1 ciphertext	. 401
19.11.1.2 device	. 402
19.11.1.3 key_block	. 402
19.11.1.4 key_id	. 402
19.12 atca_aes_cmac_ctx Struct Reference	. 402
19.12.1 Field Documentation	. 402
19.12.1.1 block	. 402
19.12.1.2 block_size	. 403
19.12.1.3 cbc_ctx	. 403
19.13 atca_aes_ctr_ctx Struct Reference	. 403
19.13.1 Field Documentation	. 403
19.13.1.1 cb	. 403
19.13.1.2 counter_size	. 404
19.13.1.3 device	. 404
19.13.1.4 key_block	. 404
19.13.1.5 key_id	. 404
19.14 atca_aes_gcm_ctx Struct Reference	. 404
19.14.1 Detailed Description	. 405
19.14.2 Field Documentation	. 405
19.14.2.1 aad_size	. 405
19.14.2.2 cb	. 405
19.14.2.3 ciphertext_block	. 406
19.14.2.4 data_size	. 406
19.14.2.5 enc_cb	. 406
19.14.2.6 h	. 406
19.14.2.7 j0	. 406
19.14.2.8 key_block	. 406
19.14.2.9 key_id	. 407
19.14.2.10 partial_aad	. 407
19.14.2.11 partial_aad_size	407
19.14.2.12 y	. 407
19.15 atca_check_mac_in_out Struct Reference	. 407
19.15.1 Detailed Description	. 408
19.15.2 Field Documentation	. 408
19.15.2.1 client_chal	. 408
19.15.2.2 client_resp	. 408
19.15.2.3 key_id	. 408
19.15.2.4 mode	. 408
19.15.2.5 other_data	. 408
19.15.2.6 otp	. 409
19.15.2.7 slot kev	409

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXİX

19.15.2.8 sn	. 409
19.15.2.9 target_key	. 409
19.15.2.10 temp_key	. 409
19.16 atca_command Struct Reference	. 409
19.16.1 Detailed Description	. 410
19.16.2 Field Documentation	. 410
19.16.2.1 clock_divider	. 410
19.16.2.2 dt	. 410
19.16.2.3 execution_time_msec	. 410
19.17 atca_decrypt_in_out Struct Reference	. 410
19.17.1 Detailed Description	. 410
19.18 atca_derive_key_in_out Struct Reference	. 411
19.18.1 Detailed Description	. 411
19.18.2 Field Documentation	. 411
19.18.2.1 mode	. 411
19.18.2.2 parent_key	. 411
19.18.2.3 sn	. 412
19.18.2.4 target_key	. 412
19.18.2.5 target_key_id	. 412
19.18.2.6 temp_key	. 412
19.19 atca_derive_key_mac_in_out Struct Reference	. 412
19.19.1 Detailed Description	. 413
19.19.2 Field Documentation	. 413
19.19.2.1 mac	. 413
19.19.2.2 mode	. 413
19.19.2.3 parent_key	. 413
19.19.2.4 sn	. 413
19.19.2.5 target_key_id	. 413
19.20 atca_device Struct Reference	. 414
19.20.1 Detailed Description	. 414
19.20.2 Field Documentation	. 414
19.20.2.1 mCommands	. 414
19.20.2.2 mlface	. 414
19.20.2.3 session_counter	. 414
19.20.2.4 session_key	. 415
19.20.2.5 session_key_id	. 415
19.20.2.6 session_key_len	. 415
19.20.2.7 session_state	. 415
19.21 atca_gen_dig_in_out Struct Reference	. 415
19.21.1 Detailed Description	. 416
19.21.2 Field Documentation	. 416
19.21.2.1 counter	. 416

19.21.2.2 is_key_nomac	416
19.21.2.3 key_conf	416
19.21.2.4 key_id	416
19.21.2.5 other_data	416
19.21.2.6 slot_conf	417
19.21.2.7 slot_locked	417
19.21.2.8 sn	417
19.21.2.9 stored_value	417
19.21.2.10 temp_key	417
19.21.2.11 zone	417
19.22 atca_gen_key_in_out Struct Reference	418
19.22.1 Detailed Description	418
19.22.2 Field Documentation	418
19.22.2.1 key_id	418
19.22.2.2 mode	418
19.22.2.3 other_data	419
19.22.2.4 public_key	419
19.22.2.5 public_key_size	419
19.22.2.6 sn	419
19.22.2.7 temp_key	419
19.23 atca_hmac_in_out Struct Reference	419
19.23.1 Detailed Description	420
19.24 atca_iface Struct Reference	420
19.24.1 Detailed Description	420
19.24.2 Field Documentation	420
19.24.2.1 atidle	421
19.24.2.2 atinit	421
19.24.2.3 atpostinit	421
19.24.2.4 atreceive	421
19.24.2.5 atsend	421
19.24.2.6 atsleep	421
19.24.2.7 atwake	421
19.24.2.8 hal_data	421
19.24.2.9 mlfaceCFG	422
19.24.2.10 mType	422
19.25 atca_include_data_in_out Struct Reference	422
19.25.1 Detailed Description	422
19.25.2 Field Documentation	422
19.25.2.1 mode	422
19.26 atca_io_decrypt_in_out Struct Reference	422
19.26.1 Field Documentation	423
19 26 1 1 data	423

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

xxxi

19.26.1.2 data_size
19.26.1.3 io_key
19.26.1.4 out_nonce
19.27 atca_jwt_t Struct Reference
19.27.1 Detailed Description
19.27.2 Field Documentation
19.27.2.1 buf
19.27.2.2 buflen
19.27.2.3 cur
19.28 atca_mac_in_out Struct Reference
19.28.1 Detailed Description
19.29 atca_nonce_in_out Struct Reference
19.29.1 Detailed Description
19.30 atca_secureboot_enc_in_out Struct Reference
19.30.1 Field Documentation
19.30.1.1 digest
19.30.1.2 digest_enc
19.30.1.3 hashed_key
19.30.1.4 io_key
19.30.1.5 temp_key
19.31 atca_secureboot_mac_in_out Struct Reference
19.31.1 Field Documentation
19.31.1.1 digest
19.31.1.2 hashed_key
19.31.1.3 mac
19.31.1.4 mode
19.31.1.5 param2
19.31.1.6 secure_boot_config
19.31.1.7 signature
19.32 atca_sha256_ctx Struct Reference
19.32.1 Field Documentation
19.32.1.1 block
19.32.1.2 block_size
19.32.1.3 total_msg_size
19.33 atca_sign_internal_in_out Struct Reference
19.33.1 Detailed Description
19.33.2 Field Documentation
19.33.2.1 digest
19.33.2.2 for_invalidate
19.33.2.3 is_slot_locked
19.33.2.4 key_config
19.33.2.5 key_id

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXXII

19.33.2.6 message	. 431
19.33.2.7 mode	. 431
19.33.2.8 slot_config	. 432
19.33.2.9 sn	. 432
19.33.2.10 temp_key	. 432
19.33.2.11 update_count	. 432
19.33.2.12 use_flag	. 432
19.33.2.13 verify_other_data	. 432
19.34 atca_temp_key Struct Reference	. 433
19.34.1 Detailed Description	. 433
19.34.2 Field Documentation	. 433
19.34.2.1 gen_dig_data	. 433
19.34.2.2 gen_key_data	. 433
19.34.2.3 is_64	. 434
19.34.2.4 key_id	. 434
19.34.2.5 no_mac_flag	. 434
19.34.2.6 source_flag	. 434
19.34.2.7 valid	. 434
19.34.2.8 value	. 434
19.35 atca_verify_in_out Struct Reference	. 435
19.35.1 Detailed Description	. 435
19.36 atca_verify_mac Struct Reference	. 435
19.36.1 Field Documentation	. 436
19.36.1.1 io_key	. 436
19.36.1.2 key_id	. 436
19.36.1.3 mac	. 436
19.36.1.4 mode	. 436
19.36.1.5 msg_dig_buf	. 436
19.36.1.6 other_data	. 437
19.36.1.7 signature	. 437
19.36.1.8 sn	. 437
19.36.1.9 temp_key	. 437
19.37 atca_write_mac_in_out Struct Reference	. 437
19.37.1 Detailed Description	. 438
19.37.2 Field Documentation	. 438
19.37.2.1 auth_mac	. 438
19.37.2.2 encrypted_data	. 438
19.37.2.3 input_data	. 438
19.37.2.4 key_id	. 438
19.37.2.5 sn	. 438
19.37.2.6 temp_key	. 439
19.37.2.7 zone	. 439

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XXXIII

19.38 atcacert_build_state_s Struct Reference	Э
19.38.1 Detailed Description	9
19.38.2 Field Documentation	9
19.38.2.1 cert	0
19.38.2.2 cert_def	0
19.38.2.3 cert_size	0
19.38.2.4 device_sn	0
19.38.2.5 is_device_sn	0
19.38.2.6 max_cert_size	0
19.39 atcacert_cert_element_s Struct Reference	1
19.39.1 Detailed Description	1
19.39.2 Field Documentation	1
19.39.2.1 cert_loc	1
19.39.2.2 device_loc	1
19.39.2.3 id	1
19.39.2.4 transforms	2
19.40 atcacert_cert_loc_s Struct Reference	2
19.40.1 Detailed Description	2
19.40.2 Field Documentation	2
19.40.2.1 count	2
19.40.2.2 offset	2
19.41 atcacert_def_s Struct Reference	2
19.41.1 Detailed Description	3
19.41.2 Field Documentation	3
19.41.2.1 ca_cert_def	4
19.41.2.2 cert_elements	4
19.41.2.3 cert_elements_count	4
19.41.2.4 cert_sn_dev_loc	4
19.41.2.5 cert_template	4
19.41.2.6 cert_template_size	4
19.41.2.7 chain_id	5
19.41.2.8 comp_cert_dev_loc	5
19.41.2.9 expire_date_format	5
19.41.2.10 expire_years	5
19.41.2.11 issue_date_format	5
19.41.2.12 private_key_slot	5
19.41.2.13 public_key_dev_loc	6
19.41.2.14 sn_source	6
19.41.2.15 std_cert_elements	6
19.41.2.16 tbs_cert_loc	6
19.41.2.17 template_id	6
19.41.2.18 type	6

19.42 atcacert_device_loc_s Struct Reference	47
19.42.1 Detailed Description	l47
19.42.2 Field Documentation	l47
19.42.2.1 count	l47
19.42.2.2 is_genkey	l47
19.42.2.3 offset	l47
19.42.2.4 slot	l48
19.42.2.5 zone	l48
19.43 atcacert_tm_utc_s Struct Reference	l48
19.43.1 Detailed Description	l48
19.43.2 Field Documentation	l48
19.43.2.1 tm_hour	l48
19.43.2.2 tm_mday	148
19.43.2.3 tm_min	149
19.43.2.4 tm_mon	149
19.43.2.5 tm_sec	149
19.43.2.6 tm_year	149
19.44 ATCAHAL_t Struct Reference	149
19.44.1 Detailed Description	l49
19.44.2 Field Documentation	ŀ50
19.44.2.1 hal_data	ŀ50
19.44.2.2 halidle	ŀ50
19.44.2.3 halinit	ŀ50
19.44.2.4 halpostinit	ŀ50
19.44.2.5 halreceive	ŀ50
19.44.2.6 halrelease	ŀ50
19.44.2.7 halsend	ŀ50
19.44.2.8 halsleep	ŀ51
19.44.2.9 halwake	ŀ51
19.45 atcal2Cmaster Struct Reference	ŀ51
19.45.1 Detailed Description	ŀ51
19.45.2 Field Documentation	ŀ51
19.45.2.1 bus_index	ŀ51
19.45.2.2 i2c_file	ŀ51
19.45.2.3 id	ŀ52
19.45.2.4 ref_ct	152
19.45.2.5 twi_id	152
19.45.2.6 twi_master_instance	152
19.46 ATCAlfaceCfg Struct Reference	152
19.46.1 Field Documentation	153
19.46.1.1 "@1	ŀ53
19 46 1 2 atcacustom 4	153

19.46.1.3 atcahid	-53
19.46.1.4 atcai2c	54
19.46.1.5 atcaspi	54
19.46.1.6 atcaswi	54
19.46.1.7 atcauart	54
19.46.1.8 baud	54
19.46.1.9 bus	54
19.46.1.10 cfg_data	54
19.46.1.11 dev_identity	54
19.46.1.12 dev_interface	-55
19.46.1.13 devtype	55
19.46.1.14 halidle	-55
19.46.1.15 halinit	-55
19.46.1.16 halpostinit	55
19.46.1.17 halreceive	-55
19.46.1.18 halrelease	-55
19.46.1.19 halsend	-55
19.46.1.20 halsleep	-56
19.46.1.21 halwake	-56
19.46.1.22 idx	-56
19.46.1.23 iface_type	-56
19.46.1.24 packetsize	-56
19.46.1.25 parity	-56
19.46.1.26 pid	-56
19.46.1.27 port	-56
19.46.1.28 rx_retries	57
19.46.1.29 select_pin	-57
19.46.1.30 slave_address	-57
19.46.1.31 stopbits	-57
19.46.1.32 vid	57
19.46.1.33 wake_delay	57
19.46.1.34 wordsize	-57
19.47 ATCAPacket Struct Reference	-57
19.47.1 Field Documentation	-58
19.47.1.1 _reserved	-58
19.47.1.2 data	-58
19.47.1.3 execTime	-58
19.47.1.4 opcode	-58
19.47.1.5 param1	-58
19.47.1.6 param2	59
19.47.1.7 txsize	59
19.48 atcaSPImaster Struct Reference	59

19.48.1 Field Documentation	59
19.48.1.1 ref_ct	59
19.48.1.2 spi_file	59
19.49 atcaSWImaster Struct Reference	59
19.49.1 Detailed Description	30
19.49.2 Field Documentation	30
19.49.2.1 bus_index	30
19.49.2.2 ref_ct	30
19.49.2.3 sercom_core_freq	30
19.49.2.4 usart_instance	30
19.49.2.5 USART_SWI	30
19.50 CK_AES_CBC_ENCRYPT_DATA_PARAMS Struct Reference	31
19.50.1 Field Documentation	31
19.50.1.1 iv	31
19.50.1.2 length	31
19.50.1.3 pData	31
19.51 CK_AES_CCM_PARAMS Struct Reference	31
19.51.1 Field Documentation	32
19.51.1.1 pAAD	32
19.51.1.2 pNonce	32
19.51.1.3 ulAADLen	32
19.51.1.4 ulDataLen	32
19.51.1.5 ulMACLen	32
19.51.1.6 ulNonceLen	32
19.52 CK_AES_CTR_PARAMS Struct Reference	32
19.52.1 Field Documentation	33
19.52.1.1 cb	33
19.52.1.2 ulCounterBits	33
19.53 CK_AES_GCM_PARAMS Struct Reference	33
19.53.1 Field Documentation	33
19.53.1.1 pAAD	33
19.53.1.2 plv	34
19.53.1.3 ulAADLen	34
19.53.1.4 ullvBits	34
19.53.1.5 ullvLen	34
19.53.1.6 ulTagBits	34
19.54 CK_ARIA_CBC_ENCRYPT_DATA_PARAMS Struct Reference	34
19.54.1 Field Documentation	34
19.54.1.1 iv	35
19.54.1.2 length	35
19.54.1.3 pData	35
19.55 CK ATTRIBUTE Struct Reference	35

19.55.1 Field Documentation	165
19.55.1.1 pValue	165
19.55.1.2 type	165
19.55.1.3 ulValueLen	166
19.56 CK_C_INITIALIZE_ARGS Struct Reference	166
19.56.1 Field Documentation	166
19.56.1.1 CreateMutex	166
19.56.1.2 DestroyMutex	166
19.56.1.3 flags	166
19.56.1.4 LockMutex	166
19.56.1.5 pReserved	167
19.56.1.6 UnlockMutex	167
19.57 CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS Struct Reference	167
19.57.1 Field Documentation	167
19.57.1.1 iv	167
19.57.1.2 length	167
19.57.1.3 pData	167
19.58 CK_CAMELLIA_CTR_PARAMS Struct Reference	168
19.58.1 Field Documentation	168
19.58.1.1 cb	168
19.58.1.2 ulCounterBits	168
19.59 CK_CCM_PARAMS Struct Reference	168
19.59.1 Field Documentation	168
19.59.1.1 pAAD	169
19.59.1.2 pNonce	169
19.59.1.3 ulAADLen	169
19.59.1.4 ulDataLen	169
19.59.1.5 ulMACLen	169
19.59.1.6 ulNonceLen	169
19.60 CK_CMS_SIG_PARAMS Struct Reference	169
19.60.1 Field Documentation	470
19.60.1.1 certificateHandle	470
19.60.1.2 pContentType	470
19.60.1.3 pDigestMechanism	170
19.60.1.4 pRequestedAttributes	170
19.60.1.5 pRequiredAttributes	470
19.60.1.6 pSigningMechanism	170
19.60.1.7 ulRequestedAttributesLen	470
and the state of the state of	471
19.61 CK_DATE Struct Reference	
19.61.1 Field Documentation	171
19.61.1.1 day	171

19.61.1.2 month	. 4/1
19.61.1.3 year	
19.62 CK_DES_CBC_ENCRYPT_DATA_PARAMS Struct Reference	. 471
19.62.1 Field Documentation	. 472
19.62.1.1 iv	. 472
19.62.1.2 length	. 472
19.62.1.3 pData	. 472
19.63 CK_DSA_PARAMETER_GEN_PARAM Struct Reference	. 472
19.63.1 Field Documentation	. 472
19.63.1.1 hash	. 472
19.63.1.2 pSeed	. 473
19.63.1.3 ullndex	. 473
19.63.1.4 ulSeedLen	. 473
19.64 CK_ECDH1_DERIVE_PARAMS Struct Reference	. 473
19.64.1 Field Documentation	. 473
19.64.1.1 kdf	. 473
19.64.1.2 pPublicData	. 473
19.64.1.3 pSharedData	. 474
19.64.1.4 ulPublicDataLen	. 474
19.64.1.5 ulSharedDataLen	. 474
19.65 CK_ECDH2_DERIVE_PARAMS Struct Reference	. 474
19.65.1 Field Documentation	. 474
19.65.1.1 hPrivateData	. 474
19.65.1.2 kdf	. 475
19.65.1.3 pPublicData	. 475
19.65.1.4 pPublicData2	. 475
19.65.1.5 pSharedData	. 475
19.65.1.6 ulPrivateDataLen	. 475
19.65.1.7 ulPublicDataLen	. 475
19.65.1.8 ulPublicDataLen2	. 475
19.65.1.9 ulSharedDataLen	. 475
19.66 CK_ECDH_AES_KEY_WRAP_PARAMS Struct Reference	. 476
19.66.1 Field Documentation	. 476
19.66.1.1 kdf	. 476
19.66.1.2 pSharedData	. 476
19.66.1.3 ulAESKeyBits	. 476
19.66.1.4 ulSharedDataLen	. 476
19.67 CK_ECMQV_DERIVE_PARAMS Struct Reference	. 476
19.67.1 Field Documentation	. 477
19.67.1.1 hPrivateData	. 477
19.67.1.2 kdf	. 477
19.67.1.3 pPublicData	477

19.67.1.4 pPublicData2	177
19.67.1.5 pSharedData	ŀ77
19.67.1.6 publicKey	ŀ78
19.67.1.7 ulPrivateDataLen	ŀ78
19.67.1.8 ulPublicDataLen	ŀ78
19.67.1.9 ulPublicDataLen2	ŀ78
19.67.1.10 ulSharedDataLen	ŀ78
19.68 CK_FUNCTION_LIST Struct Reference	ŀ78
19.68.1 Field Documentation	ŀ78
19.68.1.1 version	ŀ78
19.69 CK_GCM_PARAMS Struct Reference	ŀ79
19.69.1 Field Documentation	ŀ79
19.69.1.1 pAAD	ŀ79
19.69.1.2 plv	ŀ79
19.69.1.3 ulAADLen	ŀ79
19.69.1.4 ullvBits	ŀ79
19.69.1.5 ullvLen	ŀ79
19.69.1.6 ulTagBits	180
19.70 CK_GOSTR3410_DERIVE_PARAMS Struct Reference	180
19.70.1 Field Documentation	180
19.70.1.1 kdf	180
19.70.1.2 pPublicData	180
19.70.1.3 pUKM	180
19.70.1.4 ulPublicDataLen	180
19.70.1.5 ulUKMLen	l81
19.71 CK_GOSTR3410_KEY_WRAP_PARAMS Struct Reference	l81
19.71.1 Field Documentation	l81
19.71.1.1 hKey	l81
19.71.1.2 pUKM	l81
19.71.1.3 pWrapOID	l81
19.71.1.4 ulUKMLen	181
19.71.1.5 ulWrapOIDLen	182
19.72 CK_INFO Struct Reference	182
19.72.1 Field Documentation	182
19.72.1.1 cryptokiVersion	ŀ82
19.72.1.2 flags	182
19.72.1.3 libraryDescription	182
19.72.1.4 libraryVersion	182
19.72.1.5 manufacturerID	183
19.73 CK_KEA_DERIVE_PARAMS Struct Reference	183
19.73.1 Field Documentation	183
19 73 1 1 isSender 4	เลว

19.73.1.2 pPublicData	183
19.73.1.3 pRandomA	<del>1</del> 83
19.73.1.4 pRandomB	<del>1</del> 83
19.73.1.5 ulPublicDataLen	184
19.73.1.6 ulRandomLen	184
19.74 CK_KEY_DERIVATION_STRING_DATA Struct Reference	184
19.74.1 Field Documentation	184
19.74.1.1 pData	184
19.74.1.2 ulLen	184
19.75 CK_KEY_WRAP_SET_OAEP_PARAMS Struct Reference	184
19.75.1 Field Documentation	185
19.75.1.1 bBC	185
19.75.1.2 pX	185
19.75.1.3 ulXLen	185
19.76 CK_KIP_PARAMS Struct Reference	185
19.76.1 Field Documentation	185
19.76.1.1 hKey	185
19.76.1.2 pMechanism	186
19.76.1.3 pSeed	186
19.76.1.4 ulSeedLen	186
19.77 CK_MECHANISM Struct Reference	186
19.77.1 Field Documentation	186
19.77.1.1 mechanism	<del>1</del> 86
19.77.1.2 pParameter	<del>1</del> 86
19.77.1.3 ulParameterLen	187
19.78 CK_MECHANISM_INFO Struct Reference	187
19.78.1 Field Documentation	<del>1</del> 87
19.78.1.1 flags	<del>1</del> 87
19.78.1.2 ulMaxKeySize	<del>1</del> 87
19.78.1.3 ulMinKeySize	<del>1</del> 87
19.79 CK_OTP_PARAM Struct Reference	487
19.79.1 Field Documentation	<del>1</del> 88
19.79.1.1 pValue	188
19.79.1.2 type	<del>1</del> 88
19.79.1.3 ulValueLen	188
19.80 CK_OTP_PARAMS Struct Reference	488
19.80.1 Field Documentation	<del>1</del> 88
19.80.1.1 pParams	<del>1</del> 88
19.80.1.2 ulCount	188
19.81 CK_OTP_SIGNATURE_INFO Struct Reference	<del>1</del> 89
19.81.1 Field Documentation	<del>1</del> 89
19.81.1.1 nParame	189

19.81.1.2 ulCount
19.82 CK_PBE_PARAMS Struct Reference
19.82.1 Field Documentation
19.82.1.1 plnitVector
19.82.1.2 pPassword
19.82.1.3 pSalt
19.82.1.4 ullteration
19.82.1.5 ulPasswordLen
19.82.1.6 ulSaltLen
19.83 CK_PKCS5_PBKD2_PARAMS Struct Reference
19.83.1 Field Documentation
19.83.1.1 iterations
19.83.1.2 pPassword
19.83.1.3 pPrfData
19.83.1.4 prf
19.83.1.5 pSaltSourceData
19.83.1.6 saltSource
19.83.1.7 ulPasswordLen
19.83.1.8 ulPrfDataLen
19.83.1.9 ulSaltSourceDataLen
19.84 CK_PKCS5_PBKD2_PARAMS2 Struct Reference
19.84.1 Field Documentation
19.84.1.1 iterations
19.84.1.2 pPassword
19.84.1.3 pPrfData
19.84.1.4 prf
19.84.1.5 pSaltSourceData
19.84.1.6 saltSource
19.84.1.7 ulPasswordLen
19.84.1.8 ulPrfDataLen
19.84.1.9 ulSaltSourceDataLen
19.85 CK_RC2_CBC_PARAMS Struct Reference
19.85.1 Field Documentation
19.85.1.1 iv
19.85.1.2 ulEffectiveBits
19.86 CK_RC2_MAC_GENERAL_PARAMS Struct Reference
19.86.1 Field Documentation
19.86.1.1 ulEffectiveBits
19.86.1.2 ulMacLength
19.87 CK_RC5_CBC_PARAMS Struct Reference
19.87.1 Field Documentation
19.87.1.1 plv

19.87.1.2 ullvLen	495
19.87.1.3 ulRounds	495
19.87.1.4 ulWordsize	495
19.88 CK_RC5_MAC_GENERAL_PARAMS Struct Reference	495
19.88.1 Field Documentation	496
19.88.1.1 ulMacLength	496
19.88.1.2 ulRounds	496
19.88.1.3 ulWordsize	496
19.89 CK_RC5_PARAMS Struct Reference	496
19.89.1 Field Documentation	496
19.89.1.1 ulRounds	496
19.89.1.2 ulWordsize	497
19.90 CK_RSA_AES_KEY_WRAP_PARAMS Struct Reference	497
19.90.1 Field Documentation	497
19.90.1.1 pOAEPParams	497
19.90.1.2 ulAESKeyBits	497
19.91 CK_RSA_PKCS_OAEP_PARAMS Struct Reference	497
19.91.1 Field Documentation	497
19.91.1.1 hashAlg	498
19.91.1.2 mgf	498
19.91.1.3 pSourceData	498
19.91.1.4 source	498
19.91.1.5 ulSourceDataLen	498
19.92 CK_RSA_PKCS_PSS_PARAMS Struct Reference	498
19.92.1 Field Documentation	498
19.92.1.1 hashAlg	499
19.92.1.2 mgf	499
19.92.1.3 sLen	499
19.93 CK_SEED_CBC_ENCRYPT_DATA_PARAMS Struct Reference	499
19.93.1 Field Documentation	499
19.93.1.1 iv	499
19.93.1.2 length	499
19.93.1.3 pData	500
19.94 CK_SESSION_INFO Struct Reference	500
19.94.1 Field Documentation	500
19.94.1.1 flags	500
19.94.1.2 slotID	500
19.94.1.3 state	500
19.94.1.4 ulDeviceError	500
19.95 CK_SKIPJACK_PRIVATE_WRAP_PARAMS Struct Reference	501
19.95.1 Field Documentation	501
19.95.1.1 pBaseG	501

19.95.1.2 pPassword
19.95.1.3 pPrimeP
19.95.1.4 pPublicData
19.95.1.5 pRandomA
19.95.1.6 pSubprimeQ
19.95.1.7 ulPAndGLen
19.95.1.8 ulPasswordLen
19.95.1.9 ulPublicDataLen
19.95.1.10 ulQLen
19.95.1.11 ulRandomLen
19.96 CK_SKIPJACK_RELAYX_PARAMS Struct Reference
19.96.1 Field Documentation
19.96.1.1 pNewPassword
19.96.1.2 pNewPublicData
19.96.1.3 pNewRandomA
19.96.1.4 pOldPassword
19.96.1.5 pOldPublicData
19.96.1.6 pOldRandomA
19.96.1.7 pOldWrappedX
19.96.1.8 ulNewPasswordLen
19.96.1.9 ulNewPublicDataLen
19.96.1.10 ulNewRandomLen
19.96.1.11 ulOldPasswordLen
19.96.1.12 ulOldPublicDataLen
19.96.1.13 ulOldRandomLen
19.96.1.14 ulOldWrappedXLen
19.97 CK_SLOT_INFO Struct Reference
19.97.1 Field Documentation
19.97.1.1 firmwareVersion
19.97.1.2 flags
19.97.1.3 hardwareVersion
19.97.1.4 manufacturerID
19.97.1.5 slotDescription
19.98 CK_SSL3_KEY_MAT_OUT Struct Reference
19.98.1 Field Documentation
19.98.1.1 hClientKey
19.98.1.2 hClientMacSecret
19.98.1.3 hServerKey
19.98.1.4 hServerMacSecret
19.98.1.5 pIVClient
19.98.1.6 pIVServer
19.99 CK SSL3 KEY MAT PARAMS Struct Reference 50

19.99.1 Field Documentation	507
19.99.1.1 blsExport	507
19.99.1.2 pReturnedKeyMaterial	507
19.99.1.3 RandomInfo	508
19.99.1.4 ullVSizeInBits	508
19.99.1.5 ulKeySizeInBits	508
19.99.1.6 ulMacSizeInBits	508
19.100 CK_SSL3_MASTER_KEY_DERIVE_PARAMS Struct Reference	508
19.100.1 Field Documentation	508
19.100.1.1 pVersion	508
19.100.1.2 RandomInfo	509
19.101 CK_SSL3_RANDOM_DATA Struct Reference	509
19.101.1 Field Documentation	509
19.101.1.1 pClientRandom	509
19.101.1.2 pServerRandom	509
19.101.1.3 ulClientRandomLen	509
19.101.1.4 ulServerRandomLen	509
19.102 CK_TLS12_KEY_MAT_PARAMS Struct Reference	510
19.102.1 Field Documentation	510
19.102.1.1 blsExport	510
19.102.1.2 pReturnedKeyMaterial	510
19.102.1.3 prfHashMechanism	510
19.102.1.4 RandomInfo	510
19.102.1.5 ullVSizeInBits	510
19.102.1.6 ulKeySizeInBits	511
19.102.1.7 ulMacSizeInBits	511
19.103 CK_TLS12_MASTER_KEY_DERIVE_PARAMS Struct Reference	511
19.103.1 Field Documentation	511
19.103.1.1 prfHashMechanism	511
19.103.1.2 pVersion	511
19.103.1.3 RandomInfo	511
19.104 CK_TLS_KDF_PARAMS Struct Reference	511
19.104.1 Field Documentation	512
19.104.1.1 pContextData	512
19.104.1.2 pLabel	512
19.104.1.3 prfMechanism	512
19.104.1.4 RandomInfo	512
19.104.1.5 ulContextDataLength	512
19.104.1.6 ulLabelLength	512
19.105 CK_TLS_MAC_PARAMS Struct Reference	513
19.105.1 Field Documentation	513
19 105 1 1 prfHashMechanism	513

19.105.1.2 ulMacLength
19.105.1.3 ulServerOrClient
19.106 CK_TLS_PRF_PARAMS Struct Reference
19.106.1 Field Documentation
19.106.1.1 pLabel
19.106.1.2 pOutput
19.106.1.3 pSeed
19.106.1.4 pulOutputLen
19.106.1.5 ulLabelLen
19.106.1.6 ulSeedLen
19.107 CK_TOKEN_INFO Struct Reference
19.107.1 Field Documentation
19.107.1.1 firmwareVersion
19.107.1.2 flags
19.107.1.3 hardwareVersion
19.107.1.4 label
19.107.1.5 manufacturerID
19.107.1.6 model
19.107.1.7 serialNumber
19.107.1.8 ulFreePrivateMemory
19.107.1.9 ulFreePublicMemory
19.107.1.10 ulMaxPinLen
19.107.1.11 ulMaxRwSessionCount
19.107.1.12 ulMaxSessionCount
19.107.1.13 ulMinPinLen
19.107.1.14 ulRwSessionCount
19.107.1.15 ulSessionCount
19.107.1.16 ulTotalPrivateMemory
19.107.1.17 ulTotalPublicMemory
19.107.1.18 utcTime
19.108 CK_VERSION Struct Reference
19.108.1 Field Documentation
19.108.1.1 major
19.108.1.2 minor
19.109 CK_WTLS_KEY_MAT_OUT Struct Reference
19.109.1 Field Documentation
19.109.1.1 hKey
19.109.1.2 hMacSecret
19.109.1.3 plV
19.110 CK_WTLS_KEY_MAT_PARAMS Struct Reference
19.110.1 Field Documentation
19.110.1.1 blsExport

19.110.1.2 DigestMechanism	519
19.110.1.3 pReturnedKeyMaterial	519
19.110.1.4 RandomInfo	519
19.110.1.5 ullVSizeInBits	520
19.110.1.6 ulKeySizeInBits	520
19.110.1.7 ulMacSizeInBits	520
19.110.1.8 ulSequenceNumber	520
19.111 CK_WTLS_MASTER_KEY_DERIVE_PARAMS Struct Reference	520
19.111.1 Field Documentation	520
19.111.1.1 DigestMechanism	520
19.111.1.2 pVersion	521
19.111.1.3 RandomInfo	521
19.112 CK_WTLS_PRF_PARAMS Struct Reference	521
19.112.1 Field Documentation	521
19.112.1.1 DigestMechanism	521
19.112.1.2 pLabel	521
19.112.1.3 pOutput	521
19.112.1.4 pSeed	522
19.112.1.5 pulOutputLen	522
19.112.1.6 ulLabelLen	522
19.112.1.7 ulSeedLen	522
19.113 CK_WTLS_RANDOM_DATA Struct Reference	522
19.113.1 Field Documentation	522
19.113.1.1 pClientRandom	522
19.113.1.2 pServerRandom	523
19.113.1.3 ulClientRandomLen	523
19.113.1.4 ulServerRandomLen	523
19.114 CK_X9_42_DH1_DERIVE_PARAMS Struct Reference	523
19.114.1 Field Documentation	523
19.114.1.1 kdf	523
19.114.1.2 pOtherInfo	523
19.114.1.3 pPublicData	524
19.114.1.4 ulOtherInfoLen	524
19.114.1.5 ulPublicDataLen	524
19.115 CK_X9_42_DH2_DERIVE_PARAMS Struct Reference	524
19.115.1 Field Documentation	524
19.115.1.1 hPrivateData	524
19.115.1.2 kdf	525
19.115.1.3 pOtherInfo	525
19.115.1.4 pPublicData	525
19.115.1.5 pPublicData2	525
19.115.1.6.ulOtherInfoLen	525

19.115.1./ ulPrivateDataLen	25
19.115.1.8 ulPublicDataLen	25
19.115.1.9 ulPublicDataLen2	25
19.116 CK_X9_42_MQV_DERIVE_PARAMS Struct Reference	26
19.116.1 Field Documentation	26
19.116.1.1 hPrivateData	26
19.116.1.2 kdf	26
19.116.1.3 pOtherInfo	26
19.116.1.4 pPublicData	26
19.116.1.5 pPublicData2	27
19.116.1.6 publicKey	27
19.116.1.7 ulOtherInfoLen	27
19.116.1.8 ulPrivateDataLen	27
19.116.1.9 ulPublicDataLen	27
19.116.1.10 ulPublicDataLen2	27
19.117 CL_HashContext Struct Reference	27
19.117.1 Field Documentation	28
19.117.1.1 buf	28
19.117.1.2 byteCount	28
19.117.1.3 byteCountHi	28
19.117.1.4 h	28
19.118 hw_sha256_ctx Struct Reference	28
19.118.1 Field Documentation	28
19.118.1.1 block	29
19.118.1.2 block_size	29
19.118.1.3 total_msg_size	29
19.119 i2c_sam0_instance Struct Reference	29
19.119.1 Field Documentation	29
19.119.1.1 change_baudrate	29
19.119.1.2 i2c_instance	29
19.120 i2c_sam_instance Struct Reference	30
19.120.1 Field Documentation	30
19.120.1.1 change_baudrate	30
19.120.1.2 i2c_instance	30
19.121 i2c_start_instance Struct Reference	30
19.121.1 Field Documentation	30
19.121.1.1 change_baudrate	30
19.121.1.2 i2c_descriptor	31
19.122 memory_parameters Struct Reference	31
19.122.1 Field Documentation	31
19.122.1.1 memory_size	31
19.122.1.2 reserved	31

19.122.1.3 signature	531
19.122.1.4 start_address	531
19.122.1.5 version_info	532
19.123 secure_boot_config_bits Struct Reference	532
19.123.1 Field Documentation	532
19.123.1.1 secure_boot_mode	532
19.123.1.2 secure_boot_persistent_enable	532
19.123.1.3 secure_boot_pub_key	532
19.123.1.4 secure_boot_rand_nonce	532
19.123.1.5 secure_boot_reserved1	533
19.123.1.6 secure_boot_reserved2	533
19.123.1.7 secure_boot_sig_dig	533
19.124 secure_boot_parameters Struct Reference	533
19.124.1 Field Documentation	533
19.124.1.1 app_digest	533
19.124.1.2 memory_params	533
19.124.1.3 s_sha_context	534
19.125 sw_sha256_ctx Struct Reference	534
19.125.1 Field Documentation	534
19.125.1.1 block	534
19.125.1.2 block_size	534
19.125.1.3 hash	534
19.125.1.4 total_msg_size	535
19.126 tng_cert_map_element Struct Reference	535
19.126.1 Field Documentation	535
19.126.1.1 cert_def	535
19.126.1.2 otpcode	535
	537
. –	537
20.1.1 Detailed Description	
	538
20.1.2.1 sha206a_authenticate()	
20.1.2.2 sha206a_check_dk_useflag_validity()	
20.1.2.3 sha206a_check_pk_useflag_validity()	
20.1.2.4 sha206a_diversify_parent_key()	
	540
	540
	540
20.1.2.8 sha206a_get_dk_update_count()	
20.1.2.9 sha206a_get_dk_useflag_count()	
20.1.2.10 sha206a_get_pk_useflag_count()	541

20.1.2.11 Shazooa_read_data_store()	+2
20.1.2.12 sha206a_verify_device_consumption()	42
20.1.2.13 sha206a_write_data_store()	43
20.2 api_206a.h File Reference	43
20.2.1 Detailed Description	14
20.2.2 Macro Definition Documentation	14
20.2.2.1 ATCA_SHA206A_DKEY_CONSUMPTION_MASK	14
20.2.2.2 ATCA_SHA206A_PKEY_CONSUMPTION_MASK	45
20.2.2.3 ATCA_SHA206A_SYMMETRIC_KEY_ID_SLOT	45
20.2.2.4 ATCA_SHA206A_ZONE_WRITE_LOCK	45
20.2.3 Enumeration Type Documentation	45
20.2.3.1 anonymous enum	45
20.2.4 Function Documentation	45
20.2.4.1 sha206a_authenticate()	45
20.2.4.2 sha206a_check_dk_useflag_validity()	46
20.2.4.3 sha206a_check_pk_useflag_validity()	46
20.2.4.4 sha206a_diversify_parent_key()	17
20.2.4.5 sha206a_generate_challenge_response_pair()	47
20.2.4.6 sha206a_generate_derive_key()	47
20.2.4.7 sha206a_get_data_store_lock_status()	48
20.2.4.8 sha206a_get_dk_update_count()	48
20.2.4.9 sha206a_get_dk_useflag_count()	49
20.2.4.10 sha206a_get_pk_useflag_count()	49
20.2.4.11 sha206a_read_data_store()	49
20.2.4.12 sha206a_verify_device_consumption()	50
20.2.4.13 sha206a_write_data_store()	50
20.3 atca_basic.c File Reference	51
20.3.1 Detailed Description	57
20.3.2 Variable Documentation	57
20.3.2.1 _gDevice	57
20.3.2.2 atca_version	57
20.4 atca_basic.h File Reference	57
20.4.1 Detailed Description	34
20.5 atca_bool.h File Reference	35
20.5.1 Detailed Description	35
20.6 atca_cfgs.c File Reference	35
20.6.1 Detailed Description	35
20.7 atca_cfgs.h File Reference	35
20.7.1 Detailed Description	36
20.7.2 Variable Documentation	36
20.7.2.1 cfg_ateccx08a_i2c_default	36
20.7.2.2 cfg_ateccx08a_kitcdc_default	

20.7.2.3 cfg_ateccx08a_kithid_default	. 567
20.7.2.4 cfg_ateccx08a_swi_default	. 567
20.7.2.5 cfg_atsha20xa_i2c_default	. 567
20.7.2.6 cfg_atsha20xa_kitcdc_default	. 567
20.7.2.7 cfg_atsha20xa_kithid_default	. 567
20.7.2.8 cfg_atsha20xa_swi_default	. 567
20.8 atca_command.c File Reference	. 568
20.8.1 Detailed Description	. 568
20.9 atca_command.h File Reference	. 568
20.9.1 Detailed Description	. 569
20.10 atca_compiler.h File Reference	. 569
20.10.1 Detailed Description	. 569
20.11 atca_crypto_hw_aes.h File Reference	. 569
20.11.1 Detailed Description	. 570
20.11.2 Typedef Documentation	. 570
20.11.2.1 atca_aes_cbc_ctx_t	. 570
20.11.2.2 atca_aes_cmac_ctx_t	. 570
20.11.2.3 atca_aes_ctr_ctx_t	. 570
20.12 atca_crypto_hw_aes_cbc.c File Reference	. 570
20.12.1 Detailed Description	. 571
20.13 atca_crypto_hw_aes_cmac.c File Reference	. 571
20.13.1 Detailed Description	. 572
20.14 atca_crypto_hw_aes_ctr.c File Reference	. 572
20.14.1 Detailed Description	. 573
20.15 atca_crypto_sw.h File Reference	. 573
20.15.1 Detailed Description	. 574
20.15.2 Macro Definition Documentation	. 574
20.15.2.1 ATCA_SHA1_DIGEST_SIZE	. 574
20.15.2.2 ATCA_SHA2_256_BLOCK_SIZE	. 575
20.15.2.3 ATCA_SHA2_256_DIGEST_SIZE	. 575
20.15.2.4 MBEDTLS_CMAC_C	. 575
20.15.3 Typedef Documentation	. 575
20.15.3.1 atcac_aes_cmac_ctx	. 575
20.15.3.2 atcac_aes_gcm_ctx	. 575
20.15.3.3 atcac_hmac_sha256_ctx	. 575
20.15.3.4 atcac_sha1_ctx	. 575
20.15.3.5 atcac_sha2_256_ctx	. 576
20.15.4 Function Documentation	. 576
20.15.4.1 atcac_aes_cmac_finish()	. 576
20.15.4.2 atcac_aes_cmac_init()	. 576
20.15.4.3 atcac_aes_cmac_update()	. 576
20.15.4.4 atcac_aes_gcm_aad_update()	. 577

20.15.4.5 atcac_aes_gcm_decrypt_finish()	577
20.15.4.6 atcac_aes_gcm_decrypt_start()	577
20.15.4.7 atcac_aes_gcm_decrypt_update()	578
20.15.4.8 atcac_aes_gcm_encrypt_finish()	578
20.15.4.9 atcac_aes_gcm_encrypt_start()	578
20.15.4.10 atcac_aes_gcm_encrypt_update()	579
20.16 atca_crypto_sw_ecdsa.c File Reference	579
20.16.1 Detailed Description	579
20.17 atca_crypto_sw_ecdsa.h File Reference	579
20.17.1 Detailed Description	580
20.18 atca_crypto_sw_rand.c File Reference	580
20.18.1 Detailed Description	580
20.19 atca_crypto_sw_rand.h File Reference	580
20.19.1 Detailed Description	581
20.20 atca_crypto_sw_sha1.c File Reference	581
20.20.1 Detailed Description	581
20.21 atca_crypto_sw_sha1.h File Reference	581
20.21.1 Detailed Description	582
20.22 atca_crypto_sw_sha2.c File Reference	582
20.22.1 Detailed Description	582
20.23 atca_crypto_sw_sha2.h File Reference	582
20.23.1 Detailed Description	583
20.24 atca_debug.c File Reference	583
20.24.1 Detailed Description	584
20.24.2 Function Documentation	584
20.24.2.1 atca_trace()	584
20.24.2.2 atca_trace_config()	584
20.24.2.3 atca_trace_msg()	584
20.24.3 Variable Documentation	584
20.24.3.1 g_trace_fp	584
20.25 atca_debug.h File Reference	584
20.25.1 Function Documentation	585
20.25.1.1 atca_trace()	585
20.25.1.2 atca_trace_config()	585
20.25.1.3 atca_trace_msg()	585
20.26 atca_device.c File Reference	585
20.26.1 Detailed Description	586
20.27 atca_device.h File Reference	586
20.27.1 Detailed Description	589
20.28 atca_devtypes.h File Reference	589
20.28.1 Detailed Description	589
20.29 atca_hal.c File Reference	590

20.29.1 Detailed Description		590
20.30 atca_hal.h File Reference		590
20.30.1 Detailed Description		591
20.31 atca_helpers.c File Reference		591
20.31.1 Detailed Description		593
20.31.2 Macro Definition Documentation		593
20.31.2.1 B64_IS_EQUAL		593
20.31.2.2 B64_IS_INVALID		593
20.31.3 Function Documentation		593
20.31.3.1 atcab_base64decode()		593
20.31.3.2 atcab_base64decode_()		594
20.31.3.3 atcab_base64encode()		594
20.31.3.4 atcab_base64encode_()		595
20.31.3.5 atcab_bin2hex()		595
20.31.3.6 atcab_bin2hex_()		596
20.31.3.7 atcab_hex2bin()		596
20.31.3.8 atcab_hex2bin_()		597
20.31.3.9 atcab_memset_s()		597
20.31.3.10 atcab_reversal()		597
20.31.3.11 base64Char()		597
20.31.3.12 base64Index()		599
20.31.3.13 isAlpha()		599
20.31.3.14 isBase64()		600
20.31.3.15 isBase64Digit()		600
20.31.3.16 isDigit()		600
20.31.3.17 isHex()		601
20.31.3.18 isHexAlpha()		601
20.31.3.19 isHexDigit()		601
20.31.3.20 isWhiteSpace()		602
20.31.3.21 packHex()		602
20.31.4 Variable Documentation		603
20.31.4.1 atcab_b64rules_default		603
20.31.4.2 atcab_b64rules_mime		603
20.31.4.3 atcab_b64rules_urlsafe		603
20.32 atca_helpers.h File Reference		603
20.32.1 Detailed Description		604
20.32.2 Function Documentation		604
20.32.2.1 atcab_base64decode()		605
20.32.2.2 atcab_base64decode_()		605
20.32.2.3 atcab_base64encode()		605
20.32.2.4 atcab_base64encode_()		606
20.32.2.5 atcab_bin2hex()		606

20.32.2.6 atcab_bin2hex_()	 . 607
20.32.2.7 atcab_hex2bin()	 . 607
20.32.2.8 atcab_hex2bin_()	 . 608
20.32.2.9 atcab_memset_s()	 . 608
20.32.2.10 atcab_printbin_label()	 . 608
20.32.2.11 atcab_printbin_sp()	 . 608
20.32.2.12 atcab_reversal()	 . 608
20.32.2.13 base64Char()	 . 609
20.32.2.14 base64Index()	 . 609
20.32.2.15 isAlpha()	 . 610
20.32.2.16 isBase64()	 . 610
20.32.2.17 isBase64Digit()	 . 610
20.32.2.18 isDigit()	 . 611
20.32.2.19 isHex()	 . 611
20.32.2.20 isHexAlpha()	 . 612
20.32.2.21 isHexDigit()	 . 612
20.32.2.22 isWhiteSpace()	 . 612
20.32.2.23 packHex()	 . 613
20.32.3 Variable Documentation	 . 613
20.32.3.1 atcab_b64rules_default	 . 613
20.32.3.2 atcab_b64rules_mime	 . 613
20.32.3.3 atcab_b64rules_urlsafe	 . 613
20.33 atca_host.c File Reference	 . 614
20.33.1 Detailed Description	 . 615
20.34 atca_host.h File Reference	 . 615
20.34.1 Detailed Description	 . 618
20.35 atca_iface.c File Reference	 . 618
20.35.1 Detailed Description	 . 619
20.36 atca_iface.h File Reference	 . 619
20.36.1 Detailed Description	 . 620
20.37 atca_jwt.c File Reference	 . 621
20.37.1 Detailed Description	 . 621
20.38 atca_jwt.h File Reference	 . 621
20.38.1 Detailed Description	 . 622
20.39 atca_mbedtls_ecdh.c File Reference	 . 622
20.40 atca_mbedtls_ecdsa.c File Reference	 . 622
20.41 atca_mbedtls_wrap.c File Reference	 . 622
20.41.1 Detailed Description	 . 624
20.41.2 Macro Definition Documentation	 . 624
20.41.2.1 mbedtls_calloc	 . 624
20.41.2.2 mbedtls_free	 . 624
20.41.3 Function Documentation	 . 624

20.41.3.1 atca_mbedtls_cert_add()	24
20.41.3.2 atcac_aes_cmac_finish()	25
20.41.3.3 atcac_aes_cmac_init()	25
20.41.3.4 atcac_aes_cmac_update()	26
20.41.3.5 atcac_aes_gcm_aad_update()	26
20.41.3.6 atcac_aes_gcm_decrypt_finish()	26
20.41.3.7 atcac_aes_gcm_decrypt_start()	27
20.41.3.8 atcac_aes_gcm_decrypt_update()	27
20.41.3.9 atcac_aes_gcm_encrypt_finish()	28
20.41.3.10 atcac_aes_gcm_encrypt_start()	28
20.41.3.11 atcac_aes_gcm_encrypt_update()	29
20.41.3.12 atcac_sw_sha1_finish()	29
20.41.3.13 atcac_sw_sha2_256_finish()	30
20.42 atca_mbedtls_wrap.h File Reference	30
20.43 atca_openssl_interface.c File Reference	30
20.43.1 Detailed Description	32
20.43.2 Function Documentation	32
20.43.2.1 atcac_aes_cmac_finish()	32
20.43.2.2 atcac_aes_cmac_init()	32
20.43.2.3 atcac_aes_cmac_update()	33
20.43.2.4 atcac_aes_gcm_aad_update()	33
20.43.2.5 atcac_aes_gcm_decrypt_finish()	34
20.43.2.6 atcac_aes_gcm_decrypt_start()	34
20.43.2.7 atcac_aes_gcm_decrypt_update()	35
20.43.2.8 atcac_aes_gcm_encrypt_finish()	35
20.43.2.9 atcac_aes_gcm_encrypt_start()	35
20.43.2.10 atcac_aes_gcm_encrypt_update()	36
20.43.2.11 atcac_sw_sha1_finish()	36
20.43.2.12 atcac_sw_sha2_256_finish()	37
20.44 atca_start_config.h File Reference	37
20.45 atca_start_iface.h File Reference	37
20.46 atca_status.h File Reference	37
20.46.1 Detailed Description	38
20.46.2 Macro Definition Documentation	38
20.46.2.1 ATCA_STATUS_AUTH_BIT	38
20.46.3 Enumeration Type Documentation	38
20.46.3.1 ATCA_STATUS	38
20.47 atca_version.h File Reference	40
20.47.1 Detailed Description	40
20.47.2 Macro Definition Documentation	40
20.47.2.1 ATCA_LIBRARY_VERSION_BUILD	40
20 47 2 2 ATCA LIBRARY VERSION DATE 6	<b>4</b> 0

20.47.2.3 ATCA_LIBRARY_VERSION_MAJOR	641
20.47.2.4 ATCA_LIBRARY_VERSION_MINOR	641
20.48 atca_wolfssl_interface.c File Reference	641
20.48.1 Detailed Description	641
20.49 atcacert.h File Reference	641
20.49.1 Detailed Description	642
20.50 atcacert_client.c File Reference	642
20.50.1 Detailed Description	643
20.51 atcacert_client.h File Reference	643
20.51.1 Detailed Description	644
20.52 atcacert_date.c File Reference	644
20.52.1 Detailed Description	645
20.53 atcacert_date.h File Reference	645
20.53.1 Detailed Description	647
20.54 atcacert_def.c File Reference	647
20.54.1 Detailed Description	649
20.54.2 Macro Definition Documentation	649
20.54.2.1 ATCACERT_MAX	650
20.54.2.2 ATCACERT_MIN	650
20.55 atcacert_def.h File Reference	650
20.55.1 Detailed Description	653
20.55.2 Macro Definition Documentation	653
20.55.2.1 ATCA_MAX_TRANSFORMS	653
20.56 atcacert_der.c File Reference	654
20.56.1 Detailed Description	654
20.57 atcacert_der.h File Reference	654
20.57.1 Detailed Description	655
20.58 atcacert_host_hw.c File Reference	655
20.58.1 Detailed Description	656
20.59 atcacert_host_hw.h File Reference	656
20.59.1 Detailed Description	656
20.60 atcacert_host_sw.c File Reference	656
20.60.1 Detailed Description	657
20.61 atcacert_host_sw.h File Reference	657
20.61.1 Detailed Description	657
20.62 atcacert_pem.c File Reference	658
20.62.1 Detailed Description	658
20.62.2 Function Documentation	658
20.62.2.1 atcacert_decode_pem()	658
20.62.2.2 atcacert_decode_pem_cert()	659
20.62.2.3 atcacert_decode_pem_csr()	659
20.62.2.4 atcacert_encode_pem()	660

20.62.2.5 atcacert_encode_pem_cert()60	50
20.62.2.6 atcacert_encode_pem_csr()	31
20.63 atcacert_pem.h File Reference	31
20.63.1 Detailed Description	32
20.63.2 Macro Definition Documentation	32
20.63.2.1 PEM_CERT_BEGIN	32
20.63.2.2 PEM_CERT_END	32
20.63.2.3 PEM_CSR_BEGIN	33
20.63.2.4 PEM_CSR_END	33
20.63.3 Function Documentation	33
20.63.3.1 atcacert_decode_pem()	33
20.63.3.2 atcacert_decode_pem_cert()	33
20.63.3.3 atcacert_decode_pem_csr()	34
20.63.3.4 atcacert_encode_pem()	34
20.63.3.5 atcacert_encode_pem_cert()	35
20.63.3.6 atcacert_encode_pem_csr()	35
20.64 calib_aes.c File Reference	36
20.64.1 Detailed Description	36
20.65 calib_aes_gcm.c File Reference	37
20.65.1 Detailed Description	37
20.65.2 Macro Definition Documentation	38
20.65.2.1 RETURN	38
20.65.3 Function Documentation	38
20.65.3.1 calib_aes_gcm_aad_update()	38
20.65.3.2 calib_aes_gcm_decrypt_finish()	38
20.65.3.3 calib_aes_gcm_decrypt_update()	39
20.65.3.4 calib_aes_gcm_encrypt_finish()	39
20.65.3.5 calib_aes_gcm_encrypt_update()	70
20.65.3.6 calib_aes_gcm_init()	70
20.65.3.7 calib_aes_gcm_init_rand()	71
20.66 calib_aes_gcm.h File Reference	71
20.66.1 Detailed Description	72
20.67 calib_basic.c File Reference	72
20.67.1 Detailed Description	73
20.67.2 Macro Definition Documentation	73
20.67.2.1 MAX_BUSES	73
20.68 calib_basic.h File Reference	73
20.69 calib_checkmac.c File Reference	79
20.69.1 Detailed Description	79
20.70 calib_command.c File Reference	79
20.70.1 Detailed Description	31
20.70.2 Function Documentation	31

	20.70.2.1 atAES()	681
	20.70.2.2 atCalcCrc()	682
	20.70.2.3 atCheckCrc()	682
	20.70.2.4 atCheckMAC()	682
	20.70.2.5 atCounter()	683
	20.70.2.6 atCRC()	683
	20.70.2.7 atDeriveKey()	683
	20.70.2.8 atECDH()	684
	20.70.2.9 atGenDig()	684
	20.70.2.10 atGenKey()	684
	20.70.2.11 atHMAC()	685
	20.70.2.12 atInfo()	685
	20.70.2.13 atlsECCFamily()	686
	20.70.2.14 atlsSHAFamily()	686
	20.70.2.15 atKDF()	686
	20.70.2.16 atLock()	687
	20.70.2.17 atMAC()	687
	20.70.2.18 atNonce()	687
	20.70.2.19 atPause()	688
	20.70.2.20 atPrivWrite()	688
	20.70.2.21 atRandom()	689
	20.70.2.22 atRead()	689
	20.70.2.23 atSecureBoot()	689
	20.70.2.24 atSelfTest()	690
	20.70.2.25 atSHA()	690
	20.70.2.26 atSign()	690
	20.70.2.27 atUpdateExtra()	691
	20.70.2.28 atVerify()	691
	20.70.2.29 atWrite()	692
	20.70.2.30 isATCAError()	692
20.71 calib_c	command.h File Reference	692
20.71.1	Detailed Description	710
20.71.2	2 Macro Definition Documentation	711
	20.71.2.1 AES_COUNT	711
	20.71.2.2 AES_DATA_SIZE	711
	20.71.2.3 AES_INPUT_IDX	711
	20.71.2.4 AES_KEYID_IDX	711
	20.71.2.5 AES_MODE_DECRYPT	711
	20.71.2.6 AES_MODE_ENCRYPT	712
	20.71.2.7 AES_MODE_GFM	712
	20.71.2.8 AES_MODE_IDX	712
	20.71.2.9 AES_MODE_KEY_BLOCK_MASK	712

20.71.2.10 AES_MODE_KEY_BLOCK_POS	712
20.71.2.11 AES_MODE_MASK	712
20.71.2.12 AES_MODE_OP_MASK	713
20.71.2.13 AES_RSP_SIZE	713
20.71.2.14 ATCA_ADDRESS_MASK	713
20.71.2.15 ATCA_ADDRESS_MASK_CONFIG	713
20.71.2.16 ATCA_ADDRESS_MASK_OTP	713
20.71.2.17 ATCA_AES	713
20.71.2.18 ATCA_AES_GFM_SIZE	714
20.71.2.19 ATCA_AES_KEY_TYPE	714
20.71.2.20 ATCA_B283_KEY_TYPE	714
20.71.2.21 ATCA_BLOCK_SIZE	714
20.71.2.22 ATCA_CHECKMAC	714
20.71.2.23 ATCA_CHIPMODE_CLOCK_DIV_M0	714
20.71.2.24 ATCA_CHIPMODE_CLOCK_DIV_M1	715
20.71.2.25 ATCA_CHIPMODE_CLOCK_DIV_M2	715
20.71.2.26 ATCA_CHIPMODE_CLOCK_DIV_MASK	715
20.71.2.27 ATCA_CHIPMODE_I2C_ADDRESS_FLAG	715
20.71.2.28 ATCA_CHIPMODE_OFFSET	715
20.71.2.29 ATCA_CHIPMODE_TTL_ENABLE_FLAG	715
20.71.2.30 ATCA_CHIPMODE_WATCHDOG_LONG	716
20.71.2.31 ATCA_CHIPMODE_WATCHDOG_MASK	716
20.71.2.32 ATCA_CHIPMODE_WATCHDOG_SHORT	716
20.71.2.33 ATCA_CMD_SIZE_MAX	716
20.71.2.34 ATCA_CMD_SIZE_MIN	716
20.71.2.35 ATCA_COUNT_IDX	716
20.71.2.36 ATCA_COUNT_SIZE	717
20.71.2.37 ATCA_COUNTER	717
20.71.2.38 ATCA_CRC_SIZE	717
20.71.2.39 ATCA_DATA_IDX	717
20.71.2.40 ATCA_DATA_SIZE	717
20.71.2.41 ATCA_DERIVE_KEY	717
20.71.2.42 ATCA_ECC_CONFIG_SIZE	718
20.71.2.43 ATCA_ECDH	718
20.71.2.44 ATCA_GENDIG	718
20.71.2.45 ATCA_GENKEY	718
20.71.2.46 ATCA_HMAC	
20.71.2.47 ATCA_INFO	
20.71.2.48 ATCA_K283_KEY_TYPE	
20.71.2.49 ATCA_KDF	719
20.71.2.50 ATCA_KEY_COUNT	719
20.71.2.51 ATCA KEY ID MAX	710

20.71.2.52 AI CA_KEY_SIZE
20.71.2.53 ATCA_LOCK
20.71.2.54 ATCA_LOCKED
20.71.2.55 ATCA_MAC
20.71.2.56 ATCA_NONCE
20.71.2.57 ATCA_OPCODE_IDX
20.71.2.58 ATCA_OTP_BLOCK_MAX
20.71.2.59 ATCA_OTP_SIZE
20.71.2.60 ATCA_P256_KEY_TYPE
20.71.2.61 ATCA_PACKET_OVERHEAD
20.71.2.62 ATCA_PARAM1_IDX
20.71.2.63 ATCA_PARAM2_IDX
20.71.2.64 ATCA_PAUSE
20.71.2.65 ATCA_PRIV_KEY_SIZE
20.71.2.66 ATCA_PRIVWRITE
20.71.2.67 ATCA_PUB_KEY_PAD
20.71.2.68 ATCA_PUB_KEY_SIZE
20.71.2.69 ATCA_RANDOM
20.71.2.70 ATCA_READ
20.71.2.71 ATCA_RSP_DATA_IDX
20.71.2.72 ATCA_RSP_SIZE_16
20.71.2.73 ATCA_RSP_SIZE_32
20.71.2.74 ATCA_RSP_SIZE_4
20.71.2.75 ATCA_RSP_SIZE_64
20.71.2.76 ATCA_RSP_SIZE_72
20.71.2.77 ATCA_RSP_SIZE_MAX
20.71.2.78 ATCA_RSP_SIZE_MIN
20.71.2.79 ATCA_RSP_SIZE_VAL
20.71.2.80 ATCA_SECUREBOOT
20.71.2.81 ATCA_SELFTEST
20.71.2.82 ATCA_SERIAL_NUM_SIZE
20.71.2.83 ATCA_SHA
20.71.2.84 ATCA_SHA_CONFIG_SIZE
20.71.2.85 ATCA_SHA_DIGEST_SIZE
20.71.2.86 ATCA_SHA_KEY_TYPE
20.71.2.87 ATCA_SIG_SIZE
20.71.2.88 ATCA_SIGN
20.71.2.89 ATCA_TEMPKEY_KEYID
20.71.2.90 ATCA_UNLOCKED
20.71.2.91 ATCA_UPDATE_EXTRA
20.71.2.92 ATCA_VERIFY
20.71.2.93 ATCA_WORD_SIZE

20.71.2.94 ATCA_WRITE	726
20.71.2.95 ATCA_ZONE_ENCRYPTED	726
20.71.2.96 ATCA_ZONE_MASK	727
20.71.2.97 ATCA_ZONE_READWRITE_32	727
20.71.2.98 CHECKMAC_CLIENT_CHALLENGE_IDX	727
20.71.2.99 CHECKMAC_CLIENT_CHALLENGE_SIZE	727
20.71.2.100 CHECKMAC_CLIENT_COMMAND_SIZE	727
20.71.2.101 CHECKMAC_CLIENT_RESPONSE_IDX	727
20.71.2.102 CHECKMAC_CLIENT_RESPONSE_SIZE	728
20.71.2.103 CHECKMAC_CMD_MATCH	728
20.71.2.104 CHECKMAC_CMD_MISMATCH	728
20.71.2.105 CHECKMAC_COUNT	728
20.71.2.106 CHECKMAC_DATA_IDX	728
20.71.2.107 CHECKMAC_KEYID_IDX	728
20.71.2.108 CHECKMAC_MODE_BLOCK1_TEMPKEY	729
20.71.2.109 CHECKMAC_MODE_BLOCK2_TEMPKEY	729
20.71.2.110 CHECKMAC_MODE_CHALLENGE	729
20.71.2.111 CHECKMAC_MODE_IDX	729
20.71.2.112 CHECKMAC_MODE_INCLUDE_OTP_64	729
20.71.2.113 CHECKMAC_MODE_MASK	729
20.71.2.114 CHECKMAC_MODE_SOURCE_FLAG_MATCH	730
20.71.2.115 CHECKMAC_OTHER_DATA_SIZE	730
20.71.2.116 CHECKMAC_RSP_SIZE	730
20.71.2.117 CMD_STATUS_BYTE_COMM	730
20.71.2.118 CMD_STATUS_BYTE_ECC	730
20.71.2.119 CMD_STATUS_BYTE_EXEC	730
20.71.2.120 CMD_STATUS_BYTE_PARSE	731
20.71.2.121 CMD_STATUS_SUCCESS	731
20.71.2.122 CMD_STATUS_WAKEUP	731
20.71.2.123 COUNTER_COUNT	731
20.71.2.124 COUNTER_KEYID_IDX	731
20.71.2.125 COUNTER_MAX_VALUE	731
20.71.2.126 COUNTER_MODE_IDX	732
20.71.2.127 COUNTER_MODE_INCREMENT	732
20.71.2.128 COUNTER_MODE_MASK	732
20.71.2.129 COUNTER_MODE_READ	732
20.71.2.130 COUNTER_RSP_SIZE	732
20.71.2.131 COUNTER_SIZE	732
20.71.2.132 DERIVE_KEY_COUNT_LARGE	733
20.71.2.133 DERIVE_KEY_COUNT_SMALL	733
20.71.2.134 DERIVE_KEY_MAC_IDX	733
20.71.2.135 DERIVE KEY MAC SIZE	733

20.71.2.136 DERIVE_KEY_MODE
20.71.2.137 DERIVE_KEY_RANDOM_FLAG
20.71.2.138 DERIVE_KEY_RANDOM_IDX
20.71.2.139 DERIVE_KEY_RSP_SIZE
20.71.2.140 DERIVE_KEY_TARGETKEY_IDX
20.71.2.141 ECDH_COUNT
20.71.2.142 ECDH_KEY_SIZE
20.71.2.143 ECDH_MODE_COPY_COMPATIBLE
20.71.2.144 ECDH_MODE_COPY_EEPROM_SLOT
20.71.2.145 ECDH_MODE_COPY_MASK
20.71.2.146 ECDH_MODE_COPY_OUTPUT_BUFFER
20.71.2.147 ECDH_MODE_COPY_TEMP_KEY
20.71.2.148 ECDH_MODE_OUTPUT_CLEAR
20.71.2.149 ECDH_MODE_OUTPUT_ENC
20.71.2.150 ECDH_MODE_OUTPUT_MASK
20.71.2.151 ECDH_MODE_SOURCE_EEPROM_SLOT
20.71.2.152 ECDH_MODE_SOURCE_MASK
20.71.2.153 ECDH_MODE_SOURCE_TEMPKEY
20.71.2.154 ECDH_PREFIX_MODE
20.71.2.155 ECDH_RSP_SIZE
20.71.2.156 GENDIG_COUNT
20.71.2.157 GENDIG_DATA_IDX
20.71.2.158 GENDIG_KEYID_IDX
20.71.2.159 GENDIG_RSP_SIZE
20.71.2.160 GENDIG_ZONE_CONFIG
20.71.2.161 GENDIG_ZONE_COUNTER
20.71.2.162 GENDIG_ZONE_DATA
20.71.2.163 GENDIG_ZONE_IDX
20.71.2.164 GENDIG_ZONE_KEY_CONFIG
20.71.2.165 GENDIG_ZONE_OTP
20.71.2.166 GENDIG_ZONE_SHARED_NONCE
20.71.2.167 GENKEY_COUNT
20.71.2.168 GENKEY_COUNT_DATA
20.71.2.169 GENKEY_DATA_IDX
20.71.2.170 GENKEY_KEYID_IDX
20.71.2.171 GENKEY_MODE_DIGEST
20.71.2.172 GENKEY_MODE_IDX
20.71.2.173 GENKEY_MODE_MASK
20.71.2.174 GENKEY_MODE_PRIVATE
20.71.2.175 GENKEY_MODE_PUBKEY_DIGEST
20.71.2.176 GENKEY_MODE_PUBLIC
20.71.2.177 GENKEY OTHER DATA SIZE 740

20.71.2.178 GENKEY_PRIVATE_TO_TEMPKEY
20.71.2.179 GENKEY_RSP_SIZE_LONG
20.71.2.180 GENKEY_RSP_SIZE_SHORT
20.71.2.181 HMAC_COUNT
20.71.2.182 HMAC_DIGEST_SIZE
20.71.2.183 HMAC_KEYID_IDX
20.71.2.184 HMAC_MODE_FLAG_FULLSN
20.71.2.185 HMAC_MODE_FLAG_OTP64
20.71.2.186 HMAC_MODE_FLAG_OTP88
20.71.2.187 HMAC_MODE_FLAG_TK_NORAND
20.71.2.188 HMAC_MODE_FLAG_TK_RAND
20.71.2.189 HMAC_MODE_IDX
20.71.2.190 HMAC_MODE_MASK
20.71.2.191 HMAC_RSP_SIZE
20.71.2.192 INFO_COUNT
20.71.2.193 INFO_DRIVER_STATE_MASK
20.71.2.194 INFO_MODE_GPIO
20.71.2.195 INFO_MODE_KEY_VALID
20.71.2.196 INFO_MODE_MAX
20.71.2.197 INFO_MODE_REVISION
20.71.2.198 INFO_MODE_STATE
20.71.2.199 INFO_MODE_VOL_KEY_PERMIT
20.71.2.200 INFO_NO_STATE
20.71.2.201 INFO_OUTPUT_STATE_MASK
20.71.2.202 INFO_PARAM1_IDX
20.71.2.203 INFO_PARAM2_IDX
20.71.2.204 INFO_PARAM2_LATCH_CLEAR
20.71.2.205 INFO_PARAM2_LATCH_SET
20.71.2.206 INFO_PARAM2_SET_LATCH_STATE
20.71.2.207 INFO_RSP_SIZE
20.71.2.208 INFO_SIZE
20.71.2.209 KDF_DETAILS_AES_KEY_LOC_MASK
20.71.2.210 KDF_DETAILS_HKDF_MSG_LOC_INPUT
20.71.2.211 KDF_DETAILS_HKDF_MSG_LOC_IV
20.71.2.212 KDF_DETAILS_HKDF_MSG_LOC_MASK
20.71.2.213 KDF_DETAILS_HKDF_MSG_LOC_SLOT
20.71.2.214 KDF_DETAILS_HKDF_MSG_LOC_TEMPKEY
20.71.2.215 KDF_DETAILS_HKDF_ZERO_KEY
20.71.2.216 KDF_DETAILS_IDX
20.71.2.217 KDF_DETAILS_PRF_AEAD_MASK
20.71.2.218 KDF_DETAILS_PRF_AEAD_MODE0
20.71.2.219 KDF DETAILS PRE AFAD MODE1 747

20.71.2.220 KDF_DETAILS_PRF_KEY_LEN_16	47
20.71.2.221 KDF_DETAILS_PRF_KEY_LEN_32	47
20.71.2.222 KDF_DETAILS_PRF_KEY_LEN_48	47
20.71.2.223 KDF_DETAILS_PRF_KEY_LEN_64	47
20.71.2.224 KDF_DETAILS_PRF_KEY_LEN_MASK	47
20.71.2.225 KDF_DETAILS_PRF_TARGET_LEN_32	48
20.71.2.226 KDF_DETAILS_PRF_TARGET_LEN_64	48
20.71.2.227 KDF_DETAILS_PRF_TARGET_LEN_MASK	48
20.71.2.228 KDF_DETAILS_SIZE	48
20.71.2.229 KDF_KEYID_IDX	48
20.71.2.230 KDF_MESSAGE_IDX	48
20.71.2.231 KDF_MODE_ALG_AES	49
20.71.2.232 KDF_MODE_ALG_HKDF	49
20.71.2.233 KDF_MODE_ALG_MASK	49
20.71.2.234 KDF_MODE_ALG_PRF	49
20.71.2.235 KDF_MODE_IDX	49
20.71.2.236 KDF_MODE_SOURCE_ALTKEYBUF	49
20.71.2.237 KDF_MODE_SOURCE_MASK	50
20.71.2.238 KDF_MODE_SOURCE_SLOT	50
20.71.2.239 KDF_MODE_SOURCE_TEMPKEY	50
20.71.2.240 KDF_MODE_SOURCE_TEMPKEY_UP	50
20.71.2.241 KDF_MODE_TARGET_ALTKEYBUF	50
20.71.2.242 KDF_MODE_TARGET_MASK	50
20.71.2.243 KDF_MODE_TARGET_OUTPUT	51
20.71.2.244 KDF_MODE_TARGET_OUTPUT_ENC	51
20.71.2.245 KDF_MODE_TARGET_SLOT	51
20.71.2.246 KDF_MODE_TARGET_TEMPKEY	51
20.71.2.247 KDF_MODE_TARGET_TEMPKEY_UP	51
20.71.2.248 LOCK_COUNT	51
20.71.2.249 LOCK_RSP_SIZE	52
20.71.2.250 LOCK_SUMMARY_IDX	52
20.71.2.251 LOCK_ZONE_CONFIG	52
20.71.2.252 LOCK_ZONE_DATA	52
20.71.2.253 LOCK_ZONE_DATA_SLOT	52
20.71.2.254 LOCK_ZONE_IDX	52
20.71.2.255 LOCK_ZONE_MASK	53
20.71.2.256 LOCK_ZONE_NO_CRC	53
20.71.2.257 MAC_CHALLENGE_IDX	53
20.71.2.258 MAC_CHALLENGE_SIZE	53
20.71.2.259 MAC_COUNT_LONG	53
20.71.2.260 MAC_COUNT_SHORT	53
20.71.2.261 MAC KEVID IDX	54

20./1.2.262 MAC_MODE_BLOCK1_TEMPREY
20.71.2.263 MAC_MODE_BLOCK2_TEMPKEY
20.71.2.264 MAC_MODE_CHALLENGE
20.71.2.265 MAC_MODE_IDX
20.71.2.266 MAC_MODE_INCLUDE_OTP_64
20.71.2.267 MAC_MODE_INCLUDE_OTP_88
20.71.2.268 MAC_MODE_INCLUDE_SN
20.71.2.269 MAC_MODE_MASK
20.71.2.270 MAC_MODE_PASSTHROUGH
20.71.2.271 MAC_MODE_PTNONCE_TEMPKEY
20.71.2.272 MAC_MODE_SOURCE_FLAG_MATCH
20.71.2.273 MAC_RSP_SIZE
20.71.2.274 MAC_SIZE
20.71.2.275 NONCE_COUNT_LONG
20.71.2.276 NONCE_COUNT_LONG_64
20.71.2.277 NONCE_COUNT_SHORT
20.71.2.278 NONCE_INPUT_IDX
20.71.2.279 NONCE_MODE_IDX
20.71.2.280 NONCE_MODE_INPUT_LEN_32
20.71.2.281 NONCE_MODE_INPUT_LEN_64
20.71.2.282 NONCE_MODE_INPUT_LEN_MASK
20.71.2.283 NONCE_MODE_INVALID
20.71.2.284 NONCE_MODE_MASK
20.71.2.285 NONCE_MODE_NO_SEED_UPDATE
20.71.2.286 NONCE_MODE_PASSTHROUGH
20.71.2.287 NONCE_MODE_SEED_UPDATE
20.71.2.288 NONCE_MODE_TARGET_ALTKEYBUF
20.71.2.289 NONCE_MODE_TARGET_MASK
20.71.2.290 NONCE_MODE_TARGET_MSGDIGBUF
20.71.2.291 NONCE_MODE_TARGET_TEMPKEY
20.71.2.292 NONCE_NUMIN_SIZE
20.71.2.293 NONCE_NUMIN_SIZE_PASSTHROUGH
20.71.2.294 NONCE_PARAM2_IDX
20.71.2.295 NONCE_RSP_SIZE_LONG
20.71.2.296 NONCE_RSP_SIZE_SHORT
20.71.2.297 NONCE_ZERO_CALC_MASK
20.71.2.298 NONCE_ZERO_CALC_RANDOM
20.71.2.299 NONCE_ZERO_CALC_TEMPKEY
20.71.2.300 OUTNONCE_SIZE
20.71.2.301 PAUSE_COUNT
20.71.2.302 PAUSE_PARAM2_IDX
20.71.2.303 PAUSE_RSP_SIZE

20.71.2.304 PAUSE_SELECT_IDX
20.71.2.305 PRIVWRITE_COUNT
20.71.2.306 PRIVWRITE_KEYID_IDX
20.71.2.307 PRIVWRITE_MAC_IDX
20.71.2.308 PRIVWRITE_MODE_ENCRYPT
20.71.2.309 PRIVWRITE_RSP_SIZE
20.71.2.310 PRIVWRITE_VALUE_IDX
20.71.2.311 PRIVWRITE_ZONE_IDX
20.71.2.312 PRIVWRITE_ZONE_MASK
20.71.2.313 RANDOM_COUNT
20.71.2.314 RANDOM_MODE_IDX
20.71.2.315 RANDOM_NO_SEED_UPDATE
20.71.2.316 RANDOM_NUM_SIZE
20.71.2.317 RANDOM_PARAM2_IDX
20.71.2.318 RANDOM_RSP_SIZE
20.71.2.319 RANDOM_SEED_UPDATE
20.71.2.320 READ_32_RSP_SIZE
20.71.2.321 READ_4_RSP_SIZE
20.71.2.322 READ_ADDR_IDX
20.71.2.323 READ_COUNT
20.71.2.324 READ_ZONE_IDX
20.71.2.325 READ_ZONE_MASK
20.71.2.326 RSA2048_KEY_SIZE
20.71.2.327 SECUREBOOT_COUNT_DIG
20.71.2.328 SECUREBOOT_COUNT_DIG_SIG
20.71.2.329 SECUREBOOT_DIGEST_SIZE
20.71.2.330 SECUREBOOT_MAC_SIZE
20.71.2.331 SECUREBOOT_MODE_ENC_MAC_FLAG
20.71.2.332 SECUREBOOT_MODE_FULL
20.71.2.333 SECUREBOOT_MODE_FULL_COPY
20.71.2.334 SECUREBOOT_MODE_FULL_STORE
20.71.2.335 SECUREBOOT_MODE_IDX
20.71.2.336 SECUREBOOT_MODE_MASK
20.71.2.337 SECUREBOOT_MODE_PROHIBIT_FLAG
20.71.2.338 SECUREBOOT_RSP_SIZE_MAC
20.71.2.339 SECUREBOOT_RSP_SIZE_NO_MAC
20.71.2.340 SECUREBOOT_SIGNATURE_SIZE
20.71.2.341 SECUREBOOTCONFIG_MODE_DISABLED
20.71.2.342 SECUREBOOTCONFIG_MODE_FULL_BOTH
20.71.2.343 SECUREBOOTCONFIG_MODE_FULL_DIG
20.71.2.344 SECUREBOOTCONFIG_MODE_FULL_SIG
20.71.2.345.SECUREBOOTCONEIG MODE MASK 768

20.71.2.346 SECUREBOOTCONFIG_OFFSET
20.71.2.347 SELFTEST_COUNT
20.71.2.348 SELFTEST_MODE_AES
20.71.2.349 SELFTEST_MODE_ALL
20.71.2.350 SELFTEST_MODE_ECDH
20.71.2.351 SELFTEST_MODE_ECDSA_SIGN_VERIFY
20.71.2.352 SELFTEST_MODE_IDX
20.71.2.353 SELFTEST_MODE_RNG
20.71.2.354 SELFTEST_MODE_SHA
20.71.2.355 SELFTEST_RSP_SIZE
20.71.2.356 SHA_COUNT_LONG
20.71.2.357 SHA_COUNT_SHORT
20.71.2.358 SHA_DATA_MAX
20.71.2.359 SHA_MODE_608_HMAC_END
20.71.2.360 SHA_MODE_HMAC_END
20.71.2.361 SHA_MODE_HMAC_START
20.71.2.362 SHA_MODE_HMAC_UPDATE
20.71.2.363 SHA_MODE_MASK
20.71.2.364 SHA_MODE_READ_CONTEXT
20.71.2.365 SHA_MODE_SHA256_END
20.71.2.366 SHA_MODE_SHA256_PUBLIC
20.71.2.367 SHA_MODE_SHA256_START
20.71.2.368 SHA_MODE_SHA256_UPDATE
20.71.2.369 SHA_MODE_TARGET_MASK
20.71.2.370 SHA_MODE_WRITE_CONTEXT
20.71.2.371 SHA_RSP_SIZE
20.71.2.372 SHA_RSP_SIZE_LONG
20.71.2.373 SHA_RSP_SIZE_SHORT
20.71.2.374 SIGN_COUNT
20.71.2.375 SIGN_KEYID_IDX
20.71.2.376 SIGN_MODE_EXTERNAL
20.71.2.377 SIGN_MODE_IDX
20.71.2.378 SIGN_MODE_INCLUDE_SN
20.71.2.379 SIGN_MODE_INTERNAL
20.71.2.380 SIGN_MODE_INVALIDATE
20.71.2.381 SIGN_MODE_MASK
20.71.2.382 SIGN_MODE_SOURCE_MASK
20.71.2.383 SIGN_MODE_SOURCE_MSGDIGBUF
20.71.2.384 SIGN_MODE_SOURCE_TEMPKEY
20.71.2.385 SIGN_RSP_SIZE
20.71.2.386 UPDATE_COUNT
20.71.2.387 UPDATE_MODE_DEC_COUNTER

20.71.2.388 UPDATE_MODE_IDX
20.71.2.389 UPDATE_MODE_SELECTOR
20.71.2.390 UPDATE_MODE_USER_EXTRA
20.71.2.391 UPDATE_MODE_USER_EXTRA_ADD
20.71.2.392 UPDATE_RSP_SIZE
20.71.2.393 UPDATE_VALUE_IDX
20.71.2.394 VERIFY_256_EXTERNAL_COUNT
20.71.2.395 VERIFY_256_KEY_SIZE
20.71.2.396 VERIFY_256_SIGNATURE_SIZE
20.71.2.397 VERIFY_256_STORED_COUNT
20.71.2.398 VERIFY_256_VALIDATE_COUNT
20.71.2.399 VERIFY_283_EXTERNAL_COUNT
20.71.2.400 VERIFY_283_KEY_SIZE
20.71.2.401 VERIFY_283_SIGNATURE_SIZE
20.71.2.402 VERIFY_283_STORED_COUNT
20.71.2.403 VERIFY_283_VALIDATE_COUNT
20.71.2.404 VERIFY_DATA_IDX
20.71.2.405 VERIFY_KEY_B283
20.71.2.406 VERIFY_KEY_K283
20.71.2.407 VERIFY_KEY_P256
20.71.2.408 VERIFY_KEYID_IDX
20.71.2.409 VERIFY_MODE_EXTERNAL
20.71.2.410 VERIFY_MODE_IDX
20.71.2.411 VERIFY_MODE_INVALIDATE
20.71.2.412 VERIFY_MODE_MAC_FLAG
20.71.2.413 VERIFY_MODE_MASK
20.71.2.414 VERIFY_MODE_SOURCE_MASK
20.71.2.415 VERIFY_MODE_SOURCE_MSGDIGBUF
20.71.2.416 VERIFY_MODE_SOURCE_TEMPKEY
20.71.2.417 VERIFY_MODE_STORED
20.71.2.418 VERIFY_MODE_VALIDATE
20.71.2.419 VERIFY_MODE_VALIDATE_EXTERNAL
20.71.2.420 VERIFY_OTHER_DATA_SIZE
20.71.2.421 VERIFY_RSP_SIZE
20.71.2.422 VERIFY_RSP_SIZE_MAC
20.71.2.423 WRITE_ADDR_IDX
20.71.2.424 WRITE_MAC_SIZE
20.71.2.425 WRITE_MAC_VL_IDX
20.71.2.426 WRITE_MAC_VS_IDX
20.71.2.427 WRITE_RSP_SIZE
20.71.2.428 WRITE_VALUE_IDX
20 71 2 429 WRITE 70NE DATA 782

20.71.2.430 WRITE_ZONE_IDX	782
20.71.2.431 WRITE_ZONE_MASK	782
20.71.2.432 WRITE_ZONE_OTP	782
20.71.2.433 WRITE_ZONE_WITH_MAC	782
20.71.3 Function Documentation	782
20.71.3.1 atAES()	
20.71.3.2 atCalcCrc()	783
20.71.3.3 atCheckCrc()	783
20.71.3.4 atCheckMAC()	783
20.71.3.5 atCounter()	784
20.71.3.6 atCRC()	784
20.71.3.7 atDeriveKey()	785
20.71.3.8 atECDH()	785
20.71.3.9 atGenDig()	
20.71.3.10 atGenKey()	786
20.71.3.11 atHMAC()	786
20.71.3.12 atlnfo()	787
20.71.3.13 atlsECCFamily()	787
20.71.3.14 atlsSHAFamily()	787
20.71.3.15 atKDF()	788
20.71.3.16 atLock()	788
20.71.3.17 atMAC()	788
20.71.3.18 atNonce()	789
20.71.3.19 atPause()	789
20.71.3.20 atPrivWrite()	790
20.71.3.21 atRandom()	790
20.71.3.22 atRead()	790
20.71.3.23 atSecureBoot()	791
20.71.3.24 atSelfTest()	791
20.71.3.25 atSHA()	791
20.71.3.26 atSign()	793
20.71.3.27 atUpdateExtra()	793
20.71.3.28 atVerify()	794
20.71.3.29 atWrite()	794
20.71.3.30 isATCAError()	794
20.72 calib_counter.c File Reference	795
20.72.1 Detailed Description	795
20.73 calib_derivekey.c File Reference	
20.73.1 Detailed Description	796
20.74 calib_ecdh.c File Reference	
20.74.1 Detailed Description	797
20.74.2 Function Documentation	797

20.74.2.1 calib_ecdh_enc()	)/
20.75 calib_execution.c File Reference	98
20.75.1 Detailed Description	98
20.75.2 Function Documentation	98
20.75.2.1 calib_execute_command()	98
20.76 calib_execution.h File Reference	<b>)</b> 9
20.76.1 Detailed Description	<b>)</b> 9
20.76.2 Macro Definition Documentation	99
20.76.2.1 ATCA_UNSUPPORTED_CMD	)0
20.76.3 Function Documentation	)0
20.76.3.1 calib_execute_command()	)0
20.77 calib_gendig.c File Reference	)0
20.77.1 Detailed Description	)0
20.78 calib_genkey.c File Reference	)1
20.78.1 Detailed Description	)1
20.79 calib_hmac.c File Reference	)1
20.79.1 Detailed Description	)2
20.80 calib_info.c File Reference	)2
20.80.1 Detailed Description	)2
20.81 calib_kdf.c File Reference	)3
20.81.1 Detailed Description	)3
20.82 calib_lock.c File Reference	)3
20.82.1 Detailed Description	)4
20.83 calib_mac.c File Reference	)4
20.83.1 Detailed Description	)4
20.84 calib_nonce.c File Reference	)5
20.84.1 Detailed Description	)5
20.85 calib_privwrite.c File Reference	)5
20.85.1 Detailed Description	)6
20.85.2 Function Documentation	)6
20.85.2.1 calib_priv_write()	)6
20.86 calib_random.c File Reference	)7
20.86.1 Detailed Description	)7
20.87 calib_read.c File Reference	)7
20.87.1 Detailed Description	)8
20.87.2 Function Documentation	)8
20.87.2.1 calib_read_enc()	)9
20.88 calib_secureboot.c File Reference	)9
20.88.1 Detailed Description	10
20.89 calib_selftest.c File Reference	10
20.89.1 Detailed Description	10
20.90 calib_sha.c File Reference	10

20.90.1 Detailed Description
20.91 calib_sign.c File Reference
20.91.1 Detailed Description
20.92 calib_updateextra.c File Reference
20.92.1 Detailed Description
20.93 calib_verify.c File Reference
20.93.1 Detailed Description
20.94 calib_write.c File Reference
20.94.1 Detailed Description
20.94.2 Function Documentation
20.94.2.1 calib_write_enc()
20.95 cryptoauthlib.h File Reference
20.95.1 Detailed Description
20.95.2 Macro Definition Documentation
20.95.2.1 ATCA_AES128_BLOCK_SIZE
20.95.2.2 ATCA_AES128_KEY_SIZE
20.95.2.3 ATCA_ATECC608_SUPPORT
20.95.2.4 ATCA_CA_SUPPORT
20.95.2.5 ATCA_DLL
20.95.2.6 ATCA_ECC_SUPPORT
20.95.2.7 ATCA_ECCP256_KEY_SIZE
20.95.2.8 ATCA_ECCP256_PUBKEY_SIZE
20.95.2.9 ATCA_ECCP256_SIG_SIZE
20.95.2.10 ATCA_SHA256_BLOCK_SIZE
20.95.2.11 ATCA_SHA256_DIGEST_SIZE
20.95.2.12 ATCA_SHA_SUPPORT
20.95.2.13 ATCA_STRINGIFY
20.95.2.14 ATCA_TA_SUPPORT
20.95.2.15 ATCA_TOSTRING
20.95.2.16 ATCA_TRACE
20.95.2.17 ATCA_ZONE_CONFIG
20.95.2.18 ATCA_ZONE_DATA
20.95.2.19 ATCA_ZONE_OTP
20.95.2.20 SHA_MODE_TARGET_MSGDIGBUF
20.95.2.21 SHA_MODE_TARGET_OUT_ONLY
20.95.2.22 SHA_MODE_TARGET_TEMPKEY
20.96 cryptoki.h File Reference
20.96.1 Macro Definition Documentation
20.96.1.1 CK_CALLBACK_FUNCTION
20.96.1.2 CK_DECLARE_FUNCTION
20.96.1.3 CK_DECLARE_FUNCTION_POINTER
20.96.1.4 CK_PTR

	20.96.1.5 NULL_PTR	822
	20.96.1.6 PKCS11_API	822
	20.96.1.7 PKCS11_HELPER_DLL_EXPORT	822
	20.96.1.8 PKCS11_HELPER_DLL_IMPORT	822
	20.96.1.9 PKCS11_HELPER_DLL_LOCAL	822
	20.96.1.10 PKCS11_LOCAL	822
20.97 examp	ole_cert_chain.c File Reference	822
20.97.	1 Variable Documentation	823
	20.97.1.1 g_cert_def_0_root	823
	20.97.1.2 g_cert_def_1_signer	823
	20.97.1.3 g_cert_def_2_device	823
	20.97.1.4 g_cert_elements_1_signer	823
	20.97.1.5 g_cert_template_1_signer	823
	20.97.1.6 g_cert_template_2_device	824
20.98 examp	ole_cert_chain.h File Reference	824
20.98.	1 Variable Documentation	824
	20.98.1.1 g_cert_def_1_signer	824
	20.98.1.2 g_cert_def_2_device	824
20.99 examp	ole_pkcs11_config.c File Reference	825
20.99.	1 Macro Definition Documentation	825
	20.99.1.1 pkcs11configLABEL_DEVICE_CERTIFICATE_FOR_TLS	825
	20.99.1.1 pkcs11configLABEL_DEVICE_CERTIFICATE_FOR_TLS	
		825
	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS	825 826
20.99.	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS	825 826 826
20.99.	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS	825 826 826 826
20.99.	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS  20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS  20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE  2 Function Documentation	825 826 826 826 826
20.99.:	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS  20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS  20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE  2 Function Documentation  20.99.2.1 pkcs11_config_cert()	825 826 826 826 826 826
	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS  20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS  20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE  2 Function Documentation  20.99.2.1 pkcs11_config_cert()  20.99.2.2 pkcs11_config_key()	825 826 826 826 826 826 826
	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects()	825 826 826 826 826 826 826
20.99.	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation	825 826 826 826 826 826 826 826 827
20.99.3 20.100 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config	825 826 826 826 826 826 826 827 827
20.99.3 20.100 hal_a 20.100	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference	825 826 826 826 826 826 826 827 827
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference	825 826 826 826 826 826 827 827 828
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description esp32_i2c.c File Reference	825 826 826 826 826 826 827 827 828 828
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description esp32_i2c.c File Reference .1 Macro Definition Documentation	825 826 826 826 826 826 827 827 828 828 829
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description esp32_i2c.c File Reference .1 Macro Definition Documentation 20.101.1.1 ACK_CHECK_DIS	825 826 826 826 826 826 827 827 828 828 829 830
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description esp32_i2c.c File Reference .1 Macro Definition Documentation 20.101.1.1 ACK_CHECK_DIS 20.101.1.1.2 ACK_CHECK_EN	825 826 826 826 826 826 827 827 828 829 829 830
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 3.1 Detailed Description esp32_i2c.c File Reference .1 Macro Definition Documentation 20.101.1.1 ACK_CHECK_DIS 20.101.1.2 ACK_CHECK_EN	825 826 826 826 826 826 827 827 828 828 829 830 830
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DITP_CERTIFICATE 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description esp32_i2c.c File Reference .1 Macro Definition Documentation 20.101.1.1 ACK_CHECK_DIS 20.101.1.2 ACK_CHECK_EN 20.101.1.3 ACK_VAL 20.101.1.3 ACK_VAL 20.101.1.4 LOG_LOCAL_LEVEL	825 826 826 826 826 826 827 827 828 829 830 830 830
20.99.3 20.100 hal_a 20.100 20.101 hal_a	20.99.1.2 pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS 20.99.1.3 pkcs11configLABEL_DIVICE_PUBLIC_KEY_FOR_TLS 20.99.1.4 pkcs11configLABEL_JITP_CERTIFICATE 2 Function Documentation 20.99.2.1 pkcs11_config_cert() 20.99.2.2 pkcs11_config_key() 20.99.2.3 pkcs11_config_load_objects() 3 Variable Documentation 20.99.3.1 atecc608_config all_platforms_kit_hidapi.c File Reference 0.1 Detailed Description 20sp32_i2c.c File Reference 1 Macro Definition Documentation 20.101.1.1 ACK_CHECK_DIS 20.101.1.2 ACK_CHECK_EN 20.101.1.3 ACK_VAL 20.101.1.5 MAX_I2C_BUSES	825 826 826 826 826 827 827 828 829 830 830 830 830

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

20.101.2 Typedef Documentation	30
20.101.2.1 ATCAI2CMaster_t	31
20.101.3 Function Documentation	31
20.101.3.1 hal_i2c_change_baud()	31
20.101.3.2 hal_i2c_discover_buses()	31
20.101.3.3 hal_i2c_discover_devices()	32
20.101.3.4 hal_i2c_idle()	33
20.101.3.5 hal_i2c_init()	33
20.101.3.6 hal_i2c_post_init()	35
20.101.3.7 hal_i2c_receive()	35
20.101.3.8 hal_i2c_release()	36
20.101.3.9 hal_i2c_send()	37
20.101.3.10 hal_i2c_sleep()	38
20.101.3.11 hal_i2c_wake()	38
20.101.4 Variable Documentation	39
20.101.4.1 conf	39
20.101.4.2 i2c_bus_ref_ct	39
20.101.4.3 i2c_hal_data	39
20.101.4.4 TAG	39
20.102 hal_esp32_timer.c File Reference	39
20.102.1 Function Documentation	40
20.102.1.1 atca_delay_ms()	40
20.102.1.2 ets_delay_us()	40
20.103 hal_freertos.c File Reference	40
20.103.1 Detailed Description	40
20.103.2 Macro Definition Documentation	41
20.103.2.1 ATCA_MUTEX_TIMEOUT	41
20.104 hal_i2c_harmony.c File Reference	41
20.104.1 Detailed Description	42
20.105 hal_i2c_start.c File Reference	42
20.105.1 Detailed Description	43
20.106 hal_i2c_start.h File Reference	43
20.106.1 Detailed Description	43
20.107 hal_linux.c File Reference	44
20.107.1 Detailed Description	44
20.108 hal_linux_i2c_userspace.c File Reference	44
20.108.1 Detailed Description	45
20.109 hal_linux_i2c_userspace.h File Reference	45
20.109.1 Detailed Description	46
20.110 hal_linux_spi_userspace.c File Reference	46
20.110.1 Function Documentation	47
20.110.1.1 hal_spi_discover_buses()	47

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXIII

20.110.1.2 hal_spi_discover_devices()	847
20.110.1.3 hal_spi_idle()	847
20.110.1.4 hal_spi_init()	848
20.110.1.5 hal_spi_open_file()	848
20.110.1.6 hal_spi_post_init()	848
20.110.1.7 hal_spi_receive()	849
20.110.1.8 hal_spi_release()	849
20.110.1.9 hal_spi_send()	849
20.110.1.10 hal_spi_sleep()	850
20.110.1.11 hal_spi_wake()	850
20.111 hal_linux_spi_userspace.h File Reference	851
20.111.1 Detailed Description	851
20.112 hal_sam0_i2c_asf.c File Reference	851
20.112.1 Detailed Description	852
20.113 hal_sam0_i2c_asf.h File Reference	852
20.113.1 Detailed Description	853
20.113.2 Typedef Documentation	853
20.113.2.1 i2c_sam0_instance_t	853
20.113.2.2 sam0_change_baudrate	853
20.114 hal_sam_i2c_asf.c File Reference	853
20.114.1 Detailed Description	854
20.115 hal_sam_i2c_asf.h File Reference	854
20.115.1 Detailed Description	855
20.116 hal_sam_timer_asf.c File Reference	855
20.116.1 Detailed Description	855
20.117 hal_spi_harmony.c File Reference	856
20.117.1 Detailed Description	856
20.118 hal_swi_uart.c File Reference	857
20.118.1 Detailed Description	857
20.119 hal_swi_uart.h File Reference	858
20.119.1 Detailed Description	858
20.120 hal_timer_start.c File Reference	858
20.120.1 Detailed Description	859
20.121 hal_uc3_i2c_asf.c File Reference	859
20.121.1 Detailed Description	860
20.122 hal_uc3_i2c_asf.h File Reference	
20.122.1 Detailed Description	860
20.123 hal_uc3_timer_asf.c File Reference	861
•	861
20.124 hal_windows.c File Reference	861
20.124.1 Detailed Description	
20.125 io_protection_key.h File Reference	862

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXIV

20.125.1 Detailed Description	862
20.125.2 Function Documentation	862
20.125.2.1 io_protection_get_key()	862
20.125.2.2 io_protection_set_key()	862
20.126 kit_phy.h File Reference	863
20.126.1 Detailed Description	863
20.127 kit_protocol.c File Reference	863
20.127.1 Detailed Description	864
20.128 kit_protocol.h File Reference	864
20.128.1 Detailed Description	865
20.129 license.txt File Reference	865
20.129.1 Function Documentation	874
20.129.1.1 DAMAGES()	874
20.129.1.2 files()	874
20.129.1.3 software()	875
20.129.1.4 TORT()	875
20.129.1.5 Version()	875
20.129.2 Variable Documentation	876
20.129.2.1 ANY	876
20.129.2.2 BASIS	876
20.129.2.3 CAUSED	876
20.129.2.4 charge	877
20.129.2.5 CLAIM	877
20.129.2.6 conditions	877
20.129.2.7 CONTRACT	877
20.129.2.8 copy	878
20.129.2.9 DAMAGE	878
20.129.2.10 DIRECT	878
20.129.2.11 distribute	879
20.129.2.12 EXEMPLARY	879
20.129.2.13 EXPRESS	879
20.129.2.14 FEES	880
20.129.2.15 forms	880
20.129.2.16 FROM	880
20.129.2.17 granted	880
20.129.2.18 http	881
20.129.2.19 IMPLIED	881
20.129.2.20 INCIDENTAL	881
20.129.2.21 INCLUDING	881
20.129.2.22 INDIRECT	882
20.129.2.23 INFRINGEMENT	882
20 129 2 24 KIND	883

20.129.2.25 LAW	383
20.129.2.26 LIABILITY	383
20.129.2.27 license	383
20.129.2.28 License	384
20.129.2.29 LOSS	384
20.129.2.30 MERCHANTABILITY	384
20.129.2.31 merge	384
20.129.2.32 met	385
20.129.2.33 modification	385
20.129.2.34 modify	385
20.129.2.35 notice	385
20.129.2.36 OTHERWISE	386
20.129.2.37 Ott	386
20.129.2.38 publish	386
20.129.2.39 PUNITIVE	386
20.129.2.40 restriction	387
20.129.2.41 so	387
20.129.2.42 SOFTWARE	387
20.129.2.43 Software	387
20.129.2.44 SPECIAL	388
20.129.2.45 STATUTORY	388
20.129.2.46 sublicense	388
20.129.2.47 terms	388
20.129.2.48 TO	389
20.129.2.49 use	389
20.129.2.50 VanderVoord	389
20.129.2.51 WARRANTIES	389
20.130 pkcs11.h File Reference	390
20.130.1 Macro Definition Documentation	390
20.130.1.1PASTE	390
20.130.1.2 CK_NEED_ARG_LIST [1/2]	391
20.130.1.3 CK_NEED_ARG_LIST [2/2]	391
20.130.1.4 CK_PKCS11_FUNCTION_INFO [1/3] 8	391
<b>20.130.1.5 CK_PKCS11_FUNCTION_INFO</b> [2/3]	391
<b>20.130.1.6 CK_PKCS11_FUNCTION_INFO</b> [3/3]	391
20.131 pkcs11_attrib.c File Reference	391
20.131.1 Detailed Description	392
20.132 pkcs11_attrib.h File Reference	392
20.132.1 Detailed Description	392
20.132.2 Typedef Documentation	393
20.132.2.1 attrib_f	393
20.132.2.2 pkcs11_attrib_model	393

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 IXXVI

20.132.2.3 pkcs11_attrib_model_ptr	893
20.133 pkcs11_cert.c File Reference	893
20.133.1 Detailed Description	894
20.134 pkcs11_cert.h File Reference	894
20.134.1 Detailed Description	894
20.135 pkcs11_config.c File Reference	895
20.135.1 Detailed Description	895
20.136 pkcs11_debug.c File Reference	895
20.136.1 Detailed Description	896
20.137 pkcs11_debug.h File Reference	896
20.137.1 Detailed Description	896
20.137.2 Macro Definition Documentation	896
20.137.2.1 PKCS11_DEBUG	896
20.137.2.2 pkcs11_debug_attributes	896
20.137.2.3 PKCS11_DEBUG_NOFILE	897
20.137.2.4 PKCS11_DEBUG_RETURN	897
20.138 pkcs11_digest.c File Reference	897
20.138.1 Function Documentation	897
20.138.1.1 pkcs11_digest()	897
20.138.1.2 pkcs11_digest_final()	898
20.138.1.3 pkcs11_digest_init()	898
20.138.1.4 pkcs11_digest_update()	898
20.139 pkcs11_digest.h File Reference	898
20.139.1 Detailed Description	899
20.139.2 Function Documentation	899
20.139.2.1 pkcs11_digest()	899
20.139.2.2 pkcs11_digest_final()	899
20.139.2.3 pkcs11_digest_init()	899
20.139.2.4 pkcs11_digest_update()	900
20.140 pkcs11_find.c File Reference	900
20.140.1 Detailed Description	900
20.141 pkcs11_find.h File Reference	900
20.141.1 Detailed Description	901
20.142 pkcs11_info.c File Reference	901
20.142.1 Detailed Description	901
20.143 pkcs11_info.h File Reference	902
20.143.1 Detailed Description	902
20.144 pkcs11_init.c File Reference	902
20.144.1 Detailed Description	903
20.145 pkcs11_init.h File Reference	903
20.145.1 Detailed Description	903
20 145 2 Typedef Documentation	904

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXVII

20.145.2.1 pkcs11_lib_ctx	04
20.145.2.2 pkcs11_lib_ctx_ptr	04
20.146 pkcs11_key.c File Reference	04
20.146.1 Detailed Description	05
20.147 pkcs11_key.h File Reference	05
20.147.1 Detailed Description	06
20.148 pkcs11_main.c File Reference	06
20.148.1 Detailed Description	10
20.149 pkcs11_mech.c File Reference	10
20.149.1 Detailed Description	)11
20.150 pkcs11_mech.h File Reference	)11
20.150.1 Detailed Description	)11
20.151 pkcs11_object.c File Reference	11
20.151.1 Detailed Description	112
20.152 pkcs11_object.h File Reference	112
20.152.1 Detailed Description	114
20.152.2 Macro Definition Documentation	114
20.152.2.1 PKCS11_OBJECT_FLAG_DESTROYABLE	114
20.152.2.2 PKCS11_OBJECT_FLAG_DYNAMIC	114
20.152.2.3 PKCS11_OBJECT_FLAG_MODIFIABLE	114
20.152.2.4 PKCS11_OBJECT_FLAG_SENSITIVE	114
20.152.2.5 PKCS11_OBJECT_FLAG_TA_TYPE	114
20.152.2.6 PKCS11_OBJECT_FLAG_TRUST_TYPE	114
20.152.3 Typedef Documentation	
20170210 Typodol Boodinionation	115
20.152.3.1 pkcs11_object	
•	915
20.152.3.1 pkcs11_object	915
20.152.3.1 pkcs11_object	915 915 915
20.152.3.1 pkcs11_object       9         20.152.3.2 pkcs11_object_cache_t       9         20.152.3.3 pkcs11_object_ptr       9	)15 )15 )15 )15
20.152.3.1 pkcs11_object	915 915 915 915
20.152.3.1 pkcs11_object	915 915 915 915 916
20.152.3.1 pkcs11_object	915 915 915 915 916
20.152.3.1 pkcs11_object	915 915 915 915 916 916
20.152.3.1 pkcs11_object       9         20.152.3.2 pkcs11_object_cache_t       9         20.152.3.3 pkcs11_object_ptr       9         20.153 pkcs11_os.c File Reference       9         20.153.1 Detailed Description       9         20.154 pkcs11_os.h File Reference       9         20.154.1 Detailed Description       9         20.154.2 Macro Definition Documentation       9	915 915 915 915 916 916 916
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 916
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 916 917
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 917 917
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 917 917
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 917 917 918
20.152.3.1 pkcs11_object	915 915 915 915 916 916 916 917 917 918 918

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXVIII

20.156.3.1 pkcs11_session_authorize()	19
20.157 pkcs11_signature.c File Reference	19
20.157.1 Detailed Description	20
20.158 pkcs11_signature.h File Reference	20
20.158.1 Detailed Description	20
20.159 pkcs11_slot.c File Reference	21
20.159.1 Detailed Description	21
20.160 pkcs11_slot.h File Reference	21
20.160.1 Detailed Description	22
20.160.2 Typedef Documentation	22
20.160.2.1 pkcs11_slot_ctx	22
20.160.2.2 pkcs11_slot_ctx_ptr	22
20.161 pkcs11_token.c File Reference	23
20.161.1 Detailed Description	23
20.162 pkcs11_token.h File Reference	23
20.162.1 Detailed Description	24
20.163 pkcs11_util.c File Reference	24
20.163.1 Detailed Description	24
20.164 pkcs11_util.h File Reference	25
20.164.1 Detailed Description	25
20.164.2 Macro Definition Documentation	25
20.164.2.1 PKCS11_UTIL_ARRAY_SIZE	25
20.165 pkcs11f.h File Reference	26
20.166 pkcs11t.h File Reference	26
20.166.1 Macro Definition Documentation	44
20.166.1.1 CK_CERTIFICATE_CATEGORY_AUTHORITY	44
20.166.1.2 CK_CERTIFICATE_CATEGORY_OTHER_ENTITY	44
20.166.1.3 CK_CERTIFICATE_CATEGORY_TOKEN_USER	44
20.166.1.4 CK_CERTIFICATE_CATEGORY_UNSPECIFIED	44
20.166.1.5 CK_EFFECTIVELY_INFINITE	44
20.166.1.6 CK_FALSE	44
20.166.1.7 CK_INVALID_HANDLE	45
20.166.1.8 CK_OTP_CHALLENGE	45
20.166.1.9 CK_OTP_COUNTER	45
20.166.1.10 CK_OTP_FLAGS	45
20.166.1.11 CK_OTP_FORMAT_ALPHANUMERIC	45
20.166.1.12 CK_OTP_FORMAT_BINARY	45
20.166.1.13 CK_OTP_FORMAT_DECIMAL	45
20.166.1.14 CK_OTP_FORMAT_HEXADECIMAL	45
20.166.1.15 CK_OTP_OUTPUT_FORMAT	46
20.166.1.16 CK_OTP_OUTPUT_LENGTH	46
20.166.1.17 CK_OTP_PARAM_IGNORED	46

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXIX

20.166.1.18 CK_OTP_PARAM_MANDATORY
20.166.1.19 CK_OTP_PARAM_OPTIONAL
20.166.1.20 CK_OTP_PIN
20.166.1.21 CK_OTP_TIME
20.166.1.22 CK_OTP_VALUE
20.166.1.23 CK_SECURITY_DOMAIN_MANUFACTURER
20.166.1.24 CK_SECURITY_DOMAIN_OPERATOR
20.166.1.25 CK_SECURITY_DOMAIN_THIRD_PARTY
20.166.1.26 CK_SECURITY_DOMAIN_UNSPECIFIED
20.166.1.27 CK_TRUE
20.166.1.28 CK_UNAVAILABLE_INFORMATION
20.166.1.29 CKA_AC_ISSUER
20.166.1.30 CKA_ALLOWED_MECHANISMS
20.166.1.31 CKA_ALWAYS_AUTHENTICATE
20.166.1.32 CKA_ALWAYS_SENSITIVE
20.166.1.33 CKA_APPLICATION
20.166.1.34 CKA_ATTR_TYPES
20.166.1.35 CKA_AUTH_PIN_FLAGS
20.166.1.36 CKA_BASE
20.166.1.37 CKA_BITS_PER_PIXEL
20.166.1.38 CKA_CERTIFICATE_CATEGORY
20.166.1.39 CKA_CERTIFICATE_TYPE
20.166.1.40 CKA_CHAR_COLUMNS
20.166.1.41 CKA_CHAR_ROWS
20.166.1.42 CKA_CHAR_SETS
20.166.1.43 CKA_CHECK_VALUE
20.166.1.44 CKA_CLASS
20.166.1.45 CKA_COEFFICIENT
20.166.1.46 CKA_COLOR
20.166.1.47 CKA_COPYABLE
20.166.1.48 CKA_DECRYPT
20.166.1.49 CKA_DEFAULT_CMS_ATTRIBUTES
20.166.1.50 CKA_DERIVE
20.166.1.51 CKA_DERIVE_TEMPLATE
20.166.1.52 CKA_DESTROYABLE
20.166.1.53 CKA_EC_PARAMS
20.166.1.54 CKA_EC_POINT
20.166.1.55 CKA_ECDSA_PARAMS
20.166.1.56 CKA_ENCODING_METHODS
20.166.1.57 CKA_ENCRYPT
20.166.1.58 CKA_END_DATE
20.166.1.59 CKA_EXPONENT_1

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXX

20.166.1.60 CKA_EXPONENT_2
20.166.1.61 CKA_EXTRACTABLE
20.166.1.62 CKA_GOST28147_PARAMS
20.166.1.63 CKA_GOSTR3410_PARAMS
20.166.1.64 CKA_GOSTR3411_PARAMS
20.166.1.65 CKA_HAS_RESET
20.166.1.66 CKA_HASH_OF_ISSUER_PUBLIC_KEY
20.166.1.67 CKA_HASH_OF_SUBJECT_PUBLIC_KEY
20.166.1.68 CKA_HW_FEATURE_TYPE
20.166.1.69 CKA_ID
20.166.1.70 CKA_ISSUER
20.166.1.71 CKA_JAVA_MIDP_SECURITY_DOMAIN
20.166.1.72 CKA_KEY_GEN_MECHANISM
20.166.1.73 CKA_KEY_TYPE
20.166.1.74 CKA_LABEL
20.166.1.75 CKA_LOCAL
20.166.1.76 CKA_MECHANISM_TYPE
20.166.1.77 CKA_MIME_TYPES
20.166.1.78 CKA_MODIFIABLE
20.166.1.79 CKA_MODULUS
20.166.1.80 CKA_MODULUS_BITS
20.166.1.81 CKA_NAME_HASH_ALGORITHM
20.166.1.82 CKA_NEVER_EXTRACTABLE
20.166.1.83 CKA_OBJECT_ID
20.166.1.84 CKA_OTP_CHALLENGE_REQUIREMENT
20.166.1.85 CKA_OTP_COUNTER
20.166.1.86 CKA_OTP_COUNTER_REQUIREMENT
20.166.1.87 CKA_OTP_FORMAT
20.166.1.88 CKA_OTP_LENGTH
20.166.1.89 CKA_OTP_PIN_REQUIREMENT
20.166.1.90 CKA_OTP_SERVICE_IDENTIFIER
20.166.1.91 CKA_OTP_SERVICE_LOGO
20.166.1.92 CKA_OTP_SERVICE_LOGO_TYPE
20.166.1.93 CKA_OTP_TIME
20.166.1.94 CKA_OTP_TIME_INTERVAL
20.166.1.95 CKA_OTP_TIME_REQUIREMENT
20.166.1.96 CKA_OTP_USER_FRIENDLY_MODE
20.166.1.97 CKA_OTP_USER_IDENTIFIER
20.166.1.98 CKA_OWNER
20.166.1.99 CKA_PIXEL_X
20.166.1.100 CKA_PIXEL_Y
20.166.1.101 CKA_PRIME

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 IXXXI

20.166.1.102 CKA_PRIME_1
20.166.1.103 CKA_PRIME_2
20.166.1.104 CKA_PRIME_BITS
20.166.1.105 CKA_PRIVATE
20.166.1.106 CKA_PRIVATE_EXPONENT
20.166.1.107 CKA_PUBLIC_EXPONENT
20.166.1.108 CKA_PUBLIC_KEY_INFO
20.166.1.109 CKA_REQUIRED_CMS_ATTRIBUTES
20.166.1.110 CKA_RESET_ON_INIT
20.166.1.111 CKA_RESOLUTION
20.166.1.112 CKA_SECONDARY_AUTH
20.166.1.113 CKA_SENSITIVE
20.166.1.114 CKA_SERIAL_NUMBER
20.166.1.115 CKA_SIGN
20.166.1.116 CKA_SIGN_RECOVER
20.166.1.117 CKA_START_DATE
20.166.1.118 CKA_SUB_PRIME_BITS
20.166.1.119 CKA_SUBJECT
20.166.1.120 CKA_SUBPRIME
20.166.1.121 CKA_SUBPRIME_BITS
20.166.1.122 CKA_SUPPORTED_CMS_ATTRIBUTES
20.166.1.123 CKA_TOKEN
20.166.1.124 CKA_TRUSTED
20.166.1.125 CKA_UNWRAP
20.166.1.126 CKA_UNWRAP_TEMPLATE
20.166.1.127 CKA_URL
20.166.1.128 CKA_VALUE
20.166.1.129 CKA_VALUE_BITS
20.166.1.130 CKA_VALUE_LEN
20.166.1.131 CKA_VENDOR_DEFINED
20.166.1.132 CKA_VERIFY
20.166.1.133 CKA_VERIFY_RECOVER
20.166.1.134 CKA_WRAP
20.166.1.135 CKA_WRAP_TEMPLATE
20.166.1.136 CKA_WRAP_WITH_TRUSTED
20.166.1.137 CKC_OPENPGP
20.166.1.138 CKC_VENDOR_DEFINED
20.166.1.139 CKC_WTLS
20.166.1.140 CKC_X_509
20.166.1.141 CKC_X_509_ATTR_CERT
20.166.1.142 CKD_CPDIVERSIFY_KDF
20.166.1.143 CKD_NULL

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXXII

20.166.1.144 CKD_SHA1_KDF
20.166.1.145 CKD_SHA1_KDF_ASN1
20.166.1.146 CKD_SHA1_KDF_CONCATENATE
20.166.1.147 CKD_SHA224_KDF
20.166.1.148 CKD_SHA256_KDF
20.166.1.149 CKD_SHA384_KDF
20.166.1.150 CKD_SHA512_KDF
20.166.1.151 CKF_ARRAY_ATTRIBUTE
20.166.1.152 CKF_CLOCK_ON_TOKEN
20.166.1.153 CKF_DECRYPT
20.166.1.154 CKF_DERIVE
20.166.1.155 CKF_DIGEST
20.166.1.156 CKF_DONT_BLOCK
20.166.1.157 CKF_DUAL_CRYPTO_OPERATIONS
20.166.1.158 CKF_EC_COMPRESS
20.166.1.159 CKF_EC_ECPARAMETERS
20.166.1.160 CKF_EC_F_2M
20.166.1.161 CKF_EC_F_P
20.166.1.162 CKF_EC_NAMEDCURVE
20.166.1.163 CKF_EC_UNCOMPRESS
20.166.1.164 CKF_ENCRYPT
20.166.1.165 CKF_ERROR_STATE
20.166.1.166 CKF_EXCLUDE_CHALLENGE
20.166.1.167 CKF_EXCLUDE_COUNTER
20.166.1.168 CKF_EXCLUDE_PIN
20.166.1.169 CKF_EXCLUDE_TIME
20.166.1.170 CKF_EXTENSION
20.166.1.171 CKF_GENERATE
20.166.1.172 CKF_GENERATE_KEY_PAIR
20.166.1.173 CKF_HW
20.166.1.174 CKF_HW_SLOT
20.166.1.175 CKF_LIBRARY_CANT_CREATE_OS_THREADS
20.166.1.176 CKF_LOGIN_REQUIRED
20.166.1.177 CKF_NEXT_OTP
20.166.1.178 CKF_OS_LOCKING_OK
20.166.1.179 CKF_PROTECTED_AUTHENTICATION_PATH
20.166.1.180 CKF_REMOVABLE_DEVICE
20.166.1.181 CKF_RESTORE_KEY_NOT_NEEDED
20.166.1.182 CKF_RNG
20.166.1.183 CKF_RW_SESSION
20.166.1.184 CKF_SECONDARY_AUTHENTICATION
20.166.1.185 CKF_SERIAL_SESSION

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXXIII

20.166.1.186 CKF_SIGN
20.166.1.187 CKF_SIGN_RECOVER
20.166.1.188 CKF_SO_PIN_COUNT_LOW
20.166.1.189 CKF_SO_PIN_FINAL_TRY
20.166.1.190 CKF_SO_PIN_LOCKED
20.166.1.191 CKF_SO_PIN_TO_BE_CHANGED
20.166.1.192 CKF_TOKEN_INITIALIZED
20.166.1.193 CKF_TOKEN_PRESENT
20.166.1.194 CKF_UNWRAP
20.166.1.195 CKF_USER_FRIENDLY_OTP
20.166.1.196 CKF_USER_PIN_COUNT_LOW
20.166.1.197 CKF_USER_PIN_FINAL_TRY
20.166.1.198 CKF_USER_PIN_INITIALIZED
20.166.1.199 CKF_USER_PIN_LOCKED
20.166.1.200 CKF_USER_PIN_TO_BE_CHANGED
20.166.1.201 CKF_VERIFY
20.166.1.202 CKF_VERIFY_RECOVER
20.166.1.203 CKF_WRAP
20.166.1.204 CKF_WRITE_PROTECTED
20.166.1.205 CKG_MGF1_SHA1
20.166.1.206 CKG_MGF1_SHA224
20.166.1.207 CKG_MGF1_SHA256
20.166.1.208 CKG_MGF1_SHA384
20.166.1.209 CKG_MGF1_SHA512
20.166.1.210 CKH_CLOCK
20.166.1.211 CKH_MONOTONIC_COUNTER
20.166.1.212 CKH_USER_INTERFACE
20.166.1.213 CKH_VENDOR_DEFINED
20.166.1.214 CKK_ACTI
20.166.1.215 CKK_AES
20.166.1.216 CKK_ARIA
20.166.1.217 CKK_BATON
20.166.1.218 CKK_BLOWFISH
20.166.1.219 CKK_CAMELLIA
20.166.1.220 CKK_CAST
20.166.1.221 CKK_CAST128 971
20.166.1.222 CKK_CAST3
20.166.1.223 CKK_CAST5
20.166.1.224 CKK_CDMF
20.166.1.225 CKK_DES
20.166.1.226 CKK_DES2
20.166.1.227 CKK_DES3

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXXIV

	28 CKK_DH	
	29 CKK_DSA	
	30 CKK_EC	
	31 CKK_ECDSA	
	32 CKK_GENERIC_SECRET	
	33 CKK_GOST28147	
	34 CKK_GOSTR3410	
	35 CKK_GOSTR3411	
	36 CKK_HOTP	
	37 CKK_IDEA	
	38 CKK_JUNIPER	
	39 CKK_KEA	
	40 CKK_MD5_HMAC	
20.166.1.2	41 CKK_RC2	974
	42 CKK_RC4	
20.166.1.2	43 CKK_RC5	974
20.166.1.2	44 CKK_RIPEMD128_HMAC	974
20.166.1.2	45 CKK_RIPEMD160_HMAC	974
20.166.1.2	46 CKK_RSA	974
20.166.1.2	47 CKK_SECURID	975
20.166.1.2	48 CKK_SEED	975
20.166.1.2	49 CKK_SHA224_HMAC	975
20.166.1.2	50 CKK_SHA256_HMAC	975
20.166.1.2	51 CKK_SHA384_HMAC	975
20.166.1.2	52 CKK_SHA512_HMAC	975
20.166.1.2	53 CKK_SHA_1_HMAC	975
20.166.1.2	54 CKK_SKIPJACK	975
20.166.1.2	55 CKK_TWOFISH	976
20.166.1.2	56 CKK_VENDOR_DEFINED	976
20.166.1.2	57 CKK_X9_42_DH	976
20.166.1.2	58 CKM_ACTI	976
20.166.1.2	59 CKM_ACTI_KEY_GEN	976
20.166.1.2	60 CKM_AES_CBC	976
20.166.1.2	61 CKM_AES_CBC_ENCRYPT_DATA	976
20.166.1.2	62 CKM_AES_CBC_PAD	976
20.166.1.2	63 CKM_AES_CCM	977
20.166.1.2	64 CKM_AES_CFB1	977
20.166.1.2	65 CKM_AES_CFB128	977
20.166.1.2	66 CKM_AES_CFB64	977
20.166.1.2	67 CKM_AES_CFB8	977
20.166.1.2	68 CKM_AES_CMAC	977
20.166.1.2	69 CKM_AES_CMAC_GENERAL	977

20.166.1.270 CKM_AES_CTR
20.166.1.271 CKM_AES_CTS
20.166.1.272 CKM_AES_ECB
20.166.1.273 CKM_AES_ECB_ENCRYPT_DATA
20.166.1.274 CKM_AES_GCM
20.166.1.275 CKM_AES_GMAC
20.166.1.276 CKM_AES_KEY_GEN
20.166.1.277 CKM_AES_KEY_WRAP
20.166.1.278 CKM_AES_KEY_WRAP_PAD
20.166.1.279 CKM_AES_MAC
20.166.1.280 CKM_AES_MAC_GENERAL
20.166.1.281 CKM_AES_OFB
20.166.1.282 CKM_AES_XCBC_MAC
20.166.1.283 CKM_AES_XCBC_MAC_96
20.166.1.284 CKM_ARIA_CBC
20.166.1.285 CKM_ARIA_CBC_ENCRYPT_DATA
20.166.1.286 CKM_ARIA_CBC_PAD
20.166.1.287 CKM_ARIA_ECB
20.166.1.288 CKM_ARIA_ECB_ENCRYPT_DATA
20.166.1.289 CKM_ARIA_KEY_GEN
20.166.1.290 CKM_ARIA_MAC
20.166.1.291 CKM_ARIA_MAC_GENERAL
20.166.1.292 CKM_BATON_CBC128
20.166.1.293 CKM_BATON_COUNTER
20.166.1.294 CKM_BATON_ECB128
20.166.1.295 CKM_BATON_ECB96
20.166.1.296 CKM_BATON_KEY_GEN
20.166.1.297 CKM_BATON_SHUFFLE
20.166.1.298 CKM_BATON_WRAP
20.166.1.299 CKM_BLOWFISH_CBC
20.166.1.300 CKM_BLOWFISH_CBC_PAD
20.166.1.301 CKM_BLOWFISH_KEY_GEN
20.166.1.302 CKM_CAMELLIA_CBC
20.166.1.303 CKM_CAMELLIA_CBC_ENCRYPT_DATA
20.166.1.304 CKM_CAMELLIA_CBC_PAD
20.166.1.305 CKM_CAMELLIA_CTR
20.166.1.306 CKM_CAMELLIA_ECB
20.166.1.307 CKM_CAMELLIA_ECB_ENCRYPT_DATA
20.166.1.308 CKM_CAMELLIA_KEY_GEN
20.166.1.309 CKM_CAMELLIA_MAC
20.166.1.310 CKM_CAMELLIA_MAC_GENERAL
20.166.1.311 CKM_CAST128_CBC

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 İXXXVİ

20.166.1.312 CKM_CAST128_CBC_PAD
20.166.1.313 CKM_CAST128_ECB
20.166.1.314 CKM_CAST128_KEY_GEN
20.166.1.315 CKM_CAST128_MAC
20.166.1.316 CKM_CAST128_MAC_GENERAL
20.166.1.317 CKM_CAST3_CBC
20.166.1.318 CKM_CAST3_CBC_PAD
20.166.1.319 CKM_CAST3_ECB
20.166.1.320 CKM_CAST3_KEY_GEN
20.166.1.321 CKM_CAST3_MAC
20.166.1.322 CKM_CAST3_MAC_GENERAL
20.166.1.323 CKM_CAST5_CBC
20.166.1.324 CKM_CAST5_CBC_PAD
20.166.1.325 CKM_CAST5_ECB
20.166.1.326 CKM_CAST5_KEY_GEN
20.166.1.327 CKM_CAST5_MAC
20.166.1.328 CKM_CAST5_MAC_GENERAL
20.166.1.329 CKM_CAST_CBC
20.166.1.330 CKM_CAST_CBC_PAD
20.166.1.331 CKM_CAST_ECB
20.166.1.332 CKM_CAST_KEY_GEN
20.166.1.333 CKM_CAST_MAC
20.166.1.334 CKM_CAST_MAC_GENERAL
20.166.1.335 CKM_CDMF_CBC
20.166.1.336 CKM_CDMF_CBC_PAD
20.166.1.337 CKM_CDMF_ECB
20.166.1.338 CKM_CDMF_KEY_GEN
20.166.1.339 CKM_CDMF_MAC
20.166.1.340 CKM_CDMF_MAC_GENERAL
20.166.1.341 CKM_CMS_SIG
20.166.1.342 CKM_CONCATENATE_BASE_AND_DATA
20.166.1.343 CKM_CONCATENATE_BASE_AND_KEY
20.166.1.344 CKM_CONCATENATE_DATA_AND_BASE
20.166.1.345 CKM_DES2_KEY_GEN
20.166.1.346 CKM_DES3_CBC
20.166.1.347 CKM_DES3_CBC_ENCRYPT_DATA
20.166.1.348 CKM_DES3_CBC_PAD
20.166.1.349 CKM_DES3_CMAC
20.166.1.350 CKM_DES3_CMAC_GENERAL
20.166.1.351 CKM_DES3_ECB
20.166.1.352 CKM_DES3_ECB_ENCRYPT_DATA
20.166.1.353 CKM_DES3_KEY_GEN

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

20.166.1.354 CKM_DES3_MAG
20.166.1.355 CKM_DES3_MAC_GENERAL
20.166.1.356 CKM_DES_CBC
20.166.1.357 CKM_DES_CBC_ENCRYPT_DATA
20.166.1.358 CKM_DES_CBC_PAD
20.166.1.359 CKM_DES_CFB64
20.166.1.360 CKM_DES_CFB8
20.166.1.361 CKM_DES_ECB
20.166.1.362 CKM_DES_ECB_ENCRYPT_DATA
20.166.1.363 CKM_DES_KEY_GEN
20.166.1.364 CKM_DES_MAC
20.166.1.365 CKM_DES_MAC_GENERAL
20.166.1.366 CKM_DES_OFB64
20.166.1.367 CKM_DES_OFB8
20.166.1.368 CKM_DH_PKCS_DERIVE
20.166.1.369 CKM_DH_PKCS_KEY_PAIR_GEN
20.166.1.370 CKM_DH_PKCS_PARAMETER_GEN
20.166.1.371 CKM_DSA
20.166.1.372 CKM_DSA_KEY_PAIR_GEN
20.166.1.373 CKM_DSA_PARAMETER_GEN
20.166.1.374 CKM_DSA_PROBABLISTIC_PARAMETER_GEN
20.166.1.375 CKM_DSA_SHA1
20.166.1.376 CKM_DSA_SHA224
20.166.1.377 CKM_DSA_SHA256
20.166.1.378 CKM_DSA_SHA384
20.166.1.379 CKM_DSA_SHA512
20.166.1.380 CKM_DSA_SHAWE_TAYLOR_PARAMETER_GEN
20.166.1.381 CKM_EC_KEY_PAIR_GEN
20.166.1.382 CKM_ECDH1_COFACTOR_DERIVE
20.166.1.383 CKM_ECDH1_DERIVE
20.166.1.384 CKM_ECDH_AES_KEY_WRAP
20.166.1.385 CKM_ECDSA
20.166.1.386 CKM_ECDSA_KEY_PAIR_GEN
20.166.1.387 CKM_ECDSA_SHA1
20.166.1.388 CKM_ECDSA_SHA224
20.166.1.389 CKM_ECDSA_SHA256
20.166.1.390 CKM_ECDSA_SHA384
20.166.1.391 CKM_ECDSA_SHA512
20.166.1.392 CKM_ECMQV_DERIVE
20.166.1.393 CKM_EXTRACT_KEY_FROM_KEY
20.166.1.394 CKM_FASTHASH
20.166.1.395 CKM_FORTEZZA_TIMESTAMP

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 IXXXVIII

20.166.1.396 CKM_GENERIC_SECRET_KEY_GEN
20.166.1.397 CKM_GOST28147
20.166.1.398 CKM_GOST28147_ECB
20.166.1.399 CKM_GOST28147_KEY_GEN
20.166.1.400 CKM_GOST28147_KEY_WRAP
20.166.1.401 CKM_GOST28147_MAC
20.166.1.402 CKM_GOSTR3410
20.166.1.403 CKM_GOSTR3410_DERIVE
20.166.1.404 CKM_GOSTR3410_KEY_PAIR_GEN
20.166.1.405 CKM_GOSTR3410_KEY_WRAP
20.166.1.406 CKM_GOSTR3410_WITH_GOSTR3411
20.166.1.407 CKM_GOSTR3411
20.166.1.408 CKM_GOSTR3411_HMAC
20.166.1.409 CKM_HOTP
20.166.1.410 CKM_HOTP_KEY_GEN
20.166.1.411 CKM_IDEA_CBC
20.166.1.412 CKM_IDEA_CBC_PAD
20.166.1.413 CKM_IDEA_ECB
20.166.1.414 CKM_IDEA_KEY_GEN
20.166.1.415 CKM_IDEA_MAC
20.166.1.416 CKM_IDEA_MAC_GENERAL
20.166.1.417 CKM_JUNIPER_CBC128
20.166.1.418 CKM_JUNIPER_COUNTER
20.166.1.419 CKM_JUNIPER_ECB128
20.166.1.420 CKM_JUNIPER_KEY_GEN
20.166.1.421 CKM_JUNIPER_SHUFFLE
20.166.1.422 CKM_JUNIPER_WRAP
20.166.1.423 CKM_KEA_DERIVE
20.166.1.424 CKM_KEA_KEY_DERIVE
20.166.1.425 CKM_KEA_KEY_PAIR_GEN
20.166.1.426 CKM_KEY_WRAP_LYNKS
20.166.1.427 CKM_KEY_WRAP_SET_OAEP
20.166.1.428 CKM_KIP_DERIVE
20.166.1.429 CKM_KIP_MAC
20.166.1.430 CKM_KIP_WRAP
20.166.1.431 CKM_MD2
20.166.1.432 CKM_MD2_HMAC
20.166.1.433 CKM_MD2_HMAC_GENERAL
20.166.1.434 CKM_MD2_KEY_DERIVATION
20.166.1.435 CKM_MD2_RSA_PKCS
20.166.1.436 CKM_MD5
20.166.1.437 CKM MD5 HMAC

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 IXXXIX

20.166.1.438 CKM_MD5_HMAC_GENERAL
20.166.1.439 CKM_MD5_KEY_DERIVATION
20.166.1.440 CKM_MD5_RSA_PKCS
20.166.1.441 CKM_PBA_SHA1_WITH_SHA1_HMAC
20.166.1.442 CKM_PBE_MD2_DES_CBC
20.166.1.443 CKM_PBE_MD5_CAST128_CBC
20.166.1.444 CKM_PBE_MD5_CAST3_CBC
20.166.1.445 CKM_PBE_MD5_CAST5_CBC
20.166.1.446 CKM_PBE_MD5_CAST_CBC
20.166.1.447 CKM_PBE_MD5_DES_CBC
20.166.1.448 CKM_PBE_SHA1_CAST128_CBC
20.166.1.449 CKM_PBE_SHA1_CAST5_CBC
20.166.1.450 CKM_PBE_SHA1_DES2_EDE_CBC
20.166.1.451 CKM_PBE_SHA1_DES3_EDE_CBC
20.166.1.452 CKM_PBE_SHA1_RC2_128_CBC
20.166.1.453 CKM_PBE_SHA1_RC2_40_CBC
20.166.1.454 CKM_PBE_SHA1_RC4_128
20.166.1.455 CKM_PBE_SHA1_RC4_40
20.166.1.456 CKM_PKCS5_PBKD2
20.166.1.457 CKM_RC2_CBC
20.166.1.458 CKM_RC2_CBC_PAD
20.166.1.459 CKM_RC2_ECB
20.166.1.460 CKM_RC2_KEY_GEN
20.166.1.461 CKM_RC2_MAC
20.166.1.462 CKM_RC2_MAC_GENERAL
20.166.1.463 CKM_RC4
20.166.1.464 CKM_RC4_KEY_GEN
20.166.1.465 CKM_RC5_CBC
20.166.1.466 CKM_RC5_CBC_PAD
20.166.1.467 CKM_RC5_ECB
20.166.1.468 CKM_RC5_KEY_GEN
20.166.1.469 CKM_RC5_MAC
20.166.1.470 CKM_RC5_MAC_GENERAL
20.166.1.471 CKM_RIPEMD128
20.166.1.472 CKM_RIPEMD128_HMAC
20.166.1.473 CKM_RIPEMD128_HMAC_GENERAL
20.166.1.474 CKM_RIPEMD128_RSA_PKCS
20.166.1.475 CKM_RIPEMD160
20.166.1.476 CKM_RIPEMD160_HMAC
20.166.1.477 CKM_RIPEMD160_HMAC_GENERAL
20.166.1.478 CKM_RIPEMD160_RSA_PKCS
20 166 1 479 CKM RSA 9796

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XC

20.166.1.480 CKM_RSA_AES_KEY_WRAP
20.166.1.481 CKM_RSA_PKCS
20.166.1.482 CKM_RSA_PKCS_KEY_PAIR_GEN
20.166.1.483 CKM_RSA_PKCS_OAEP
20.166.1.484 CKM_RSA_PKCS_OAEP_TPM_1_1
20.166.1.485 CKM_RSA_PKCS_PSS
20.166.1.486 CKM_RSA_PKCS_TPM_1_1
20.166.1.487 CKM_RSA_X9_31
20.166.1.488 CKM_RSA_X9_31_KEY_PAIR_GEN
20.166.1.489 CKM_RSA_X_509
20.166.1.490 CKM_SECURID
20.166.1.491 CKM_SECURID_KEY_GEN
20.166.1.492 CKM_SEED_CBC
20.166.1.493 CKM_SEED_CBC_ENCRYPT_DATA
20.166.1.494 CKM_SEED_CBC_PAD
20.166.1.495 CKM_SEED_ECB
20.166.1.496 CKM_SEED_ECB_ENCRYPT_DATA
20.166.1.497 CKM_SEED_KEY_GEN
20.166.1.498 CKM_SEED_MAC
20.166.1.499 CKM_SEED_MAC_GENERAL
20.166.1.500 CKM_SHA1_KEY_DERIVATION
20.166.1.501 CKM_SHA1_RSA_PKCS
20.166.1.502 CKM_SHA1_RSA_PKCS_PSS
20.166.1.503 CKM_SHA1_RSA_X9_31
20.166.1.504 CKM_SHA224
20.166.1.505 CKM_SHA224_HMAC
20.166.1.506 CKM_SHA224_HMAC_GENERAL
20.166.1.507 CKM_SHA224_KEY_DERIVATION
20.166.1.508 CKM_SHA224_RSA_PKCS
20.166.1.509 CKM_SHA224_RSA_PKCS_PSS
20.166.1.510 CKM_SHA256
20.166.1.511 CKM_SHA256_HMAC
20.166.1.512 CKM_SHA256_HMAC_GENERAL
20.166.1.513 CKM_SHA256_KEY_DERIVATION
20.166.1.514 CKM_SHA256_RSA_PKCS
20.166.1.515 CKM_SHA256_RSA_PKCS_PSS
20.166.1.516 CKM_SHA384
20.166.1.517 CKM_SHA384_HMAC
20.166.1.518 CKM_SHA384_HMAC_GENERAL
20.166.1.519 CKM_SHA384_KEY_DERIVATION
20.166.1.520 CKM_SHA384_RSA_PKCS
20.166.1.521 CKM_SHA384_RSA_PKCS_PSS

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XCİ

20.166.1.522 CKM_SHA512
20.166.1.523 CKM_SHA512_224
20.166.1.524 CKM_SHA512_224_HMAC
20.166.1.525 CKM_SHA512_224_HMAC_GENERAL
20.166.1.526 CKM_SHA512_224_KEY_DERIVATION
20.166.1.527 CKM_SHA512_256
20.166.1.528 CKM_SHA512_256_HMAC
20.166.1.529 CKM_SHA512_256_HMAC_GENERAL
20.166.1.530 CKM_SHA512_256_KEY_DERIVATION
20.166.1.531 CKM_SHA512_HMAC
20.166.1.532 CKM_SHA512_HMAC_GENERAL
20.166.1.533 CKM_SHA512_KEY_DERIVATION
20.166.1.534 CKM_SHA512_RSA_PKCS
20.166.1.535 CKM_SHA512_RSA_PKCS_PSS
20.166.1.536 CKM_SHA512_T
20.166.1.537 CKM_SHA512_T_HMAC
20.166.1.538 CKM_SHA512_T_HMAC_GENERAL
20.166.1.539 CKM_SHA512_T_KEY_DERIVATION
20.166.1.540 CKM_SHA_1
20.166.1.541 CKM_SHA_1_HMAC
20.166.1.542 CKM_SHA_1_HMAC_GENERAL
20.166.1.543 CKM_SKIPJACK_CBC64
20.166.1.544 CKM_SKIPJACK_CFB16
20.166.1.545 CKM_SKIPJACK_CFB32
20.166.1.546 CKM_SKIPJACK_CFB64
20.166.1.547 CKM_SKIPJACK_CFB8
20.166.1.548 CKM_SKIPJACK_ECB64
20.166.1.549 CKM_SKIPJACK_KEY_GEN
20.166.1.550 CKM_SKIPJACK_OFB64
20.166.1.551 CKM_SKIPJACK_PRIVATE_WRAP
20.166.1.552 CKM_SKIPJACK_RELAYX
20.166.1.553 CKM_SKIPJACK_WRAP
20.166.1.554 CKM_SSL3_KEY_AND_MAC_DERIVE
20.166.1.555 CKM_SSL3_MASTER_KEY_DERIVE
20.166.1.556 CKM_SSL3_MASTER_KEY_DERIVE_DH
20.166.1.557 CKM_SSL3_MD5_MAC
20.166.1.558 CKM_SSL3_PRE_MASTER_KEY_GEN
20.166.1.559 CKM_SSL3_SHA1_MAC
20.166.1.560 CKM_TLS10_MAC_CLIENT
20.166.1.561 CKM_TLS10_MAC_SERVER
20.166.1.562 CKM_TLS12_KDF
20.166.1.563 CKM_TLS12_KEY_AND_MAC_DERIVE

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XCİİ

20.166.1.564 CKM_TLS12_KEY_SAFE_DERIVE
20.166.1.565 CKM_TLS12_MAC
20.166.1.566 CKM_TLS12_MASTER_KEY_DERIVE
20.166.1.567 CKM_TLS12_MASTER_KEY_DERIVE_DH
20.166.1.568 CKM_TLS_KDF
20.166.1.569 CKM_TLS_KEY_AND_MAC_DERIVE
20.166.1.570 CKM_TLS_MAC
20.166.1.571 CKM_TLS_MASTER_KEY_DERIVE
20.166.1.572 CKM_TLS_MASTER_KEY_DERIVE_DH
20.166.1.573 CKM_TLS_PRE_MASTER_KEY_GEN
20.166.1.574 CKM_TLS_PRF
20.166.1.575 CKM_TWOFISH_CBC
20.166.1.576 CKM_TWOFISH_CBC_PAD
20.166.1.577 CKM_TWOFISH_KEY_GEN
20.166.1.578 CKM_VENDOR_DEFINED
20.166.1.579 CKM_WTLS_CLIENT_KEY_AND_MAC_DERIVE
20.166.1.580 CKM_WTLS_MASTER_KEY_DERIVE
20.166.1.581 CKM_WTLS_MASTER_KEY_DERIVE_DH_ECC
20.166.1.582 CKM_WTLS_PRE_MASTER_KEY_GEN
20.166.1.583 CKM_WTLS_PRF
20.166.1.584 CKM_WTLS_SERVER_KEY_AND_MAC_DERIVE
20.166.1.585 CKM_X9_42_DH_DERIVE
20.166.1.586 CKM_X9_42_DH_HYBRID_DERIVE
20.166.1.587 CKM_X9_42_DH_KEY_PAIR_GEN
20.166.1.588 CKM_X9_42_DH_PARAMETER_GEN
20.166.1.589 CKM_X9_42_MQV_DERIVE
20.166.1.590 CKM_XOR_BASE_AND_DATA
20.166.1.591 CKN_OTP_CHANGED
20.166.1.592 CKN_SURRENDER
20.166.1.593 CKO_CERTIFICATE
20.166.1.594 CKO_DATA
20.166.1.595 CKO_DOMAIN_PARAMETERS
20.166.1.596 CKO_HW_FEATURE
20.166.1.597 CKO_MECHANISM
20.166.1.598 CKO_OTP_KEY
20.166.1.599 CKO_PRIVATE_KEY
20.166.1.600 CKO_PUBLIC_KEY
20.166.1.601 CKO_SECRET_KEY
20.166.1.602 CKO_VENDOR_DEFINED
20.166.1.603 CKP_PKCS5_PBKD2_HMAC_GOSTR3411
20.166.1.604 CKP_PKCS5_PBKD2_HMAC_SHA1
20.166.1.605 CKP_PKCS5_PBKD2_HMAC_SHA224

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XCIII

20.166.1.606 CKP_PKCS5_PBKD2_HMAC_SHA256
20.166.1.607 CKP_PKCS5_PBKD2_HMAC_SHA384
20.166.1.608 CKP_PKCS5_PBKD2_HMAC_SHA512
20.166.1.609 CKP_PKCS5_PBKD2_HMAC_SHA512_224
20.166.1.610 CKP_PKCS5_PBKD2_HMAC_SHA512_256
20.166.1.611 CKR_ACTION_PROHIBITED
20.166.1.612 CKR_ARGUMENTS_BAD
20.166.1.613 CKR_ATTRIBUTE_READ_ONLY
20.166.1.614 CKR_ATTRIBUTE_SENSITIVE
20.166.1.615 CKR_ATTRIBUTE_TYPE_INVALID
20.166.1.616 CKR_ATTRIBUTE_VALUE_INVALID
20.166.1.617 CKR_BUFFER_TOO_SMALL
20.166.1.618 CKR_CANCEL
20.166.1.619 CKR_CANT_LOCK
20.166.1.620 CKR_CRYPTOKI_ALREADY_INITIALIZED
20.166.1.621 CKR_CRYPTOKI_NOT_INITIALIZED
20.166.1.622 CKR_CURVE_NOT_SUPPORTED
20.166.1.623 CKR_DATA_INVALID
20.166.1.624 CKR_DATA_LEN_RANGE
20.166.1.625 CKR_DEVICE_ERROR
20.166.1.626 CKR_DEVICE_MEMORY
20.166.1.627 CKR_DEVICE_REMOVED
20.166.1.628 CKR_DOMAIN_PARAMS_INVALID
20.166.1.629 CKR_ENCRYPTED_DATA_INVALID
20.166.1.630 CKR_ENCRYPTED_DATA_LEN_RANGE
20.166.1.631 CKR_EXCEEDED_MAX_ITERATIONS
20.166.1.632 CKR_FIPS_SELF_TEST_FAILED
20.166.1.633 CKR_FUNCTION_CANCELED
20.166.1.634 CKR_FUNCTION_FAILED
20.166.1.635 CKR_FUNCTION_NOT_PARALLEL
20.166.1.636 CKR_FUNCTION_NOT_SUPPORTED
20.166.1.637 CKR_FUNCTION_REJECTED
20.166.1.638 CKR_GENERAL_ERROR
20.166.1.639 CKR_HOST_MEMORY
20.166.1.640 CKR_INFORMATION_SENSITIVE
20.166.1.641 CKR_KEY_CHANGED
20.166.1.642 CKR_KEY_FUNCTION_NOT_PERMITTED
20.166.1.643 CKR_KEY_HANDLE_INVALID
20.166.1.644 CKR_KEY_INDIGESTIBLE
20.166.1.645 CKR_KEY_NEEDED
20.166.1.646 CKR_KEY_NOT_NEEDED
20.166.1.647 CKR_KEY_NOT_WRAPPABLE

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XCİV

20.166.1.648 CKR_KEY_SIZE_RANGE
20.166.1.649 CKR_KEY_TYPE_INCONSISTENT
20.166.1.650 CKR_KEY_UNEXTRACTABLE
20.166.1.651 CKR_LIBRARY_LOAD_FAILED
20.166.1.652 CKR_MECHANISM_INVALID
20.166.1.653 CKR_MECHANISM_PARAM_INVALID
20.166.1.654 CKR_MUTEX_BAD
20.166.1.655 CKR_MUTEX_NOT_LOCKED
20.166.1.656 CKR_NEED_TO_CREATE_THREADS
20.166.1.657 CKR_NEW_PIN_MODE
20.166.1.658 CKR_NEXT_OTP
20.166.1.659 CKR_NO_EVENT
20.166.1.660 CKR_OBJECT_HANDLE_INVALID
20.166.1.661 CKR_OK
20.166.1.662 CKR_OPERATION_ACTIVE
20.166.1.663 CKR_OPERATION_NOT_INITIALIZED
20.166.1.664 CKR_PIN_EXPIRED
20.166.1.665 CKR_PIN_INCORRECT
20.166.1.666 CKR_PIN_INVALID
20.166.1.667 CKR_PIN_LEN_RANGE
20.166.1.668 CKR_PIN_LOCKED
20.166.1.669 CKR_PIN_TOO_WEAK
20.166.1.670 CKR_PUBLIC_KEY_INVALID
20.166.1.671 CKR_RANDOM_NO_RNG
20.166.1.672 CKR_RANDOM_SEED_NOT_SUPPORTED
20.166.1.673 CKR_SAVED_STATE_INVALID
20.166.1.674 CKR_SESSION_CLOSED
20.166.1.675 CKR_SESSION_COUNT
20.166.1.676 CKR_SESSION_EXISTS
20.166.1.677 CKR_SESSION_HANDLE_INVALID
20.166.1.678 CKR_SESSION_PARALLEL_NOT_SUPPORTED1028
20.166.1.679 CKR_SESSION_READ_ONLY
20.166.1.680 CKR_SESSION_READ_ONLY_EXISTS
20.166.1.681 CKR_SESSION_READ_WRITE_SO_EXISTS
20.166.1.682 CKR_SIGNATURE_INVALID
20.166.1.683 CKR_SIGNATURE_LEN_RANGE
20.166.1.684 CKR_SLOT_ID_INVALID
20.166.1.685 CKR_STATE_UNSAVEABLE
20.166.1.686 CKR_TEMPLATE_INCOMPLETE
20.166.1.687 CKR_TEMPLATE_INCONSISTENT
20.166.1.688 CKR_TOKEN_NOT_PRESENT
20.166.1.689 CKR_TOKEN_NOT_RECOGNIZED

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XCV

20.166.1.690 CKR_TOKEN_WRITE_PROTECTED	1030
20.166.1.691 CKR_UNWRAPPING_KEY_HANDLE_INVALID	1030
20.166.1.692 CKR_UNWRAPPING_KEY_SIZE_RANGE	1030
20.166.1.693 CKR_UNWRAPPING_KEY_TYPE_INCONSISTENT	1030
20.166.1.694 CKR_USER_ALREADY_LOGGED_IN	1030
20.166.1.695 CKR_USER_ANOTHER_ALREADY_LOGGED_IN	1031
20.166.1.696 CKR_USER_NOT_LOGGED_IN	1031
20.166.1.697 CKR_USER_PIN_NOT_INITIALIZED	1031
20.166.1.698 CKR_USER_TOO_MANY_TYPES	1031
20.166.1.699 CKR_USER_TYPE_INVALID	1031
20.166.1.700 CKR_VENDOR_DEFINED	1031
20.166.1.701 CKR_WRAPPED_KEY_INVALID	1031
20.166.1.702 CKR_WRAPPED_KEY_LEN_RANGE	1031
20.166.1.703 CKR_WRAPPING_KEY_HANDLE_INVALID	1032
20.166.1.704 CKR_WRAPPING_KEY_SIZE_RANGE	1032
20.166.1.705 CKR_WRAPPING_KEY_TYPE_INCONSISTENT	1032
20.166.1.706 CKS_RO_PUBLIC_SESSION	1032
20.166.1.707 CKS_RO_USER_FUNCTIONS	1032
20.166.1.708 CKS_RW_PUBLIC_SESSION	1032
20.166.1.709 CKS_RW_SO_FUNCTIONS	1032
20.166.1.710 CKS_RW_USER_FUNCTIONS	1032
20.166.1.711 CKU_CONTEXT_SPECIFIC	1033
20.166.1.712 CKU_SO	1033
20.166.1.713 CKU_USER	1033
20.166.1.714 CKZ_DATA_SPECIFIED	1033
20.166.1.715 CKZ_SALT_SPECIFIED	1033
20.166.1.716 CRYPTOKI_VERSION_AMENDMENT	1033
20.166.1.717 CRYPTOKI_VERSION_MAJOR	1033
20.166.1.718 CRYPTOKI_VERSION_MINOR	1033
20.166.1.719 FALSE	1034
20.166.1.720 TRUE	1034
20.166.2 Typedef Documentation	1034
20.166.2.1 CK_AES_CBC_ENCRYPT_DATA_PARAMS	1034
20.166.2.2 CK_AES_CBC_ENCRYPT_DATA_PARAMS_PTR	1034
20.166.2.3 CK_AES_CCM_PARAMS	1034
20.166.2.4 CK_AES_CCM_PARAMS_PTR	1034
20.166.2.5 CK_AES_CTR_PARAMS	1034
20.166.2.6 CK_AES_CTR_PARAMS_PTR	1035
20.166.2.7 CK_AES_GCM_PARAMS	1035
20.166.2.8 CK_AES_GCM_PARAMS_PTR	1035
20.166.2.9 CK_ARIA_CBC_ENCRYPT_DATA_PARAMS	1035
20.166.2.10 CK_ARIA_CBC_ENCRYPT_DATA_PARAMS_PTR	1035

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XCVİ

20.166.2.11 CK_ALTRIBUTE
20.166.2.12 CK_ATTRIBUTE_PTR
20.166.2.13 CK_ATTRIBUTE_TYPE
20.166.2.14 CK_BBOOL
20.166.2.15 CK_BYTE
20.166.2.16 CK_BYTE_PTR
20.166.2.17 CK_C_INITIALIZE_ARGS
20.166.2.18 CK_C_INITIALIZE_ARGS_PTR
20.166.2.19 CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS
20.166.2.20 CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS_PTR
20.166.2.21 CK_CAMELLIA_CTR_PARAMS
20.166.2.22 CK_CAMELLIA_CTR_PARAMS_PTR
20.166.2.23 CK_CCM_PARAMS
20.166.2.24 CK_CCM_PARAMS_PTR
20.166.2.25 CK_CERTIFICATE_CATEGORY
20.166.2.26 CK_CERTIFICATE_TYPE
20.166.2.27 CK_CHAR
20.166.2.28 CK_CHAR_PTR
20.166.2.29 CK_CMS_SIG_PARAMS
20.166.2.30 CK_CMS_SIG_PARAMS_PTR
20.166.2.31 CK_DATE
20.166.2.32 CK_DES_CBC_ENCRYPT_DATA_PARAMS
20.166.2.33 CK_DES_CBC_ENCRYPT_DATA_PARAMS_PTR
20.166.2.34 CK_DSA_PARAMETER_GEN_PARAM
20.166.2.35 CK_DSA_PARAMETER_GEN_PARAM_PTR
20.166.2.36 CK_EC_KDF_TYPE
20.166.2.37 CK_ECDH1_DERIVE_PARAMS
20.166.2.38 CK_ECDH1_DERIVE_PARAMS_PTR
20.166.2.39 CK_ECDH2_DERIVE_PARAMS
20.166.2.40 CK_ECDH2_DERIVE_PARAMS_PTR
20.166.2.41 CK_ECDH_AES_KEY_WRAP_PARAMS
20.166.2.42 CK_ECDH_AES_KEY_WRAP_PARAMS_PTR
20.166.2.43 CK_ECMQV_DERIVE_PARAMS
20.166.2.44 CK_ECMQV_DERIVE_PARAMS_PTR
20.166.2.45 CK_EXTRACT_PARAMS
20.166.2.46 CK_EXTRACT_PARAMS_PTR
20.166.2.47 CK_FLAGS
20.166.2.48 CK_FUNCTION_LIST
20.166.2.49 CK_FUNCTION_LIST_PTR
20.166.2.50 CK_FUNCTION_LIST_PTR_PTR
20.166.2.51 CK_GCM_PARAMS
20.166.2.52 CK_GCM_PARAMS_PTR

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 XCVİİ

20.166.2.53 CK_GOSTR3410_DERIVE_PARAMS
20.166.2.54 CK_GOSTR3410_DERIVE_PARAMS_PTR
20.166.2.55 CK_GOSTR3410_KEY_WRAP_PARAMS
20.166.2.56 CK_GOSTR3410_KEY_WRAP_PARAMS_PTR
20.166.2.57 CK_HW_FEATURE_TYPE
20.166.2.58 CK_INFO
20.166.2.59 CK_INFO_PTR
20.166.2.60 CK_JAVA_MIDP_SECURITY_DOMAIN
20.166.2.61 CK_KEA_DERIVE_PARAMS
20.166.2.62 CK_KEA_DERIVE_PARAMS_PTR
20.166.2.63 CK_KEY_DERIVATION_STRING_DATA
20.166.2.64 CK_KEY_DERIVATION_STRING_DATA_PTR
20.166.2.65 CK_KEY_TYPE
20.166.2.66 CK_KEY_WRAP_SET_OAEP_PARAMS
20.166.2.67 CK_KEY_WRAP_SET_OAEP_PARAMS_PTR
20.166.2.68 CK_KIP_PARAMS
20.166.2.69 CK_KIP_PARAMS_PTR
20.166.2.70 CK_LONG
20.166.2.71 CK_MAC_GENERAL_PARAMS
20.166.2.72 CK_MAC_GENERAL_PARAMS_PTR
20.166.2.73 CK_MECHANISM
20.166.2.74 CK_MECHANISM_INFO
20.166.2.75 CK_MECHANISM_INFO_PTR
20.166.2.76 CK_MECHANISM_PTR
20.166.2.77 CK_MECHANISM_TYPE
20.166.2.78 CK_MECHANISM_TYPE_PTR
20.166.2.79 CK_NOTIFICATION
20.166.2.80 CK_OBJECT_CLASS
20.166.2.81 CK_OBJECT_CLASS_PTR
20.166.2.82 CK_OBJECT_HANDLE
20.166.2.83 CK_OBJECT_HANDLE_PTR
20.166.2.84 CK_OTP_PARAM
20.166.2.85 CK_OTP_PARAM_PTR
20.166.2.86 CK_OTP_PARAM_TYPE
20.166.2.87 CK_OTP_PARAMS
20.166.2.88 CK_OTP_PARAMS_PTR
20.166.2.89 CK_OTP_SIGNATURE_INFO
20.166.2.90 CK_OTP_SIGNATURE_INFO_PTR
20.166.2.91 CK_PARAM_TYPE
20.166.2.92 CK_PBE_PARAMS
20.166.2.93 CK_PBE_PARAMS_PTR
20 166 2 94 CK PKCS5 PRKD2 PARAMS 1046

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XCVIII

20.166.2.95 CK_PKCS5_PBKD2_PARAMS21046
20.166.2.96 CK_PKCS5_PBKD2_PARAMS2_PTR
20.166.2.97 CK_PKCS5_PBKD2_PARAMS_PTR
20.166.2.98 CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_TYPE
20.166.2.99 CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_TYPE_PTR 1046
20.166.2.100 CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE
20.166.2.101 CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE_PTR
20.166.2.102 CK_RC2_CBC_PARAMS
20.166.2.103 CK_RC2_CBC_PARAMS_PTR
20.166.2.104 CK_RC2_MAC_GENERAL_PARAMS
20.166.2.105 CK_RC2_MAC_GENERAL_PARAMS_PTR
20.166.2.106 CK_RC2_PARAMS
20.166.2.107 CK_RC2_PARAMS_PTR
20.166.2.108 CK_RC5_CBC_PARAMS
20.166.2.109 CK_RC5_CBC_PARAMS_PTR
20.166.2.110 CK_RC5_MAC_GENERAL_PARAMS
20.166.2.111 CK_RC5_MAC_GENERAL_PARAMS_PTR
20.166.2.112 CK_RC5_PARAMS
20.166.2.113 CK_RC5_PARAMS_PTR
20.166.2.114 CK_RSA_AES_KEY_WRAP_PARAMS
20.166.2.115 CK_RSA_AES_KEY_WRAP_PARAMS_PTR
20.166.2.116 CK_RSA_PKCS_MGF_TYPE
20.166.2.117 CK_RSA_PKCS_MGF_TYPE_PTR
20.166.2.118 CK_RSA_PKCS_OAEP_PARAMS
20.166.2.119 CK_RSA_PKCS_OAEP_PARAMS_PTR
20.166.2.120 CK_RSA_PKCS_OAEP_SOURCE_TYPE
20.166.2.121 CK_RSA_PKCS_OAEP_SOURCE_TYPE_PTR
20.166.2.122 CK_RSA_PKCS_PSS_PARAMS
20.166.2.123 CK_RSA_PKCS_PSS_PARAMS_PTR
20.166.2.124 CK_RV
20.166.2.125 CK_SEED_CBC_ENCRYPT_DATA_PARAMS
20.166.2.126 CK_SEED_CBC_ENCRYPT_DATA_PARAMS_PTR
20.166.2.127 CK_SESSION_HANDLE
20.166.2.128 CK_SESSION_HANDLE_PTR
20.166.2.129 CK_SESSION_INFO
20.166.2.130 CK_SESSION_INFO_PTR
20.166.2.131 CK_SKIPJACK_PRIVATE_WRAP_PARAMS
20.166.2.132 CK_SKIPJACK_PRIVATE_WRAP_PARAMS_PTR1050
20.166.2.133 CK_SKIPJACK_RELAYX_PARAMS
20.166.2.134 CK_SKIPJACK_RELAYX_PARAMS_PTR
20.166.2.135 CK_SLOT_ID
20.166.2.136 CK_SLOT_ID_PTR

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 XCİX

20.166.2.137 CK_SLOT_INFO
20.166.2.138 CK_SLOT_INFO_PTR
20.166.2.139 CK_SSL3_KEY_MAT_OUT
20.166.2.140 CK_SSL3_KEY_MAT_OUT_PTR
20.166.2.141 CK_SSL3_KEY_MAT_PARAMS
20.166.2.142 CK_SSL3_KEY_MAT_PARAMS_PTR
20.166.2.143 CK_SSL3_MASTER_KEY_DERIVE_PARAMS
20.166.2.144 CK_SSL3_MASTER_KEY_DERIVE_PARAMS_PTR
20.166.2.145 CK_SSL3_RANDOM_DATA
20.166.2.146 CK_STATE
20.166.2.147 CK_TLS12_KEY_MAT_PARAMS
20.166.2.148 CK_TLS12_KEY_MAT_PARAMS_PTR
20.166.2.149 CK_TLS12_MASTER_KEY_DERIVE_PARAMS
20.166.2.150 CK_TLS12_MASTER_KEY_DERIVE_PARAMS_PTR1053
20.166.2.151 CK_TLS_KDF_PARAMS
20.166.2.152 CK_TLS_KDF_PARAMS_PTR
20.166.2.153 CK_TLS_MAC_PARAMS
20.166.2.154 CK_TLS_MAC_PARAMS_PTR
20.166.2.155 CK_TLS_PRF_PARAMS
20.166.2.156 CK_TLS_PRF_PARAMS_PTR
20.166.2.157 CK_TOKEN_INFO
20.166.2.158 CK_TOKEN_INFO_PTR
20.166.2.159 CK_ULONG
20.166.2.160 CK_ULONG_PTR
20.166.2.161 CK_USER_TYPE
20.166.2.162 CK_UTF8CHAR
20.166.2.163 CK_UTF8CHAR_PTR
20.166.2.164 CK_VERSION
20.166.2.165 CK_VERSION_PTR
20.166.2.166 CK_VOID_PTR
20.166.2.167 CK_VOID_PTR_PTR
20.166.2.168 CK_WTLS_KEY_MAT_OUT
20.166.2.169 CK_WTLS_KEY_MAT_OUT_PTR
20.166.2.170 CK_WTLS_KEY_MAT_PARAMS
20.166.2.171 CK_WTLS_KEY_MAT_PARAMS_PTR
20.166.2.172 CK_WTLS_MASTER_KEY_DERIVE_PARAMS
20.166.2.173 CK_WTLS_MASTER_KEY_DERIVE_PARAMS_PTR 1055
20.166.2.174 CK_WTLS_PRF_PARAMS
20.166.2.175 CK_WTLS_PRF_PARAMS_PTR
20.166.2.176 CK_WTLS_RANDOM_DATA
20.166.2.177 CK_WTLS_RANDOM_DATA_PTR
20.166.2.178 CK_X9_42_DH1_DERIVE_PARAMS

© 2020 Microchip Technology Inc

20.166.2.179 CK_X9_42_DH1_DERIVE_PARAMS_PTR
20.166.2.180 CK_X9_42_DH2_DERIVE_PARAMS
20.166.2.181 CK_X9_42_DH2_DERIVE_PARAMS_PTR
20.166.2.182 CK_X9_42_DH_KDF_TYPE
20.166.2.183 CK_X9_42_DH_KDF_TYPE_PTR
20.166.2.184 CK_X9_42_MQV_DERIVE_PARAMS
20.166.2.185 CK_X9_42_MQV_DERIVE_PARAMS_PTR
20.166.2.186 event
20.166.2.187 pApplication
20.166.3 Function Documentation
20.166.3.1 CK_CALLBACK_FUNCTION() [1/5]
20.166.3.2 CK_CALLBACK_FUNCTION() [2/5]
20.166.3.3 CK_CALLBACK_FUNCTION() [3/5]
20.166.3.4 CK_CALLBACK_FUNCTION() [4/5]
20.166.3.5 CK_CALLBACK_FUNCTION() [5/5]
20.167 readme.md File Reference
20.168 README.md File Reference
20.169 README.md File Reference
20.170 README.md File Reference
20.171 README.md File Reference
20.172 README.md File Reference
20.173 README.md File Reference
20.174 README.md File Reference
20.175 README.md File Reference
20.176 README.md File Reference
20.177 README.md File Reference
20.178 secure_boot.c File Reference
20.178.1 Detailed Description
20.178.2 Function Documentation
20.178.2.1 bind_host_and_secure_element_with_io_protection()
20.178.2.2 secure_boot_process()
20.179 secure_boot.h File Reference
20.179.1 Detailed Description
20.179.2 Macro Definition Documentation
20.179.2.1 SECURE_BOOT_CONFIG_DISABLE
20.179.2.2 SECURE_BOOT_CONFIG_FULL_BOTH
20.179.2.3 SECURE_BOOT_CONFIG_FULL_DIG
20.179.2.4 SECURE_BOOT_CONFIG_FULL_SIGN
20.179.2.5 SECURE_BOOT_CONFIGURATION
20.179.2.6 SECURE_BOOT_DIGEST_ENCRYPT_ENABLED
20.179.2.7 SECURE_BOOT_UPGRADE_SUPPORT
20.179.3 Function Documentation

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Cİ

20.179.3.1 bind_host_and_secure_element_with_io_protection()
20.179.3.2 host_generate_random_number()
20.179.3.3 secure_boot_process()
20.180 secure_boot_memory.h File Reference
20.180.1 Detailed Description
20.180.2 Function Documentation
20.180.2.1 secure_boot_check_full_copy_completion()
20.180.2.2 secure_boot_deinit_memory()
20.180.2.3 secure_boot_init_memory()
20.180.2.4 secure_boot_mark_full_copy_completion()
20.180.2.5 secure_boot_read_memory()
20.180.2.6 secure_boot_write_memory()
20.181 sha1_routines.c File Reference
20.181.1 Detailed Description
20.181.2 Function Documentation
20.181.2.1 CL_hash()
20.181.2.2 CL_hashFinal()
20.181.2.3 CL_hashInit()
20.181.2.4 CL_hashUpdate()
20.181.2.5 shaEngine()
20.182 sha1_routines.h File Reference
20.182.1 Detailed Description
20.182.2 Macro Definition Documentation
20.182.2.1 _NOP
20.182.2.2 _WDRESET
20.182.2.3 leftRotate
20.182.2.4 memcpy_P
20.182.2.5 strcpy_P
20.182.2.6 U16
20.182.2.7 U32
20.182.2.8 U8
20.182.3 Function Documentation
20.182.3.1 CL_hash()
20.182.3.2 CL_hashFinal()
20.182.3.3 CL_hashInit()
20.182.3.4 CL_hashUpdate()
20.182.3.5 shaEngine()
20.183 sha2_routines.c File Reference
20.183.1 Detailed Description
20.183.2 Macro Definition Documentation
20.183.2.1 rotate_right
20.183.3 Function Documentation

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Cİİ

20.183.3.1 sw_sha256()
20.183.3.2 sw_sha256_final()
20.183.3.3 sw_sha256_init()
20.183.3.4 sw_sha256_update()
20.184 sha2_routines.h File Reference
20.184.1 Detailed Description
20.184.2 Macro Definition Documentation
20.184.2.1 SHA256_BLOCK_SIZE
20.184.2.2 SHA256_DIGEST_SIZE
20.184.3 Function Documentation
20.184.3.1 sw_sha256()
20.184.3.2 sw_sha256_final()
20.184.3.3 sw_sha256_init()
20.184.3.4 sw_sha256_update()
20.185 swi_uart_samd21_asf.c File Reference
20.185.1 Detailed Description
20.186 swi_uart_samd21_asf.h File Reference
20.186.1 Detailed Description
20.187 swi_uart_start.c File Reference
20.187.1 Detailed Description
20.187.2 Macro Definition Documentation
20.187.2.1 USART_BAUD_RATE
20.188 swi_uart_start.h File Reference
20.188.1 Detailed Description
20.189 symmetric_authentication.c File Reference
20.189.1 Detailed Description
20.189.2 Function Documentation
20.189.2.1 symmetric_authenticate()
20.190 symmetric_authentication.h File Reference
20.190.1 Detailed Description
20.190.2 Function Documentation
20.190.2.1 symmetric_authenticate()
20.191 tflxtls_cert_def_4_device.c File Reference
20.191.1 Detailed Description
20.191.2 Variable Documentation
20.191.2.1 g_tflxtls_cert_elements_4_device
20.191.2.2 g_tflxtls_cert_template_4_device
20.192 tflxtls_cert_def_4_device.h File Reference
20.192.1 Detailed Description
20.193 tng_atca.c File Reference
20.193.1 Detailed Description
20 194 trg. atca h File Reference

© 2020 Microchip Technology Inc Crypto AuthLib v3.2.3 Ciji

20.194.1 Detailed Description
20.195 tng_atcacert_client.c File Reference
20.195.1 Detailed Description
20.195.2 Function Documentation
20.195.2.1 tng_atcacert_device_public_key()
20.195.2.2 tng_atcacert_max_signer_cert_size()
20.195.2.3 tng_atcacert_read_device_cert()
20.195.2.4 tng_atcacert_read_signer_cert()
20.195.2.5 tng_atcacert_root_cert()
20.195.2.6 tng_atcacert_root_cert_size()
20.195.2.7 tng_atcacert_root_public_key()
20.195.2.8 tng_atcacert_signer_public_key()
20.196 tng_atcacert_client.h File Reference
20.196.1 Detailed Description
20.197 tng_root_cert.c File Reference
20.197.1 Detailed Description
20.197.2 Variable Documentation
20.197.2.1 g_cryptoauth_root_ca_002_cert
20.197.2.2 g_cryptoauth_root_ca_002_cert_size
20.198 tng_root_cert.h File Reference
20.198.1 Detailed Description
20.199 tnglora_cert_def_1_signer.c File Reference
20.199.1 Detailed Description
20.199.2 Variable Documentation
20.199.2.1 g_tngtls_cert_elements_1_signer
20.199.2.2 g_tngtls_cert_template_1_signer
20.200 tnglora_cert_def_1_signer.h File Reference
20.200.1 Detailed Description
20.201 tnglora_cert_def_2_device.c File Reference
20.201.1 Detailed Description
20.201.2 Variable Documentation
20.201.2.1 g_tngtls_cert_elements_2_device
20.201.2.2 g_tngtls_cert_template_2_device
20.202 tnglora_cert_def_2_device.h File Reference
20.202.1 Detailed Description
20.203 tnglora_cert_def_4_device.c File Reference
20.203.1 Detailed Description
20.203.2 Variable Documentation
20.203.2.1 g_tnglora_cert_def_4_device
20.203.2.2 g_tnglora_cert_elements_4_device
20.203.2.3 g_tnglora_cert_template_4_device
20.204 tnglora_cert_def_4_device.h File Reference

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 CİV

2	.204.1 Detailed Description
20.205	ngtls_cert_def_1_signer.c File Reference
2	.205.1 Detailed Description
2	.205.2 Variable Documentation
	20.205.2.1 g_tngtls_cert_def_1_signer
	20.205.2.2 g_tngtls_cert_elements_1_signer
	20.205.2.3 g_tngtls_cert_template_1_signer
20.206	ngtls_cert_def_1_signer.h File Reference
2	.206.1 Detailed Description
20.207	ngtls_cert_def_2_device.c File Reference
2	.207.1 Detailed Description
2	.207.2 Variable Documentation
	20.207.2.1 g_tngtls_cert_def_2_device
	20.207.2.2 g_tngtls_cert_elements_2_device
	20.207.2.3 g_tngtls_cert_template_2_device
20.208	ngtls_cert_def_2_device.h File Reference
2	.208.1 Detailed Description
20.209	ngtls_cert_def_3_device.c File Reference
2	.209.1 Detailed Description
2	.209.2 Variable Documentation
	20.209.2.1 g_tngtls_cert_def_3_device
	20.209.2.2 g_tngtls_cert_elements_3_device
	20.209.2.3 g_tngtls_cert_template_3_device
20.210	ngtls_cert_def_3_device.h File Reference
2	.210.1 Detailed Description
20.211	rust_pkcs11_config.c File Reference
2	.211.1 Detailed Description
la da	
Index	1099

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 CV

## **Chapter 1**

## License

mbedTLS Interface Functions that enable mbedtls objects to use cryptoauthlib functions

Replace mbedTLS ECDSA Functions with hardware acceleration & hardware key security.

Subject to your compliance with these terms, you may use Microchip software and any derivatives exclusively with Microchip products. It is your responsibility to comply with third party license terms applicable to your use of third party software (including open source software) that may accompany Microchip software.

THIS SOFTWARE IS SUPPLIED BY MICROCHIP "AS IS". NO WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, APPLY TO THIS SOFTWARE, INCLUDING ANY IMPLIED WARRANTIES OF NON-INFRING ← EMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS, DAMAGE, COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE SOFTWARE, HOWEVER CAUSED, E ← VEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS SOFTWARE.

Replace mbedTLS ECDH Functions with hardware acceleration & hardware key security.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

Subject to your compliance with these terms, you may use Microchip software and any derivatives exclusively with Microchip products. It is your responsibility to comply with third party license terms applicable to your use of third party software (including open source software) that may accompany Microchip software.

THIS SOFTWARE IS SUPPLIED BY MICROCHIP "AS IS". NO WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, APPLY TO THIS SOFTWARE, INCLUDING ANY IMPLIED WARRANTIES OF NON-INFRING ← EMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS, DAMAGE, COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE SOFTWARE, HOWEVER CAUSED, E ← VEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS SOFTWARE.

Replace mbedTLS ECDSA Functions with hardware acceleration & hardware key security

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

Subject to your compliance with these terms, you may use Microchip software and any derivatives exclusively with Microchip products. It is your responsibility to comply with third party license terms applicable to your use of third party software (including open source software) that may accompany Microchip software.

THIS SOFTWARE IS SUPPLIED BY MICROCHIP "AS IS". NO WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, APPLY TO THIS SOFTWARE, INCLUDING ANY IMPLIED WARRANTIES OF NON-INFRING  $\leftarrow$  EMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS, DAMAGE, COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE SOFTWARE, HOWEVER CAUSED, E  $\leftarrow$  VEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS SOFTWARE.

mbedTLS Interface Functions that enable mbedtls objects to use cryptoauthlib functions

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

Subject to your compliance with these terms, you may use Microchip software and any derivatives exclusively with Microchip products. It is your responsibility to comply with third party license terms applicable to your use of third party software (including open source software) that may accompany Microchip software.

THIS SOFTWARE IS SUPPLIED BY MICROCHIP "AS IS". NO WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, APPLY TO THIS SOFTWARE, INCLUDING ANY IMPLIED WARRANTIES OF NON-INFRING ← EMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS, DAMAGE, COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE SOFTWARE, HOWEVER CAUSED, E ← VEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS SOFTWARE.

# calib directory - Purpose

The purpose of this directory is to contain the files implementing the APIs for a basic interface to the core Crypto← AuthLib library.

High-level functions like these make it very convenient to use the library when standard configurations and defaults are in play. They are the easiest to use when developing examples or trying to understand the "flow" of an authentication operation without getting overwhelmed by the details.

This makes simple jobs easy and if you need more sophistication and power, you can employ the full power of the CryptoAuthLib object model.

See the Doxygen documentation in cryptoauthlib/docs for details on the API of the calib commands.

# crypto directory - Purpose

This directory contains software implementations of cryptographic functions. The functions at the base level are wrappers that will point to the final implementations of the software crypto functions.

# **HAL Directory - Purpose**

This directory contains all the Hardware Abstraction Layer (HAL) files used to adapt the upper levels of atca-ng and abstractions to physical hardware.

HAL contains physical implementations for I2C, SWI, SPI, UART and timers for specific hardware platforms.

Include just those HAL files you require based on platform type.

### CryptoAuthLib Supported HAL Layers

HAL Layers files are combined into groups. Initial group is generic files that are typically included in a project. Files are then broken out by uController Family and or Operating System Interface.

Protocol Files	Interface	Files	API	Notes
atca		atca_hal.c/h		For all projects
kit protocol		kit_protocol.c/h		For all Kit Protocol projects
		kit_phy.h		

# Microchip Harmony 3 for all PIC32 & ARM products - Use the Harmony 3 Configurator to generate and configure prjects

Obtain library and configure using Harmony 3

Interface	Files	API	Notes
I2C	hal_i2c_harmony.c	plib.←	For all Harmony 3 based projects
		h	
SPI	hal_spi_harmony.c	plib.←	
		h	

#### Microchip 8 & 16 bit products - AVR, PIC16/18, PIC24/DSPIC

### **OS & RTOS integrations**

Use CMake to configure the library in Linux, Windows, and MacOS environments

os	Interface	Files	API	Notes
Linux	I2C	hal_linux_i2c_userspace.c/h	i2c-dev	
Linux	SPI	hal_linux_spi_userspace.c/h	spidev	
Linux/Mac		hal_linux.c		For all Linux/Mac projects
Windows		hal_windows.c		For all Windows projects
All	kit-hid	hal_all_platforms_kit_hidapi.c/h	hidapi	Works for Windows, Linux, and Mac
freeRTOS		hal_freertos.c		freeRTOS common routines

### Legacy Support - Atmel START for AVR, ARM based processesors (SAM)

Interface	Files	API	Notes
	hal_timer_start.c	START	Timer implementation
I2C	hal_i2c_start.c/h	START	
SWI	swi_uart_start.c/h	START	SWI using UART

### Legacy Support - ASF3 for ARM Cortex-m0 & Cortex-m based processors (SAM)

SAM Micros	Interface	Files	API	Notes
cortex-m0	I2C	hal_sam0_i2c_asf.c/h	ASF3	SAMD21, SAMB11, etc
cortex-m3/4/7	I2C	hal_sam_i2c_asf.c/h	ASF3	SAM4S, SAMG55, SAMV71, etc
all		hal_sam_timer_asf.c	ASF3	Common timer hal for all platforms

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3

# mbedtls directory - Purpose

This directory contains the interfacing and wrapper functions to integrate mbedtls as the software crypto library as well as provide eliptic curve cryptography (ECC) hardware acceleration.

# openssI directory - Purpose

This directory contains the interfacing and wrapper functions to integrate openssl as the software crypto library.

# **IP Protection with Symmetric Authentication**

The IP protection can be easily integrated to the existing projects. The user project should include symmetric\_authentication.c & symmetric\_authentication.h files which contains the api

• symmetric\_authenticate() - For Performing the authentication between host & device.

#### **User Considerations**

- The user should take care on how the master key should be stored on the MCU side.
- The api's in the file doesn't do the provisioning of the chip and user should take care of the provisioning.

With the provisioned cryptoauthentication device and after doing the cryptoauthlib initialisation, user should only be calling the function symmetric\_authenticate() with its necessary parameters for the authentication. The returned authentication status should be used in the application.

### **Examples**

For more information about IP protection and its example project refer Microchip github

# Setting up cryptoauthlib as a PKCS11 Provider for your system (LINUX)

These instructions are for building, installing and configuring cryptoauthlib as a pkcs11 provider. These instructions are for commonly available Linux systems with package managers.

### Update libp11 on the system. The version should be at minimum 0.4.10

· Install the build dependendencies for the system:

```bash

### **Debian like systems**

```
$ sudo apt-get build-dep libengine-pkcs11-openssl1.1 ```
```bash
```

### **RPM** based systems

```
$ yum-builddep engine-pkcs11 ```
```

· Change to a sane directory

```
```bash cd \sim ```
```

• Get the latest version of libp11

```
""bash $ git clone https://github.com/OpenSC/libp11.git"
```

· Rerun the build configuration tools:

```
" $ cd libp11 $ ./bootstrap $ ./configure "
```

· Build the library:

```
```bash $ make ```
```

· Install the library:

```
"bash $ sudo make install "
```

#### Build and Install cryptoauthlib with PKCS11 support

• Install the build dependencies for the system:

```
```bash
```

### **Debian like systems**

```
$ sudo apt-get install cmake libudev-dev ```
```bash
```

### **RPM** based systems

\$ yum install cmake \$ yum install libudev-devel ```

· Change to a sane directory

```
```bash cd \sim ```
```

· Get the latest version of cryptoauthlib with PKCS11 support

```
""bash $ git clone -single-branch -b pkcs11 https://github.com/MicrochipTech/cryptoauthlib
```

· Rerun the build configuration tools:

```
```bash $ cd cryptoauthlib $ cmake . ```
```

· Build the library:

```
```bash $ make ```
```

· Install the library:

### Configuring the cryptoauthlib PKCS11 library

By default the following files will be created.

· /etc/cryptoauthlib/cryptoauthlib.conf

```text

# **Cryptoauthlib Configuration File**

filestore = /var/lib/cryptoauthlib ```

· /var/lib/cryptoauthlib/slot.conf.tmpl

```text

<sup>&</sup>quot;bash \$ sudo make install "

### **Reserved Configuration for a device**

The objects in this file will be created and marked as undeletable

These are processed in order. Configuration parameters must be comma

### delimited and may not contain spaces

interface = i2c,0xB0 freeslots = 1,2,3

### Slot 0 is the primary private key

object = private, device, 0

### Slot 10 is the certificate data for the device's public key

#object = certificate, device, 10

### Slot 12 is the intermedate/signer certificate data

#object = certificate, signer, 12

### Slot 15 is a public key

object = public,root,15 ```

#### cryptoauthlib.conf

This file provides the basic configuation information for the library. The only variable is "filestore" which is where cryptoauthlib will find device specific configuration and where it will store object files from pkcs11 operations.

#### slot.conf.tmpl

This is a template for device configuration files that cryptoauthlib will use to map devices and their resources into pkcs11 tokens and objects.

A device file must be named <pkcs11\_slot\_number>.conf

#### For a single device:

\$ cd /var/lib/cryptoauthlib \$ cp slot.conf.tmpl 0.conf

Then edit 0.conf to match the device configuration being used.

**interface** Allows values: 'hid', 'i2c' If using i2c specify the address in hex for the device. This is in the device format (upper 7 bits define the address) so will not appear the same as the i2cdetect address (lower 7 bits)

**freeslots** This is a list of slots that may be used by the library when a pkcs11 operation that creates new objects is used. When the library is initialized it will scan for files of the form <pkcs11\_slot\_num>.<device\_slot\_num>.conf which defines the object using that device resource.

#### Using p11-kit-proxy

This is an optional step but is very helpful for using multiple pkcs11 libraries in a system. Detailed setup can be

```
found at p11-glue
# Debian like systems
$ sudo apt-get install p11-kit
# RPM based systems
$ yum install p11-kit
```

• Create or edit the global configuration file /etc/pkcs11/pkcs11.conf. The directory /etc/pkcs11 may require creation first.

...

This setting controls whether to load user configuration from the

 $\sim$ /.config/pkcs11 directory. Possible values:

none: No user configuration

merge: Merge the user config over the system configuration (default)

only: Only user configuration, ignore system configuration

```
user-config: merge ```
```

- · Create a module configuration file.
  - User module name (only available for a single user): ~/.config/pkcs11/modules/cryptoauthlib. ← module
  - Global module name (available to the whole system): /usr/share/pl1-kit/modules/cryptoauthlib.modu
    "" module: /usr/lib/libcryptoauth.so critical: yes trust-policy: yes managed: yes log-calls: no ""

For more details on the configuration files see the configuration documentation.

#### Without using p11-kit-proxy

OpenSSL (via the libp11 project above) and p11tool support p11-kit-proxy natively so do not require additional set up if it is being used. If p11-kit-proxy is not being used then OpenSSL will have to be manually configured to use libp11 and cryptoauthlib

This requires editing the default openssl.cnf file. To locate the file being used by the system run the following command:

```
$ openssl version -a | grep OPENSSLDIR:
OPENSSLDIR: "/usr/lib/ssl"
```

This gives the default path where openssl is compiled to find the openssl.cnf file

In this case the file to edit will be /usr/lib/ssl/openssl.cnf

This line must be placed at the top, before any sections are defined:

```
openssl_conf = openssl_init
```

This should be added to the bottom of the file:

```
[openssl_init]
engines=engine_section
[engine_section]
pkcs11 = pkcs11_section
[pkcs11_section]
engine_id = pkcs11
# Wherever the engine installed by libp11 is. For example it could be:
# /usr/lib/arm-linux-gnueabihf/engines-1.1/libpkcs11.so
dynamic_path = /usr/lib/ssl/engines/libpkcs11.so
MODULE_PATH = /usr/lib/libcryptoauth.so
init = 0
```

#### **Testing**

#### To use p11tool it has to be installed:

```
# Debian like systems
$ sudo apt-get install gnutls-bin
# RPM based systems
$ yum install gnutls-utils
```

**Note**: If not using p11-kit-proxy then the provider has to be specified in p11tool calls:

```
$ p11tool --provider=/usr/lib/libcryptoauth.so
```

- Get the public key for a private key (as defined by the 0.conf file cited above):
  - ```bash \$ p11tool —export-pubkey "pkcs11:token=0123EE;object=device;type=private" warning: —login was not specified and it may be required for this operation. warning: no —outfile was specified and the public key will be printed on screen. --—BEGIN PUBLIC KEY-— MFkwEwYHKoZIzj0CAQYIKoZIzj0DAQcDQg AE9wzUq1EUAoNrG01rXYjNd35mxKuA Ojw/kIIrNEBciSLLOTLjs/gvFS7N8AFXDK18vpxxu6ykzF2LRd7R Y8yEFw== --—END PUBLIC KEY-— ```
- · Get the public key and decode it using OpenSSL
  - ```bash \$ p11tool —export-pubkey "pkcs11:token=0123EE;object=device;type=private" | openssl pkey -pubin -text -noout warning: —login was not specified and it may be required for this operation. warning: no —outfile was specified and the public key will be printed on screen. Public-Key: (256 bit) pub: 04:f7:0c:d4:ab:51 ← :14:02:83:6b:1b:4d:6b:5d:88: cd:77:7e:66:c4:ab:80:3a:3c:3f:92:52:2b:34:40: 5c:89:22:cb:39:32:e3:b3:f8:2f ← :15:2e:cd:f0:01: 57:0c:ad:7c:be:9c:71:bb:ac:a4:cc:5d:8b:45:de: d1:63:cc:84:17 ASN1 OID: prime256v1 NIST CURVE: P-256 ```

#### · Create a CSR for the private key

"bash \$ openssl req -engine pkcs11 -key "pkcs11:token=0123EE;object=device;type=private" -keyform engine -new -out new device.csr -subj "/CN=NEW CSR EXAMPLE" engine "pkcs11" set.

\$ cat new\_device.csr ----BEGIN CERTIFICATE REQUEST---- MIHVMHwCAQAwGjEYMBYGA1UEAww PTkVXIENTUIBFWEFNUExFMFkwEwYHKoZIzj0C AQYIKoZIzj0DAQcDQgAE9wzUq1EUAoNrG01rXYj Nd35mxKuAOjw/kllrNEBciSLL OTLjs/gvFS7N8AFXDK18vpxxu6ykzF2LRd7RY8yEF6AAMAoGCCqGS M49BAMCA0kA MEYCIQDUPeLfPcOwtZxYJDYXPdI2UhpReVn6kK2lKCCX6byM8QlhAlfqfnggtcCi W21x LAzabr8A4mHyfIIQ1ofYBg8QO9jZ ----END CERTIFICATE REQUEST---- ```

#### · Verify the newly created csr

"bash \$ openssl req -in new\_device.csr -verify -text -noout verify OK Certificate Request: Data: Version: 1 (0x0) Subject: CN = NEW CSR EXAMPLE Subject Public Key Info: Public Key Algorithm: id-ecPublicKey Public-Key: (256 bit) pub: 04:f7:0c:d4:ab:51:14:02:83:6b:1b:4d:6b:5d:88: cd:77:7e:66:c4:ab:80:3a:3c:3f↔ :92:52:2b:34:40: 5c:89:22:cb:39:32:e3:b3:f8:2f:15:2e:cd:f0:01: 57:0c:ad:7c:be:9c:71:bb:ac:a4:cc:5d:8b:45↔ :de: d1:63:cc:84:17 ASN1 OID: prime256v1 NIST CURVE: P-256 Attributes: a0:00 Signature Algorithm↔ : ecdsa-with-SHA256 30:46:02:21:00:d4:3d:e2:df:3d:c3:b0:b5:9c:58:24:36:17: 3d:d9:76:52:1a:51:79:59:fa↔ :90:ad:a5:28:20:97:e9:bc:8c: f1:02:21:00:87:ea:7e:78:20:b5:c0:a2:5b:6d:71:2c:0c:da: 6e:bf:00:e2:61:f2:7c↔ :82:10:d6:87:d8:06:0f:10:3b:d8:d9 ```

# app directory - Purpose

This directory is for application specific implementation of various use cases.

Methods in this directory provide a simple API to perform potentially complex combinations of calls to the main library or API.

# **Secure boot using ATECC608**

The SecureBoot command is a new feature on the ATECC608A device compared to earlier CryptoAuthentication devices from Microchip. This feature helps the MCU to identify fraudulent code installed on it. When this feature is implemented, the MCU can send a firmware digest and signature to the ATECC608. The ATECC608 validates this information (ECDSA verify) and responds to host with a yes or no answer.

The ATECC608 provides options to reduce the firmware verification time by storing the signature or digest after a good full verification (FullStore mode of the SecureBoot command).

- When the ATECC608 stores the digest (SecureBootMode is FullDig), the host only needs to send the firmware digest, which is compared to the stored copy. This skips the comparatively lengthy ECDSA verify, speeding up the secure boot process.
- When the ATECC608 stores the signature (SecureBootMode is FullSig), the host only needs to send the firmware digest, which is verified against the stored signature using ECDSA. This saves time by not needing to send the signature in the command over the bus.

The ATECC608 also provides wire protection features for the SecureBoot command, which can be used to encrypt the digest being sent from the host to the ATECC608 and add a MAC to the verify result coming back to the host so it can't be forced to a success state. This feature makes use of a shared secret between the host and ATECC608, called the IO protection key.

The secure boot feature can be easily integrated to an existing project. The project should include the following files from the secure\_boot folder:

- secure\_boot.c
- secure\_boot.h
- · secure\_boot\_memory.h
- · io\_protection\_key.h

The project should also implement the following platform-specific APIs:

- secure boot init memory()
- secure\_boot\_read\_memory()
- secure\_boot\_deinit\_memory()

- secure\_boot\_mark\_full\_copy\_completion()
- · secure boot check full copy completion()
- io protection get key()
- io protection set key()

The project can set the secure boot configuration with the following defines:

- SECURE\_BOOT\_CONFIGURATION
- SECURE\_BOOT\_DIGEST\_ENCRYPT\_ENABLED
- SECURE\_BOOT\_UPGRADE\_SUPPORT

The secure boot process is performed by initializing CryptoAuthLib and calling the secure\_boot\_process() function.

### Implementation Considerations

- Need to perform SHA256 calculations on the host. CryptoAuthLib provides a software implementation in lib/crypto/atca\_crypto\_sw\_sha2.c
- · When using the wire protection features:
  - The host needs to be able to generate a nonce (number used once). This is the NumIn parameter to the Nonce command that is sent before the SecureBoot command. The ATECC608 can not be used to generate NumIn, but it should come from a good random or non-repeating source in the host.
  - If the host has any protected internal memory, it should be used to store its copy of the IO protection key.
- Secure boot depends on proper protections of the boot loader code in the host. If the code can be easily changed, then the secure boot process can be easily skipped. Boot loader should ideally be stored in an immutable (unchangeable) location like a boot ROM or write-protected flash.
- Note that these APIs don't provision the ATECC608. They assume the ATECC608 has already been configured and provisioned with the necessary keys for secure boot.

### **Examples**

For more information about secure boot, please see the example implementation project and documentation at: https://github.com/MicrochipTech/cryptoauth\_usecase\_secureboot

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 24

# **TNG Functions**

This folder has a number of convenience functions for working with TNG devices (currently ATECC608A-MAHTN-T).

These devices have standard certificates that can be easily read using the functions in tng\_atcacert\_client.h

# CryptoAuthLib - Microchip CryptoAuthentication Library

#### Introduction

This library implements the APIs required to communicate with Microchip Security device. The family of devices supported currently are:

- ATSHA204A
- ATECC108A
- ATECC508A
- ATECC608A

The best place to start is with the Microchip Trust Platform

Online API documentation is at https://microchiptech.github.io/cryptoauthlib/

Latest software and examples can be found at:

- https://www.microchip.com/design-centers/security-ics/trust-platform
- http://www.microchip.com/SWLibraryWeb/product.aspx?product=CryptoAuth← Lib

Prerequisite hardware to run CryptoAuthLib examples:

• CryptoAuth Trust Platform Development Kit

Alternatively a Microchip MCU and Adapter Board:

- ATSAMR21 Xplained Pro or ATSAMD21 Xplained Pro
- CryptoAuth Xplained Pro Extension **or** CryptoAuthentication SOIC Socket Board **to accept SOIC parts**

For most development, using socketed top-boards is preferable until your configuration is well tested, then you can commit it to a CryptoAuth Xplained Pro Extension, for example. Keep in mind that once you lock a device, it will not be changeable.

### **Examples**

- Watch CryptoAuthLib Documents for new examples coming online.
- Node Authentication Example Using Asymmetric PKI is a complete, all-in-one example demonstrating all the stages of crypto authentication starting from provisioning the Crypto Authentication device ATECC608/← ATECC508A with keys and certificates to demonstrating an authentication sequence using asymmetric techniques. http://www.microchip.com/SWLibraryWeb/product.aspx?product=← CryptoAuthLib

### Configuration

In order to properly configured the library there must be a header file in your project named  $atca\_config. \leftarrow h$  at minimum this needs to contain defines for the hal and device types being used. Most integrations have an configuration mechanism for generating this file. See the  $atca\_config.h.in$  template which is configured by CMake for Linux, MacOS, & Windows projects.

An example of the configuration:

There are two major compiler defines that affect the operation of the library.

- ATCA\_NO\_POLL can be used to revert to a non-polling mechanism for device responses. Normally responses are polled for after sending a command, giving quicker response times. However, if ATCA\_NO\_
  POLL is defined, then the library will simply delay the max execution time of a command before reading the response.
- ATCA\_NO\_HEAP can be used to remove the use of malloc/free from the main library. This can be helpful for smaller MCUs that don't have a heap implemented. If just using the basic API, then there shouldn't be any code changes required. The lower-level API will no longer use the new/delete functions and the init/release functions should be used directly.

#### Release notes

See Release Notes

### **Host Device Support**

CryptoAuthLib will run on a variety of platforms from small micro-controllers to desktop host systems. The current list of hardware abstraction layer support includes:

Rich OS Hosts:

- · Linux Kit Protocol over HID USB
- · Linux I2C
- · Linux SPI
- · Windows Kit Protocol over HID USB

#### Microcontrollers:

· Microchip AVR, SAM, & PIC families. See hal readme

If you have specific microcontrollers or Rich OS platforms you need support for, please contact us through the Microchip portal with your request.

### CryptoAuthLib Architecture

Cryptoauthlib API documentation is at https://microchiptech.github.io/cryptoauthlib/

The library is structured to support portability to:

- multiple hardware/microcontroller platforms
- · multiple environments including bare-metal, RTOS and Windows/Linux/MacOS
- multiple chip communication protocols (I2C, SPI, and SWI)

All platform dependencies are contained within the HAL (hardware abstraction layer).

### **Directory Structure**

```
lib - primary library source code
lib/atcacert - certificate data and i/o methods
lib/calib - the Basic Cryptoauth API
lib/crypto - Software crypto implementations external crypto libraries support (primarily SHA1 and SHA256)
lib/hal - hardware abstraction layer code for supporting specific platforms
lib/nost - support functions for common host-side calculations
lib/jwt - json web token functions
test - Integration test and examples. See test/cmd-processor.c for main() implementation.
For production code, test directories should be excluded by not compiling it
into a project, so it is up to the developer to include or not as needed. Test
code adds significant bulk to an application - it's not intended to be included
in production code.
```

#### **Tests**

There is a set of integration tests found in the test directory which will at least partially demonstrate the use of the objects. Some tests may depend upon a certain device being configured in a certain way and may not work for all devices or specific configurations of the device.

The test/cmd-processor.c file contains a main() function for running the tests. It implements a command-line interface. Typing help will bring up the list of commands available.

One first selects a device type, with one of the following commands:

- 204 (ATSHA204A)
- 108 (ATECC108A)
- 508 (ATECC508A)
- 608 (ATECC608A/B)

From there the following unit test sweets are available:

- · unit (test command builder functions)
- · basic (test basic API functions)
- · cio (test certification i/o functions)
- cd (test certificate data functions)
- util (test utility functions)
- · crypto (test software crypto functions)

Tests available depend on the lock level of the device. The unit tests won't lock the config or data zones automatically to allow retesting at desired lock levels. Therefore, some commands will need to be repeated after locking to exercise all available tests.

Starting from a blank device, the sequence of commands to exercise all unit tests is:

unit
basic
lockefg
unit
basic
lockdata
unit
basic
cio
cd
util
crypto

## **Using CryptoAuthLib (Microchip CryptoAuth Library)**

The best place to start is with the Microchip Trust Platform

Also application examples are included as part of the Harmony 3 framework and can be copied from the Harmony Content Manager or found with the Harmony 3 Framework Cryptoauthlib\_apps

### Incorporating CryptoAuthLib in a Linux project using USB HID devices

The Linux HID HAL files use the Linux udev development software package.

To install the udev development package under Ubuntu Linux, please type the following command at the terminal window:

sudo apt-get install libudev-dev

This adds the udev development development software package to the Ubuntu Linux installation.

The Linux HID HAL files also require a udev rule to be added to change the permissions of the USB HID Devices. Please add a new udev rule for the Microchip CryptoAuth USB devices.

cd /etc/udev/rules.d sudo touch mchp-cryptoauth.rules

Edit the mchp-cryptoauth.rules file and add the following line to the file:

SUBSYSTEM=="hidraw", ATTRS{idVendor}=="03eb", ATTRS{idProduct}=="2312", MODE="0666"

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 31

# **Deprecated List**

#### Global atcab\_init\_device (ATCADevice ca\_device)

This function is not recommended for use generally. Use of \_ext is recommended instead. You can use atcab — \_init\_ext to obtain an initialized instance and associated it with the global structure - but this shouldn't be a required process except in extremely unusual circumstances.

# **Todo List**

#### Global pkcs11\_init (CK\_C\_INITIALIZE\_ARGS\_PTR plnitArgs)

This is where we should allocate a new context if we're using dynamic memory

If we're using dyamic memory we need to make sure to deallocate it if any of the errors after the allocations are encountered

#### Global pkcs11\_deinit (CK\_VOID\_PTR pReserved)

If other threads are waiting for something to happen this call should cause those calls to unblock and return CKR\_CRYPTOKI\_NOT\_INITIALIZED - How that is done by this simplified mutex API is yet to be determined

# **Module Index**

## 15.1 Modules

Here is a list of all modules:

| Basic Crypto API methods (atcab_)                        |
|----------------------------------------------------------|
| Configuration (cfg_)                                     |
| ATCACommand (atca_)                                      |
| ATCADevice (atca_)                                       |
| ATCAlface (atca_)                                        |
| Certificate manipulation methods (atcacert_)             |
| Basic Crypto API methods for CryptoAuth Devices (calib_) |
| Software crypto methods (atcac_)                         |
| Hardware abstraction layer (hal_)                        |
| Host side crypto methods (atcah_) 303                    |
| JSON Web Token (JWT) methods (atca_jwt_)                 |
| mbedTLS Wrapper methods (atca_mbedtls_)                  |
| Attributes (pkcs11_attrib_)                              |
| TNG API (tng.)                                           |

# **Chapter 16**

# **Data Structure Index**

## 16.1 Data Structures

Here are the data structures with brief descriptions:

| _atecc508a_config                                                                             | 381 |
|-----------------------------------------------------------------------------------------------|-----|
| _atecc608_config                                                                              | 384 |
| _atsha204a_config                                                                             | 389 |
| _pcks11_mech_table_e                                                                          | 392 |
| _pkcs11_attrib_model                                                                          | 392 |
| _pkcs11_lib_ctx                                                                               | 393 |
| _pkcs11_object                                                                                | 394 |
| _pkcs11_object_cache_t                                                                        | 396 |
| _pkcs11_session_ctx                                                                           | 397 |
| _pkcs11_slot_ctx                                                                              | 399 |
| atca_aes_cbc_ctx                                                                              | 401 |
| atca_aes_cmac_ctx                                                                             | 402 |
| atca_aes_ctr_ctx                                                                              | 403 |
| atca_aes_gcm_ctx                                                                              | 404 |
| atca_check_mac_in_out                                                                         |     |
| Input/output parameters for function atcah_check_mac()                                        | 407 |
| atca_command                                                                                  |     |
| Atca_command is the C object backing ATCACommand                                              | 409 |
| atca_decrypt_in_out                                                                           |     |
| Input/output parameters for function atca_decrypt()                                           | 410 |
| atca_derive_key_in_out                                                                        |     |
| Input/output parameters for function atcah_derive_key()                                       | 411 |
| atca_derive_key_mac_in_out                                                                    |     |
| Input/output parameters for function atcah_derive_key_mac()                                   | 412 |
| atca_device                                                                                   |     |
| Atca_device is the C object backing ATCADevice. See the atca_device.h file for details on the |     |
| ATCADevice methods                                                                            | 414 |
| atca_gen_dig_in_out                                                                           |     |
| Input/output parameters for function atcah_gen_dig()                                          | 415 |
| atca_gen_key_in_out                                                                           |     |
| Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey com- |     |
| mand with the atcah_gen_key_msg() function                                                    | 418 |
| atca_hmac_in_out                                                                              |     |
| Input/output parameters for function atca hmac()                                              | 419 |

| atca_iface                                                                                                     |      |
|----------------------------------------------------------------------------------------------------------------|------|
| Atca_iface is the C object backing ATCAlface. See the atca_iface.h file for details on the ATC← Alface methods | 420  |
| atca_include_data_in_out                                                                                       |      |
| Input / output parameters for function atca_include_data()                                                     | 422  |
| atca io decrypt in out                                                                                         | 422  |
| atca_jwt_t                                                                                                     |      |
| Structure to hold metadata information about the jwt being built                                               | 424  |
| atca_mac_in_out                                                                                                |      |
|                                                                                                                | 424  |
| atca_nonce_in_out                                                                                              |      |
| Input/output parameters for function atca_nonce()                                                              | 425  |
| atca_secureboot_enc_in_out                                                                                     | 426  |
| atca_secureboot_mac_in_out                                                                                     | 427  |
| atca_sha256_ctx                                                                                                | 429  |
| atca_sign_internal_in_out                                                                                      |      |
| Input/output parameters for calculating the message and digest used by the Sign(internal) com-                 |      |
| mand. Used with the atcah_sign_internal_msg() function                                                         | 429  |
| atca_temp_key                                                                                                  |      |
| Structure to hold TempKey fields                                                                               | 433  |
| atca_verify_in_out                                                                                             |      |
| Input/output parameters for function atcah_verify()                                                            | 435  |
| atca_verify_mac                                                                                                | 435  |
| atca_write_mac_in_out                                                                                          |      |
| Input/output parameters for function atcah_write_auth_mac() and atcah_privwrite_auth_mac()                     | 437  |
| atcacert_build_state_s                                                                                         | 439  |
| atcacert_cert_element_s                                                                                        | 441  |
| atcacert_cert_loc_s                                                                                            | 442  |
| atcacert_def_s                                                                                                 | 442  |
|                                                                                                                | 447  |
|                                                                                                                | 448  |
| ATCAHAL_t                                                                                                      |      |
| Intermediary data structure to allow the HAL layer to point the standard API functions used by                 |      |
| the upper layers to the HAL implementation for the interface. This isolates the upper layers and               | 4.40 |
|                                                                                                                | 449  |
| atcal2Cmaster                                                                                                  | 454  |
| <del>-</del>                                                                                                   | 451  |
| · · · · · · · · · · · · · · · · · · ·                                                                          | 452  |
| ATCAPacket                                                                                                     |      |
| atcaSWImaster                                                                                                  | 408  |
|                                                                                                                | 459  |
|                                                                                                                | 461  |
|                                                                                                                | 461  |
|                                                                                                                | 462  |
|                                                                                                                | 463  |
| CK_ARIA_CBC_ENCRYPT_DATA_PARAMS                                                                                | 464  |
| CK ATTRIBUTE                                                                                                   | 465  |
| CK C INITIALIZE ARGS                                                                                           | 466  |
| CK CAMELLIA CBC ENCRYPT DATA PARAMS                                                                            | 467  |
| CK CAMELLIA CTR PARAMS                                                                                         | 468  |
| CK CCM PARAMS                                                                                                  | 468  |
|                                                                                                                | 469  |
|                                                                                                                | 471  |
| CK DES CBC ENCRYPT DATA PARAMS                                                                                 | 471  |
|                                                                                                                | 472  |
| CK ECDH1 DERIVE PARAMS                                                                                         |      |
|                                                                                                                |      |
| CK ECDH2 DERIVE PARAMS                                                                                         | 474  |

| CK_ECDH_AES_KEY_WRAP_PARAMS       |
|-----------------------------------|
| CK_ECMQV_DERIVE_PARAMS            |
| CK_FUNCTION_LIST 478              |
| CK_GCM_PARAMS                     |
| CK_GOSTR3410_DERIVE_PARAMS        |
| CK GOSTR3410 KEY WRAP PARAMS      |
| CK INFO                           |
| CK KEA DERIVE PARAMS              |
| CK_KEY_DERIVATION_STRING_DATA     |
| CK_KEY_WRAP_SET_OAEP_PARAMS       |
| CK KIP PARAMS                     |
| CK MECHANISM                      |
| CK MECHANISM INFO                 |
| CK OTP PARAM                      |
| CK OTP PARAMS                     |
| CK OTP SIGNATURE INFO             |
| CK_PBE_PARAMS                     |
| CK PKCS5 PBKD2 PARAMS             |
| CK_PKCS5_PBKD2_PARAMS2            |
| CK_RC2_CBC_PARAMS                 |
|                                   |
| CK_RC2_MAC_GENERAL_PARAMS         |
| CK_RC5_CBC_PARAMS                 |
| CK_RC5_MAC_GENERAL_PARAMS         |
| CK_RC5_PARAMS                     |
| CK_RSA_AES_KEY_WRAP_PARAMS        |
| CK_RSA_PKCS_OAEP_PARAMS           |
| CK_RSA_PKCS_PSS_PARAMS            |
| CK_SEED_CBC_ENCRYPT_DATA_PARAMS   |
| CK_SESSION_INFO                   |
| CK_SKIPJACK_PRIVATE_WRAP_PARAMS   |
| CK_SKIPJACK_RELAYX_PARAMS         |
| CK_SLOT_INFO 505                  |
| CK_SSL3_KEY_MAT_OUT 506           |
| CK_SSL3_KEY_MAT_PARAMS            |
| CK_SSL3_MASTER_KEY_DERIVE_PARAMS  |
| CK_SSL3_RANDOM_DATA               |
| CK_TLS12_KEY_MAT_PARAMS           |
| CK_TLS12_MASTER_KEY_DERIVE_PARAMS |
| CK_TLS_KDF_PARAMS 511             |
| CK_TLS_MAC_PARAMS                 |
| CK_TLS_PRF_PARAMS                 |
| CK_TOKEN_INFO                     |
| CK_VERSION 517                    |
| CK_WTLS_KEY_MAT_OUT               |
| CK_WTLS_KEY_MAT_PARAMS            |
| CK_WTLS_MASTER_KEY_DERIVE_PARAMS  |
| CK WTLS PRF PARAMS                |
| CK WTLS RANDOM DATA               |
| CK X9 42 DH1 DERIVE PARAMS        |
| CK X9 42 DH2 DERIVE PARAMS        |
| CK X9 42 MQV DERIVE PARAMS        |
| CL HashContext                    |
| hw sha256 ctx                     |
| i2c sam0 instance                 |
| i2c sam instance                  |
| i2c start instance                |
| memory parameters                 |
| secure boot config bits           |
|                                   |

| secure_boot_parameters | 533 |
|------------------------|-----|
| sw_sha256_ctx          | 534 |
| tng cert man element   | 535 |

# **Chapter 17**

# File Index

## 17.1 File List

Here is a list of all files with brief descriptions:

| api_206a.c                                                                                                                                                                                                                                                                                                                            |       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| Provides APIs to use with ATSHA206A device                                                                                                                                                                                                                                                                                            | 537   |
| api_206a.h                                                                                                                                                                                                                                                                                                                            |       |
| Provides api interfaces to use with ATSHA206A device                                                                                                                                                                                                                                                                                  | 543   |
| atca_basic.c                                                                                                                                                                                                                                                                                                                          |       |
| CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core crypto methods                                                                                                                                                                                                                                | 551   |
| atca_basic.h                                                                                                                                                                                                                                                                                                                          |       |
| CryptoAuthLib Basic API methods - a simple crypto authentication API. These methods manage a global ATCADevice object behind the scenes. They also manage the wake/idle state transitions so callers don't need to                                                                                                                    | 5     |
| atca bool.h                                                                                                                                                                                                                                                                                                                           | 007   |
| Bool define for systems that don't have it                                                                                                                                                                                                                                                                                            | 565   |
| atca cfgs.c                                                                                                                                                                                                                                                                                                                           | 000   |
| Set of default configurations for various ATCA devices and interfaces                                                                                                                                                                                                                                                                 | 565   |
| atca cfgs.h                                                                                                                                                                                                                                                                                                                           |       |
| Set of default configurations for various ATCA devices and interfaces                                                                                                                                                                                                                                                                 | 565   |
| atca_command.c                                                                                                                                                                                                                                                                                                                        |       |
| Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send that byte string through the device interface | 5<br> |
| atca command.h                                                                                                                                                                                                                                                                                                                        |       |
| Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the ATCAIFace object to dispatch                                                                                                                |       |
| atca_compiler.h                                                                                                                                                                                                                                                                                                                       |       |
| CryptoAuthLiub is meant to be portable across architectures, even non-Microchip architectures and compiler environments. This file is for isolating compiler specific macros                                                                                                                                                          |       |
| atca_crypto_hw_aes.h                                                                                                                                                                                                                                                                                                                  |       |
| AES CTR, CBC & CMAC structure definitions                                                                                                                                                                                                                                                                                             | 569   |
| atca_crypto_hw_aes_cbc.c                                                                                                                                                                                                                                                                                                              |       |
| CryptoAuthLib Basic API methods for AES CBC mode                                                                                                                                                                                                                                                                                      | 570   |
| atca_crypto_hw_aes_cmac.c                                                                                                                                                                                                                                                                                                             |       |
| CryptoAuthLib Basic API methods for AES CBC_MAC mode                                                                                                                                                                                                                                                                                  | . 571 |

| atca_crypto_hw_aes_ctr.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| CryptoAuthLib Basic API methods for AES CTR mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | 572                                                         |
| atca_crypto_sw.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | F-74                                                        |
| Common defines for CryptoAuthLib software crypto wrappers                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 573                                                         |
| atca_crypto_sw_ecdsa.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                             |
| API wrapper for software ECDSA verify. Currently unimplemented but could be implemented via a 3rd party library such as MicroECC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                             |
| atca_crypto_sw_ecdsa.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                             |
| atca_crypto_sw_rand.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 578                                                         |
| API wrapper for software random                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 580                                                         |
| atca_crypto_sw_rand.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                             |
| atca_crypto_sw_sha1.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 300                                                         |
| Wrapper API for SHA 1 routines                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 581                                                         |
| atca_crypto_sw_sha1.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 50                                                          |
| Wrapper API for SHA 1 routines                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 581                                                         |
| atca_crypto_sw_sha2.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                             |
| Wrapper API for software SHA 256 routines                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 582                                                         |
| atca crypto sw sha2.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                             |
| Wrapper API for software SHA 256 routines                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 582                                                         |
| atca_debug.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                             |
| Debug/Trace for CryptoAuthLib calls                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 583                                                         |
| atca_debug.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                             |
| atca_device.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                             |
| Microchip CryptoAuth device object                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | 585                                                         |
| atca_device.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                             |
| Microchip Crypto Auth device object                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 586                                                         |
| atca_devtypes.h                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                             |
| Microchip Crypto Auth                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 589                                                         |
| atca_hal.c                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                             |
| atoa_nano                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                             |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590                                                         |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590                                                         |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590                                                  |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590                                                         |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591                                           |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591                                           |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603                                    |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 590<br>590<br>591<br>603                                    |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 590<br>590<br>591<br>603<br>614                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 590<br>590<br>591<br>603<br>614                             |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 590<br>590<br>591<br>603<br>614<br>615                      |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603<br>614<br>615                      |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603<br>614<br>618                      |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 590<br>590<br>591<br>603<br>614<br>618                      |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603<br>614<br>618<br>618               |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603<br>614<br>618<br>618               |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>590<br>591<br>603<br>614<br>618<br>619               |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation.  atca_hal.h  Low-level HAL - methods used to setup indirection to physical layer interface                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 590<br>590<br>591<br>603<br>614<br>618<br>621<br>621        |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implemetation.  atca_hal.h  Low-level HAL - methods used to setup indirection to physical layer interface                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 590<br>591<br>603<br>614<br>618<br>621<br>621<br>621        |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>591<br>603<br>614<br>618<br>621<br>621<br>621        |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation  atca_hal.h  Low-level HAL - methods used to setup indirection to physical layer interface  atca_helpers.c  Helpers to support the CryptoAuthLib Basic API methods  atca_helpers.h  Helpers to support the CryptoAuthLib Basic API methods  atca_host.c  Host side methods to support CryptoAuth computations  atca_host.h  Definitions and Prototypes for ATCA Utility Functions  atca_iface.c  Microchip CryptoAuthLib hardware interface object  atca_iface.h  Microchip Crypto Auth hardware interface object  atca_iface.h  Utilities to create and verify a JSON Web Token (JWT)  atca_mbedtls_ecdh.c  atca_mbedtls_ecdsa.c  atca_mbedtls_wrap.c | 590<br>591<br>603<br>614<br>618<br>619<br>621<br>622<br>622 |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAIFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 590<br>591<br>603<br>614<br>618<br>621<br>622<br>622        |
| Low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation  atca_hal.h  Low-level HAL - methods used to setup indirection to physical layer interface  atca_helpers.c  Helpers to support the CryptoAuthLib Basic API methods  atca_helpers.h  Helpers to support the CryptoAuthLib Basic API methods  atca_host.c  Host side methods to support CryptoAuth computations  atca_host.h  Definitions and Prototypes for ATCA Utility Functions  atca_iface.c  Microchip CryptoAuthLib hardware interface object  atca_iface.h  Microchip Crypto Auth hardware interface object  atca_iface.h  Utilities to create and verify a JSON Web Token (JWT)  atca_mbedtls_ecdh.c  atca_mbedtls_ecdsa.c  atca_mbedtls_wrap.c | 590<br>591<br>603<br>614<br>618<br>621<br>622<br>622        |

| atca_openssl_interface.c                                                                           |     |
|----------------------------------------------------------------------------------------------------|-----|
| Crypto abstraction functions for external host side cryptography                                   | 630 |
| atca_start_config.h                                                                                | 637 |
| atca_start_iface.h                                                                                 | 637 |
| atca_status.h                                                                                      |     |
| Microchip Crypto Auth status codes                                                                 | 637 |
| atca version.h                                                                                     |     |
| Microchip CryptoAuth Library Version                                                               | 640 |
| atca wolfssl interface.c                                                                           | 040 |
| <del></del>                                                                                        | 044 |
| Crypto abstraction functions for external host side cryptography                                   | 641 |
| atcacert.h                                                                                         |     |
| Declarations common to all atcacert code                                                           | 641 |
| atcacert_client.c                                                                                  |     |
| Client side cert i/o methods. These declarations deal with the client-side, the node being authen- |     |
| ticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication   |     |
| device (e.g. ATECC508A) and the certificates are stored on that device                             | 642 |
| atcacert_client.h                                                                                  |     |
| Client side cert i/o methods. These declarations deal with the client-side, the node being authen- |     |
| ticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication   |     |
| device (e.g. ATECC508A) and the certificates are stored on that device                             | 643 |
|                                                                                                    | 040 |
| atcacert_date.c                                                                                    |     |
| Date handling with regard to certificates                                                          | 644 |
| atcacert_date.h                                                                                    |     |
| Declarations for date handling with regard to certificates                                         | 645 |
| atcacert_def.c                                                                                     |     |
| Main certificate definition implementation                                                         | 647 |
| atcacert_def.h                                                                                     |     |
| Declarations for certificates related to ECC CryptoAuthentication devices. These are the def-      |     |
| initions required to define a certificate and its various elements with regards to the Crypto←     |     |
| Authentication ECC devices                                                                         | 650 |
|                                                                                                    | 030 |
| atcacert_der.c                                                                                     |     |
| Functions required to work with DER encoded data related to X.509 certificates                     | 654 |
| atcacert_der.h                                                                                     |     |
| Function declarations required to work with DER encoded data related to X.509 certificates         | 654 |
| atcacert_host_hw.c                                                                                 |     |
| Host side methods using CryptoAuth hardware                                                        | 655 |
| atcacert_host_hw.h                                                                                 |     |
| Host side methods using CryptoAuth hardware                                                        | 656 |
| atcacert host sw.c                                                                                 |     |
|                                                                                                    | 656 |
| · · · · · · · · · · · · · · · · · · ·                                                              | 030 |
| atcacert_host_sw.h                                                                                 |     |
| Host side methods using software implementations. host-side, the one authenticating a client, of   |     |
| the authentication process. Crypto functions are performed using a software library                | 657 |
| atcacert_pem.c                                                                                     |     |
| Functions required to work with PEM encoded data related to X.509 certificates                     | 658 |
| atcacert_pem.h                                                                                     |     |
| Functions for converting between DER and PEM formats                                               | 661 |
| calib_aes.c                                                                                        |     |
|                                                                                                    | 666 |
| calib_aes_gcm.c                                                                                    | -   |
|                                                                                                    | 66- |
| 21                                                                                                 | 667 |
| calib_aes_gcm.h                                                                                    |     |
| 2 3                                                                                                | 671 |
| calib_basic.c                                                                                      |     |
| CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core            |     |
| crypto methods                                                                                     | 672 |
| calib_basic.h                                                                                      | 673 |

| calib_checkmac.c                                                                                                                                                                                                                                                                                         |       |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| CryptoAuthLib Basic API methods for CheckMAC command                                                                                                                                                                                                                                                     | 679   |
| calib_command.c  Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send |       |
| that byte string through the device interface                                                                                                                                                                                                                                                            | 679   |
| calib_command.h  Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the                                                                                               | 000   |
| ATCAlFace object to dispatch                                                                                                                                                                                                                                                                             | 692   |
| calib_counter.c  CryptoAuthLib Basic API methods for Counter command                                                                                                                                                                                                                                     | 795   |
| CryptoAuthLib Basic API methods for DeriveKey command                                                                                                                                                                                                                                                    | 795   |
| calib ecdh.c                                                                                                                                                                                                                                                                                             | , ,   |
| CryptoAuthLib Basic API methods for ECDH command                                                                                                                                                                                                                                                         | 796   |
| Implements an execution handler that executes a given command on a device and returns the results                                                                                                                                                                                                        | 798   |
| calib_execution.h                                                                                                                                                                                                                                                                                        |       |
| Defines an execution handler that executes a given command on a device and returns the results                                                                                                                                                                                                           | s 799 |
| calib_gendig.c                                                                                                                                                                                                                                                                                           |       |
| CryptoAuthLib Basic API methods for GenDig command                                                                                                                                                                                                                                                       | 800   |
| calib_genkey.c  CryptoAuthLib Basic API methods for GenKey command                                                                                                                                                                                                                                       | 801   |
| calib_hmac.c                                                                                                                                                                                                                                                                                             |       |
| CryptoAuthLib Basic API methods for HMAC command                                                                                                                                                                                                                                                         | 801   |
| calib_info.c  CryptoAuthLib Basic API methods for Info command                                                                                                                                                                                                                                           | 802   |
| calib_kdf.c  CryptoAuthLib Basic API methods for KDF command                                                                                                                                                                                                                                             | 803   |
| CryptoAuthLib Basic API methods for Lock command                                                                                                                                                                                                                                                         | 803   |
| calib_mac.c  CryptoAuthLib Basic API methods for MAC command                                                                                                                                                                                                                                             | 804   |
| calib_nonce.c                                                                                                                                                                                                                                                                                            |       |
| CryptoAuthLib Basic API methods for Nonce command                                                                                                                                                                                                                                                        | 808   |
| calib_privwrite.c  CryptoAuthLib Basic API methods for PrivWrite command                                                                                                                                                                                                                                 | 805   |
| CryptoAuthLib Basic API methods for Random command                                                                                                                                                                                                                                                       | 807   |
| calib read.c                                                                                                                                                                                                                                                                                             | 001   |
| CryptoAuthLib Basic API methods for Read command                                                                                                                                                                                                                                                         | 807   |
| calib_secureboot.c  CryptoAuthLib Basic API methods for SecureBoot command                                                                                                                                                                                                                               | 809   |
| calib_selftest.c                                                                                                                                                                                                                                                                                         |       |
| CryptoAuthLib Basic API methods for SelfTest command                                                                                                                                                                                                                                                     | 810   |
| CryptoAuthLib Basic API methods for SHA command                                                                                                                                                                                                                                                          | 810   |
| calib_sign.c  CryptoAuthLib Basic API methods for Sign command                                                                                                                                                                                                                                           | 812   |
| calib_updateextra.c  CryptoAuthLib Basic API methods for UpdateExtra command                                                                                                                                                                                                                             | 813   |
| calib_verify.c  CryptoAuthLib Basic API methods for Verify command                                                                                                                                                                                                                                       | 813   |
| calib_write.c                                                                                                                                                                                                                                                                                            |       |
| CryptoAuthLib Basic API methods for Write command                                                                                                                                                                                                                                                        | 814   |

| cryptoauthlib.h                                                                     |      |
|-------------------------------------------------------------------------------------|------|
| Single aggregation point for all CryptoAuthLib header files                         |      |
| cryptoki.h                                                                          |      |
| example_cert_chain.c                                                                |      |
| example_cert_chain.h                                                                |      |
| example_pkcs11_config.c                                                             | 020  |
| HAL for kit protocol over HID for any platform                                      | 827  |
| hal_esp32_i2c.c                                                                     |      |
| hal_esp32_timer.c                                                                   | 839  |
| hal freertos.c                                                                      |      |
| FreeRTOS Hardware/OS Abstration Layer                                               | 840  |
| hal_i2c_harmony.c                                                                   |      |
| ATCA Hardware abstraction layer for SAMD21 I2C over Harmony PLIB                    | 841  |
| hal_i2c_start.c                                                                     |      |
| ATCA Hardware abstraction layer for SAMD21 I2C over START drivers                   | 842  |
| hal_i2c_start.h                                                                     | 0.46 |
| ATCA Hardware abstraction layer for SAMD21 I2C over START drivers                   | 843  |
| hal_linux.c  Timer Utility Functions for Linux                                      | 844  |
| hal linux i2c userspace.c                                                           | 0-   |
| ATCA Hardware abstraction layer for Linux using I2C                                 | 844  |
| hal_linux_i2c_userspace.h                                                           |      |
| ATCA Hardware abstraction layer for Linux using I2C                                 | 845  |
| hal_linux_spi_userspace.c                                                           | 846  |
| hal_linux_spi_userspace.h                                                           |      |
| ATCA Hardware abstraction layer for Linux using SPI                                 | 851  |
| hal_sam0_i2c_asf.c                                                                  | 054  |
| •                                                                                   | 851  |
| hal_sam0_i2c_asf.h  ATCA Hardware abstraction layer for SAMD21 I2C over ASF drivers | 852  |
| hal_sam_i2c_asf.c                                                                   | 001  |
| ATCA Hardware abstraction layer for SAM flexcom & twi I2C over ASF drivers          | 853  |
| hal_sam_i2c_asf.h                                                                   |      |
| ATCA Hardware abstraction layer for SAMG55 I2C over ASF drivers                     | 854  |
| hal_sam_timer_asf.c                                                                 |      |
| ATCA Hardware abstraction layer for SAMD21 timer/delay over ASF drivers             | 855  |
| hal_spi_harmony.c                                                                   | 050  |
| ATCA Hardware abstraction layer for SPI over Harmony PLIB                           | 856  |
| ATCA Hardware abstraction layer for SWI over UART drivers                           | 857  |
| hal swi uart.h                                                                      | 001  |
| ATCA Hardware abstraction layer for SWI over UART drivers                           | 858  |
| hal_timer_start.c                                                                   |      |
| ATCA Hardware abstraction layer for SAMD21 I2C over START drivers                   | 858  |
| hal_uc3_i2c_asf.c                                                                   |      |
| ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers                     | 859  |
| hal_uc3_i2c_asf.h                                                                   | 000  |
| ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers                     | 860  |
| hal_uc3_timer_asf.c  ATCA Hardware abstraction layer for SAM4S I2C over ASF drivers | 861  |
| hal windows.c                                                                       |      |
| ATCA Hardware abstraction layer for windows timer functions                         | 861  |
| io_protection_key.h                                                                 |      |
|                                                                                     | 862  |
| kit_phy.h                                                                           |      |
| ATCA Hardware abstraction layer physical send & receive function definitions        | 863  |

| kit_protocol.c                                                               |              |
|------------------------------------------------------------------------------|--------------|
| Microchip Crypto Auth hardware interface object                              | 863          |
|                                                                              | 864          |
| •                                                                            | 890          |
| pkcs11_attrib.c                                                              |              |
| <i>, ,</i>                                                                   | 891          |
| pkcs11_attrib.h  PKCS11 Library Object Attribute Handling                    | 892          |
| pkcs11 cert.c                                                                | 332          |
| • =                                                                          | 893          |
| pkcs11_cert.h                                                                |              |
| • –                                                                          | 894          |
| pkcs11_config.c                                                              |              |
|                                                                              | 895          |
| pkcs11_debug.c                                                               |              |
| , 66 6                                                                       | 895          |
| pkcs11_debug.h  PKCS11 Library Debugging                                     | <u>وم</u>    |
|                                                                              | 897          |
| pkcs11_digest.h                                                              |              |
| • — •                                                                        | 898          |
| pkcs11_find.c                                                                |              |
| PKCS11 Library Object Find/Searching                                         | 900          |
| pkcs11_find.h                                                                |              |
|                                                                              | 900          |
| pkcs11_info.c                                                                | 004          |
| ,                                                                            | 901          |
| pkcs11_info.h PKCS11 Library Information Functions                           | 902          |
| pkcs11_init.c                                                                | 302          |
|                                                                              | 902          |
| pkcs11_init.h                                                                |              |
| PKCS11 Library Initialization & Context                                      | 903          |
| pkcs11_key.c                                                                 |              |
| , , ,                                                                        | 904          |
| pkcs11_key.h                                                                 | 001          |
| PKCS11 Library Object Handling                                               | 900          |
| PKCS11 Basic library redirects based on the 2.40 specification http://docs.↔ |              |
| oasis-open.org/pkcs11/pkcs11-base/v2.40/os/pkcs11-base-v2.↔                  |              |
| 40-os.html                                                                   | 906          |
| pkcs11_mech.c                                                                |              |
| ,                                                                            | 910          |
| pkcs11_mech.h                                                                | <b>.</b>     |
|                                                                              | 911          |
| pkcs11_object.c PKCS11 Library Object Handling Base                          | 911          |
| pkcs11_object.h                                                              | <i>3</i> 1 1 |
| $\cdot$ – $\cdot$                                                            | 912          |
| pkcs11_os.c                                                                  |              |
| PKCS11 Library Operating System Abstraction Functions                        | 915          |
| pkcs11_os.h                                                                  |              |
| PKCS11 Library Operating System Abstraction                                  | 916          |
| pkcs11_session.c                                                             | O 4 -        |
| PKCS11 Library Session Handling                                              | 911          |
| PKCS11 Library Session Management & Context                                  | 917          |
|                                                                              |              |

| pkcs11_signature.c                                                                                                        |
|---------------------------------------------------------------------------------------------------------------------------|
| PKCS11 Library Sign/Verify Handling                                                                                       |
| pkcs11_signature.h PKCS11 Library Sign/Verify Handling                                                                    |
| pkcs11_slot.c                                                                                                             |
| PKCS11 Library Slot Handling                                                                                              |
| pkcs11_slot.h                                                                                                             |
| PKCS11 Library Slot Handling & Context                                                                                    |
| pkcs11_token.c                                                                                                            |
| PKCS11 Library Token Handling                                                                                             |
| PKCS11 Library Token Management & Context                                                                                 |
| pkcs11_util.c                                                                                                             |
| PKCS11 Library Utility Functions                                                                                          |
| pkcs11_util.h                                                                                                             |
| PKCS11 Library Utilities         925           pkcs11f.h         926                                                      |
| pkcs11f.h                                                                                                                 |
| secure boot.c                                                                                                             |
| Provides required APIs to manage secure boot under various scenarios                                                      |
| secure_boot.h                                                                                                             |
| Provides required APIs to manage secure boot under various scenarios                                                      |
| secure_boot_memory.h  Provides interface to memory component for the secure boot                                          |
| sha1 routines.c                                                                                                           |
| Software implementation of the SHA1 algorithm                                                                             |
| sha1_routines.h                                                                                                           |
| Software implementation of the SHA1 algorithm                                                                             |
| sha2_routines.c  Software implementation of the SHA256 algorithm                                                          |
| sha2 routines.h                                                                                                           |
| Software implementation of the SHA256 algorithm                                                                           |
| swi_uart_samd21_asf.c                                                                                                     |
| ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers 1075                                        |
| swi_uart_samd21_asf.h  ATVMECA's ATCA Hardware shotraction layer for SWII interface over LIART drivers                    |
| ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers 1076 swi_uart_start.c                       |
| swi_uart_start.h                                                                                                          |
| symmetric_authentication.c                                                                                                |
| Contains API for performing the symmetric Authentication between the Host and the device 1079                             |
| symmetric_authentication.h                                                                                                |
| Contains API for performing the symmetric Authentication between the Host and the device 1080 tflxtls cert def 4 device.c |
| TNG TLS device certificate definition                                                                                     |
| tflxtls_cert_def_4_device.h                                                                                               |
| TNG TLS device certificate definition                                                                                     |
| tng_atca.c                                                                                                                |
| TNG Helper Functions                                                                                                      |
| tng_atca.h  TNG Helper Functions                                                                                          |
| tng_atcacert_client.c                                                                                                     |
| Client side certificate I/O functions for TNG devices                                                                     |
| tng_atcacert_client.h                                                                                                     |
| Client side certificate I/O functions for TNG devices                                                                     |
| tng_root_cert.c  TNG root certificate (DER)                                                                               |
| tng_root_cert.h                                                                                                           |
| TNG root certificate (DER)                                                                                                |

| tnglora_cert_def_1_signer.c                                      |
|------------------------------------------------------------------|
| TNG LORA signer certificate definition                           |
| tnglora_cert_def_1_signer.h                                      |
| TNG LORA signer certificate definition                           |
| tnglora_cert_def_2_device.c                                      |
| TNG LORA device certificate definition                           |
| tnglora_cert_def_2_device.h                                      |
| TNG LORA device certificate definition                           |
| tnglora_cert_def_4_device.c                                      |
| TNG LORA device certificate definition                           |
| tnglora_cert_def_4_device.h                                      |
| TNG LORA device certificate definition                           |
| tngtls_cert_def_1_signer.c                                       |
| TNG TLS signer certificate definition                            |
| tngtls_cert_def_1_signer.h                                       |
| TNG TLS signer certificate definition                            |
| tngtls_cert_def_2_device.c TNG TLS device certificate definition |
|                                                                  |
| tngtls_cert_def_2_device.h TNG TLS device certificate definition |
| tingtis cert def 3 device.c                                      |
| TNG TLS device certificate definition                            |
| angtis cert def 3 device.h                                       |
| TNG TLS device certificate definition                            |
| trust_pkcs11_config.c                                            |
| PKCS11 Trust Platform Configuration                              |
|                                                                  |

## **Chapter 18**

## **Module Documentation**

## 18.1 Basic Crypto API methods (atcab\_)

These methods provide the most convenient, simple API to CryptoAuth chips.

### **Macros**

- #define atcab\_cfg\_discover(...) calib\_cfg\_discover(\_\_VA\_ARGS\_\_)
- #define atcab\_get\_addr(...) calib\_get\_addr(\_\_VA\_ARGS\_\_)
- #define atca\_execute\_command(...) calib\_execute\_command(\_\_VA\_ARGS\_\_)
- #define SHA\_CONTEXT\_MAX\_SIZE (109)

## **Functions**

ATCA\_STATUS atcab\_version (char \*ver\_str)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA STATUS atcab init ext (ATCADevice \*device, ATCAlfaceCfg \*cfg)

Creates and initializes a ATCADevice context.

ATCA\_STATUS atcab\_init (ATCAlfaceCfg \*cfg)

Creates a global ATCADevice object used by Basic API.

ATCA\_STATUS atcab\_init\_device (ATCADevice ca\_device)

Initialize the global ATCADevice object to point to one of your choosing for use with all the atcab\_ basic API.

• ATCA\_STATUS atcab\_release\_ext (ATCADevice \*device)

release (free) the an ATCADevice instance.

ATCA\_STATUS atcab\_release (void)

release (free) the global ATCADevice instance. This must be called in order to release or free up the interface.

ATCADevice atcab\_get\_device (void)

Get the global device object.

ATCADeviceType atcab\_get\_device\_type\_ext (ATCADevice device)

Get the selected device type of rthe device context.

ATCADeviceType atcab get device type (void)

Get the current device type configured for the global ATCADevice.

bool atcab\_is\_ca\_device (ATCADeviceType dev\_type)

Check whether the device is cryptoauth device.

bool atcab\_is\_ta\_device (ATCADeviceType dev\_type)

Check whether the device is Trust Anchor device.

ATCA\_STATUS atcab\_aes\_cbc\_init\_ext (ATCADevice device, atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv)

Initialize context for AES CBC operation.

ATCA\_STATUS atcab\_aes\_cbc\_init (atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv)

Initialize context for AES CBC operation.

- ATCA\_STATUS atcab\_aes\_cbc\_encrypt\_block\_ext (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_t \*ciphertext)
- ATCA\_STATUS atcab\_aes\_cbc\_encrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Encrypt a block of data using CBC mode and a key within the device. atcab\_aes\_cbc\_init() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_cbc\_decrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Decrypt a block of data using CBC mode and a key within the device. atcab\_aes\_cbc\_init() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_cmac\_init\_ext (ATCADevice device, atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block)

Initialize a CMAC calculation using an AES-128 key in the device.

- ATCA\_STATUS atcab\_aes\_cmac\_init (atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block)
   Initialize a CMAC calculation using an AES-128 key in the device.
- ATCA\_STATUS atcab\_aes\_cmac\_update (atca\_aes\_cmac\_ctx\_t \*ctx, const uint8\_t \*data, uint32\_t data\_
   size)

Add data to an initialized CMAC calculation.

- ATCA\_STATUS atcab\_aes\_cmac\_finish (atca\_aes\_cmac\_ctx\_t \*ctx, uint8\_t \*cmac, uint32\_t cmac\_size)

  Finish a CMAC operation returning the CMAC value.
- ATCA\_STATUS atcab\_aes\_ctr\_init\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8 t key block, uint8 t counter size, const uint8 t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

• ATCA\_STATUS atcab\_aes\_ctr\_init (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_← t counter size, const uint8 t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_t counter\_size, uint8\_t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_t counter\_size, uint8\_t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

- ATCA\_STATUS atcab\_aes\_ctr\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*input, uint8\_t \*output)
  - Process a block of data using CTR mode and a key within the device. <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a> or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.
- ATCA\_STATUS atcab\_aes\_ctr\_encrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_←
  t \*ciphertext)

Encrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_ctr\_decrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_←
t \*plaintext)

Decrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_ctr\_increment (atca\_aes\_ctr\_ctx\_t \*ctx)

Increments AES CTR counter value.

- ATCA STATUS atcab exit (void)
- ATCA STATUS atcab wakeup (void)

wakeup the CryptoAuth device

ATCA STATUS atcab idle (void)

idle the CryptoAuth device

ATCA STATUS atcab sleep (void)

invoke sleep on the CryptoAuth device

ATCA\_STATUS atcab\_get\_zone\_size (uint8\_t zone, uint16\_t slot, size\_t \*size)

Gets the size of the specified zone in bytes.

ATCA\_STATUS atcab\_aes (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8\_t \*aes\_out)
 Compute the AES-128 encrypt, decrypt, or GFM calculation.

ATCA\_STATUS atcab\_aes\_encrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_←
t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

 ATCA\_STATUS atcab\_aes\_encrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*plaintext, uint8 t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

ATCA\_STATUS atcab\_aes\_decrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

 ATCA\_STATUS atcab\_aes\_decrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

• ATCA STATUS atcab aes gfm (const uint8 t \*h, const uint8 t \*input, uint8 t \*output)

Perform a Galois Field Multiply (GFM) operation.

 ATCA\_STATUS atcab\_aes\_gcm\_init (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv, size\_t iv\_size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_init\_rand (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, size\_t rand\_size, const uint8\_t \*free\_field, size\_t free\_field\_size, uint8\_t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_aad\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32\_t aad
 \_size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint32\_t plaintext\_size, uint8\_t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size\_t tag\_size)

Complete a GCM encrypt operation returning the authentication tag.

• ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32\_t ciphertext\_size, uint8\_t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag
 size, bool \*is verified)

Complete a GCM decrypt operation verifying the authentication tag.

ATCA\_STATUS atcab\_checkmac (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, const uint8\_←
 t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

ATCA\_STATUS atcab\_counter (uint8\_t mode, uint16\_t counter\_id, uint32\_t \*counter\_value)
 Compute the Counter functions.

• ATCA STATUS atcab counter increment (uint16 t counter id, uint32 t \*counter value)

Increments one of the device's monotonic counters.

ATCA\_STATUS atcab\_counter\_read (uint16\_t counter\_id, uint32\_t \*counter\_value)

Read one of the device's monotonic counters.

ATCA\_STATUS atcab\_derivekey (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*mac)

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

ATCA\_STATUS atcab\_ecdh\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, uint8\_t \*out\_nonce)

Base function for generating premaster secret key using ECDH.

ATCA STATUS atcab ecdh (uint16 t key id, const uint8 t \*public key, uint8 t \*pms)

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

• ATCA\_STATUS atcab\_ecdh\_enc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*read key, uint16\_t read key id, const uint8\_t num in[(20)])

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

ATCA\_STATUS atcab\_ecdh\_ioenc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS atcab\_ecdh\_tempkey (const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

• ATCA\_STATUS atcab\_ecdh\_tempkey\_ioenc (const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS atcab\_gendig (uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_t other\_data 
 — size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

ATCA\_STATUS atcab\_genkey\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_←
t \*public key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

ATCA\_STATUS atcab\_genkey (uint16\_t key\_id, uint8\_t \*public\_key)

Issues GenKey command, which generates a new random private key in slot/handle and returns the public key.

• ATCA\_STATUS atcab\_get\_pubkey (uint16\_t key\_id, uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

• ATCA STATUS atcab hmac (uint8 t mode, uint16 t key id, uint8 t \*digest)

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS atcab\_info\_base (uint8\_t mode, uint16\_t param2, uint8\_t \*out\_data)

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

ATCA STATUS atcab info (uint8 t \*revision)

Use the Info command to get the device revision (DevRev).

ATCA\_STATUS atcab\_info\_set\_latch (bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

• ATCA\_STATUS atcab\_info\_get\_latch (bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

 ATCA\_STATUS atcab\_kdf (uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8 t \*out data, uint8 t \*out nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

ATCA\_STATUS atcab\_lock (uint8\_t mode, uint16\_t summary\_crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

ATCA\_STATUS atcab\_lock\_config\_zone (void)

Unconditionally (no CRC required) lock the config zone.

ATCA\_STATUS atcab\_lock\_config\_zone\_crc (uint16\_t summary\_crc)

Lock the config zone with summary CRC.

ATCA STATUS atcab lock data zone (void)

Unconditionally (no CRC required) lock the data zone (slots and OTP). for CryptoAuth devices and lock the setup for Trust Anchor device.

ATCA STATUS atcab lock data zone crc (uint16 t summary crc)

Lock the data zone (slots and OTP) with summary CRC.

ATCA STATUS atcab lock data slot (uint16 t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1) (for cryptoauth devices) or Lock an individual handle in shared data element on an Trust Anchor device (for Trust Anchor devices).

ATCA STATUS atcab mac (uint8 t mode, uint16 t key id, const uint8 t \*challenge, uint8 t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS atcab\_nonce\_base (uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

ATCA STATUS atcab nonce (const uint8 t \*num in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

• ATCA STATUS atcab nonce load (uint8 t target, const uint8 t \*num in, uint16 t num in size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

ATCA STATUS atcab nonce rand (const uint8 t \*num in, uint8 t \*rand out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

ATCA\_STATUS atcab\_challenge (const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

• ATCA\_STATUS atcab\_challenge\_seed\_update (const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number

 ATCA\_STATUS atcab\_priv\_write (uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write\_key\_id, const uint8\_t write\_key[32], const uint8\_t num\_in[(20)])

Executes PrivWrite command, to write externally generated ECC private keys into the device.

ATCA\_STATUS atcab\_random (uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the device.

ATCA\_STATUS atcab\_random\_ext (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the device.

ATCA\_STATUS atcab\_read\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint8\_t \*data, uint8\_t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

ATCA\_STATUS atcab\_is\_locked (uint8\_t zone, bool \*is\_locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

ATCA\_STATUS atcab\_is\_config\_locked (bool \*is\_locked)

This function check whether configuration zone is locked or not.

ATCA\_STATUS atcab\_is\_data\_locked (bool \*is\_locked)

This function check whether data/setup zone is locked or not.

• ATCA\_STATUS atcab\_is\_slot\_locked (uint16\_t slot, bool \*is\_locked)

This function check whether slot/handle is locked or not.

ATCA\_STATUS atcab\_read\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset, uint8\_t \*data, size\_
 t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

• ATCA STATUS atcab read serial number (uint8 t \*serial number)

This function returns serial number of the device.

ATCA\_STATUS atcab\_read\_pubkey (uint16\_t slot, uint8\_t \*public\_key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

ATCA STATUS atcab read sig (uint16 t slot, uint8 t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

ATCA\_STATUS atcab\_read\_config\_zone (uint8\_t \*config\_data)

Executes Read command to read the complete device configuration zone.

ATCA STATUS atcab cmp config zone (uint8 t \*config data, bool \*same config)

Compares a specified configuration zone with the configuration zone currently on the device.

• ATCA\_STATUS atcab\_read\_enc (uint16\_t key\_id, uint8\_t block, uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key id, const uint8\_t num\_in[(20)])

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

ATCA\_STATUS atcab\_secureboot (uint8\_t mode, uint16\_t param2, const uint8\_t \*digest, const uint8\_←
t \*signature, uint8\_t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

• ATCA\_STATUS atcab\_secureboot\_mac (uint8\_t mode, const uint8\_t \*digest, const uint8\_t \*signature, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

• ATCA STATUS atcab selftest (uint8 t mode, uint16 t param2, uint8 t \*result)

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT  $\leftarrow$  ECC608 chip.

ATCA\_STATUS atcab\_sha\_base (uint8\_t mode, uint16\_t length, const uint8\_t \*data\_in, uint8\_t \*data\_out, uint16\_t \*data\_out\_size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

ATCA\_STATUS atcab\_sha\_start (void)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA\_STATUS atcab\_sha\_update (const uint8\_t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

ATCA\_STATUS atcab\_sha\_end (uint8\_t \*digest, uint16\_t length, const uint8\_t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

• ATCA\_STATUS atcab\_sha\_read\_context (uint8\_t \*context, uint16\_t \*context\_size)

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

• ATCA\_STATUS atcab\_sha\_write\_context (const uint8\_t \*context, uint16\_t context\_size)

Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.

• ATCA STATUS atcab sha (uint16 t length, const uint8 t \*message, uint8 t \*digest)

Use the SHA command to compute a SHA-256 digest.

• ATCA\_STATUS atcab\_hw\_sha2\_256 (const uint8\_t \*data, size\_t data\_size, uint8\_t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA\_STATUS atcab\_hw\_sha2\_256\_init (atca\_sha256\_ctx\_t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

ATCA\_STATUS atcab\_hw\_sha2\_256\_update (atca\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data\_
 size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

• ATCA\_STATUS atcab\_hw\_sha2\_256\_finish (atca\_sha256\_ctx\_t \*ctx, uint8\_t \*digest)

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

ATCA\_STATUS atcab\_sha\_hmac\_init (atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac\_update (atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data
 — size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

- ATCA\_STATUS atcab\_sha\_hmac\_finish (atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_t \*digest, uint8\_t target)
  - Executes SHA command to complete a HMAC/SHA-256 operation.
- ATCA\_STATUS atcab\_sha\_hmac (const uint8\_t \*data, size\_t data\_size, uint16\_t key\_slot, uint8\_t \*digest, uint8 t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

ATCA STATUS atcab sign base (uint8 t mode, uint16 t key id, uint8 t \*signature)

Executes the Sign command, which generates a signature using the ECDSA algorithm.

ATCA STATUS atcab sign (uint16 t key id, const uint8 t \*msg, uint8 t \*signature)

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

- ATCA\_STATUS atcab\_sign\_internal (uint16\_t key\_id, bool is\_invalidate, bool is\_full\_sn, uint8\_t \*signature)

  Executes Sign command to sign an internally generated message.
- ATCA\_STATUS atcab\_updateextra (uint8\_t mode, uint16\_t new\_value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

ATCA\_STATUS atcab\_verify (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public
key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS atcab\_verify\_extern (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_←
t \*public\_key, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS atcab\_verify\_extern\_mac (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public\_key, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

 ATCA\_STATUS atcab\_verify\_stored (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp Key for other devices.

ATCA\_STATUS atcab\_verify\_stored\_mac (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key
 —id, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

 ATCA\_STATUS atcab\_verify\_validate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

 ATCA\_STATUS atcab\_verify\_invalidate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

• ATCA\_STATUS atcab\_write (uint8\_t zone, uint16\_t address, const uint8\_t \*value, const uint8\_t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

ATCA\_STATUS atcab\_write\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, const uint8\_←
t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

ATCA\_STATUS atcab\_write\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

ATCA\_STATUS atcab\_write\_pubkey (uint16\_t slot, const uint8\_t \*public\_key)

Uses the write command to write a public key to a slot in the proper format.

ATCA\_STATUS atcab\_write\_config\_zone (const uint8\_t \*config\_data)

Executes the Write command, which writes the configuration zone.

 ATCA\_STATUS atcab\_write\_enc (uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

ATCA\_STATUS atcab\_write\_config\_counter (uint16\_t counter\_id, uint32\_t counter\_value)

Initialize one of the monotonic counters in device with a specific value.

### **Variables**

- SHARED\_LIB\_IMPORT ATCADevice \_gDevice
- ATCA\_STATUS atcab\_printbin (uint8\_t \*binary, size\_t bin\_len, bool add\_space)
- const char \* atca basic aes gcm version
- ATCA\_STATUS calib\_aes\_gcm\_init (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8
   — t key\_block, const uint8\_t \*iv, size\_t iv\_size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

• ATCA\_STATUS calib\_aes\_gcm\_init\_rand (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8 t key block, size t rand size, const uint8 t \*free field, size t free field size, uint8 t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS calib\_aes\_gcm\_aad\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32 t aad size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

• ATCA\_STATUS calib\_aes\_gcm\_encrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint32\_t plaintext\_size, uint8\_t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS calib\_aes\_gcm\_encrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size t tag size)

Complete a GCM encrypt operation returning the authentication tag.

• ATCA\_STATUS calib\_aes\_gcm\_decrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32\_t ciphertext\_size, uint8\_t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

 ATCA\_STATUS calib\_aes\_gcm\_decrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag\_size, bool \*is\_verified)

Complete a GCM decrypt operation verifying the authentication tag.

- #define ATCA AES GCM IV STD LENGTH 12
- typedef struct atca\_aes\_gcm\_ctx atca\_aes\_gcm\_ctx\_t

## 18.1.1 Detailed Description

These methods provide the most convenient, simple API to CryptoAuth chips.

## 18.1.2 Macro Definition Documentation

## 18.1.2.1 ATCA\_AES\_GCM\_IV\_STD\_LENGTH

```
#define ATCA_AES_GCM_IV_STD_LENGTH 12
```

## 18.1.2.2 atca\_execute\_command

## 18.1.2.3 atcab\_cfg\_discover

## 18.1.2.4 atcab\_get\_addr

## 18.1.2.5 SHA\_CONTEXT\_MAX\_SIZE

```
#define SHA_CONTEXT_MAX_SIZE (109)
```

## 18.1.3 Typedef Documentation

## 18.1.3.1 atca\_aes\_gcm\_ctx\_t

```
{\tt typedef \ struct \ atca\_aes\_gcm\_ctx \ atca\_aes\_gcm\_ctx\_t}
```

Context structure for AES GCM operations.

## 18.1.4 Function Documentation

## 18.1.4.1 \_atcab\_exit()

```
ATCA_STATUS _atcab_exit ( void )
```

## 18.1.4.2 atcab\_aes()

```
ATCA_STATUS atcab_aes (
    uint8_t mode,
    uint16_t key_id,
    const uint8_t * aes_in,
    uint8_t * aes_out)
```

Compute the AES-128 encrypt, decrypt, or GFM calculation.

#### **Parameters**

| in  | mode                                                                                 | node The mode for the AES command.                            |  |
|-----|--------------------------------------------------------------------------------------|---------------------------------------------------------------|--|
| in  | in key_id Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKe |                                                               |  |
| in  | aes_in                                                                               | Input data to the AES command (16 bytes).                     |  |
| out | aes_out                                                                              | Output data from the AES command is returned here (16 bytes). |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 18.1.4.3 atcab\_aes\_cbc\_decrypt\_block()

Decrypt a block of data using CBC mode and a key within the device. <a href="atcab\_aes\_cbc\_init">atcab\_aes\_cbc\_init</a>() should be called before the first use of this function.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 60

| in  | ctx        | AES CBC context.                            |
|-----|------------|---------------------------------------------|
| in  | ciphertext | Ciphertext to be decrypted (16 bytes).      |
| out | plaintext  | Decrypted data is returned here (16 bytes). |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.4 atcab\_aes\_cbc\_encrypt\_block()

Encrypt a block of data using CBC mode and a key within the device. <a href="atcab\_aes\_cbc\_init">atcab\_aes\_cbc\_init</a>() should be called before the first use of this function.

#### **Parameters**

| in  | ctx        | AES CBC context.                            |
|-----|------------|---------------------------------------------|
| in  | plaintext  | Plaintext to be encrypted (16 bytes).       |
| out | ciphertext | Encrypted data is returned here (16 bytes). |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.5 atcab\_aes\_cbc\_encrypt\_block\_ext()

## 18.1.4.6 atcab\_aes\_cbc\_init()

```
ATCA_STATUS atcab_aes_cbc_init (
    atca_aes_cbc_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    const uint8_t * iv )
```

Initialize context for AES CBC operation.

| in | ctx                                                                 | ctx AES CBC context to be initialized                                             |  |
|----|---------------------------------------------------------------------|-----------------------------------------------------------------------------------|--|
| in | in key_id Key location. Can either be a slot/handles or in TempKey. |                                                                                   |  |
| in | key_block                                                           | ock Index of the 16-byte block to use within the key location for the actual key. |  |
| in | iv                                                                  | Initialization vector (16 bytes).                                                 |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.7 atcab\_aes\_cbc\_init\_ext()

Initialize context for AES CBC operation.

#### **Parameters**

| in | device                                | Device context pointer                                                               |  |
|----|---------------------------------------|--------------------------------------------------------------------------------------|--|
| in | ctx AES CBC context to be initialized |                                                                                      |  |
| in | key_id                                | Key location. Can either be a slot/handles or in TempKey.                            |  |
| in | key_block                             | y_block Index of the 16-byte block to use within the key location for the actual key |  |
| in | iv Initialization vector (16 bytes).  |                                                                                      |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.8 atcab\_aes\_cmac\_finish()

Finish a CMAC operation returning the CMAC value.

| in  | ctx       | AES-128 CMAC context.                           |
|-----|-----------|-------------------------------------------------|
| out | cmac      | CMAC is returned here.                          |
| in  | cmac_size | Size of CMAC requested in bytes (max 16 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.9 atcab\_aes\_cmac\_init()

Initialize a CMAC calculation using an AES-128 key in the device.

#### **Parameters**

|   | in | ctx                                                              | AES-128 CMAC context.                                                         |  |
|---|----|------------------------------------------------------------------|-------------------------------------------------------------------------------|--|
|   | in | key_id Key location. Can either be a slot/handles or in TempKey. |                                                                               |  |
| ĺ | in | key_block                                                        | Index of the 16-byte block to use within the key location for the actual key. |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.10 atcab\_aes\_cmac\_init\_ext()

Initialize a CMAC calculation using an AES-128 key in the device.

#### **Parameters**

| _ |    |                              |                                                                               |  |
|---|----|------------------------------|-------------------------------------------------------------------------------|--|
|   | in | device                       | Device context pointer                                                        |  |
| Ī | in | in ctx AES-128 CMAC context. |                                                                               |  |
|   | in | key_id                       | Key location. Can either be a slot/handles or in TempKey.                     |  |
| Ī | in | key_block                    | Index of the 16-byte block to use within the key location for the actual key. |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.11 atcab\_aes\_cmac\_update()

Add data to an initialized CMAC calculation.

#### **Parameters**

| in | ctx       | AES-128 CMAC context.                  |
|----|-----------|----------------------------------------|
| in | data      | Data to be added.                      |
| in | data_size | Size of the data to be added in bytes. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.12 atcab\_aes\_ctr\_block()

Process a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

## **Parameters**

| in  | ctx    | AES CTR context structure.               |
|-----|--------|------------------------------------------|
| in  | input  | Input data to be processed (16 bytes).   |
| out | output | Output data is returned here (16 bytes). |

#### Returns

ATCA\_SUCCESS on success, ATCA\_INVALID\_SIZE on counter overflow, otherwise an error code.

## 18.1.4.13 atcab\_aes\_ctr\_decrypt\_block()

Decrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

#### **Parameters**

| in  | ctx        | AES CTR context structure.                  |
|-----|------------|---------------------------------------------|
| in  | ciphertext | Ciphertext to be decrypted (16 bytes).      |
| out | plaintext  | Decrypted data is returned here (16 bytes). |

#### Returns

ATCA\_SUCCESS on success, ATCA\_INVALID\_SIZE on counter overflow, otherwise an error code.

#### 18.1.4.14 atcab\_aes\_ctr\_encrypt\_block()

Encrypt a block of data using CTR mode and a key within the device. <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_c

#### **Parameters**

| in                    | ctx       | AES CTR context structure.                  |
|-----------------------|-----------|---------------------------------------------|
| in                    | plaintext | Plaintext to be encrypted (16 bytes).       |
| out <i>ciphertext</i> |           | Encrypted data is returned here (16 bytes). |

#### Returns

ATCA\_SUCCESS on success, ATCA\_INVALID\_SIZE on counter overflow, otherwise an error code.

## 18.1.4.15 atcab\_aes\_ctr\_increment()

Increments AES CTR counter value.

| in,out | ctx | AES CTR context |
|--------|-----|-----------------|
|--------|-----|-----------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 18.1.4.16 atcab\_aes\_ctr\_init()

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

The IV is a combination of nonce (left-field) and big-endian counter (right-field). The counter\_size field sets the size of the counter and the remaining bytes are assumed to be the nonce.

#### **Parameters**

| in | ctx AES CTR context to be initialized.                                               |  |
|----|--------------------------------------------------------------------------------------|--|
| in | key_id Key location. Can either be a slot/handles or in TempKey.                     |  |
| in | key_block Index of the 16-byte block to use within the key location for the actual k |  |
| in | in counter_size Size of counter in IV in bytes. 4 bytes is a common size.            |  |
| in | iv Initialization vector (concatenation of nonce and counter) 16 bytes.              |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.17 atcab\_aes\_ctr\_init\_ext()

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

The IV is a combination of nonce (left-field) and big-endian counter (right-field). The counter\_size field sets the size of the counter and the remaining bytes are assumed to be the nonce.

| in | device                                                                               | Device context pointer |  |
|----|--------------------------------------------------------------------------------------|------------------------|--|
| in | ctx AES CTR context to be initialized.                                               |                        |  |
| in | key_id Key location. Can either be a slot/handles or in TempKey.                     |                        |  |
| in | key_block Index of the 16-byte block to use within the key location for the actual k |                        |  |
| in | counter_size Size of counter in IV in bytes. 4 bytes is a common size.               |                        |  |
| in | iv Initialization vector (concatenation of nonce and counter) 16 bytes.              |                        |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.18 atcab\_aes\_ctr\_init\_rand()

```
ATCA_STATUS atcab_aes_ctr_init_rand (
    atca_aes_ctr_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    uint8_t counter_size,
    uint8_t * iv )
```

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

The IV is a combination of nonce (left-field) and big-endian counter (right-field). The counter\_size field sets the size of the counter and the remaining bytes are assumed to be the nonce.

#### **Parameters**

| in  | ctx AES CTR context to be initialized.                                                   |  |
|-----|------------------------------------------------------------------------------------------|--|
| in  | n key_id Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey     |  |
| in  | key_block Index of the 16-byte block to use within the key location for the actual key.  |  |
| in  | counter_size Size of counter in IV in bytes. 4 bytes is a common size.                   |  |
| out | iv Initialization vector (concatenation of nonce and counter) is returned here (16 bytes |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.19 atcab\_aes\_ctr\_init\_rand\_ext()

```
atca_aes_ctr_ctx_t * ctx,
uint16_t key_id,
uint8_t key_block,
uint8_t counter_size,
uint8_t * iv )
```

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

The IV is a combination of nonce (left-field) and big-endian counter (right-field). The counter\_size field sets the size of the counter and the remaining bytes are assumed to be the nonce.

#### **Parameters**

| in  | device                                                                                   | Device context pointer                                                                 |  |
|-----|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|--|
| in  | ctx                                                                                      | AES CTR context to be initialized.                                                     |  |
| in  | key_id                                                                                   | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.           |  |
| in  | key_block                                                                                | ey_block Index of the 16-byte block to use within the key location for the actual key. |  |
| in  | counter_size Size of counter in IV in bytes. 4 bytes is a common size.                   |                                                                                        |  |
| out | iv Initialization vector (concatenation of nonce and counter) is returned here (16 bytes |                                                                                        |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.20 atcab\_aes\_decrypt()

```
ATCA_STATUS atcab_aes_decrypt (
    uint16_t key_id,
    uint8_t key_block,
    const uint8_t * ciphertext,
    uint8_t * plaintext )
```

Perform an AES-128 decrypt operation with a key in the device.

## **Parameters**

| in  | key_id                                                                                  | key_id Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey |  |
|-----|-----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|--|
| in  | key_block Index of the 16-byte block to use within the key location for the actual key. |                                                                                    |  |
| in  | ciphertext Input ciphertext to be decrypted (16 bytes).                                 |                                                                                    |  |
| out | t plaintext Output plaintext is returned here (16 bytes).                               |                                                                                    |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 68

## 18.1.4.21 atcab\_aes\_decrypt\_ext()

Perform an AES-128 decrypt operation with a key in the device.

#### **Parameters**

| in  | device                                                  | Device context pointer                                                        |  |
|-----|---------------------------------------------------------|-------------------------------------------------------------------------------|--|
| in  | key_id                                                  | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |  |
| in  | key_block                                               | Index of the 16-byte block to use within the key location for the actual key. |  |
| in  | ciphertext                                              | Input ciphertext to be decrypted (16 bytes).                                  |  |
| out | plaintext Output plaintext is returned here (16 bytes). |                                                                               |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.22 atcab\_aes\_encrypt()

Perform an AES-128 encrypt operation with a key in the device.

#### **Parameters**

| in  | key_id                                                                                  | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey. |  |
|-----|-----------------------------------------------------------------------------------------|------------------------------------------------------------------------------|--|
| in  | key_block Index of the 16-byte block to use within the key location for the actual key. |                                                                              |  |
| in  | plaintext                                                                               | Input plaintext to be encrypted (16 bytes).                                  |  |
| out | ciphertext Output ciphertext is returned here (16 bytes).                               |                                                                              |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.23 atcab\_aes\_encrypt\_ext()

Perform an AES-128 encrypt operation with a key in the device.

#### **Parameters**

| in  | device     | Device context pointer                                                        |  |
|-----|------------|-------------------------------------------------------------------------------|--|
| in  | key_id     | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |  |
| in  | key_block  | Index of the 16-byte block to use within the key location for the actual key. |  |
| in  | plaintext  | Input plaintext to be encrypted (16 bytes).                                   |  |
| out | ciphertext | Output ciphertext is returned here (16 bytes).                                |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.24 atcab\_aes\_gcm\_aad\_update()

```
ATCA_STATUS atcab_aes_gcm_aad_update (
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * aad,
    uint32_t aad_size )
```

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

This can be called multiple times. <a href="atcab\_aes\_gcm\_init">atcab\_aes\_gcm\_init</a> () should be called before the first use of this function. When there is AAD to include, this should be called before <a href="atcab\_aes\_gcm\_encrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a> () or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_ae

#### **Parameters**

|                        | in ctx AES GCM context in aad Additional authenticat |          | AES GCM context                           |
|------------------------|------------------------------------------------------|----------|-------------------------------------------|
|                        |                                                      |          | Additional authenticated data to be added |
| in aad_size Size of aa |                                                      | aad_size | Size of aad in bytes                      |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 70

#### 18.1.4.25 atcab\_aes\_gcm\_decrypt\_finish()

Complete a GCM decrypt operation verifying the authentication tag.

#### **Parameters**

| in  | ctx         | AES GCM context structure.               |  |
|-----|-------------|------------------------------------------|--|
| in  | tag         | Expected authentication tag.             |  |
| in  | tag_size    | Size of tag in bytes (12 to 16 bytes).   |  |
| out | is_verified | Returns whether or not the tag verified. |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.26 atcab\_aes\_gcm\_decrypt\_update()

```
ATCA_STATUS atcab_aes_gcm_decrypt_update (
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * ciphertext,
    uint32_t ciphertext_size,
    uint8_t * plaintext )
```

Decrypt data using GCM mode and a key within the ATECC608 device. <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function.

#### **Parameters**

| in  | ctx             | AES GCM context structure.       |
|-----|-----------------|----------------------------------|
| in  | ciphertext      | Ciphertext to be decrypted.      |
| in  | ciphertext_size | Size of ciphertext in bytes.     |
| out | plaintext       | Decrypted data is returned here. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.27 atcab\_aes\_gcm\_encrypt\_finish()

```
uint8_t * tag,
size_t tag_size )
```

Complete a GCM encrypt operation returning the authentication tag.

#### **Parameters**

| in  | ctx      | AES GCM context structure.           |
|-----|----------|--------------------------------------|
| out | tag      | Authentication tag is returned here. |
| in  | tag_size | Tag size in bytes (12 to 16 bytes).  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.28 atcab\_aes\_gcm\_encrypt\_update()

```
ATCA_STATUS atcab_aes_gcm_encrypt_update (
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * plaintext,
    uint32_t plaintext_size,
    uint8_t * ciphertext )
```

Encrypt data using GCM mode and a key within the ATECC608 device. <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function.

## **Parameters**

| in  | ctx            | AES GCM context structure.            |
|-----|----------------|---------------------------------------|
| in  | plaintext      | Plaintext to be encrypted (16 bytes). |
| in  | plaintext_size | Size of plaintext in bytes.           |
| out | ciphertext     | Encrypted data is returned here.      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.29 atcab\_aes\_gcm\_init()

```
ATCA_STATUS atcab_aes_gcm_init (
    atca_aes_gcm_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    const uint8_t * iv,
    size_t iv_size )
```

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

| in | ctx       | AES GCM context to be initialized.                                            |
|----|-----------|-------------------------------------------------------------------------------|
| in | key_id    | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |
| in | key_block | Index of the 16-byte block to use within the key location for the actual key. |
| in | iv        | Initialization vector.                                                        |
| in | iv_size   | Size of IV in bytes. Standard is 12 bytes.                                    |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.30 atcab\_aes\_gcm\_init\_rand()

```
ATCA_STATUS atcab_aes_gcm_init_rand (
    atca_aes_gcm_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    size_t rand_size,
    const uint8_t * free_field,
    size_t free_field_size,
    uint8_t * iv)
```

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

### **Parameters**

| in  | ctx             | AES CTR context to be initialized.                                                               |
|-----|-----------------|--------------------------------------------------------------------------------------------------|
| in  | key_id          | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.                     |
| in  | key_block       | Index of the 16-byte block to use within the key location for the actual key.                    |
| in  | rand_size       | Size of the random field in bytes. Minimum and recommended size is 12 bytes. Max is 32 bytes.    |
| in  | free_field      | Fixed data to include in the IV after the random field. Can be NULL if not used.                 |
| in  | free_field_size | Size of the free field in bytes.                                                                 |
| out | iv              | Initialization vector is returned here. Its size will be rand_size and free_field_size combined. |

## Returns

ATCA SUCCESS on success, otherwise an error code.

## 18.1.4.31 atcab\_aes\_gfm()

```
ATCA_STATUS atcab_aes_gfm ( const uint8_t * h,
```

```
const uint8_t * input,
uint8_t * output )
```

Perform a Galois Field Multiply (GFM) operation.

## **Parameters**

| in  | h      | First input value (16 bytes).           |
|-----|--------|-----------------------------------------|
| in  | input  | Second input value (16 bytes).          |
| out | output | GFM result is returned here (16 bytes). |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.32 atcab\_challenge()

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

#### **Parameters**

| in | num← | Data to be loaded into TempKey (32 bytes). |
|----|------|--------------------------------------------|
|    | _in  |                                            |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.33 atcab\_challenge\_seed\_update()

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number.

| in  | num_in   | Host nonce to be combined with the device random number (20 bytes).             |
|-----|----------|---------------------------------------------------------------------------------|
| out | rand_out | Internally generated 32-byte random number that was used in the nonce/challenge |
|     |          | calculation is returned here. Can be NULL if not needed.                        |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.34 atcab\_checkmac()

Compares a MAC response with input values.

#### **Parameters**

| in | mode       | Controls which fields within the device are used in the message |
|----|------------|-----------------------------------------------------------------|
| in | key_id     | Key location in the CryptoAuth device to use for the MAC        |
| in | challenge  | Challenge data (32 bytes)                                       |
| in | response   | MAC response data (32 bytes)                                    |
| in | other_data | OtherData parameter (13 bytes)                                  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.35 atcab\_cmp\_config\_zone()

Compares a specified configuration zone with the configuration zone currently on the device.

This only compares the static portions of the configuration zone and skips those that are unique per device (first 16 bytes) and areas that can change after the configuration zone has been locked (e.g. LastKeyUse).

| in  | config_data | Full configuration data to compare the device against.                                  |
|-----|-------------|-----------------------------------------------------------------------------------------|
| out | same_config | Result is returned here. True if the static portions on the configuration zones are the |
|     |             | same.                                                                                   |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.36 atcab\_counter()

Compute the Counter functions.

## **Parameters**

|   | in  | mode          | the mode used for the counter                     |
|---|-----|---------------|---------------------------------------------------|
|   | in  | counter_id    | The counter to be used                            |
| Ī | out | counter_value | pointer to the counter value returned from device |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.37 atcab\_counter\_increment()

Increments one of the device's monotonic counters.

# Parameters

| in  | counter_id    | Counter to be incremented                                             |
|-----|---------------|-----------------------------------------------------------------------|
| out | counter_value | New value of the counter is returned here. Can be NULL if not needed. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.38 atcab\_counter\_read()

Read one of the device's monotonic counters.

#### **Parameters**

| in  | counter_id    | Counter to be read              |
|-----|---------------|---------------------------------|
| out | counter_value | Counter value is returned here. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.39 atcab\_derivekey()

```
ATCA_STATUS atcab_derivekey (
            uint8_t mode,
            uint16_t key_id,
            const uint8_t * mac )
```

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

## **Parameters**

| in | mode | Bit 2 must match the value in TempKey.SourceFlag                       |  |
|----|------|------------------------------------------------------------------------|--|
| in | key⊷ | Key slot to be written                                                 |  |
|    | _id  |                                                                        |  |
| in | mac  | Optional 32 byte MAC used to validate operation. NULL if not required. |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.40 atcab\_ecdh()

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

| in | key_id     | Slot of private key for ECDH computation                                                  |
|----|------------|-------------------------------------------------------------------------------------------|
| in | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for |
|    |            | P256 key.                                                                                 |
| ou | pms        | Computed ECDH premaster secret is returned here. 32 bytes.                                |

ATCA\_SUCCESS on success

# 18.1.4.41 atcab\_ecdh\_base()

```
ATCA_STATUS atcab_ecdh_base (
    uint8_t mode,
    uint16_t key_id,
    const uint8_t * public_key,
    uint8_t * pms,
    uint8_t * out_nonce)
```

Base function for generating premaster secret key using ECDH.

#### **Parameters**

| in  | mode       | Mode to be used for ECDH computation                                                                |
|-----|------------|-----------------------------------------------------------------------------------------------------|
| in  | key_id     | Slot of key for ECDH computation                                                                    |
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms        | Computed ECDH pre-master secret is returned here (32 bytes) if returned directly. Otherwise NULL.   |
| out | out_nonce  | Nonce used to encrypt pre-master secret. NULL if output encryption not used.                        |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.42 atcab\_ecdh\_enc()

```
ATCA_STATUS atcab_ecdh_enc (
    uint16_t key_id,
    const uint8_t * public_key,
    uint8_t * pms,
    const uint8_t * read_key,
    uint16_t read_key_id,
    const uint8_t num_in[(20)])
```

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

This function only works for even numbered slots with the proper configuration.

| in | key_id     | Slot of key for ECDH computation                                                      |
|----|------------|---------------------------------------------------------------------------------------|
| in | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes |
|    |            | for P256 key.                                                                         |

| out | pms              | Computed ECDH premaster secret is returned here (32 bytes). |  |
|-----|------------------|-------------------------------------------------------------|--|
| in  | read_key         | Read key for the premaster secret slot (key_id 1).          |  |
| in  | read_key⊷<br>_id | Read key slot for read_key.                                 |  |
| in  | num_in           | 20 byte host nonce to inject into Nonce calculation         |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.43 atcab\_ecdh\_ioenc()

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

# **Parameters**

| in  | key_id     | Slot of key for ECDH computation                                                          |  |
|-----|------------|-------------------------------------------------------------------------------------------|--|
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for |  |
|     |            | P256 key.                                                                                 |  |
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                               |  |
| in  | io_key     | IO protection key.                                                                        |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.44 atcab\_ecdh\_tempkey()

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 79

| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |  |
|-----|------------|-----------------------------------------------------------------------------------------------------|--|
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                                         |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.45 atcab\_ecdh\_tempkey\_ioenc()

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.

#### **Parameters**

| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |  |
|-----|------------|-----------------------------------------------------------------------------------------------------|--|
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                                         |  |
| in  | io_key     | IO protection key.                                                                                  |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.46 atcab\_gendig()

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

| in zone Designates the source of the data to hash with TempKey.                 |  | Designates the source of the data to hash with TempKey.                                                                              |    |
|---------------------------------------------------------------------------------|--|--------------------------------------------------------------------------------------------------------------------------------------|----|
| in key_id Indicates the key, OTP block, or message order for shared nonce mode. |  |                                                                                                                                      |    |
| in other data<br>© 2020 Microchip Technology Inc                                |  | Four bytes of data for SHA calculation when using a NoMac key, 32 bytes for<br>"Shared Nonce" mode, otherwise ignored (can be NULL). | 80 |
| in other_data_size Size of other_data in bytes.                                 |  | Size of other_data in bytes.                                                                                                         |    |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.47 atcab\_genkey()

```
ATCA_STATUS atcab_genkey ( uint16_t key_id, uint8_t * public_key )
```

Issues GenKey command, which generates a new random private key in slot/handle and returns the public key.

## **Parameters**

| in  | key_id     | Slot number where an ECC private key is configured. Can also be ATCA_TEMPKEY_KEYID to generate a private key in TempKey.                                       |  |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve. Set to NULL if public key isn't required. |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.48 atcab\_genkey\_base()

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

## **Parameters**

| in  | mode       | Mode determines what operations the GenKey command performs.                                                                                                                                                  |  |
|-----|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| in  | key_id     | Slot to perform the GenKey command on.                                                                                                                                                                        |  |
| in  | other_data | therData for PubKey digest calculation. Can be set to NULL otherwise.                                                                                                                                         |  |
| out | public_key | If the mode indicates a public key will be calculated, it will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve. Set to NULL if public key isn't required. |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.49 atcab\_get\_device()

```
ATCADevice atcab_get_device ( void )
```

Get the global device object.

## Returns

instance of global ATCADevice

# 18.1.4.50 atcab\_get\_device\_type()

Get the current device type configured for the global ATCADevice.

## Returns

Device type if basic api is initialized or ATCA\_DEV\_UNKNOWN.

# 18.1.4.51 atcab\_get\_device\_type\_ext()

Get the selected device type of rthe device context.

# **Parameters**

|  | in | device | Device context pointer |
|--|----|--------|------------------------|
|--|----|--------|------------------------|

# Returns

Device type if basic api is initialized or ATCA\_DEV\_UNKNOWN.

# 18.1.4.52 atcab\_get\_pubkey()

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 82

Uses GenKey command to calculate the public key from an existing private key in a slot.

#### **Parameters**

| in  | key_id     | Slot number of the private key.                                                     |  |
|-----|------------|-------------------------------------------------------------------------------------|--|
| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian |  |
|     |            | format. 64 bytes for P256 curve. Set to NULL if public key isn't required.          |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.53 atcab\_get\_zone\_size()

Gets the size of the specified zone in bytes.

#### **Parameters**

| in  | zone | Zone to get size information from. Config(0), OTP(1), or Data(2) which requires a slot. |  |
|-----|------|-----------------------------------------------------------------------------------------|--|
| in  | slot | If zone is Data(2), the slot to query for size.                                         |  |
| out | size | Zone size is returned here.                                                             |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.54 atcab\_hmac()

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

| in  | mode   | Controls which fields within the device are used in the message.                              |  |
|-----|--------|-----------------------------------------------------------------------------------------------|--|
| in  | key⊷   | Which key is to be used to generate the response. Bits 0:3 only are used to select a slot but |  |
|     | _id    | all 16 bits are used in the HMAC message.                                                     |  |
| out | digest | HMAC digest is returned in this buffer (32 bytes).                                            |  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.55 atcab\_hw\_sha2\_256()

Use the SHA command to compute a SHA-256 digest.

## **Parameters**

| in  | data      | Message data to be hashed.          |
|-----|-----------|-------------------------------------|
| in  | data_size | Size of data in bytes.              |
| out | digest    | Digest is returned here (32 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.56 atcab\_hw\_sha2\_256\_finish()

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

#### **Parameters**

| in  | ctx    | SHA256 context                            |
|-----|--------|-------------------------------------------|
| out | digest | SHA256 digest is returned here (32 bytes) |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.57 atcab\_hw\_sha2\_256\_init()

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

#### **Parameters**

| in ctx SHA256 context |
|-----------------------|
|-----------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.58 atcab\_hw\_sha2\_256\_update()

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

#### **Parameters**

| in | ctx       | SHA256 context                    |
|----|-----------|-----------------------------------|
| in | data      | Message data to be added to hash. |
| in | data_size | Size of data in bytes.            |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.59 atcab\_idle()

```
ATCA_STATUS atcab_idle ( void )
```

idle the CryptoAuth device

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.60 atcab\_info()

Use the Info command to get the device revision (DevRev).

| revision Device revision is returned here (4 bytes). | out <i>revision</i> |
|------------------------------------------------------|---------------------|
|------------------------------------------------------|---------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.61 atcab\_info\_base()

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

## **Parameters**

|                                                                                    | in | in <i>mode</i> Selects which mode to be used for info command.            |                                             |
|------------------------------------------------------------------------------------|----|---------------------------------------------------------------------------|---------------------------------------------|
|                                                                                    | in | param2                                                                    | Selects the particular fields for the mode. |
| out out_data Response from info command (4 bytes). Can be set to NULL if not requi |    | Response from info command (4 bytes). Can be set to NULL if not required. |                                             |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.62 atcab\_info\_get\_latch()

```
ATCA_STATUS atcab_info_get_latch ( bool * state )
```

Use the Info command to get the persistent latch current state for an ATECC608 device.

# **Parameters**

| out   | state | The state is returned here. Set (true) or Cler (false). |
|-------|-------|---------------------------------------------------------|
| 0 4 0 | Olalo | 1110 01410 10 101411104 110101 001 (11410)              |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 86

## 18.1.4.63 atcab\_info\_set\_latch()

```
ATCA_STATUS atcab_info_set_latch ( bool state )
```

Use the Info command to set the persistent latch state for an ATECC608 device.

## **Parameters**

| out | state | Persistent latch state. | Set (true) or clear (false). |
|-----|-------|-------------------------|------------------------------|
|-----|-------|-------------------------|------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.64 atcab\_init()

```
ATCA_STATUS atcab_init ( {\tt ATCAIfaceCfg} \ * \ cfg \ )
```

Creates a global ATCADevice object used by Basic API.

#### **Parameters**

| in | cfg | Logical interface configuration. Some predefined configurations can be found in atca_cfgs.h |
|----|-----|---------------------------------------------------------------------------------------------|
|----|-----|---------------------------------------------------------------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.65 atcab\_init\_device()

```
ATCA_STATUS atcab_init_device (
ATCADevice ca_device)
```

Initialize the global ATCADevice object to point to one of your choosing for use with all the atcab\_basic API.

**Deprecated** This function is not recommended for use generally. Use of \_ext is recommended instead. You can use atcab\_init\_ext to obtain an initialized instance and associated it with the global structure - but this shouldn't be a required process except in extremely unusual circumstances.

| in | ca_device | ATCADevice instance to use as the global Basic API crypto device instance |  |
|----|-----------|---------------------------------------------------------------------------|--|
|----|-----------|---------------------------------------------------------------------------|--|

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.66 atcab\_init\_ext()

Creates and initializes a ATCADevice context.

# **Parameters**

| out | device | Pointer to the device context pointer                                                       |  |
|-----|--------|---------------------------------------------------------------------------------------------|--|
| in  | cfg    | Logical interface configuration. Some predefined configurations can be found in atca_cfgs.h |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.67 atcab\_is\_ca\_device()

Check whether the device is cryptoauth device.

# Returns

True if device is cryptoauth device or False.

# 18.1.4.68 atcab\_is\_config\_locked()

```
ATCA_STATUS atcab_is_config_locked ( bool * is_locked )
```

This function check whether configuration zone is locked or not.

| out | is locked | Lock state returned here. True if locked. |
|-----|-----------|-------------------------------------------|
|     |           |                                           |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.69 atcab\_is\_data\_locked()

```
ATCA_STATUS atcab_is_data_locked ( bool * is\_locked )
```

This function check whether data/setup zone is locked or not.

## **Parameters**

|  | out | is_locked | Lock state returned here. True if locked. |
|--|-----|-----------|-------------------------------------------|
|--|-----|-----------|-------------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.70 atcab\_is\_locked()

```
ATCA_STATUS atcab_is_locked ( uint8_t zone, bool * is_locked )
```

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

# Parameters

| in  | zone      | The zone to query for locked (use LOCK_ZONE_CONFIG or LOCK_ZONE_DATA). |
|-----|-----------|------------------------------------------------------------------------|
| out | is_locked | Lock state returned here. True if locked.                              |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.71 atcab\_is\_slot\_locked()

```
ATCA_STATUS atcab_is_slot_locked ( uint16_t slot, bool * is_locked )
```

This function check whether slot/handle is locked or not.

| in  | slot      | Slot to query for locked                  |
|-----|-----------|-------------------------------------------|
| out | is_locked | Lock state returned here. True if locked. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.72 atcab\_is\_ta\_device()

Check whether the device is Trust Anchor device.

#### Returns

True if device is Trust Anchor device or False.

# 18.1.4.73 atcab\_kdf()

```
ATCA_STATUS atcab_kdf (
    uint8_t mode,
    uint16_t key_id,
    const uint32_t details,
    const uint8_t * message,
    uint8_t * out_data,
    uint8_t * out_nonce)
```

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

Generally this function combines a source key with an input string and creates a result key/digest/array.

| in  | mode      | Mode determines KDF algorithm (PRF,AES,HKDF), source key location, and target key locations.                                                                            |
|-----|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | key_id    | Source and target key slots if locations are in the EEPROM. Source key slot is the LSB and target key slot is the MSB.                                                  |
| in  | details   | Further information about the computation, depending on the algorithm (4 bytes).                                                                                        |
| in  | message   | Input value from system (up to 128 bytes). Actual size of message is 16 bytes for AES algorithm or is encoded in the MSB of the details parameter for other algorithms. |
| out | out_data  | Output of the KDF function is returned here. If the result remains in the device, this can be NULL.                                                                     |
| out | out_nonce | If the output is encrypted, a 32 byte random nonce generated by the device is returned here. If output encryption is not used, this can be NULL.                        |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.74 atcab\_lock()

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

#### **Parameters**

| - | in | mode        | Zone, and/or slot, and summary check (bit 7).                                      |
|---|----|-------------|------------------------------------------------------------------------------------|
| - | in | summary_crc | CRC of the config or data zones. Ignored for slot locks or when mode bit 7 is set. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.75 atcab\_lock\_config\_zone()

```
ATCA_STATUS atcab_lock_config_zone ( void )
```

Unconditionally (no CRC required) lock the config zone.

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.76 atcab\_lock\_config\_zone\_crc()

```
ATCA_STATUS atcab_lock_config_zone_crc ( uint16_t summary_crc )
```

Lock the config zone with summary CRC.

The CRC is calculated over the entire config zone contents. 48 bytes for TA100, 88 bytes for ATSHA devices, 128 bytes for ATECC devices. Lock will fail if the provided CRC doesn't match the internally calculated one.

| in summary_crc | Expected CRC over the config zone. |
|----------------|------------------------------------|
|----------------|------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.77 atcab\_lock\_data\_slot()

```
ATCA_STATUS atcab_lock_data_slot ( uint16_t slot )
```

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1) (for cryptoauth devices) or Lock an individual handle in shared data element on an Trust Anchor device (for Trust Anchor devices).

## **Parameters**

| in | slot | Slot to be locked in data zone. |
|----|------|---------------------------------|
|----|------|---------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.78 atcab\_lock\_data\_zone()

```
ATCA_STATUS atcab_lock_data_zone ( void )
```

Unconditionally (no CRC required) lock the data zone (slots and OTP). for CryptoAuth devices and lock the setup for Trust Anchor device.

ConfigZone must be locked and DataZone must be unlocked for the zone to be successfully locked.

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.79 atcab\_lock\_data\_zone\_crc()

```
ATCA_STATUS atcab_lock_data_zone_crc ( uint16_t summary_crc )
```

Lock the data zone (slots and OTP) with summary CRC.

The CRC is calculated over the concatenated contents of all the slots and OTP at the end. Private keys (Key← Config.Private=1) are skipped. Lock will fail if the provided CRC doesn't match the internally calculated one.

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.80 atcab\_mac()

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

#### **Parameters**

| in  | mode      | Controls which fields within the device are used in the message                         |
|-----|-----------|-----------------------------------------------------------------------------------------|
| in  | key_id    | Key in the CryptoAuth device to use for the MAC                                         |
| in  | challenge | Challenge message (32 bytes). May be NULL if mode indicates a challenge isn't required. |
| out | digest    | MAC response is returned here (32 bytes).                                               |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.81 atcab\_nonce()

```
ATCA_STATUS atcab_nonce (
const uint8_t * num_in )
```

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

| in | num← | Data to be loaded into TempKey (32 bytes). |  |  |
|----|------|--------------------------------------------|--|--|
|    | in   |                                            |  |  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.82 atcab\_nonce\_base()

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

#### **Parameters**

| in  | mode     | Controls the mechanism of the internal RNG or fixed write.                                                                                                             |
|-----|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | zero     | Param2, normally 0, but can be used to indicate a nonce calculation mode (bit 15).                                                                                     |
| in  | num_in   | Input value to either be included in the nonce calculation in random modes (20 bytes) or to be written directly (32 bytes or 64 bytes(ATECC608)) in pass-through mode. |
| out | rand_out | If using a random mode, the internally generated 32-byte random number that was used in the nonce calculation is returned here. Can be NULL if not needed.             |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.83 atcab\_nonce\_load()

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

For the ATECC608, available targets are TempKey (32 or 64 bytes), Message Digest Buffer (32 or 64 bytes), or the Alternate Key Buffer (32 bytes). For all other devices, only TempKey (32 bytes) is available.

| in | target      | Target device buffer to load. Can be NONCE_MODE_TARGET_TEMPKEY, NONCE_MODE_TARGET_MSGDIGBUF, or NONCE_MODE_TARGET_ALTKEYBUF. |  |
|----|-------------|------------------------------------------------------------------------------------------------------------------------------|--|
| in | num_in      | Data to load into the buffer.                                                                                                |  |
| in | num_in_size | Size of num_in in bytes. Can be 32 or 64 bytes depending on device and target.                                               |  |

# 18.1 Basic Crypto API methods (atcab\_)

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.84 atcab\_nonce\_rand()

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

#### **Parameters**

| in  | num_in   | Host nonce to be combined with the device random number (20 bytes).             |
|-----|----------|---------------------------------------------------------------------------------|
| out | rand_out | Internally generated 32-byte random number that was used in the nonce/challenge |
|     |          | calculation is returned here. Can be NULL if not needed.                        |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.85 atcab\_printbin()

# 18.1.4.86 atcab\_priv\_write()

Executes PrivWrite command, to write externally generated ECC private keys into the device.

| in                               | key_id                                   | Slot to write the external private key into.                                                                             |
|----------------------------------|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| in                               | priv_key                                 | External private key (36 bytes) to be written. The first 4 bytes should be zero for P256                                 |
| © <del>2020 <b>M</b></del><br>in | icrochip Technology<br>Write_key←<br>_id | curve.  CryptoAuthLib.v32.3  Write key slot. Ignored if write_key is NULL.                                               |
| in                               | write_key                                | Write key (32 bytes). If NULL, perform an unencrypted PrivWrite, which is only available when the data zone is unlocked. |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.87 atcab\_random()

```
ATCA_STATUS atcab_random ( uint8_t * rand_out )
```

Executes Random command, which generates a 32 byte random number from the device.

## **Parameters**

| out | rand_out | 32 bytes of random data is returned here. |
|-----|----------|-------------------------------------------|
|-----|----------|-------------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.88 atcab\_random\_ext()

Executes Random command, which generates a 32 byte random number from the device.

## **Parameters**

| in  | device   | Device context pointer                    |
|-----|----------|-------------------------------------------|
| out | rand_out | 32 bytes of random data is returned here. |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.89 atcab\_read\_bytes\_zone()

```
uint8_t * data,
size_t length )
```

Used to read an arbitrary number of bytes from any zone configured for clear reads.

This function will issue the Read command as many times as is required to read the requested data.

#### **Parameters**

| in  | zone   | Zone to read data from. Option are ATCA_ZONE_CONFIG(0), ATCA_ZONE_OTP(1), or ATCA_ZONE_DATA(2). |
|-----|--------|-------------------------------------------------------------------------------------------------|
| in  | slot   | Slot number to read from if zone is ATCA_ZONE_DATA(2). Ignored for all other zones.             |
| in  | offset | Byte offset within the zone to read from.                                                       |
| out | data   | Read data is returned here.                                                                     |
| in  | length | Number of bytes to read starting from the offset.                                               |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.90 atcab\_read\_config\_zone()

```
ATCA_STATUS atcab_read_config_zone ( uint8_t * config_data )
```

Executes Read command to read the complete device configuration zone.

# **Parameters**

| out | config_data | Configuration zone data is returned here. 88 bytes for ATSHA devices, 128 bytes for |
|-----|-------------|-------------------------------------------------------------------------------------|
|     |             | ATECC devices and 48 bytes for Trust Anchor devices.                                |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.91 atcab\_read\_enc()

```
ATCA_STATUS atcab_read_enc (
    uint16_t key_id,
    uint8_t block,
    uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[(20)])
```

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

Data zone must be locked for this command to succeed. Can only read 32 byte blocks.

| in  | key_id   | The slot ID to read from.                                             |
|-----|----------|-----------------------------------------------------------------------|
| in  | block    | Index of the 32 byte block within the slot to read.                   |
| out | data     | Decrypted (plaintext) data from the read is returned here (32 bytes). |
| in  | enc_key  | 32 byte ReadKey for the slot being read.                              |
| in  | enc_key← | KeyID of the ReadKey being used.                                      |
|     | _id      |                                                                       |
| in  | num_in   | 20 byte host nonce to inject into Nonce calculation                   |

returns ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.92 atcab\_read\_pubkey()

```
ATCA_STATUS atcab_read_pubkey ( uint16_t slot, uint8_t * public_key )
```

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

This function assumes the public key is stored using the ECC public key format specified in the datasheet.

## **Parameters**

| in  | slot       | Slot number to read from. Only slots 8 to 15 are large enough for a public key.       |
|-----|------------|---------------------------------------------------------------------------------------|
| out | public_key | Public key is returned here (64 bytes). Format will be the 32 byte X and Y big-endian |
|     |            | integers concatenated.                                                                |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.93 atcab\_read\_serial\_number()

This function returns serial number of the device.

## **Parameters**

| out serial_number 9 | byte serial number is returned here. |
|---------------------|--------------------------------------|
|---------------------|--------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.94 atcab\_read\_sig()

```
ATCA_STATUS atcab_read_sig ( uint16_t slot, uint8_t * sig )
```

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

#### **Parameters**

| in  | slot | Slot number to read from. Only slots 8 to 15 are large enough for a signature.                                   |
|-----|------|------------------------------------------------------------------------------------------------------------------|
| out | sig  | Signature will be returned here (64 bytes). Format will be the 32 byte R and S big-endian integers concatenated. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.95 atcab\_read\_zone()

```
ATCA_STATUS atcab_read_zone (
    uint8_t zone,
    uint16_t slot,
    uint8_t block,
    uint8_t offset,
    uint8_t * data,
    uint8_t len )
```

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

When reading a slot or OTP, data zone must be locked and the slot configuration must not be secret for a slot to be successfully read.

## **Parameters**

| in  | zone   | Zone to be read from device. Options are ATCA_ZONE_CONFIG, ATCA_ZONE_OTP, or ATCA_ZONE_DATA. |
|-----|--------|----------------------------------------------------------------------------------------------|
| in  | slot   | Slot number for data zone and ignored for other zones.                                       |
| in  | block  | 32 byte block index within the zone.                                                         |
| in  | offset | 4 byte work index within the block. Ignored for 32 byte reads.                               |
| out | data   | Read data is returned here.                                                                  |
| in  | len    | Length of the data to be read. Must be either 4 or 32.                                       |

returns ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 99

# 18.1.4.96 atcab\_release()

```
ATCA_STATUS atcab_release ( void )
```

release (free) the global ATCADevice instance. This must be called in order to release or free up the interface.

# Returns

Returns ATCA\_SUCCESS .

## 18.1.4.97 atcab\_release\_ext()

```
ATCA_STATUS atcab_release_ext (
ATCADevice * device )
```

release (free) the an ATCADevice instance.

#### **Parameters**

| i | n | device | Pointer to the device context pointer |
|---|---|--------|---------------------------------------|
|---|---|--------|---------------------------------------|

## Returns

Returns ATCA\_SUCCESS .

# 18.1.4.98 atcab\_secureboot()

```
ATCA_STATUS atcab_secureboot (
    uint8_t mode,
    uint16_t param2,
    const uint8_t * digest,
    const uint8_t * signature,
    uint8_t * mac)
```

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

| in  | mode      | Mode determines what operations the SecureBoot command performs.                            |
|-----|-----------|---------------------------------------------------------------------------------------------|
| in  | param2    | Not used, must be 0.                                                                        |
| in  | digest    | Digest of the code to be verified (32 bytes).                                               |
| in  | signature | Signature of the code to be verified (64 bytes). Can be NULL when using the FullStore mode. |
| out | mac       | Validating MAC will be returned here (32 bytes). Can be NULL if not required.               |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.99 atcab\_secureboot\_mac()

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

#### **Parameters**

| in  | mode        | Mode determines what operations the SecureBoot command performs.                            |  |
|-----|-------------|---------------------------------------------------------------------------------------------|--|
| in  | digest      | Digest of the code to be verified (32 bytes). This is the plaintext digest (not encrypted). |  |
| in  | signature   | Signature of the code to be verified (64 bytes). Can be NULL when using the FullStore       |  |
|     |             | mode.                                                                                       |  |
| in  | num_in      | Host nonce (20 bytes).                                                                      |  |
| in  | io_key      | IO protection key (32 bytes).                                                               |  |
| out | is_verified | Verify result is returned here.                                                             |  |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.100 atcab\_selftest()

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the ATECC608 chip.

| in  | mode   | Functions to test. Can be a bit field combining any of the following: |  |
|-----|--------|-----------------------------------------------------------------------|--|
|     |        | SELFTEST_MODE_RNG, SELFTEST_MODE_ECDSA_VERIFY,                        |  |
|     |        | SELFTEST_MODE_ECDSA_SIGN, SELFTEST_MODE_ECDH, SELFTEST_MODE_AES,      |  |
|     |        | SELFTEST_MODE_SHA, SELFTEST_MODE_ALL.                                 |  |
| in  | param2 | Currently unused, should be 0.                                        |  |
| out | result | Results are returned here as a bit field.                             |  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.101 atcab\_sha()

Use the SHA command to compute a SHA-256 digest.

## **Parameters**

| in  | length  | Size of message parameter in bytes. |
|-----|---------|-------------------------------------|
| in  | message | Message data to be hashed.          |
| out | digest  | Digest is returned here (32 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.102 atcab\_sha\_base()

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

Only the Start(0) and Compute(1) modes are available for ATSHA devices.

| in                              | mode          | SHA command mode Start(0), Update/Compute(1), End(2), Public(3), HMACstart(4), HMACend(5), Read_Context(6), or Write_Context(7). Also message digest target location for the ATECC608. |  |
|---------------------------------|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| in                              | length        | Number of bytes in the message parameter or KeySlot for the HMAC key if Mode is HMACstart(4) or Public(3).                                                                             |  |
| in                              | data_in       | Message bytes to be hashed or Write_Context if restoring a context on the ATECC608. Can be NULL if not required by the mode.                                                           |  |
| out                             | data_out      | Data returned by the command (digest or context).                                                                                                                                      |  |
| in,out                          | data_out_size | As input, the size of the data_out buffer. As output, the number of bytes returned                                                                                                     |  |
| © 2020 Microchip Technology Inc |               | in data_out. CryptoAuthLib v3.2.3 102                                                                                                                                                  |  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.103 atcab\_sha\_end()

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

# **Parameters**

| 0 | ut | digest  | Digest from SHA-256 or HMAC/SHA-256 will be returned here (32 bytes). |
|---|----|---------|-----------------------------------------------------------------------|
| i | .n | length  | Length of any remaining data to include in hash. Max 64 bytes.        |
| i | .n | message | Remaining data to include in hash. NULL if length is 0.               |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.104 atcab\_sha\_hmac()

Use the SHA command to compute an HMAC/SHA-256 operation.

| in  | data      | Message data to be hashed.                                                                                                                                                                                                |  |
|-----|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| in  | data_size | Size of data in bytes.                                                                                                                                                                                                    |  |
| in  | key_slot  | Slot key id to use for the HMAC calculation                                                                                                                                                                               |  |
| out | digest    | Digest is returned here (32 bytes).                                                                                                                                                                                       |  |
| in  | target    | Where to save the digest internal to the device. For ATECC608, can be SHA_MODE_TARGET_TEMPKEY, SHA_MODE_TARGET_MSGDIGBUF, or SHA_MODE_TARGET_OUT_ONLY. For all other devices, SHA_MODE_TARGET_TEMPKEY is the only option. |  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.105 atcab\_sha\_hmac\_finish()

Executes SHA command to complete a HMAC/SHA-256 operation.

## **Parameters**

| in  | ctx    | HMAC/SHA-256 context                                                  |  |
|-----|--------|-----------------------------------------------------------------------|--|
| out | digest | HMAC/SHA-256 result is returned here (32 bytes).                      |  |
| in  | target | Where to save the digest internal to the device. For ATECC608, can be |  |
|     |        | SHA_MODE_TARGET_TEMPKEY, SHA_MODE_TARGET_MSGDIGBUF, or                |  |
|     |        | SHA_MODE_TARGET_OUT_ONLY. For all other devices,                      |  |
|     |        | SHA_MODE_TARGET_TEMPKEY is the only option.                           |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.106 atcab\_sha\_hmac\_init()

Executes SHA command to start an HMAC/SHA-256 operation.

## **Parameters**

| in | ctx      | HMAC/SHA-256 context                        |
|----|----------|---------------------------------------------|
| in | key_slot | Slot key id to use for the HMAC calculation |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.107 atcab\_sha\_hmac\_update()

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

#### **Parameters**

| in | ctx       | HMAC/SHA-256 context          |
|----|-----------|-------------------------------|
| in | data      | Message data to add           |
| in | data_size | Size of message data in bytes |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.108 atcab\_sha\_read\_context()

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

## **Parameters**

| out    | context      | Context data is returned here.                                                         |
|--------|--------------|----------------------------------------------------------------------------------------|
| in,out | context_size | As input, the size of the context buffer in bytes. As output, the size of the returned |
|        |              | context data.                                                                          |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.109 atcab\_sha\_start()

```
ATCA_STATUS atcab_sha_start ( void )
```

Executes SHA command to initialize SHA-256 calculation engine.

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.110 atcab\_sha\_update()

Executes SHA command to add 64 bytes of message data to the current context.

## **Parameters**

| in | message | 64 bytes of message data to add to add to operation. |  |
|----|---------|------------------------------------------------------|--|
|----|---------|------------------------------------------------------|--|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.111 atcab\_sha\_write\_context()

Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.

## **Parameters**

| in | context      | Context data to be restored.       |
|----|--------------|------------------------------------|
| in | context_size | Size of the context data in bytes. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.1.4.112 atcab\_sign()

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

| in  | key_id    | Slot of the private key to be used to sign the message.                                                    |
|-----|-----------|------------------------------------------------------------------------------------------------------------|
| in  | msg       | 32-byte message to be signed. Typically the SHA256 hash of the full message.                               |
| out | signature | Signature will be returned here. Format is R and S integers in big-endian format. 64 bytes for P256 curve. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.113 atcab\_sign\_base()

Executes the Sign command, which generates a signature using the ECDSA algorithm.

## **Parameters**

| in  | mode      | Mode determines what the source of the message to be signed.                                          |
|-----|-----------|-------------------------------------------------------------------------------------------------------|
| in  | key_id    | Private key slot used to sign the message.                                                            |
| out | signature | Signature is returned here. Format is R and S integers in big-endian format. 64 bytes for P256 curve. |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.114 atcab\_sign\_internal()

Executes Sign command to sign an internally generated message.

| in  | key_id                           | Slot of the private key to be used to sign the message.                                                        |
|-----|----------------------------------|----------------------------------------------------------------------------------------------------------------|
| in  | is_invalidate                    | Set to true if the signature will be used with the Verify(Invalidate) command. false for all                   |
|     |                                  | other cases.                                                                                                   |
| in  | is_full_sn                       | Set to true if the message should incorporate the device's full serial number.                                 |
| out | ochip Technology In<br>Signature | CryptoAuthLib v3.2.3 107 Signature is returned here. Format is R and S integers in big-endian format. 64 bytes |
|     |                                  | for P256 curve.                                                                                                |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.115 atcab\_sleep()

```
ATCA_STATUS atcab_sleep ( void )
```

invoke sleep on the CryptoAuth device

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.116 atcab\_updateextra()

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

Can also be used to decrement the limited use counter associated with the key in slot NewValue.

## **Parameters**

| i | n | mode      | Mode determines what operations the UpdateExtra command performs. |
|---|---|-----------|-------------------------------------------------------------------|
| i | n | new_value | Value to be written.                                              |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.117 atcab\_verify()

```
const uint8_t * other_data,
uint8_t * mac )
```

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

For the Stored, External, and ValidateExternal Modes, the contents of TempKey (or Message Digest Buffer in some cases for the ATECC608) should contain the 32 byte message.

#### **Parameters**

| in  | mode       | Verify command mode and options                                                                                                                                                                                                                                                                                                    |
|-----|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | key_id     | Stored mode, the slot containing the public key to be used for the verification.  ValidateExternal mode, the slot containing the public key to be validated. External mode, KeyID contains the curve type to be used to Verify the signature. Validate or Invalidate mode, the slot containing the public key to be (in)validated. |
| in  | signature  | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve.                                                                                                                                                                                                                                          |
| in  | public_key | If mode is External, the public key to be used for verification. X and Y integers in big-endian format. 64 bytes for P256 curve. NULL for all other modes.                                                                                                                                                                         |
| in  | other_data | If mode is Validate, the bytes used to generate the message for the validation (19 bytes). NULL for all other modes.                                                                                                                                                                                                               |
| out | mac        | If mode indicates a validating MAC, then the MAC will will be returned here. Can be NULL otherwise.                                                                                                                                                                                                                                |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.118 atcab\_verify\_extern()

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.                              |
|-----|-------------|-------------------------------------------------------------------------------------------------------------|
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve.                   |
| in  | public_key  | The public key to be used for verification. X and Y integers in big-endian format. 64 bytes for P256 curve. |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                                         |

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.119 atcab\_verify\_extern\_mac()

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

#### **Parameters**

| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | public_key  | The public key to be used for verification. X and Y integers in big-endian format. 64     |
|     |             | bytes for P256 curve.                                                                     |
| in  | num_in      | System nonce (32 byte) used for the verification MAC.                                     |
| in  | io_key      | IO protection key for verifying the validation MAC.                                       |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

### Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.120 atcab\_verify\_invalidate()

```
ATCA_STATUS atcab_verify_invalidate (
    uint16_t key_id,
    const uint8_t * signature,
    const uint8_t * other_data,
    bool * is_verified )
```

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

This command can only be run after GenKey has been used to create a PubKey digest of the public key to be invalidated in TempKey (mode=0x10).

#### **Parameters**

| in          | key_id                               | Slot containing the public key to be invalidated.                                         |
|-------------|--------------------------------------|-------------------------------------------------------------------------------------------|
| in          | signature                            | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| © 20½0 Micr | ०८भ <i>िन्दि</i> टामी <b>ले</b> ट्सि | nd 9 bytes of data used to by dathe verification message.                                 |
| out         | is_verified                          | Boolean whether or not the message, signature, validation public key verified.            |

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.121 atcab\_verify\_stored()

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

#### **Parameters**

| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | key_id      | Slot containing the public key to be used in the verification.                            |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

### Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.122 atcab\_verify\_stored\_mac()

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

### **Parameters**

| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | key_id      | Slot containing the public key to be used in the verification.                            |
| in  | num_in      | System nonce (32 byte) used for the verification MAC.                                     |
| in  | io_key      | IO protection key for verifying the validation MAC.                                       |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.123 atcab\_verify\_validate()

```
ATCA_STATUS atcab_verify_validate (
    uint16_t key_id,
    const uint8_t * signature,
    const uint8_t * other_data,
    bool * is_verified )
```

Executes the Verify command in Validate mode to validate a public key stored in a slot.

This command can only be run after GenKey has been used to create a PubKey digest of the public key to be validated in TempKey (mode=0x10).

#### **Parameters**

| in  | key_id      | Slot containing the public key to be validated.                                           |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | other_data  | 19 bytes of data used to build the verification message.                                  |
| out | is_verified | Boolean whether or not the message, signature, validation public key verified.            |

### Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

### 18.1.4.124 atcab\_version()

```
ATCA_STATUS atcab_version ( char * ver_str )
```

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

returns a version string for the CryptoAuthLib release. The format of the version string returned is "yyyymmdd"

### **Parameters**

| out | ver str | ptr to space to receive version string |
|-----|---------|----------------------------------------|
|     |         | 9                                      |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.125 atcab\_wakeup()

```
ATCA_STATUS atcab_wakeup ( void )
```

wakeup the CryptoAuth device

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.126 atcab\_write()

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

#### **Parameters**

| in | zone    | Zone/Param1 for the write command.                                                            |
|----|---------|-----------------------------------------------------------------------------------------------|
| in | address | Address/Param2 for the write command.                                                         |
| in | value   | Plain-text data to be written or cipher-text for encrypted writes. 32 or 4 bytes depending on |
|    |         | bit 7 in the zone.                                                                            |
| in | mac     | MAC required for encrypted writes (32 bytes). Set to NULL if not required.                    |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.127 atcab\_write\_bytes\_zone()

```
const uint8_t * data,
size_t length )
```

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

Config zone must be unlocked for writes to that zone. If data zone is unlocked, only 32-byte writes are allowed to slots and OTP and the offset and length must be multiples of 32 or the write will fail.

#### **Parameters**

| in | zone         | Zone to write data to: ATCA_ZONE_CONFIG(0), ATCA_ZONE_OTP(1), or ATCA_ZONE_DATA(2).     |
|----|--------------|-----------------------------------------------------------------------------------------|
| in | slot         | If zone is ATCA_ZONE_DATA(2), the slot number to write to. Ignored for all other zones. |
| in | offset_bytes | Byte offset within the zone to write to. Must be a multiple of a word (4 bytes).        |
| in | data         | Data to be written.                                                                     |
| in | length       | Number of bytes to be written. Must be a multiple of a word (4 bytes).                  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.128 atcab\_write\_config\_counter()

Initialize one of the monotonic counters in device with a specific value.

The monotonic counters are stored in the configuration zone using a special format. This encodes a binary count value into the 8 byte encoded value required. Can only be set while the configuration zone is unlocked.

### **Parameters**

| in | counter_id    | Counter to be written. |
|----|---------------|------------------------|
| in | counter_value | Counter value to set.  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.129 atcab\_write\_config\_zone()

Executes the Write command, which writes the configuration zone.

First 16 bytes are skipped as they are not writable. LockValue and LockConfig are also skipped and can only be changed via the Lock command.

This command may fail if UserExtra and/or Selector bytes have already been set to non-zero values.

#### **Parameters**

| in | config_data | Data to the config zone data. This should be 88 bytes for SHA devices and 128 bytes for |
|----|-------------|-----------------------------------------------------------------------------------------|
|    |             | ECC devices.                                                                            |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.130 atcab write enc()

```
ATCA_STATUS atcab_write_enc (
    uint16_t key_id,
    uint8_t block,
    const uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[(20)])
```

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

The function takes clear text bytes and encrypts them for writing over the wire. Data zone must be locked and the slot configuration must be set to encrypted write for the block to be successfully written.

### **Parameters**

| in | key_id   | Slot ID to write to.                                  |
|----|----------|-------------------------------------------------------|
| in | block    | Index of the 32 byte block to write in the slot.      |
| in | data     | 32 bytes of clear text data to be written to the slot |
| in | enc_key  | WriteKey to encrypt with for writing                  |
| in | enc_key⊷ | The KeyID of the WriteKey                             |
|    | _id      |                                                       |
| in | num_in   | 20 byte host nonce to inject into Nonce calculation   |

returns ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.131 atcab\_write\_pubkey()

```
ATCA_STATUS atcab_write_pubkey ( uint16_t slot, const uint8_t * public_key )
```

Uses the write command to write a public key to a slot in the proper format.

| in | slot       | Slot number to write. Only slots 8 to 15 are large enough to store a public key.             |
|----|------------|----------------------------------------------------------------------------------------------|
| in | public_key | Public key to write into the slot specified. X and Y integers in big-endian format. 64 bytes |
|    |            | for P256 curve.                                                                              |

### **Returns**

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.132 atcab\_write\_zone()

```
ATCA_STATUS atcab_write_zone (
    uint8_t zone,
    uint16_t slot,
    uint8_t block,
    uint8_t offset,
    const uint8_t * data,
    uint8_t len )
```

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

#### **Parameters**

| in | zone   | Device zone to write to (0=config, 1=OTP, 2=data).                                                   |
|----|--------|------------------------------------------------------------------------------------------------------|
| in | slot   | If writing to the data zone, it is the slot to write to, otherwise it should be 0.                   |
| in | block  | 32-byte block to write to.                                                                           |
| in | offset | 4-byte word within the specified block to write to. If performing a 32-byte write, this should be 0. |
| in | data   | Data to be written.                                                                                  |
| in | len    | Number of bytes to be written. Must be either 4 or 32.                                               |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.133 calib\_aes\_gcm\_aad\_update()

```
ATCA_STATUS calib_aes_gcm_aad_update (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * aad,
    uint32_t aad_size)
```

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

This can be called multiple times. <a href="atcab\_aes\_gcm\_init">atcab\_aes\_gcm\_init</a> rand() should be called before the first use of this function. When there is AAD to include, this should be called before <a href="atcab\_aes\_gcm\_encrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a>().

| in | device   | Device context pointer                    |
|----|----------|-------------------------------------------|
| in | ctx      | AES GCM context                           |
| in | aad      | Additional authenticated data to be added |
| in | aad_size | Size of aad in bytes                      |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.134 calib\_aes\_gcm\_decrypt\_finish()

```
ATCA_STATUS calib_aes_gcm_decrypt_finish (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * tag,
    size_t tag_size,
    bool * is_verified )
```

Complete a GCM decrypt operation verifying the authentication tag.

### **Parameters**

| in  | device      | Device context pointer                   |
|-----|-------------|------------------------------------------|
| in  | ctx         | AES GCM context structure.               |
| in  | tag         | Expected authentication tag.             |
| in  | tag_size    | Size of tag in bytes (12 to 16 bytes).   |
| out | is_verified | Returns whether or not the tag verified. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.135 calib\_aes\_gcm\_decrypt\_update()

Decrypt data using GCM mode and a key within the ATECC608 device. <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function.

| in  | device          | Device context pointer           |
|-----|-----------------|----------------------------------|
| in  | ctx             | AES GCM context structure.       |
| in  | ciphertext      | Ciphertext to be decrypted.      |
| in  | ciphertext_size | Size of ciphertext in bytes.     |
| out | plaintext       | Decrypted data is returned here. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.136 calib\_aes\_gcm\_encrypt\_finish()

Complete a GCM encrypt operation returning the authentication tag.

### **Parameters**

| in  | device   | Device context pointer               |
|-----|----------|--------------------------------------|
| in  | ctx      | AES GCM context structure.           |
| out | tag      | Authentication tag is returned here. |
| in  | tag_size | Tag size in bytes (12 to 16 bytes).  |

### **Returns**

ATCA\_SUCCESS on success, otherwise an error code.

### 18.1.4.137 calib\_aes\_gcm\_encrypt\_update()

```
ATCA_STATUS calib_aes_gcm_encrypt_update (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * plaintext,
    uint32_t plaintext_size,
    uint8_t * ciphertext )
```

Encrypt data using GCM mode and a key within the ATECC608 device. <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function.

| in  | device         | Device context pointer                |
|-----|----------------|---------------------------------------|
| in  | ctx            | AES GCM context structure.            |
| in  | plaintext      | Plaintext to be encrypted (16 bytes). |
| in  | plaintext_size | Size of plaintext in bytes.           |
| out | ciphertext     | Encrypted data is returned here.      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.138 calib\_aes\_gcm\_init()

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

### **Parameters**

| in | device    | Device context pointer                                                        |
|----|-----------|-------------------------------------------------------------------------------|
| in | ctx       | AES GCM context to be initialized.                                            |
| in | key_id    | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |
| in | key_block | Index of the 16-byte block to use within the key location for the actual key. |
| in | iv        | Initialization vector.                                                        |
| in | iv_size   | Size of IV in bytes. Standard is 12 bytes.                                    |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.4.139 calib\_aes\_gcm\_init\_rand()

```
ATCA_STATUS calib_aes_gcm_init_rand (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    size_t rand_size,
```

```
const uint8_t * free_field,
size_t free_field_size,
uint8_t * iv )
```

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

### **Parameters**

| in  | device          | Device context pointer                                                                           |
|-----|-----------------|--------------------------------------------------------------------------------------------------|
| in  | ctx             | AES CTR context to be initialized.                                                               |
| in  | key_id          | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.                     |
| in  | key_block       | Index of the 16-byte block to use within the key location for the actual key.                    |
| in  | rand_size       | Size of the random field in bytes. Minimum and recommended size is 12 bytes. Max is 32 bytes.    |
| in  | free_field      | Fixed data to include in the IV after the random field. Can be NULL if not used.                 |
| in  | free_field_size | Size of the free field in bytes.                                                                 |
| out | iv              | Initialization vector is returned here. Its size will be rand_size and free_field_size combined. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.1.5 Variable Documentation

# 18.1.5.1 \_gDevice

SHARED\_LIB\_IMPORT ATCADevice \_gDevice

### 18.1.5.2 atca\_basic\_aes\_gcm\_version

 $\verb"const char* atca\_basic\_aes\_gcm\_version"$ 

# 18.2 Configuration (cfg\_)

Logical device configurations describe the CryptoAuth device type and logical interface.

Logical device configurations describe the CryptoAuth device type and logical interface.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 121

# 18.3 ATCACommand (atca\_)

CryptoAuthLib command builder object, ATCACommand. Member functions for the ATCACommand object.

### **Data Structures**

struct atca\_command
 atca\_command is the C object backing ATCACommand.

# **Typedefs**

typedef struct atca command \* ATCACommand

### **Functions**

- ATCA\_STATUS initATCACommand (ATCADeviceType device\_type, ATCACommand ca\_cmd)
   Initializer for ATCACommand.
- ATCACommand newATCACommand (ATCADeviceType device\_type)
   constructor for ATCACommand
- void deleteATCACommand (ATCACommand \*ca\_cmd)

ATCACommand destructor.

# 18.3.1 Detailed Description

CryptoAuthLib command builder object, ATCACommand. Member functions for the ATCACommand object.

# 18.3.2 Typedef Documentation

#### 18.3.2.1 ATCACommand

```
typedef struct atca_command* ATCACommand
```

### 18.3.3 Function Documentation

### 18.3.3.1 deleteATCACommand()

ATCACommand destructor.

# 18.3 ATCACommand (atca\_)

### **Parameters**

| in | ca_cmd | instance of a command object |
|----|--------|------------------------------|
|----|--------|------------------------------|

# 18.3.3.2 initATCACommand()

```
ATCA_STATUS initATCACommand (

ATCADeviceType device_type,

ATCACommand ca_cmd )
```

### Initializer for ATCACommand.

### **Parameters**

| in | device_type | Specifies which set of commands and execution times should be associated with this command object. |
|----|-------------|----------------------------------------------------------------------------------------------------|
| in | ca_cmd      | Pre-allocated command structure to initialize.                                                     |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.3.3.3 newATCACommand()

```
ATCACommand newATCACommand ( {\tt ATCADeviceType} \ device\_type \ )
```

# constructor for ATCACommand

### **Parameters**

| in | device_type | Specifies which set of commands and execution times should be associated with this |
|----|-------------|------------------------------------------------------------------------------------|
|    |             | command object.                                                                    |

### Returns

Initialized object on success. NULL on failure.

# 18.4 ATCADevice (atca\_)

ATCADevice object - composite of command and interface objects.

#### **Data Structures**

- · struct atsha204a config
- struct atecc508a config
- struct \_atecc608\_config
- struct atca\_device

atca\_device is the C object backing ATCADevice. See the atca\_device.h file for details on the ATCADevice methods

### **Macros**

- #define ATCA\_PACKED
- #define ATCA\_AES\_ENABLE\_EN\_SHIFT (0)
- #define ATCA AES ENABLE EN MASK (0x01u << ATCA AES ENABLE EN SHIFT)</li>
- #define ATCA\_I2C\_ENABLE\_EN\_SHIFT (0)
- #define ATCA\_I2C\_ENABLE\_EN\_MASK (0x01u << ATCA\_I2C\_ENABLE\_EN\_SHIFT)</li>
- #define ATCA COUNTER MATCH EN SHIFT (0)
- #define ATCA\_COUNTER\_MATCH\_EN\_MASK (0x01u << ATCA\_COUNTER\_MATCH\_EN\_SHIFT)</li>
- #define ATCA COUNTER MATCH KEY SHIFT (4)
- #define ATCA\_COUNTER\_MATCH\_KEY\_MASK (0x0Fu << ATCA\_COUNTER\_MATCH\_KEY\_SHIFT)</li>
- #define ATCA\_COUNTER\_MATCH\_KEY(v) (ATCA\_COUNTER\_MATCH\_KEY\_MASK & (v << ATCA\_COUNTER\_MATCH\_KEY)</li>
- #define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT (0)
- #define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_MASK (0x01u << ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT)</li>
- #define ATCA\_CHIP\_MODE\_TTL\_EN\_SHIFT (1)
- #define ATCA CHIP MODE TTL EN MASK (0x01u << ATCA CHIP MODE TTL EN SHIFT)</li>
- #define ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT (2)
- #define ATCA\_CHIP\_MODE\_WDG\_LONG\_MASK (0x01u << ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT)</li>
- #define ATCA CHIP MODE CLK DIV SHIFT (3)
- #define ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK (0x1Fu << ATCA\_CHIP\_MODE\_CLK\_DIV\_SHIFT)</li>
- #define ATCA\_CHIP\_MODE\_CLK\_DIV(v) (ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK & (v << ATCA\_CHIP\_MODE\_CLK\_DIV\_S</li>
- #define ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT (0)
- #define ATCA\_SLOT\_CONFIG\_READKEY\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_READKEY(v) (ATCA\_SLOT\_CONFIG\_READKEY\_MASK & (v << ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT))</li>
- #define ATCA SLOT CONFIG NOMAC SHIFT (4)
- #define ATCA\_SLOT\_CONFIG\_NOMAC\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT)
- #define ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_SHIFT (5)
- #define ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_SHIFT)

#define ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIP</li>

- #define ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT (6)
- #define ATCA SLOT CONFIG IS SECRET SHIFT (7)
- #define ATCA\_SLOT\_CONFIG\_IS\_SECRET\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_IS\_SECRET\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT (8)
- #define ATCA SLOT CONFIG WRITE KEY MASK (0x0Fu << ATCA SLOT CONFIG WRITE KEY SHIFT)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_KEY(v) (ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_MASK & (v << ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT))</li>
- #define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT (12)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT)

- #define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG(v) (ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_MASK & (v << ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT))</li>
- #define ATCA\_SLOT\_CONFIG\_EXT\_SIG\_SHIFT (0)
- #define ATCA\_SLOT\_CONFIG\_EXT\_SIG\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_EXT\_SIG\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT (1)
- #define ATCA\_SLOT\_CONFIG\_INT\_SIG\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT)</li>
- #define ATCA SLOT CONFIG ECDH SHIFT (2)
- #define ATCA\_SLOT\_CONFIG\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_ECDH\_SHIFT)</li>
- #define ATCA SLOT CONFIG WRITE ECDH SHIFT (3)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_SHIFT)
- #define ATCA SLOT CONFIG GEN KEY SHIFT (8)
- #define ATCA\_SLOT\_CONFIG\_GEN\_KEY\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_GEN\_KEY\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT (9)
- #define ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT)</li>
- #define ATCA\_USE\_LOCK\_ENABLE\_SHIFT (0)
- #define ATCA\_USE\_LOCK\_ENABLE\_MASK (0x0Fu << ATCA\_USE\_LOCK\_ENABLE\_SHIFT)</li>
- #define ATCA USE LOCK KEY SHIFT (4)
- #define ATCA USE LOCK KEY MASK (0x0Fu << ATCA USE LOCK KEY SHIFT)</li>
- #define ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT (0)
- #define ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK (0x0Fu << ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT)
- #define ATCA\_VOL\_KEY\_PERM\_SLOT(v) (ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK & (v << ATCA\_VOL\_KEY\_PERM\_SLOT
- #define ATCA\_VOL\_KEY\_PERM\_EN\_SHIFT (7)
- #define ATCA VOL KEY PERM EN MASK (0x01u << ATCA VOL KEY PERM EN SHIFT)</li>
- #define ATCA SECURE BOOT MODE SHIFT (0)
- #define ATCA\_SECURE\_BOOT\_MODE\_MASK (0x03u << ATCA\_SECURE\_BOOT\_MODE\_SHIFT)</li>
- $\bullet \ \ \text{\#define ATCA\_SECURE\_BOOT\_MODE(v) (ATCA\_SECURE\_BOOT\_MODE\_MASK \& (v << ATCA\_SECURE\_BOOT\_MODE\_MASK) }$
- #define ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT (3)
- #define ATCA\_SECURE\_BOOT\_PERSIST\_EN\_MASK (0x01u << ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT)
- #define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT (4)
- #define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_MASK (0x01u << ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT)
- #define ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT (8)
- #define ATCA\_SECURE\_BOOT\_DIGEST\_MASK (0x0Fu << ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT)</li>
- #define ATCA SECURE BOOT DIGEST(v) (ATCA SECURE BOOT DIGEST MASK & (v << ATCA SECURE BOOT DIG
- #define ATCA SECURE BOOT PUB KEY SHIFT (12)
- #define ATCA SECURE BOOT PUB KEY MASK (0x0Fu << ATCA SECURE BOOT PUB KEY SHIFT)
- #define ATCA\_SECURE\_BOOT\_PUB\_KEY(v) (ATCA\_SECURE\_BOOT\_PUB\_KEY\_MASK & (v << ATCA\_SECURE\_BOOT\_PUB\_KEY\_SHIFT))</li>
- #define ATCA\_SLOT\_LOCKED(v) ((0x01 << v) & 0xFFFFu)</li>
- #define ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT (0)
- #define ATCA\_CHIP\_OPT\_POST\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT)</li>
- #define ATCA CHIP OPT IO PROT EN SHIFT (1)
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_SHIFT)</li>
- #define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT (2)
- #define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT)
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT (8)
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK (0x03u << ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT)
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT(v) (ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK & (v << ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK _OPT\_KDF\_PROT\_SHIFT (10)
- #define ATCA\_CHIP\_OPT\_KDF\_PROT\_MASK (0x03u << ATCA\_CHIP\_OPT\_KDF\_PROT\_SHIFT)</li>
- #define ATCA\_CHIP\_OPT\_KDF\_PROT(v) (ATCA\_CHIP\_OPT\_KDF\_PROT\_MASK & (v << ATCA\_CHIP\_OPT\_KDF\_PROT\_</li>
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT (12)
- #define ATCA CHIP OPT IO PROT KEY MASK (0x0Fu << ATCA CHIP OPT IO PROT KEY SHIFT)
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY(v) (ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_MASK & (v << ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT))</li>
- #define ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT (0)

- #define ATCA\_KEY\_CONFIG\_PRIVATE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT)
- #define ATCA KEY CONFIG PUB INFO SHIFT (1)
- #define ATCA\_KEY\_CONFIG\_PUB\_INFO\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PUB\_INFO\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_KEY\_TYPE\_SHIFT (2)
- #define ATCA KEY CONFIG KEY TYPE MASK (0x07u << ATCA KEY CONFIG KEY TYPE SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_KEY\_TYPE(v) (ATCA\_KEY\_CONFIG\_KEY\_TYPE\_MASK & (v << ATCA KEY CONFIG KEY TYPE SHIFT))</li>
- #define ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT (5)
- #define ATCA KEY CONFIG LOCKABLE MASK (0x01u << ATCA KEY CONFIG LOCKABLE SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT (6)
- #define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_MASK (0x01u << ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT)
- #define ATCA KEY CONFIG REQ AUTH SHIFT (7)
- #define ATCA KEY CONFIG REQ AUTH MASK (0x01u << ATCA KEY CONFIG REQ AUTH SHIFT)
- #define ATCA KEY CONFIG AUTH KEY SHIFT (8)
- #define ATCA KEY CONFIG AUTH KEY MASK (0x0Fu << ATCA KEY CONFIG AUTH KEY SHIFT)
- #define ATCA\_KEY\_CONFIG\_AUTH\_KEY(v) (ATCA\_KEY\_CONFIG\_AUTH\_KEY\_MASK & (v << ATCA KEY CONFIG AUTH KEY SHIFT))</li>
- #define ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT (12)
- #define ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT)</li>
- #define ATCA KEY CONFIG RFU SHIFT (13)
- #define ATCA KEY CONFIG RFU MASK (0x01u << ATCA KEY CONFIG RFU SHIFT)
- #define ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT (14)
- #define ATCA KEY CONFIG X509 ID MASK (0x03u << ATCA KEY CONFIG X509 ID SHIFT)
- #define ATCA KEY CONFIG X509 ID(v) (ATCA KEY CONFIG X509 ID MASK & (v << ATCA KEY CONFIG X509 ID

### **Typedefs**

- typedef struct atsha204a config atsha204a config t
- typedef struct \_atecc508a\_config atecc508a\_config\_t
- typedef struct \_atecc608\_config atecc608\_config\_t
- typedef struct atca device \* ATCADevice

#### **Enumerations**

enum ATCADeviceType {
 ATSHA204A = 0, ATECC108A = 1, ATECC508A = 2, ATECC608A = 3,
 ATECC608B = 3, ATECC608 = 3, ATSHA206A = 4, TA100 = 0x10,
 ATCA\_DEV\_UNKNOWN = 0x20 }

The supported Device type in Cryptoauthlib library.

### **Functions**

ATCADevice newATCADevice (ATCAlfaceCfg \*cfg)

constructor for a Microchip CryptoAuth device

• void deleteATCADevice (ATCADevice \*ca dev)

destructor for a device NULLs reference after object is freed

• ATCA\_STATUS initATCADevice (ATCAlfaceCfg \*cfg, ATCADevice ca\_dev)

Initializer for an Microchip CryptoAuth device.

ATCACommand atGetCommands (ATCADevice dev)

returns a reference to the ATCACommand object for the device

ATCAlface atGetIFace (ATCADevice dev)

returns a reference to the ATCAlface interface object for the device

ATCA STATUS releaseATCADevice (ATCADevice ca dev)

Release any resources associated with the device.

# 18.4.1 Detailed Description

ATCADevice object - composite of command and interface objects.

# 18.4.2 Macro Definition Documentation

### 18.4.2.1 ATCA\_AES\_ENABLE\_EN\_MASK

### 18.4.2.2 ATCA\_AES\_ENABLE\_EN\_SHIFT

#define ATCA\_AES\_ENABLE\_EN\_SHIFT (0)

# 18.4.2.3 ATCA\_CHIP\_MODE\_CLK\_DIV

# 18.4.2.4 ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK

#define ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK (0x1Fu << ATCA\_CHIP\_MODE\_CLK\_DIV\_SHIFT)

# 18.4.2.5 ATCA\_CHIP\_MODE\_CLK\_DIV\_SHIFT

#define ATCA\_CHIP\_MODE\_CLK\_DIV\_SHIFT (3)

# 18.4.2.6 ATCA\_CHIP\_MODE\_I2C\_EXTRA\_MASK

#define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_MASK (0x01u << ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT)

# 18.4.2.7 ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT

#define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT (0)

# 18.4.2.8 ATCA\_CHIP\_MODE\_TTL\_EN\_MASK

#define ATCA\_CHIP\_MODE\_TTL\_EN\_MASK (0x01u << ATCA\_CHIP\_MODE\_TTL\_EN\_SHIFT)

### 18.4.2.9 ATCA CHIP MODE TTL EN SHIFT

#define ATCA\_CHIP\_MODE\_TTL\_EN\_SHIFT (1)

### 18.4.2.10 ATCA\_CHIP\_MODE\_WDG\_LONG\_MASK

#define ATCA\_CHIP\_MODE\_WDG\_LONG\_MASK (0x01u << ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT)

# 18.4.2.11 ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT

#define ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT (2)

# 18.4.2.12 ATCA\_CHIP\_OPT\_ECDH\_PROT

#define ATCA\_CHIP\_OPT\_ECDH\_PROT(  $v \ ) \ (atca_chip_opt_ecdh_prot_mask \ \& \ (v << atca_chip_opt_ecdh_prot_shift))$ 

### 18.4.2.13 ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK

 $\texttt{\#define ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK (0x03u << ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT) }$ 

# 18.4.2.14 ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT

#define ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT (8)

# 18.4.2.15 ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_MASK

#define ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_SHIFT)

# 18.4.2.16 ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_SHIFT

#define ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_SHIFT (1)

### 18.4.2.17 ATCA\_CHIP\_OPT\_IO\_PROT\_KEY

#define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY(  $v \ ) \ ( \ \ \, \text{ATCA_CHIP_OPT_IO_PROT_KEY_MASK \& (v << ATCA_CHIP_OPT_IO_PROT_KEY_SHIFT) ) }$ 

# 18.4.2.18 ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_MASK

#define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_MASK (0x0Fu << ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT)

# 18.4.2.19 ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT

#define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT (12)

### 18.4.2.20 ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_MASK

 $\texttt{\#define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT) }$ 

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 129

# 18.4.2.21 ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT

#define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT (2)

# 18.4.2.22 ATCA\_CHIP\_OPT\_KDF\_PROT

```
#define ATCA_CHIP_OPT_KDF_PROT( v \ ) \ (\text{ATCA_CHIP_OPT_KDF_PROT_MASK \& (v << ATCA_CHIP_OPT_KDF_PROT_SHIFT)}) \\
```

# 18.4.2.23 ATCA\_CHIP\_OPT\_KDF\_PROT\_MASK

#define ATCA\_CHIP\_OPT\_KDF\_PROT\_MASK (0x03u << ATCA\_CHIP\_OPT\_KDF\_PROT\_SHIFT)

### 18.4.2.24 ATCA\_CHIP\_OPT\_KDF\_PROT\_SHIFT

#define ATCA\_CHIP\_OPT\_KDF\_PROT\_SHIFT (10)

# 18.4.2.25 ATCA\_CHIP\_OPT\_POST\_EN\_MASK

#define ATCA\_CHIP\_OPT\_POST\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT)

# 18.4.2.26 ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT

#define ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT (0)

### 18.4.2.27 ATCA\_COUNTER\_MATCH\_EN\_MASK

#define ATCA\_COUNTER\_MATCH\_EN\_MASK (0x01u << ATCA\_COUNTER\_MATCH\_EN\_SHIFT)</pre>

### 18.4.2.28 ATCA\_COUNTER\_MATCH\_EN\_SHIFT

#define ATCA\_COUNTER\_MATCH\_EN\_SHIFT (0)

### 18.4.2.29 ATCA\_COUNTER\_MATCH\_KEY

```
#define ATCA_COUNTER_MATCH_KEY( v \ ) \ (\text{ATCA}\_\text{COUNTER}\_\text{MATCH}\_\text{KEY}\_\text{MASK \& (} v << \text{ATCA}\_\text{COUNTER}\_\text{MATCH}\_\text{KEY}\_\text{SHIFT)})
```

### 18.4.2.30 ATCA COUNTER MATCH KEY MASK

#define ATCA\_COUNTER\_MATCH\_KEY\_MASK (0x0Fu << ATCA\_COUNTER\_MATCH\_KEY\_SHIFT)

### 18.4.2.31 ATCA COUNTER MATCH KEY SHIFT

#define ATCA\_COUNTER\_MATCH\_KEY\_SHIFT (4)

### 18.4.2.32 ATCA\_I2C\_ENABLE\_EN\_MASK

# 18.4.2.33 ATCA\_I2C\_ENABLE\_EN\_SHIFT

#define ATCA\_I2C\_ENABLE\_EN\_SHIFT (0)

# 18.4.2.34 ATCA\_KEY\_CONFIG\_AUTH\_KEY

# 18.4.2.35 ATCA\_KEY\_CONFIG\_AUTH\_KEY\_MASK

#define ATCA\_KEY\_CONFIG\_AUTH\_KEY\_MASK (0x0Fu << ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT)

# 18.4.2.36 ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT

#define ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT (8)

# 18.4.2.37 ATCA\_KEY\_CONFIG\_KEY\_TYPE

### 18.4.2.38 ATCA\_KEY\_CONFIG\_KEY\_TYPE\_MASK

### 18.4.2.39 ATCA KEY CONFIG KEY TYPE SHIFT

#define ATCA\_KEY\_CONFIG\_KEY\_TYPE\_SHIFT (2)

# 18.4.2.40 ATCA\_KEY\_CONFIG\_LOCKABLE\_MASK

#define ATCA\_KEY\_CONFIG\_LOCKABLE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT)

### 18.4.2.41 ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT

#define ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT (5)

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 132

# 18.4.2.42 ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_MASK

#define ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT)

### 18.4.2.43 ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT

#define ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT (12)

# 18.4.2.44 ATCA\_KEY\_CONFIG\_PRIVATE\_MASK

#define ATCA\_KEY\_CONFIG\_PRIVATE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT)

### 18.4.2.45 ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT

#define ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT (0)

### 18.4.2.46 ATCA\_KEY\_CONFIG\_PUB\_INFO\_MASK

### 18.4.2.47 ATCA KEY CONFIG PUB INFO SHIFT

#define ATCA\_KEY\_CONFIG\_PUB\_INFO\_SHIFT (1)

# 18.4.2.48 ATCA\_KEY\_CONFIG\_REQ\_AUTH\_MASK

#define ATCA\_KEY\_CONFIG\_REQ\_AUTH\_MASK (0x01u << ATCA\_KEY\_CONFIG\_REQ\_AUTH\_SHIFT)

### 18.4.2.49 ATCA\_KEY\_CONFIG\_REQ\_AUTH\_SHIFT

#define ATCA\_KEY\_CONFIG\_REQ\_AUTH\_SHIFT (7)

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 133

# 18.4.2.50 ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_MASK

#define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_MASK (0x01u << ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT)

# 18.4.2.51 ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT

#define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT (6)

### 18.4.2.52 ATCA\_KEY\_CONFIG\_RFU\_MASK

#define ATCA\_KEY\_CONFIG\_RFU\_MASK (0x01u << ATCA\_KEY\_CONFIG\_RFU\_SHIFT)</pre>

### 18.4.2.53 ATCA\_KEY\_CONFIG\_RFU\_SHIFT

#define ATCA\_KEY\_CONFIG\_RFU\_SHIFT (13)

# 18.4.2.54 ATCA\_KEY\_CONFIG\_X509\_ID

# 18.4.2.55 ATCA\_KEY\_CONFIG\_X509\_ID\_MASK

#define ATCA\_KEY\_CONFIG\_X509\_ID\_MASK (0x03u << ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT)

### 18.4.2.56 ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT

#define ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT (14)

### 18.4.2.57 ATCA\_PACKED

#define ATCA\_PACKED

### 18.4.2.58 ATCA\_SECURE\_BOOT\_DIGEST

### 18.4.2.59 ATCA SECURE BOOT DIGEST MASK

#define ATCA\_SECURE\_BOOT\_DIGEST\_MASK (0x0Fu << ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT)

### 18.4.2.60 ATCA SECURE BOOT DIGEST SHIFT

#define ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT (8)

### 18.4.2.61 ATCA\_SECURE\_BOOT\_MODE

```
#define ATCA_SECURE_BOOT_MODE( v \ ) \ (\text{ATCA_SECURE\_BOOT\_MODE\_MASK \& (v << ATCA_SECURE\_BOOT\_MODE\_SHIFT)}) \\
```

# 18.4.2.62 ATCA\_SECURE\_BOOT\_MODE\_MASK

#define ATCA\_SECURE\_BOOT\_MODE\_MASK (0x03u << ATCA\_SECURE\_BOOT\_MODE\_SHIFT)

# 18.4.2.63 ATCA\_SECURE\_BOOT\_MODE\_SHIFT

#define ATCA\_SECURE\_BOOT\_MODE\_SHIFT (0)

# 18.4.2.64 ATCA\_SECURE\_BOOT\_PERSIST\_EN\_MASK

#define ATCA\_SECURE\_BOOT\_PERSIST\_EN\_MASK (0x01u << ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT)

# 18.4.2.65 ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT

#define ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT (3)

# 18.4.2.66 ATCA\_SECURE\_BOOT\_PUB\_KEY

#define ATCA\_SECURE\_BOOT\_PUB\_KEY(  $v \ ) \ ( \ \ \, \text{ATCA_SECURE\_BOOT\_PUB\_KEY\_MASK \& } \ ( \ \ \, \text{v} \ << \ \ \, \text{ATCA\_SECURE\_BOOT\_PUB\_KEY\_SHIFT) } )$ 

### 18.4.2.67 ATCA\_SECURE\_BOOT\_PUB\_KEY\_MASK

### 18.4.2.68 ATCA SECURE BOOT PUB KEY SHIFT

#define ATCA\_SECURE\_BOOT\_PUB\_KEY\_SHIFT (12)

### 18.4.2.69 ATCA\_SECURE\_BOOT\_RAND\_NONCE\_MASK

#define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_MASK (0x01u << ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT)

### 18.4.2.70 ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT

#define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT (4)

# 18.4.2.71 ATCA\_SLOT\_CONFIG\_ECDH\_MASK

#define ATCA\_SLOT\_CONFIG\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_ECDH\_SHIFT)

### 18.4.2.72 ATCA\_SLOT\_CONFIG\_ECDH\_SHIFT

#define ATCA\_SLOT\_CONFIG\_ECDH\_SHIFT (2)

# 18.4.2.73 ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_MASK

 $\# define \ ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_MASK \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT)$ 

### 18.4.2.74 ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT

#define ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT (6)

### 18.4.2.75 ATCA\_SLOT\_CONFIG\_EXT\_SIG\_MASK

### 18.4.2.76 ATCA SLOT CONFIG EXT SIG SHIFT

#define ATCA\_SLOT\_CONFIG\_EXT\_SIG\_SHIFT (0)

# 18.4.2.77 ATCA\_SLOT\_CONFIG\_GEN\_KEY\_MASK

#define ATCA\_SLOT\_CONFIG\_GEN\_KEY\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_GEN\_KEY\_SHIFT)

### 18.4.2.78 ATCA\_SLOT\_CONFIG\_GEN\_KEY\_SHIFT

#define ATCA\_SLOT\_CONFIG\_GEN\_KEY\_SHIFT (8)

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 137

# 18.4.2.79 ATCA\_SLOT\_CONFIG\_INT\_SIG\_MASK

#define ATCA\_SLOT\_CONFIG\_INT\_SIG\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT)

### 18.4.2.80 ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT

#define ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT (1)

# 18.4.2.81 ATCA\_SLOT\_CONFIG\_IS\_SECRET\_MASK

#define ATCA\_SLOT\_CONFIG\_IS\_SECRET\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_IS\_SECRET\_SHIFT)

### 18.4.2.82 ATCA\_SLOT\_CONFIG\_IS\_SECRET\_SHIFT

#define ATCA\_SLOT\_CONFIG\_IS\_SECRET\_SHIFT (7)

### 18.4.2.83 ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_MASK

### 18.4.2.84 ATCA SLOT CONFIG LIMITED USE SHIFT

#define ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_SHIFT (5)

# 18.4.2.85 ATCA\_SLOT\_CONFIG\_NOMAC\_MASK

#define ATCA\_SLOT\_CONFIG\_NOMAC\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT)

### 18.4.2.86 ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT

#define ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT (4)

# 18.4.2.87 ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_MASK

#define ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT)

### 18.4.2.88 ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT

#define ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT (9)

### 18.4.2.89 ATCA SLOT CONFIG READKEY

### 18.4.2.90 ATCA SLOT CONFIG READKEY MASK

#define ATCA\_SLOT\_CONFIG\_READKEY\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT)

### 18.4.2.91 ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT

#define ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT (0)

# 18.4.2.92 ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG

# 18.4.2.93 ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_MASK

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 139

# 18.4.2.94 ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT

#define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT (12)

### 18.4.2.95 ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_MASK

#define ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_SHIFT)

### 18.4.2.96 ATCA SLOT CONFIG WRITE ECDH SHIFT

#define ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_SHIFT (3)

### 18.4.2.97 ATCA SLOT CONFIG WRITE KEY

### 18.4.2.98 ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_MASK

#define ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT)

# 18.4.2.99 ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT

#define ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT (8)

# 18.4.2.100 ATCA\_SLOT\_LOCKED

```
#define ATCA_SLOT_LOCKED( v \ ) \ ((0 \text{x01} << \text{v}) \text{ & 0xFFFFu})
```

# 18.4.2.101 ATCA\_USE\_LOCK\_ENABLE\_MASK

#define ATCA\_USE\_LOCK\_ENABLE\_MASK (0x0Fu << ATCA\_USE\_LOCK\_ENABLE\_SHIFT)

# 18.4.2.102 ATCA\_USE\_LOCK\_ENABLE\_SHIFT

#define ATCA\_USE\_LOCK\_ENABLE\_SHIFT (0)

### 18.4.2.103 ATCA USE LOCK KEY MASK

#define ATCA\_USE\_LOCK\_KEY\_MASK (0x0Fu << ATCA\_USE\_LOCK\_KEY\_SHIFT)</pre>

### 18.4.2.104 ATCA\_USE\_LOCK\_KEY\_SHIFT

#define ATCA\_USE\_LOCK\_KEY\_SHIFT (4)

# 18.4.2.105 ATCA\_VOL\_KEY\_PERM\_EN\_MASK

# 18.4.2.106 ATCA\_VOL\_KEY\_PERM\_EN\_SHIFT

#define ATCA\_VOL\_KEY\_PERM\_EN\_SHIFT (7)

# 18.4.2.107 ATCA\_VOL\_KEY\_PERM\_SLOT

#define ATCA\_VOL\_KEY\_PERM\_SLOT(  $v \ ) \ (\text{ATCA_VOL_KEY_PERM_SLOT_MASK \& (v << ATCA_VOL_KEY_PERM_SLOT_SHIFT)}) \\$ 

### 18.4.2.108 ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK

 $\texttt{\#define ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK (0x0Fu << ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT)}$ 

# 18.4.2.109 ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT

#define ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT (0)

# 18.4.3 Typedef Documentation

### 18.4.3.1 ATCADevice

typedef struct atca\_device\* ATCADevice

# 18.4.3.2 atecc508a\_config\_t

typedef struct \_atecc508a\_config atecc508a\_config\_t

### 18.4.3.3 atecc608\_config\_t

typedef struct \_atecc608\_config atecc608\_config\_t

### 18.4.3.4 atsha204a\_config\_t

typedef struct \_atsha204a\_config atsha204a\_config\_t

# 18.4.4 Enumeration Type Documentation

### 18.4.4.1 ATCADeviceType

enum ATCADeviceType

The supported Device type in Cryptoauthlib library.

### Enumerator

| ATSHA204A        |  |
|------------------|--|
| ATECC108A        |  |
| ATECC508A        |  |
| ATECC608A        |  |
| ATECC608B        |  |
| ATECC608         |  |
| ATSHA206A        |  |
| TA100            |  |
| ATCA_DEV_UNKNOWN |  |

# 18.4.5 Function Documentation

# 18.4.5.1 atGetCommands()

```
ATCACommand atGetCommands (  \begin{tabular}{ll} ATCADevice $dev$ ) \end{tabular} \label{eq:atcacommand}
```

returns a reference to the ATCACommand object for the device

### **Parameters**

| in | dev | reference to a device |
|----|-----|-----------------------|

### Returns

reference to the ATCACommand object for the device

# 18.4.5.2 atGetIFace()

```
ATCAIface atGetIFace ( {\tt ATCADevice}\ dev\ )
```

returns a reference to the ATCAlface interface object for the device

#### **Parameters**

| in | dev | reference to a device |
|----|-----|-----------------------|

reference to the ATCAlface object for the device

# 18.4.5.3 deleteATCADevice()

```
void deleteATCADevice ( {\tt ATCADevice} \ * \ {\it ca\_dev} \ )
```

destructor for a device NULLs reference after object is freed

### **Parameters**

| in | ca_dev | pointer to a reference to a device |
|----|--------|------------------------------------|
|----|--------|------------------------------------|

### 18.4.5.4 initATCADevice()

```
ATCA_STATUS initATCADevice (  \mbox{ATCAIfaceCfg} * cfg, \\ \mbox{ATCADevice} ca\_dev \mbox{)}
```

Initializer for an Microchip CryptoAuth device.

### **Parameters**

| in     | cfg    | pointer to an interface configuration object                                      |  |
|--------|--------|-----------------------------------------------------------------------------------|--|
| in,out | ca_dev | As input, pre-allocated structure to be initialized. mCommands and mlface members |  |
|        |        | should point to existing structures to be initialized.                            |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.4.5.5 newATCADevice()

```
ATCADevice newATCADevice ( {\tt ATCAIfaceCfg} \ * \ cfg \ )
```

constructor for a Microchip CryptoAuth device

### **Parameters**

| in | cfg | Interface configuration object |
|----|-----|--------------------------------|
|----|-----|--------------------------------|

Reference to a new ATCADevice on success. NULL on failure.

# 18.4.5.6 releaseATCADevice()

```
ATCA_STATUS releaseATCADevice ( {\tt ATCADevice} \ \ {\tt ca\_dev} \ )
```

Release any resources associated with the device.

### **Parameters**

| in ca_dev | Device to release |
|-----------|-------------------|
|-----------|-------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5 ATCAlface (atca\_)

Abstract interface to all CryptoAuth device types. This interface connects to the HAL implementation and abstracts the physical details of the device communication from all the upper layers of CryptoAuthLib.

### **Data Structures**

- struct ATCAlfaceCfg
- · struct atca iface

atca iface is the C object backing ATCAlface. See the atca iface.h file for details on the ATCAlface methods

# **Typedefs**

typedef struct atca iface \* ATCAlface

### **Enumerations**

enum ATCAlfaceType {
 ATCA\_I2C\_IFACE, ATCA\_SWI\_IFACE, ATCA\_UART\_IFACE, ATCA\_SPI\_IFACE,
 ATCA\_HID\_IFACE, ATCA\_CUSTOM\_IFACE, ATCA\_UNKNOWN\_IFACE }

enum ATCAKitType {
 ATCA\_KIT\_AUTO\_IFACE, ATCA\_KIT\_I2C\_IFACE, ATCA\_KIT\_SWI\_IFACE, ATCA\_KIT\_SPI\_IFACE,
 ATCA\_KIT\_UNKNOWN\_IFACE }

## **Functions**

ATCA STATUS initATCAlface (ATCAlfaceCfg \*cfg, ATCAlface ca iface)

Initializer for ATCAlface objects.

• ATCAlface newATCAlface (ATCAlfaceCfg \*cfg)

Constructor for ATCAlface objects.

• ATCA STATUS atinit (ATCAlface ca iface)

Performs the HAL initialization by calling intermediate HAL wrapper function. If using the basic API, the atcab\_init() function should be called instead.

ATCA\_STATUS atsend (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

Sends the data to the device by calling intermediate HAL wrapper function.

• ATCA\_STATUS atreceive (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

Receives data from the device by calling intermediate HAL wrapper function.

ATCA\_STATUS atwake (ATCAlface ca\_iface)

Wakes up the device by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_wakeup()">atcab\_wakeup()</a> function should be used instead.

ATCA STATUS atidle (ATCAlface ca iface)

Puts the device into idle state by calling intermediate HAL wrapper function. If using the basic API, the atcab\_idle() function should be used instead.

• ATCA STATUS atsleep (ATCAlface ca iface)

Puts the device into sleep state by calling intermediate HAL wrapper function. If using the basic API, the atcab\_sleep() function should be used instead.

ATCAlfaceCfg \* atgetifacecfg (ATCAlface ca\_iface)

Returns the logical interface configuration for the device.

void \* atgetifacehaldat (ATCAlface ca iface)

Returns the HAL data pointer for the device.

• ATCA STATUS releaseATCAlface (ATCAlface ca iface)

Instruct the HAL driver to release any resources associated with this interface.

• void deleteATCAlface (ATCAlface \*ca iface)

Instruct the HAL driver to release any resources associated with this interface, then delete the object.

· ATCA STATUS atpostinit (ATCAlface ca iface)

# 18.5.1 Detailed Description

Abstract interface to all CryptoAuth device types. This interface connects to the HAL implementation and abstracts the physical details of the device communication from all the upper layers of CryptoAuthLib.

# 18.5.2 Typedef Documentation

## 18.5.2.1 ATCAlface

typedef struct atca\_iface\* ATCAIface

# 18.5.3 Enumeration Type Documentation

# 18.5.3.1 ATCAlfaceType

enum ATCAIfaceType

### Enumerator

| ATCA_I2C_IFACE     |  |
|--------------------|--|
| ATCA_SWI_IFACE     |  |
| ATCA_UART_IFACE    |  |
| ATCA_SPI_IFACE     |  |
| ATCA_HID_IFACE     |  |
| ATCA_CUSTOM_IFACE  |  |
| ATCA_UNKNOWN_IFACE |  |

# 18.5.3.2 ATCAKitType

enum ATCAKitType

## Enumerator

| ATCA_KIT_AUTO_IFACE    |  |
|------------------------|--|
| ATCA_KIT_I2C_IFACE     |  |
| ATCA_KIT_SWI_IFACE     |  |
| ATCA_KIT_SPI_IFACE     |  |
| ATCA_KIT_UNKNOWN_IFACE |  |

# 18.5.4 Function Documentation

# 18.5.4.1 atgetifacecfg()

Returns the logical interface configuration for the device.

### **Parameters**

| in | ca iface | Device interface. |
|----|----------|-------------------|
|    |          |                   |

### Returns

Logical interface configuration.

# 18.5.4.2 atgetifacehaldat()

Returns the HAL data pointer for the device.

## **Parameters**

| in | ca_iface | Device interface. |
|----|----------|-------------------|

### Returns

HAL data pointer.

# 18.5.4.3 atidle()

```
ATCA_STATUS atidle (
ATCAIface ca_iface )
```

Puts the device into idle state by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_idle">atcab\_idle</a>() function should be used instead.

# 18.5 ATCAlface (atca\_)

### **Parameters**

| in ca_iface Device to interact with. |
|--------------------------------------|
|--------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.4 atinit()

```
ATCA_STATUS atinit (
ATCAIface ca_iface)
```

Performs the HAL initialization by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_init()">atcab\_init()</a> function should be called instead.

### **Parameters**

| in ca_iface | Device to interact with. |
|-------------|--------------------------|
|-------------|--------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.5 atpostinit()

```
ATCA_STATUS atpostinit ( {\tt ATCAIface}\ \ ca\_iface\ )
```

## 18.5.4.6 atreceive()

```
ATCA_STATUS atreceive (

ATCAIface ca_iface,

uint8_t word_address,

uint8_t * rxdata,

uint16_t * rxlength )
```

Receives data from the device by calling intermediate HAL wrapper function.

| in                              | ca_iface     | Device to interact with.                                                          |    |
|---------------------------------|--------------|-----------------------------------------------------------------------------------|----|
| in                              | word_address | device transaction type                                                           |    |
| OUT<br>© 2020 <b>Microchi</b> r | rxdata       | Data received will be returned here.                                              | 49 |
| in, out                         | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |    |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.7 atsend()

Sends the data to the device by calling intermediate HAL wrapper function.

### **Parameters**

| in | ca_iface     | Device to interact with.                         |
|----|--------------|--------------------------------------------------|
| in | word_address | device transaction type                          |
| in | txdata       | Data to be transmitted to the device.            |
| in | txlength     | Number of bytes to be transmitted to the device. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.8 atsleep()

```
ATCA_STATUS atsleep ( {\tt ATCAIface}\ ca\_iface\ )
```

Puts the device into sleep state by calling intermediate HAL wrapper function. If using the basic API, the atcab\_sleep() function should be used instead.

### **Parameters**

```
in ca_iface Device to interact with.
```

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.5.4.9 atwake()

```
ATCA_STATUS atwake ( {\tt ATCAIface}\ ca\_iface\ )
```

Wakes up the device by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_wakeup()">atcab\_wakeup()</a> function should be used instead.

### **Parameters**

| in | ca iface | Device to interact with. |
|----|----------|--------------------------|
|    |          |                          |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.10 deleteATCAlface()

Instruct the HAL driver to release any resources associated with this interface, then delete the object.

### **Parameters**

| in | ca iface | Device interface. |
|----|----------|-------------------|

# 18.5.4.11 initATCAlface()

```
ATCA_STATUS initATCAIface ( {\tt ATCAIfaceCfg} * cfg, \\ {\tt ATCAIface} \; ca\_iface \; )
```

Initializer for ATCAlface objects.

## **Parameters**

| in | cfg      | Logical configuration for the interface |
|----|----------|-----------------------------------------|
| in | ca_iface | Interface structure to initialize.      |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.5.4.12 newATCAlface()

```
ATCAIface newATCAIface ( {\tt ATCAIfaceCfg} \ * \ cfg \ )
```

Constructor for ATCAlface objects.

## **Parameters**

| in | cfg | Logical configuration for the interface |
|----|-----|-----------------------------------------|
|----|-----|-----------------------------------------|

### Returns

New interface instance on success. NULL on failure.

# 18.5.4.13 releaseATCAlface()

```
ATCA_STATUS releaseATCAIface ( {\tt ATCAIface}\ ca\_iface\ )
```

Instruct the HAL driver to release any resources associated with this interface.

## **Parameters**

| in ca_iface | Device interface. |
|-------------|-------------------|
|-------------|-------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.6 Certificate manipulation methods (atcacert\_)

These methods provide convenient ways to perform certification I/O with CryptoAuth chips and perform certificate manipulation in memory.

### **Data Structures**

- · struct atcacert tm utc s
- · struct atcacert\_device\_loc\_s
- · struct atcacert cert loc s
- · struct atcacert\_cert\_element\_s
- · struct atcacert def s
- · struct atcacert\_build\_state\_s

### **Macros**

- #define FALSE (0)
- #define TRUE (1)
- #define ATCACERT\_E\_SUCCESS 0

Operation completed successfully.

#define ATCACERT E ERROR 1

General error.

• #define ATCACERT\_E\_BAD\_PARAMS 2

Invalid/bad parameter passed to function.

• #define ATCACERT E BUFFER TOO SMALL 3

Supplied buffer for output is too small to hold the result.

• #define ATCACERT\_E\_DECODING\_ERROR 4

Data being decoded/parsed has an invalid format.

• #define ATCACERT E INVALID DATE 5

Date is invalid.

• #define ATCACERT\_E\_UNIMPLEMENTED 6

Function is unimplemented for the current configuration.

• #define ATCACERT\_E\_UNEXPECTED\_ELEM\_SIZE 7

A certificate element size was not what was expected.

#define ATCACERT\_E\_ELEM\_MISSING 8

The certificate element isn't defined for the certificate definition.

• #define ATCACERT\_E\_ELEM\_OUT\_OF\_BOUNDS 9

Certificate element is out of bounds for the given certificate.

• #define ATCACERT\_E\_BAD\_CERT 10

Certificate structure is bad in some way.

- #define ATCACERT\_E\_WRONG\_CERT\_DEF 11
- #define ATCACERT\_E\_VERIFY\_FAILED 12

Certificate or challenge/response verification failed.

• #define ATCACERT E INVALID TRANSFORM 13

Invalid transform passed to function.

- #define DATEFMT\_ISO8601\_SEP\_SIZE (20)
- #define DATEFMT RFC5280 UTC SIZE (13)
- #define DATEFMT POSIX UINT32 BE SIZE (4)
- #define DATEFMT POSIX UINT32 LE SIZE (4)
- #define DATEFMT\_RFC5280\_GEN\_SIZE (15)
- #define DATEFMT MAX SIZE DATEFMT ISO8601 SEP SIZE
- #define ATCACERT\_DATE\_FORMAT\_SIZES\_COUNT 5
- #define ATCA PACKED

# **Typedefs**

- typedef struct atcacert\_tm\_utc\_s atcacert\_tm\_utc\_t
- typedef enum atcacert\_date\_format\_e atcacert\_date\_format\_t
- typedef enum atcacert\_cert\_type\_e atcacert\_cert\_type\_t
- typedef enum atcacert cert sn src e atcacert cert sn src t
- typedef enum atcacert device zone e atcacert device zone t
- typedef enum atcacert transform e atcacert transform t

How to transform the data from the device to the certificate.

- · typedef enum atcacert std cert element e atcacert std cert element t
- typedef struct atcacert\_device\_loc\_s atcacert\_device\_loc\_t
- typedef struct atcacert\_cert\_loc\_s atcacert\_cert\_loc\_t
- typedef struct atcacert\_cert\_element\_s atcacert\_cert\_element\_t
- · typedef struct atcacert\_def\_s atcacert\_def\_t
- · typedef struct atcacert build state s atcacert build state t

### **Enumerations**

```
• enum atcacert date format e {
 DATEFMT_ISO8601_SEP, DATEFMT_RFC5280_UTC, DATEFMT_POSIX_UINT32_BE, DATEFMT_POSIX_UINT32_LE,
 DATEFMT RFC5280 GEN }
enum atcacert_cert_type_e { CERTTYPE_X509, CERTTYPE_CUSTOM }

    enum atcacert cert sn src e {

 SNSRC_STORED = 0x0, SNSRC_STORED_DYNAMIC = 0x7, SNSRC_DEVICE_SN = 0x8, SNSRC_SIGNER_ID
 SNSRC_PUB_KEY_HASH = 0xA, SNSRC_DEVICE_SN_HASH = 0xB, SNSRC_PUB_KEY_HASH_POS =
 0xC, SNSRC DEVICE SN HASH POS = 0xD,
 SNSRC_PUB_KEY_HASH_RAW = 0xE, SNSRC_DEVICE_SN_HASH_RAW = 0xF }

    enum atcacert device zone e { DEVZONE CONFIG = 0x00, DEVZONE OTP = 0x01, DEVZONE DATA =

 0x02, DEVZONE NONE = 0x07 }

    enum atcacert transform e {

 TF_NONE, TF_REVERSE, TF_BIN2HEX_UC, TF_BIN2HEX_LC,
 TF_HEX2BIN_UC, TF_HEX2BIN_LC, TF_BIN2HEX_SPACE_UC, TF_BIN2HEX_SPACE_LC,
 TF_HEX2BIN_SPACE_UC, TF_HEX2BIN_SPACE_LC }
    How to transform the data from the device to the certificate.
• enum atcacert std cert element e {
 STDCERT PUBLIC KEY, STDCERT SIGNATURE, STDCERT ISSUE DATE, STDCERT EXPIRE DATE,
 STDCERT SIGNER ID, STDCERT CERT SN, STDCERT AUTH KEY ID, STDCERT SUBJ KEY ID,
 STDCERT_NUM_ELEMENTS }
```

## **Functions**

- int atcacert\_read\_device\_loc (const atcacert\_device\_loc\_t \*device\_loc, uint8\_t \*data)
  - Read the data from a device location.
- int atcacert\_read\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t ca\_public\_key[64], uint8\_t \*cert, size\_t \*cert size)

Reads the certificate specified by the certificate definition from the ATECC508A device.

- int atcacert\_write\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size)
  - Take a full certificate and write it to the ATECC508A device according to the certificate definition.
- int atcacert\_create\_csr (const atcacert\_def\_t \*csr\_def, uint8\_t \*csr, size\_t \*csr\_size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

• int atcacert\_create\_csr\_pem (const atcacert\_def\_t \*csr\_def, char \*csr, size\_t \*csr\_size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

• int atcacert\_get\_response (uint8\_t device\_private\_key\_slot, const uint8\_t challenge[32], uint8\_← t response[64])

Calculates the response to a challenge sent from the host.

int atcacert\_read\_subj\_key\_id (const atcacert\_def\_t \*cert\_def, uint8\_t subj\_key\_id[20])

Reads the subject key ID based on a certificate definition.

• int atcacert read cert size (const atcacert def t \*cert def, size t \*cert size)

Return the actual certificate size in bytes for a given cert def. Certificate can be variable size, so this gives the absolute buffer size when reading the certificates.

int atcacert\_date\_enc (atcacert\_date\_format\_t format, const atcacert\_tm\_utc\_t \*timestamp, uint8\_←
 t \*formatted\_date, size\_t \*formatted\_date\_size)

Format a timestamp according to the format type.

int atcacert\_date\_dec (atcacert\_date\_format\_t format, const uint8\_t \*formatted\_date, size\_t formatted\_
 date\_size, atcacert\_tm\_utc\_t \*timestamp)

Parse a formatted timestamp according to the specified format.

int atcacert\_date\_enc\_compcert (const atcacert\_tm\_utc\_t \*issue\_date, uint8\_t expire\_years, uint8\_t enc\_
dates[3])

Encode the issue and expire dates in the format used by the compressed certificate.

• int atcacert\_date\_dec\_compcert (const uint8\_t enc\_dates[3], atcacert\_date\_format\_t expire\_date\_format, atcacert\_tm\_utc\_t \*issue\_date, atcacert\_tm\_utc\_t \*expire\_date)

Decode the issue and expire dates from the format used by the compressed certificate.

• int atcacert date get max date (atcacert date format t format, atcacert tm utc t \*timestamp)

Return the maximum date available for the given format.

- int atcacert\_date\_enc\_iso8601\_sep (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(20)])
- int atcacert\_date\_dec\_iso8601\_sep (const uint8\_t formatted\_date[(20)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_utc (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(13)])
- int atcacert\_date\_dec\_rfc5280\_utc (const uint8\_t formatted\_date[(13)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_gen (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(15)])
- int atcacert\_date\_dec\_rfc5280\_gen (const uint8\_t formatted\_date[(15)], atcacert\_tm\_utc\_t \*timestamp)
   int atcacert\_date\_enc\_posix\_uint32\_be (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(4)])
- int atcacert date dec posix uint32 be (const uint8 t formatted date[(4)], atcacert tm utc t \*timestamp)
- int atcacert\_date\_enc\_posix\_uint32\_le (const\_atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(4)])
- int atcacert\_date\_dec\_posix\_uint32\_le (const uint8\_t formatted\_date[(4)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_get\_device\_locs (const atcacert\_def\_t \*cert\_def, atcacert\_device\_loc\_t \*device\_locs, size\_ t \*device\_locs\_count, size\_t device\_locs\_max\_count, size\_t block\_size)

Add all the device locations required to rebuild the specified certificate (cert\_def) to a device locations list.

• int atcacert\_cert\_build\_start (atcacert\_build\_state\_t \*build\_state, const atcacert\_def\_t \*cert\_def, uint8\_← t \*cert, size t \*cert size, const uint8 t ca public key[64])

Starts the certificate rebuilding process.

int atcacert\_cert\_build\_process (atcacert\_build\_state\_t \*build\_state, const atcacert\_device\_loc\_t \*device ← loc, const uint8 t \*device data)

Process information read from the ATECC device. If it contains information for the certificate, it will be incorporated into the certificate.

int atcacert\_cert\_build\_finish (atcacert\_build\_state\_t \*build\_state)

Completes any final certificate processing required after all data from the device has been incorporated.

• int atcacert\_get\_device\_data (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const atcacert device loc t \*device loc, uint8 t \*device data)

Gets the dynamic data that would be saved to the specified device location. This function is primarily used to break down a full certificate into the dynamic components to be saved to a device.

• int atcacert\_set\_subj\_public\_key (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t subj\_public\_key[64])

Sets the subject public key and subject key ID in a certificate.

• int atcacert\_get\_subj\_public\_key (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t subj\_public\_key[64])

Gets the subject public key from a certificate.

int atcacert\_get\_subj\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t subj key id[20])

Gets the subject key ID from a certificate.

int atcacert\_set\_signature (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_
 cert size, const uint8 t signature[64])

Sets the signature in a certificate. This may alter the size of the X.509 certificates.

int atcacert\_get\_signature (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t signature[64])

Gets the signature from a certificate.

• int atcacert\_set\_issue\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert tm utc t \*timestamp)

Sets the issue date (notBefore) in a certificate. Will be formatted according to the date format specified in the certificate definition.

• int atcacert\_get\_issue\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert\_tm\_utc\_t \*timestamp)

Gets the issue date from a certificate. Will be parsed according to the date format specified in the certificate definition.

 int atcacert\_set\_expire\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert\_tm\_utc\_t \*timestamp)

Sets the expire date (notAfter) in a certificate. Will be formatted according to the date format specified in the certificate definition.

int atcacert\_get\_expire\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert\_tm\_utc\_t \*timestamp)

Gets the expire date from a certificate. Will be parsed according to the date format specified in the certificate definition.

int atcacert\_set\_signer\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_
 t signer\_id[2])

Sets the signer ID in a certificate. Will be formatted as 4 upper-case hex digits.

 int atcacert\_get\_signer\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_← t signer\_id[2])

Gets the signer ID from a certificate. Will be parsed as 4 upper-case hex digits.

int atcacert\_set\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_cert
 \_size, const uint8\_t \*cert\_sn, size\_t cert\_sn\_size)

Sets the certificate serial number in a certificate.

• int atcacert\_gen\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_← t device\_sn[9])

Sets the certificate serial number by generating it from other information in the certificate using the scheme specified by sn\_source in cert\_def. See the.

int atcacert\_get\_cert\_sn (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t \*cert cert\_size, uint8\_t \*cert cert\_size, uint8\_t \*cert cert\_size, uint8\_t \*cert cert\_size, uint8\_t \*cert\_size

Gets the certificate serial number from a certificate.

int atcacert\_set\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t auth\_public\_key[64])

Sets the authority key ID in a certificate. Note that this takes the actual public key creates a key ID from it.

• int atcacert\_set\_auth\_key\_id\_raw (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*auth\_key\_id)

Sets the authority key ID in a certificate.

• int atcacert\_get\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t auth\_key\_id[20])

Gets the authority key ID from a certificate.

int atcacert\_set\_comp\_cert (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_
 cert\_size, const uint8\_t comp\_cert[72])

Sets the signature, issue date, expire date, and signer ID found in the compressed certificate. This also checks fields common between the cert def and the compressed certificate to make sure they match.

 int atcacert\_get\_comp\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_← t comp\_cert[72])

Generate the compressed certificate for the given certificate.

int atcacert\_get\_tbs (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*\*tbs, size\_t \*tbs\_size)

Get a pointer to the TBS data in a certificate.

int atcacert\_get\_tbs\_digest (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t tbs\_digest[32])

Get the SHA256 digest of certificate's TBS data.

• int atcacert\_set\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*data, size\_t data\_size)

Sets an element in a certificate. The data size must match the size in cert loc.

• int atcacert\_get\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, const uint8\_t \*cert\_size\_t cert\_size, uint8\_t \*data, size\_t data\_size)

Gets an element from a certificate.

• int atcacert get key id (const uint8 t public key[64], uint8 t key id[20])

Calculates the key ID for a given public ECC P256 key.

int atcacert\_merge\_device\_loc (atcacert\_device\_loc\_t \*device\_locs, size\_t \*device\_locs\_count, size\_
 t device locs max count, const atcacert device loc t \*device loc, size t block size)

Merge a new device location into a list of device locations. If the new location overlaps with an existing location, the existing one will be modified to encompass both. Otherwise the new location is appended to the end of the list.

• int atcacert\_is\_device\_loc\_overlap (const atcacert\_device\_loc\_t \*device\_loc1, const atcacert\_device\_loc\_t \*device\_loc2)

Determines if the two device locations overlap.

• void atcacert\_public\_key\_add\_padding (const uint8\_t raw\_key[64], uint8\_t padded\_key[72])

Takes a raw P256 ECC public key and converts it to the padded version used by ATECC devices. Input and output buffers can point to the same location to do an in-place transform.

void atcacert\_public\_key\_remove\_padding (const uint8\_t padded\_key[72], uint8\_t raw\_key[64])

Takes a padded public key used by ATECC devices and converts it to a raw P256 ECC public key. Input and output buffers can point to the same location to do an in-place transform.

• int atcacert\_transform\_data (atcacert\_transform\_t transform, const uint8\_t \*data, size\_t data\_size, uint8\_t \*destination, size\_t \*destination\_size)

Apply the specified transform to the specified data.

int atcacert\_max\_cert\_size (const atcacert\_def\_t \*cert\_def, size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a given cert def. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificates.

• int atcacert\_der\_enc\_length (uint32\_t length, uint8\_t \*der\_length, size\_t \*der\_length\_size)

Encode a length in DER format.

• int atcacert\_der\_dec\_length (const uint8\_t \*der\_length, size\_t \*der\_length\_size, uint32\_t \*length)

Decode a DER format length.

- int atcacert\_der\_adjust\_length (uint8\_t \*der\_length, size\_t \*der\_length\_size, int delta\_length, uint32\_← t \*new length)
- int atcacert\_der\_enc\_integer (const uint8\_t \*int\_data, size\_t int\_data\_size, uint8\_t is\_unsigned, uint8\_← t \*der\_int, size\_t \*der\_int\_size)

Encode an ASN.1 integer in DER format, including tag and length fields.

int atcacert\_der\_dec\_integer (const uint8\_t \*der\_int, size\_t \*der\_int\_size, uint8\_t \*int\_data, size\_t \*int\_
 data\_size)

Decode an ASN.1 DER encoded integer.

 $\bullet \ \ int \ \ at cacert\_der\_enc\_ecdsa\_sig\_value \ (const \ uint8\_t \ raw\_sig[64], \ uint8\_t \ *der\_sig, \ size\_t \ *der\_sig\_size)$ 

Formats a raw ECDSA P256 signature in the DER encoding found in X.509 certificates.

• int atcacert\_der\_dec\_ecdsa\_sig\_value (const uint8\_t \*der\_sig, size\_t \*der\_sig\_size, uint8\_t raw\_sig[64])

Parses an ECDSA P256 signature in the DER encoding as found in X.509 certificates.

• int atcacert\_verify\_cert\_hw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t ca\_public\_key[64])

Verify a certificate against its certificate authority's public key using the host's ATECC device for crypto functions.

• int atcacert\_gen\_challenge\_hw (uint8\_t challenge[32])

Generate a random challenge to be sent to the client using the RNG on the host's ATECC device.

• int atcacert\_verify\_response\_hw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8\_t response[64])

Verify a client's response to a challenge using the host's ATECC device for crypto functions.

• int atcacert\_verify\_cert\_sw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8 t ca public key[64])

Verify a certificate against its certificate authority's public key using software crypto functions. The function is currently not implemented.

• int atcacert\_gen\_challenge\_sw (uint8\_t challenge[32])

Generate a random challenge to be sent to the client using a software PRNG. The function is currently not implemented.

• int atcacert\_verify\_response\_sw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8\_t response[64])

Verify a client's response to a challenge using software crypto functions. The function is currently not implemented.

### **Variables**

const size\_t ATCACERT\_DATE\_FORMAT\_SIZES [5]

# 18.6.1 Detailed Description

These methods provide convenient ways to perform certification I/O with CryptoAuth chips and perform certificate manipulation in memory.

## 18.6.2 Macro Definition Documentation

## 18.6.2.1 ATCA PACKED

#define ATCA\_PACKED

### 18.6.2.2 ATCACERT DATE FORMAT SIZES COUNT

#define ATCACERT\_DATE\_FORMAT\_SIZES\_COUNT 5

## 18.6.2.3 ATCACERT\_E\_BAD\_CERT

```
#define ATCACERT_E_BAD_CERT 10
```

Certificate structure is bad in some way.

### 18.6.2.4 ATCACERT\_E\_BAD\_PARAMS

```
#define ATCACERT_E_BAD_PARAMS 2
```

Invalid/bad parameter passed to function.

# 18.6.2.5 ATCACERT\_E\_BUFFER\_TOO\_SMALL

```
#define ATCACERT_E_BUFFER_TOO_SMALL 3
```

Supplied buffer for output is too small to hold the result.

# 18.6.2.6 ATCACERT\_E\_DECODING\_ERROR

```
#define ATCACERT_E_DECODING_ERROR 4
```

Data being decoded/parsed has an invalid format.

# 18.6.2.7 ATCACERT\_E\_ELEM\_MISSING

```
#define ATCACERT_E_ELEM_MISSING 8
```

The certificate element isn't defined for the certificate definition.

# 18.6.2.8 ATCACERT\_E\_ELEM\_OUT\_OF\_BOUNDS

```
#define ATCACERT_E_ELEM_OUT_OF_BOUNDS 9
```

Certificate element is out of bounds for the given certificate.

## 18.6.2.9 ATCACERT\_E\_ERROR

#define ATCACERT\_E\_ERROR 1

General error.

## 18.6.2.10 ATCACERT\_E\_INVALID\_DATE

#define ATCACERT\_E\_INVALID\_DATE 5

Date is invalid.

# 18.6.2.11 ATCACERT\_E\_INVALID\_TRANSFORM

#define ATCACERT\_E\_INVALID\_TRANSFORM 13

Invalid transform passed to function.

# 18.6.2.12 ATCACERT\_E\_SUCCESS

#define ATCACERT\_E\_SUCCESS 0

Operation completed successfully.

# 18.6.2.13 ATCACERT\_E\_UNEXPECTED\_ELEM\_SIZE

#define ATCACERT\_E\_UNEXPECTED\_ELEM\_SIZE 7

A certificate element size was not what was expected.

# 18.6.2.14 ATCACERT\_E\_UNIMPLEMENTED

#define ATCACERT\_E\_UNIMPLEMENTED 6

Function is unimplemented for the current configuration.

# 18.6.2.15 ATCACERT\_E\_VERIFY\_FAILED

#define ATCACERT\_E\_VERIFY\_FAILED 12

Certificate or challenge/response verification failed.

# 18.6.2.16 ATCACERT\_E\_WRONG\_CERT\_DEF

#define ATCACERT\_E\_WRONG\_CERT\_DEF 11

# 18.6.2.17 DATEFMT\_ISO8601\_SEP\_SIZE

#define DATEFMT\_ISO8601\_SEP\_SIZE (20)

## 18.6.2.18 DATEFMT\_MAX\_SIZE

#define DATEFMT\_MAX\_SIZE DATEFMT\_IS08601\_SEP\_SIZE

## 18.6.2.19 DATEFMT\_POSIX\_UINT32\_BE\_SIZE

#define DATEFMT\_POSIX\_UINT32\_BE\_SIZE (4)

# 18.6.2.20 DATEFMT\_POSIX\_UINT32\_LE\_SIZE

#define DATEFMT\_POSIX\_UINT32\_LE\_SIZE (4)

# 18.6.2.21 DATEFMT\_RFC5280\_GEN\_SIZE

#define DATEFMT\_RFC5280\_GEN\_SIZE (15)

# 18.6.2.22 DATEFMT\_RFC5280\_UTC\_SIZE

```
#define DATEFMT_RFC5280_UTC_SIZE (13)
```

### 18.6.2.23 FALSE

```
#define FALSE (0)
```

### 18.6.2.24 TRUE

```
#define TRUE (1)
```

# 18.6.3 Typedef Documentation

# 18.6.3.1 atcacert\_build\_state\_t

```
typedef struct atcacert_build_state_s atcacert_build_state_t
```

Tracks the state of a certificate as it's being rebuilt from device information.

### 18.6.3.2 atcacert\_cert\_element\_t

```
typedef struct atcacert_cert_element_s atcacert_cert_element_t
```

Defines a generic dynamic element for a certificate including the device and template locations.

# 18.6.3.3 atcacert\_cert\_loc\_t

```
{\tt typedef \ struct \ atcacert\_cert\_loc\_s \ atcacert\_cert\_loc\_t}
```

Defines a chunk of data in a certificate template.

# 18.6.3.4 atcacert\_cert\_sn\_src\_t

```
typedef enum atcacert_cert_sn_src_e atcacert_cert_sn_src_t
```

Sources for the certificate serial number.

### 18.6.3.5 atcacert\_cert\_type\_t

```
typedef enum atcacert_cert_type_e atcacert_cert_type_t
```

Types of certificates.

### 18.6.3.6 atcacert\_date\_format\_t

```
typedef enum atcacert_date_format_e atcacert_date_format_t
```

Date formats.

## 18.6.3.7 atcacert\_def\_t

```
typedef struct atcacert_def_s atcacert_def_t
```

Defines a certificate and all the pieces to work with it.

If any of the standard certificate elements (std\_cert\_elements) are not a part of the certificate definition, set their count to 0 to indicate their absence.

## 18.6.3.8 atcacert\_device\_loc\_t

```
typedef struct atcacert_device_loc_s atcacert_device_loc_t
```

Defines a chunk of data in an ATECC device.

# 18.6.3.9 atcacert\_device\_zone\_t

```
typedef enum atcacert_device_zone_e atcacert_device_zone_t
```

ATECC device zones. The values match the Zone Encodings as specified in the datasheet.

## 18.6.3.10 atcacert\_std\_cert\_element\_t

```
typedef enum atcacert_std_cert_element_e atcacert_std_cert_element_t
```

Standard dynamic certificate elements.

## 18.6.3.11 atcacert\_tm\_utc\_t

```
typedef struct atcacert_tm_utc_s atcacert_tm_utc_t
```

Holds a broken-down date in UTC. Mimics atcacert\_tm\_utc\_t from time.h.

# 18.6.3.12 atcacert\_transform\_t

 ${\tt typedef \ enum \ atcacert\_transform\_e \ atcacert\_transform\_t}$ 

How to transform the data from the device to the certificate.

# 18.6.4 Enumeration Type Documentation

# 18.6.4.1 atcacert\_cert\_sn\_src\_e

enum atcacert\_cert\_sn\_src\_e

Sources for the certificate serial number.

# Enumerator

| SNSRC_STORED             | Cert serial is stored on the device.                                                                                                                                   |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SNSRC_STORED_DYNAMIC     | Cert serial is stored on the device with the first byte being the DER size (X509 certs only).                                                                          |
| SNSRC_DEVICE_SN          | Cert serial number is 0x40(MSB) + 9-byte device serial number. Only applies to device certificates.                                                                    |
| SNSRC_SIGNER_ID          | Cert serial number is 0x40(MSB) + 2-byte signer ID. Only applies to signer certificates.                                                                               |
| SNSRC_PUB_KEY_HASH       | Cert serial number is the SHA256(Subject public key + Encoded dates), with uppermost 2 bits set to 01.                                                                 |
| SNSRC_DEVICE_SN_HASH     | Cert serial number is the SHA256(Device SN + Encoded dates), with uppermost 2 bits set to 01. Only applies to device certificates.                                     |
| SNSRC_PUB_KEY_HASH_POS   | Depreciated, don't use. Cert serial number is the SHA256(Subject public key + Encoded dates), with MSBit set to 0 to ensure it's positive.                             |
| SNSRC_DEVICE_SN_HASH_POS | Depreciated, don't use. Cert serial number is the SHA256(Device SN + Encoded dates), with MSBit set to 0 to ensure it's positive. Only applies to device certificates. |
| SNSRC_PUB_KEY_HASH_RAW   | Depreciated, don't use. Cert serial number is the SHA256(Subject public key + Encoded dates).                                                                          |
| SNSRC_DEVICE_SN_HASH_RAW | Depreciated, don't use. Cert serial number is the SHA256(Device SN + Encoded dates). Only applies to device certificates.                                              |

# 18.6.4.2 atcacert\_cert\_type\_e

enum atcacert\_cert\_type\_e

Types of certificates.

## Enumerator

| CERTTYPE_X509   | Standard X509 certificate. |
|-----------------|----------------------------|
| CERTTYPE_CUSTOM | Custom format.             |

# 18.6.4.3 atcacert\_date\_format\_e

enum atcacert\_date\_format\_e

Date formats.

## Enumerator

| DATEFMT_ISO8601_SEP     | ISO8601 full date YYYY-MM-DDThh:mm:ssZ.                                                       |
|-------------------------|-----------------------------------------------------------------------------------------------|
| DATEFMT_RFC5280_UTC     | RFC 5280 (X.509) 4.1.2.5.1 UTCTime format YYMMDDhhmmssZ.                                      |
| DATEFMT_POSIX_UINT32_BE | POSIX (aka UNIX) date format. Seconds since Jan 1, 1970. 32 bit unsigned integer, big endian. |

## Enumerator

| DATEFMT_POSIX_UINT32_LE | POSIX (aka UNIX) date format. Seconds since Jan 1, 1970. 32 bit unsigned integer, little endian. |
|-------------------------|--------------------------------------------------------------------------------------------------|
| DATEFMT_RFC5280_GEN     | RFC 5280 (X.509) 4.1.2.5.2 GeneralizedTime format YYYYMMDDhhmmssZ.                               |

# 18.6.4.4 atcacert\_device\_zone\_e

enum atcacert\_device\_zone\_e

ATECC device zones. The values match the Zone Encodings as specified in the datasheet.

## Enumerator

| DEVZONE_CONFIG | Configuration zone.                                         |
|----------------|-------------------------------------------------------------|
| DEVZONE_OTP    | One Time Programmable zone.                                 |
| DEVZONE_DATA   | Data zone (slots).                                          |
| DEVZONE_NONE   | Special value used to indicate there is no device location. |

# 18.6.4.5 atcacert\_std\_cert\_element\_e

enum atcacert\_std\_cert\_element\_e

Standard dynamic certificate elements.

# Enumerator

| STDCERT_PUBLIC_KEY   |                                                           |
|----------------------|-----------------------------------------------------------|
| STDCERT_SIGNATURE    |                                                           |
| STDCERT_ISSUE_DATE   |                                                           |
| STDCERT_EXPIRE_DATE  |                                                           |
| STDCERT_SIGNER_ID    |                                                           |
| STDCERT_CERT_SN      |                                                           |
| STDCERT_AUTH_KEY_ID  |                                                           |
| STDCERT_SUBJ_KEY_ID  |                                                           |
| STDCERT_NUM_ELEMENTS | Special item to give the number of elements in this enum. |

# 18.6.4.6 atcacert\_transform\_e

 $\verb"enum atcacert_transform_e"$ 

### Enumerator

| TF_NONE             | No transform, data is used byte for byte.                         |
|---------------------|-------------------------------------------------------------------|
| TF_REVERSE          | Reverse the bytes (e.g. change endianness)                        |
| TF_BIN2HEX_UC       | Convert raw binary into ASCII hex, uppercase.                     |
| TF_BIN2HEX_LC       | Convert raw binary into ASCII hex, lowercase.                     |
| TF_HEX2BIN_UC       | Convert ASCII hex, uppercase to binary.                           |
| TF_HEX2BIN_LC       | Convert ASCII hex, lowercase to binary.                           |
| TF_BIN2HEX_SPACE_UC | Convert raw binary into ASCII hex, uppercase space between bytes. |
| TF_BIN2HEX_SPACE_LC | Convert raw binary into ASCII hex, lowercase space between bytes. |
| TF_HEX2BIN_SPACE_UC | Convert ASCII hex, uppercase with spaces between bytes to binary. |
| TF_HEX2BIN_SPACE_LC | Convert ASCII hex, lowercase with spaces between bytes to binary. |

## 18.6.5 Function Documentation

## 18.6.5.1 atcacert\_cert\_build\_finish()

Completes any final certificate processing required after all data from the device has been incorporated.

The final certificate and its size in bytes are contained in the cert and cert\_size elements of the build\_state structure. This will be the same buffers as supplied to the atcacert\_cert\_build\_start function at the beginning of the certificate rebuilding process.

### **Parameters**

| in <i>build</i> | _state | Current certificate build state. |
|-----------------|--------|----------------------------------|
|-----------------|--------|----------------------------------|

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.2 atcacert\_cert\_build\_process()

Process information read from the ATECC device. If it contains information for the certificate, it will be incorporated into the certificate.

### **Parameters**

| in | build_state | Current certificate building state.                                                                               |
|----|-------------|-------------------------------------------------------------------------------------------------------------------|
| in | device_loc  | Device location structure describing where on the device the following data came from.                            |
| in | device_data | Actual data from the device. It should represent the offset and byte count specified in the device_loc parameter. |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.3 atcacert\_cert\_build\_start()

```
int atcacert_cert_build_start (
    atcacert_build_state_t * build_state,
    const atcacert_def_t * cert_def,
    uint8_t * cert,
    size_t * cert_size,
    const uint8_t ca_public_key[64] )
```

Starts the certificate rebuilding process.

### **Parameters**

| out | build_state   | Structure is initialized to start the certificate building process. Will be passed to the other certificate building functions.                                                                                                                          |
|-----|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | cert_def      | Certificate definition for the certificate being built.                                                                                                                                                                                                  |
| in  | cert          | Buffer to contain the rebuilt certificate.                                                                                                                                                                                                               |
| in  | cert_size     | As input, the size of the cert buffer in bytes. This value will be adjusted to the current/final size of the certificate through the building process.                                                                                                   |
| in  | ca_public_key | ECC P256 public key of the certificate authority (issuer) for the certificate being built. Set to NULL if the authority key id is not needed, set properly in the cert_def template, or stored on the device as specified in the cert_def cert_elements. |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.4 atcacert\_create\_csr()

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

### **Parameters**

| in     | csr_def  | CSR definition describing where to find the dynamic CSR information on the device      |
|--------|----------|----------------------------------------------------------------------------------------|
|        |          | and how to incorporate it into the template.                                           |
| out    | csr      | Buffer to receive the CSR.                                                             |
| in,out | csr_size | As input, the size of the CSR buffer in bytes. As output, the size of the CSR returned |
|        |          | in cert in bytes.                                                                      |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.6.5.5 atcacert\_create\_csr\_pem()

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

## **Parameters**

| in     | csr_def  | CSR definition describing where to find the dynamic CSR information on the device and how to incorporate it into the template. |
|--------|----------|--------------------------------------------------------------------------------------------------------------------------------|
| out    | csr      | Buffer to received the CSR formatted as PEM.                                                                                   |
| in,out | csr_size | As input, the size of the CSR buffer in bytes. As output, the size of the CSR as PEM                                           |
|        |          | returned in cert in bytes.                                                                                                     |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.6.5.6 atcacert\_date\_dec()

Parse a formatted timestamp according to the specified format.

### **Parameters**

| in  | format              | Format to parse the formatted date as. |
|-----|---------------------|----------------------------------------|
| in  | formatted_date      | Formatted date to be parsed.           |
| in  | formatted_date_size | Size of the formatted date in bytes.   |
| out | timestamp           | Parsed timestamp is returned here.     |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.7 atcacert\_date\_dec\_compcert()

Decode the issue and expire dates from the format used by the compressed certificate.

### **Parameters**

| in  | enc_dates          | Encoded date from the compressed certificate. 3 bytes.                           |
|-----|--------------------|----------------------------------------------------------------------------------|
| in  | expire_date_format | Expire date format. Only used to determine max date when no expiration date      |
|     |                    | is specified by the encoded date.                                                |
| out | issue_date         | Decoded issue date is returned here.                                             |
| out | expire_date        | Decoded expire date is returned here. If there is no expiration date, the expire |
|     |                    | date will be set to a maximum value for the given expire_date_format.            |

## Returns

0 on success

# 18.6.5.8 atcacert\_date\_dec\_iso8601\_sep()

## 18.6.5.9 atcacert\_date\_dec\_posix\_uint32\_be()

## 18.6.5.10 atcacert\_date\_dec\_posix\_uint32\_le()

## 18.6.5.11 atcacert\_date\_dec\_rfc5280\_gen()

# 18.6.5.12 atcacert\_date\_dec\_rfc5280\_utc()

# 18.6.5.13 atcacert\_date\_enc()

Format a timestamp according to the format type.

| in     | format              | Format to use.                                                              |
|--------|---------------------|-----------------------------------------------------------------------------|
| in     | timestamp           | Timestamp to format.                                                        |
| out    | formatted_date      | Formatted date will be returned in this buffer.                             |
| in,out | formatted_date_size | As input, the size of the formatted_date buffer. As output, the size of the |
|        |                     | returned formatted_date.                                                    |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.14 atcacert\_date\_enc\_compcert()

Encode the issue and expire dates in the format used by the compressed certificate.

### **Parameters**

| in  | issue_date   | Issue date to encode. Note that minutes and seconds will be ignored.                   |
|-----|--------------|----------------------------------------------------------------------------------------|
| in  | expire_years | Expire date is expressed as a number of years past the issue date. 0 should be used if |
|     |              | there is no expire date.                                                               |
| out | enc_dates    | Encoded dates for use in the compressed certificate is returned here. 3 bytes.         |

### Returns

0 on success

# 18.6.5.15 atcacert\_date\_enc\_iso8601\_sep()

## 18.6.5.16 atcacert\_date\_enc\_posix\_uint32\_be()

# 18.6.5.17 atcacert\_date\_enc\_posix\_uint32\_le()

### 18.6.5.18 atcacert\_date\_enc\_rfc5280\_gen()

## 18.6.5.19 atcacert\_date\_enc\_rfc5280\_utc()

## 18.6.5.20 atcacert\_date\_get\_max\_date()

Return the maximum date available for the given format.

### **Parameters**

| in  | format    | Format to get the max date for. |
|-----|-----------|---------------------------------|
| out | timestamp | Max date is returned here.      |

# Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.21 atcacert\_der\_adjust\_length()

```
int atcacert_der_adjust_length (
          uint8_t * der_length,
          size_t * der_length_size,
          int delta_length,
          uint32_t * new_length )
```

### 18.6.5.22 atcacert\_der\_dec\_ecdsa\_sig\_value()

Parses an ECDSA P256 signature in the DER encoding as found in X.509 certificates.

This will parse the DER encoding of the signatureValue field as found in an X.509 certificate (RFC 5280). x509\_sig should include the tag, length, and value. The value of the signatureValue is the DER encoding of the ECDSA-Sig-Value as specified by RFC 5480 and SECG SEC1.

#### **Parameters**

| in     | der_sig      | X.509 format signature (TLV of signatureValue) to be parsed.                                                            |  |
|--------|--------------|-------------------------------------------------------------------------------------------------------------------------|--|
| in,out | der_sig_size | As input, size of the der_sig buffer in bytes. As output, size of the DER x.509 signature parsed from the buffer.       |  |
| out    | raw_sig      | Parsed P256 ECDSA signature will be returned in this buffer. Formatted as R S integers concatenated together. 64 bytes. |  |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.23 atcacert\_der\_dec\_integer()

## Decode an ASN.1 DER encoded integer.

X.680 ( http://www.itu.int/rec/T-REC-X.680/en) section 19.8, for tag value X.690 ( http://www.itu.int/rec/T-REC-X.690/en) section 8.3, for encoding

|     |      | , , ,         | DED LIAONATA THE HARMAN                                                             |
|-----|------|---------------|-------------------------------------------------------------------------------------|
| in  |      | der_int       | DER encoded ASN.1 integer, including the tag and length fields.                     |
| in, | out, | der int size  | As input, the size of the der int buffer in bytes. As output, the size of the DER   |
|     |      |               | integer decoded in bytes.                                                           |
| out |      | int_data      | Decode integer is returned in this buffer in a signed big-endian format.            |
| in, | out, | int_data_size | As input, the size of int_data in bytes. As output, the size of the decoded integer |
|     |      |               | in bytes.                                                                           |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.24 atcacert\_der\_dec\_length()

Decode a DER format length.

```
X.690 ( http://www.itu.int/rec/T-REC-X.690/en) section 8.1.3, for encoding
```

### **Parameters**

| in     | der_length      | DER encoded length.                                                                                                   |
|--------|-----------------|-----------------------------------------------------------------------------------------------------------------------|
| in,out | der_length_size | As input, the size of the der_length buffer in bytes. As output, the size of the DER encoded length that was decoded. |
|        |                 | DEN encoded length that was decoded.                                                                                  |
| out    | length          | Decoded length is returned here.                                                                                      |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.25 atcacert\_der\_enc\_ecdsa\_sig\_value()

Formats a raw ECDSA P256 signature in the DER encoding found in X.509 certificates.

This will return the DER encoding of the signature Value field as found in an X.509 certificate (RFC 5280). This include the tag, length, and value. The value of the signature Value is the DER encoding of the ECDSA-Sig-Value as specified by RFC 5480 and SECG SEC1.

| in     | raw_sig      | P256 ECDSA signature to be formatted. Input format is R and S integers concatenated together. 64 bytes.           |
|--------|--------------|-------------------------------------------------------------------------------------------------------------------|
| out    | der_sig      | X.509 format signature (TLV of signatureValue) will be returned in this buffer.                                   |
| in,out | der_sig_size | As input, the size of the x509_sig buffer in bytes. As output, the size of the returned X.509 signature in bytes. |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.26 atcacert\_der\_enc\_integer()

Encode an ASN.1 integer in DER format, including tag and length fields.

X.680 ( http://www.itu.int/rec/T-REC-X.680/en) section 19.8, for tag value X.690 ( http://www.itu.int/rec/T-REC-X.690/en) section 8.3, for encoding

### **Parameters**

| in     | int_data      | Raw integer in big-endian format.                                                                            |
|--------|---------------|--------------------------------------------------------------------------------------------------------------|
| in     | int_data_size | Size of the raw integer in bytes.                                                                            |
| in     | is_unsigned   | Indicate whether the input integer should be treated as unsigned.                                            |
| out    | der_int       | DER encoded integer is returned in this buffer.                                                              |
| in,out | der_int_size  | As input, the size of the der_int buffer in bytes. As output, the size of the DER integer returned in bytes. |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.27 atcacert\_der\_enc\_length()

Encode a length in DER format.

X.690 ( http://www.itu.int/rec/T-REC-X.690/en) section 8.1.3, for encoding

| in     | length          | Length to be encoded.                                                                                  |
|--------|-----------------|--------------------------------------------------------------------------------------------------------|
| out    | der_length      | DER encoded length will returned in this buffer.                                                       |
| in,out | der_length_size | As input, size of der_length buffer in bytes. As output, the size of the DER length encoding in bytes. |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.28 atcacert\_gen\_cert\_sn()

Sets the certificate serial number by generating it from other information in the certificate using the scheme specified by sn\_source in cert\_def. See the.

This method requires certain elements in the certificate be set properly as they're used for generating the serial number. See atcacert\_cert\_sn\_src\_t for what elements should be set in the certificate beforehand. If the sn\_source is set to SNSRC\_STORED or SNSRC\_STORED\_DYNAMIC, the function will return ATCACERT\_E\_SUCCESS without making any changes to the certificate.

### **Parameters**

| in     | cert_def  | Certificate definition for the certificate.                                                               |
|--------|-----------|-----------------------------------------------------------------------------------------------------------|
| in,out | cert      | Certificate to update.                                                                                    |
| in     | cert_size | Size of the certificate (cert) in bytes.                                                                  |
| in     | device_sn | Device serial number, only used if required by the sn_source scheme. Can be set to NULL, if not required. |

### Returns

ATCACERT E SUCCESS on success, otherwise an error code.

### 18.6.5.29 atcacert gen challenge hw()

Generate a random challenge to be sent to the client using the RNG on the host's ATECC device.

### **Parameters**

| out | challenge | Random challenge is return here. 32 bytes. |
|-----|-----------|--------------------------------------------|
|-----|-----------|--------------------------------------------|

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.30 atcacert\_gen\_challenge\_sw()

Generate a random challenge to be sent to the client using a software PRNG. The function is currently not implemented.

### **Parameters**

|  | out | challenge | Random challenge is return here. 32 bytes. |  |
|--|-----|-----------|--------------------------------------------|--|
|--|-----|-----------|--------------------------------------------|--|

## Returns

ATCA\_UNIMPLEMENTED, as the function is currently not implemented.

### 18.6.5.31 atcacert\_get\_auth\_key\_id()

Gets the authority key ID from a certificate.

### **Parameters**

|   | in  | cert_def  | Certificate definition for the certificate.            |
|---|-----|-----------|--------------------------------------------------------|
|   | in  | cert      | Certificate to get element from.                       |
|   | in  | cert_size | Size of the certificate (cert) in bytes.               |
| Ī | out | auth_key⇔ | Authority key ID is returned in this buffer. 20 bytes. |
|   |     | _id       |                                                        |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.32 atcacert\_get\_cert\_element()

```
const atcacert_cert_loc_t * cert_loc,
const uint8_t * cert,
size_t cert_size,
uint8_t * data,
size_t data_size)
```

Gets an element from a certificate.

### **Parameters**

| in  | cert_def  | Certificate definition for the certificate.                                                                  |
|-----|-----------|--------------------------------------------------------------------------------------------------------------|
| in  | cert_loc  | Certificate location for this element.                                                                       |
| in  | cert      | Certificate to get element from.                                                                             |
| in  | cert_size | Size of the certificate (cert) in bytes.                                                                     |
| out | data      | Element data will be returned in this buffer. This buffer must be large enough to hold cert_loc.count bytes. |
| in  | data_size | Expected size of the cert element data.                                                                      |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.33 atcacert\_get\_cert\_sn()

Gets the certificate serial number from a certificate.

### **Parameters**

| in     | cert_def     | Certificate definition for the certificate.                                                             |
|--------|--------------|---------------------------------------------------------------------------------------------------------|
| in     | cert         | Certificate to get element from.                                                                        |
| in     | cert_size    | Size of the certificate (cert) in bytes.                                                                |
| out    | cert_sn      | Certificate SN will be returned in this buffer.                                                         |
| in,out | cert_sn_size | As input, the size of the cert_sn buffer. As output, the size of the certificate SN (cert_sn) in bytes. |

# Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.34 atcacert\_get\_comp\_cert()

Generate the compressed certificate for the given certificate.

### **Parameters**

| in  | cert_def  | Certificate definition for the certificate.                  |
|-----|-----------|--------------------------------------------------------------|
| in  | cert      | Certificate to generate the compressed certificate for.      |
| in  | cert_size | Size of the certificate (cert) in bytes.                     |
| out | comp_cert | Compressed certificate is returned in this buffer. 72 bytes. |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 18.6.5.35 atcacert get device data()

Gets the dynamic data that would be saved to the specified device location. This function is primarily used to break down a full certificate into the dynamic components to be saved to a device.

The atcacert\_add\_device\_locs function can be used to generate a list of device locations a particular certificate definition requires.

## **Parameters**

| in  | cert_def    | Certificate definition for the certificate we're getting data from.           |
|-----|-------------|-------------------------------------------------------------------------------|
| in  | cert        | Certificate to get the device data from.                                      |
| in  | cert_size   | Size of the certificate in bytes.                                             |
| in  | device_loc  | Device location to request data for.                                          |
| out | device_data | Buffer that represents the device data in device_loc. Required to be at least |
|     |             | device_loc.count in size.                                                     |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 18.6.5.36 atcacert\_get\_device\_locs()

Add all the device locations required to rebuild the specified certificate (cert\_def) to a device locations list.

The block\_size parameter will adjust all added device locations to have a offset and count that aligns with that block size. This allows one to generate a list of device locations that matches specific read or write semantics (e.g. 4 byte or 32 byte reads).

#### **Parameters**

| in     | cert_def              | Certificate definition containing all the device locations to add to the list. |
|--------|-----------------------|--------------------------------------------------------------------------------|
|        |                       | 7.7                                                                            |
| in,out | device_locs           | List of device locations to add to.                                            |
| in,out | device_locs_count     | As input, existing size of the device locations list. As output, the new       |
|        |                       | size of the device locations list.                                             |
| in     | device_locs_max_count | Maximum number of elements device_locs can hold.                               |
| in     | block_size            | Block size to align all offsets and counts to when adding device               |
|        |                       | locations.                                                                     |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.37 atcacert\_get\_expire\_date()

Gets the expire date from a certificate. Will be parsed according to the date format specified in the certificate definition.

| in  | cert_def  | Certificate definition for the certificate. |
|-----|-----------|---------------------------------------------|
| in  | cert      | Certificate to get element from.            |
| in  | cert_size | Size of the certificate (cert) in bytes.    |
| out | timestamp | Expire date is returned in this structure.  |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.38 atcacert\_get\_issue\_date()

Gets the issue date from a certificate. Will be parsed according to the date format specified in the certificate definition.

#### **Parameters**

| in  | cert_def  | Certificate definition for the certificate. |
|-----|-----------|---------------------------------------------|
| in  | cert      | Certificate to get element from.            |
| in  | cert_size | Size of the certificate (cert) in bytes.    |
| out | timestamp | Issue date is returned in this structure.   |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.39 atcacert\_get\_key\_id()

Calculates the key ID for a given public ECC P256 key.

Uses method 1 for calculating the keyldentifier as specified by RFC 5280, section 4.2.1.2: (1) The keyldentifier is composed of the 160-bit SHA-1 hash of the value of the BIT STRING subjectPublicKey (excluding the tag, length, and number of unused bits).

| in | public_key | ECC P256 public key to calculate key key ID for. Formatted as the X and Y integers |  |
|----|------------|------------------------------------------------------------------------------------|--|
|    |            | concatenated together. 64 bytes.                                                   |  |
| in | key_id     | ey_id Calculated key ID will be returned in this buffer. 20 bytes.                 |  |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.40 atcacert\_get\_response()

Calculates the response to a challenge sent from the host.

The challenge-response protocol is an ECDSA Sign and Verify. This performs the ECDSA Sign on the challenge and returns the signature as the response.

#### **Parameters**

| in  | device_private_key_slot | Slot number for the device's private key. This must be the same slot used to generate the public key included in the device's certificate. |
|-----|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| in  | challenge               | Challenge to generate the response for. Must be 32 bytes.                                                                                  |
| out | response                | Response will be returned in this buffer. 64 bytes.                                                                                        |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.6.5.41 atcacert\_get\_signature()

Gets the signature from a certificate.

| in  | cert_def                                                                                                     | Certificate definition for the certificate. |  |
|-----|--------------------------------------------------------------------------------------------------------------|---------------------------------------------|--|
| in  | cert                                                                                                         | Certificate to get element from.            |  |
| in  | cert_size                                                                                                    | Size of the certificate (cert) in bytes.    |  |
| out | signature Signature is returned in this buffer. Formatted at R and S integers concatenated togethe 64 bytes. |                                             |  |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.42 atcacert\_get\_signer\_id()

Gets the signer ID from a certificate. Will be parsed as 4 upper-case hex digits.

#### **Parameters**

| in  | cert_def  | Certificate definition for the certificate.         |
|-----|-----------|-----------------------------------------------------|
| in  | cert      | Certificate to get element from.                    |
| in  | cert_size | Size of the certificate (cert) in bytes.            |
| out | signer⊷   | Signer ID will be returned in this buffer. 2 bytes. |
|     | _id       |                                                     |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.43 atcacert\_get\_subj\_key\_id()

Gets the subject key ID from a certificate.

|   | in  | cert_def  | Certificate definition for the certificate.          |
|---|-----|-----------|------------------------------------------------------|
|   | in  | cert      | Certificate to get element from.                     |
| Ī | in  | cert_size | Size of the certificate (cert) in bytes.             |
| ĺ | out | subj_key⇔ | Subject key ID is returned in this buffer. 20 bytes. |
|   |     | _id       |                                                      |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.44 atcacert\_get\_subj\_public\_key()

Gets the subject public key from a certificate.

### **Parameters**

| in  | cert_def        | Certificate definition for the certificate.                                                                          |  |
|-----|-----------------|----------------------------------------------------------------------------------------------------------------------|--|
| in  | cert            | Certificate to get element from.                                                                                     |  |
| in  | cert_size       | Size of the certificate (cert) in bytes.                                                                             |  |
| out | subj_public_key | ic_key Subject public key is returned in this buffer. Formatted at X and Y integers concatenated together. 64 bytes. |  |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.45 atcacert\_get\_tbs()

Get a pointer to the TBS data in a certificate.

| in  | cert_def                                                                  | f Certificate definition for the certificate.      |  |
|-----|---------------------------------------------------------------------------|----------------------------------------------------|--|
| in  | cert                                                                      | cert Certificate to get the TBS data pointer for.  |  |
| in  | cert_size                                                                 | cert_size Size of the certificate (cert) in bytes. |  |
| out | tbs Pointer to a const pointer that will be set the start of the TBS data |                                                    |  |
| out | tbs_size Size of the TBS data will be returned here.                      |                                                    |  |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.46 atcacert\_get\_tbs\_digest()

Get the SHA256 digest of certificate's TBS data.

#### **Parameters**

| in  | cert_def                                           | Certificate definition for the certificate.      |
|-----|----------------------------------------------------|--------------------------------------------------|
| in  | cert                                               | Certificate to get the TBS data pointer for.     |
| in  | cert_size Size of the certificate (cert) in bytes. |                                                  |
| out | tbs_digest                                         | TBS data digest will be returned here. 32 bytes. |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.47 atcacert\_is\_device\_loc\_overlap()

Determines if the two device locations overlap.

#### **Parameters**

|   | in | device_loc1 | First device location to check. |
|---|----|-------------|---------------------------------|
| ſ | in | device loc2 | Second device location o check. |

### Returns

0 (false) if they don't overlap, non-zero if the do overlap.

### 18.6.5.48 atcacert\_max\_cert\_size()

Return the maximum possible certificate size in bytes for a given cert def. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificates.

#### **Parameters**

| in  | cert_def      | Certificate definition to find a max size for.           |
|-----|---------------|----------------------------------------------------------|
| out | max_cert_size | Maximum certificate size will be returned here in bytes. |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 18.6.5.49 atcacert\_merge\_device\_loc()

```
int atcacert_merge_device_loc (
    atcacert_device_loc_t * device_locs,
    size_t * device_locs_count,
    size_t device_locs_max_count,
    const atcacert_device_loc_t * device_loc,
    size_t block_size )
```

Merge a new device location into a list of device locations. If the new location overlaps with an existing location, the existing one will be modified to encompass both. Otherwise the new location is appended to the end of the list.

The block\_size parameter will adjust all added device locations to have an offset and count that aligns with that block size. This allows one to generate a list of device locations that matches specific read/write semantics (e.g. 4 byte or 32 byte reads). Note that this block\_size only applies to the device\_loc being added. Existing device locations in the list won't be modified to match the block size.

## Parameters

| in,out | device_locs           | Existing device location list to merge the new device location into.                                             |  |
|--------|-----------------------|------------------------------------------------------------------------------------------------------------------|--|
| in,out | device_locs_count     | As input, the existing number of items in the device_locs list. As output, the new size of the device_locs list. |  |
| in     | device_locs_max_count | Maximum number of items the device_locs list can hold.                                                           |  |
| in     | device_loc            | New device location to be merged into the device_locs list.                                                      |  |
| in     | block_size            | Block size to align all offsets and counts to when adding device                                                 |  |
|        |                       | location.                                                                                                        |  |

### Returns

### 18.6.5.50 atcacert\_public\_key\_add\_padding()

Takes a raw P256 ECC public key and converts it to the padded version used by ATECC devices. Input and output buffers can point to the same location to do an in-place transform.

#### **Parameters**

|   | in                                                                                                  | raw_key | Public key as X and Y integers concatenated together. 64 bytes.                         |  |
|---|-----------------------------------------------------------------------------------------------------|---------|-----------------------------------------------------------------------------------------|--|
| Ī | out padded_key Padded key is returned in this buffer. X and Y integers are padded with 4 bytes of 0 |         | Padded key is returned in this buffer. X and Y integers are padded with 4 bytes of 0 in |  |
|   |                                                                                                     |         | the MSB. 72 bytes.                                                                      |  |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 18.6.5.51 atcacert\_public\_key\_remove\_padding()

Takes a padded public key used by ATECC devices and converts it to a raw P256 ECC public key. Input and output buffers can point to the same location to do an in-place transform.

### **Parameters**

| out | padded_key | X and Y integers are padded with 4 bytes of 0 in the MSB. 72 bytes.             |  |
|-----|------------|---------------------------------------------------------------------------------|--|
| in  | raw_key    | Raw key is returned in this buffer. Public key as X and Y integers concatenated |  |
|     |            | together. 64 bytes.                                                             |  |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.52 atcacert\_read\_cert()

Reads the certificate specified by the certificate definition from the ATECC508A device.

This process involves reading the dynamic cert data from the device and combining it with the template found in the certificate definition.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 190

#### **Parameters**

|   | in     | cert_def      | Certificate definition describing where to find the dynamic certificate information on the device and how to incorporate it into the template.                                                                                                                                                                                    |  |
|---|--------|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
|   | in     | ca_public_key | The ECC P256 public key of the certificate authority that signed this certificate. Formatted as the 32 byte X and Y integers concatenated together (64 bytes total). Set to NULL if the authority key id is not needed, set properly in the cert_def template, or stored on the device as specifed in the cert_def cert_elements. |  |
| ſ | out    | cert          | Buffer to received the certificate.                                                                                                                                                                                                                                                                                               |  |
|   | in,out | cert_size     | As input, the size of the cert buffer in bytes. As output, the size of the certif returned in cert in bytes.                                                                                                                                                                                                                      |  |

### Returns

ATCACERT E SUCCESS on success, otherwise an error code.

# 18.6.5.53 atcacert\_read\_cert\_size()

Return the actual certificate size in bytes for a given cert def. Certificate can be variable size, so this gives the absolute buffer size when reading the certificates.

# Parameters

| in  | cert_def  | Certificate definition to find a max size for.   |
|-----|-----------|--------------------------------------------------|
| out | cert_size | Certificate size will be returned here in bytes. |

# Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.54 atcacert\_read\_device\_loc()

Read the data from a device location.

| in   | device_loc | Device location to read data from. |
|------|------------|------------------------------------|
| _out | data       | Data read is returned here.        |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.55 atcacert\_read\_subj\_key\_id()

Reads the subject key ID based on a certificate definition.

### **Parameters**

| in  | cert_def  | Certificate definition                               |
|-----|-----------|------------------------------------------------------|
| out | subj_key⊷ | Subject key ID is returned in this buffer. 20 bytes. |
|     | _id       |                                                      |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 18.6.5.56 atcacert\_set\_auth\_key\_id()

Sets the authority key ID in a certificate. Note that this takes the actual public key creates a key ID from it.

#### **Parameters**

| in     | cert_def        | Certificate definition for the certificate.                               |
|--------|-----------------|---------------------------------------------------------------------------|
| in,out | cert            | Certificate to update.                                                    |
| in     | cert_size       | Size of the certificate (cert) in bytes.                                  |
| in     | auth_public_key | Authority public key as X and Y integers concatenated together. 64 bytes. |

# Returns

## 18.6.5.57 atcacert\_set\_auth\_key\_id\_raw()

Sets the authority key ID in a certificate.

#### **Parameters**

| in     | cert_def  | Certificate definition for the certificate.             |
|--------|-----------|---------------------------------------------------------|
| in,out | cert      | Certificate to update.                                  |
| in     | cert_size | Size of the certificate (cert) in bytes.                |
| in     | auth_key⇔ | Authority key ID. Same size as defined in the cert_def. |
|        | _id       |                                                         |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.58 atcacert\_set\_cert\_element()

Sets an element in a certificate. The data\_size must match the size in cert\_loc.

## **Parameters**

| in     | cert_def  | Certificate definition for the certificate.                                                                              |  |
|--------|-----------|--------------------------------------------------------------------------------------------------------------------------|--|
| in     | cert_loc  | Certificate location for this element.                                                                                   |  |
| in,out | cert      | Certificate to update.                                                                                                   |  |
| in     | cert_size | Size of the certificate (cert) in bytes.                                                                                 |  |
| in     | data      | Element data to insert into the certificate. Buffer must contain cert_loc.count bytes to be copied into the certificate. |  |
| in     | data_size | Size of the data in bytes.                                                                                               |  |

#### Returns

## 18.6.5.59 atcacert\_set\_cert\_sn()

Sets the certificate serial number in a certificate.

#### **Parameters**

| in     | cert_def      | Certificate definition for the certificate.     |
|--------|---------------|-------------------------------------------------|
| in,out | cert          | Certificate to update.                          |
| in,out | cert_size     | Size of the certificate (cert) in bytes.        |
| in     | max_cert_size | Maximum size of the cert buffer.                |
| in     | cert_sn       | Certificate serial number.                      |
| in     | cert_sn_size  | Size of the certificate serial number in bytes. |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.60 atcacert\_set\_comp\_cert()

Sets the signature, issue date, expire date, and signer ID found in the compressed certificate. This also checks fields common between the cert\_def and the compressed certificate to make sure they match.

## **Parameters**

| in     | cert_def      | Certificate definition for the certificate.                                                    |
|--------|---------------|------------------------------------------------------------------------------------------------|
| in,out | cert          | Certificate to update.                                                                         |
| in,out | cert_size     | As input, size of the certificate (cert) in bytes. As output, the new size of the certificate. |
| in     | max_cert_size | Maximum size of the cert buffer.                                                               |
| in     | comp_cert     | Compressed certificate. 72 bytes.                                                              |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 194

ATCACERT\_E\_SUCCESS on success. ATCACERT\_E\_WRONG\_CERT\_DEF if the template ID, chain ID, and/or SN source don't match between the cert\_def and the compressed certificate.

### 18.6.5.61 atcacert\_set\_expire\_date()

Sets the expire date (notAfter) in a certificate. Will be formatted according to the date format specified in the certificate definition.

#### **Parameters**

| in     | cert_def  | Certificate definition for the certificate. |
|--------|-----------|---------------------------------------------|
| in,out | cert      | Certificate to update.                      |
| in     | cert_size | Size of the certificate (cert) in bytes.    |
| in     | timestamp | Expire date.                                |

### Returns

ATCACERT E SUCCESS on success, otherwise an error code.

## 18.6.5.62 atcacert\_set\_issue\_date()

Sets the issue date (notBefore) in a certificate. Will be formatted according to the date format specified in the certificate definition.

| in     | cert_def  | Certificate definition for the certificate. |
|--------|-----------|---------------------------------------------|
| in,out | cert      | Certificate to update.                      |
| in     | cert_size | Size of the certificate (cert) in bytes.    |
| in     | timestamp | Issue date.                                 |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.63 atcacert\_set\_signature()

Sets the signature in a certificate. This may alter the size of the X.509 certificates.

#### **Parameters**

| in     | cert_def      | Certificate definition for the certificate.                                                    |
|--------|---------------|------------------------------------------------------------------------------------------------|
| in,out | cert          | Certificate to update.                                                                         |
| in,out | cert_size     | As input, size of the certificate (cert) in bytes. As output, the new size of the certificate. |
| in     | max_cert_size | Maximum size of the cert buffer.                                                               |
| in     | signature     | Signature as R and S integers concatenated together. 64 bytes.                                 |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.64 atcacert\_set\_signer\_id()

Sets the signer ID in a certificate. Will be formatted as 4 upper-case hex digits.

| in     | cert_def  | Certificate definition for the certificate. |
|--------|-----------|---------------------------------------------|
| in,out | cert      | Certificate to update.                      |
| in     | cert_size | Size of the certificate (cert) in bytes.    |
| in     | signer⊷   | Signer ID.                                  |
|        | _id       |                                             |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.65 atcacert\_set\_subj\_public\_key()

Sets the subject public key and subject key ID in a certificate.

### **Parameters**

| in     | cert_def        | Certificate definition for the certificate.                             |
|--------|-----------------|-------------------------------------------------------------------------|
| in,out | cert            | Certificate to update.                                                  |
| in     | cert_size       | Size of the certificate (cert) in bytes.                                |
| in     | subj_public_key | Subject public key as X and Y integers concatenated together. 64 bytes. |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.5.66 atcacert\_transform\_data()

```
int atcacert_transform_data (
    atcacert_transform_t transform,
    const uint8_t * data,
    size_t data_size,
    uint8_t * destination,
    size_t * destination_size )
```

Apply the specified transform to the specified data.

| in     | transform        | Transform to be performed.                                              |
|--------|------------------|-------------------------------------------------------------------------|
| in     | data             | Input data to be transformed.                                           |
| in     | data_size        | Size of the input data in bytes.                                        |
| out    | destination      | Destination buffer to hold the transformed data.                        |
| in,out | destination_size | As input, the size of the destination buffer. As output the size of the |
|        |                  | transformed data.                                                       |

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.6.5.67 atcacert\_verify\_cert\_hw()

Verify a certificate against its certificate authority's public key using the host's ATECC device for crypto functions.

#### **Parameters**

| in | cert_def      | Certificate definition describing how to extract the TBS and signature components from the certificate specified. |
|----|---------------|-------------------------------------------------------------------------------------------------------------------|
| in | cert          | Certificate to verify.                                                                                            |
| in | cert_size     | Size of the certificate (cert) in bytes.                                                                          |
| in | ca_public_key | The ECC P256 public key of the certificate authority that signed this certificate.                                |
|    |               | Formatted as the 32 byte X and Y integers concatenated together (64 bytes total).                                 |

# Returns

ATCACERT\_E\_SUCCESS if the verify succeeds, ATCACERT\_VERIFY\_FAILED or ATCA\_EXECUTION\_← ERROR if it fails to verify. ATCA\_EXECUTION\_ERROR may occur when the public key is invalid and doesn't fall on the P256 curve.

# 18.6.5.68 atcacert\_verify\_cert\_sw()

Verify a certificate against its certificate authority's public key using software crypto functions. The function is currently not implemented.

| - | in | cert_def      | Certificate definition describing how to extract the TBS and signature components from the certificate specified. |
|---|----|---------------|-------------------------------------------------------------------------------------------------------------------|
|   | in | cert          | Certificate to verify.                                                                                            |
|   | in | cert_size     | Size of the certificate (cert) in bytes.                                                                          |
|   | in | ca_public_key | The ECC P256 public key of the certificate authority that signed this certificate.                                |
|   |    |               | Formatted as the 32 byte X and Y integers concatenated together (64 bytes total).                                 |

ATCA\_UNIMPLEMENTED, as the function is currently not implemented.

### 18.6.5.69 atcacert\_verify\_response\_hw()

Verify a client's response to a challenge using the host's ATECC device for crypto functions.

The challenge-response protocol is an ECDSA Sign and Verify. This performs an ECDSA verify on the response returned by the client, verifying the client has the private key counter-part to the public key returned in its certificate.

#### **Parameters**

| in | device_public_key | Device public key as read from its certificate. Formatted as the X and Y integers concatenated together. 64 bytes. |
|----|-------------------|--------------------------------------------------------------------------------------------------------------------|
| in | challenge         | Challenge that was sent to the client. 32 bytes.                                                                   |
| in | response          | Response returned from the client to be verified. 64 bytes.                                                        |

### Returns

ATCACERT\_E\_SUCCESS if the verify succeeds, ATCACERT\_VERIFY\_FAILED or ATCA\_EXECUTION\_← ERROR if it fails to verify. ATCA\_EXECUTION\_ERROR may occur when the public key is invalid and doesn't fall on the P256 curve.

### 18.6.5.70 atcacert\_verify\_response\_sw()

Verify a client's response to a challenge using software crypto functions. The function is currently not implemented.

The challenge-response protocol is an ECDSA Sign and Verify. This performs an ECDSA verify on the response returned by the client, verifying the client has the private key counter-part to the public key returned in its certificate.

| in | device_public_key | Device public key as read from its certificate. Formatted as the X and Y integers concatenated together. 64 bytes. |
|----|-------------------|--------------------------------------------------------------------------------------------------------------------|
| in | challenge         | Challenge that was sent to the client. 32 bytes.                                                                   |
| in | response          | Response returned from the client to be verified. 64 bytes.                                                        |

ATCA\_UNIMPLEMENTED , as the function is currently not implemented.

# 18.6.5.71 atcacert\_write\_cert()

Take a full certificate and write it to the ATECC508A device according to the certificate definition.

# **Parameters**

| in | cert_def | Certificate definition describing where the dynamic certificate information is and how to |
|----|----------|-------------------------------------------------------------------------------------------|
|    |          | store it on the device.                                                                   |
| in | cert     | Full certificate to be stored.                                                            |
|    |          |                                                                                           |

## Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 18.6.6 Variable Documentation

## 18.6.6.1 ATCACERT\_DATE\_FORMAT\_SIZES

```
const size_t ATCACERT_DATE_FORMAT_SIZES[5]
```

# 18.7 Basic Crypto API methods for CryptoAuth Devices (calib\_)

These methods provide a simple API to CryptoAuth chips.

#### **Data Structures**

struct atca sha256 ctx

## **Typedefs**

- typedef struct atca\_sha256\_ctx atca\_sha256\_ctx\_t
- typedef atca\_sha256\_ctx\_t atca\_hmac\_sha256\_ctx\_t

#### **Functions**

ATCA STATUS calib wakeup (ATCADevice device)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA STATUS calib idle (ATCADevice device)

idle the CryptoAuth device

ATCA STATUS calib sleep (ATCADevice device)

invoke sleep on the CryptoAuth device

ATCA\_STATUS \_calib\_exit (ATCADevice device)

common cleanup code which idles the device after any operation

ATCA\_STATUS calib\_cfg\_discover (ATCAlfaceCfg cfg\_array[], int max)

auto discovery of crypto auth devices

- ATCA\_STATUS calib\_get\_addr (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint16\_t \*addr)
   Compute the address given the zone, slot, block, and offset.
- ATCA\_STATUS calib\_get\_zone\_size (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t \*size)

  Gets the size of the specified zone in bytes.
- ATCA\_STATUS calib\_aes (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8←
  t \*aes out)

Compute the AES-128 encrypt, decrypt, or GFM calculation.

ATCA\_STATUS calib\_aes\_encrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

ATCA\_STATUS calib\_aes\_decrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

- ATCA\_STATUS calib\_aes\_gfm (ATCADevice device, const uint8\_t \*h, const uint8\_t \*input, uint8\_t \*output)

  Perform a Galois Field Multiply (GFM) operation.
- ATCA\_STATUS calib\_checkmac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_←
   t \*challenge, const uint8\_t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

ATCA\_STATUS calib\_counter (ATCADevice device, uint8\_t mode, uint16\_t counter\_id, uint32\_t \*counter 
 value)

Compute the Counter functions.

ATCA\_STATUS calib\_counter\_increment (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_
 value)

Increments one of the device's monotonic counters.

ATCA\_STATUS calib\_counter\_read (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_value)
 Read one of the device's monotonic counters.

- ATCA\_STATUS calib\_derivekey (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*mac)

  Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.
- ATCA\_STATUS calib\_ecdh\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_ t \*public\_key, uint8\_t \*pms, uint8\_t \*out\_nonce)

Base function for generating premaster secret key using ECDH.

- ATCA\_STATUS calib\_ecdh (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms)

  ECDH command with a private key in a slot and the premaster secret is returned in the clear.
- ATCA\_STATUS calib\_ecdh\_enc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_←
  t \*pms, const uint8 t \*read key, uint16 t read key id, const uint8 t num in[(20)])
- ATCA\_STATUS calib\_ecdh\_ioenc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

- ATCA\_STATUS calib\_ecdh\_tempkey (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms)

  ECDH command with a private key in TempKey and the premaster secret is returned in the clear.
- ATCA\_STATUS calib\_ecdh\_tempkey\_ioenc (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS calib\_gendig (ATCADevice device, uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8 t other data size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

ATCA\_STATUS calib\_genkey\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_
 t \*other\_data, uint8\_t \*public\_key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

ATCA STATUS calib genkey (ATCADevice device, uint16 t key id, uint8 t \*public key)

Issues GenKey command, which generates a new random private key in slot and returns the public key.

ATCA\_STATUS calib\_get\_pubkey (ATCADevice device, uint16\_t key\_id, uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

• ATCA STATUS calib hmac (ATCADevice device, uint8 t mode, uint16 t key id, uint8 t \*digest)

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

- ATCA STATUS calib info base (ATCADevice device, uint8 t mode, uint16 t param2, uint8 t \*out data)
  - Issues an Info command, which return internal device information and can control GPIO and the persistent latch.
- ATCA\_STATUS calib\_info (ATCADevice device, uint8\_t \*revision)

Use the Info command to get the device revision (DevRev).

ATCA STATUS calib info set latch (ATCADevice device, bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

ATCA\_STATUS calib\_info\_get\_latch (ATCADevice device, bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

 ATCA\_STATUS calib\_kdf (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8\_t \*out\_data, uint8\_t \*out\_nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

• ATCA STATUS calib lock (ATCADevice device, uint8 t mode, uint16 t summary crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

ATCA\_STATUS calib\_lock\_config\_zone (ATCADevice device)

Unconditionally (no CRC required) lock the config zone.

ATCA\_STATUS calib\_lock\_config\_zone\_crc (ATCADevice device, uint16\_t summary\_crc)

Lock the config zone with summary CRC.

ATCA STATUS calib lock data zone (ATCADevice device)

Unconditionally (no CRC required) lock the data zone (slots and OTP).

ATCA\_STATUS calib\_lock\_data\_zone\_crc (ATCADevice device, uint16\_t summary\_crc)

Lock the data zone (slots and OTP) with summary CRC.

ATCA STATUS calib lock data slot (ATCADevice device, uint16 t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1).

ATCA\_STATUS calib\_mac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, uint8 t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS calib\_nonce\_base (ATCADevice device, uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

• ATCA STATUS calib nonce (ATCADevice device, const uint8 t \*num in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_nonce\_load (ATCADevice device, uint8\_t target, const uint8\_t \*num\_in, uint16\_←
t num\_in\_size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

ATCA STATUS calib nonce rand (ATCADevice device, const uint8 t \*num in, uint8 t \*rand out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

• ATCA\_STATUS calib\_challenge (ATCADevice device, const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_challenge\_seed\_update (ATCADevice device, const uint8\_t \*num\_in, uint8\_t \*rand
 — out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number

- ATCA\_STATUS calib\_priv\_write (ATCADevice device, uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write key id, const uint8 t write key[32], const uint8 t num in[(20)])
- ATCA\_STATUS calib\_random (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the CryptoAuth device.

ATCA\_STATUS calib\_read\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_←
t offset, uint8\_t \*data, uint8\_t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

ATCA\_STATUS calib\_is\_locked (ATCADevice device, uint8\_t zone, bool \*is\_locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

ATCA STATUS calib is slot locked (ATCADevice device, uint16 t slot, bool \*is locked)

Executes Read command, which reads the configuration zone to see if the specified slot is locked.

 ATCA\_STATUS calib\_read\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset, uint8\_t \*data, size\_t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

• ATCA\_STATUS calib\_read\_serial\_number (ATCADevice device, uint8\_t \*serial\_number)

Executes Read command, which reads the 9 byte serial number of the device from the config zone.

ATCA STATUS calib read pubkey (ATCADevice device, uint16 t slot, uint8 t \*public key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

ATCA\_STATUS calib\_read\_sig (ATCADevice device, uint16\_t slot, uint8\_t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

- ATCA\_STATUS calib\_read\_config\_zone (ATCADevice device, uint8\_t \*config\_data)
  - Executes Read command to read the complete device configuration zone.
- ATCA\_STATUS calib\_cmp\_config\_zone (ATCADevice device, uint8\_t \*config\_data, bool \*same\_config)
   Compares a specified configuration zone with the configuration zone currently on the device.
- ATCA\_STATUS calib\_read\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t block, uint8\_t \*data, const uint8 t \*enc key, const uint16 t enc key id, const uint8 t num in[(20)])
- ATCA\_STATUS calib\_secureboot (ATCADevice device, uint8\_t mode, uint16\_t param2, const uint8\_←
  t \*digest, const uint8\_t \*signature, uint8\_t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

• ATCA\_STATUS calib\_secureboot\_mac (ATCADevice device, uint8\_t mode, const uint8\_t \*digest, const uint8 t \*signature, const uint8 t \*num in, const uint8 t \*io key, bool \*is verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

ATCA\_STATUS calib\_selftest (ATCADevice device, uint8\_t mode, uint16\_t param2, uint8\_t \*result)

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT  $\leftarrow$  ECC608 chip.

ATCA\_STATUS calib\_sha\_base (ATCADevice device, uint8\_t mode, uint16\_t length, const uint8\_t \*data\_in, uint8\_t \*data\_out, uint16\_t \*data\_out\_size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

• ATCA STATUS calib sha start (ATCADevice device)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA\_STATUS calib\_sha\_update (ATCADevice device, const uint8\_t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

 ATCA\_STATUS calib\_sha\_end (ATCADevice device, uint8\_t \*digest, uint16\_t length, const uint8\_← t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

- ATCA\_STATUS calib\_sha\_read\_context (ATCADevice device, uint8\_t \*context, uint16\_t \*context\_size)
   Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.
- ATCA\_STATUS calib\_sha\_write\_context (ATCADevice device, const uint8\_t \*context, uint16\_t context\_size)
   Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.
- ATCA\_STATUS calib\_sha (ATCADevice device, uint16\_t length, const uint8\_t \*message, uint8\_t \*digest)

  Use the SHA command to compute a SHA-256 digest.
- ATCA\_STATUS calib\_hw\_sha2\_256 (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint8\_
   t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA STATUS calib hw sha2 256 init (ATCADevice device, atca sha256 ctx t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

ATCA\_STATUS calib\_hw\_sha2\_256\_update (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, const uint8\_←
 t \*data, size\_t data\_size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

- ATCA\_STATUS calib\_hw\_sha2\_256\_finish (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, uint8\_t \*digest)

  Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.
- ATCA\_STATUS calib\_sha\_hmac\_init (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_
   slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_update (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8
 — t \*data, size\_t data\_size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_finish (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_←
 t \*digest, uint8 t target)

Executes SHA command to complete a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint16\_t key
 —slot, uint8\_t \*digest, uint8\_t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sign\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, uint8\_t \*signature)

Executes the Sign command, which generates a signature using the ECDSA algorithm.

ATCA STATUS calib sign (ATCADevice device, uint16 t key id, const uint8 t \*msq, uint8 t \*signature)

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

 ATCA\_STATUS calib\_sign\_internal (ATCADevice device, uint16\_t key\_id, bool is\_invalidate, bool is\_full\_sn, uint8\_t \*signature)

Executes Sign command to sign an internally generated message.

ATCA STATUS calib updateextra (ATCADevice device, uint8 t mode, uint16 t new value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

ATCA\_STATUS calib\_verify (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS calib\_verify\_extern (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public\_key, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS calib\_verify\_extern\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_←
t \*signature, const uint8\_t \*public\_key, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

ATCA\_STATUS calib\_verify\_stored (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp Key for other devices.

• ATCA\_STATUS calib\_verify\_stored\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_← t \*signature, uint16\_t key\_id, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

ATCA\_STATUS calib\_verify\_validate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

• ATCA\_STATUS calib\_verify\_invalidate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

 ATCA\_STATUS calib\_write (ATCADevice device, uint8\_t zone, uint16\_t address, const uint8\_t \*value, const uint8\_t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

• ATCA\_STATUS calib\_write\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_ t offset, const uint8\_t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

• ATCA\_STATUS calib\_write\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

- ATCA\_STATUS calib\_write\_pubkey (ATCADevice device, uint16\_t slot, const uint8\_t \*public\_key)
  - Uses the write command to write a public key to a slot in the proper format.
- ATCA\_STATUS calib\_write\_config\_zone (ATCADevice device, const uint8\_t \*config\_data)
  - Executes the Write command, which writes the configuration zone.
- ATCA\_STATUS calib\_write\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])
- ATCA\_STATUS calib\_write\_config\_counter (ATCADevice device, uint16\_t counter\_id, uint32\_t counter\_
   value)

Initialize one of the monotonic counters in device with a specific value.

const char \* atca\_basic\_aes\_gcm\_version = "2.0"

# 18.7.1 Detailed Description

These methods provide a simple API to CryptoAuth chips.

# 18.7.2 Typedef Documentation

```
18.7.2.1 atca_hmac_sha256_ctx_t
```

```
typedef atca_sha256_ctx_t atca_hmac_sha256_ctx_t
```

### 18.7.2.2 atca\_sha256\_ctx\_t

```
typedef struct atca_sha256_ctx atca_sha256_ctx_t
```

### 18.7.3 Function Documentation

### 18.7.3.1 \_calib\_exit()

```
ATCA_STATUS _calib_exit (
ATCADevice device )
```

common cleanup code which idles the device after any operation

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 206

## **Parameters**

| in d | levice | Device context pointer |
|------|--------|------------------------|
|------|--------|------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.2 calib\_aes()

Compute the AES-128 encrypt, decrypt, or GFM calculation.

### **Parameters**

| in  | device  | Device context pointer                                                       |
|-----|---------|------------------------------------------------------------------------------|
| in  | mode    | The mode for the AES command.                                                |
| in  | key_id  | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey. |
| in  | aes_in  | Input data to the AES command (16 bytes).                                    |
| out | aes_out | Output data from the AES command is returned here (16 bytes).                |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.3 calib\_aes\_decrypt()

Perform an AES-128 decrypt operation with a key in the device.

| in                        | device     | Device context pointer                                                        |   |
|---------------------------|------------|-------------------------------------------------------------------------------|---|
| in                        | key_id     | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |   |
| in<br>© 2020 <b>Mic</b> r | key_block  | Index of the 16-byte block to use within the key location for the actual key. | 2 |
| in                        | ciphertext | Input ciphertext to be decrypted (16 bytes).                                  |   |
| out                       | plaintext  | Output plaintext is returned here (16 bytes).                                 | ] |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.4 calib\_aes\_encrypt()

Perform an AES-128 encrypt operation with a key in the device.

#### **Parameters**

| in  | device     | Device context pointer                                                        |
|-----|------------|-------------------------------------------------------------------------------|
| in  | key_id     | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |
| in  | key_block  | Index of the 16-byte block to use within the key location for the actual key. |
| in  | plaintext  | Input plaintext to be encrypted (16 bytes).                                   |
| out | ciphertext | Output ciphertext is returned here (16 bytes).                                |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.5 calib\_aes\_gfm()

Perform a Galois Field Multiply (GFM) operation.

| in  | device | Device context pointer                  |
|-----|--------|-----------------------------------------|
| in  | h      | First input value (16 bytes).           |
| in  | input  | Second input value (16 bytes).          |
| out | output | GFM result is returned here (16 bytes). |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.6 calib\_cfg\_discover()

auto discovery of crypto auth devices

Calls interface discovery functions and fills in cfg\_array up to the maximum number of configurations either found or the size of the array. The cfg\_array can have a mixture of interface types (ie: some I2C, some SWI or UART) depending upon which interfaces you've enabled

#### **Parameters**

| out | cfg_array  | ptr to an array of interface configs |
|-----|------------|--------------------------------------|
| in  | max_ifaces | maximum size of cfg_array            |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.7 calib\_challenge()

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

#### **Parameters**

| in | device | Device context pointer                     |
|----|--------|--------------------------------------------|
| in | num←   | Data to be loaded into TempKey (32 bytes). |
|    | in     |                                            |

#### Returns

## 18.7.3.8 calib\_challenge\_seed\_update()

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number.

### **Parameters**

| in  | device   | Device context pointer                                                                                                                   |
|-----|----------|------------------------------------------------------------------------------------------------------------------------------------------|
| in  | num_in   | Host nonce to be combined with the device random number (20 bytes).                                                                      |
| out | rand_out | Internally generated 32-byte random number that was used in the nonce/challenge calculation is returned here. Can be NULL if not needed. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.9 calib\_checkmac()

```
ATCA_STATUS calib_checkmac (
    ATCADevice device,
    uint8_t mode,
    uint16_t key_id,
    const uint8_t * challenge,
    const uint8_t * response,
    const uint8_t * other_data)
```

Compares a MAC response with input values.

## **Parameters**

| in | device     | Device context pointer                                          |
|----|------------|-----------------------------------------------------------------|
| in | mode       | Controls which fields within the device are used in the message |
| in | key_id     | Key location in the CryptoAuth device to use for the MAC        |
| in | challenge  | Challenge data (32 bytes)                                       |
| in | response   | MAC response data (32 bytes)                                    |
| in | other_data | OtherData parameter (13 bytes)                                  |

### Returns

### 18.7.3.10 calib\_cmp\_config\_zone()

Compares a specified configuration zone with the configuration zone currently on the device.

This only compares the static portions of the configuration zone and skips those that are unique per device (first 16 bytes) and areas that can change after the configuration zone has been locked (e.g. LastKeyUse).

#### **Parameters**

| in  | device      | Device context pointer                                                                  |
|-----|-------------|-----------------------------------------------------------------------------------------|
| in  | config_data | Full configuration data to compare the device against.                                  |
| out | same_config | Result is returned here. True if the static portions on the configuration zones are the |
|     |             | same.                                                                                   |

### Returns

ATCA SUCCESS on success, otherwise an error code.

Max for all configs

# 18.7.3.11 calib\_counter()

Compute the Counter functions.

## **Parameters**

|   | in  | device        | Device context pointer                            |
|---|-----|---------------|---------------------------------------------------|
|   | in  | mode          | the mode used for the counter                     |
| ĺ | in  | counter_id    | The counter to be used                            |
| ĺ | out | counter_value | pointer to the counter value returned from device |

### Returns

# 18.7.3.12 calib\_counter\_increment()

```
ATCA_STATUS calib_counter_increment (

ATCADevice device,

uint16_t counter_id,

uint32_t * counter_value )
```

Increments one of the device's monotonic counters.

### **Parameters**

| in  | device        | Device context pointer                                                |
|-----|---------------|-----------------------------------------------------------------------|
| in  | counter_id    | Counter to be incremented                                             |
| out | counter_value | New value of the counter is returned here. Can be NULL if not needed. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.13 calib\_counter\_read()

Read one of the device's monotonic counters.

### **Parameters**

| in  | device        | Device context pointer          |
|-----|---------------|---------------------------------|
| in  | counter_id    | Counter to be read              |
| out | counter_value | Counter value is returned here. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.14 calib\_derivekey()

```
ATCA_STATUS calib_derivekey (
    ATCADevice device,
    uint8_t mode,
    uint16_t target_key,
    const uint8_t * mac)
```

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

### **Parameters**

| in | device     | Device context pointer                                                 |
|----|------------|------------------------------------------------------------------------|
| in | mode       | Bit 2 must match the value in TempKey.SourceFlag                       |
| in | target_key | Key slot to be written                                                 |
| in | mac        | Optional 32 byte MAC used to validate operation. NULL if not required. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.15 calib\_ecdh()

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

### **Parameters**

| in  | device     | Device context pointer                                                                              |
|-----|------------|-----------------------------------------------------------------------------------------------------|
| in  | key_id     | Slot of key for ECDH computation                                                                    |
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms        | Computed ECDH premaster secret is returned here. 32 bytes.                                          |

#### Returns

ATCA\_SUCCESS on success

## 18.7.3.16 calib\_ecdh\_base()

Base function for generating premaster secret key using ECDH.

### **Parameters**

| in  | device     | Device context pointer                                                                              |
|-----|------------|-----------------------------------------------------------------------------------------------------|
| in  | mode       | Mode to be used for ECDH computation                                                                |
| in  | key_id     | Slot of key for ECDH computation                                                                    |
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms        | Computed ECDH pre-master secret is returned here (32 bytes) if returned directly. Otherwise NULL.   |
| out | out_nonce  | Nonce used to encrypt pre-master secret. NULL if output encryption not used.                        |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.17 calib\_ecdh\_enc()

## 18.7.3.18 calib\_ecdh\_ioenc()

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

| in  | device     | Device context pointer                                                                              |
|-----|------------|-----------------------------------------------------------------------------------------------------|
| in  | key_id     | Slot of key for ECDH computation                                                                    |
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                                         |
| in  | io_key     | IO protection key.                                                                                  |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.19 calib\_ecdh\_tempkey()

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

#### **Parameters**

| in  | device     | Device context pointer                                                                              |
|-----|------------|-----------------------------------------------------------------------------------------------------|
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                                         |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.20 calib ecdh tempkey ioenc()

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.

### **Parameters**

| in  | device     | Device context pointer                                                                    |
|-----|------------|-------------------------------------------------------------------------------------------|
| in  | public_key | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for |
|     |            | P256 key.                                                                                 |
| out | pms        | Computed ECDH premaster secret is returned here (32 bytes).                               |
| in  | io_key     | IO protection key.                                                                        |

## Returns

## 18.7.3.21 calib\_gendig()

```
ATCA_STATUS calib_gendig (
    ATCADevice device,
    uint8_t zone,
    uint16_t key_id,
    const uint8_t * other_data,
    uint8_t other_data_size )
```

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

#### **Parameters**

| in | device          | Device context pointer                                                                                                            |
|----|-----------------|-----------------------------------------------------------------------------------------------------------------------------------|
| in | zone            | Designates the source of the data to hash with TempKey.                                                                           |
| in | key_id          | Indicates the key, OTP block, or message order for shared nonce mode.                                                             |
| in | other_data      | Four bytes of data for SHA calculation when using a NoMac key, 32 bytes for "Shared Nonce" mode, otherwise ignored (can be NULL). |
| in | other_data_size | Size of other_data in bytes.                                                                                                      |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.22 calib\_genkey()

Issues GenKey command, which generates a new random private key in slot and returns the public key.

#### **Parameters**

| in  | device     | Device context pointer                                                                                                                                         |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | key_id     | Slot number where an ECC private key is configured. Can also be ATCA_TEMPKEY_KEYID to generate a private key in TempKey.                                       |
| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve. Set to NULL if public key isn't required. |

## Returns

# 18.7.3.23 calib\_genkey\_base()

```
ATCA_STATUS calib_genkey_base (
    ATCADevice device,
    uint8_t mode,
    uint16_t key_id,
    const uint8_t * other_data,
    uint8_t * public_key )
```

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

### **Parameters**

| in  | device     | Device context pointer                                                                                                                                                                                        |
|-----|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | mode       | Mode determines what operations the GenKey command performs.                                                                                                                                                  |
| in  | key_id     | Slot to perform the GenKey command on.                                                                                                                                                                        |
| in  | other_data | OtherData for PubKey digest calculation. Can be set to NULL otherwise.                                                                                                                                        |
| out | public_key | If the mode indicates a public key will be calculated, it will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve. Set to NULL if public key isn't required. |

### Returns

ATCA SUCCESS on success, otherwise an error code.

# 18.7.3.24 calib\_get\_addr()

Compute the address given the zone, slot, block, and offset.

### **Parameters**

| in  | zone   | Zone to get address from. Config(0), OTP(1), or Data(2) which requires a slot. |
|-----|--------|--------------------------------------------------------------------------------|
| in  | slot   | Slot Id number for data zone and zero for other zones.                         |
| in  | block  | Block number within the data or configuration or OTP zone .                    |
| in  | offset | Offset Number within the block of data or configuration or OTP zone.           |
| out | addr   | Pointer to the address of data or configuration or OTP zone.                   |

## Returns

## 18.7.3.25 calib\_get\_pubkey()

Uses GenKey command to calculate the public key from an existing private key in a slot.

### **Parameters**

| in  | device     | Device context pointer                                                                                                                                         |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | key_id     | Slot number of the private key.                                                                                                                                |
| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve. Set to NULL if public key isn't required. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.26 calib\_get\_zone\_size()

Gets the size of the specified zone in bytes.

# **Parameters**

| in  | device | Device context pointer                                                                  |
|-----|--------|-----------------------------------------------------------------------------------------|
| in  | zone   | Zone to get size information from. Config(0), OTP(1), or Data(2) which requires a slot. |
| in  | slot   | If zone is Data(2), the slot to query for size.                                         |
| out | size   | Zone size is returned here.                                                             |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.27 calib\_hmac()

```
ATCA_STATUS calib_hmac (
ATCADevice device,
```

```
uint8_t mode,
uint16_t key_id,
uint8_t * digest )
```

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

#### **Parameters**

| in  | device      | Device context pointer                                                                                                                  |  |
|-----|-------------|-----------------------------------------------------------------------------------------------------------------------------------------|--|
| in  | mode        | Controls which fields within the device are used in the message.                                                                        |  |
| in  | key⊷<br>_id | Which key is to be used to generate the response. Bits 0:3 only are used to select a slot but all 16 bits are used in the HMAC message. |  |
| out | digest      | HMAC digest is returned in this buffer (32 bytes).                                                                                      |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.28 calib\_hw\_sha2\_256()

```
ATCA_STATUS calib_hw_sha2_256 (
    ATCADevice device,
    const uint8_t * data,
    size_t data_size,
    uint8_t * digest )
```

Use the SHA command to compute a SHA-256 digest.

### **Parameters**

| in  | device    | Device context pointer              |
|-----|-----------|-------------------------------------|
| in  | data      | Message data to be hashed.          |
| in  | data_size | Size of data in bytes.              |
| out | digest    | Digest is returned here (32 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.29 calib\_hw\_sha2\_256\_finish()

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

| in  | device | Device context pointer                    |
|-----|--------|-------------------------------------------|
| in  | ctx    | SHA256 context                            |
| out | digest | SHA256 digest is returned here (32 bytes) |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.30 calib\_hw\_sha2\_256\_init()

```
ATCA_STATUS calib_hw_sha2_256_init (

ATCADevice device,

atca_sha256_ctx_t * ctx )
```

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

### **Parameters**

| in | device | Device context pointer |
|----|--------|------------------------|
| in | ctx    | SHA256 context         |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.31 calib\_hw\_sha2\_256\_update()

```
ATCA_STATUS calib_hw_sha2_256_update (
    ATCADevice device,
    atca_sha256_ctx_t * ctx,
    const uint8_t * data,
    size_t data_size)
```

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

| in | device    | Device context pointer            |
|----|-----------|-----------------------------------|
| in | ctx       | SHA256 context                    |
| in | data      | Message data to be added to hash. |
| in | data_size | Size of data in bytes.            |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.32 calib\_idle()

```
ATCA_STATUS calib_idle (
ATCADevice device)
```

idle the CryptoAuth device

### **Parameters**

| in <i>device</i> | Device context pointer |
|------------------|------------------------|
|------------------|------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.33 calib\_info()

Use the Info command to get the device revision (DevRev).

### **Parameters**

| in  | device   | Device context pointer                      |
|-----|----------|---------------------------------------------|
| out | revision | Device revision is returned here (4 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.34 calib\_info\_base()

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

| in  | device   | Device context pointer                                                    |
|-----|----------|---------------------------------------------------------------------------|
| in  | mode     | Selects which mode to be used for info command.                           |
| in  | param2   | Selects the particular fields for the mode.                               |
| out | out_data | Response from info command (4 bytes). Can be set to NULL if not required. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.35 calib\_info\_get\_latch()

Use the Info command to get the persistent latch current state for an ATECC608 device.

### **Parameters**

| in |             | device | Device context pointer                                  |
|----|-------------|--------|---------------------------------------------------------|
| ou | .t <b>s</b> | state  | The state is returned here. Set (true) or Cler (false). |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.36 calib\_info\_set\_latch()

Use the Info command to set the persistent latch state for an ATECC608 device.

# **Parameters**

| in              | device  | Device context pointer                               |
|-----------------|---------|------------------------------------------------------|
| ou <sup>-</sup> | t state | Persistent latch state. Set (true) or clear (false). |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 222

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.37 calib\_is\_locked()

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

### **Parameters**

| in  | device    | Device context pointer                                                 |
|-----|-----------|------------------------------------------------------------------------|
| in  | zone      | The zone to query for locked (use LOCK_ZONE_CONFIG or LOCK_ZONE_DATA). |
| out | is_locked | Lock state returned here. True if locked.                              |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.38 calib\_is\_slot\_locked()

Executes Read command, which reads the configuration zone to see if the specified slot is locked.

#### **Parameters**

| in  | device    | Device context pointer                    |
|-----|-----------|-------------------------------------------|
| in  | slot      | Slot to query for locked (slot 0-15)      |
| out | is_locked | Lock state returned here. True if locked. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.39 calib\_kdf()

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

Generally this function combines a source key with an input string and creates a result key/digest/array.

#### **Parameters**

| in  | device    | Device context pointer                                                                                                                                                  |
|-----|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | mode      | Mode determines KDF algorithm (PRF,AES,HKDF), source key location, and target key locations.                                                                            |
| in  | key_id    | Source and target key slots if locations are in the EEPROM. Source key slot is the LSB and target key slot is the MSB.                                                  |
| in  | details   | Further information about the computation, depending on the algorithm (4 bytes).                                                                                        |
| in  | message   | Input value from system (up to 128 bytes). Actual size of message is 16 bytes for AES algorithm or is encoded in the MSB of the details parameter for other algorithms. |
| out | out_data  | Output of the KDF function is returned here. If the result remains in the device, this can be NULL.                                                                     |
| out | out_nonce | If the output is encrypted, a 32 byte random nonce generated by the device is returned here. If output encryption is not used, this can be NULL.                        |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.40 calib\_lock()

```
ATCA_STATUS calib_lock (

ATCADevice device,

uint8_t mode,

uint16_t summary_crc )
```

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

| in | device      | Device context pointer                                                             |
|----|-------------|------------------------------------------------------------------------------------|
| in | mode        | Zone, and/or slot, and summary check (bit 7).                                      |
| in | summary_crc | CRC of the config or data zones. Ignored for slot locks or when mode bit 7 is set. |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.41 calib\_lock\_config\_zone()

Unconditionally (no CRC required) lock the config zone.

### **Parameters**

### Returns

ATCA SUCCESS on success, otherwise an error code.

## 18.7.3.42 calib\_lock\_config\_zone\_crc()

Lock the config zone with summary CRC.

The CRC is calculated over the entire config zone contents. 88 bytes for ATSHA devices, 128 bytes for ATECC devices. Lock will fail if the provided CRC doesn't match the internally calculated one.

### **Parameters**

| in | device      | Device context pointer             |
|----|-------------|------------------------------------|
| in | summary_crc | Expected CRC over the config zone. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.43 calib\_lock\_data\_slot()

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1).

#### **Parameters**

| in | device | Device context pointer          |
|----|--------|---------------------------------|
| in | slot   | Slot to be locked in data zone. |

#### Returns

ATCA SUCCESS on success, otherwise an error code.

## 18.7.3.44 calib\_lock\_data\_zone()

Unconditionally (no CRC required) lock the data zone (slots and OTP).

ConfigZone must be locked and DataZone must be unlocked for the zone to be successfully locked.

#### **Parameters**

| in <i>device</i> | Device context pointer |
|------------------|------------------------|
|------------------|------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.45 calib\_lock\_data\_zone\_crc()

Lock the data zone (slots and OTP) with summary CRC.

The CRC is calculated over the concatenated contents of all the slots and OTP at the end. Private keys (Key← Config.Private=1) are skipped. Lock will fail if the provided CRC doesn't match the internally calculated one.

| in | device      | Device context pointer           |
|----|-------------|----------------------------------|
| in | summary_crc | Expected CRC over the data zone. |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.46 calib\_mac()

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

### **Parameters**

| in  | device    | Device context pointer                                                                  |  |
|-----|-----------|-----------------------------------------------------------------------------------------|--|
| in  | mode      | node Controls which fields within the device are used in the message                    |  |
| in  | key_id    | Key in the CryptoAuth device to use for the MAC                                         |  |
| in  | challenge | Challenge message (32 bytes). May be NULL if mode indicates a challenge isn't required. |  |
| out | digest    | MAC response is returned here (32 bytes).                                               |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.47 calib\_nonce()

```
ATCA_STATUS calib_nonce (

ATCADevice device,

const uint8_t * num_in )
```

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

#### **Parameters**

| in | device | Device context pointer                     |
|----|--------|--------------------------------------------|
| in | num⊷   | Data to be loaded into TempKey (32 bytes). |
|    | _in    |                                            |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.48 calib\_nonce\_base()

```
ATCA_STATUS calib_nonce_base (
    ATCADevice device,
    uint8_t mode,
    uint16_t zero,
    const uint8_t * num_in,
    uint8_t * rand_out )
```

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

#### **Parameters**

| in  | device   | Device context pointer                                                                                                                                                 |  |
|-----|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| in  | mode     | Controls the mechanism of the internal RNG or fixed write.                                                                                                             |  |
| in  | zero     | Param2, normally 0, but can be used to indicate a nonce calculation mode (bit 15).                                                                                     |  |
| in  | num_in   | Input value to either be included in the nonce calculation in random modes (20 bytes) or to be written directly (32 bytes or 64 bytes(ATECC608)) in pass-through mode. |  |
| out | rand_out | If using a random mode, the internally generated 32-byte random number that was used in the nonce calculation is returned here. Can be NULL if not needed.             |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.49 calib\_nonce\_load()

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

For the ATECC608, available targets are TempKey (32 or 64 bytes), Message Digest Buffer (32 or 64 bytes), or the Alternate Key Buffer (32 bytes). For all other devices, only TempKey (32 bytes) is available.

## **Parameters**

| in | device      | Device context pointer                                                         |
|----|-------------|--------------------------------------------------------------------------------|
| in | target      | Target device buffer to load. Can be NONCE_MODE_TARGET_TEMPKEY,                |
|    |             | NONCE_MODE_TARGET_MSGDIGBUF, or NONCE_MODE_TARGET_ALTKEYBUF.                   |
| in | num_in      | Data to load into the buffer.                                                  |
| in | num_in_size | Size of num_in in bytes. Can be 32 or 64 bytes depending on device and target. |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 228

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.50 calib\_nonce\_rand()

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

#### **Parameters**

|   | in  | device   | Device context pointer                                                          |
|---|-----|----------|---------------------------------------------------------------------------------|
| Ī | in  | num_in   | Host nonce to be combined with the device random number (20 bytes).             |
| Ī | out | rand_out | Internally generated 32-byte random number that was used in the nonce/challenge |
|   |     |          | calculation is returned here. Can be NULL if not needed.                        |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.51 calib\_priv\_write()

## 18.7.3.52 calib\_random()

```
ATCA_STATUS calib_random (

ATCADevice device,

uint8_t * rand_out )
```

Executes Random command, which generates a 32 byte random number from the CryptoAuth device.

| in  | device   | Device context pointer                    |
|-----|----------|-------------------------------------------|
| out | rand_out | 32 bytes of random data is returned here. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.53 calib\_read\_bytes\_zone()

Used to read an arbitrary number of bytes from any zone configured for clear reads.

This function will issue the Read command as many times as is required to read the requested data.

## **Parameters**

| in  | device | Device context pointer                                                                          |
|-----|--------|-------------------------------------------------------------------------------------------------|
| in  | zone   | Zone to read data from. Option are ATCA_ZONE_CONFIG(0), ATCA_ZONE_OTP(1), or ATCA_ZONE_DATA(2). |
| in  | slot   | Slot number to read from if zone is ATCA_ZONE_DATA(2). Ignored for all other zones.             |
| in  | offset | Byte offset within the zone to read from.                                                       |
| out | data   | Read data is returned here.                                                                     |
| in  | length | Number of bytes to read starting from the offset.                                               |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.54 calib\_read\_config\_zone()

Executes Read command to read the complete device configuration zone.

| in  | device      | Device context pointer                                                                             |
|-----|-------------|----------------------------------------------------------------------------------------------------|
| out | config_data | Configuration zone data is returned here. 88 bytes for ATSHA devices, 128 bytes for ATECC devices. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.55 calib\_read\_enc()

```
ATCA_STATUS calib_read_enc (
    ATCADevice device,
    uint16_t key_id,
    uint8_t block,
    uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[(20)])
```

# 18.7.3.56 calib\_read\_pubkey()

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

This function assumes the public key is stored using the ECC public key format specified in the datasheet.

#### **Parameters**

| in  | device     | Device context pointer                                                                                       |
|-----|------------|--------------------------------------------------------------------------------------------------------------|
| in  | slot       | Slot number to read from. Only slots 8 to 15 are large enough for a public key.                              |
| out | public_key | Public key is returned here (64 bytes). Format will be the 32 byte X and Y big-endian integers concatenated. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.57 calib\_read\_serial\_number()

Executes Read command, which reads the 9 byte serial number of the device from the config zone.

### **Parameters**

| in <i>device</i> |               | Device context pointer                 |  |
|------------------|---------------|----------------------------------------|--|
| out              | serial_number | 9 byte serial number is returned here. |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.58 calib\_read\_sig()

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

## **Parameters**

| in  | device | Device context pointer                                                                                           |
|-----|--------|------------------------------------------------------------------------------------------------------------------|
| in  | slot   | Slot number to read from. Only slots 8 to 15 are large enough for a signature.                                   |
| out | sig    | Signature will be returned here (64 bytes). Format will be the 32 byte R and S big-endian integers concatenated. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.59 calib\_read\_zone()

```
uint8_t * data,
uint8_t len )
```

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

When reading a slot or OTP, data zone must be locked and the slot configuration must not be secret for a slot to be successfully read.

#### **Parameters**

| in  | device | Device context pointer                                                                       |
|-----|--------|----------------------------------------------------------------------------------------------|
| in  | zone   | Zone to be read from device. Options are ATCA_ZONE_CONFIG, ATCA_ZONE_OTP, or ATCA_ZONE_DATA. |
|     |        | ATOA_ZONE_DATA.                                                                              |
| in  | slot   | Slot number for data zone and ignored for other zones.                                       |
| in  | block  | 32 byte block index within the zone.                                                         |
| in  | offset | 4 byte work index within the block. Ignored for 32 byte reads.                               |
| out | data   | Read data is returned here.                                                                  |
| in  | len    | Length of the data to be read. Must be either 4 or 32.                                       |

returns ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.60 calib\_secureboot()

```
ATCA_STATUS calib_secureboot (
    ATCADevice device,
    uint8_t mode,
    uint16_t param2,
    const uint8_t * digest,
    const uint8_t * signature,
    uint8_t * mac)
```

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

## **Parameters**

| in  | device    | Device context pointer                                                                      |
|-----|-----------|---------------------------------------------------------------------------------------------|
| in  | mode      | Mode determines what operations the SecureBoot command performs.                            |
| in  | param2    | Not used, must be 0.                                                                        |
| in  | digest    | Digest of the code to be verified (32 bytes).                                               |
| in  | signature | Signature of the code to be verified (64 bytes). Can be NULL when using the FullStore mode. |
| out | тас       | Validating MAC will be returned here (32 bytes). Can be NULL if not required.               |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.61 calib\_secureboot\_mac()

```
ATCA_STATUS calib_secureboot_mac (
    ATCADevice device,
    uint8_t mode,
    const uint8_t * digest,
    const uint8_t * signature,
    const uint8_t * num_in,
    const uint8_t * io_key,
    bool * is_verified )
```

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

#### **Parameters**

| in  | device      | Device context pointer                                                                      |
|-----|-------------|---------------------------------------------------------------------------------------------|
| in  | mode        | Mode determines what operations the SecureBoot command performs.                            |
| in  | digest      | Digest of the code to be verified (32 bytes). This is the plaintext digest (not encrypted). |
| in  | signature   | Signature of the code to be verified (64 bytes). Can be NULL when using the FullStore       |
|     |             | mode.                                                                                       |
| in  | num_in      | Host nonce (20 bytes).                                                                      |
| in  | io_key      | IO protection key (32 bytes).                                                               |
| out | is_verified | Verify result is returned here.                                                             |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.62 calib\_selftest()

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the ATECC608 chip.

|   | in  | device | Device context pointer                                                                                                                                                                                                         |
|---|-----|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | in  | mode   | Functions to test. Can be a bit field combining any of the following:  SELFTEST_MODE_RNG, SELFTEST_MODE_ECDSA_VERIFY,  SELFTEST_MODE_ECDSA_SIGN, SELFTEST_MODE_ECDH, SELFTEST_MODE_AES,  SELFTEST_MODE_SHA, SELFTEST_MODE_ALL. |
|   | in  | param2 | Currently unused, should be 0.                                                                                                                                                                                                 |
| İ | out | result | Results are returned here as a bit field.                                                                                                                                                                                      |

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.63 calib\_sha()

Use the SHA command to compute a SHA-256 digest.

#### **Parameters**

| in  | device  | Device context pointer              |
|-----|---------|-------------------------------------|
| in  | length  | Size of message parameter in bytes. |
| in  | message | Message data to be hashed.          |
| out | digest  | Digest is returned here (32 bytes). |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.64 calib\_sha\_base()

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

Only the Start(0) and Compute(1) modes are available for ATSHA devices.

| in | device | Device context pointer                                                                                                                                                                 |
|----|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in | mode   | SHA command mode Start(0), Update/Compute(1), End(2), Public(3), HMACstart(4), HMACend(5), Read_Context(6), or Write_Context(7). Also message digest target location for the ATECC608. |
| in | length | Number of bytes in the message parameter or KeySlot for the HMAC key if Mode is HMACstart(4) or Public(3).                                                                             |

| in     | message       | Message bytes to be hashed or Write_Context if restoring a context on the ATECC608. Can be NULL if not required by the mode. |  |
|--------|---------------|------------------------------------------------------------------------------------------------------------------------------|--|
| out    | data_out      | Data returned by the command (digest or context).                                                                            |  |
| in,out | data_out_size | As input, the size of the data_out buffer. As output, the number of bytes returned                                           |  |
|        |               | in data_out.                                                                                                                 |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.65 calib\_sha\_end()

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

## **Parameters**

| in  | device  | Device context pointer                                                |
|-----|---------|-----------------------------------------------------------------------|
| out | digest  | Digest from SHA-256 or HMAC/SHA-256 will be returned here (32 bytes). |
| in  | length  | Length of any remaining data to include in hash. Max 64 bytes.        |
| in  | message | Remaining data to include in hash. NULL if length is 0.               |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.66 calib\_sha\_hmac()

Use the SHA command to compute an HMAC/SHA-256 operation.

| in  | device    | Device context pointer                                                                                                                                                                                                    |
|-----|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | data      | Message data to be hashed.                                                                                                                                                                                                |
| in  | data_size | Size of data in bytes.                                                                                                                                                                                                    |
| in  | key_slot  | Slot key id to use for the HMAC calculation                                                                                                                                                                               |
| out | digest    | Digest is returned here (32 bytes).                                                                                                                                                                                       |
| in  | target    | Where to save the digest internal to the device. For ATECC608, can be SHA_MODE_TARGET_TEMPKEY, SHA_MODE_TARGET_MSGDIGBUF, or SHA_MODE_TARGET_OUT_ONLY. For all other devices, SHA_MODE_TARGET_TEMPKEY is the only option. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.67 calib\_sha\_hmac\_finish()

```
ATCA_STATUS calib_sha_hmac_finish (
    ATCADevice device,
    atca_hmac_sha256_ctx_t * ctx,
    uint8_t * digest,
    uint8_t target )
```

Executes SHA command to complete a HMAC/SHA-256 operation.

## **Parameters**

| in  | device | Device context pointer                                                                                                                                                                                                    |  |
|-----|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| in  | ctx    | HMAC/SHA-256 context                                                                                                                                                                                                      |  |
| out | digest | HMAC/SHA-256 result is returned here (32 bytes).                                                                                                                                                                          |  |
| in  | target | Where to save the digest internal to the device. For ATECC608, can be SHA_MODE_TARGET_TEMPKEY, SHA_MODE_TARGET_MSGDIGBUF, or SHA_MODE_TARGET_OUT_ONLY. For all other devices, SHA_MODE_TARGET_TEMPKEY is the only option. |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.68 calib\_sha\_hmac\_init()

Executes SHA command to start an HMAC/SHA-256 operation.

| in | device   | Device context pointer                      |
|----|----------|---------------------------------------------|
| in | ctx      | HMAC/SHA-256 context                        |
| in | key_slot | Slot key id to use for the HMAC calculation |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.69 calib\_sha\_hmac\_update()

```
ATCA_STATUS calib_sha_hmac_update (
    ATCADevice device,
    atca_hmac_sha256_ctx_t * ctx,
    const uint8_t * data,
    size_t data_size )
```

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

#### **Parameters**

| in | device    | Device context pointer        |
|----|-----------|-------------------------------|
| in | ctx       | HMAC/SHA-256 context          |
| in | data      | Message data to add           |
| in | data_size | Size of message data in bytes |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.70 calib\_sha\_read\_context()

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

| in                                                                                                          | device         | Device context pointer         |  |
|-------------------------------------------------------------------------------------------------------------|----------------|--------------------------------|--|
| out                                                                                                         | context        | Context data is returned here. |  |
| in, out context_size As input, the size of the context buffer in bytes. As output, the size of the returned |                |                                |  |
| © 2020 Microchin                                                                                            | Toohnology Inc | context data.                  |  |

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.71 calib\_sha\_start()

```
ATCA_STATUS calib_sha_start (
ATCADevice device)
```

Executes SHA command to initialize SHA-256 calculation engine.

### **Parameters**

| in <i>device</i> | Device context pointer |
|------------------|------------------------|
|------------------|------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.72 calib\_sha\_update()

Executes SHA command to add 64 bytes of message data to the current context.

### **Parameters**

| in | device  | Device context pointer                               |
|----|---------|------------------------------------------------------|
| in | message | 64 bytes of message data to add to add to operation. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.73 calib\_sha\_write\_context()

Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.

| in | device       | Device context pointer             |
|----|--------------|------------------------------------|
| in | context      | Context data to be restored.       |
| in | context_size | Size of the context data in bytes. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.74 calib\_sign()

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

#### **Parameters**

| in  | device    | Device context pointer                                                                     |
|-----|-----------|--------------------------------------------------------------------------------------------|
| in  | key_id    | Slot of the private key to be used to sign the message.                                    |
| in  | msg       | 32-byte message to be signed. Typically the SHA256 hash of the full message.               |
| out | signature | Signature will be returned here. Format is R and S integers in big-endian format. 64 bytes |
|     |           | for P256 curve.                                                                            |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.75 calib\_sign\_base()

Executes the Sign command, which generates a signature using the ECDSA algorithm.

| in  | device    | Device context pointer                                                                                |
|-----|-----------|-------------------------------------------------------------------------------------------------------|
| in  | mode      | Mode determines what the source of the message to be signed.                                          |
| in  | key_id    | Private key slot used to sign the message.                                                            |
| out | signature | Signature is returned here. Format is R and S integers in big-endian format. 64 bytes for P256 curve. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.76 calib\_sign\_internal()

Executes Sign command to sign an internally generated message.

## **Parameters**

| in  | device        | Device context pointer                                                                       |
|-----|---------------|----------------------------------------------------------------------------------------------|
| in  | key_id        | Slot of the private key to be used to sign the message.                                      |
| in  | is_invalidate | Set to true if the signature will be used with the Verify(Invalidate) command. false for all |
|     |               | other cases.                                                                                 |
| in  | is_full_sn    | Set to true if the message should incorporate the device's full serial number.               |
| out | signature     | Signature is returned here. Format is R and S integers in big-endian format. 64 bytes        |
|     |               | for P256 curve.                                                                              |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.77 calib\_sleep()

```
ATCA_STATUS calib_sleep (
ATCADevice device)
```

invoke sleep on the CryptoAuth device

| in device Device context pointer |
|----------------------------------|
|----------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.78 calib updateextra()

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

Can also be used to decrement the limited use counter associated with the key in slot NewValue.

#### **Parameters**

| in | device    | Device context pointer                                            |
|----|-----------|-------------------------------------------------------------------|
| in | mode      | Mode determines what operations the UpdateExtra command performs. |
| in | new_value | Value to be written.                                              |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.79 calib\_verify()

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

For the Stored, External, and ValidateExternal Modes, the contents of TempKey (or Message Digest Buffer in some cases for the ATECC608) should contain the 32 byte message.

| in  | device     | Device context pointer                                                                                                                                                                                                                                                                                                             |
|-----|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| in  | mode       | Verify command mode and options                                                                                                                                                                                                                                                                                                    |
| in  | key_id     | Stored mode, the slot containing the public key to be used for the verification.  ValidateExternal mode, the slot containing the public key to be validated. External mode, KeyID contains the curve type to be used to Verify the signature. Validate or Invalidate mode, the slot containing the public key to be (in)validated. |
| in  | signature  | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve.                                                                                                                                                                                                                                          |
| in  | public_key | If mode is External, the public key to be used for verification. X and Y integers in big-endian format. 64 bytes for P256 curve. NULL for all other modes.                                                                                                                                                                         |
| in  | other_data | If mode is Validate, the bytes used to generate the message for the validation (19 bytes). NULL for all other modes.                                                                                                                                                                                                               |
| out | mac        | If mode indicates a validating MAC, then the MAC will will be returned here. Can be NULL otherwise.                                                                                                                                                                                                                                |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.80 calib\_verify\_extern()

```
ATCA_STATUS calib_verify_extern (
    ATCADevice device,
    const uint8_t * message,
    const uint8_t * signature,
    const uint8_t * public_key,
    bool * is_verified )
```

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

## **Parameters**

| in  | device      | Device context pointer                                                                    |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | public_key  | The public key to be used for verification. X and Y integers in big-endian format. 64     |
|     |             | bytes for P256 curve.                                                                     |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

## Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

## 18.7.3.81 calib\_verify\_extern\_mac()

```
ATCA_STATUS calib_verify_extern_mac (
    ATCADevice device,
    const uint8_t * message,
    const uint8_t * signature,
    const uint8_t * public_key,
    const uint8_t * num_in,
    const uint8_t * io_key,
    bool * is_verified )
```

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

#### **Parameters**

| in  | device      | Device context pointer                                                                    |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | public_key  | The public key to be used for verification. X and Y integers in big-endian format. 64     |
|     |             | bytes for P256 curve.                                                                     |
| in  | num_in      | System nonce (32 byte) used for the verification MAC.                                     |
| in  | io_key      | IO protection key for verifying the validation MAC.                                       |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

## Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

## 18.7.3.82 calib\_verify\_invalidate()

```
ATCA_STATUS calib_verify_invalidate (
    ATCADevice device,
    uint16_t key_id,
    const uint8_t * signature,
    const uint8_t * other_data,
    bool * is_verified )
```

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

This command can only be run after GenKey has been used to create a PubKey digest of the public key to be invalidated in TempKey (mode=0x10).

| in  | device      | Device context pointer                                                                    |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | key_id      | Slot containing the public key to be invalidated.                                         |
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | other_data  | 19 bytes of data used to build the verification message.                                  |
| out | is_verified | Boolean whether or not the message, signature, validation public key verified.            |

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

## 18.7.3.83 calib\_verify\_stored()

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

#### **Parameters**

| in  | device      | Device context pointer                                                                    |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | message     | 32 byte message to be verified. Typically the SHA256 hash of the full message.            |
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | key_id      | Slot containing the public key to be used in the verification.                            |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

## Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

## 18.7.3.84 calib\_verify\_stored\_mac()

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

| in | device  | Device context pointer                                                         |
|----|---------|--------------------------------------------------------------------------------|
| in | message | 32 byte message to be verified. Typically the SHA256 hash of the full message. |

| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | key_id      | Slot containing the public key to be used in the verification.                            |
| in  | num_in      | System nonce (32 byte) used for the verification MAC.                                     |
| in  | io_key      | IO protection key for verifying the validation MAC.                                       |
| out | is_verified | Boolean whether or not the message, signature, public key verified.                       |

### Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

## 18.7.3.85 calib\_verify\_validate()

```
ATCA_STATUS calib_verify_validate (
    ATCADevice device,
    uint16_t key_id,
    const uint8_t * signature,
    const uint8_t * other_data,
    bool * is_verified )
```

Executes the Verify command in Validate mode to validate a public key stored in a slot.

This command can only be run after GenKey has been used to create a PubKey digest of the public key to be validated in TempKey (mode=0x10).

## **Parameters**

| in  | device      | Device context pointer                                                                    |
|-----|-------------|-------------------------------------------------------------------------------------------|
| in  | key_id      | Slot containing the public key to be validated.                                           |
| in  | signature   | Signature to be verified. R and S integers in big-endian format. 64 bytes for P256 curve. |
| in  | other_data  | 19 bytes of data used to build the verification message.                                  |
| out | is_verified | Boolean whether or not the message, signature, validation public key verified.            |

### Returns

ATCA\_SUCCESS on verification success or failure, because the command still completed successfully.

# 18.7.3.86 calib\_wakeup()

```
ATCA_STATUS calib_wakeup (
ATCADevice device)
```

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

wakeup the CryptoAuth device

| in d | levice | Device context pointer |
|------|--------|------------------------|
|------|--------|------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.87 calib write()

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

#### **Parameters**

| in | device  | Device context pointer                                                                        |
|----|---------|-----------------------------------------------------------------------------------------------|
| in | zone    | Zone/Param1 for the write command.                                                            |
| in | address | Address/Param2 for the write command.                                                         |
| in | value   | Plain-text data to be written or cipher-text for encrypted writes. 32 or 4 bytes depending on |
|    |         | bit 7 in the zone.                                                                            |
| in | mac     | MAC required for encrypted writes (32 bytes). Set to NULL if not required.                    |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.88 calib\_write\_bytes\_zone()

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

Config zone must be unlocked for writes to that zone. If data zone is unlocked, only 32-byte writes are allowed to slots and OTP and the offset and length must be multiples of 32 or the write will fail.

| in | device       | Device context pointer                                                                  |
|----|--------------|-----------------------------------------------------------------------------------------|
| in | zone         | Zone to write data to: ATCA_ZONE_CONFIG(0), ATCA_ZONE_OTP(1), or ATCA_ZONE_DATA(2).     |
| in | slot         | If zone is ATCA_ZONE_DATA(2), the slot number to write to. Ignored for all other zones. |
| in | offset_bytes | Byte offset within the zone to write to. Must be a multiple of a word (4 bytes).        |
| in | data         | Data to be written.                                                                     |
| in | length       | Number of bytes to be written. Must be a multiple of a word (4 bytes).                  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.7.3.89 calib\_write\_config\_counter()

Initialize one of the monotonic counters in device with a specific value.

The monotonic counters are stored in the configuration zone using a special format. This encodes a binary count value into the 8 byte encoded value required. Can only be set while the configuration zone is unlocked.

## **Parameters**

|   | in | device        | Device context pointer |
|---|----|---------------|------------------------|
|   | in | counter_id    | Counter to be written. |
| ſ | in | counter_value | Counter value to set.  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.7.3.90 calib\_write\_config\_zone()

Executes the Write command, which writes the configuration zone.

First 16 bytes are skipped as they are not writable. LockValue and LockConfig are also skipped and can only be changed via the Lock command.

This command may fail if UserExtra and/or Selector bytes have already been set to non-zero values.

| in | device      | Device context pointer                                                                  |
|----|-------------|-----------------------------------------------------------------------------------------|
| in | config_data | Data to the config zone data. This should be 88 bytes for SHA devices and 128 bytes for |
|    |             | ECC devices.                                                                            |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.91 calib\_write\_enc()

```
ATCA_STATUS calib_write_enc (
    ATCADevice device,
    uint16_t key_id,
    uint8_t block,
    const uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[(20)])
```

# 18.7.3.92 calib\_write\_pubkey()

Uses the write command to write a public key to a slot in the proper format.

## **Parameters**

| in | device     | Device context pointer                                                                                       |
|----|------------|--------------------------------------------------------------------------------------------------------------|
| in | slot       | Slot number to write. Only slots 8 to 15 are large enough to store a public key.                             |
| in | public_key | Public key to write into the slot specified. X and Y integers in big-endian format. 64 bytes for P256 curve. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.3.93 calib\_write\_zone()

```
ATCA_STATUS calib_write_zone (
ATCADevice device,
```

```
uint8_t zone,
uint16_t slot,
uint8_t block,
uint8_t offset,
const uint8_t * data,
uint8_t len )
```

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

### **Parameters**

| in | device | Device context pointer                                                                               |
|----|--------|------------------------------------------------------------------------------------------------------|
| in | zone   | Device zone to write to (0=config, 1=OTP, 2=data).                                                   |
| in | slot   | If writing to the data zone, it is the slot to write to, otherwise it should be 0.                   |
| in | block  | 32-byte block to write to.                                                                           |
| in | offset | 4-byte word within the specified block to write to. If performing a 32-byte write, this should be 0. |
| in | data   | Data to be written.                                                                                  |
| in | len    | Number of bytes to be written. Must be either 4 or 32.                                               |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.7.4 Variable Documentation

# 18.7.4.1 atca\_basic\_aes\_gcm\_version

```
const char* atca_basic_aes_gcm_version = "2.0"
```

# 18.8 Software crypto methods (atcac)

These methods provide a software implementation of various crypto algorithms.

### **Macros**

- #define ATCA ECC P256 FIELD SIZE (256 / 8)
- #define ATCA ECC P256 PRIVATE KEY SIZE (ATCA ECC P256 FIELD SIZE)
- #define ATCA\_ECC\_P256\_PUBLIC\_KEY\_SIZE (ATCA\_ECC\_P256\_FIELD\_SIZE \* 2)
- #define ATCA\_ECC\_P256\_SIGNATURE\_SIZE (ATCA\_ECC\_P256\_FIELD\_SIZE \* 2)

## **Functions**

- int atcac\_sw\_ecdsa\_verify\_p256 (const uint8\_t msg[(256/8)], const uint8\_t signature[((256/8) \*2)], const uint8\_t public key[((256/8) \*2)])
  - return software generated ECDSA verification result and the function is currently not implemented
- int atcac\_sw\_random (uint8\_t \*data, size\_t data\_size)
  - return software generated random number and the function is currently not implemented
- int atcac\_sw\_sha1\_init (atcac\_sha1\_ctx \*ctx)
  - Initialize context for performing SHA1 hash in software.
- int atcac\_sw\_sha1\_update (atcac\_sha1\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)
  - Add data to a SHA1 hash.
- int atcac sw sha1 finish (atcac sha1 ctx \*ctx, uint8 t digest[(20)])
- int atcac sw sha1 (const uint8 t \*data, size t data size, uint8 t digest[(20)])
  - Perform SHA1 hash of data in software.
- int atcac\_sw\_sha2\_256\_init (atcac\_sha2\_256\_ctx \*ctx)
  - Initialize context for performing SHA256 hash in software.
- int atcac\_sw\_sha2\_256\_update (atcac\_sha2\_256\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)
  - Add data to a SHA256 hash.
- int atcac\_sw\_sha2\_256\_finish (atcac\_sha2\_256\_ctx \*ctx, uint8\_t digest[(32)])
- int atcac sw sha2 256 (const uint8 t \*data, size t data size, uint8 t digest[(32)])
  - single call convenience function which computes Hash of given data using SHA256 software
- ATCA\_STATUS atcac\_sha256\_hmac\_init (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)
  - Initialize context for performing HMAC (sha256) in software.
- ATCA\_STATUS atcac\_sha256\_hmac\_update (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*data, size\_
   t data\_size)
  - Update HMAC context with input data.
- ATCA\_STATUS atcac\_sha256\_hmac\_finish (atcac\_hmac\_sha256\_ctx \*ctx, uint8\_t \*digest, size\_t \*digest ← \_ len)

Finish CMAC calculation and clear the HMAC context.

# 18.8.1 Detailed Description

These methods provide a software implementation of various crypto algorithms.

## 18.8.2 Macro Definition Documentation

## 18.8.2.1 ATCA\_ECC\_P256\_FIELD\_SIZE

```
#define ATCA_ECC_P256_FIELD_SIZE (256 / 8)
```

### 18.8.2.2 ATCA\_ECC\_P256\_PRIVATE\_KEY\_SIZE

```
#define ATCA_ECC_P256_PRIVATE_KEY_SIZE (ATCA_ECC_P256_FIELD_SIZE)
```

# 18.8.2.3 ATCA\_ECC\_P256\_PUBLIC\_KEY\_SIZE

```
#define ATCA_ECC_P256_PUBLIC_KEY_SIZE (ATCA_ECC_P256_FIELD_SIZE * 2)
```

## 18.8.2.4 ATCA\_ECC\_P256\_SIGNATURE\_SIZE

```
#define ATCA_ECC_P256_SIGNATURE_SIZE (ATCA_ECC_P256_FIELD_SIZE * 2)
```

## 18.8.3 Function Documentation

# 18.8.3.1 atcac\_sha256\_hmac\_finish()

Finish CMAC calculation and clear the HMAC context.

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 252

### 18.8.3.2 atcac\_sha256\_hmac\_init()

Initialize context for performing HMAC (sha256) in software.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.8.3.3 atcac\_sha256\_hmac\_update()

Update HMAC context with input data.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.8.3.4 atcac\_sw\_ecdsa\_verify\_p256()

return software generated ECDSA verification result and the function is currently not implemented

### **Parameters**

| in | msg        | ptr to message or challenge                                                                                                     |
|----|------------|---------------------------------------------------------------------------------------------------------------------------------|
| in | signature  | ptr to the signature to verify                                                                                                  |
| in | public_key | ptr to public key of device which signed the challenge return ATCA_UNIMPLEMENTED , as the function is currently not implemented |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 253

### 18.8.3.5 atcac\_sw\_random()

return software generated random number and the function is currently not implemented

### **Parameters**

| out | data      | ptr to space to receive the random number                                          |
|-----|-----------|------------------------------------------------------------------------------------|
| in  | data_size | size of data buffer return ATCA_UNIMPLEMENTED , as the function is not implemented |

# 18.8.3.6 atcac\_sw\_sha1()

Perform SHA1 hash of data in software.

#### **Parameters**

| in  | data      | Data to be hashed                  |
|-----|-----------|------------------------------------|
| in  | data_size | Data size in bytes                 |
| out | digest    | Digest is returned here (20 bytes) |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.8.3.7 atcac\_sw\_sha1\_finish()

### 18.8.3.8 atcac\_sw\_sha1\_init()

```
int atcac_sw_shal_init (
          atcac_shal_ctx * ctx )
```

Initialize context for performing SHA1 hash in software.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.8.3.9 atcac\_sw\_sha1\_update()

Add data to a SHA1 hash.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.8.3.10 atcac\_sw\_sha2\_256()

single call convenience function which computes Hash of given data using SHA256 software

### **Parameters**

| in  | data      | pointer to stream of data to hash |
|-----|-----------|-----------------------------------|
| in  | data_size | size of data stream to hash       |
| out | digest    | result                            |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.8.3.11 atcac\_sw\_sha2\_256\_finish()

## 18.8.3.12 atcac\_sw\_sha2\_256\_init()

Initialize context for performing SHA256 hash in software.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.8.3.13 atcac\_sw\_sha2\_256\_update()

Add data to a SHA256 hash.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9 Hardware abstraction layer (hal\_)

These methods define the hardware abstraction layer for communicating with a CryptoAuth device.

#### **Data Structures**

struct ATCAHAL t

an intermediary data structure to allow the HAL layer to point the standard API functions used by the upper layers to the HAL implementation for the interface. This isolates the upper layers and loosely couples the ATCAlface object from the physical implementation.

- struct i2c\_start\_instance
- struct atcal2Cmaster

this is the hal data for ATCA HAL for ASF SERCOM

- · struct atcaSPImaster
- · struct i2c sam instance
- · struct atcaSWImaster

this is the hal\_data for ATCA HAL for ASF SERCOM

#### **Macros**

- #define ATCA POLLING INIT TIME MSEC 1
- #define ATCA POLLING FREQUENCY TIME MSEC 2
- #define ATCA\_POLLING\_MAX\_TIME\_MSEC 2500
- · #define hal memset s atcab memset s
- #define HID PACKET MAX 512
- #define MAX I2C BUSES 2
- #define MAX SPI BUSES 2
- #define SWI\_WAKE\_TOKEN ((uint8\_t)0x00)

flag preceding a command

• #define SWI\_FLAG\_CMD ((uint8\_t)0x77)

flag preceding a command

• #define SWI FLAG TX ((uint8 t)0x88)

flag requesting a response

#define SWI\_FLAG\_IDLE ((uint8\_t)0xBB)

flag requesting to go into Idle mode

• #define SWI FLAG SLEEP ((uint8 t)0xCC)

flag requesting to go into Sleep mode

- #define MAX I2C BUSES 3
- #define KIT\_MAX\_SCAN\_COUNT 4
- #define KIT\_MAX\_TX\_BUF 32
- #define KIT\_TX\_WRAP\_SIZE (10)
- #define KIT MSG SIZE (32)
- #define KIT\_RX\_WRAP\_SIZE (KIT\_MSG\_SIZE + 6)
- #define MAX SWI BUSES 6
- #define RECEIVE MODE 0
- #define TRANSMIT MODE 1
- #define RX\_DELAY 10
- #define TX DELAY 90
- #define DEBUG\_PIN\_1 EXT2\_PIN\_5
- #define DEBUG\_PIN\_2 EXT2\_PIN\_6
- #define MAX SWI BUSES 6
- #define RECEIVE MODE 0
- #define TRANSMIT MODE 1
- #define RX DELAY 10
- #define TX\_DELAY 93

## **Typedefs**

- typedef void(\* start\_change\_baudrate) (ATCAlface iface, uint32\_t speed)
- typedef struct i2c\_start\_instance i2c\_start\_instance\_t
- typedef struct atcal2Cmaster ATCAl2CMaster\_t
- typedef struct atcaSPImaster ATCASPIMaster\_t
- typedef void(\* sam\_change\_baudrate) (ATCAlface iface, uint32\_t speed)
- typedef struct i2c\_sam\_instance i2c\_sam\_instance\_t
- typedef struct atcal2Cmaster ATCAl2CMaster\_t

this is the hal data for ATCA HAL for ASF SERCOM

typedef struct atcaSWImaster ATCASWIMaster\_t

this is the hal data for ATCA HAL for ASF SERCOM

typedef struct atcaSWImaster ATCASWIMaster\_t

this is the hal\_data for ATCA HAL for ASF SERCOM

### **Functions**

ATCA STATUS hal iface init (ATCAlfaceCfg \*, ATCAHAL t \*\*hal)

Standard HAL API for ATCA to initialize a physical interface.

ATCA\_STATUS hal\_iface\_release (ATCAlfaceType, void \*hal\_data)

releases a physical interface, HAL knows how to interpret hal\_data

ATCA\_STATUS hal\_check\_wake (const uint8\_t \*response, int response\_size)

Utility function for hal\_wake to check the reply.

· void atca delay ms (uint32 t ms)

Timer API for legacy implementations.

void atca delay us (uint32 t delay)

This function delays for a number of microseconds.

void hal\_rtos\_delay\_ms (uint32\_t ms)

Timer API implemented at the HAL level.

void hal\_delay\_ms (uint32\_t delay)

This function delays for a number of milliseconds.

void hal\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

ATCA\_STATUS hal\_create\_mutex (void \*\*ppMutex, char \*pName)

Optional hal interfaces.

- ATCA\_STATUS hal\_destroy\_mutex (void \*pMutex)
- ATCA\_STATUS hal\_lock\_mutex (void \*pMutex)
- ATCA\_STATUS hal\_unlock\_mutex (void \*pMutex)
- void \* hal\_malloc (size\_t size)
- void hal\_free (void \*ptr)
- $\bullet \ \ \mathsf{ATCA\_STATUS} \ \mathsf{hal\_iface\_register\_hal} \ (\mathsf{ATCAIfaceType} \ \mathsf{iface\_type}, \ \mathsf{ATCAHAL\_t} \ *\mathsf{hal}, \ \mathsf{ATCAHAL\_t} \ **\mathsf{old})$

Register/Replace a HAL with a.

ATCA\_STATUS hal\_kit\_hid\_discover\_buses (int hid\_buses[], int max\_buses)

discover cdc buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA STATUS hal kit hid discover devices (int bus num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA STATUS hal kit hid init (void \*hal, ATCAlfaceCfg \*cfg)

HAL implementation of Kit USB HID init.

• ATCA STATUS hal kit hid post init (ATCAlface iface)

HAL implementation of Kit HID post init.

ATCA\_STATUS kit\_phy\_send (ATCAlface iface, uint8\_t \*txdata, int txlength)

HAL implementation of send over USB HID.

• ATCA STATUS kit phy receive (ATCAlface iface, uint8 t \*rxdata, int \*rxsize)

HAL implementation of kit protocol send over USB HID.

ATCA\_STATUS kit\_phy\_num\_found (int8\_t \*num\_found)

Number of USB HID devices found.

ATCA STATUS hal kit hid send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of kit protocol send over USB HID.

ATCA\_STATUS hal\_kit\_hid\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_←
t \*rxsize)

HAL implementation of send over USB HID.

· ATCA STATUS hal kit hid wake (ATCAlface iface)

Call the wake for kit protocol.

ATCA STATUS hal kit hid idle (ATCAlface iface)

Call the idle for kit protocol.

· ATCA STATUS hal kit hid sleep (ATCAlface iface)

Call the sleep for kit protocol.

• ATCA\_STATUS hal\_kit\_hid\_release (void \*hal\_data)

Close the physical port for HID.

ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

ATCA STATUS hal i2c discover devices (int bus num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_i2c\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAIFace is abstracted from the physical details.

• ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

• ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

ATCA STATUS change i2c speed (ATCAlface iface, uint32 t speed)

method to change the bus speec of I2C

ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

· ATCA STATUS hal i2c sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

void hal\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

• void atca\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

ATCA STATUS hal spi discover buses (int spi buses[], int max buses)

discover spi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS hal\_spi\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any TA100 devices on a given logical bus number

ATCA\_STATUS hal\_spi\_init (void \*hal, ATCAlfaceCfg \*cfg)

initialize an SPI interface using given config

ATCA\_STATUS hal\_spi\_post\_init (ATCAlface iface)

HAL implementation of SPI post init.

ATCA STATUS hal spi send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of SPI send over Harmony.

ATCA\_STATUS hal\_spi\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of SPI receive function for HARMONY SPI.

ATCA STATUS hal spi wake (ATCAlface iface)

wake up TA100 device using SPI bus

ATCA\_STATUS hal\_spi\_idle (ATCAlface iface)

idle TA100 device using SPI bus

ATCA STATUS hal spi sleep (ATCAlface iface)

sleep TA100 device using SPI bus

• ATCA\_STATUS hal\_spi\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

• ATCA\_STATUS hal\_swi\_discover\_buses (int swi\_buses[], int max\_buses)

discover swi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

ATCA STATUS hal swi discover devices (int bus num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA STATUS hal swi init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_swi\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAlFace instances using the same bus, and you can have multiple ATCAlFace instances on multiple swi buses, so hal\_swi\_init manages these things and ATCAlFace is abstracted from the physical details.

ATCA\_STATUS hal\_swi\_post\_init (ATCAlface iface)

HAL implementation of SWI post init.

• ATCA STATUS hal swi send flag (ATCAlface iface, uint8 t data)

HAL implementation of SWI send one byte over UART.

• ATCA\_STATUS hal\_swi\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of SWI send command over UART.

ATCA\_STATUS hal\_swi\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_
 t \*rxlength)

HAL implementation of SWI receive function over UART.

• ATCA\_STATUS hal\_swi\_wake (ATCAlface iface)

wake up CryptoAuth device using SWI interface

ATCA\_STATUS hal\_swi\_idle (ATCAlface iface)

idle CryptoAuth device using SWI interface

ATCA STATUS hal swi sleep (ATCAlface iface)

sleep CryptoAuth device using SWI interface

ATCA\_STATUS hal\_swi\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

- ATCA\_STATUS kit\_phy\_send (ATCAlface iface, const char \*txdata, int txlength)
- ATCA\_STATUS kit\_phy\_receive (ATCAlface iface, char \*rxdata, int \*rxlength)
- char \* strnchr (const char \*s, size\_t count, int c)
- const char \* kit\_id\_from\_devtype (ATCADeviceType devtype)
- const char \* kit\_interface\_from\_kittype (ATCAKitType kittype)
- · ATCA STATUS kit init (ATCAlface iface)

HAL implementation of kit protocol init. This function calls back to the physical protocol to send the bytes.

ATCA\_STATUS kit\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of kit protocol send. This function calls back to the physical protocol to send the bytes.

• ATCA\_STATUS kit\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxsize)

HAL implementation to receive bytes and unwrap from kit protocol. This function calls back to the physical protocol to receive the bytes.

ATCA STATUS kit wake (ATCAlface iface)

Call the wake for kit protocol.

ATCA STATUS kit idle (ATCAlface iface)

Call the idle for kit protocol.

ATCA\_STATUS kit\_sleep (ATCAlface iface)

Call the sleep for kit protocol.

ATCA STATUS kit wrap cmd (const uint8 t \*txdata, int txlen, char \*pkitcmd, int \*nkitcmd, char target)

Wrap binary bytes in ascii kit protocol.

ATCA\_STATUS kit\_parse\_rsp (const char \*pkitbuf, int nkitbuf, uint8\_t \*kitstatus, uint8\_t \*rxdata, int \*datasize)

Parse the response ascii from the kit.

ATCA\_STATUS swi\_uart\_init (ATCASWIMaster\_t \*instance)

Implementation of SWI UART init.

ATCA\_STATUS swi\_uart\_deinit (ATCASWIMaster\_t \*instance)

Implementation of SWI UART deinit.

• void swi uart setbaud (ATCASWIMaster t \*instance, uint32 t baudrate)

implementation of SWI UART change baudrate.

void swi\_uart\_mode (ATCASWIMaster\_t \*instance, uint8\_t mode)

implementation of SWI UART change mode.

void swi uart discover buses (int swi uart buses[], int max buses)

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

ATCA\_STATUS swi\_uart\_send\_byte (ATCASWIMaster\_t \*instance, uint8\_t data)

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

ATCA\_STATUS swi\_uart\_receive\_byte (ATCASWIMaster\_t \*instance, uint8\_t \*data)

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

### **Variables**

· struct port config pin conf

#### 18.9.1 Detailed Description

These methods define the hardware abstraction layer for communicating with a CryptoAuth device.

These methods define the hardware abstraction layer for communicating with a CryptoAuth device using SWI interface.

These methods define the hardware abstraction layer for communicating with a CryptoAuth device using SWI Interface.

These methods define the hardware abstraction layer for communicating with a TA100 device.

< Uncomment when debugging

These methods define the hardware abstraction layer for communicating with a CryptoAuth device using I2C driver of ASF.

## 18.9.2 Macro Definition Documentation

# 18.9.2.1 ATCA\_POLLING\_FREQUENCY\_TIME\_MSEC

#define ATCA\_POLLING\_FREQUENCY\_TIME\_MSEC 2

## 18.9.2.2 ATCA\_POLLING\_INIT\_TIME\_MSEC

#define ATCA\_POLLING\_INIT\_TIME\_MSEC 1

### 18.9.2.3 ATCA POLLING MAX TIME MSEC

#define ATCA\_POLLING\_MAX\_TIME\_MSEC 2500

## 18.9.2.4 DEBUG\_PIN\_1

#define DEBUG\_PIN\_1 EXT2\_PIN\_5

### 18.9.2.5 DEBUG\_PIN\_2

#define DEBUG\_PIN\_2 EXT2\_PIN\_6

## 18.9.2.6 hal\_memset\_s

#define hal\_memset\_s atcab\_memset\_s

# 18.9.2.7 HID\_PACKET\_MAX

#define HID\_PACKET\_MAX 512

# 18.9.2.8 KIT\_MAX\_SCAN\_COUNT

#define KIT\_MAX\_SCAN\_COUNT 4

## 18.9.2.9 KIT\_MAX\_TX\_BUF

#define KIT\_MAX\_TX\_BUF 32

# 18.9.2.10 KIT\_MSG\_SIZE

#define KIT\_MSG\_SIZE (32)

## 18.9.2.11 KIT\_RX\_WRAP\_SIZE

#define KIT\_RX\_WRAP\_SIZE (KIT\_MSG\_SIZE + 6)

# 18.9.2.12 KIT\_TX\_WRAP\_SIZE

#define KIT\_TX\_WRAP\_SIZE (10)

## 18.9.2.13 MAX\_I2C\_BUSES [1/2]

#define MAX\_I2C\_BUSES 2

# 18.9.2.14 MAX\_I2C\_BUSES [2/2]

#define MAX\_I2C\_BUSES 3

### 18.9.2.15 MAX\_SPI\_BUSES

#define MAX\_SPI\_BUSES 2

### 18.9.2.16 MAX\_SWI\_BUSES [1/2]

#define MAX\_SWI\_BUSES 6

• this HAL implementation assumes you've included the ASF SERCOM UART libraries in your project, otherwise, the HAL layer will not compile because the ASF UART drivers are a dependency \*

## 18.9.2.17 MAX\_SWI\_BUSES [2/2]

```
#define MAX_SWI_BUSES 6
```

• this HAL implementation assumes you've included the ASF SERCOM UART libraries in your project, otherwise, the HAL layer will not compile because the ASF UART drivers are a dependency \*

### 18.9.2.18 RECEIVE\_MODE [1/2]

#define RECEIVE\_MODE 0

## 18.9.2.19 RECEIVE\_MODE [2/2]

#define RECEIVE\_MODE 0

#### 18.9.2.20 RX\_DELAY [1/2]

#define RX\_DELAY 10

## 18.9.2.21 RX\_DELAY [2/2]

#define RX\_DELAY 10

## 18.9.2.22 SWI\_FLAG\_CMD

```
#define SWI_FLAG_CMD ((uint8_t)0x77)
```

flag preceding a command

### 18.9.2.23 SWI FLAG IDLE

```
#define SWI_FLAG_IDLE ((uint8_t)0xBB)
```

flag requesting to go into Idle mode

## 18.9.2.24 SWI\_FLAG\_SLEEP

```
#define SWI_FLAG_SLEEP ((uint8_t)0xCC)
```

flag requesting to go into Sleep mode

# 18.9.2.25 SWI\_FLAG\_TX

```
#define SWI_FLAG_TX ((uint8_t)0x88)
```

flag requesting a response

## 18.9.2.26 SWI\_WAKE\_TOKEN

```
#define SWI_WAKE_TOKEN ((uint8_t)0x00)
```

flag preceding a command

# 18.9.2.27 TRANSMIT\_MODE [1/2]

#define TRANSMIT\_MODE 1

## 18.9.2.28 TRANSMIT\_MODE [2/2]

#define TRANSMIT\_MODE 1

## 18.9.2.29 TX\_DELAY [1/2]

#define TX\_DELAY 90

# 18.9.2.30 TX\_DELAY [2/2]

#define TX\_DELAY 93

# 18.9.3 Typedef Documentation

## 18.9.3.1 ATCAI2CMaster\_t [1/2]

typedef struct atcaI2Cmaster ATCAI2CMaster\_t

### 18.9.3.2 ATCAI2CMaster\_t [2/2]

 ${\tt typedef \ struct \ atcaI2Cmaster \ ATCAI2CMaster\_t}$ 

this is the hal\_data for ATCA HAL for ASF SERCOM

## 18.9.3.3 ATCASPIMaster\_t

 ${\tt typedef \ struct \ atcaSPImaster \ ATCASPIMaster\_t}$ 

### 18.9.3.4 ATCASWIMaster\_t [1/2]

 ${\tt typedef \ struct \ atcaSWImaster \ ATCASWIMaster\_t}$ 

this is the hal\_data for ATCA HAL for ASF SERCOM

### 18.9.3.5 ATCASWIMaster\_t [2/2]

```
typedef struct atcaSWImaster ATCASWIMaster_t
```

this is the hal\_data for ATCA HAL for ASF SERCOM

### 18.9.3.6 i2c\_sam\_instance\_t

```
typedef struct i2c_sam_instance i2c_sam_instance_t
```

## 18.9.3.7 i2c\_start\_instance\_t

```
typedef struct i2c_start_instance i2c_start_instance_t
```

### 18.9.3.8 sam\_change\_baudrate

```
typedef void(* sam_change_baudrate) (ATCAIface iface, uint32_t speed)
```

### 18.9.3.9 start\_change\_baudrate

```
typedef void(* start_change_baudrate) (ATCAIface iface, uint32_t speed)
```

## 18.9.4 Function Documentation

## 18.9.4.1 atca\_delay\_10us()

This function delays for a number of tens of microseconds.

### **Parameters**

| in | delay | number of 0.01 milliseconds to delay |
|----|-------|--------------------------------------|

#### 18.9.4.2 atca delay ms()

Timer API for legacy implementations.

This function delays for a number of milliseconds.

```
You can override this function if you like to do something else in your system while delaying.
```

#### **Parameters**

| i | delay | number of milliseconds to delay |  |
|---|-------|---------------------------------|--|
|---|-------|---------------------------------|--|

## 18.9.4.3 atca\_delay\_us()

This function delays for a number of microseconds.

### Parameters

| in | delay | number of 0.001 milliseconds to delay |
|----|-------|---------------------------------------|
| in | delay | number of microseconds to delay       |

## 18.9.4.4 change\_i2c\_speed()

method to change the bus speec of I2C

method to change the bus speed of I2C

method to change the bus speed of I2C. This function is not used in Linux.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 268

#### **Parameters**

| in | iface | interface on which to change bus speed |
|----|-------|----------------------------------------|
| in | speed | baud rate (typically 100000 or 400000) |
| in | iface | interface on which to change bus speed |
| in | speed | baud rate (typically 100000 or 400000) |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.5 hal\_check\_wake()

Utility function for hal\_wake to check the reply.

### **Parameters**

| in | response      | Wake response to be checked.   |
|----|---------------|--------------------------------|
| in | response_size | Size of the response to check. |

#### Returns

ATCA\_SUCCESS for expected wake, ATCA\_STATUS\_SELFTEST\_ERROR if the power on self test failed, ATCA\_WAKE\_FAILED for other failures.

## 18.9.4.6 hal\_create\_mutex()

```
ATCA_STATUS hal_create_mutex ( void ** ppMutex, char * pName )
```

Optional hal interfaces.

Application callback for creating a mutex object.

#### **Parameters**

| in,out | ppMutex | location to receive ptr to mutex                        |
|--------|---------|---------------------------------------------------------|
| in,out | pName   | String used to identify the mutex                       |
|        | [IN/O↔  | ppMutex location to receive ptr to mutex                |
|        | UT]     |                                                         |
|        | [IN]    | pName Name of the mutex for systems using named objects |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 269

## 18.9.4.7 hal\_delay\_10us()

This function delays for a number of tens of microseconds.

#### **Parameters**

|  | in | delay | number of 0.01 milliseconds to delay |  |
|--|----|-------|--------------------------------------|--|
|--|----|-------|--------------------------------------|--|

# 18.9.4.8 hal\_delay\_ms()

This function delays for a number of milliseconds.

```
You can override this function if you like to do something else in your system while delaying.
```

#### **Parameters**

|  | in | delay | number of milliseconds to delay |
|--|----|-------|---------------------------------|
|--|----|-------|---------------------------------|

# 18.9.4.9 hal\_delay\_us()

This function delays for a number of microseconds.

#### **Parameters**

| in | delay | number of microseconds to delay |
|----|-------|---------------------------------|
|----|-------|---------------------------------|

### 18.9.4.10 hal\_destroy\_mutex()

```
{\tt ATCA\_STATUS} \  \, {\tt hal\_destroy\_mutex} \  \, (
```

```
void * pMutex )
```

#### 18.9.4.11 hal free()

```
void hal_free ( \label{eq:void * ptr } \mbox{$\mathsf{v}$}
```

### 18.9.4.12 hal\_i2c\_discover\_buses()

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

This HAL implementation assumes you've included the ASF TWI libraries in your project, otherwise, the HAL layer will not compile because the ASF TWI drivers are a dependency.

logical to physical bus mapping structure

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge. This function is not implemented.

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

### **Parameters**

| in | i2c_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

### Returns

ATCA SUCCESS

#### **Parameters**

| in | i2c_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

### Returns

#### ATCA UNIMPLEMENTED

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

#### **Parameters**

| in | i2c_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

#### Returns

# ATCA\_SUCCESS

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

#### **Parameters**

| ſ                                                                                | in | i2c_buses                                                                          | - an array of logical bus numbers |  |
|----------------------------------------------------------------------------------|----|------------------------------------------------------------------------------------|-----------------------------------|--|
| in max_buses - maximum number of buses the app wants to attempt to discover retu |    | - maximum number of buses the app wants to attempt to discover return ATCA_SUCCESS |                                   |  |

# 18.9.4.13 hal\_i2c\_discover\_devices()

```
ATCA_STATUS hal_i2c_discover_devices (
    int bus_num,
    ATCAIfaceCfg cfg[],
    int * found )
```

discover any CryptoAuth devices on a given logical bus number

## **Parameters**

| in bus_num logical bus number on which to look for CryptoAuth devices |                                                                                                  | logical bus number on which to look for CryptoAuth devices |
|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| out                                                                   | out cfg pointer to head of an array of interface config structures which get filled in by this m |                                                            |
| out found number of devices found on this bus                         |                                                                                                  | number of devices found on this bus                        |

#### Returns

ATCA\_SUCCESS

## **Parameters**

| in                                                                                             | in bus_num logical bus number on which to look for CryptoAuth devices |                                                                                               |
|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| out cfg pointer to head of an array of interface config structures which get filled in by this |                                                                       | pointer to head of an array of interface config structures which get filled in by this method |
| out found number of devices found on this bus                                                  |                                                                       | number of devices found on this bus                                                           |

### Returns

ATCA\_UNIMPLEMENTED

#### **Parameters**

|   | in                                               | bus_num                                                                                        | - logical bus number on which to look for CryptoAuth devices |  |
|---|--------------------------------------------------|------------------------------------------------------------------------------------------------|--------------------------------------------------------------|--|
|   | out                                              | - pointer to head of an array of interface config structures which get filled in by this metho |                                                              |  |
| Ī | out *found - number of devices found on this bus |                                                                                                |                                                              |  |

### Returns

ATCA\_SUCCESS

#### **Parameters**

| in                                            | bus_num                                                                                   | bus_num Logical bus number on which to look for CryptoAuth devices |  |
|-----------------------------------------------|-------------------------------------------------------------------------------------------|--------------------------------------------------------------------|--|
| out                                           | Pointer to head of an array of interface config structures which get filled in by this me |                                                                    |  |
| out found Number of devices found on this bus |                                                                                           |                                                                    |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.14 hal\_i2c\_idle()

```
ATCA_STATUS hal_i2c_idle (
ATCAIface iface)
```

idle CryptoAuth device using I2C bus

#### **Parameters**

| in | iface | interface to logical device to idle |
|----|-------|-------------------------------------|
|----|-------|-------------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.15 hal\_i2c\_init()

```
ATCA_STATUS hal_i2c_init ( void * hal, ATCAIfaceCfg * cfg )
```

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAlFace

instances using the same bus, and you can have multiple ATCAlFace instances on multiple i2c buses, so hal\_i2c—init manages these things and ATCAlFace is abstracted from the physical details.

hal\_i2c\_init manages requests to initialize a physical interface. It manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c init manages these things and ATCAIFace is abstracted from the physical details.

initialize an I2C interface using given config

HAL implementation of I2C init.

• this HAL implementation assumes you've included the START Twi libraries in your project, otherwise, the HAL layer will not compile because the START TWI drivers are a dependency \*

initialize an I2C interface using given config

#### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

this implementation assumes I2C peripheral has been enabled by user. It only initialize an I2C interface using given config.

#### **Parameters**

| in | hal | pointer to HAL specific data that is maintained by this HAL                    |  |
|----|-----|--------------------------------------------------------------------------------|--|
| in | cfg | pointer to HAL specific configuration data that is used to initialize this HAL |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

• this HAL implementation assumes you've included the ASF SERCOM I2C libraries in your project, otherwise, the HAL layer will not compile because the ASF I2C drivers are a dependency \*

#### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

initialize an I2C interface using given config

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 274

#### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

• this HAL implementation assumes you've included the ASF Twi libraries in your project, otherwise, the HAL layer will not compile because the ASF TWI drivers are a dependency \*

initialize an I2C interface using given config

#### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.16 hal\_i2c\_post\_init()

```
ATCA_STATUS hal_i2c_post_init (
ATCAIface iface)
```

HAL implementation of I2C post init.

### **Parameters**

| in | iface | instance |
|----|-------|----------|

#### Returns

ATCA\_SUCCESS

### **Parameters**

| in | iface | instance |
|----|-------|----------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.17 hal\_i2c\_receive()

HAL implementation of I2C receive function for START I2C.

HAL implementation of I2C receive function for ASF I2C.

HAL implementation of I2C receive function.

#### **Parameters**

| in     | iface        | Device to interact with.                                                          |  |
|--------|--------------|-----------------------------------------------------------------------------------|--|
| in     | word_address | device transaction type                                                           |  |
| out    | rxdata       | Data received will be returned here.                                              |  |
| in,out | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | iface    | Device to interact with.                                                          |  |
|--------|----------|-----------------------------------------------------------------------------------|--|
| out    | rxdata   | Data received will be returned here.                                              |  |
| in,out | rxlength | As input, the size of the rxdata buffer. As output, the number of bytes received. |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | iface        | Device to interact with.                                                          |  |
|--------|--------------|-----------------------------------------------------------------------------------|--|
| in     | word_address | device word address                                                               |  |
| out    | rxdata       | Data received will be returned here.                                              |  |
| in,out | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |  |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.18 hal\_i2c\_release()

```
ATCA_STATUS hal_i2c_release ( void * hal_data )
```

manages reference count on given bus and releases resource if no more refences exist

manages reference count on given bus and releases resource if no more refernces exist

#### **Parameters**

| ſ | in <i>hal_</i> | data - | - opaque pointer to hal data structure - known only to the HAL implementation |
|---|----------------|--------|-------------------------------------------------------------------------------|
|---|----------------|--------|-------------------------------------------------------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### **Parameters**

| in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation return ATCA_SUCCESS |
|----|----------|---------------------------------------------------------------------------------------------------|
| in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation                     |

#### Returns

ATCA\_SUCCESS

## 18.9.4.19 hal\_i2c\_send()

HAL implementation of I2C send over START.

HAL implementation of I2C send over ASF.

HAL implementation of I2C send.

#### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device transaction type           |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## **Parameters**

| in | iface    | instance                          |
|----|----------|-----------------------------------|
| in | txdata   | pointer to space to bytes to send |
| in | txlength | number of bytes to send           |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device word address               |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.20 hal\_i2c\_sleep()

```
ATCA_STATUS hal_i2c_sleep (
ATCAIface iface)
```

sleep CryptoAuth device using I2C bus

## **Parameters**

| _ |    |       |                                      |
|---|----|-------|--------------------------------------|
|   | in | iface | interface to logical device to sleep |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.21 hal\_i2c\_wake()

```
ATCA_STATUS hal_i2c_wake (
ATCAIface iface)
```

wake up CryptoAuth device using I2C bus

#### **Parameters**

|  | in | iface | interface to logical device to wakeup |  |
|--|----|-------|---------------------------------------|--|
|--|----|-------|---------------------------------------|--|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.22 hal\_iface\_init()

Standard HAL API for ATCA to initialize a physical interface.

### **Parameters**

| in | cfg | pointer to ATCAlfaceCfg object                   |  |
|----|-----|--------------------------------------------------|--|
| in | hal | pointer to ATCAHAL_t intermediate data structure |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.23 hal\_iface\_register\_hal()

Register/Replace a HAL with a.

### **Parameters**

|                        | in | iface_type | - the type of physical interface to register       |
|------------------------|----|------------|----------------------------------------------------|
| Ī                      | in | hal        | pointer to the new ATCAHAL_t structure to register |
| out old pointer to the |    | old        | pointer to the existing ATCAHAL_t structure        |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 18.9.4.24 hal\_iface\_release()

releases a physical interface, HAL knows how to interpret hal\_data

### **Parameters**

| i | iface_type | - the type of physical interface to release                                           |
|---|------------|---------------------------------------------------------------------------------------|
| i | hal_data   | - pointer to opaque hal data maintained by HAL implementation for this interface type |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.25 hal\_kit\_hid\_discover\_buses()

```
ATCA_STATUS hal_kit_hid_discover_buses (
          int hid_buses[],
          int max_buses )
```

discover cdc buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

### **Parameters**

| in | hid_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

### 18.9.4.26 hal\_kit\_hid\_discover\_devices()

```
ATCA_STATUS hal_kit_hid_discover_devices (
    int bus_num,
    ATCAIfaceCfg cfg[],
    int * found )
```

discover any CryptoAuth devices on a given logical bus number

## **Parameters**

|   | in  | bus_num | - logical bus number on which to look for CryptoAuth devices                                    |
|---|-----|---------|-------------------------------------------------------------------------------------------------|
|   | out | cfg[]   | - pointer to head of an array of interface config structures which get filled in by this method |
| ĺ | out | *found  | - number of devices found on this bus                                                           |

## 18.9.4.27 hal\_kit\_hid\_idle()

Call the idle for kit protocol.

#### **Parameters**

| in | iface | ATCAlface instance that is the interface object to send the bytes over |
|----|-------|------------------------------------------------------------------------|
|----|-------|------------------------------------------------------------------------|

#### Returns

ATCA\_STATUS

## 18.9.4.28 hal\_kit\_hid\_init()

```
ATCA_STATUS hal_kit_hid_init ( void * hal, ATCAIfaceCfg * cfg )
```

HAL implementation of Kit USB HID init.

#### **Parameters**

| in | hal | pointer to HAL specific data that is maintained by this HAL                    |
|----|-----|--------------------------------------------------------------------------------|
| in | cfg | pointer to HAL specific configuration data that is used to initialize this HAL |

### Returns

ATCA\_STATUS

## 18.9.4.29 hal\_kit\_hid\_post\_init()

HAL implementation of Kit HID post init.

#### **Parameters**

| in | iface | instance |
|----|-------|----------|

#### Returns

ATCA\_STATUS

## 18.9.4.30 hal\_kit\_hid\_receive()

HAL implementation of send over USB HID.

#### **Parameters**

| in              | iface  | instance                                           |
|-----------------|--------|----------------------------------------------------|
| in word_address |        | determine device transaction type                  |
| in              | rxdata | pointer to space to receive the data               |
| in,out          | rxsize | ptr to expected number of receive bytes to request |

#### Returns

ATCA\_STATUS

# 18.9.4.31 hal\_kit\_hid\_release()

```
ATCA_STATUS hal_kit_hid_release ( void * hal_data )
```

Close the physical port for HID.

#### **Parameters**

| in | hal_data | The hardware abstraction data specific to this HAL |
|----|----------|----------------------------------------------------|
|----|----------|----------------------------------------------------|

### Returns

ATCA\_STATUS

## 18.9.4.32 hal\_kit\_hid\_send()

```
ATCA_STATUS hal_kit_hid_send (
ATCAIface iface,
```

```
uint8_t word_address,
uint8_t * txdata,
int txlength )
```

HAL implementation of kit protocol send over USB HID.

#### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | determine device transaction type |
| in | txdata       | pointer to bytes to send          |
| in | txlength     | number of bytes to send           |

### Returns

ATCA\_STATUS

### 18.9.4.33 hal\_kit\_hid\_sleep()

```
ATCA_STATUS hal_kit_hid_sleep (
ATCAIface iface)
```

Call the sleep for kit protocol.

### **Parameters**

| i | n | iface | ATCAlface instance that is the interface object to send the bytes over |
|---|---|-------|------------------------------------------------------------------------|
|---|---|-------|------------------------------------------------------------------------|

## Returns

ATCA\_STATUS

### 18.9.4.34 hal\_kit\_hid\_wake()

```
ATCA_STATUS hal_kit_hid_wake (
ATCAIface iface)
```

Call the wake for kit protocol.

### **Parameters**

| in | iface | ATCAlface instance that is the interface object to send the bytes over |
|----|-------|------------------------------------------------------------------------|

#### Returns

ATCA\_STATUS

## 18.9.4.35 hal\_lock\_mutex()

```
ATCA_STATUS hal_lock_mutex ( void * pMutex )
```

## 18.9.4.36 hal\_malloc()

### 18.9.4.37 hal\_rtos\_delay\_ms()

Timer API implemented at the HAL level.

This function delays for a number of milliseconds.

```
You can override this function if you like to do something else in your system while delaying.
```

## **Parameters**

| in delay Number of milliseconds to dela |
|-----------------------------------------|
|-----------------------------------------|

## 18.9.4.38 hal\_spi\_discover\_buses()

discover spi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

### **Parameters**

| in | spi_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

#### Returns

ATCA\_SUCCESS

## 18.9.4.39 hal\_spi\_discover\_devices()

```
ATCA_STATUS hal_spi_discover_devices (
    int bus_num,
    ATCAIfaceCfg cfg[],
    int * found )
```

discover any TA100 devices on a given logical bus number

#### **Parameters**

| in  | bus_num | logical bus number on which to look for TA100 devices                                         |
|-----|---------|-----------------------------------------------------------------------------------------------|
| out | cfg     | pointer to head of an array of interface config structures which get filled in by this method |
| out | found   | number of devices found on this bus                                                           |

#### Returns

ATCA\_SUCCESS

## 18.9.4.40 hal\_spi\_idle()

```
ATCA_STATUS hal_spi_idle (
ATCAIface iface)
```

idle TA100 device using SPI bus

### **Parameters**

|  | in | iface | interface to logical device to idle |
|--|----|-------|-------------------------------------|
|--|----|-------|-------------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.41 hal\_spi\_init()

```
ATCA_STATUS hal_spi_init ( void * hal, ATCAIfaceCfg * cfg )
```

initialize an SPI interface using given config

### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.42 hal\_spi\_post\_init()

```
ATCA_STATUS hal_spi_post_init (
ATCAIface iface)
```

HAL implementation of SPI post init.

#### **Parameters**

| in   <i>Itace</i>   Instance |
|------------------------------|
|------------------------------|

### Returns

ATCA\_SUCCESS

## 18.9.4.43 hal\_spi\_receive()

HAL implementation of SPI receive function for HARMONY SPI.

## **Parameters**

| in iface Device to interact with.             |              | Device to interact with.                                                          |    |
|-----------------------------------------------|--------------|-----------------------------------------------------------------------------------|----|
| in                                            | word_address | device transaction type                                                           |    |
| out rxdata<br>© 2020 Microchip Technology Inc |              | Data received will be returned here.                                              | 86 |
| in, out                                       | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |    |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.44 hal\_spi\_release()

```
ATCA_STATUS hal_spi_release ( void * hal_data )
```

manages reference count on given bus and releases resource if no more refences exist

#### **Parameters**

| ſ | in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation |  |
|---|----|----------|-------------------------------------------------------------------------------|--|
|---|----|----------|-------------------------------------------------------------------------------|--|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.45 hal\_spi\_send()

HAL implementation of SPI send over Harmony.

#### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device transaction type           |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.46 hal\_spi\_sleep()

```
ATCA_STATUS hal_spi_sleep (
ATCAIface iface)
```

sleep TA100 device using SPI bus

#### **Parameters**

| iface interface to logical device to sleep | in <i>iface</i> |
|--------------------------------------------|-----------------|
|--------------------------------------------|-----------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.47 hal\_spi\_wake()

```
ATCA_STATUS hal_spi_wake (
ATCAIface iface)
```

wake up TA100 device using SPI bus

#### **Parameters**

|  | in | iface | interface to logical device to wakeup |
|--|----|-------|---------------------------------------|
|--|----|-------|---------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.48 hal\_swi\_discover\_buses()

discover swi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

#### **Parameters**

|   | in | swi_buses | - an array of logical bus numbers                              |
|---|----|-----------|----------------------------------------------------------------|
| ſ | in | max_buses | - maximum number of buses the app wants to attempt to discover |

#### Returns

ATCA\_SUCCESS

## 18.9.4.49 hal\_swi\_discover\_devices()

```
ATCA_STATUS hal_swi_discover_devices (
    int bus_num,
    ATCAIfaceCfg cfg[],
    int * found )
```

discover any CryptoAuth devices on a given logical bus number

#### **Parameters**

| in  | bus_num | - logical bus number on which to look for CryptoAuth devices                                    |
|-----|---------|-------------------------------------------------------------------------------------------------|
| out | cfg[]   | - pointer to head of an array of interface config structures which get filled in by this method |
| out | *found  | - number of devices found on this bus                                                           |

#### Returns

```
ATCA_SUCCESS
```

default configuration, to be reused during discovery process

## 18.9.4.50 hal\_swi\_idle()

```
ATCA_STATUS hal_swi_idle (
ATCAIface iface)
```

idle CryptoAuth device using SWI interface

## **Parameters**

| in | iface | interface to logical device to idle |
|----|-------|-------------------------------------|
|----|-------|-------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.51 hal\_swi\_init()

```
ATCA_STATUS hal_swi_init ( void * hal, ATCAIfaceCfg * cfg )
```

hal\_swi\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple swi buses, so hal\_\circ swi\_init manages these things and ATCAIFace is abstracted from the physical details.

initialize an SWI interface using given config

### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.52 hal\_swi\_post\_init()

HAL implementation of SWI post init.

### **Parameters**

| in | iface | instance |
|----|-------|----------|
|----|-------|----------|

### Returns

ATCA\_SUCCESS

## 18.9.4.53 hal\_swi\_receive()

HAL implementation of SWI receive function over UART.

## **Parameters**

| in     | iface        | Device to interact with.                                                          |
|--------|--------------|-----------------------------------------------------------------------------------|
| in     | word_address | device transaction type                                                           |
| out    | rxdata       | Data received will be returned here.                                              |
| in,out | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.54 hal\_swi\_release()

```
ATCA_STATUS hal_swi_release ( void * hal_data )
```

manages reference count on given bus and releases resource if no more refences exist

### **Parameters**

|  | in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation |
|--|----|----------|-------------------------------------------------------------------------------|
|--|----|----------|-------------------------------------------------------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.55 hal\_swi\_send()

HAL implementation of SWI send command over UART.

### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device transaction type           |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.56 hal\_swi\_send\_flag()

HAL implementation of SWI send one byte over UART.

### **Parameters**

| in | iface | instance      |
|----|-------|---------------|
| in | data  | bytes to send |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.57 hal\_swi\_sleep()

```
ATCA_STATUS hal_swi_sleep (
ATCAIface iface)
```

sleep CryptoAuth device using SWI interface

### **Parameters**

|  | in | iface | interface to logical device to sleep |
|--|----|-------|--------------------------------------|
|--|----|-------|--------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.58 hal\_swi\_wake()

```
ATCA_STATUS hal_swi_wake (
ATCAIface iface)
```

wake up CryptoAuth device using SWI interface

### **Parameters**

| in | iface | interface to logical device to wakeup |
|----|-------|---------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.9.4.59 hal\_unlock\_mutex()

```
ATCA_STATUS hal_unlock_mutex ( void * pMutex )
```

# 18.9.4.60 kit\_id\_from\_devtype()

Kit Protocol is key

# 18.9.4.61 kit\_idle()

```
ATCA_STATUS kit_idle (
ATCAIface iface)
```

Call the idle for kit protocol.

#### **Parameters**

|  | in | iface | the interface object to send the bytes over |  |
|--|----|-------|---------------------------------------------|--|
|--|----|-------|---------------------------------------------|--|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.62 kit\_init()

```
ATCA_STATUS kit_init (
ATCAIface iface)
```

HAL implementation of kit protocol init. This function calls back to the physical protocol to send the bytes.

#### **Parameters**

```
in iface instance
```

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.63 kit\_interface\_from\_kittype()

Kit interface from device

# 18.9.4.64 kit\_parse\_rsp()

Parse the response ascii from the kit.

#### **Parameters**

| out               | pkitbuf   | pointer to ascii kit protocol data to parse   |
|-------------------|-----------|-----------------------------------------------|
| in <i>nkitbuf</i> |           | length of the ascii kit protocol data         |
| in                | kitstatus | status of the ascii device                    |
| in                | rxdata    | pointer to the binary data buffer             |
| in                | datasize  | size of the pointer to the binary data buffer |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.65 kit\_phy\_num\_found()

```
ATCA_STATUS kit_phy_num_found ( int8_t * num_found )
```

Number of USB HID devices found.

## **Parameters**

| out | num_found | return number of USB HID devices found |
|-----|-----------|----------------------------------------|
|-----|-----------|----------------------------------------|

# Returns

ATCA\_STATUS

# 18.9.4.66 kit\_phy\_receive() [1/2]

## 18.9.4.67 kit\_phy\_receive() [2/2]

HAL implementation of kit protocol send over USB HID.

#### **Parameters**

| in     | iface  | instance                                           |
|--------|--------|----------------------------------------------------|
| out    | rxdata | pointer to space to receive the data               |
| in,out | rxsize | ptr to expected number of receive bytes to request |

## Returns

ATCA\_STATUS

# 18.9.4.68 kit\_phy\_send() [1/2]

# 18.9.4.69 kit\_phy\_send() [2/2]

HAL implementation of send over USB HID.

### **Parameters**

| in | iface    | instance                 |
|----|----------|--------------------------|
| in | txdata   | pointer to bytes to send |
| in | txlength | number of bytes to send  |

## Returns

ATCA\_STATUS

## 18.9.4.70 kit\_receive()

HAL implementation to receive bytes and unwrap from kit protocol. This function calls back to the physical protocol to receive the bytes.

## **Parameters**

| in     | iface        | instance                                           |
|--------|--------------|----------------------------------------------------|
| in     | word_address | device transaction type                            |
| in     | rxdata       | pointer to space to receive the data               |
| in,out | rxsize       | ptr to expected number of receive bytes to request |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.71 kit\_send()

```
ATCA_STATUS kit_send (

ATCAIface iface,

uint8_t word_address,

uint8_t * txdata,

int txlength)
```

HAL implementation of kit protocol send. This function calls back to the physical protocol to send the bytes.

# **Parameters**

| in                      | iface                            | instance                 |                  |
|-------------------------|----------------------------------|--------------------------|------------------|
| in                      | word_address                     | device transaction type  |                  |
| in<br>© 2020 <b>M</b> i | txdata<br>crochip Technology Ind | pointer to bytes to send | toAuthLib v3.2.3 |
| in                      | txlength                         | number of bytes to send  |                  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.72 kit\_sleep()

```
ATCA_STATUS kit_sleep (
ATCAIface iface)
```

Call the sleep for kit protocol.

### **Parameters**

| in | iface | the interface object to send the bytes over |  |
|----|-------|---------------------------------------------|--|
|----|-------|---------------------------------------------|--|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.73 kit\_wake()

```
ATCA_STATUS kit_wake (
ATCAIface iface)
```

Call the wake for kit protocol.

## **Parameters**

| in | iface | the interface object to send the bytes over |
|----|-------|---------------------------------------------|
|----|-------|---------------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.74 kit\_wrap\_cmd()

Wrap binary bytes in ascii kit protocol.

### **Parameters**

| in     | txdata  | Binary data to wrap.                                                                                     |  |
|--------|---------|----------------------------------------------------------------------------------------------------------|--|
| in     | txlen   | Length of binary data in bytes.                                                                          |  |
| out    | pkitcmd | ASCII kit protocol wrapped data is return here.                                                          |  |
| in,out | nkitcmd | As input, the size of the pkitcmd buffer. As output, the number of bytes returned in the pkitcmd buffer. |  |
| in     | target  | Target char to use 's' for SHA devices, 'e' for ECC devices.                                             |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.75 strnchr()

# 18.9.4.76 swi\_uart\_deinit()

Implementation of SWI UART deinit.

HAL implementation of SWI UART deinit.

# **Parameters**

| ĺ | in | instance | instance |
|---|----|----------|----------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## **Parameters**

| in | instance | instance |
|----|----------|----------|

## Returns

ATCA\_SUCCESS

## 18.9.4.77 swi\_uart\_discover\_buses()

```
void swi_uart_discover_buses (
          int swi_uart_buses[],
          int max_buses )
```

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

#### **Parameters**

| in | swi_uart_buses | - an array of logical bus numbers                              |
|----|----------------|----------------------------------------------------------------|
| in | max_buses      | - maximum number of buses the app wants to attempt to discover |

# 18.9.4.78 swi\_uart\_init()

```
ATCA_STATUS swi_uart_init (

ATCASWIMaster_t * instance )
```

Implementation of SWI UART init.

HAL implementation of SWI UART init.

this HAL implementation assumes you've included the ASF SERCOM UART libraries in your project, otherwise, the HAL layer will not compile because the ASF UART drivers are a dependency \*

#### **Parameters**

| in <i>instance</i> | instance |
|--------------------|----------|
|--------------------|----------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

• this HAL implementation assumes you've included the START SERCOM UART libraries in your project, otherwise, the HAL layer will not compile because the START UART drivers are a dependency \*

# **Parameters**

| in | instance | instance |
|----|----------|----------|
|----|----------|----------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.9.4.79 swi\_uart\_mode()

implementation of SWI UART change mode.

HAL implementation of SWI UART change mode.

### **Parameters**

| in | instance | instance                        |
|----|----------|---------------------------------|
| in | mode     | (TRANSMIT_MODE or RECEIVE_MODE) |

## 18.9.4.80 swi\_uart\_receive\_byte()

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

## **Parameters**

| in  | instance | instance                             |
|-----|----------|--------------------------------------|
| out | data     | pointer to space to receive the data |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.81 swi\_uart\_send\_byte()

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

# **Parameters**

| in | instance | instance               |
|----|----------|------------------------|
| in | data     | number of byte to send |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.9.4.82 swi\_uart\_setbaud()

implementation of SWI UART change baudrate.

HAL implementation of SWI UART change baudrate.

### **Parameters**

| in | instance | instance                             |
|----|----------|--------------------------------------|
| in | baudrate | (typically 230400, 160000 or 115200) |
| in | instance | instance                             |
| in | baudrate | (typically 230400 or 115200)         |

# 18.9.5 Variable Documentation

# 18.9.5.1 pin\_conf

struct port\_config pin\_conf

# 18.10 Host side crypto methods (atcah)

Use these functions if your system does not use an ATCADevice as a host but implements the host in firmware. The functions provide host-side cryptographic functionality for an ATECC client device. They are intended to accompany the CryptoAuthLib functions. They can be called directly from an application, or integrated into an API.

### **Data Structures**

struct atca\_temp\_key

Structure to hold TempKey fields.

· struct atca include data in out

Input / output parameters for function atca\_include\_data().

struct atca\_nonce\_in\_out

Input/output parameters for function atca\_nonce().

- struct atca\_io\_decrypt\_in\_out
- struct atca\_verify\_mac
- · struct atca\_secureboot\_enc\_in\_out
- struct atca\_secureboot\_mac\_in\_out
- struct atca\_mac\_in\_out

Input/output parameters for function atca\_mac().

· struct atca hmac in out

Input/output parameters for function atca\_hmac().

· struct atca\_gen\_dig\_in\_out

Input/output parameters for function atcah\_gen\_dig().

struct atca\_write\_mac\_in\_out

Input/output parameters for function atcah\_write\_auth\_mac() and atcah\_privwrite\_auth\_mac().

struct atca\_derive\_key\_in\_out

Input/output parameters for function atcah\_derive\_key().

struct atca\_derive\_key\_mac\_in\_out

Input/output parameters for function atcah\_derive\_key\_mac().

struct atca\_decrypt\_in\_out

Input/output parameters for function atca\_decrypt().

struct atca\_check\_mac\_in\_out

Input/output parameters for function atcah\_check\_mac().

struct atca\_verify\_in\_out

Input/output parameters for function atcah\_verify().

struct atca\_gen\_key\_in\_out

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the <a href="atcah\_gen\_key\_msg(">atcah\_gen\_key\_msg()</a>) function.

struct atca\_sign\_internal\_in\_out

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

# **Typedefs**

- typedef struct atca\_temp\_key atca\_temp\_key\_t
  - Structure to hold TempKey fields.
- typedef struct atca nonce in out atca nonce in out t
- typedef struct atca\_io\_decrypt\_in\_out atca\_io\_decrypt\_in\_out\_t
- typedef struct atca\_verify\_mac atca\_verify\_mac\_in\_out\_t
- typedef struct atca\_secureboot\_enc\_in\_out atca\_secureboot\_enc\_in\_out\_t
- · typedef struct atca secureboot mac in out atca secureboot mac in out t
- · typedef struct atca mac in out atca mac in out t
- typedef struct atca\_gen\_dig\_in\_out atca\_gen\_dig\_in\_out\_t

Input/output parameters for function atcah\_gen\_dig().

typedef struct atca\_write\_mac\_in\_out atca\_write\_mac\_in\_out\_t

Input/output parameters for function atcah write auth mac() and atcah privwrite auth mac().

typedef struct atca\_check\_mac\_in\_out atca\_check\_mac\_in\_out\_t

Input/output parameters for function atcah check mac().

- typedef struct atca\_verify\_in\_out atca\_verify\_in\_out\_t
- typedef struct atca\_gen\_key\_in\_out atca\_gen\_key\_in\_out\_t

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the atcah\_gen\_key\_msg() function.

typedef struct atca\_sign\_internal\_in\_out atca\_sign\_internal\_in\_out\_t

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

### **Functions**

ATCA STATUS atcah nonce (struct atca nonce in out \*param)

This function calculates host side nonce with the parameters passed.

ATCA\_STATUS atcah\_mac (struct atca\_mac\_in\_out \*param)

This function generates an SHA-256 digest (MAC) of a key, challenge, and other information.

ATCA\_STATUS atcah\_check\_mac (struct atca\_check\_mac\_in\_out \*param)

This function performs the checkmac operation to generate client response on the host side .

ATCA\_STATUS atcah\_hmac (struct atca\_hmac\_in\_out \*param)

This function generates an HMAC / SHA-256 hash of a key and other information.

ATCA\_STATUS atcah\_gen\_dig (struct atca\_gen\_dig\_in\_out \*param)

This function combines the current TempKey with a stored value.

• ATCA\_STATUS atcah\_gen\_mac (struct atca\_gen\_dig\_in\_out \*param)

This function generates mac with session key with a plain text.

ATCA\_STATUS atcah\_write\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the Write command.

ATCA\_STATUS atcah\_privwrite\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the PrivWrite command.

ATCA\_STATUS atcah\_derive\_key (struct atca\_derive\_key\_in\_out \*param)

This function derives a key with a key and TempKey.

ATCA STATUS atcah derive key mac (struct atca derive key mac in out \*param)

This function calculates the input MAC for a DeriveKey command.

ATCA\_STATUS atcah\_decrypt (struct atca\_decrypt\_in\_out \*param)

This function decrypts 32-byte encrypted data received with the Read command.

ATCA STATUS atcah sha256 (int32 t len, const uint8 t \*message, uint8 t \*digest)

This function creates a SHA256 digest on a little-endian system.

uint8\_t \* atcah\_include\_data (struct atca\_include\_data\_in\_out \*param)

This function copies otp and sn data into a command buffer.

ATCA\_STATUS atcah\_gen\_key\_msg (struct atca\_gen\_key\_in\_out \*param)

Calculate the PubKey digest created by GenKey and saved to TempKey.

 ATCA\_STATUS atcah\_config\_to\_sign\_internal (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param, const uint8\_t \*config)

Populate the slot\_config, key\_config, and is\_slot\_locked fields in the atca\_sign\_internal\_in\_out structure from the provided config zone.

 ATCA\_STATUS atcah\_sign\_internal\_msg (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param)

Builds the full message that would be signed by the Sign(Internal) command.

ATCA\_STATUS atcah\_verify\_mac (atca\_verify\_mac\_in\_out\_t \*param)

Calculate the expected MAC on the host side for the Verify command.

ATCA\_STATUS atcah\_secureboot\_enc (atca\_secureboot\_enc\_in\_out\_t \*param)

Encrypts the digest for the SecureBoot command when using the encrypted digest / validating mac option.

ATCA STATUS atcah secureboot mac (atca secureboot mac in out t\*param)

Calculates the expected MAC returned from the SecureBoot command when verification is a success.

ATCA STATUS atcah encode counter match (uint32 t counter, uint8 t \*counter match)

Builds the counter match value that needs to be stored in a slot.

ATCA\_STATUS atcah\_io\_decrypt (struct atca\_io\_decrypt\_in\_out \*param)

Decrypt data that's been encrypted by the IO protection key. The ECDH and KDF commands on the ATECC608 are the only ones that support this operation.

#### **Variables**

```
uint8_t * p_temp
```

[out] pointer to output buffer

const uint8\_t \* otp

[in] pointer to one-time-programming data

const uint8\_t \* sn

[in] pointer to serial number data

• uint8 t mode

[in] Mode parameter used in Nonce command (Param1).

· uint16\_t zero

[in] Zero parameter used in Nonce command (Param2).

• const uint8 t \* num in

[in] Pointer to 20-byte NumIn data used in Nonce command.

const uint8\_t \* rand\_out

[in] Pointer to 32-byte RandOut data from Nonce command.

struct atca\_temp\_key \* temp\_key

[in,out] Pointer to TempKey structure.

uint8\_t mode

[in] Mode parameter used in MAC command (Param1).

· uint16\_t key\_id

[in] KeyID parameter used in MAC command (Param2).

const uint8 t \* challenge

[in] Pointer to 32-byte Challenge data used in MAC command, depending on mode.

const uint8\_t \* key

[in] Pointer to 32-byte key used to generate MAC digest.

const uint8\_t \* otp

[in] Pointer to 11-byte OTP, optionally included in MAC digest, depending on mode.

const uint8\_t \* sn

```
[in] Pointer to 9-byte SN, optionally included in MAC digest, depending on mode.
• uint8_t * response
     [out] Pointer to 32-byte SHA-256 digest (MAC).
struct atca_temp_key * temp_key
      [in,out] Pointer to TempKey structure.
• uint8 t mode
     [in] Mode parameter used in HMAC command (Param1).
· uint16_t key_id
     [in] KeyID parameter used in HMAC command (Param2).
const uint8_t * key
      [in] Pointer to 32-byte key used to generate HMAC digest.

    const uint8 t * otp

     [in] Pointer to 11-byte OTP, optionally included in HMAC digest, depending on mode.
• const uint8 t * sn
     [in] Pointer to 9-byte SN, optionally included in HMAC digest, depending on mode.

    uint8 t * response

     [out] Pointer to 32-byte SHA-256 HMAC digest.

    struct atca temp key * temp key

     [in,out] Pointer to TempKey structure.

    uint8 t * crypto data

     [in,out] Pointer to 32-byte data. Input encrypted data from Read command (Contents field), output decrypted.
struct atca_temp_key * temp_key
     [in,out] Pointer to TempKey structure.
• uint16 t curve type
     [in] Curve type used in Verify command (Param2).

    const uint8 t * signature

     [in] Pointer to ECDSA signature to be verified
const uint8_t * public_key
     [in] Pointer to the public key to be used for verification
struct atca_temp_key * temp_key
     [in,out] Pointer to TempKey structure.
```

## Definitions for ATECC Message Sizes to Calculate a SHA256 Hash

"||" is the concatenation operator. The number in braces is the length of the hash input value in bytes.

```
#define ATCA_MSG_SIZE_NONCE (55)

RandOut{32} || NumIn{20} || OpCode{1} || Mode{1} || LSB of Param2{1}.
#define ATCA_MSG_SIZE_MAC (88)

(Key or TempKey){32} || (Challenge or TempKey){32} || OpCode{1} || Mode{1} || Param2{2} || (OTP0_7 or 0){8} || (OTP8_10 or 0){3} || SN8{1} || (SN4_7 or 0){4} || SN0_1{2} || (SN2_3 or 0){2}
#define ATCA_MSG_SIZE_HMAC (88)
#define ATCA_MSG_SIZE_GEN_DIG (96)

KeyId{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0_1{2} || 0{25} || TempKey{32}.
#define ATCA_MSG_SIZE_DERIVE_KEY (96)

KeyId{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0_1{2} || 0{25} || TempKey{32}.
#define ATCA_MSG_SIZE_DERIVE_KEY_MAC (39)

KeyId{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0_1{2}.
#define ATCA_MSG_SIZE_DERIVE_KEY_MAC (39)
KeyId{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0_1{2}.
```

```
KeyId{32} || OpCode{1} || Param1{1} || Param2{2}|| SN8{1} || SN0_1{2} || 0{25} || TempKey{32}.
```

- #define ATCA\_MSG\_SIZE\_PRIVWRITE\_MAC (96)
  - KeyId{32} || OpCode{1} || Param1{1} || Param2{2}|| SN8{1} || SN0\_1{2} || 0{21} || PlainText{36}.
- #define ATCA\_COMMAND\_HEADER\_SIZE (4)
- #define ATCA GENDIG ZEROS SIZE (25)
- #define ATCA WRITE MAC ZEROS SIZE (25)
- #define ATCA PRIVWRITE MAC ZEROS SIZE (21)
- #define ATCA\_PRIVWRITE\_PLAIN\_TEXT\_SIZE (36)
- #define ATCA DERIVE KEY ZEROS SIZE (25)
- #define ATCA HMAC BLOCK SIZE (64)
- #define ENCRYPTION KEY SIZE (64)

# Default Fixed Byte Values of Serial Number (SN[0:1] and SN[8])

- #define ATCA SN 0 DEF (0x01)
- #define ATCA SN 1 DEF (0x23)
- #define ATCA\_SN\_8\_DEF (0xEE)

# **Definition for TempKey Mode**

• #define MAC\_MODE\_USE\_TEMPKEY\_MASK ((uint8\_t)0x03)

mode mask for MAC command when using TempKey

# 18.10.1 Detailed Description

Use these functions if your system does not use an ATCADevice as a host but implements the host in firmware. The functions provide host-side cryptographic functionality for an ATECC client device. They are intended to accompany the CryptoAuthLib functions. They can be called directly from an application, or integrated into an API.

Modern compilers can garbage-collect unused functions. If your compiler does not support this feature, you can just discard this module from your project if you do use an ATECC as a host. Or, if you don't, delete the functions you do not use.

### 18.10.2 Macro Definition Documentation

# 18.10.2.1 ATCA\_COMMAND\_HEADER\_SIZE

```
#define ATCA_COMMAND_HEADER_SIZE ( 4)
```

## 18.10.2.2 ATCA\_DERIVE\_KEY\_ZEROS\_SIZE

```
#define ATCA_DERIVE_KEY_ZEROS_SIZE (25)
```

## 18.10.2.3 ATCA\_GENDIG\_ZEROS\_SIZE

#define ATCA\_GENDIG\_ZEROS\_SIZE (25)

## 18.10.2.4 ATCA\_HMAC\_BLOCK\_SIZE

#define ATCA\_HMAC\_BLOCK\_SIZE (64)

# 18.10.2.5 ATCA\_MSG\_SIZE\_DERIVE\_KEY

#define ATCA\_MSG\_SIZE\_DERIVE\_KEY (96)

 $KeyId\{32\} \mid\mid OpCode\{1\} \mid\mid Param1\{1\} \mid\mid Param2\{2\} \mid\mid SN8\{1\} \mid\mid SN0\_1\{2\} \mid\mid 0\{25\} \mid\mid TempKey\{32\}.$ 

### 18.10.2.6 ATCA\_MSG\_SIZE\_DERIVE\_KEY\_MAC

#define ATCA\_MSG\_SIZE\_DERIVE\_KEY\_MAC (39)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0\_1{2}.

# 18.10.2.7 ATCA\_MSG\_SIZE\_ENCRYPT\_MAC

#define ATCA\_MSG\_SIZE\_ENCRYPT\_MAC (96)

 $KeyId\{32\} \mid\mid OpCode\{1\} \mid\mid Param1\{1\} \mid\mid Param2\{2\} \mid\mid SN8\{1\} \mid\mid SN0\_1\{2\} \mid\mid 0\{25\} \mid\mid TempKey\{32\}.$ 

# 18.10.2.8 ATCA\_MSG\_SIZE\_GEN\_DIG

#define ATCA\_MSG\_SIZE\_GEN\_DIG (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0\_1{2} || 0{25} || TempKey{32}.

## 18.10.2.9 ATCA\_MSG\_SIZE\_HMAC

#define ATCA\_MSG\_SIZE\_HMAC (88)

## 18.10.2.10 ATCA\_MSG\_SIZE\_MAC

#define ATCA\_MSG\_SIZE\_MAC (88)

(Key or TempKey){32} || (Challenge or TempKey){32} || OpCode{1} || Mode{1} || Param2{2} || (OTP0\_7 or 0){8} || (OTP8\_10 or 0){3} || SN8{1} || (SN4\_7 or 0){4} || SN0\_1{2} || (SN2\_3 or 0){2}

## 18.10.2.11 ATCA MSG SIZE NONCE

#define ATCA\_MSG\_SIZE\_NONCE (55)

RandOut{32} || NumIn{20} || OpCode{1} || Mode{1} || LSB of Param2{1}.

## 18.10.2.12 ATCA\_MSG\_SIZE\_PRIVWRITE\_MAC

#define ATCA\_MSG\_SIZE\_PRIVWRITE\_MAC (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2}|| SN8{1} || SN0\_1{2} || 0{21} || PlainText{36}.

# 18.10.2.13 ATCA\_PRIVWRITE\_MAC\_ZEROS\_SIZE

#define ATCA\_PRIVWRITE\_MAC\_ZEROS\_SIZE (21)

# 18.10.2.14 ATCA\_PRIVWRITE\_PLAIN\_TEXT\_SIZE

#define ATCA\_PRIVWRITE\_PLAIN\_TEXT\_SIZE (36)

# 18.10.2.15 ATCA\_SN\_0\_DEF

#define ATCA\_SN\_0\_DEF (0x01)

## 18.10.2.16 ATCA\_SN\_1\_DEF

#define ATCA\_SN\_1\_DEF (0x23)

# 18.10.2.17 ATCA\_SN\_8\_DEF

#define ATCA\_SN\_8\_DEF (0xEE)

# 18.10.2.18 ATCA\_WRITE\_MAC\_ZEROS\_SIZE

#define ATCA\_WRITE\_MAC\_ZEROS\_SIZE (25)

# 18.10.2.19 ENCRYPTION\_KEY\_SIZE

#define ENCRYPTION\_KEY\_SIZE (64)

# 18.10.2.20 MAC\_MODE\_USE\_TEMPKEY\_MASK

#define MAC\_MODE\_USE\_TEMPKEY\_MASK ((uint8\_t)0x03)

mode mask for MAC command when using TempKey

# 18.10.3 Typedef Documentation

## 18.10.3.1 atca\_check\_mac\_in\_out\_t

 ${\tt typedef \ struct \ atca\_check\_mac\_in\_out \ atca\_check\_mac\_in\_out\_t}$ 

Input/output parameters for function atcah\_check\_mac().

# 18.10.3.2 atca\_gen\_dig\_in\_out\_t

 ${\tt typedef\ struct\ atca\_gen\_dig\_in\_out\ atca\_gen\_dig\_in\_out\_t}$ 

Input/output parameters for function atcah\_gen\_dig().

## 18.10.3.3 atca\_gen\_key\_in\_out\_t

```
typedef struct atca_gen_key_in_out atca_gen_key_in_out_t
```

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the atcah\_gen\_key\_msg() function.

### 18.10.3.4 atca\_io\_decrypt\_in\_out\_t

typedef struct atca\_io\_decrypt\_in\_out atca\_io\_decrypt\_in\_out\_t

# 18.10.3.5 atca\_mac\_in\_out\_t

 ${\tt typedef \ struct \ atca\_mac\_in\_out \ atca\_mac\_in\_out\_t}$ 

### 18.10.3.6 atca\_nonce\_in\_out\_t

typedef struct atca\_nonce\_in\_out atca\_nonce\_in\_out\_t

# 18.10.3.7 atca\_secureboot\_enc\_in\_out\_t

 ${\tt typedef \ struct \ atca\_secureboot\_enc\_in\_out \ atca\_secureboot\_enc\_in\_out\_t}$ 

## 18.10.3.8 atca\_secureboot\_mac\_in\_out\_t

typedef struct atca\_secureboot\_mac\_in\_out atca\_secureboot\_mac\_in\_out\_t

## 18.10.3.9 atca\_sign\_internal\_in\_out\_t

 ${\tt typedef \ struct \ atca\_sign\_internal\_in\_out \ atca\_sign\_internal\_in\_out\_t}$ 

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

## 18.10.3.10 atca\_temp\_key\_t

```
typedef struct atca_temp_key atca_temp_key_t
```

Structure to hold TempKey fields.

## 18.10.3.11 atca\_verify\_in\_out\_t

```
{\tt typedef \ struct \ atca\_verify\_in\_out \ atca\_verify\_in\_out\_t}
```

# 18.10.3.12 atca\_verify\_mac\_in\_out\_t

```
typedef struct atca_verify_mac atca_verify_mac_in_out_t
```

### 18.10.3.13 atca\_write\_mac\_in\_out\_t

```
typedef struct atca_write_mac_in_out atca_write_mac_in_out_t
```

Input/output parameters for function atcah\_write\_auth\_mac() and atcah\_privwrite\_auth\_mac().

# 18.10.4 Function Documentation

## 18.10.4.1 atcah\_check\_mac()

```
ATCA_STATUS atcah_check_mac ( struct atca_check_mac_in_out * param )
```

This function performs the checkmac operation to generate client response on the host side .

## **Parameters**

| in,out | param | Input and output parameters |
|--------|-------|-----------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 312

## 18.10.4.2 atcah\_config\_to\_sign\_internal()

Populate the slot\_config, key\_config, and is\_slot\_locked fields in the atca\_sign\_internal\_in\_out structure from the provided config zone.

The atca\_sign\_internal\_in\_out structure has a number of fields (slot\_config, key\_config, is\_slot\_locked) that can be determined automatically from the current state of TempKey and the full config zone.

#### **Parameters**

| in,out | param       | Sign(Internal) parameters to be filled out. Only slot_config, key_config, and is_slot_locked will be set. |
|--------|-------------|-----------------------------------------------------------------------------------------------------------|
| in     | device_type | The type of the device.                                                                                   |
| in     | config      | Full 128 byte config zone for the device.                                                                 |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.10.4.3 atcah\_decrypt()

This function decrypts 32-byte encrypted data received with the Read command.

To use this function, first the nonce must be valid and synchronized between device and application. The application sends a GenDig command to the Device, using a key specified by SlotConfig.ReadKey. The device updates its TempKey. The application then updates its own TempKey using the GenDig calculation function, using the same key. The application sends a Read command to the device for a user zone configured with EncryptRead. The device encrypts 32-byte zone content, and outputs it to the host. The application passes these encrypted data to this decryption function. The function decrypts the data and returns them. TempKey must be updated by Gen $_{\rm C}$ Dig using a ParentKey as specified by SlotConfig.ReadKey before executing this function. The decryption function does not check whether the TempKey has been generated by a correct ParentKey for the corresponding zone. Therefore to get a correct result, the application has to make sure that prior GenDig calculation was done using correct ParentKey.

#### **Parameters**

| in, out   param   pointer to parameter structure |
|--------------------------------------------------|
|--------------------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.10.4.4 atcah\_derive\_key()

```
ATCA_STATUS atcah_derive_key (
struct atca_derive_key_in_out * param )
```

This function derives a key with a key and TempKey.

Used in conjunction with DeriveKey command, the key derived by this function will match the key in the device. Two kinds of operation are supported:

- Roll Key operation: target\_key and parent\_key parameters should be set to point to the same location (TargetKey).
- Create Key operation: target\_key should be set to point to TargetKey, parent\_key should be set to point to ParentKey.

After executing this function, the initial value of target\_key will be overwritten with the derived key. The TempKey should be valid (temp\_key.valid = 1) before executing this function.

#### **Parameters**

| in,out <i>param</i> | pointer to parameter structure |
|---------------------|--------------------------------|
|---------------------|--------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.5 atcah\_derive\_key\_mac()

```
ATCA_STATUS atcah_derive_key_mac (
struct atca_derive_key_mac_in_out * param )
```

This function calculates the input MAC for a DeriveKey command.

The DeriveKey command will need an input MAC if SlotConfig[TargetKey].Bit15 is set.

## **Parameters**

| in,ou | t <i>param</i> | pointer to parameter structure |
|-------|----------------|--------------------------------|

## Returns

ATCA SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 314

## 18.10.4.6 atcah\_encode\_counter\_match()

Builds the counter match value that needs to be stored in a slot.

#### **Parameters**

| in  | counter_value       | Counter value to be used for the counter match. This must be a multiple of 32. |
|-----|---------------------|--------------------------------------------------------------------------------|
| out | counter_match_value | Data to be stored in the beginning of a counter match slot will be returned    |
|     |                     | here (8 bytes).                                                                |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.10.4.7 atcah\_gen\_dig()

```
ATCA_STATUS atcah_gen_dig ( struct atca_gen_dig_in_out * param )
```

This function combines the current TempKey with a stored value.

The stored value can be a data slot, OTP page, configuration zone, or hardware transport key. The TempKey generated by this function will match with the TempKey in the device generated when executing a GenDig command. The TempKey should be valid (temp\_key.valid = 1) before executing this function. To use this function, an application first sends a GenDig command with a chosen stored value to the device. This stored value must be known by the application and is passed to this GenDig calculation function. The function calculates a new TempKey and returns it.

## **Parameters**

| in,out | param | pointer to parameter structure    |
|--------|-------|-----------------------------------|
|        |       | pointer to pointing on a distance |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.8 atcah\_gen\_key\_msg()

Calculate the PubKey digest created by GenKey and saved to TempKey.

#### **Parameters**

| in,out | param | GenKey parameters required to calculate the PubKey digest. Digest is return in the |
|--------|-------|------------------------------------------------------------------------------------|
|        |       | temp_key parameter.                                                                |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.9 atcah\_gen\_mac()

```
ATCA_STATUS atcah_gen_mac ( struct atca_gen_dig_in_out * param )
```

This function generates mac with session key with a plain text.

## **Parameters**

|  | in,out | param | pointer to parameter structure |  |
|--|--------|-------|--------------------------------|--|
|--|--------|-------|--------------------------------|--|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.10 atcah\_hmac()

```
ATCA_STATUS atcah_hmac ( struct atca_hmac_in_out * param )
```

This function generates an HMAC  $\!\!/$  SHA-256 hash of a key and other information.

The resulting hash will match with the one generated in the device by an HMAC command. The TempKey has to be valid (temp\_key.valid = 1) before executing this function.

## **Parameters**

| param | pointer to parameter structure |
|-------|--------------------------------|
| ı     | param                          |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 18.10.4.11 atcah\_include\_data()

This function copies otp and sn data into a command buffer.

### **Parameters**

| in,out <i>param</i> | pointer to parameter structure |
|---------------------|--------------------------------|
|---------------------|--------------------------------|

### **Returns**

pointer to command buffer byte that was copied last

## 18.10.4.12 atcah\_io\_decrypt()

Decrypt data that's been encrypted by the IO protection key. The ECDH and KDF commands on the ATECC608 are the only ones that support this operation.

# Parameters

| in,out | param | Parameters required to perform the operation. |
|--------|-------|-----------------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.13 atcah\_mac()

```
ATCA_STATUS atcah_mac ( struct atca_mac_in_out * param )
```

This function generates an SHA-256 digest (MAC) of a key, challenge, and other information.

The resulting digest will match with the one generated by the device when executing a MAC command. The Temp $\leftarrow$  Key (if used) should be valid (temp key.valid = 1) before executing this function.

## **Parameters**

| in,out | param | pointer to parameter structure |
|--------|-------|--------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.14 atcah\_nonce()

```
ATCA_STATUS atcah_nonce ( struct atca_nonce_in_out * param )
```

This function calculates host side nonce with the parameters passed.

### **Parameters**

| in,out <i>param</i> | pointer to parameter structure |
|---------------------|--------------------------------|
|---------------------|--------------------------------|

### **Returns**

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.15 atcah\_privwrite\_auth\_mac()

This function calculates the input MAC for the PrivWrite command.

The PrivWrite command will need an input MAC if SlotConfig.WriteConfig.Encrypt is set.

## **Parameters**

| in,out | param | pointer to parameter structure |
|--------|-------|--------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.16 atcah\_secureboot\_enc()

Encrypts the digest for the SecureBoot command when using the encrypted digest / validating mac option.

### **Parameters**

| in,out para | Data required to perform the operation. |
|-------------|-----------------------------------------|
|-------------|-----------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.10.4.17 atcah\_secureboot\_mac()

Calculates the expected MAC returned from the SecureBoot command when verification is a success.

The result of this function (param->mac) should be compared with the actual MAC returned to validate the response.

### **Parameters**

|  | in,out | param | Data required to perform the operation. |  |
|--|--------|-------|-----------------------------------------|--|
|--|--------|-------|-----------------------------------------|--|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.18 atcah\_sha256()

This function creates a SHA256 digest on a little-endian system.

## **Parameters**

| in  | len     | byte length of message |
|-----|---------|------------------------|
| in  | message | pointer to message     |
| out | digest  | SHA256 of message      |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.10.4.19 atcah\_sign\_internal\_msg()

Builds the full message that would be signed by the Sign(Internal) command.

Additionally, the function will optionally output the OtherData data required by the Verify(In/Validate) command as well as the SHA256 digest of the full message.

#### **Parameters**

| out | device_type | Device type to perform the calculation for. |
|-----|-------------|---------------------------------------------|
| out | param       | Input data and output buffers required.     |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.4.20 atcah\_verify\_mac()

Calculate the expected MAC on the host side for the Verify command.

#### **Parameters**

| in,out | param | Data required to perform the operation. |
|--------|-------|-----------------------------------------|
|--------|-------|-----------------------------------------|

### Returns

ATCA SUCCESS on success, otherwise an error code.

# 18.10.4.21 atcah\_write\_auth\_mac()

```
ATCA_STATUS atcah_write_auth_mac (
    struct atca_write_mac_in_out * param )
```

This function calculates the input MAC for the Write command.

The Write command will need an input MAC if SlotConfig.WriteConfig.Encrypt is set.

# 18.10 Host side crypto methods (atcah\_)

## **Parameters**

| in,out <i>param</i> | pointer to parameter structure |
|---------------------|--------------------------------|
|---------------------|--------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.10.5 Variable Documentation

# 18.10.5.1 challenge

challenge

[in] Pointer to 32-byte Challenge data used in MAC command, depending on mode.

# 18.10.5.2 crypto\_data

crypto\_data

[in,out] Pointer to 32-byte data. Input encrypted data from Read command (Contents field), output decrypted.

# 18.10.5.3 curve\_type

curve\_type

[in] Curve type used in Verify command (Param2).

### 18.10.5.4 key [1/2]

key

[in] Pointer to 32-byte key used to generate MAC digest.

# 18.10.5.5 key [2/2] key [in] Pointer to 32-byte key used to generate HMAC digest. 18.10.5.6 key\_id [1/2] key\_id [in] KeyID parameter used in MAC command (Param2). 18.10.5.7 key\_id [2/2] key\_id [in] KeyID parameter used in HMAC command (Param2). 18.10.5.8 mode [1/3] mode [in] Mode parameter used in Nonce command (Param1). 18.10.5.9 mode [2/3] mode [in] Mode parameter used in MAC command (Param1). 18.10.5.10 mode [3/3] mode [in] Mode parameter used in HMAC command (Param1).

# 18.10 Host side crypto methods (atcah\_) 18.10.5.11 num\_in num\_in [in] Pointer to 20-byte NumIn data used in Nonce command. **18.10.5.12** otp [1/3] otp [in] pointer to one-time-programming data 18.10.5.13 otp [2/3] otp [in] Pointer to 11-byte OTP, optionally included in MAC digest, depending on mode. 18.10.5.14 otp [3/3] otp [in] Pointer to 11-byte OTP, optionally included in HMAC digest, depending on mode. 18.10.5.15 p\_temp p\_temp [out] pointer to output buffer

# 18.10.5.16 public\_key

public\_key

[in] Pointer to the public key to be used for verification

# 18.10.5.17 rand\_out rand\_out [in] Pointer to 32-byte RandOut data from Nonce command. 18.10.5.18 response [1/2] response [out] Pointer to 32-byte SHA-256 digest (MAC). 18.10.5.19 response [2/2] response [out] Pointer to 32-byte SHA-256 HMAC digest. 18.10.5.20 signature signature [in] Pointer to ECDSA signature to be verified 18.10.5.21 sn [1/3] sn [in] pointer to serial number data

[in] Pointer to 9-byte SN, optionally included in MAC digest, depending on mode.

18.10.5.22 sn [2/3]

sn

## 18.10.5.23 sn [3/3]

sn

[in] Pointer to 9-byte SN, optionally included in HMAC digest, depending on mode.

## 18.10.5.24 temp\_key [1/5]

temp\_key

[in,out] Pointer to TempKey structure.

## 18.10.5.25 temp\_key [2/5]

temp\_key

[in,out] Pointer to TempKey structure.

## 18.10.5.26 temp\_key [3/5]

temp\_key

[in,out] Pointer to TempKey structure.

# 18.10.5.27 temp\_key [4/5]

temp\_key

[in,out] Pointer to TempKey structure.

# 18.10.5.28 temp\_key [5/5]

temp\_key

[in,out] Pointer to TempKey structure.

#### 18.10.5.29 zero

zero

[in] Zero parameter used in Nonce command (Param2).

# 18.11 JSON Web Token (JWT) methods (atca\_jwt\_)

Methods for signing and verifying JSON Web Token (JWT) tokens.

### **Data Structures**

· struct atca\_jwt\_t

Structure to hold metadata information about the jwt being built.

#### **Functions**

- ATCA\_STATUS atca\_jwt\_init (atca\_jwt\_t \*jwt, char \*buf, uint16\_t buflen)
   Initialize a JWT structure.
- ATCA\_STATUS atca\_jwt\_add\_claim\_string (atca\_jwt\_t \*jwt, const char \*claim, const char \*value)

  Add a string claim to a token.
- ATCA\_STATUS atca\_jwt\_add\_claim\_numeric (atca\_jwt\_t \*jwt, const char \*claim, int32\_t value)

  Add a numeric claim to a token.
- ATCA\_STATUS atca\_jwt\_finalize (atca\_jwt\_t \*jwt, uint16\_t key\_id)

Close the claims of a token, encode them, then sign the result.

void atca\_jwt\_check\_payload\_start (atca\_jwt\_t \*jwt)

Check the provided context to see what character needs to be added in order to append a claim.

ATCA\_STATUS atca\_jwt\_verify (const char \*buf, uint16\_t buflen, const uint8\_t \*pubkey)

Verifies the signature of a jwt using the provided public key.

# 18.11.1 Detailed Description

Methods for signing and verifying JSON Web Token (JWT) tokens.

#### 18.11.2 Function Documentation

# 18.11.2.1 atca\_jwt\_add\_claim\_numeric()

```
ATCA_STATUS atca_jwt_add_claim_numeric (
    atca_jwt_t * jwt,
    const char * claim,
    int32_t value )
```

Add a numeric claim to a token.

Note

This function does not escape strings so the user has to ensure the claim is valid first

#### 18.11.2.2 atca\_jwt\_add\_claim\_string()

Add a string claim to a token.

Note

This function does not escape strings so the user has to ensure they are valid for use in a JSON string first

# 18.11.2.3 atca\_jwt\_check\_payload\_start()

Check the provided context to see what character needs to be added in order to append a claim.

#### 18.11.2.4 atca jwt finalize()

Close the claims of a token, encode them, then sign the result.

# 18.11.2.5 atca\_jwt\_init()

Initialize a JWT structure.

#### 18.11.2.6 atca\_jwt\_verify()

Verifies the signature of a jwt using the provided public key.

# 18.12 mbedTLS Wrapper methods (atca\_mbedtls\_)

These methods are for interfacing cryptoauthlib to mbedtls.

#### **Functions**

- int atca\_mbedtls\_pk\_init (struct mbedtls\_pk\_context \*pkey, const uint16\_t slotid)
   Initializes an mbedtls pk context for use with EC operations.
- int atca\_mbedtls\_cert\_add (struct mbedtls\_x509\_crt \*cert, const struct atcacert\_def\_s \*cert\_def)
- int atca\_mbedtls\_ecdh\_slot\_cb (void)

ECDH Callback to obtain the "slot" used in ECDH operations from the application.

int atca\_mbedtls\_ecdh\_ioprot\_cb (uint8\_t secret[32])

ECDH Callback to obtain the IO Protection secret from the application.

# 18.12.1 Detailed Description

These methods are for interfacing cryptoauthlib to mbedtls.

#### 18.12.2 Function Documentation

### 18.12.2.1 atca\_mbedtls\_cert\_add()

#### 18.12.2.2 atca\_mbedtls\_ecdh\_ioprot\_cb()

ECDH Callback to obtain the IO Protection secret from the application.

#### **Parameters**

```
out secret 32 byte array used to store the secret
```

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 18.12.2.3 atca\_mbedtls\_ecdh\_slot\_cb()

ECDH Callback to obtain the "slot" used in ECDH operations from the application.

# Returns

Slot Number

### 18.12.2.4 atca\_mbedtls\_pk\_init()

Initializes an mbedtls pk context for use with EC operations.

### **Parameters**

| in,out | pkey   | ptr to space to receive version string |
|--------|--------|----------------------------------------|
| in     | slotid | Associated with this key               |

#### Returns

0 on success, otherwise an error code.

# 18.13 Attributes (pkcs11 attrib )

#### **Data Structures**

• struct \_pcks11\_mech\_table\_e

#### **Macros**

- #define PCKS11\_MECH\_ECC508\_EC\_CAPABILITY (CKF\_EC\_F\_P | CKF\_EC\_NAMEDCURVE | CKF\_EC\_UNCOMPRESS)
- #define TABLE\_SIZE(x) sizeof(x) / sizeof(x[0])

### **Typedefs**

- typedef struct pcks11 mech table e pcks11 mech table e
- typedef struct \_pcks11\_mech\_table\_e \* pcks11\_mech\_table\_ptr

#### **Functions**

CK\_RV pkcs11\_attrib\_fill (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_VOID\_PTR pData, const CK\_ULONG ulSize)

Perform the nessasary checks and copy data into an attribute structure.

 CK\_RV pkcs11\_attrib\_value (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_ULONG ulValue, const CK\_ULONG ulSize)

Helper function to write a numerical value to an attribute buffer.

- CK\_RV pkcs11\_attrib\_false (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_attrib\_true (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_attrib\_empty (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_encoded (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_subject (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_subject\_key\_id (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_authority\_key\_id (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_trusted\_flag (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_x509\_write (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- void pkcs11\_config\_init\_private (pkcs11\_object\_ptr pObject, char \*label, size\_t len)
- void pkcs11 config init public (pkcs11 object ptr pObject, char \*label, size t len)
- void pkcs11\_config\_init\_cert (pkcs11\_object\_ptr pObject, char \*label, size\_t len)
- CK\_RV pkcs11\_config\_cert (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p↔ Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK\_RV pkcs11\_config\_key (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p
   — Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK\_RV pkcs11\_config\_remove\_object (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr pObject)
- CK\_RV pkcs11\_config\_load\_objects (pkcs11\_slot\_ctx\_ptr slot\_ctx)
- CK\_RV pkcs11\_config\_load (pkcs11\_slot\_ctx\_ptr slot\_ctx)
- CK\_RV pkcs11\_find\_init (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_find\_continue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE\_PTR phObject, CK\_ULONG ulMaxObjectCount, CK\_ULONG\_PTR pulObjectCount)
- CK\_RV pkcs11\_find\_finish (CK\_SESSION\_HANDLE hSession)

- CK\_RV pkcs11\_find\_get\_attribute (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_get\_lib\_info (CK\_INFO\_PTR pInfo)

Obtains general information about Cryptoki.

pkcs11\_lib\_ctx\_ptr pkcs11\_get\_context (void)

Retrieve the current library context.

- CK RV pkcs11 lock context (pkcs11 lib ctx ptr pContext)
- CK RV pkcs11 unlock context (pkcs11 lib ctx ptr pContext)
- CK\_RV pkcs11\_init\_check (pkcs11\_lib\_ctx\_ptr \*ppContext, CK\_BBOOL lock)

Check if the library is initialized properly.

• CK\_RV pkcs11\_init (CK\_C\_INITIALIZE\_ARGS\_PTR plnitArgs)

Initializes the PKCS11 API Library for Cryptoauthlib.

- CK\_RV pkcs11\_deinit (CK\_VOID\_PTR pReserved)
- CK\_RV pkcs11\_key\_write (CK\_VOID\_PTR pSession, CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR p

  Attribute)
- CK\_RV pkcs11\_key\_generate\_pair (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p
   Mechanism, CK\_ATTRIBUTE\_PTR pPublicKeyTemplate, CK\_ULONG ulPublicKeyAttributeCount,
   CK\_ATTRIBUTE\_PTR pPrivateKeyTemplate, CK\_ULONG ulPrivateKeyAttributeCount, CK\_OBJECT\_HANDLE\_PTR
   phPublicKey, CK\_OBJECT\_HANDLE\_PTR phPrivateKey)
- CK\_RV pkcs11\_key\_derive (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hBaseKey, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)
- CK RV C Initialize (CK VOID PTR pInitArgs)

Initializes Cryptoki library NOTES: If plnitArgs is a non-NULL\_PTR is must dereference to a CK\_C\_INITIALIZE\_ARGS structure.

CK RV C Finalize (CK VOID PTR pReserved)

Clean up miscellaneous Cryptoki-associated resources.

• CK\_RV C\_GetInfo (CK\_INFO\_PTR pInfo)

Obtains general information about Cryptoki.

• CK\_RV C\_GetFunctionList (CK\_FUNCTION\_LIST\_PTR\_PTR ppFunctionList)

Obtains entry points of Cryptoki library functions.

CK\_RV C\_GetSlotList (CK\_BBOOL tokenPresent, CK\_SLOT\_ID\_PTR pSlotList, CK\_ULONG\_PTR pul
 — Count)

Obtains a list of slots in the system.

• CK RV C GetSlotInfo (CK SLOT ID slotID, CK SLOT INFO PTR pInfo)

Obtains information about a particular slot.

• CK\_RV C\_GetTokenInfo (CK\_SLOT\_ID slotID, CK\_TOKEN\_INFO\_PTR pInfo)

Obtains information about a particular token.

 CK\_RV C\_GetMechanismList (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE\_PTR pMechanismList, CK\_ULONG\_PTR pulCount)

Obtains a list of mechanisms supported by a token (in a slot)

CK\_RV C\_GetMechanismInfo (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE type, CK\_MECHANISM\_INFO\_PTR plnfo)

Obtains information about a particular mechanism of a token (in a slot)

• CK\_RV C\_InitToken (CK\_SLOT\_ID slotID, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen, CK\_UTF8CHAR\_PTR pLabel)

Initializes a token (in a slot)

- CK\_RV C\_InitPIN (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)

  Initializes the normal user's PIN.
- CK\_RV C\_SetPIN (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pOldPin, CK\_ULONG ulOld ← Len, CK\_UTF8CHAR\_PTR pNewPin, CK\_ULONG ulNewLen)

Modifies the PIN of the current user.

CK\_RV C\_OpenSession (CK\_SLOT\_ID slotID, CK\_FLAGS flags, CK\_VOID\_PTR pApplication, CK\_NOTIFY notify, CK\_SESSION\_HANDLE\_PTR phSession)

Opens a connection between an application and a particular token or sets up an application callback for token insertion.

• CK\_RV C\_CloseSession (CK\_SESSION\_HANDLE hSession)

Close the given session.

CK\_RV C\_CloseAllSessions (CK\_SLOT\_ID slotID)

Close all open sessions.

· CK RV C GetSessionInfo (CK SESSION HANDLE hSession, CK SESSION INFO PTR pInfo)

Retrieve information about the specified session.

• CK\_RV C\_GetOperationState (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pOperationState, CK\_ULONG\_PTR pulOperationStateLen)

Obtains the cryptographic operations state of a session.

 CK\_RV C\_SetOperationState (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pOperationState, CK\_ULONG ulOperationStateLen, CK\_OBJECT\_HANDLE hEncryptionKey, CK\_OBJECT\_HANDLE h

AuthenticationKey)

Sets the cryptographic operations state of a session.

 CK\_RV C\_Login (CK\_SESSION\_HANDLE hSession, CK\_USER\_TYPE userType, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)

Login on the token in the specified session.

• CK\_RV C\_Logout (CK\_SESSION\_HANDLE hSession)

Log out of the token in the specified session.

CK\_RV C\_CreateObject (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phObject)

Create a new object on the token in the specified session using the given attribute template.

 CK\_RV C\_CopyObject (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phNewObject)

Create a copy of the object with the specified handle.

CK\_RV C\_DestroyObject (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)
 Destroy the specified object.

• CK\_RV C\_GetObjectSize (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ULONG\_PTR pulSize)

Obtains the size of an object in bytes.

• CK\_RV C\_GetAttributeValue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

Obtains an attribute value of an object.

 CK\_RV C\_SetAttributeValue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

Change or set the value of the specified attributes on the specified object.

 CK\_RV C\_FindObjectsInit (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

Initializes an object search in the specified session using the specified attribute template as search parameters.

 CK\_RV C\_FindObjects (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE\_PTR phObject, CK\_ULONG ulMaxObjectCount, CK\_ULONG\_PTR pulObjectCount)

Continue the search for objects in the specified session.

• CK\_RV C\_FindObjectsFinal (CK\_SESSION\_HANDLE hSession)

Finishes an object search operation (and cleans up)

 CK\_RV C\_EncryptInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hObject)

Initializes an encryption operation using the specified mechanism and session.

 CK\_RV C\_Encrypt (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Perform a single operation encryption operation in the specified session.

CK\_RV C\_EncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ul
 — DataLen, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Continues a multiple-part encryption operation.

CK\_RV C\_EncryptFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Finishes a multiple-part encryption operation.

 CK\_RV C\_DecryptInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hObject)

Initialize decryption using the specified object.

Perform a single operation decryption in the given session.

• CK\_RV C\_DecryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG ulEncryptedDataLen, CK\_BYTE\_PTR pData, CK\_ULONG\_PTR pDataLen)

Continues a multiple-part decryption operation.

Finishes a multiple-part decryption operation.

• CK RV C DigestInit (CK SESSION HANDLE hSession, CK MECHANISM PTR pMechanism)

Initializes a message-digesting operation using the specified mechanism in the specified session.

 CK\_RV C\_Digest (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Digest the specified data in a one-pass operation and return the resulting digest.

- CK\_RV C\_DigestUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen) Continues a multiple-part digesting operation.
- CK\_RV C\_DigestKey (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)

Update a running digest operation by digesting a secret key with the specified handle.

CK\_RV C\_DigestFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Finishes a multiple-part digesting operation.

• CK\_RV C\_SignInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initialize a signing operation using the specified key and mechanism.

• CK\_RV C\_Sign (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Sign the data in a single pass operation.

- CK\_RV C\_SignUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen) Continues a multiple-part signature operation.
- CK\_RV C\_SignFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Finishes a multiple-part signature operation.

 CK\_RV C\_SignRecoverInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK OBJECT HANDLE hKey)

Initializes a signature operation, where the data can be recovered from the signature.

CK\_RV C\_SignRecover (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulData
 — Len, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Signs single-part data, where the data can be recovered from the signature.

CK\_RV C\_VerifyInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation using the specified key and mechanism.

• CK\_RV C\_Verify (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Verifies a signature on single-part data.

- CK\_RV C\_VerifyUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

  Continues a multiple-part verification operation.
- CK\_RV C\_VerifyFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG ul
   — SignatureLen)

Finishes a multiple-part verification operation.

• CK\_RV C\_VerifyRecoverInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation where the data is recovered from the signature.

CK\_RV C\_VerifyRecover (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG ul
 — SignatureLen, CK\_BYTE\_PTR pData, CK\_ULONG\_PTR pulDataLen)

Verifies a signature on single-part data, where the data is recovered from the signature.

• CK\_RV C\_DigestEncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen, CK\_BYTE\_PTR pEncryptedPart, CK\_ULONG\_PTR pulEncryptedPartLen)

Continues simultaneous multiple-part digesting and encryption operations.

• CK\_RV C\_DecryptDigestUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen, CK\_BYTE\_PTR pDecryptedPart, CK\_ULONG\_PTR pulDecryptedPartLen)

Continues simultaneous multiple-part decryption and digesting operations.

CK\_RV C\_SignEncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ul
 — PartLen, CK BYTE PTR pEncryptedPart, CK ULONG PTR pulEncryptedPartLen)

Continues simultaneous multiple-part signature and encryption operations.

• CK\_RV C\_DecryptVerifyUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedPart, CK ULONG ulEncryptedPartLen, CK BYTE PTR pPart, CK ULONG PTR pulPartLen)

Continues simultaneous multiple-part decryption and verification operations.

• CK\_RV C\_GenerateKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Generates a secret key using the specified mechanism.

 CK\_RV C\_GenerateKeyPair (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_ATTRIBUTE\_PTR pPublicKeyTemplate, CK\_ULONG ulPublicKeyAttributeCount, CK\_ATTRIBUTE\_PTR pPrivateKeyTemplate, CK\_ULONG ulPrivateKeyAttributeCount, CK\_OBJECT\_HANDLE\_PTR phPublicKey, CK\_OBJECT\_HANDLE\_PTR phPrivateKey)

Generates a public-key/private-key pair using the specified mechanism.

 CK\_RV C\_WrapKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hWrappingKey, CK\_OBJECT\_HANDLE hKey, CK\_BYTE\_PTR pWrappedKey, CK\_ULONG\_PTR pul← WrappedKeyLen)

Wraps (encrypts) the specified key using the specified wrapping key and mechanism.

• CK\_RV C\_UnwrapKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hUnwrappingKey, CK\_BYTE\_PTR pWrappedKey, CK\_ULONG ulWrappedKey Len, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Unwraps (decrypts) the specified key using the specified unwrapping key.

 CK\_RV C\_DeriveKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hBaseKey, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Derive a key from the specified base key.

Mixes in additional seed material to the random number generator.

• CK\_RV C\_GenerateRandom (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pRandomData, CK\_ULONG\_ulRandomLen)

Generate the specified amount of random data.

• CK RV C\_GetFunctionStatus (CK\_SESSION\_HANDLE hSession)

Legacy function - see PKCS#11 v2.40.

• CK\_RV C\_CancelFunction (CK\_SESSION\_HANDLE hSession)

Legacy function

• CK RV C WaitForSlotEvent (CK FLAGS flags, CK SLOT ID PTR pSlot, CK VOID PTR pReserved)

Wait for a slot event (token insertion, removal, etc) on the specified slot to occur.

- CK\_RV pkcs11\_mech\_get\_list (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE\_PTR pMechanismList, CK\_ULONG\_PTR pulCount)
- CK\_RV pkcs\_mech\_get\_info (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE type, CK\_MECHANISM\_INFO\_PTR plnfo)
- CK\_RV pkcs11\_object\_alloc (pkcs11\_object\_ptr \*ppObject)

\*\*

- CK\_RV pkcs11\_object\_free (pkcs11\_object\_ptr pObject)
- CK\_RV pkcs11\_object\_check (pkcs11\_object\_ptr \*ppObject, CK\_OBJECT\_HANDLE hObject)
- CK RV pkcs11 object get handle (pkcs11 object ptr pObject, CK OBJECT HANDLE PTR phObject)
- CK RV pkcs11 object get name (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_class (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK RV pkcs11 object get type (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_destroyable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_size (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ULONG\_PTR\_pulSize)
- CK\_RV pkcs11\_object\_find (pkcs11\_object\_ptr \*ppObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_object\_create (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phObject)

Create a new object on the token in the specified session using the given attribute template.

• CK\_RV pkcs11\_object\_destroy (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)

Destroy the specified object.

- CK\_RV pkcs11\_object\_deinit (pkcs11\_lib\_ctx\_ptr pContext)
- CK RV pkcs11 object load handle info (pkcs11 lib ctx ptr pContext)
- CK RV pkcs11 os create mutex (CK VOID PTR PTR ppMutex)

Application callback for creating a mutex object.

- CK RV pkcs11 os destroy mutex (CK VOID PTR pMutex)
- CK\_RV pkcs11\_os\_lock\_mutex (CK\_VOID\_PTR pMutex)
- CK\_RV pkcs11\_os\_unlock\_mutex (CK\_VOID\_PTR pMutex)
- pkcs11\_session\_ctx\_ptr pkcs11\_get\_session\_context (CK\_SESSION\_HANDLE hSession)
- CK\_RV pkcs11\_session\_check (pkcs11\_session\_ctx\_ptr \*pSession, CK\_SESSION\_HANDLE hSession)

  Check if the session is initialized properly.

Oricox ii tile session is iiittanzea property.

- CK\_RV pkcs11\_session\_open (CK\_SLOT\_ID slotID, CK\_FLAGS flags, CK\_VOID\_PTR pApplication, CK\_
   —
   NOTIFY notify, CK\_SESSION\_HANDLE\_PTR phSession)
- CK\_RV pkcs11\_session\_close (CK\_SESSION\_HANDLE hSession)
- CK RV pkcs11 session closeall (CK SLOT ID slotID)

Close all sessions for a given slot - not actually all open sessions.

- CK\_RV pkcs11\_session\_get\_info (CK\_SESSION\_HANDLE hSession, CK\_SESSION\_INFO\_PTR plnfo)
   Obtains information about a particular session.
- CK\_RV pkcs11\_session\_login (CK\_SESSION\_HANDLE hSession, CK\_USER\_TYPE userType, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)
- CK\_RV pkcs11\_session\_logout (CK\_SESSION\_HANDLE hSession)
- CK\_RV pkcs11\_signature\_sign\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p↔ Mechanism, CK\_OBJECT\_HANDLE hKey)

Initialize a signing operation using the specified key and mechanism.

• CK\_RV pkcs11\_signature\_sign (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Sign the data in a single pass operation.

• CK\_RV pkcs11\_signature\_sign\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG\_ulPartLen)

Continues a multiple-part signature operation.

 CK\_RV pkcs11\_signature\_sign\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen) Finishes a multiple-part signature operation.

CK\_RV pkcs11\_signature\_verify\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p
 — Mechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation using the specified key and mechanism.

CK\_RV pkcs11\_signature\_verify (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Verifies a signature on single-part data.

 CK\_RV pkcs11\_signature\_verify\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG\_ulPartLen)

Continues a multiple-part verification operation.

 CK\_RV pkcs11\_signature\_verify\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_ulSignatureLen)

Finishes a multiple-part verification operation.

pkcs11 slot ctx ptr pkcs11 slot get context (pkcs11 lib ctx ptr lib ctx, CK SLOT ID slotID)

Retrieve the current slot context.

- CK\_VOID\_PTR pkcs11\_slot\_initslots (CK\_ULONG pulCount)
- CK\_RV pkcs11\_slot\_config (CK\_SLOT\_ID slotID)
- CK RV pkcs11 slot init (CK SLOT ID slotID)
- CK\_RV pkcs11\_slot\_get\_list (CK\_BBOOL tokenPresent, CK\_SLOT\_ID\_PTR pSlotList, CK\_ULONG\_PTR pulCount)
- CK\_RV pkcs11\_slot\_get\_info (CK\_SLOT\_ID slotID, CK\_SLOT\_INFO\_PTR pInfo)

Obtains information about a particular slot.

- CK\_RV pkcs11\_token\_init (CK\_SLOT\_ID slotID, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen, CK\_UTF8CHAR\_PTR pLabel)
- CK\_RV pkcs11\_token\_get\_access\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_writable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_storage (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_info (CK\_SLOT\_ID slotID, CK\_TOKEN\_INFO\_PTR plnfo)

Obtains information about a particular token.

 CK\_RV pkcs11\_token\_random (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pRandomData, CK\_ULONG ulRandomLen)

Generate the specified amount of random data.

- CK\_RV pkcs11\_token\_convert\_pin\_to\_key (const CK\_UTF8CHAR\_PTR pPin, const CK\_ULONG ulPinLen, const CK\_UTF8CHAR\_PTR pSalt, const CK\_ULONG ulSaltLen, CK\_BYTE\_PTR pKey, CK\_ULONG ulKey ← Len)
- CK\_RV pkcs11\_token\_set\_pin (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pOldPin, CK\_ULONG ulOldLen, CK\_UTF8CHAR\_PTR pNewPin, CK\_ULONG ulNewLen)
- void pkcs11\_util\_escape\_string (CK\_UTF8CHAR\_PTR buf, CK\_ULONG buf\_len)
- CK\_RV pkcs11\_util\_convert\_rv (ATCA\_STATUS status)
- int pkcs11\_util\_memset (void \*dest, size\_t destsz, int ch, size\_t count)

#### **Variables**

- const pkcs11 attrib model pkcs11 cert x509public attributes []
- const CK\_ULONG pkcs11\_cert\_x509public\_attributes\_count = sizeof( pkcs11\_cert\_x509public\_attributes ) / sizeof( pkcs11\_cert\_x509public\_attributes [0])
- const pkcs11\_attrib\_model pkcs11\_cert\_wtlspublic\_attributes []
- const CK\_ULONG pkcs11\_cert\_wtlspublic\_attributes\_count = sizeof( pkcs11\_cert\_wtlspublic\_attributes ) / sizeof( pkcs11\_cert\_wtlspublic\_attributes [0])
- const pkcs11 attrib model pkcs11 cert x509 attributes []
- const CK\_ULONG pkcs11\_cert\_x509\_attributes\_count = sizeof( pkcs11\_cert\_x509\_attributes ) / sizeof( pkcs11\_cert\_x509\_attributes [0])
- const char pkcs11\_lib\_manufacturer\_id [] = "Microchip Technology Inc"

- const char pkcs11\_lib\_description [] = "Cryptoauthlib PKCS11 Interface"
- const pkcs11\_attrib\_model pkcs11\_key\_public\_attributes []
- const CK\_ULONG pkcs11\_key\_public\_attributes\_count = sizeof( pkcs11\_key\_public\_attributes ) / sizeof( pkcs11\_key\_public\_attributes [0])
- const pkcs11\_attrib\_model pkcs11\_key\_ec\_public\_attributes []
- const pkcs11 attrib model pkcs11 key private attributes[]
- const CK\_ULONG pkcs11\_key\_private\_attributes\_count = sizeof( pkcs11\_key\_private\_attributes ) / sizeof( pkcs11 key private attributes [0])
- const pkcs11\_attrib\_model pkcs11\_key\_rsa\_private\_attributes []
- const pkcs11\_attrib\_model pkcs11\_key\_ec\_private\_attributes []
- const pkcs11 attrib model pkcs11 key secret attributes []
- const CK\_ULONG pkcs11\_key\_secret\_attributes\_count = sizeof( pkcs11\_key\_secret\_attributes ) / sizeof( pkcs11\_key\_secret\_attributes [0])
- pkcs11\_object\_cache\_t pkcs11\_object\_cache [PKCS11\_MAX\_OBJECTS\_ALLOWED]
- const pkcs11 attrib model pkcs11 object monotonic attributes []
- const CK\_ULONG pkcs11\_object\_monotonic\_attributes\_count = sizeof( pkcs11\_object\_monotonic\_attributes
   ) / sizeof( pkcs11\_object\_monotonic\_attributes [0])

### 18.13.1 Detailed Description

### 18.13.2 Macro Definition Documentation

#### 18.13.2.1 PCKS11\_MECH\_ECC508\_EC\_CAPABILITY

```
#define PCKS11_MECH_ECC508_EC_CAPABILITY (CKF_EC_F_P | CKF_EC_NAMEDCURVE | CKF_EC_UNCOMPRESS)
```

### 18.13.2.2 TABLE SIZE

### 18.13.3 Typedef Documentation

### 18.13.3.1 pcks11\_mech\_table\_e

```
typedef struct _pcks11_mech_table_e pcks11_mech_table_e
```

### 18.13.3.2 pcks11\_mech\_table\_ptr

```
typedef struct _pcks11_mech_table_e * pcks11_mech_table_ptr
```

### 18.13.4 Function Documentation

# 18.13.4.1 C\_CancelFunction()

Legacy function.

# 18.13.4.2 C\_CloseAllSessions()

Close all open sessions.

# 18.13.4.3 C\_CloseSession()

Close the given session.

# 18.13.4.4 C\_CopyObject()

```
CK_RV C_CopyObject (

CK_SESSION_HANDLE hSession,

CK_OBJECT_HANDLE hObject,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount,

CK_OBJECT_HANDLE_PTR phNewObject )
```

Create a copy of the object with the specified handle.

### 18.13.4.5 C\_CreateObject()

Create a new object on the token in the specified session using the given attribute template.

#### 18.13.4.6 C Decrypt()

```
CK_RV C_Decrypt (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pEncryptedData,

CK_ULONG ulEncryptedDataLen,

CK_BYTE_PTR pData,

CK_ULONG_PTR pulDataLen )
```

Perform a single operation decryption in the given session.

### 18.13.4.7 C\_DecryptDigestUpdate()

Continues simultaneous multiple-part decryption and digesting operations.

### 18.13.4.8 C\_DecryptFinal()

Finishes a multiple-part decryption operation.

### 18.13.4.9 C\_DecryptInit()

```
CK_RV C_DecryptInit (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hObject )
```

Initialize decryption using the specified object.

### 18.13.4.10 C\_DecryptUpdate()

```
CK_RV C_DecryptUpdate (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pEncryptedData,

CK_ULONG ulEncryptedDataLen,

CK_BYTE_PTR pData,

CK_ULONG_PTR pDataLen )
```

Continues a multiple-part decryption operation.

### 18.13.4.11 C\_DecryptVerifyUpdate()

Continues simultaneous multiple-part decryption and verification operations.

### 18.13.4.12 C\_DeriveKey()

```
CK_RV C_DeriveKey (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hBaseKey,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount,

CK_OBJECT_HANDLE_PTR phKey )
```

Derive a key from the specified base key.

### 

Destroy the specified object.

#### 18.13.4.14 C Digest()

```
CK_RV C_Digest (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pDigest,

CK_ULONG_PTR pulDigestLen )
```

Digest the specified data in a one-pass operation and return the resulting digest.

#### 18.13.4.15 C\_DigestEncryptUpdate()

Continues simultaneous multiple-part digesting and encryption operations.

# 

Finishes a multiple-part digesting operation.

### 18.13.4.17 C\_DigestInit()

Initializes a message-digesting operation using the specified mechanism in the specified session.

# 18.13.4.18 C\_DigestKey()

Update a running digest operation by digesting a secret key with the specified handle.

### 

Continues a multiple-part digesting operation.

### 18.13.4.20 C\_Encrypt()

```
CK_RV C_Encrypt (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pEncryptedData,

CK_ULONG_PTR pulEncryptedDataLen)
```

Perform a single operation encryption operation in the specified session.

#### 18.13.4.21 C EncryptFinal()

```
CK_RV C_EncryptFinal (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pEncryptedData,

CK_ULONG_PTR pulEncryptedDataLen )
```

Finishes a multiple-part encryption operation.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 342

### 18.13.4.22 C\_EncryptInit()

```
CK_RV C_EncryptInit (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hObject )
```

Initializes an encryption operation using the specified mechanism and session.

# 18.13.4.23 C\_EncryptUpdate()

```
CK_RV C_EncryptUpdate (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pEncryptedData,

CK_ULONG_PTR pulEncryptedDataLen)
```

Continues a multiple-part encryption operation.

### 18.13.4.24 C\_Finalize()

Clean up miscellaneous Cryptoki-associated resources.

# 18.13.4.25 C\_FindObjects()

Continue the search for objects in the specified session.

#### 18.13.4.26 C\_FindObjectsFinal()

Finishes an object search operation (and cleans up)

### 18.13.4.27 C\_FindObjectsInit()

Initializes an object search in the specified session using the specified attribute template as search parameters.

### 18.13.4.28 C\_GenerateKey()

```
CK_RV C_GenerateKey (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount,

CK_OBJECT_HANDLE_PTR phKey )
```

Generates a secret key using the specified mechanism.

### 18.13.4.29 C\_GenerateKeyPair()

```
CK_RV C_GenerateKeyPair (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_ATTRIBUTE_PTR pPublicKeyTemplate,

CK_ULONG ulPublicKeyAttributeCount,

CK_ATTRIBUTE_PTR pPrivateKeyTemplate,

CK_ULONG ulPrivateKeyAttributeCount,

CK_OBJECT_HANDLE_PTR phPublicKey,

CK_OBJECT_HANDLE_PTR phPrivateKey )
```

Generates a public-key/private-key pair using the specified mechanism.

#### 18.13.4.30 C\_GenerateRandom()

Generate the specified amount of random data.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 344

### 18.13.4.31 C\_GetAttributeValue()

```
CK_RV C_GetAttributeValue (

CK_SESSION_HANDLE hSession,

CK_OBJECT_HANDLE hObject,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount )
```

Obtains an attribute value of an object.

# 18.13.4.32 C\_GetFunctionList()

Obtains entry points of Cryptoki library functions.

### 18.13.4.33 C\_GetFunctionStatus()

Legacy function - see PKCS#11 v2.40.

### 18.13.4.34 C\_GetInfo()

Obtains general information about Cryptoki.

# 18.13.4.35 C\_GetMechanismInfo()

Obtains information about a particular mechanism of a token (in a slot)

### 18.13.4.36 C\_GetMechanismList()

Obtains a list of mechanisms supported by a token (in a slot)

# 18.13.4.37 C\_GetObjectSize()

Obtains the size of an object in bytes.

#### 18.13.4.38 C GetOperationState()

Obtains the cryptographic operations state of a session.

### 18.13.4.39 C\_GetSessionInfo()

Retrieve information about the specified session.

#### 18.13.4.40 C\_GetSlotInfo()

Obtains information about a particular slot.

### 18.13.4.41 C\_GetSlotList()

Obtains a list of slots in the system.

# 18.13.4.42 C\_GetTokenInfo()

Obtains information about a particular token.

# 18.13.4.43 C\_Initialize()

Initializes Cryptoki library NOTES: If plnitArgs is a non-NULL\_PTR is must dereference to a CK\_C\_INITIALIZE\_ARGS structure.

# 18.13.4.44 C\_InitPIN()

Initializes the normal user's PIN.

### 18.13.4.45 C\_InitToken()

```
CK_RV C_InitToken (

CK_SLOT_ID slotID,

CK_UTF8CHAR_PTR pPin,

CK_ULONG ulPinLen,

CK_UTF8CHAR_PTR pLabel )
```

Initializes a token (in a slot)

### 18.13.4.46 C\_Login()

```
CK_RV C_Login (

CK_SESSION_HANDLE hSession,

CK_USER_TYPE userType,

CK_UTF8CHAR_PTR pPin,

CK_ULONG ulPinLen )
```

Login on the token in the specified session.

# 18.13.4.47 C\_Logout()

```
CK_RV C_Logout (

CK_SESSION_HANDLE hSession )
```

Log out of the token in the specified session.

# 18.13.4.48 C\_OpenSession()

Opens a connection between an application and a particular token or sets up an application callback for token insertion.

# 18.13.4.49 C\_SeedRandom()

Mixes in additional seed material to the random number generator.

### 18.13.4.50 C\_SetAttributeValue()

Change or set the value of the specified attributes on the specified object.

### 18.13.4.51 C\_SetOperationState()

```
CK_RV C_SetOperationState (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pOperationState,

CK_ULONG ulOperationStateLen,

CK_OBJECT_HANDLE hEncryptionKey,

CK_OBJECT_HANDLE hAuthenticationKey)
```

Sets the cryptographic operations state of a session.

### 18.13.4.52 C\_SetPIN()

```
CK_RV C_SetPIN (

CK_SESSION_HANDLE hSession,

CK_UTF8CHAR_PTR pOldPin,

CK_ULONG ulOldLen,

CK_UTF8CHAR_PTR pNewPin,

CK_ULONG ulNewLen)
```

Modifies the PIN of the current user.

# 18.13.4.53 C\_Sign()

```
CK_RV C_Sign (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pSignature,

CK_ULONG_PTR pulSignatureLen )
```

Sign the data in a single pass operation.

### 18.13.4.54 C\_SignEncryptUpdate()

Continues simultaneous multiple-part signature and encryption operations.

### 18.13.4.55 C\_SignFinal()

Finishes a multiple-part signature operation.

# 18.13.4.56 C\_SignInit()

```
CK_RV C_SignInit (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hKey )
```

Initialize a signing operation using the specified key and mechanism.

### 

```
CK_RV C_SignRecover (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pSignature,

CK_ULONG_PTR pulSignatureLen)
```

Signs single-part data, where the data can be recovered from the signature.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 350

### 18.13.4.58 C\_SignRecoverInit()

```
CK_RV C_SignRecoverInit (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hKey )
```

Initializes a signature operation, where the data can be recovered from the signature.

# 18.13.4.59 C\_SignUpdate()

Continues a multiple-part signature operation.

#### 18.13.4.60 C UnwrapKey()

```
CK_RV C_UnwrapKey (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hUnwrappingKey,

CK_BYTE_PTR pWrappedKey,

CK_ULONG ulWrappedKeyLen,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount,

CK_OBJECT_HANDLE_PTR phKey )
```

Unwraps (decrypts) the specified key using the specified unwrapping key.

# 18.13.4.61 C\_Verify()

```
CK_RV C_Verify (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pSignature,

CK_ULONG ulSignatureLen)
```

Verifies a signature on single-part data.

### 18.13.4.62 C\_VerifyFinal()

Finishes a multiple-part verification operation.

### 18.13.4.63 C\_VerifyInit()

```
CK_RV C_VerifyInit (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hKey )
```

Initializes a verification operation using the specified key and mechanism.

# 18.13.4.64 C\_VerifyRecover()

```
CK_RV C_VerifyRecover (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pSignature,

CK_ULONG ulSignatureLen,

CK_BYTE_PTR pData,

CK_ULONG_PTR pulDataLen )
```

Verifies a signature on single-part data, where the data is recovered from the signature.

# 18.13.4.65 C\_VerifyRecoverInit()

Initializes a verification operation where the data is recovered from the signature.

# 18.13.4.66 C\_VerifyUpdate()

Continues a multiple-part verification operation.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 352

### 18.13.4.67 C\_WaitForSlotEvent()

Wait for a slot event (token insertion, removal, etc) on the specified slot to occur.

#### 18.13.4.68 C WrapKey()

```
CK_RV C_WrapKey (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hWrappingKey,

CK_OBJECT_HANDLE hKey,

CK_BYTE_PTR pWrappedKey,

CK_ULONG_PTR pulWrappedKeyLen)
```

Wraps (encrypts) the specified key using the specified wrapping key and mechanism.

#### 18.13.4.69 pkcs11\_attrib\_empty()

### 18.13.4.70 pkcs11\_attrib\_false()

# 18.13.4.71 pkcs11\_attrib\_fill()

Perform the nessasary checks and copy data into an attribute structure.

The ulValueLen field is modified to hold the exact length of the specified attribute for the object. In the special case of an attribute whose value is an array of attributes, for example CKA\_WRAP\_TEMPLATE, where it is passed in with pValue not NULL, then if the pValue of elements within the array is NULL\_PTR then the ulValueLen of elements within the array will be set to the required length. If the pValue of elements within the array is not NULL\_PTR, then the ulValueLen element of attributes within the array MUST reflect the space that the corresponding pValue points to, and pValue is filled in if there is sufficient room. Therefore it is important to initialize the contents of a buffer before calling C\_GetAttributeValue to get such an array value. If any ulValueLen within the array isn't large enough, it will be set to CK\_UNAVAILABLE\_INFORMATION and the function will return CKR\_BUFFER\_TOO\_SMALL, as it does if an attribute in the pTemplate argument has ulValueLen too small Note that any attribute whose value is an array of attributes is identifiable by virtue of the attribute type having the CKF\_ARRAY\_ATTRIBUTE bit set.

### 18.13.4.72 pkcs11\_attrib\_true()

# 18.13.4.73 pkcs11\_attrib\_value()

Helper function to write a numerical value to an attribute buffer.

# 18.13.4.74 pkcs11\_cert\_get\_authority\_key\_id()

### 18.13.4.75 pkcs11\_cert\_get\_encoded()

### 18.13.4.76 pkcs11\_cert\_get\_subject()

### 18.13.4.77 pkcs11\_cert\_get\_subject\_key\_id()

#### 18.13.4.78 pkcs11\_cert\_get\_trusted\_flag()

# 18.13.4.79 pkcs11\_cert\_get\_type()

### 18.13.4.80 pkcs11\_cert\_x509\_write()

#### 18.13.4.81 pkcs11\_config\_cert()

### 18.13.4.82 pkcs11\_config\_init\_cert()

### 18.13.4.83 pkcs11\_config\_init\_private()

#### 18.13.4.84 pkcs11\_config\_init\_public()

#### 18.13.4.85 pkcs11\_config\_key()

### 18.13.4.86 pkcs11\_config\_load()

#### 18.13.4.87 pkcs11\_config\_load\_objects()

#### 18.13.4.88 pkcs11\_config\_remove\_object()

# 18.13.4.89 pkcs11\_deinit()

```
CK_RV pkcs11_deinit (  {\tt CK\_VOID\_PTR} \ pReserved \ ) \\
```

**Todo** If other threads are waiting for something to happen this call should cause those calls to unblock and return CKR\_CRYPTOKI\_NOT\_INITIALIZED - How that is done by this simplified mutex API is yet to be determined

#### 18.13.4.90 pkcs11\_find\_continue()

# 18.13.4.91 pkcs11\_find\_finish()

# 18.13.4.92 pkcs11\_find\_get\_attribute()

### 18.13.4.93 pkcs11\_find\_init()

# 18.13.4.94 pkcs11\_get\_context()

Retrieve the current library context.

### 18.13.4.95 pkcs11\_get\_lib\_info()

Obtains general information about Cryptoki.

#### 18.13.4.96 pkcs11\_get\_session\_context()

# 18.13.4.97 pkcs11\_init()

Initializes the PKCS11 API Library for Cryptoauthlib.

Todo This is where we should allocate a new context if we're using dynamic memory

**Todo** If we're using dyamic memory we need to make sure to deallocate it if any of the errors after the allocations are encountered

#### 18.13.4.98 pkcs11\_init\_check()

```
CK_RV pkcs11_init_check (
          pkcs11_lib_ctx_ptr * ppContext,
          CK_BBOOL lock )
```

Check if the library is initialized properly.

# 18.13.4.99 pkcs11\_key\_derive()

```
CK_RV pkcs11_key_derive (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism,

CK_OBJECT_HANDLE hBaseKey,

CK_ATTRIBUTE_PTR pTemplate,

CK_ULONG ulCount,

CK_OBJECT_HANDLE_PTR phKey)
```

#### 18.13.4.100 pkcs11\_key\_generate\_pair()

# 18.13.4.101 pkcs11\_key\_write()

# 18.13.4.102 pkcs11\_lock\_context()

### 18.13.4.103 pkcs11\_mech\_get\_list()

### 18.13.4.104 pkcs11\_object\_alloc()

### 18.13.4.105 pkcs11\_object\_check()

# 18.13.4.106 pkcs11\_object\_create()

Create a new object on the token in the specified session using the given attribute template.

#### 18.13.4.107 pkcs11\_object\_deinit()

### 18.13.4.108 pkcs11\_object\_destroy()

Destroy the specified object.

### 18.13.4.109 pkcs11\_object\_find()

# 18.13.4.110 pkcs11\_object\_free()

#### 18.13.4.111 pkcs11\_object\_get\_class()

### 18.13.4.112 pkcs11\_object\_get\_destroyable()

#### 18.13.4.113 pkcs11\_object\_get\_handle()

# 18.13.4.114 pkcs11\_object\_get\_name()

# 18.13.4.115 pkcs11\_object\_get\_size()

# 18.13.4.116 pkcs11\_object\_get\_type()

#### 18.13.4.117 pkcs11\_object\_load\_handle\_info()

## 18.13.4.118 pkcs11\_os\_create\_mutex()

Application callback for creating a mutex object.

#### **Parameters**

| in,out | ppMutex | location to receive ptr to mutex |
|--------|---------|----------------------------------|
|--------|---------|----------------------------------|

#### 18.13.4.119 pkcs11\_os\_destroy\_mutex()

```
CK_RV pkcs11_os_destroy_mutex (  {\tt CK_VOID\_PTR} \ p{\tt Mutex} \ )
```

#### 18.13.4.120 pkcs11\_os\_lock\_mutex()

## 18.13.4.121 pkcs11\_os\_unlock\_mutex()

## 18.13.4.122 pkcs11\_session\_check()

Check if the session is initialized properly.

#### 18.13.4.123 pkcs11\_session\_close()

#### 18.13.4.124 pkcs11\_session\_closeall()

Close all sessions for a given slot - not actually all open sessions.

#### 18.13.4.125 pkcs11\_session\_get\_info()

Obtains information about a particular session.

## 18.13.4.126 pkcs11\_session\_login()

```
CK_RV pkcs11_session_login (

CK_SESSION_HANDLE hSession,

CK_USER_TYPE userType,

CK_UTF8CHAR_PTR pPin,

CK_ULONG ulPinLen )
```

#### 18.13.4.127 pkcs11\_session\_logout()

#### 18.13.4.128 pkcs11\_session\_open()

#### 18.13.4.129 pkcs11\_signature\_sign()

Sign the data in a single pass operation.

#### 18.13.4.130 pkcs11 signature sign continue()

Continues a multiple-part signature operation.

#### 18.13.4.131 pkcs11\_signature\_sign\_finish()

Finishes a multiple-part signature operation.

#### 18.13.4.132 pkcs11\_signature\_sign\_init()

Initialize a signing operation using the specified key and mechanism.

#### 18.13.4.133 pkcs11\_signature\_verify()

Verifies a signature on single-part data.

#### 18.13.4.134 pkcs11\_signature\_verify\_continue()

Continues a multiple-part verification operation.

#### 18.13.4.135 pkcs11\_signature\_verify\_finish()

Finishes a multiple-part verification operation.

#### 18.13.4.136 pkcs11\_signature\_verify\_init()

Initializes a verification operation using the specified key and mechanism.

## 18.13.4.137 pkcs11\_slot\_config()

#### 18.13.4.138 pkcs11\_slot\_get\_context()

Retrieve the current slot context.

## 18.13.4.139 pkcs11\_slot\_get\_info()

Obtains information about a particular slot.

## 18.13.4.140 pkcs11\_slot\_get\_list()

## 18.13.4.141 pkcs11\_slot\_init()

## 18.13.4.142 pkcs11\_slot\_initslots()

#### 18.13.4.143 pkcs11\_token\_convert\_pin\_to\_key()

#### 18.13.4.144 pkcs11\_token\_get\_access\_type()

#### 18.13.4.145 pkcs11\_token\_get\_info()

Obtains information about a particular token.

#### 18.13.4.146 pkcs11\_token\_get\_storage()

## 18.13.4.147 pkcs11\_token\_get\_writable()

#### 18.13.4.148 pkcs11\_token\_init()

```
CK_RV pkcs11_token_init (

CK_SLOT_ID slotID,

CK_UTF8CHAR_PTR pPin,

CK_ULONG ulPinLen,

CK_UTF8CHAR_PTR pLabel )
```

Write the configuration into the device and generate new keys

## 18.13.4.149 pkcs11\_token\_random()

Generate the specified amount of random data.

#### 18.13.4.150 pkcs11\_token\_set\_pin()

#### 18.13.4.151 pkcs11\_unlock\_context()

#### 18.13.4.152 pkcs11\_util\_convert\_rv()

## 18.13.4.153 pkcs11\_util\_escape\_string()

## 18.13.4.154 pkcs11\_util\_memset()

#### 18.13.4.155 pkcs\_mech\_get\_info()

#### 18.13.5 Variable Documentation

#### 18.13.5.1 pkcs11\_cert\_wtlspublic\_attributes

```
const pkcs11_attrib_model pkcs11_cert_wtlspublic_attributes[]
```

CKO\_CERTIFICATE (Type: CKC\_WTLS) - WTLS Public Key Certificate Model

#### 18.13.5.2 pkcs11\_cert\_wtlspublic\_attributes\_count

```
const CK_ULONG pkcs11_cert_wtlspublic_attributes_count = sizeof( pkcs11_cert_wtlspublic_attributes
) / sizeof( pkcs11_cert_wtlspublic_attributes [0])
```

#### 18.13.5.3 pkcs11\_cert\_x509\_attributes

```
const pkcs11_attrib_model pkcs11_cert_x509_attributes[]
```

CKO\_CERTIFICATE (Type: CKC\_X\_509\_ATTR\_CERT) - X509 Attribute Certificate Model

#### 18.13.5.4 pkcs11\_cert\_x509\_attributes\_count

```
const CK_ULONG pkcs11_cert_x509_attributes_count = sizeof( pkcs11_cert_x509_attributes ) /
sizeof( pkcs11_cert_x509_attributes [0])
```

#### 18.13.5.5 pkcs11\_cert\_x509public\_attributes

```
const pkcs11_attrib_model pkcs11_cert_x509public_attributes[]
```

CKO\_CERTIFICATE (Type: CKC\_X\_509) - X509 Public Key Certificate Model

#### 18.13.5.6 pkcs11 cert x509public attributes count

```
const CK_ULONG pkcs11_cert_x509public_attributes_count = sizeof( pkcs11_cert_x509public_attributes
) / sizeof( pkcs11_cert_x509public_attributes [0])
```

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 369

#### 18.13.5.7 pkcs11\_key\_ec\_private\_attributes

CKO PRIVATE KEY (Type: CKK EC) - EC/ECDSA Public Key Object Model

#### 18.13.5.8 pkcs11\_key\_ec\_public\_attributes

```
const pkcs11_attrib_model pkcs11_key_ec_public_attributes[]
```

#### Initial value:

CKO\_PUBLIC\_KEY (Type: CKK\_EC) - EC/ECDSA Public Key Object Model

#### 18.13.5.9 pkcs11\_key\_private\_attributes

```
const pkcs11_attrib_model pkcs11_key_private_attributes[]
```

CKO\_PRIVATE\_KEY - Private Key Object Base Model

#### 18.13.5.10 pkcs11\_key\_private\_attributes\_count

```
const CK_ULONG pkcs11_key_private_attributes_count = sizeof( pkcs11_key_private_attributes ) /
sizeof( pkcs11_key_private_attributes [0])
```

## 18.13.5.11 pkcs11\_key\_public\_attributes

```
const pkcs11_attrib_model pkcs11_key_public_attributes[]
```

CKO PUBLIC KEY - Public Key Object Model

#### 18.13.5.12 pkcs11 key public attributes count

```
const CK_ULONG pkcsl1_key_public_attributes_count = sizeof( pkcsl1_key_public_attributes ) /
sizeof( pkcsl1_key_public_attributes [0])
```

#### 18.13.5.13 pkcs11\_key\_rsa\_private\_attributes

```
const pkcs11_attrib_model pkcs11_key_rsa_private_attributes[]
```

#### Initial value:

```
{ 0x00000120UL,
   },
{ 0x00000122UL , 0
   },
{ 0x00000123UL , 0
   },
{ 0x00000124UL ,
   },
{ 0x00000125UL ,
   }.
{ 0x00000126UL ,
                       0
{ 0x00000127UL ,
                       0
  },
{ 0x00000128UL ,
                     0
   },
```

CKO\_PRIVATE\_KEY (Type: CKK\_RSA) - RSA Private Key Object Model

#### 18.13.5.14 pkcs11 key secret attributes

```
const pkcs11_attrib_model pkcs11_key_secret_attributes[]
```

CKO SECRET KEY - Secret Key Object Base Model

#### 18.13.5.15 pkcs11\_key\_secret\_attributes\_count

```
const CK_ULONG pkcsl1_key_secret_attributes_count = sizeof( pkcsl1_key_secret_attributes ) /
sizeof( pkcsl1_key_secret_attributes [0])
```

## 18.13.5.16 pkcs11\_lib\_description

```
const char pkcs11_lib_description[] = "Cryptoauthlib PKCS11 Interface"
```

#### 18.13.5.17 pkcs11 lib manufacturer id

```
const char pkcs11_lib_manufacturer_id[] = "Microchip Technology Inc"
```

#### 18.13.5.18 pkcs11\_object\_cache

```
pkcs11_object_cache_t pkcs11_object_cache[PKCS11_MAX_OBJECTS_ALLOWED]
```

#### 18.13.5.19 pkcs11\_object\_monotonic\_attributes

```
const pkcs11_attrib_model pkcs11_object_monotonic_attributes[]
```

#### Initial value:

CKA\_CLASS == CKO\_HW\_FEATURE\_TYPE CKA\_HW\_FEATURE\_TYPE == CKH\_MONOTONIC\_COUNTER

#### 18.13.5.20 pkcs11\_object\_monotonic\_attributes\_count

const CK\_ULONG pkcs11\_object\_monotonic\_attributes\_count = sizeof( pkcs11\_object\_monotonic\_attributes
) / sizeof( pkcs11\_object\_monotonic\_attributes [0])

## 18.14 TNG API (tng )

These methods provide some convenience functions (mostly around certificates) for TNG devices, which currently include ATECC608A-MAHTN-T.

#### **Functions**

const atcacert def t \* tng map get device cert def (int index)

Helper function to iterate through all trust cert definitions.

• ATCA\_STATUS tng\_get\_device\_cert\_def (const atcacert\_def\_t \*\*cert\_def)

Get the TNG device certificate definition.

ATCA\_STATUS tng\_get\_device\_pubkey (uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from the primary device public key.

- · const atcacert\_def\_t g\_tflxtls\_cert\_def\_4\_device
- int tng atcacert max device cert size (size t \*max cert size)

Return the maximum possible certificate size in bytes for a TNG device certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

• int tng\_atcacert\_read\_device\_cert (uint8\_t \*cert, size\_t \*cert\_size, const uint8\_t \*signer\_cert)

Reads the device certificate for a TNG device.

int tng\_atcacert\_device\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the device public key.

int tng\_atcacert\_max\_signer\_cert\_size (size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a TNG signer certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

int tng\_atcacert\_read\_signer\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Reads the signer certificate for a TNG device.

• int tng\_atcacert\_signer\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the signer public key.

int tng\_atcacert\_root\_cert\_size (size\_t \*cert\_size)

Get the size of the TNG root cert.

• int tng\_atcacert\_root\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Get the TNG root cert.

• int tng atcacert root public key (uint8 t \*public key)

Gets the root public key.

- const uint8\_t g\_cryptoauth\_root\_ca\_002\_cert []
- const size\_t g\_cryptoauth\_root\_ca\_002\_cert\_size
- #define CRYPTOAUTH\_ROOT\_CA\_002\_PUBLIC\_KEY\_OFFSET 266
- const atcacert\_def\_t g\_tnglora\_cert\_def\_1\_signer
- const atcacert\_def\_t g\_tnglora\_cert\_def\_2\_device
- · const atcacert def t g tnglora cert def 4 device
- #define TNGLORA CERT TEMPLATE 4 DEVICE SIZE 552
- · ATCA DLL const atcacert def t g tngtls cert def 1 signer
- #define TNGTLS CERT TEMPLATE 1 SIGNER SIZE 520
- const atcacert\_def\_t g\_tngtls\_cert\_def\_2\_device
- #define TNGTLS CERT TEMPLATE 2 DEVICE SIZE 505
- #define TNGTLS\_CERT\_ELEMENTS\_2\_DEVICE\_COUNT 2
- const atcacert\_def\_t g\_tngtls\_cert\_def\_3\_device
- #define TNGTLS\_CERT\_TEMPLATE\_3\_DEVICE\_SIZE 546

## 18.14.1 Detailed Description

These methods provide some convenience functions (mostly around certificates) for TNG devices, which currently include ATECC608A-MAHTN-T.

#### 18.14.2 Macro Definition Documentation

#### 18.14.2.1 CRYPTOAUTH ROOT CA 002 PUBLIC KEY OFFSET

#define CRYPTOAUTH\_ROOT\_CA\_002\_PUBLIC\_KEY\_OFFSET 266

## 18.14.2.2 TNGLORA\_CERT\_TEMPLATE\_4\_DEVICE\_SIZE

#define TNGLORA\_CERT\_TEMPLATE\_4\_DEVICE\_SIZE 552

#### 18.14.2.3 TNGTLS\_CERT\_ELEMENTS\_2\_DEVICE\_COUNT

#define TNGTLS\_CERT\_ELEMENTS\_2\_DEVICE\_COUNT 2

#### 18.14.2.4 TNGTLS\_CERT\_TEMPLATE\_1\_SIGNER\_SIZE

#define TNGTLS\_CERT\_TEMPLATE\_1\_SIGNER\_SIZE 520

## 18.14.2.5 TNGTLS\_CERT\_TEMPLATE\_2\_DEVICE\_SIZE

#define TNGTLS\_CERT\_TEMPLATE\_2\_DEVICE\_SIZE 505

## 18.14.2.6 TNGTLS\_CERT\_TEMPLATE\_3\_DEVICE\_SIZE

#define TNGTLS\_CERT\_TEMPLATE\_3\_DEVICE\_SIZE 546

## 18.14.3 Function Documentation

#### 18.14.3.1 tng\_atcacert\_device\_public\_key()

Reads the device public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve.             |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------|
| in  | cert       | If supplied, the device public key is used from this certificate. If set to NULL, the device public key is read from the device. |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 18.14.3.2 tng\_atcacert\_max\_device\_cert\_size()

Return the maximum possible certificate size in bytes for a TNG device certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

#### **Parameters**

| ſ | out | max_cert_size | Maximum certificate size will be returned here in bytes. | ] |
|---|-----|---------------|----------------------------------------------------------|---|
|---|-----|---------------|----------------------------------------------------------|---|

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.14.3.3 tng\_atcacert\_max\_signer\_cert\_size()

Return the maximum possible certificate size in bytes for a TNG signer certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

#### **Parameters**

| out | max_cert_size | Maximum certificate size will be returned here in bytes. |
|-----|---------------|----------------------------------------------------------|

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 375

#### 18.14.3.4 tng\_atcacert\_read\_device\_cert()

Reads the device certificate for a TNG device.

#### **Parameters**

| out    | cert        | Buffer to received the certificate (DER format).                                                                                 |
|--------|-------------|----------------------------------------------------------------------------------------------------------------------------------|
| in,out | cert_size   | As input, the size of the cert buffer in bytes. As output, the size of the certificate returned in cert in bytes.                |
| in     | signer_cert | If supplied, the signer public key is used from this certificate. If set to NULL, the signer public key is read from the device. |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 18.14.3.5 tng\_atcacert\_read\_signer\_cert()

```
int tng_atcacert_read_signer_cert (
          uint8_t * cert,
          size_t * cert_size )
```

Reads the signer certificate for a TNG device.

#### **Parameters**

| out    | cert      | Buffer to received the certificate (DER format).                                       |
|--------|-----------|----------------------------------------------------------------------------------------|
| in,out | cert_size | As input, the size of the cert buffer in bytes. As output, the size of the certificate |
|        |           | returned in cert in bytes.                                                             |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 18.14.3.6 tng\_atcacert\_root\_cert()

```
int tng_atcacert_root_cert (
          uint8_t * cert,
          size_t * cert_size )
```

Get the TNG root cert.

#### **Parameters**

| out    | cert      | Buffer to received the certificate (DER format).                                       |
|--------|-----------|----------------------------------------------------------------------------------------|
| in,out | cert_size | As input, the size of the cert buffer in bytes. As output, the size of the certificate |
|        |           | returned in cert in bytes.                                                             |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.14.3.7 tng\_atcacert\_root\_cert\_size()

Get the size of the TNG root cert.

#### **Parameters**

| out | cert_size | Certificate size will be returned here in bytes. |
|-----|-----------|--------------------------------------------------|
|-----|-----------|--------------------------------------------------|

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

## 18.14.3.8 tng\_atcacert\_root\_public\_key()

Gets the root public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian |
|-----|------------|-------------------------------------------------------------------------------------|
|     |            | format. 64 bytes for P256 curve.                                                    |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 377

#### 18.14.3.9 tng\_atcacert\_signer\_public\_key()

Reads the signer public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve.             |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------|
| in  | cert       | If supplied, the signer public key is used from this certificate. If set to NULL, the signer public key is read from the device. |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 18.14.3.10 tng\_get\_device\_cert\_def()

Get the TNG device certificate definition.

## Parameters

| out | cert_def | TNG device certificate defnition is returned here. |
|-----|----------|----------------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.14.3.11 tng\_get\_device\_pubkey()

```
ATCA_STATUS tng_get_device_pubkey ( uint8_t * public_key )
```

Uses GenKey command to calculate the public key from the primary device public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian |
|-----|------------|-------------------------------------------------------------------------------------|
|     |            | format. 64 bytes for P256 curve.                                                    |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 18.14.3.12 tng\_map\_get\_device\_cert\_def()

Helper function to iterate through all trust cert definitions.

#### **Parameters**

| in <i>index</i> Map index |
|---------------------------|
|---------------------------|

#### Returns

non-null value if success, otherwise NULL

#### 18.14.4 Variable Documentation

## 18.14.4.1 g\_cryptoauth\_root\_ca\_002\_cert

```
const uint8_t g_cryptoauth_root_ca_002_cert[]
```

### 18.14.4.2 g\_cryptoauth\_root\_ca\_002\_cert\_size

```
{\tt const \ size\_t \ g\_cryptoauth\_root\_ca\_002\_cert\_size}
```

## 18.14.4.3 g\_tflxtls\_cert\_def\_4\_device

```
const atcacert_def_t g_tflxtls_cert_def_4_device
```

## 18.14.4.4 g\_tnglora\_cert\_def\_1\_signer

```
const atcacert_def_t g_tnglora_cert_def_1_signer
```

## 18.14.4.5 g\_tnglora\_cert\_def\_2\_device

const atcacert\_def\_t g\_tnglora\_cert\_def\_2\_device

## 18.14.4.6 g\_tnglora\_cert\_def\_4\_device

 ${\tt const~atcacert\_def\_t~g\_tnglora\_cert\_def\_4\_device}$ 

## 18.14.4.7 g\_tngtls\_cert\_def\_1\_signer

ATCA\_DLL const atcacert\_def\_t g\_tngtls\_cert\_def\_1\_signer

## 18.14.4.8 g\_tngtls\_cert\_def\_2\_device

const atcacert\_def\_t g\_tngtls\_cert\_def\_2\_device

## 18.14.4.9 g\_tngtls\_cert\_def\_3\_device

const atcacert\_def\_t g\_tngtls\_cert\_def\_3\_device

# **Chapter 19**

# **Data Structure Documentation**

# 19.1 \_atecc508a\_config Struct Reference

```
#include <atca_device.h>
```

#### **Data Fields**

- uint32\_t SN03
- uint32\_t RevNum
- uint32\_t SN47
- uint8\_t SN8
- uint8\_t Reserved0
- uint8\_t I2C\_Enable
- uint8\_t Reserved1
- uint8\_t I2C\_Address
- uint8\_t Reserved2
- uint8\_t OTPmode
- uint8\_t ChipMode
- uint16\_t SlotConfig [16]
- uint8\_t Counter0 [8]
- uint8\_t Counter1 [8]
- uint8\_t LastKeyUse [16]
- uint8\_t UserExtra
- uint8\_t Selector
- uint8\_t LockValue
- uint8\_t LockConfig
- uint16\_t SlotLocked
- uint16\_t RFU
- uint32\_t X509format
- uint16\_t KeyConfig [16]

#### 19.1.1 Field Documentation

## 19.1.1.1 ChipMode

uint8\_t ChipMode

#### 19.1.1.2 Counter0

uint8\_t Counter0[8]

## 19.1.1.3 Counter1

uint8\_t Counter1[8]

## 19.1.1.4 I2C\_Address

uint8\_t I2C\_Address

## 19.1.1.5 I2C\_Enable

uint8\_t I2C\_Enable

## 19.1.1.6 KeyConfig

uint16\_t KeyConfig[16]

## 19.1.1.7 LastKeyUse

uint8\_t LastKeyUse[16]

## 19.1.1.8 LockConfig

uint8\_t LockConfig

## 19.1.1.9 LockValue

uint8\_t LockValue

#### 19.1.1.10 OTPmode

uint8\_t OTPmode

## 19.1.1.11 Reserved0

uint8\_t Reserved0

#### 19.1.1.12 Reserved1

uint8\_t Reserved1

## 19.1.1.13 Reserved2

uint8\_t Reserved2

## 19.1.1.14 RevNum

uint32\_t RevNum

## 19.1.1.15 RFU

uint16\_t RFU

#### 19.1.1.16 Selector

uint8\_t Selector

## 19.1.1.17 SlotConfig

uint16\_t SlotConfig[16]

#### 19.1.1.18 SlotLocked

uint16\_t SlotLocked

#### 19.1.1.19 SN03

uint32\_t SN03

#### 19.1.1.20 SN47

uint32\_t SN47

## 19.1.1.21 SN8

uint8\_t SN8

## 19.1.1.22 UserExtra

uint8\_t UserExtra

## 19.1.1.23 X509format

uint32\_t X509format

# 19.2 \_atecc608\_config Struct Reference

#include <atca\_device.h>

## **Data Fields**

- uint32\_t SN03
- uint32\_t RevNum
- uint32\_t SN47
- uint8\_t SN8
- uint8\_t AES\_Enable
- uint8 t I2C Enable
- uint8\_t Reserved1
- uint8\_t I2C\_Address
- uint8\_t Reserved2
- uint8\_t CountMatch
- uint8\_t ChipMode
- uint16\_t SlotConfig [16]
- uint8 t Counter0 [8]
- uint8\_t Counter1 [8]
- uint8\_t UseLock
- uint8\_t VolatileKeyPermission
- uint16\_t SecureBoot
- uint8\_t KdflvLoc
- uint16 t KdflvStr
- uint8\_t Reserved3 [9]
- uint8\_t UserExtra
- uint8\_t UserExtraAdd
- uint8\_t LockValue
- uint8\_t LockConfig
- uint16\_t SlotLocked
- uint16 t ChipOptions
- uint32\_t X509format
- uint16\_t KeyConfig [16]

## 19.2.1 Field Documentation

## 19.2.1.1 AES\_Enable

uint8\_t AES\_Enable

## 19.2.1.2 ChipMode

uint8\_t ChipMode

## 19.2.1.3 ChipOptions

uint16\_t ChipOptions

#### 19.2.1.4 Counter0

uint8\_t Counter0[8]

## 19.2.1.5 Counter1

uint8\_t Counter1[8]

#### 19.2.1.6 CountMatch

uint8\_t CountMatch

## 19.2.1.7 I2C\_Address

uint8\_t I2C\_Address

## 19.2.1.8 I2C\_Enable

uint8\_t I2C\_Enable

## 19.2.1.9 KdflvLoc

uint8\_t KdflvLoc

#### 19.2.1.10 KdflvStr

uint16\_t KdflvStr

## 19.2.1.11 KeyConfig

uint16\_t KeyConfig[16]

## 19.2.1.12 LockConfig

uint8\_t LockConfig

## 19.2.1.13 LockValue

uint8\_t LockValue

#### 19.2.1.14 Reserved1

uint8\_t Reserved1

## 19.2.1.15 Reserved2

uint8\_t Reserved2

## 19.2.1.16 Reserved3

uint8\_t Reserved3[9]

## 19.2.1.17 RevNum

uint32\_t RevNum

#### 19.2.1.18 SecureBoot

uint16\_t SecureBoot

## 19.2.1.19 SlotConfig

uint16\_t SlotConfig[16]

#### 19.2.1.20 SlotLocked

uint16\_t SlotLocked

## 19.2.1.21 SN03

uint32\_t SN03

#### 19.2.1.22 SN47

uint32\_t SN47

## 19.2.1.23 SN8

uint8\_t SN8

## 19.2.1.24 UseLock

uint8\_t UseLock

## 19.2.1.25 UserExtra

uint8\_t UserExtra

#### 19.2.1.26 UserExtraAdd

uint8\_t UserExtraAdd

#### 19.2.1.27 VolatileKeyPermission

uint8\_t VolatileKeyPermission

#### 19.2.1.28 X509format

uint32\_t X509format

## 19.3 \_atsha204a\_config Struct Reference

#include <atca\_device.h>

#### **Data Fields**

- uint32\_t SN03
- uint32\_t RevNum
- uint32\_t SN47
- uint8\_t SN8
- uint8\_t Reserved0
- uint8\_t I2C\_Enable
- uint8 t Reserved1
- uint8\_t I2C\_Address
- uint8\_t Reserved2
- uint8\_t OTPmode
- uint8\_t ChipMode
- uint16\_t SlotConfig [16]
- uint16\_t Counter [8]
- uint8\_t LastKeyUse [16]
- uint8\_t UserExtra
- uint8\_t Selector
- uint8 t LockValue
- uint8\_t LockConfig

## 19.3.1 Field Documentation

## 19.3.1.1 ChipMode

uint8\_t ChipMode

## 19.3.1.2 Counter

uint16\_t Counter[8]

## 19.3.1.3 I2C\_Address

uint8\_t I2C\_Address

## 19.3.1.4 I2C\_Enable

uint8\_t I2C\_Enable

## 19.3.1.5 LastKeyUse

uint8\_t LastKeyUse[16]

## 19.3.1.6 LockConfig

uint8\_t LockConfig

## 19.3.1.7 LockValue

uint8\_t LockValue

## 19.3.1.8 OTPmode

uint8\_t OTPmode

#### 19.3.1.9 Reserved0

uint8\_t Reserved0

## 19.3.1.10 Reserved1

uint8\_t Reserved1

#### 19.3.1.11 Reserved2

uint8\_t Reserved2

## 19.3.1.12 RevNum

uint32\_t RevNum

#### 19.3.1.13 Selector

uint8\_t Selector

## 19.3.1.14 SlotConfig

uint16\_t SlotConfig[16]

## 19.3.1.15 SN03

uint32\_t SN03

## 19.3.1.16 SN47

uint32\_t SN47

#### 19.3.1.17 SN8

uint8\_t SN8

## 19.3.1.18 UserExtra

uint8\_t UserExtra

# 19.4 \_pcks11\_mech\_table\_e Struct Reference

## **Data Fields**

- CK\_MECHANISM\_TYPE type
- CK\_MECHANISM\_INFO info

#### 19.4.1 Field Documentation

#### 19.4.1.1 info

CK\_MECHANISM\_INFO info

## 19.4.1.2 type

CK\_MECHANISM\_TYPE type

## 19.5 \_pkcs11\_attrib\_model Struct Reference

#include <pkcs11\_attrib.h>

## **Data Fields**

- const CK\_ATTRIBUTE\_TYPE type
- const attrib\_f func

## 19.5.1 Field Documentation

#### 19.5.1.1 func

const attrib\_f func

#### 19.5.1.2 type

const CK\_ATTRIBUTE\_TYPE type

# 19.6 \_pkcs11\_lib\_ctx Struct Reference

#include <pkcs11\_init.h>

## **Data Fields**

- CK\_BBOOL initialized
- CK\_CREATEMUTEX create\_mutex
- CK\_DESTROYMUTEX destroy\_mutex
- CK\_LOCKMUTEX lock\_mutex
- CK\_UNLOCKMUTEX unlock\_mutex
- CK\_VOID\_PTR mutex
- CK\_VOID\_PTR slots
- CK\_ULONG slot\_cnt
- CK\_CHAR config\_path [200]

## 19.6.1 Detailed Description

Library Context

## 19.6.2 Field Documentation

## 19.6.2.1 config\_path

CK\_CHAR config\_path[200]

## 19.6.2.2 create\_mutex

CK\_CREATEMUTEX create\_mutex

#### 19.6.2.3 destroy\_mutex

 ${\tt CK\_DESTROYMUTEX} \ {\tt destroy\_mutex}$ 

## 19.6.2.4 initialized

CK\_BBOOL initialized

## 19.6.2.5 lock\_mutex

CK\_LOCKMUTEX lock\_mutex

## 19.6.2.6 mutex

CK\_VOID\_PTR mutex

## 19.6.2.7 slot\_cnt

CK\_ULONG slot\_cnt

## 19.6.2.8 slots

CK\_VOID\_PTR slots

## 19.6.2.9 unlock\_mutex

CK\_UNLOCKMUTEX unlock\_mutex

# 19.7 \_pkcs11\_object Struct Reference

#include <pkcs11\_object.h>

## **Data Fields**

- CK\_OBJECT\_CLASS class\_id
- CK\_ULONG class\_type
- pkcs11\_attrib\_model const \* attributes
- CK\_ULONG count
- CK\_ULONG size
- uint16\_t slot
- CK\_FLAGS flags
- CK\_UTF8CHAR name [PKCS11\_MAX\_LABEL\_SIZE+1]
- CK VOID PTR config
- CK\_VOID\_PTR data
- ta\_element\_attributes\_t handle\_info

#### 19.7.1 Field Documentation

#### 19.7.1.1 attributes

```
pkcs11_attrib_model const* attributes
```

List of attribute models this object possesses

## 19.7.1.2 class\_id

CK\_OBJECT\_CLASS class\_id

The Class Identifier

#### 19.7.1.3 class\_type

CK\_ULONG class\_type

The Class Type

## 19.7.1.4 config

CK\_VOID\_PTR config

#### 19.7.1.5 count

CK\_ULONG count

Count of attribute models

## 19.7.1.6 data

CK\_VOID\_PTR data

## 19.7.1.7 flags

CK\_FLAGS flags

#### 19.7.1.8 handle\_info

ta\_element\_attributes\_t handle\_info

#### 19.7.1.9 name

CK\_UTF8CHAR name[PKCS11\_MAX\_LABEL\_SIZE+1]

#### 19.7.1.10 size

CK\_ULONG size

#### 19.7.1.11 slot

uint16\_t slot

# 19.8 \_pkcs11\_object\_cache\_t Struct Reference

#include <pkcs11\_object.h>

## **Data Fields**

- CK\_OBJECT\_HANDLE handle
- pkcs11\_object\_ptr object

## 19.8.1 Field Documentation

#### 19.8.1.1 handle

CK\_OBJECT\_HANDLE handle

Arbitrary (but unique) non-null identifier for an object

#### 19.8.1.2 object

pkcs11\_object\_ptr object

The actual object

## 19.9 \_pkcs11\_session\_ctx Struct Reference

#include <pkcs11\_session.h>

## **Data Fields**

- CK\_BBOOL initialized
- pkcs11\_slot\_ctx\_ptr slot
- CK\_SESSION\_HANDLE handle
- CK\_STATE state
- CK\_ULONG error
- CK\_ATTRIBUTE\_PTR attrib\_list
- CK\_ULONG attrib\_count
- CK\_ULONG object\_index
- CK\_ULONG object\_count
- CK\_OBJECT\_HANDLE active\_object
- CK\_BBOOL logged\_in
- CK\_BYTE read\_key [32]

## 19.9.1 Detailed Description

Session Context

## 19.9.2 Field Documentation

## 19.9.2.1 active\_object

CK\_OBJECT\_HANDLE active\_object

## 19.9.2.2 attrib\_count

CK\_ULONG attrib\_count

## 19.9.2.3 attrib\_list

CK\_ATTRIBUTE\_PTR attrib\_list

#### 19.9.2.4 error

CK\_ULONG error

## 19.9.2.5 handle

CK\_SESSION\_HANDLE handle

## 19.9.2.6 initialized

CK\_BBOOL initialized

## 19.9.2.7 logged\_in

CK\_BBOOL logged\_in

## 19.9.2.8 object\_count

CK\_ULONG object\_count

#### 19.9.2.9 object\_index

CK\_ULONG object\_index

#### 19.9.2.10 read\_key

```
CK_BYTE read_key[32]
```

Accepted through C\_Login as the user pin

#### 19.9.2.11 slot

pkcs11\_slot\_ctx\_ptr slot

#### 19.9.2.12 state

CK\_STATE state

# 19.10 \_pkcs11\_slot\_ctx Struct Reference

#include <pkcs11\_slot.h>

#### **Data Fields**

- CK\_BBOOL initialized
- CK\_SLOT\_ID slot\_id
- ATCADevice device\_ctx
- ATCAlfaceCfg interface\_config
- CK\_SESSION\_HANDLE session
- atecc608\_config\_t cfg\_zone
- CK\_FLAGS flags
- uint16\_t user\_pin\_handle
- uint16\_t so\_pin\_handle
- CK\_UTF8CHAR label [PKCS11\_MAX\_LABEL\_SIZE+1]

## 19.10.1 Detailed Description

Slot Context

## 19.10.2 Field Documentation

#### 19.10.2.1 cfg\_zone

atecc608\_config\_t cfg\_zone

## 19.10.2.2 device\_ctx

ATCADevice device\_ctx

#### 19.10.2.3 flags

CK\_FLAGS flags

### 19.10.2.4 initialized

CK\_BBOOL initialized

## 19.10.2.5 interface\_config

ATCAIfaceCfg interface\_config

## 19.10.2.6 label

CK\_UTF8CHAR label[PKCS11\_MAX\_LABEL\_SIZE+1]

## 19.10.2.7 session

CK\_SESSION\_HANDLE session

#### 19.10.2.8 slot\_id

CK\_SLOT\_ID slot\_id

## 19.10.2.9 so\_pin\_handle

uint16\_t so\_pin\_handle

## 19.10.2.10 user\_pin\_handle

uint16\_t user\_pin\_handle

# 19.11 atca\_aes\_cbc\_ctx Struct Reference

#include <atca\_crypto\_hw\_aes.h>

#### **Data Fields**

• ATCADevice device

Device Context Pointer.

uint16\_t key\_id

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

uint8\_t key\_block

Index of the 16-byte block to use within the key location for the actual key.

• uint8\_t ciphertext [ATCA\_AES128\_BLOCK\_SIZE]

Ciphertext from last operation.

## 19.11.1 Field Documentation

## 19.11.1.1 ciphertext

uint8\_t ciphertext[ATCA\_AES128\_BLOCK\_SIZE]

Ciphertext from last operation.

#### 19.11.1.2 device

ATCADevice device

Device Context Pointer.

## 19.11.1.3 key\_block

uint8\_t key\_block

Index of the 16-byte block to use within the key location for the actual key.

#### 19.11.1.4 key\_id

uint16\_t key\_id

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

## 19.12 atca\_aes\_cmac\_ctx Struct Reference

#include <atca\_crypto\_hw\_aes.h>

### **Data Fields**

· atca aes cbc ctx t cbc ctx

CBC context.

• uint32\_t block\_size

Number of bytes in current block.

• uint8\_t block [ATCA\_AES128\_BLOCK\_SIZE]

Unprocessed message storage.

#### 19.12.1 Field Documentation

## 19.12.1.1 block

uint8\_t block[ATCA\_AES128\_BLOCK\_SIZE]

Unprocessed message storage.

#### 19.12.1.2 block\_size

```
uint32_t block_size
```

Number of bytes in current block.

#### 19.12.1.3 cbc\_ctx

```
atca_aes_cbc_ctx_t cbc_ctx
```

CBC context.

## 19.13 atca\_aes\_ctr\_ctx Struct Reference

```
#include <atca_crypto_hw_aes.h>
```

## **Data Fields**

ATCADevice device

Device Context Pointer.

· uint16\_t key\_id

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

• uint8\_t key\_block

Index of the 16-byte block to use within the key location for the actual key.

• uint8\_t cb [ATCA\_AES128\_BLOCK\_SIZE]

Counter block, comprises of nonce + count value (16 bytes).

• uint8\_t counter\_size

Size of counter in the initialization vector.

#### 19.13.1 Field Documentation

#### 19.13.1.1 cb

```
uint8_t cb[ATCA_AES128_BLOCK_SIZE]
```

Counter block, comprises of nonce + count value (16 bytes).

## 19.13.1.2 counter\_size

uint8\_t counter\_size

Size of counter in the initialization vector.

#### 19.13.1.3 device

ATCADevice device

Device Context Pointer.

## 19.13.1.4 key\_block

uint8\_t key\_block

Index of the 16-byte block to use within the key location for the actual key.

## 19.13.1.5 key\_id

uint16\_t key\_id

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

# 19.14 atca\_aes\_gcm\_ctx Struct Reference

#include <calib\_aes\_gcm.h>

#### **Data Fields**

· uint16\_t key\_id

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

· uint8\_t key\_block

Index of the 16-byte block to use within the key location for the actual key.

uint8\_t cb [AES\_DATA\_SIZE]

Counter block, comprises of nonce + count value (16 bytes).

• uint32 t data size

Size of the data being encrypted/decrypted in bytes.

· uint32 t aad size

Size of the additional authenticated data in bytes.

• uint8 th [AES DATA SIZE]

Subkey for ghash functions in GCM.

uint8\_t j0 [AES\_DATA\_SIZE]

Precounter block generated from IV.

• uint8\_t y [AES\_DATA\_SIZE]

Current GHASH output.

• uint8\_t partial\_aad [AES\_DATA\_SIZE]

Partial blocks of data waiting to be processed.

• uint32\_t partial\_aad\_size

Amount of data in the partial block buffer.

• uint8\_t enc\_cb [AES\_DATA\_SIZE]

Last encrypted counter block.

uint8\_t ciphertext\_block [AES\_DATA\_SIZE]

Last ciphertext block.

## 19.14.1 Detailed Description

Context structure for AES GCM operations.

## 19.14.2 Field Documentation

#### 19.14.2.1 aad size

```
uint32_t aad_size
```

Size of the additional authenticated data in bytes.

#### 19.14.2.2 cb

```
uint8_t cb[AES_DATA_SIZE]
```

Counter block, comprises of nonce + count value (16 bytes).

## 19.14.2.3 ciphertext\_block

```
uint8_t ciphertext_block[AES_DATA_SIZE]
```

Last ciphertext block.

#### 19.14.2.4 data\_size

```
uint32_t data_size
```

Size of the data being encrypted/decrypted in bytes.

## 19.14.2.5 enc\_cb

```
uint8_t enc_cb[AES_DATA_SIZE]
```

Last encrypted counter block.

## 19.14.2.6 h

```
uint8_t h[AES_DATA_SIZE]
```

Subkey for ghash functions in GCM.

## 19.14.2.7 j0

```
uint8_t j0[AES_DATA_SIZE]
```

Precounter block generated from IV.

## 19.14.2.8 key\_block

```
uint8_t key_block
```

Index of the 16-byte block to use within the key location for the actual key.

#### 19.14.2.9 key\_id

```
uint16_t key_id
```

Key location. Can either be a slot number or ATCA\_TEMPKEY\_KEYID for TempKey.

#### 19.14.2.10 partial\_aad

```
uint8_t partial_aad[AES_DATA_SIZE]
```

Partial blocks of data waiting to be processed.

#### 19.14.2.11 partial\_aad\_size

```
uint32_t partial_aad_size
```

Amount of data in the partial block buffer.

#### 19.14.2.12 y

```
uint8_t y[AES_DATA_SIZE]
```

Current GHASH output.

## 19.15 atca\_check\_mac\_in\_out Struct Reference

Input/output parameters for function atcah\_check\_mac().

```
#include <atca_host.h>
```

## **Data Fields**

```
• uint8_t mode
```

[in] CheckMac command Mode

uint16\_t key\_id

[in] CheckMac command KeyID

• const uint8\_t \* sn

[in] Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

const uint8\_t \* client\_chal

[in] ClientChal data, 32 bytes. Can be NULL if mode[0] is 1.

uint8\_t \* client\_resp

[out] Calculated ClientResp will be returned here.

• const uint8\_t \* other\_data

[in] OtherData, 13 bytes

const uint8\_t \* otp

[in] First 8 bytes of the OTP zone data. Can be NULL is mode[5] is 0.

- const uint8 t \* slot key
- const uint8\_t \* target\_key
- struct atca\_temp\_key \* temp\_key

 ${\it [in,out] Current state of TempKey. Required if mode [0] or mode [1] are 1.}$ 

## 19.15.1 Detailed Description

Input/output parameters for function atcah\_check\_mac().

### 19.15.2 Field Documentation

## 19.15.2.1 client\_chal

```
const uint8_t* client_chal
```

[in] ClientChal data, 32 bytes. Can be NULL if mode[0] is 1.

#### 19.15.2.2 client\_resp

```
uint8_t* client_resp
```

[out] Calculated ClientResp will be returned here.

#### 19.15.2.3 key\_id

```
uint16_t key_id
```

[in] CheckMac command KeyID

### 19.15.2.4 mode

```
uint8_t mode
```

[in] CheckMac command Mode

## 19.15.2.5 other\_data

```
const uint8_t* other_data
```

[in] OtherData, 13 bytes

#### 19.15.2.6 otp

```
const uint8_t* otp
```

[in] First 8 bytes of the OTP zone data. Can be NULL is mode[5] is 0.

#### 19.15.2.7 slot\_key

```
const uint8_t* slot_key
```

[in] 32 byte key value in the slot specified by slot\_id. Can be NULL if mode[1] is 1.

#### 19.15.2.8 sn

```
const uint8_t* sn
```

[in] Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

#### 19.15.2.9 target key

```
const uint8_t* target_key
```

[in] If this is not NULL, it assumes CheckMac copy is enabled for the specified key\_id (ReadKey=0). If key\_id is even, this should be the 32-byte key value for the slot key\_id+1, otherwise this should be set to slot\_key.

#### 19.15.2.10 temp\_key

```
struct atca_temp_key* temp_key
```

[in,out] Current state of TempKey. Required if mode[0] or mode[1] are 1.

# 19.16 atca\_command Struct Reference

atca\_command is the C object backing ATCACommand.

```
#include <atca_command.h>
```

### **Data Fields**

- ATCADeviceType dt
- uint8 t clock divider
- uint16\_t execution\_time\_msec

## 19.16.1 Detailed Description

atca\_command is the C object backing ATCACommand.

#### 19.16.2 Field Documentation

#### 19.16.2.1 clock\_divider

uint8\_t clock\_divider

#### 19.16.2.2 dt

ATCADeviceType dt

### 19.16.2.3 execution\_time\_msec

uint16\_t execution\_time\_msec

# 19.17 atca\_decrypt\_in\_out Struct Reference

Input/output parameters for function atca\_decrypt().

```
#include <atca_host.h>
```

#### **Data Fields**

- uint8\_t \* crypto\_data
  - [in,out] Pointer to 32-byte data. Input encrypted data from Read command (Contents field), output decrypted.
- struct atca\_temp\_key \* temp\_key

[in,out] Pointer to TempKey structure.

## 19.17.1 Detailed Description

Input/output parameters for function atca\_decrypt().

# 19.18 atca\_derive\_key\_in\_out Struct Reference

Input/output parameters for function atcah\_derive\_key().

```
#include <atca_host.h>
```

#### **Data Fields**

• uint8\_t mode

Mode (param 1) of the derive key command.

· uint16\_t target\_key\_id

Key ID (param 2) of the target slot to run the command on.

const uint8\_t \* sn

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

const uint8\_t \* parent\_key

Parent key to be used in the derive key calculation (32 bytes).

uint8\_t \* target\_key

Derived key will be returned here (32 bytes).

struct atca\_temp\_key \* temp\_key

Current state of TempKey.

## 19.18.1 Detailed Description

Input/output parameters for function atcah\_derive\_key().

#### 19.18.2 Field Documentation

### 19.18.2.1 mode

```
uint8_t mode
```

Mode (param 1) of the derive key command.

#### 19.18.2.2 parent key

```
const uint8_t* parent_key
```

Parent key to be used in the derive key calculation (32 bytes).

#### 19.18.2.3 sn

```
const uint8_t* sn
```

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

#### 19.18.2.4 target key

```
uint8_t* target_key
```

Derived key will be returned here (32 bytes).

#### 19.18.2.5 target\_key\_id

```
uint16_t target_key_id
```

Key ID (param 2) of the target slot to run the command on.

## 19.18.2.6 temp\_key

```
struct atca_temp_key* temp_key
```

Current state of TempKey.

# 19.19 atca\_derive\_key\_mac\_in\_out Struct Reference

Input/output parameters for function atcah\_derive\_key\_mac().

```
#include <atca_host.h>
```

#### **Data Fields**

• uint8 t mode

Mode (param 1) of the derive key command.

uint16\_t target\_key\_id

Key ID (param 2) of the target slot to run the command on.

• const uint8 t \* sn

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

const uint8\_t \* parent\_key

Parent key to be used in the derive key calculation (32 bytes).

• uint8\_t \* mac

DeriveKey MAC will be returned here.

## 19.19.1 Detailed Description

Input/output parameters for function atcah\_derive\_key\_mac().

## 19.19.2 Field Documentation

## 19.19.2.1 mac

```
uint8_t* mac
```

DeriveKey MAC will be returned here.

#### 19.19.2.2 mode

```
uint8_t mode
```

Mode (param 1) of the derive key command.

## 19.19.2.3 parent\_key

```
const uint8_t* parent_key
```

Parent key to be used in the derive key calculation (32 bytes).

#### 19.19.2.4 sn

```
const uint8_t* sn
```

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

## 19.19.2.5 target\_key\_id

```
uint16_t target_key_id
```

Key ID (param 2) of the target slot to run the command on.

# 19.20 atca\_device Struct Reference

atca\_device is the C object backing ATCADevice. See the atca\_device.h file for details on the ATCADevice methods

```
#include <atca_device.h>
```

#### **Data Fields**

ATCACommand mCommands

Command set for a given CryptoAuth device.

ATCAlface mlface

Physical interface.

- uint8\_t session\_state
- uint16\_t session\_counter
- uint16\_t session\_key\_id
- uint8\_t \* session\_key
- uint8\_t session\_key\_len

## 19.20.1 Detailed Description

atca\_device is the C object backing ATCADevice. See the atca\_device.h file for details on the ATCADevice methods

## 19.20.2 Field Documentation

#### 19.20.2.1 mCommands

ATCACommand mCommands

Command set for a given CryptoAuth device.

#### 19.20.2.2 mlface

ATCAIface mIface

Physical interface.

## 19.20.2.3 session\_counter

uint16\_t session\_counter

Secure Session Message Count

#### 19.20.2.4 session\_key

```
uint8_t* session_key
```

Session Key

#### 19.20.2.5 session key id

```
uint16_t session_key_id
```

Key ID used for a secure sesison

#### 19.20.2.6 session\_key\_len

```
uint8_t session_key_len
```

Length of key used for the session in bytes

#### 19.20.2.7 session\_state

```
uint8_t session_state
```

Secure Session State

## 19.21 atca gen dig in out Struct Reference

Input/output parameters for function atcah\_gen\_dig().

```
#include <atca_host.h>
```

#### **Data Fields**

• uint8 t zone

[in] Zone/Param1 for the GenDig command

· uint16\_t key\_id

[in] Keyld/Param2 for the GenDig command

• uint16\_t slot\_conf

[in] Slot config for the GenDig command

· uint16 t key conf

[in] Key config for the GenDig command

uint8\_t slot\_locked

[in] slot locked for the GenDig command

uint32\_t counter

[in] counter for the GenDig command

· bool is\_key\_nomac

[in] Set to true if the slot pointed to be key\_id has the SotConfig.NoMac bit set

const uint8\_t \* sn

 $\label{eq:solution} \textit{[in] Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.}$ 

• const uint8\_t \* stored\_value

[in] 32-byte slot value, config block, OTP block as specified by the Zone/Keyld parameters

• const uint8\_t \* other\_data

[in] 32-byte value for shared nonce zone, 4-byte value if is\_key\_nomac is true, ignored and/or NULL otherwise

struct atca\_temp\_key \* temp\_key

[inout] Current state of TempKey

## 19.21.1 Detailed Description

Input/output parameters for function atcah\_gen\_dig().

#### 19.21.2 Field Documentation

#### 19.21.2.1 counter

uint32\_t counter

[in] counter for the GenDig command

### 19.21.2.2 is\_key\_nomac

bool is\_key\_nomac

[in] Set to true if the slot pointed to be key\_id has the SotConfig.NoMac bit set

#### 19.21.2.3 key\_conf

uint16\_t key\_conf

[in] Key config for the GenDig command

#### 19.21.2.4 key\_id

uint16\_t key\_id

[in] Keyld/Param2 for the GenDig command

## 19.21.2.5 other\_data

const uint8\_t\* other\_data

[in] 32-byte value for shared nonce zone, 4-byte value if is\_key\_nomac is true, ignored and/or NULL otherwise

## 19.21.2.6 slot\_conf

```
uint16_t slot_conf
```

[in] Slot config for the GenDig command

#### 19.21.2.7 slot locked

```
uint8_t slot_locked
```

[in] slot locked for the GenDig command

#### 19.21.2.8 sn

```
const uint8_t* sn
```

[in] Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

### 19.21.2.9 stored\_value

```
const uint8_t* stored_value
```

[in] 32-byte slot value, config block, OTP block as specified by the Zone/Keyld parameters

#### 19.21.2.10 temp\_key

```
struct atca_temp_key* temp_key
```

[inout] Current state of TempKey

## 19.21.2.11 zone

uint8\_t zone

[in] Zone/Param1 for the GenDig command

## 19.22 atca\_gen\_key\_in\_out Struct Reference

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the <a href="atcah\_gen\_key\_msg">atcah\_gen\_key\_msg()</a> function.

```
#include <atca_host.h>
```

#### **Data Fields**

- uint8\_t mode
  - [in] GenKey Mode
- · uint16\_t key\_id

[in] GenKey KeyID

const uint8\_t \* public\_key

[in] Public key to be used in the PubKey digest. X and Y integers in big-endian format. 64 bytes for P256 curve.

· size\_t public\_key\_size

[in] Total number of bytes in the public key. 64 bytes for P256 curve.

const uint8\_t \* other\_data

[in] 3 bytes required when bit 4 of the mode is set. Can be NULL otherwise.

• const uint8 t \* sn

[in] Device serial number SN[0:8] (9 bytes). Only SN[0:1] and SN[8] are required though.

struct atca\_temp\_key \* temp\_key

[in,out] As input the current state of TempKey. As output, the resulting PubKEy digest.

## 19.22.1 Detailed Description

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the atcah\_gen\_key\_msg() function.

## 19.22.2 Field Documentation

#### 19.22.2.1 key\_id

uint16\_t key\_id

[in] GenKey KeyID

#### 19.22.2.2 mode

uint8\_t mode

[in] GenKey Mode

#### 19.22.2.3 other\_data

```
const uint8_t* other_data
```

[in] 3 bytes required when bit 4 of the mode is set. Can be NULL otherwise.

#### 19.22.2.4 public\_key

```
const uint8_t* public_key
```

[in] Public key to be used in the PubKey digest. X and Y integers in big-endian format. 64 bytes for P256 curve.

#### 19.22.2.5 public key size

```
size_t public_key_size
```

[in] Total number of bytes in the public key. 64 bytes for P256 curve.

#### 19.22.2.6 sn

```
const uint8_t* sn
```

[in] Device serial number SN[0:8] (9 bytes). Only SN[0:1] and SN[8] are required though.

#### 19.22.2.7 temp\_key

```
struct atca_temp_key* temp_key
```

[in,out] As input the current state of TempKey. As output, the resulting PubKEy digest.

# 19.23 atca\_hmac\_in\_out Struct Reference

Input/output parameters for function atca\_hmac().

```
#include <atca_host.h>
```

#### **Data Fields**

```
· uint8 t mode
```

[in] Mode parameter used in HMAC command (Param1).

· uint16\_t key\_id

[in] KeyID parameter used in HMAC command (Param2).

const uint8\_t \* key

[in] Pointer to 32-byte key used to generate HMAC digest.

const uint8\_t \* otp

[in] Pointer to 11-byte OTP, optionally included in HMAC digest, depending on mode.

• const uint8 t \* sn

[in] Pointer to 9-byte SN, optionally included in HMAC digest, depending on mode.

uint8\_t \* response

[out] Pointer to 32-byte SHA-256 HMAC digest.

struct atca\_temp\_key \* temp\_key

[in,out] Pointer to TempKey structure.

### 19.23.1 Detailed Description

Input/output parameters for function atca\_hmac().

## 19.24 atca iface Struct Reference

atca\_iface is the C object backing ATCAlface. See the atca\_iface.h file for details on the ATCAlface methods

```
#include <atca_iface.h>
```

### **Data Fields**

- ATCAlfaceType mType
- ATCAlfaceCfg \* mlfaceCFG
- ATCA\_STATUS(\* atinit )(void \*hal, ATCAlfaceCfg \*)
- ATCA\_STATUS(\* atpostinit )(ATCAlface hal)
- ATCA\_STATUS(\* atsend )(ATCAlface hal, uint8\_t word\_address, uint8\_t \*txdata, int txlength)
- ATCA\_STATUS(\* atreceive )(ATCAlface hal, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)
- ATCA STATUS(\* atwake )(ATCAlface hal)
- ATCA STATUS(\* atidle )(ATCAlface hal)
- ATCA\_STATUS(\* atsleep )(ATCAlface hal)
- void \* hal data

#### 19.24.1 Detailed Description

atca iface is the C object backing ATCAlface. See the atca iface.h file for details on the ATCAlface methods

#### 19.24.2 Field Documentation

## 19.24.2.1 atidle

```
ATCA_STATUS(* atidle) (ATCAIface hal)
```

#### 19.24.2.2 atinit

```
ATCA_STATUS(* atinit) (void *hal, ATCAIfaceCfg *)
```

## 19.24.2.3 atpostinit

```
ATCA_STATUS(* atpostinit) (ATCAIface hal)
```

#### 19.24.2.4 atreceive

```
ATCA_STATUS(* atreceive) (ATCAIface hal, uint8_t word_address, uint8_t *rxdata, uint16_t *rxlength)
```

## 19.24.2.5 atsend

```
ATCA_STATUS(* atsend) (ATCAIface hal, uint8_t word_address, uint8_t *txdata, int txlength)
```

#### 19.24.2.6 atsleep

```
ATCA_STATUS(* atsleep) (ATCAIface hal)
```

## 19.24.2.7 atwake

```
ATCA_STATUS(* atwake) (ATCAIface hal)
```

#### 19.24.2.8 hal\_data

void\* hal\_data

#### 19.24.2.9 mlfaceCFG

ATCAIfaceCfg\* mIfaceCFG

## 19.24.2.10 mType

ATCAIfaceType mType

# 19.25 atca\_include\_data\_in\_out Struct Reference

Input / output parameters for function atca\_include\_data().

```
#include <atca_host.h>
```

## **Data Fields**

uint8\_t \* p\_temp

[out] pointer to output buffer

const uint8\_t \* otp

[in] pointer to one-time-programming data

const uint8\_t \* sn

[in] pointer to serial number data

• uint8\_t mode

## 19.25.1 Detailed Description

Input / output parameters for function atca\_include\_data().

#### 19.25.2 Field Documentation

### 19.25.2.1 mode

uint8\_t mode

# 19.26 atca\_io\_decrypt\_in\_out Struct Reference

#include <atca\_host.h>

## **Data Fields**

```
    const uint8_t * io_key
        IO protection key (32 bytes).
    const uint8_t * out_nonce
        OutNonce returned from command (32 bytes).
    uint8_t * data
        As input, encrypted data. As output, decrypted data.
    size_t data_size
```

## 19.26.1 Field Documentation

Size of data in bytes (32 or 64).

#### 19.26.1.1 data

```
uint8_t* data
```

As input, encrypted data. As output, decrypted data.

## 19.26.1.2 data\_size

```
size_t data_size
```

Size of data in bytes (32 or 64).

## 19.26.1.3 io\_key

```
const uint8_t* io_key
```

IO protection key (32 bytes).

## 19.26.1.4 out\_nonce

```
const uint8_t* out_nonce
```

OutNonce returned from command (32 bytes).

# 19.27 atca\_jwt\_t Struct Reference

Structure to hold metadata information about the jwt being built.

```
#include <atca_jwt.h>
```

## **Data Fields**

- char \* buf
- uint16\_t buflen
- uint16\_t cur

## 19.27.1 Detailed Description

Structure to hold metadata information about the jwt being built.

## 19.27.2 Field Documentation

### 19.27.2.1 buf

char\* buf

## 19.27.2.2 buflen

uint16\_t buflen

#### 19.27.2.3 cur

uint16\_t cur

# 19.28 atca\_mac\_in\_out Struct Reference

Input/output parameters for function atca\_mac().

#include <atca\_host.h>

#### **Data Fields**

```
• uint8 t mode
     [in] Mode parameter used in MAC command (Param1).
uint16_t key_id
     [in] KeyID parameter used in MAC command (Param2).
• const uint8_t * challenge
     [in] Pointer to 32-byte Challenge data used in MAC command, depending on mode.

    const uint8 t * key

     [in] Pointer to 32-byte key used to generate MAC digest.
const uint8_t * otp
     [in] Pointer to 11-byte OTP, optionally included in MAC digest, depending on mode.
• const uint8_t * sn
     [in] Pointer to 9-byte SN, optionally included in MAC digest, depending on mode.
• uint8_t * response
     [out] Pointer to 32-byte SHA-256 digest (MAC).
struct atca_temp_key * temp_key
     [in,out] Pointer to TempKey structure.
```

## 19.28.1 Detailed Description

Input/output parameters for function atca\_mac().

# 19.29 atca\_nonce\_in\_out Struct Reference

```
Input/output parameters for function atca_nonce().
```

```
#include <atca_host.h>
```

#### **Data Fields**

```
    uint8_t mode
        [in] Mode parameter used in Nonce command (Param1).
    uint16_t zero
        [in] Zero parameter used in Nonce command (Param2).
    const uint8_t * num_in
        [in] Pointer to 20-byte NumIn data used in Nonce command.
    const uint8_t * rand_out
        [in] Pointer to 32-byte RandOut data from Nonce command.
```

[in,out] Pointer to TempKey structure.

struct atca\_temp\_key \* temp\_key

## 19.29.1 Detailed Description

Input/output parameters for function atca\_nonce().

# 19.30 atca\_secureboot\_enc\_in\_out Struct Reference

```
#include <atca_host.h>
```

#### **Data Fields**

• const uint8\_t \* io\_key

IO protection key value (32 bytes)

const struct atca\_temp\_key \* temp\_key

Current value of TempKey.

const uint8\_t \* digest

Plaintext digest as input.

uint8\_t \* hashed\_key

Calculated key is returned here (32 bytes)

• uint8\_t \* digest\_enc

Encrypted (ciphertext) digest is return here (32 bytes)

## 19.30.1 Field Documentation

#### 19.30.1.1 digest

```
const uint8_t* digest
```

Plaintext digest as input.

## 19.30.1.2 digest\_enc

```
uint8_t* digest_enc
```

Encrypted (ciphertext) digest is return here (32 bytes)

## 19.30.1.3 hashed\_key

```
uint8_t* hashed_key
```

Calculated key is returned here (32 bytes)

### 19.30.1.4 io\_key

```
const uint8_t* io_key
```

IO protection key value (32 bytes)

## 19.30.1.5 temp\_key

```
const struct atca_temp_key* temp_key
```

Current value of TempKey.

## 19.31 atca\_secureboot\_mac\_in\_out Struct Reference

```
#include <atca_host.h>
```

## **Data Fields**

• uint8\_t mode

SecureBoot mode (param1)

• uint16\_t param2

SecureBoot param2.

• uint16\_t secure\_boot\_config

SecureBootConfig value from configuration zone.

const uint8\_t \* hashed\_key

Hashed key. SHA256(IO Protection Key | TempKey)

• const uint8\_t \* digest

Digest (unencrypted)

• const uint8\_t \* signature

Signature (can be NULL if not required)

• uint8\_t \* mac

MAC is returned here.

## 19.31.1 Field Documentation

### 19.31.1.1 digest

```
const uint8_t* digest
```

Digest (unencrypted)

## 19.31.1.2 hashed\_key

const uint8\_t\* hashed\_key

Hashed key. SHA256(IO Protection Key | TempKey)

#### 19.31.1.3 mac

uint8\_t\* mac

MAC is returned here.

## 19.31.1.4 mode

uint8\_t mode

SecureBoot mode (param1)

## 19.31.1.5 param2

uint16\_t param2

SecureBoot param2.

## 19.31.1.6 secure\_boot\_config

uint16\_t secure\_boot\_config

SecureBootConfig value from configuration zone.

## 19.31.1.7 signature

const uint8\_t\* signature

Signature (can be NULL if not required)

## 19.32 atca sha256 ctx Struct Reference

```
#include <calib_basic.h>
```

### **Data Fields**

• uint32\_t total\_msg\_size

Total number of message bytes processed.

• uint32\_t block\_size

Number of bytes in current block.

uint8\_t block [ATCA\_SHA256\_BLOCK\_SIZE \*2]

Unprocessed message storage.

#### 19.32.1 Field Documentation

#### 19.32.1.1 block

```
uint8_t block[ATCA_SHA256_BLOCK_SIZE *2]
```

Unprocessed message storage.

#### 19.32.1.2 block size

uint32\_t block\_size

Number of bytes in current block.

## 19.32.1.3 total\_msg\_size

uint32\_t total\_msg\_size

Total number of message bytes processed.

# 19.33 atca\_sign\_internal\_in\_out Struct Reference

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

#include <atca\_host.h>

#### **Data Fields**

```
• uint8 t mode
```

[in] Sign Mode

uint16\_t key\_id

[in] Sign KeyID

uint16 t slot config

[in] SlotConfig[TempKeyFlags.keyId]

• uint16\_t key\_config

[in] KeyConfig[TempKeyFlags.keyId]

uint8\_t use\_flag

[in] UseFlag[TempKeyFlags.keyId], 0x00 for slots 8 and above and for ATECC508A

uint8\_t update\_count

[in] UpdateCount[TempKeyFlags.keyId], 0x00 for slots 8 and above and for ATECC508A

· bool is slot locked

[in] Is TempKeyFlags.keyId slot locked.

· bool for\_invalidate

[in] Set to true if this will be used for the Verify(Invalidate) command.

• const uint8 t \* sn

[in] Device serial number SN[0:8] (9 bytes)

const struct atca\_temp\_key \* temp\_key

[in] The current state of TempKey.

• uint8\_t \* message

[out] Full 55 byte message the Sign(internal) command will build. Can be NULL if not required.

uint8\_t \* verify\_other\_data

[out] The 19 byte OtherData bytes to be used with the Verify(In/Validate) command. Can be NULL if not required.

• uint8\_t \* digest

[out] SHA256 digest of the full 55 byte message. Can be NULL if not required.

#### 19.33.1 Detailed Description

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

#### 19.33.2 Field Documentation

#### 19.33.2.1 digest

uint8\_t\* digest

[out] SHA256 digest of the full 55 byte message. Can be NULL if not required.

## 19.33.2.2 for\_invalidate

bool for\_invalidate

[in] Set to true if this will be used for the Verify(Invalidate) command.

#### 19.33.2.3 is\_slot\_locked

bool is\_slot\_locked

[in] Is TempKeyFlags.keyId slot locked.

## 19.33.2.4 key\_config

uint16\_t key\_config

[in] KeyConfig[TempKeyFlags.keyId]

## 19.33.2.5 key\_id

uint16\_t key\_id

[in] Sign KeyID

## 19.33.2.6 message

uint8\_t\* message

[out] Full 55 byte message the Sign(internal) command will build. Can be NULL if not required.

### 19.33.2.7 mode

uint8\_t mode

[in] Sign Mode

#### 19.33.2.8 slot\_config

```
uint16_t slot_config
```

[in] SlotConfig[TempKeyFlags.keyId]

#### 19.33.2.9 sn

```
const uint8_t* sn
```

[in] Device serial number SN[0:8] (9 bytes)

### 19.33.2.10 temp\_key

```
const struct atca_temp_key* temp_key
```

[in] The current state of TempKey.

### 19.33.2.11 update\_count

```
uint8_t update_count
```

[in] UpdateCount[TempKeyFlags.keyId], 0x00 for slots 8 and above and for ATECC508A

#### 19.33.2.12 use\_flag

```
uint8_t use_flag
```

[in] UseFlag[TempKeyFlags.keyId], 0x00 for slots 8 and above and for ATECC508A

### 19.33.2.13 verify\_other\_data

```
uint8_t* verify_other_data
```

[out] The 19 byte OtherData bytes to be used with the Verify(In/Validate) command. Can be NULL if not required.

## 19.34 atca temp key Struct Reference

Structure to hold TempKey fields.

```
#include <atca_host.h>
```

#### **Data Fields**

• uint8\_t value [ATCA\_KEY\_SIZE \*2]

Value of TempKey (64 bytes for ATECC608 only)

· unsigned key\_id: 4

If TempKey was derived from a slot or transport key (GenDig or GenKey), that key ID is saved here.

• unsigned source\_flag: 1

Indicates id TempKey started from a random nonce (0) or not (1).

• unsigned gen\_dig\_data: 1

TempKey was derived from the GenDig command.

• unsigned gen\_key\_data: 1

TempKey was derived from the GenKey command (ATECC devices only).

unsigned no\_mac\_flag: 1

TempKey was derived from a key that has the NoMac bit set preventing the use of the MAC command. Known as CheckFlag in ATSHA devices).

• unsigned valid: 1

TempKey is valid.

uint8\_t is\_64

TempKey has 64 bytes of valid data.

## 19.34.1 Detailed Description

Structure to hold TempKey fields.

#### 19.34.2 Field Documentation

### 19.34.2.1 gen\_dig\_data

```
unsigned gen_dig_data
```

TempKey was derived from the GenDig command.

#### 19.34.2.2 gen\_key\_data

```
unsigned gen_key_data
```

TempKey was derived from the GenKey command (ATECC devices only).

#### 19.34.2.3 is\_64

```
uint8_t is_64
```

TempKey has 64 bytes of valid data.

#### 19.34.2.4 key\_id

```
unsigned key_id
```

If TempKey was derived from a slot or transport key (GenDig or GenKey), that key ID is saved here.

## 19.34.2.5 no\_mac\_flag

```
unsigned no_mac_flag
```

TempKey was derived from a key that has the NoMac bit set preventing the use of the MAC command. Known as CheckFlag in ATSHA devices).

## 19.34.2.6 source\_flag

```
unsigned source_flag
```

Indicates id TempKey started from a random nonce (0) or not (1).

#### 19.34.2.7 valid

unsigned valid

TempKey is valid.

#### 19.34.2.8 value

```
uint8_t value[ATCA_KEY_SIZE *2]
```

Value of TempKey (64 bytes for ATECC608 only)

## 19.35 atca\_verify\_in\_out Struct Reference

Input/output parameters for function atcah\_verify().

```
#include <atca_host.h>
```

#### **Data Fields**

```
• uint16_t curve_type
```

[in] Curve type used in Verify command (Param2).

• const uint8\_t \* signature

[in] Pointer to ECDSA signature to be verified

const uint8\_t \* public\_key

[in] Pointer to the public key to be used for verification

struct atca\_temp\_key \* temp\_key

[in,out] Pointer to TempKey structure.

## 19.35.1 Detailed Description

Input/output parameters for function atcah\_verify().

# 19.36 atca\_verify\_mac Struct Reference

```
#include <atca_host.h>
```

#### **Data Fields**

```
· uint8_t mode
```

Mode (Param1) parameter used in Verify command.

uint16\_t key\_id

KeyID (Param2) used in Verify command.

• const uint8\_t \* signature

Signature used in Verify command (64 bytes).

• const uint8\_t \* other\_data

OtherData used in Verify command (19 bytes).

• const uint8\_t \* msg\_dig\_buf

Message digest buffer (64 bytes).

const uint8\_t \* io\_key

IO protection key value (32 bytes).

• const uint8\_t \* sn

Serial number (9 bytes).

const atca\_temp\_key\_t \* temp\_key

TempKey.

• uint8\_t \* mac

Calculated verification MAC is returned here (32 bytes).

## 19.36.1 Field Documentation

## 19.36.1.1 io\_key

```
const uint8_t* io_key
```

IO protection key value (32 bytes).

## 19.36.1.2 key\_id

```
uint16_t key_id
```

KeyID (Param2) used in Verify command.

#### 19.36.1.3 mac

uint8\_t\* mac

Calculated verification MAC is returned here (32 bytes).

## 19.36.1.4 mode

uint8\_t mode

Mode (Param1) parameter used in Verify command.

## 19.36.1.5 msg\_dig\_buf

```
const uint8_t* msg_dig_buf
```

Message digest buffer (64 bytes).

#### 19.36.1.6 other\_data

```
const uint8_t* other_data
```

OtherData used in Verify command (19 bytes).

#### 19.36.1.7 signature

```
const uint8_t* signature
```

Signature used in Verify command (64 bytes).

#### 19.36.1.8 sn

```
const uint8_t* sn
```

Serial number (9 bytes).

#### 19.36.1.9 temp\_key

```
const atca_temp_key_t* temp_key
```

TempKey.

## 19.37 atca write mac in out Struct Reference

Input/output parameters for function atcah write auth mac() and atcah privwrite auth mac().

```
#include <atca host.h>
```

#### **Data Fields**

• uint8\_t zone

Zone/Param1 for the Write or PrivWrite command.

· uint16 t key id

KeyID/Param2 for the Write or PrivWrite command.

• const uint8 t \* sn

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

• const uint8\_t \* input\_data

Data to be encrypted. 32 bytes for Write command, 36 bytes for PrivWrite command.

• uint8\_t \* encrypted\_data

Encrypted version of input\_data will be returned here. 32 bytes for Write command, 36 bytes for PrivWrite command.

• uint8\_t \* auth\_mac

Write MAC will be returned here. 32 bytes.

struct atca\_temp\_key \* temp\_key

Current state of TempKey.

## 19.37.1 Detailed Description

Input/output parameters for function atcah\_write\_auth\_mac() and atcah\_privwrite\_auth\_mac().

#### 19.37.2 Field Documentation

## 19.37.2.1 auth\_mac

```
uint8_t* auth_mac
```

Write MAC will be returned here. 32 bytes.

#### 19.37.2.2 encrypted\_data

```
uint8_t* encrypted_data
```

Encrypted version of input\_data will be returned here. 32 bytes for Write command, 36 bytes for PrivWrite command.

#### 19.37.2.3 input\_data

```
const uint8_t* input_data
```

Data to be encrypted. 32 bytes for Write command, 36 bytes for PrivWrite command.

#### 19.37.2.4 key\_id

```
uint16_t key_id
```

KeyID/Param2 for the Write or PrivWrite command.

#### 19.37.2.5 sn

```
const uint8_t* sn
```

Device serial number SN[0:8]. Only SN[0:1] and SN[8] are required though.

#### 19.37.2.6 temp\_key

```
struct atca_temp_key* temp_key
```

Current state of TempKey.

#### 19.37.2.7 zone

```
uint8_t zone
```

Zone/Param1 for the Write or PrivWrite command.

# 19.38 atcacert\_build\_state\_s Struct Reference

```
#include <atcacert def.h>
```

#### **Data Fields**

• const atcacert\_def\_t \* cert\_def

Certificate definition for the certificate being rebuilt.

• uint8\_t \* cert

Buffer to contain the rebuilt certificate.

• size\_t \* cert\_size

Current size of the certificate in bytes.

• size\_t max\_cert\_size

Max size of the cert buffer in bytes.

uint8\_t is\_device\_sn

Indicates the structure contains the device SN.

• uint8\_t device\_sn [9]

Storage for the device SN, when it's found.

## 19.38.1 Detailed Description

Tracks the state of a certificate as it's being rebuilt from device information.

#### 19.38.2 Field Documentation

#### 19.38.2.1 cert

```
uint8_t* cert
```

Buffer to contain the rebuilt certificate.

#### 19.38.2.2 cert def

```
const atcacert_def_t* cert_def
```

Certificate definition for the certificate being rebuilt.

## 19.38.2.3 cert\_size

```
size_t* cert_size
```

Current size of the certificate in bytes.

## 19.38.2.4 device\_sn

```
uint8_t device_sn[9]
```

Storage for the device SN, when it's found.

## 19.38.2.5 is\_device\_sn

```
uint8_t is_device_sn
```

Indicates the structure contains the device SN.

#### 19.38.2.6 max\_cert\_size

```
size_t max_cert_size
```

Max size of the cert buffer in bytes.

## 19.39 atcacert cert element s Struct Reference

#include <atcacert\_def.h>

## **Data Fields**

• char id [25]

ID identifying this element.

· atcacert device loc t device loc

Location in the device for the element.

atcacert\_cert\_loc\_t cert\_loc

Location in the certificate template for the element.

• atcacert\_transform\_t transforms [2]

List of transforms from device to cert for this element.

## 19.39.1 Detailed Description

Defines a generic dynamic element for a certificate including the device and template locations.

## 19.39.2 Field Documentation

#### 19.39.2.1 cert\_loc

```
atcacert_cert_loc_t cert_loc
```

Location in the certificate template for the element.

#### 19.39.2.2 device\_loc

```
atcacert_device_loc_t device_loc
```

Location in the device for the element.

#### 19.39.2.3 id

char id[25]

ID identifying this element.

#### 19.39.2.4 transforms

```
atcacert_transform_t transforms[2]
```

List of transforms from device to cert for this element.

# 19.40 atcacert\_cert\_loc\_s Struct Reference

```
#include <atcacert_def.h>
```

#### **Data Fields**

• uint16\_t offset

Byte offset in the certificate template.

uint16\_t count

Byte count. Set to 0 if it doesn't exist.

## 19.40.1 Detailed Description

Defines a chunk of data in a certificate template.

#### 19.40.2 Field Documentation

#### 19.40.2.1 count

uint16\_t count

Byte count. Set to 0 if it doesn't exist.

#### 19.40.2.2 offset

uint16\_t offset

Byte offset in the certificate template.

# 19.41 atcacert\_def\_s Struct Reference

#include <atcacert\_def.h>

#### **Data Fields**

· atcacert\_cert\_type\_t type

Certificate type.

uint8\_t template\_id

ID for the this certificate definition (4-bit value).

• uint8\_t chain\_id

ID for the certificate chain this definition is a part of (4-bit value).

uint8\_t private\_key\_slot

If this is a device certificate template, this is the device slot for the device private key.

· atcacert\_cert\_sn\_src\_t sn\_source

Where the certificate serial number comes from (4-bit value).

atcacert\_device\_loc\_t cert\_sn\_dev\_loc

Only applies when sn\_source is SNSRC\_STORED or SNSRC\_STORED\_DYNAMIC. Describes where to get the certificate serial number on the device.

• atcacert\_date\_format\_t issue\_date\_format

Format of the issue date in the certificate.

atcacert\_date\_format\_t expire\_date\_format

format of the expire date in the certificate.

atcacert\_cert\_loc\_t tbs\_cert\_loc

Location in the certificate for the TBS (to be signed) portion.

· uint8 t expire years

Number of years the certificate is valid for (5-bit value). 0 means no expiration.

• atcacert\_device\_loc\_t public\_key\_dev\_loc

Where on the device the public key can be found.

atcacert\_device\_loc\_t comp\_cert\_dev\_loc

Where on the device the compressed cert can be found.

atcacert\_cert\_loc\_t std\_cert\_elements [STDCERT\_NUM\_ELEMENTS]

Where in the certificate template the standard cert elements are inserted.

const atcacert\_cert\_element\_t \* cert\_elements

Additional certificate elements outside of the standard certificate contents.

uint8\_t cert\_elements\_count

Number of additional certificate elements in cert elements.

• const uint8 t \* cert template

Pointer to the actual certificate template data.

• uint16\_t cert\_template\_size

Size of the certificate template in cert\_template in bytes.

const struct atcacert\_def\_s \* ca\_cert\_def

Certificate definition of the CA certificate.

#### 19.41.1 Detailed Description

Defines a certificate and all the pieces to work with it.

If any of the standard certificate elements (std\_cert\_elements) are not a part of the certificate definition, set their count to 0 to indicate their absence.

#### 19.41.2 Field Documentation

#### 19.41.2.1 ca\_cert\_def

```
const struct atcacert_def_s* ca_cert_def
```

Certificate definition of the CA certificate.

#### 19.41.2.2 cert\_elements

```
const atcacert_cert_element_t* cert_elements
```

Additional certificate elements outside of the standard certificate contents.

#### 19.41.2.3 cert\_elements\_count

```
uint8_t cert_elements_count
```

Number of additional certificate elements in cert\_elements.

#### 19.41.2.4 cert\_sn\_dev\_loc

```
atcacert_device_loc_t cert_sn_dev_loc
```

Only applies when sn\_source is SNSRC\_STORED or SNSRC\_STORED\_DYNAMIC. Describes where to get the certificate serial number on the device.

## 19.41.2.5 cert\_template

```
const uint8_t* cert_template
```

Pointer to the actual certificate template data.

#### 19.41.2.6 cert\_template\_size

```
uint16_t cert_template_size
```

Size of the certificate template in cert\_template in bytes.

#### 19.41.2.7 chain\_id

```
uint8_t chain_id
```

ID for the certificate chain this definition is a part of (4-bit value).

#### 19.41.2.8 comp\_cert\_dev\_loc

```
atcacert_device_loc_t comp_cert_dev_loc
```

Where on the device the compressed cert can be found.

## 19.41.2.9 expire\_date\_format

```
atcacert_date_format_t expire_date_format
```

format of the expire date in the certificate.

## 19.41.2.10 expire\_years

```
uint8_t expire_years
```

Number of years the certificate is valid for (5-bit value). 0 means no expiration.

## 19.41.2.11 issue\_date\_format

```
atcacert_date_format_t issue_date_format
```

Format of the issue date in the certificate.

## 19.41.2.12 private\_key\_slot

```
uint8_t private_key_slot
```

If this is a device certificate template, this is the device slot for the device private key.

## 19.41.2.13 public\_key\_dev\_loc

```
atcacert_device_loc_t public_key_dev_loc
```

Where on the device the public key can be found.

#### 19.41.2.14 sn source

```
atcacert_cert_sn_src_t sn_source
```

Where the certificate serial number comes from (4-bit value).

#### 19.41.2.15 std\_cert\_elements

```
atcacert_cert_loc_t std_cert_elements[STDCERT_NUM_ELEMENTS]
```

Where in the certificate template the standard cert elements are inserted.

#### 19.41.2.16 tbs\_cert\_loc

```
atcacert_cert_loc_t tbs_cert_loc
```

Location in the certificate for the TBS (to be signed) portion.

#### 19.41.2.17 template\_id

```
uint8_t template_id
```

ID for the this certificate definition (4-bit value).

#### 19.41.2.18 type

```
atcacert_cert_type_t type
```

Certificate type.

# 19.42 atcacert\_device\_loc\_s Struct Reference

```
#include <atcacert_def.h>
```

#### **Data Fields**

• atcacert\_device\_zone\_t zone

Zone in the device.

uint8\_t slot

Slot within the data zone. Only applies if zone is DEVZONE\_DATA.

uint8\_t is\_genkey

If true, use GenKey command to get the contents instead of Read.

uint16\_t offset

Byte offset in the zone.

• uint16\_t count

Byte count.

## 19.42.1 Detailed Description

Defines a chunk of data in an ATECC device.

#### 19.42.2 Field Documentation

#### 19.42.2.1 count

uint16\_t count

Byte count.

## 19.42.2.2 is\_genkey

```
uint8_t is_genkey
```

If true, use GenKey command to get the contents instead of Read.

## 19.42.2.3 offset

uint16\_t offset

Byte offset in the zone.

#### 19.42.2.4 slot

```
uint8_t slot
```

Slot within the data zone. Only applies if zone is DEVZONE\_DATA.

#### 19.42.2.5 zone

```
atcacert_device_zone_t zone
```

Zone in the device.

# 19.43 atcacert\_tm\_utc\_s Struct Reference

```
#include <atcacert_date.h>
```

## **Data Fields**

- int tm\_sec
- int tm\_min
- int tm\_hour
- int tm\_mday
- int tm\_mon
- int tm\_year

## 19.43.1 Detailed Description

Holds a broken-down date in UTC. Mimics atcacert\_tm\_utc\_t from time.h.

#### 19.43.2 Field Documentation

#### 19.43.2.1 tm\_hour

int tm\_hour

## 19.43.2.2 tm\_mday

int tm\_mday

#### 19.43.2.3 tm\_min

int tm\_min

## 19.43.2.4 tm\_mon

int tm\_mon

#### 19.43.2.5 tm sec

int tm\_sec

#### 19.43.2.6 tm\_year

int tm\_year

# 19.44 ATCAHAL\_t Struct Reference

an intermediary data structure to allow the HAL layer to point the standard API functions used by the upper layers to the HAL implementation for the interface. This isolates the upper layers and loosely couples the ATCAlface object from the physical implementation.

```
#include <atca_hal.h>
```

#### **Data Fields**

- ATCA\_STATUS(\* halinit)(void \*hal, ATCAlfaceCfg \*cfg)
- ATCA\_STATUS(\* halpostinit )(ATCAlface iface)
- ATCA\_STATUS(\* halsend )(ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)
- ATCA\_STATUS(\* halreceive )(ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)
- ATCA STATUS(\* halwake )(ATCAlface iface)
- ATCA\_STATUS(\* halidle )(ATCAlface iface)
- ATCA\_STATUS(\* halsleep )(ATCAlface iface)
- ATCA\_STATUS(\* halrelease )(void \*hal\_data)
- void \* hal\_data

## 19.44.1 Detailed Description

an intermediary data structure to allow the HAL layer to point the standard API functions used by the upper layers to the HAL implementation for the interface. This isolates the upper layers and loosely couples the ATCAlface object from the physical implementation.

## 19.44.2 Field Documentation

## 19.44.2.1 hal\_data

void\* hal\_data

#### 19.44.2.2 halidle

```
ATCA_STATUS(* halidle) (ATCAIface iface)
```

#### 19.44.2.3 halinit

```
ATCA_STATUS(* halinit) (void *hal, ATCAIfaceCfg *cfg)
```

#### 19.44.2.4 halpostinit

```
ATCA_STATUS(* halpostinit) (ATCAIface iface)
```

#### 19.44.2.5 halreceive

 $\label{eq:atcastatus} \mbox{ATCA\_STATUS} \mbox{ (* halreceive) (ATCAIface iface, uint8\_t word\_address, uint8\_t *rxdata, uint16\_ \mbox{$\leftarrow$} t *rxlength)$ 

#### 19.44.2.6 halrelease

```
ATCA_STATUS(* halrelease) (void *hal_data)
```

## 19.44.2.7 halsend

```
ATCA_STATUS(* halsend) (ATCAIface iface, uint8_t word_address, uint8_t *txdata, int txlength)
```

#### 19.44.2.8 halsleep

```
ATCA_STATUS(* halsleep) (ATCAIface iface)
```

#### 19.44.2.9 halwake

```
ATCA_STATUS(* halwake) (ATCAIface iface)
```

## 19.45 atcal2Cmaster Struct Reference

this is the hal\_data for ATCA HAL for ASF SERCOM

```
#include <hal_linux_i2c_userspace.h>
```

## **Data Fields**

- int id
- int ref\_ct
- int bus\_index
- char i2c\_file [16]
- uint8\_t twi\_id
- avr32\_twi\_t \* twi\_master\_instance

## 19.45.1 Detailed Description

this is the hal\_data for ATCA HAL for ASF SERCOM

## 19.45.2 Field Documentation

#### 19.45.2.1 bus\_index

int bus\_index

## 19.45.2.2 i2c\_file

char i2c\_file[16]

## 19.45.2.3 id

int id

## 19.45.2.4 ref\_ct

int ref\_ct

#### 19.45.2.5 twi\_id

uint8\_t twi\_id

#### 19.45.2.6 twi\_master\_instance

avr32\_twi\_t\* twi\_master\_instance

# **ATCAlfaceCfg Struct Reference**

#include <atca\_iface.h>

#### **Data Fields**

```
• ATCAlfaceType iface_type
```

```
• ATCADeviceType devtype
• union {
    struct {
      uint8_t slave_address
      uint8_t bus
      uint32_t baud
    } atcai2c
    struct {
      uint8_t bus
    } atcaswi
    struct {
      uint8 t bus
      uint8_t select_pin
      uint32_t baud
    } atcaspi
    struct {
      int port
      uint32_t baud
```

uint8\_t wordsize

```
uint8_t parity
      uint8_t stopbits
    } atcauart
    struct {
      int idx
      ATCAKitType dev interface
      uint8 t dev identity
      uint32_t vid
      uint32 t pid
      uint32_t packetsize
    } atcahid
            struct {
               ATCA_STATUS(* halinit )(void *hal, void *cfg)
               ATCA_STATUS(* halpostinit )(void *iface)
               ATCA_STATUS(* halsend )(void *iface, uint8_t
                 word_address, uint8_t *txdata,
                 int txlength)
               ATCA_STATUS(* halreceive )(void *iface, uint8_t
                 word_address, uint8_t *rxdata,
                 uint16_t *rxlength)
               ATCA STATUS(* halwake )(void *iface)
               ATCA STATUS(* halidle )(void *iface)
               ATCA_STATUS(* halsleep )(void *iface)
               ATCA_STATUS(* halrelease )(void *hal_data)
            } atcacustom
          };
· uint16 t wake delay
• int rx_retries
void * cfg_data
```

#### 19.46.1 Field Documentation

```
19.46.1.1 "@1
union { ... }
```

#### 19.46.1.2 atcacustom

```
struct { ... } atcacustom
```

#### 19.46.1.3 atcahid

```
struct { ... } atcahid
```

## 19.46.1.4 atcai2c

struct { ... } atcai2c

## 19.46.1.5 atcaspi

 $\texttt{struct \{ \dots \} atcaspi}$ 

## 19.46.1.6 atcaswi

struct { ... } atcaswi

#### 19.46.1.7 atcauart

struct { ... } atcauart

## 19.46.1.8 baud

uint32\_t baud

#### 19.46.1.9 bus

uint8\_t bus

## 19.46.1.10 cfg\_data

void\* cfg\_data

## 19.46.1.11 dev\_identity

uint8\_t dev\_identity

## 19.46.1.12 dev\_interface

ATCAKitType dev\_interface

## 19.46.1.13 devtype

ATCADeviceType devtype

#### 19.46.1.14 halidle

ATCA\_STATUS(\* halidle) (void \*iface)

#### 19.46.1.15 halinit

ATCA\_STATUS(\* halinit) (void \*hal, void \*cfg)

## 19.46.1.16 halpostinit

ATCA\_STATUS(\* halpostinit) (void \*iface)

## 19.46.1.17 halreceive

ATCA\_STATUS(\* halreceive) (void \*iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

## 19.46.1.18 halrelease

ATCA\_STATUS(\* halrelease) (void \*hal\_data)

#### 19.46.1.19 halsend

ATCA\_STATUS(\* halsend) (void \*iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

## 19.46.1.20 halsleep

ATCA\_STATUS(\* halsleep) (void \*iface)

#### 19.46.1.21 halwake

ATCA\_STATUS(\* halwake) (void \*iface)

## 19.46.1.22 idx

int idx

## 19.46.1.23 iface\_type

ATCAIfaceType iface\_type

## 19.46.1.24 packetsize

uint32\_t packetsize

## 19.46.1.25 parity

uint8\_t parity

## 19.46.1.26 pid

uint32\_t pid

## 19.46.1.27 port

int port

## 19.46.1.28 rx\_retries

int rx\_retries

## 19.46.1.29 select\_pin

uint8\_t select\_pin

## 19.46.1.30 slave\_address

uint8\_t slave\_address

## 19.46.1.31 stopbits

uint8\_t stopbits

## 19.46.1.32 vid

uint32\_t vid

## 19.46.1.33 wake\_delay

uint16\_t wake\_delay

## 19.46.1.34 wordsize

uint8\_t wordsize

## 19.47 ATCAPacket Struct Reference

#include <calib\_command.h>

## **Data Fields**

- uint8\_t \_reserved
- uint8 t txsize
- uint8\_t opcode
- uint8\_t param1
- uint16\_t param2
- uint8\_t data [192]
- uint8\_t execTime

## 19.47.1 Field Documentation

## 19.47.1.1 \_reserved

uint8\_t \_reserved

#### 19.47.1.2 data

uint8\_t data[192]

## 19.47.1.3 execTime

uint8\_t execTime

## 19.47.1.4 opcode

uint8\_t opcode

## 19.47.1.5 param1

uint8\_t param1

## 19.47.1.6 param2

uint16\_t param2

#### 19.47.1.7 txsize

uint8\_t txsize

## 19.48 atcaSPImaster Struct Reference

#include <hal\_linux\_spi\_userspace.h>

## **Data Fields**

- char spi\_file [16]
- int ref\_ct

#### 19.48.1 Field Documentation

#### 19.48.1.1 ref\_ct

int ref\_ct

## 19.48.1.2 spi\_file

char spi\_file[16]

# 19.49 atcaSWImaster Struct Reference

this is the hal\_data for ATCA HAL for ASF SERCOM

#include <swi\_uart\_samd21\_asf.h>

## **Data Fields**

- struct usart\_module usart\_instance
- int ref\_ct
- int bus\_index
- struct usart\_sync\_descriptor USART\_SWI
- uint32\_t sercom\_core\_freq

## 19.49.1 Detailed Description

this is the hal\_data for ATCA HAL for ASF SERCOM

## 19.49.2 Field Documentation

#### 19.49.2.1 bus\_index

int bus\_index

## 19.49.2.2 ref\_ct

int ref\_ct

## 19.49.2.3 sercom\_core\_freq

uint32\_t sercom\_core\_freq

## 19.49.2.4 usart\_instance

struct usart\_module usart\_instance

## 19.49.2.5 USART\_SWI

 $\verb|struct usart_sync_descriptor USART_SWI|\\$ 

# 19.50 CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE iv [16]
- CK\_BYTE\_PTR pData
- CK\_ULONG length

#### 19.50.1 Field Documentation

#### 19.50.1.1 iv

CK\_BYTE iv[16]

## 19.50.1.2 length

CK\_ULONG length

#### 19.50.1.3 pData

CK\_BYTE\_PTR pData

# 19.51 CK\_AES\_CCM\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_ULONG ulDataLen
- CK\_BYTE\_PTR pNonce
- CK ULONG ulNonceLen
- CK\_BYTE\_PTR pAAD
- CK\_ULONG ulAADLen
- CK\_ULONG ulMACLen

## 19.51.1 Field Documentation

## 19.51.1.1 pAAD

CK\_BYTE\_PTR pAAD

## 19.51.1.2 pNonce

CK\_BYTE\_PTR pNonce

#### 19.51.1.3 ulAADLen

CK\_ULONG ulAADLen

## 19.51.1.4 ulDataLen

CK\_ULONG ulDataLen

#### 19.51.1.5 ulMACLen

CK\_ULONG ulMACLen

## 19.51.1.6 ulNonceLen

CK\_ULONG ulNonceLen

# 19.52 CK\_AES\_CTR\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_ULONG ulCounterBits
- CK\_BYTE cb [16]

#### 19.52.1 Field Documentation

## 19.52.1.1 cb

CK\_BYTE cb[16]

#### 19.52.1.2 ulCounterBits

CK\_ULONG ulCounterBits

# 19.53 CK\_AES\_GCM\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE\_PTR plv
- CK\_ULONG ullvLen
- CK\_ULONG ullvBits
- CK\_BYTE\_PTR pAAD
- CK\_ULONG ulAADLen
- CK\_ULONG ulTagBits

## 19.53.1 Field Documentation

## 19.53.1.1 pAAD

CK\_BYTE\_PTR pAAD

#### 19.53.1.2 plv

CK\_BYTE\_PTR pIv

#### 19.53.1.3 ulAADLen

CK\_ULONG ulAADLen

#### 19.53.1.4 ullvBits

CK\_ULONG ullvBits

## 19.53.1.5 ullvLen

CK\_ULONG ullvLen

## 19.53.1.6 ulTagBits

CK\_ULONG ulTagBits

# 19.54 CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_BYTE iv [16]
- CK\_BYTE\_PTR pData
- CK\_ULONG length

## 19.54.1 Field Documentation

## 19.54.1.1 iv

CK\_BYTE iv[16]

## 19.54.1.2 length

CK\_ULONG length

#### 19.54.1.3 pData

CK\_BYTE\_PTR pData

# 19.55 CK\_ATTRIBUTE Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_ATTRIBUTE\_TYPE type
- CK\_VOID\_PTR pValue
- CK\_ULONG ulValueLen

## 19.55.1 Field Documentation

#### 19.55.1.1 pValue

CK\_VOID\_PTR pValue

## 19.55.1.2 type

CK\_ATTRIBUTE\_TYPE type

#### 19.55.1.3 ulValueLen

CK\_ULONG ulValueLen

# 19.56 CK\_C\_INITIALIZE\_ARGS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_CREATEMUTEX CreateMutex
- CK\_DESTROYMUTEX DestroyMutex
- CK LOCKMUTEX LockMutex
- CK\_UNLOCKMUTEX UnlockMutex
- CK\_FLAGS flags
- CK\_VOID\_PTR pReserved

#### 19.56.1 Field Documentation

#### 19.56.1.1 CreateMutex

CK\_CREATEMUTEX CreateMutex

## 19.56.1.2 DestroyMutex

CK\_DESTROYMUTEX DestroyMutex

## 19.56.1.3 flags

CK\_FLAGS flags

#### 19.56.1.4 LockMutex

CK\_LOCKMUTEX LockMutex

#### 19.56.1.5 pReserved

CK\_VOID\_PTR pReserved

#### 19.56.1.6 UnlockMutex

CK\_UNLOCKMUTEX UnlockMutex

# 19.57 CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE iv [16]
- CK\_BYTE\_PTR pData
- CK\_ULONG length

## 19.57.1 Field Documentation

## 19.57.1.1 iv

CK\_BYTE iv[16]

## 19.57.1.2 length

CK\_ULONG length

#### 19.57.1.3 pData

CK\_BYTE\_PTR pData

# 19.58 CK\_CAMELLIA\_CTR\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulCounterBits
- CK\_BYTE cb [16]

## 19.58.1 Field Documentation

#### 19.58.1.1 cb

CK\_BYTE cb[16]

## 19.58.1.2 ulCounterBits

CK\_ULONG ulCounterBits

# 19.59 CK\_CCM\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_ULONG ulDataLen
- CK\_BYTE\_PTR pNonce
- CK\_ULONG ulNonceLen
- CK\_BYTE\_PTR pAAD
- CK\_ULONG ulAADLen
- CK\_ULONG ulMACLen

## 19.59.1 Field Documentation

#### 19.59.1.1 pAAD

CK\_BYTE\_PTR pAAD

#### 19.59.1.2 pNonce

CK\_BYTE\_PTR pNonce

#### 19.59.1.3 ulAADLen

CK\_ULONG ulAADLen

#### 19.59.1.4 ulDataLen

CK\_ULONG ulDataLen

#### 19.59.1.5 ulMACLen

CK\_ULONG ulMACLen

#### 19.59.1.6 ulNonceLen

CK\_ULONG ulNonceLen

# 19.60 CK\_CMS\_SIG\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_OBJECT\_HANDLE certificateHandle
- CK\_MECHANISM\_PTR pSigningMechanism
- CK\_MECHANISM\_PTR pDigestMechanism
- CK UTF8CHAR PTR pContentType
- CK\_BYTE\_PTR pRequestedAttributes
- CK\_ULONG ulRequestedAttributesLen
- CK\_BYTE\_PTR pRequiredAttributes
- CK\_ULONG ulRequiredAttributesLen

#### 19.60.1 Field Documentation

### 19.60.1.1 certificateHandle

CK\_OBJECT\_HANDLE certificateHandle

### 19.60.1.2 pContentType

CK\_UTF8CHAR\_PTR pContentType

#### 19.60.1.3 pDigestMechanism

CK\_MECHANISM\_PTR pDigestMechanism

### 19.60.1.4 pRequestedAttributes

 ${\tt CK\_BYTE\_PTR} \ \, {\tt pRequestedAttributes}$ 

#### 19.60.1.5 pRequiredAttributes

CK\_BYTE\_PTR pRequiredAttributes

### 19.60.1.6 pSigningMechanism

CK\_MECHANISM\_PTR pSigningMechanism

## 19.60.1.7 ulRequestedAttributesLen

CK\_ULONG ulRequestedAttributesLen

#### 19.60.1.8 ulRequiredAttributesLen

CK\_ULONG ulRequiredAttributesLen

# 19.61 CK\_DATE Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_CHAR year [4]
- CK\_CHAR month [2]
- CK\_CHAR day [2]

### 19.61.1 Field Documentation

#### 19.61.1.1 day

CK\_CHAR day[2]

#### 19.61.1.2 month

CK\_CHAR month[2]

#### 19.61.1.3 year

CK\_CHAR year[4]

# 19.62 CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE iv [8]
- CK\_BYTE\_PTR pData
- CK\_ULONG length

### 19.62.1 Field Documentation

19.62.1.1 iv

CK\_BYTE iv[8]

#### 19.62.1.2 length

CK\_ULONG length

### 19.62.1.3 pData

CK\_BYTE\_PTR pData

# 19.63 CK\_DSA\_PARAMETER\_GEN\_PARAM Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_MECHANISM\_TYPE hash
- CK\_BYTE\_PTR pSeed
- CK ULONG ulSeedLen
- CK\_ULONG ulIndex

#### 19.63.1 Field Documentation

#### 19.63.1.1 hash

CK\_MECHANISM\_TYPE hash

### 19.63.1.2 pSeed

CK\_BYTE\_PTR pSeed

#### 19.63.1.3 ullndex

CK\_ULONG ulIndex

#### 19.63.1.4 ulSeedLen

CK\_ULONG ulSeedLen

# 19.64 CK\_ECDH1\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_EC\_KDF\_TYPE kdf
- CK\_ULONG ulSharedDataLen
- CK\_BYTE\_PTR pSharedData
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData

## 19.64.1 Field Documentation

#### 19.64.1.1 kdf

CK\_EC\_KDF\_TYPE kdf

### 19.64.1.2 pPublicData

CK\_BYTE\_PTR pPublicData

#### 19.64.1.3 pSharedData

CK\_BYTE\_PTR pSharedData

#### 19.64.1.4 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.64.1.5 ulSharedDataLen

CK\_ULONG ulSharedDataLen

# 19.65 CK\_ECDH2\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_EC\_KDF\_TYPE kdf
- CK\_ULONG ulSharedDataLen
- CK\_BYTE\_PTR pSharedData
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicDataCK\_ULONG ulPrivateDataLen
- CK\_OBJECT\_HANDLE hPrivateData
- CK\_ULONG ulPublicDataLen2
- CK\_BYTE\_PTR pPublicData2

#### 19.65.1 Field Documentation

## 19.65.1.1 hPrivateData

CK\_OBJECT\_HANDLE hPrivateData

### 19.65.1.2 kdf

CK\_EC\_KDF\_TYPE kdf

### 19.65.1.3 pPublicData

CK\_BYTE\_PTR pPublicData

### 19.65.1.4 pPublicData2

CK\_BYTE\_PTR pPublicData2

## 19.65.1.5 pSharedData

CK\_BYTE\_PTR pSharedData

#### 19.65.1.6 ulPrivateDataLen

CK\_ULONG ulPrivateDataLen

## 19.65.1.7 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.65.1.8 ulPublicDataLen2

CK\_ULONG ulPublicDataLen2

### 19.65.1.9 ulSharedDataLen

 ${\tt CK\_ULONG} \ {\tt ulSharedDataLen}$ 

# 19.66 CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulAESKeyBits
- CK\_EC\_KDF\_TYPE kdf
- CK\_ULONG ulSharedDataLen
- CK\_BYTE\_PTR pSharedData

### 19.66.1 Field Documentation

#### 19.66.1.1 kdf

CK\_EC\_KDF\_TYPE kdf

#### 19.66.1.2 pSharedData

CK\_BYTE\_PTR pSharedData

#### 19.66.1.3 uIAESKeyBits

CK\_ULONG ulAESKeyBits

#### 19.66.1.4 ulSharedDataLen

CK\_ULONG ulSharedDataLen

# 19.67 CK\_ECMQV\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_EC\_KDF\_TYPE kdf
- CK\_ULONG ulSharedDataLen
- CK\_BYTE\_PTR pSharedData
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData
- CK\_ULONG ulPrivateDataLen
- CK\_OBJECT\_HANDLE hPrivateData
- CK\_ULONG ulPublicDataLen2
- CK\_BYTE\_PTR pPublicData2
- CK\_OBJECT\_HANDLE publicKey

#### 19.67.1 Field Documentation

#### 19.67.1.1 hPrivateData

CK\_OBJECT\_HANDLE hPrivateData

#### 19.67.1.2 kdf

CK\_EC\_KDF\_TYPE kdf

#### 19.67.1.3 pPublicData

CK\_BYTE\_PTR pPublicData

#### 19.67.1.4 pPublicData2

CK\_BYTE\_PTR pPublicData2

#### 19.67.1.5 pSharedData

CK\_BYTE\_PTR pSharedData

### 19.67.1.6 publicKey

CK\_OBJECT\_HANDLE publicKey

#### 19.67.1.7 ulPrivateDataLen

CK\_ULONG ulPrivateDataLen

#### 19.67.1.8 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.67.1.9 ulPublicDataLen2

CK\_ULONG ulPublicDataLen2

## 19.67.1.10 ulSharedDataLen

CK\_ULONG ulSharedDataLen

# 19.68 CK\_FUNCTION\_LIST Struct Reference

#include <pkcs11.h>

## **Data Fields**

• CK\_VERSION version

## 19.68.1 Field Documentation

#### 19.68.1.1 version

 ${\tt CK\_VERSION} \ {\tt version}$ 

# 19.69 CK\_GCM\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_BYTE\_PTR plv
- CK\_ULONG ullvLen
- CK\_ULONG ullvBits
- CK\_BYTE\_PTR pAAD
- CK\_ULONG ulAADLen
- CK\_ULONG ulTagBits

#### 19.69.1 Field Documentation

#### 19.69.1.1 pAAD

CK\_BYTE\_PTR pAAD

## 19.69.1.2 plv

CK\_BYTE\_PTR pIv

#### 19.69.1.3 ulAADLen

CK\_ULONG ulAADLen

#### 19.69.1.4 ullvBits

CK\_ULONG ullvBits

#### 19.69.1.5 ullvLen

CK\_ULONG ullvLen

### 19.69.1.6 ulTagBits

CK\_ULONG ulTagBits

# 19.70 CK\_GOSTR3410\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_EC\_KDF\_TYPE kdf
- CK\_BYTE\_PTR pPublicData
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pUKM
- CK\_ULONG ulUKMLen

#### 19.70.1 Field Documentation

## 19.70.1.1 kdf

CK\_EC\_KDF\_TYPE kdf

## 19.70.1.2 pPublicData

CK\_BYTE\_PTR pPublicData

### 19.70.1.3 pUKM

CK\_BYTE\_PTR pUKM

## 19.70.1.4 ulPublicDataLen

CK\_ULONG ulPublicDataLen

### 19.70.1.5 ulUKMLen

CK\_ULONG ulUKMLen

# 19.71 CK\_GOSTR3410\_KEY\_WRAP\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK BYTE PTR pWrapOID
- CK\_ULONG ulWrapOIDLen
- CK\_BYTE\_PTR pUKM
- CK\_ULONG ulUKMLen
- CK\_OBJECT\_HANDLE hKey

#### 19.71.1 Field Documentation

### 19.71.1.1 hKey

CK\_OBJECT\_HANDLE hKey

#### 19.71.1.2 pUKM

CK\_BYTE\_PTR pUKM

### 19.71.1.3 pWrapOID

CK\_BYTE\_PTR pWrapOID

## 19.71.1.4 uIUKMLen

CK\_ULONG ulUKMLen

## 19.71.1.5 ulWrapOIDLen

CK\_ULONG ulWrapOIDLen

# 19.72 CK\_INFO Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK VERSION cryptokiVersion
- CK\_UTF8CHAR manufacturerID [32]
- CK\_FLAGS flags
- CK\_UTF8CHAR libraryDescription [32]
- CK\_VERSION libraryVersion

#### 19.72.1 Field Documentation

### 19.72.1.1 cryptokiVersion

CK\_VERSION cryptokiVersion

#### 19.72.1.2 flags

CK\_FLAGS flags

### 19.72.1.3 libraryDescription

CK\_UTF8CHAR libraryDescription[32]

#### 19.72.1.4 libraryVersion

CK\_VERSION libraryVersion

### 19.72.1.5 manufacturerID

CK\_UTF8CHAR manufacturerID[32]

# 19.73 CK\_KEA\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BBOOL isSender
- CK\_ULONG ulRandomLen
- CK\_BYTE\_PTR pRandomA
- CK\_BYTE\_PTR pRandomB
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData

#### 19.73.1 Field Documentation

#### 19.73.1.1 isSender

CK\_BBOOL isSender

## 19.73.1.2 pPublicData

CK\_BYTE\_PTR pPublicData

### 19.73.1.3 pRandomA

CK\_BYTE\_PTR pRandomA

#### 19.73.1.4 pRandomB

CK\_BYTE\_PTR pRandomB

### 19.73.1.5 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.73.1.6 ulRandomLen

CK\_ULONG ulRandomLen

# 19.74 CK\_KEY\_DERIVATION\_STRING\_DATA Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE\_PTR pData
- CK\_ULONG ulLen

#### 19.74.1 Field Documentation

#### 19.74.1.1 pData

CK\_BYTE\_PTR pData

### 19.74.1.2 ulLen

CK\_ULONG ullen

# 19.75 CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_BYTE bBC
- CK\_BYTE\_PTR pX
- CK\_ULONG ulXLen

### 19.75.1 Field Documentation

### 19.75.1.1 bBC

CK\_BYTE bBC

#### 19.75.1.2 pX

CK\_BYTE\_PTR pX

#### 19.75.1.3 uIXLen

CK\_ULONG ulXLen

# 19.76 CK\_KIP\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_MECHANISM\_PTR pMechanism
- CK\_OBJECT\_HANDLE hKey
- CK\_BYTE\_PTR pSeed
- CK\_ULONG ulSeedLen

#### 19.76.1 Field Documentation

## 19.76.1.1 hKey

CK\_OBJECT\_HANDLE hKey

#### 19.76.1.2 pMechanism

CK\_MECHANISM\_PTR pMechanism

## 19.76.1.3 pSeed

CK\_BYTE\_PTR pSeed

#### 19.76.1.4 ulSeedLen

CK\_ULONG ulSeedLen

# 19.77 CK\_MECHANISM Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_MECHANISM\_TYPE mechanism
- CK\_VOID\_PTR pParameter
- CK\_ULONG ulParameterLen

#### 19.77.1 Field Documentation

#### 19.77.1.1 mechanism

CK\_MECHANISM\_TYPE mechanism

#### 19.77.1.2 pParameter

CK\_VOID\_PTR pParameter

#### 19.77.1.3 ulParameterLen

CK\_ULONG ulParameterLen

# 19.78 CK\_MECHANISM\_INFO Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulMinKeySize
- CK\_ULONG ulMaxKeySize
- CK\_FLAGS flags

### 19.78.1 Field Documentation

#### 19.78.1.1 flags

CK\_FLAGS flags

#### 19.78.1.2 ulMaxKeySize

CK\_ULONG ulMaxKeySize

#### 19.78.1.3 ulMinKeySize

CK\_ULONG ulMinKeySize

# 19.79 CK\_OTP\_PARAM Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_OTP\_PARAM\_TYPE type
- CK\_VOID\_PTR pValue
- CK\_ULONG ulValueLen

### 19.79.1 Field Documentation

#### 19.79.1.1 pValue

CK\_VOID\_PTR pValue

#### 19.79.1.2 type

CK\_OTP\_PARAM\_TYPE type

#### 19.79.1.3 ulValueLen

CK\_ULONG ulValueLen

# 19.80 CK\_OTP\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_OTP\_PARAM\_PTR pParams
- CK\_ULONG ulCount

#### 19.80.1 Field Documentation

### 19.80.1.1 pParams

CK\_OTP\_PARAM\_PTR pParams

## 19.80.1.2 ulCount

CK\_ULONG ulCount

# 19.81 CK\_OTP\_SIGNATURE\_INFO Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_OTP\_PARAM\_PTR pParams
- CK\_ULONG ulCount

### 19.81.1 Field Documentation

#### 19.81.1.1 pParams

CK\_OTP\_PARAM\_PTR pParams

#### 19.81.1.2 ulCount

CK\_ULONG ulCount

# 19.82 CK\_PBE\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_BYTE\_PTR pInitVector
- CK\_UTF8CHAR\_PTR pPassword
- CK\_ULONG ulPasswordLen
- CK\_BYTE\_PTR pSalt
- CK\_ULONG ulSaltLen
- CK\_ULONG ullteration

#### 19.82.1 Field Documentation

#### 19.82.1.1 plnitVector

CK\_BYTE\_PTR pInitVector

#### 19.82.1.2 pPassword

CK\_UTF8CHAR\_PTR pPassword

#### 19.82.1.3 pSalt

CK\_BYTE\_PTR pSalt

#### 19.82.1.4 ullteration

CK\_ULONG ulIteration

#### 19.82.1.5 ulPasswordLen

CK\_ULONG ulPasswordLen

#### 19.82.1.6 ulSaltLen

CK\_ULONG ulSaltLen

# 19.83 CK\_PKCS5\_PBKD2\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE saltSource
- CK\_VOID\_PTR pSaltSourceData
- CK\_ULONG ulSaltSourceDataLen
- CK\_ULONG iterations
- CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE prf
- CK\_VOID\_PTR pPrfData
- CK\_ULONG ulPrfDataLen
- CK\_UTF8CHAR\_PTR pPassword
- CK\_ULONG\_PTR ulPasswordLen

### 19.83.1 Field Documentation

## 19.83.1.1 iterations

CK\_ULONG iterations

### 19.83.1.2 pPassword

CK\_UTF8CHAR\_PTR pPassword

### 19.83.1.3 pPrfData

CK\_VOID\_PTR pPrfData

### 19.83.1.4 prf

CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE prf

#### 19.83.1.5 pSaltSourceData

CK\_VOID\_PTR pSaltSourceData

### 19.83.1.6 saltSource

CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE saltSource

#### 19.83.1.7 ulPasswordLen

CK\_ULONG\_PTR ulPasswordLen

#### 19.83.1.8 ulPrfDataLen

CK\_ULONG ulPrfDataLen

#### 19.83.1.9 ulSaltSourceDataLen

CK\_ULONG ulSaltSourceDataLen

# 19.84 CK\_PKCS5\_PBKD2\_PARAMS2 Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE saltSource
- CK\_VOID\_PTR pSaltSourceData
- CK ULONG ulSaltSourceDataLen
- CK ULONG iterations
- CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE prf
- CK\_VOID\_PTR pPrfData
- CK\_ULONG ulPrfDataLen
- CK\_UTF8CHAR\_PTR pPassword
- CK\_ULONG ulPasswordLen

### 19.84.1 Field Documentation

#### 19.84.1.1 iterations

CK\_ULONG iterations

#### 19.84.1.2 pPassword

CK\_UTF8CHAR\_PTR pPassword

#### 19.84.1.3 pPrfData

CK\_VOID\_PTR pPrfData

#### 19.84.1.4 prf

CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE prf

#### 19.84.1.5 pSaltSourceData

CK\_VOID\_PTR pSaltSourceData

#### 19.84.1.6 saltSource

CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE saltSource

#### 19.84.1.7 ulPasswordLen

CK\_ULONG ulPasswordLen

#### 19.84.1.8 ulPrfDataLen

CK\_ULONG ulPrfDataLen

#### 19.84.1.9 ulSaltSourceDataLen

CK\_ULONG ulSaltSourceDataLen

# 19.85 CK\_RC2\_CBC\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_ULONG ulEffectiveBits
- CK\_BYTE iv [8]

#### 19.85.1 Field Documentation

#### 19.85.1.1 iv

CK\_BYTE iv[8]

#### 19.85.1.2 ulEffectiveBits

CK\_ULONG ulEffectiveBits

# 19.86 CK\_RC2\_MAC\_GENERAL\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- · CK ULONG ulEffectiveBits
- CK\_ULONG ulMacLength

## 19.86.1 Field Documentation

### 19.86.1.1 ulEffectiveBits

CK\_ULONG ulEffectiveBits

## 19.86.1.2 ulMacLength

 ${\tt CK\_ULONG} \ {\tt ulMacLength}$ 

# 19.87 CK\_RC5\_CBC\_PARAMS Struct Reference

| #include <pkcs11t.h></pkcs11t.h> | 1t.h> | <pkcs13< th=""><th>include</th></pkcs13<> | include |
|----------------------------------|-------|-------------------------------------------|---------|
|----------------------------------|-------|-------------------------------------------|---------|

#### **Data Fields**

- CK\_ULONG ulWordsize
- CK\_ULONG ulRounds
- CK\_BYTE\_PTR plv
- CK\_ULONG ullvLen

### 19.87.1 Field Documentation

### 19.87.1.1 plv

CK\_BYTE\_PTR pIv

#### 19.87.1.2 ullvLen

CK\_ULONG ullvLen

#### 19.87.1.3 ulRounds

CK\_ULONG ulRounds

#### 19.87.1.4 ulWordsize

CK\_ULONG ulWordsize

# 19.88 CK\_RC5\_MAC\_GENERAL\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulWordsize
- CK\_ULONG ulRounds
- CK\_ULONG ulMacLength

#### 19.88.1 Field Documentation

## 19.88.1.1 ulMacLength

CK\_ULONG ulMacLength

#### 19.88.1.2 ulRounds

CK\_ULONG ulRounds

#### 19.88.1.3 ulWordsize

CK\_ULONG ulWordsize

# 19.89 CK\_RC5\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_ULONG ulWordsize
- CK\_ULONG ulRounds

### 19.89.1 Field Documentation

#### 19.89.1.1 ulRounds

CK\_ULONG ulRounds

#### 19.89.1.2 ulWordsize

CK\_ULONG ulWordsize

# 19.90 CK RSA AES KEY WRAP PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- · CK\_ULONG ulAESKeyBits
- CK\_RSA\_PKCS\_OAEP\_PARAMS\_PTR pOAEPParams

#### 19.90.1 Field Documentation

#### 19.90.1.1 pOAEPParams

CK\_RSA\_PKCS\_OAEP\_PARAMS\_PTR pOAEPParams

## 19.90.1.2 uIAESKeyBits

CK\_ULONG ulaesKeyBits

# 19.91 CK\_RSA\_PKCS\_OAEP\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- · CK MECHANISM TYPE hashAlg
- CK\_RSA\_PKCS\_MGF\_TYPE mgf
- CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE source
- CK\_VOID\_PTR pSourceData
- CK\_ULONG ulSourceDataLen

## 19.91.1 Field Documentation

#### 19.91.1.1 hashAlg

CK\_MECHANISM\_TYPE hashAlg

### 19.91.1.2 mgf

CK\_RSA\_PKCS\_MGF\_TYPE mgf

#### 19.91.1.3 pSourceData

CK\_VOID\_PTR pSourceData

### 19.91.1.4 source

CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE source

#### 19.91.1.5 ulSourceDataLen

CK ULONG ulSourceDataLen

# 19.92 CK\_RSA\_PKCS\_PSS\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_MECHANISM\_TYPE hashAlg
- CK\_RSA\_PKCS\_MGF\_TYPE mgf
- CK\_ULONG sLen

### 19.92.1 Field Documentation

### 19.92.1.1 hashAlg

CK\_MECHANISM\_TYPE hashAlg

### 19.92.1.2 mgf

CK\_RSA\_PKCS\_MGF\_TYPE mgf

#### 19.92.1.3 sLen

CK\_ULONG sLen

# 19.93 CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_BYTE iv [16]
- CK\_BYTE\_PTR pData
- CK\_ULONG length

## 19.93.1 Field Documentation

#### 19.93.1.1 iv

CK\_BYTE iv[16]

#### 19.93.1.2 length

CK\_ULONG length

#### 19.93.1.3 pData

CK\_BYTE\_PTR pData

# 19.94 CK\_SESSION\_INFO Struct Reference

#include <pkcs11t.h>

### **Data Fields**

- CK\_SLOT\_ID slotID
- CK\_STATE state
- CK\_FLAGS flags
- CK\_ULONG ulDeviceError

### 19.94.1 Field Documentation

#### 19.94.1.1 flags

CK\_FLAGS flags

#### 19.94.1.2 slotID

CK\_SLOT\_ID slotID

#### 19.94.1.3 state

CK\_STATE state

#### 19.94.1.4 ulDeviceError

CK\_ULONG ulDeviceError

# 19.95 CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulPasswordLen
- CK\_BYTE\_PTR pPassword
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData
- CK\_ULONG ulPAndGLen
- CK\_ULONG ulQLen
- CK\_ULONG ulRandomLen
- CK\_BYTE\_PTR pRandomA
- CK BYTE PTR pPrimeP
- CK\_BYTE\_PTR pBaseG
- CK\_BYTE\_PTR pSubprimeQ

#### 19.95.1 Field Documentation

### 19.95.1.1 pBaseG

CK\_BYTE\_PTR pBaseG

#### 19.95.1.2 pPassword

CK\_BYTE\_PTR pPassword

### 19.95.1.3 pPrimeP

CK\_BYTE\_PTR pPrimeP

#### 19.95.1.4 pPublicData

CK\_BYTE\_PTR pPublicData

#### 19.95.1.5 pRandomA

CK\_BYTE\_PTR pRandomA

### 19.95.1.6 pSubprimeQ

CK\_BYTE\_PTR pSubprimeQ

#### 19.95.1.7 ulPAndGLen

CK\_ULONG ulPAndGLen

#### 19.95.1.8 ulPasswordLen

CK\_ULONG ulPasswordLen

#### 19.95.1.9 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.95.1.10 ulQLen

CK\_ULONG ulQLen

#### 19.95.1.11 ulRandomLen

CK\_ULONG ulRandomLen

# 19.96 CK\_SKIPJACK\_RELAYX\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_ULONG ulOldWrappedXLen
- CK BYTE PTR pOldWrappedX
- CK\_ULONG ulOldPasswordLen
- CK\_BYTE\_PTR pOldPassword
- CK\_ULONG ulOldPublicDataLen
- CK\_BYTE\_PTR pOldPublicData
- CK\_ULONG ulOldRandomLen
- CK\_BYTE\_PTR pOldRandomA
- CK\_ULONG ulNewPasswordLen
- CK\_BYTE\_PTR pNewPassword
- CK\_ULONG ulNewPublicDataLen
- CK\_BYTE\_PTR pNewPublicData
- CK\_ULONG ulNewRandomLen
- CK\_BYTE\_PTR pNewRandomA

#### 19.96.1 Field Documentation

#### 19.96.1.1 pNewPassword

CK\_BYTE\_PTR pNewPassword

#### 19.96.1.2 pNewPublicData

CK\_BYTE\_PTR pNewPublicData

#### 19.96.1.3 pNewRandomA

CK\_BYTE\_PTR pNewRandomA

#### 19.96.1.4 pOldPassword

CK\_BYTE\_PTR pOldPassword

### 19.96.1.5 pOldPublicData

CK\_BYTE\_PTR pOldPublicData

### 19.96.1.6 pOldRandomA

CK\_BYTE\_PTR pOldRandomA

### 19.96.1.7 pOldWrappedX

CK\_BYTE\_PTR pOldWrappedX

#### 19.96.1.8 ulNewPasswordLen

CK\_ULONG ulNewPasswordLen

## 19.96.1.9 ulNewPublicDataLen

CK\_ULONG ulNewPublicDataLen

#### 19.96.1.10 ulNewRandomLen

CK\_ULONG ulNewRandomLen

### 19.96.1.11 ulOldPasswordLen

CK\_ULONG ulOldPasswordLen

#### 19.96.1.12 ulOldPublicDataLen

 ${\tt CK\_ULONG} \ {\tt ulOldPublicDataLen}$ 

### 19.96.1.13 ulOldRandomLen

CK\_ULONG ulOldRandomLen

#### 19.96.1.14 ulOldWrappedXLen

CK\_ULONG ulOldWrappedXLen

# 19.97 CK\_SLOT\_INFO Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_UTF8CHAR slotDescription [64]
- CK\_UTF8CHAR manufacturerID [32]
- CK\_FLAGS flags
- CK\_VERSION hardwareVersion
- CK\_VERSION firmwareVersion

#### 19.97.1 Field Documentation

## 19.97.1.1 firmwareVersion

CK\_VERSION firmwareVersion

### 19.97.1.2 flags

CK\_FLAGS flags

## 19.97.1.3 hardwareVersion

CK\_VERSION hardwareVersion

#### 19.97.1.4 manufacturerID

CK\_UTF8CHAR manufacturerID[32]

## 19.97.1.5 slotDescription

CK\_UTF8CHAR slotDescription[64]

## 19.98 CK\_SSL3\_KEY\_MAT\_OUT Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_OBJECT\_HANDLE hClientMacSecret
- CK\_OBJECT\_HANDLE hServerMacSecret
- CK\_OBJECT\_HANDLE hClientKey
- CK\_OBJECT\_HANDLE hServerKey
- CK BYTE PTR pIVClient
- CK\_BYTE\_PTR pIVServer

## 19.98.1 Field Documentation

## 19.98.1.1 hClientKey

CK\_OBJECT\_HANDLE hClientKey

#### 19.98.1.2 hClientMacSecret

CK\_OBJECT\_HANDLE hClientMacSecret

#### 19.98.1.3 hServerKey

CK\_OBJECT\_HANDLE hServerKey

#### 19.98.1.4 hServerMacSecret

CK\_OBJECT\_HANDLE hServerMacSecret

## 19.98.1.5 pIVClient

CK\_BYTE\_PTR pIVClient

#### 19.98.1.6 plVServer

CK\_BYTE\_PTR pIVServer

## 19.99 CK\_SSL3\_KEY\_MAT\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK ULONG ulMacSizeInBits
- CK\_ULONG ulKeySizeInBits
- CK ULONG ullVSizeInBits
- CK\_BBOOL blsExport
- CK\_SSL3\_RANDOM\_DATA RandomInfo
- CK\_SSL3\_KEY\_MAT\_OUT\_PTR pReturnedKeyMaterial

#### 19.99.1 Field Documentation

## 19.99.1.1 blsExport

CK\_BBOOL bIsExport

#### 19.99.1.2 pReturnedKeyMaterial

CK\_SSL3\_KEY\_MAT\_OUT\_PTR pReturnedKeyMaterial

## 19.99.1.3 RandomInfo

CK\_SSL3\_RANDOM\_DATA RandomInfo

#### 19.99.1.4 ullVSizeInBits

CK\_ULONG ulIVSizeInBits

## 19.99.1.5 ulKeySizeInBits

CK\_ULONG ulKeySizeInBits

#### 19.99.1.6 ulMacSizeInBits

CK\_ULONG ulMacSizeInBits

# 19.100 CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_SSL3\_RANDOM\_DATA RandomInfo
- CK\_VERSION\_PTR pVersion

### 19.100.1 Field Documentation

## 19.100.1.1 pVersion

CK\_VERSION\_PTR pVersion

## 19.100.1.2 RandomInfo

CK\_SSL3\_RANDOM\_DATA RandomInfo

## 19.101 CK\_SSL3\_RANDOM\_DATA Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_BYTE\_PTR pClientRandom
- CK\_ULONG ulClientRandomLen
- CK\_BYTE\_PTR pServerRandom
- CK\_ULONG ulServerRandomLen

## 19.101.1 Field Documentation

#### 19.101.1.1 pClientRandom

CK\_BYTE\_PTR pClientRandom

#### 19.101.1.2 pServerRandom

CK\_BYTE\_PTR pServerRandom

#### 19.101.1.3 ulClientRandomLen

 ${\tt CK\_ULONG} \ {\tt ulClientRandomLen}$ 

#### 19.101.1.4 ulServerRandomLen

 ${\tt CK\_ULONG} \ {\tt ulServerRandomLen}$ 

## 19.102 CK TLS12 KEY MAT PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK ULONG ulMacSizeInBits
- CK\_ULONG ulKeySizeInBits
- CK\_ULONG ullVSizeInBits
- CK\_BBOOL blsExport
- CK\_SSL3\_RANDOM\_DATA RandomInfo
- CK\_SSL3\_KEY\_MAT\_OUT\_PTR pReturnedKeyMaterial
- CK\_MECHANISM\_TYPE prfHashMechanism

### 19.102.1 Field Documentation

#### 19.102.1.1 blsExport

CK\_BBOOL blsExport

### 19.102.1.2 pReturnedKeyMaterial

CK\_SSL3\_KEY\_MAT\_OUT\_PTR pReturnedKeyMaterial

#### 19.102.1.3 prfHashMechanism

CK\_MECHANISM\_TYPE prfHashMechanism

#### 19.102.1.4 RandomInfo

 ${\tt CK\_SSL3\_RANDOM\_DATA} \ {\tt RandomInfo}$ 

### 19.102.1.5 ullVSizeInBits

CK\_ULONG ullVSizeInBits

## 19.102.1.6 ulKeySizeInBits

CK\_ULONG ulKeySizeInBits

## 19.102.1.7 ulMacSizeInBits

CK\_ULONG ulMacSizeInBits

## 19.103 CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_SSL3\_RANDOM\_DATA RandomInfo
- CK\_VERSION\_PTR pVersion
- CK\_MECHANISM\_TYPE prfHashMechanism

#### 19.103.1 Field Documentation

## 19.103.1.1 prfHashMechanism

CK\_MECHANISM\_TYPE prfHashMechanism

### 19.103.1.2 pVersion

CK\_VERSION\_PTR pVersion

#### 19.103.1.3 RandomInfo

CK\_SSL3\_RANDOM\_DATA RandomInfo

## 19.104 CK\_TLS\_KDF\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_MECHANISM\_TYPE prfMechanism
- CK\_BYTE\_PTR pLabel
- CK\_ULONG ulLabelLength
- CK SSL3 RANDOM DATA RandomInfo
- CK\_BYTE\_PTR pContextData
- CK\_ULONG ulContextDataLength

#### 19.104.1 Field Documentation

### 19.104.1.1 pContextData

CK\_BYTE\_PTR pContextData

#### 19.104.1.2 pLabel

CK\_BYTE\_PTR pLabel

### 19.104.1.3 prfMechanism

CK\_MECHANISM\_TYPE prfMechanism

## 19.104.1.4 RandomInfo

CK\_SSL3\_RANDOM\_DATA RandomInfo

#### 19.104.1.5 ulContextDataLength

 ${\tt CK\_ULONG} \ {\tt ulContextDataLength}$ 

## 19.104.1.6 ulLabelLength

CK\_ULONG ulLabelLength

## 19.105 CK\_TLS\_MAC\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_MECHANISM\_TYPE prfHashMechanism
- CK\_ULONG ulMacLength
- CK\_ULONG ulServerOrClient

#### 19.105.1 Field Documentation

#### 19.105.1.1 prfHashMechanism

CK\_MECHANISM\_TYPE prfHashMechanism

#### 19.105.1.2 ulMacLength

CK\_ULONG ulMacLength

## 19.105.1.3 ulServerOrClient

CK\_ULONG ulServerOrClient

## 19.106 CK\_TLS\_PRF\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_BYTE\_PTR pSeed
- CK\_ULONG ulSeedLen
- CK BYTE PTR pLabel
- CK\_ULONG ulLabelLen
- CK\_BYTE\_PTR pOutput
- CK\_ULONG\_PTR pulOutputLen

## 19.106.1 Field Documentation

## 19.106.1.1 pLabel

CK\_BYTE\_PTR pLabel

## 19.106.1.2 pOutput

CK\_BYTE\_PTR pOutput

## 19.106.1.3 pSeed

CK\_BYTE\_PTR pSeed

## 19.106.1.4 pulOutputLen

CK\_ULONG\_PTR pulOutputLen

### 19.106.1.5 ulLabelLen

CK\_ULONG ullabelLen

## 19.106.1.6 ulSeedLen

CK\_ULONG ulSeedLen

# 19.107 CK\_TOKEN\_INFO Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_UTF8CHAR label [32]
- CK\_UTF8CHAR manufacturerID [32]
- CK\_UTF8CHAR model [16]
- CK\_CHAR serialNumber [16]
- CK\_FLAGS flags
- CK ULONG ulMaxSessionCount
- CK\_ULONG ulSessionCount
- CK\_ULONG ulMaxRwSessionCount
- CK ULONG ulRwSessionCount
- CK\_ULONG ulMaxPinLen
- CK ULONG ulMinPinLen
- CK\_ULONG ulTotalPublicMemory
- CK\_ULONG ulFreePublicMemory
- CK ULONG ulTotalPrivateMemory
- CK\_ULONG ulFreePrivateMemory
- CK\_VERSION hardwareVersion
- CK\_VERSION firmwareVersion
- CK\_CHAR utcTime [16]

#### 19.107.1 Field Documentation

#### 19.107.1.1 firmwareVersion

 ${\tt CK\_VERSION} \ {\tt firmwareVersion}$ 

### 19.107.1.2 flags

CK\_FLAGS flags

#### 19.107.1.3 hardwareVersion

CK\_VERSION hardwareVersion

#### 19.107.1.4 label

CK\_UTF8CHAR label[32]

## 19.107.1.5 manufacturerID

CK\_UTF8CHAR manufacturerID[32]

#### 19.107.1.6 model

CK\_UTF8CHAR model[16]

## 19.107.1.7 serialNumber

CK\_CHAR serialNumber[16]

#### 19.107.1.8 ulFreePrivateMemory

CK\_ULONG ulFreePrivateMemory

## 19.107.1.9 ulFreePublicMemory

CK\_ULONG ulFreePublicMemory

### 19.107.1.10 ulMaxPinLen

CK\_ULONG ulMaxPinLen

## 19.107.1.11 ulMaxRwSessionCount

CK\_ULONG ulMaxRwSessionCount

### 19.107.1.12 ulMaxSessionCount

CK\_ULONG ulMaxSessionCount

## 19.107.1.13 ulMinPinLen

CK\_ULONG ulMinPinLen

#### 19.107.1.14 ulRwSessionCount

CK\_ULONG ulRwSessionCount

#### 19.107.1.15 ulSessionCount

CK\_ULONG ulSessionCount

## 19.107.1.16 ulTotalPrivateMemory

CK\_ULONG ulTotalPrivateMemory

## 19.107.1.17 ulTotalPublicMemory

CK\_ULONG ulTotalPublicMemory

#### 19.107.1.18 utcTime

CK\_CHAR utcTime[16]

## 19.108 CK\_VERSION Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_BYTE major
- CK\_BYTE minor

## 19.108.1 Field Documentation

## 19.108.1.1 major

CK\_BYTE major

## 19.108.1.2 minor

CK\_BYTE minor

# 19.109 CK\_WTLS\_KEY\_MAT\_OUT Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_OBJECT\_HANDLE hMacSecret
- CK\_OBJECT\_HANDLE hKey
- CK\_BYTE\_PTR pIV

## 19.109.1 Field Documentation

## 19.109.1.1 hKey

CK\_OBJECT\_HANDLE hKey

## 19.109.1.2 hMacSecret

CK\_OBJECT\_HANDLE hMacSecret

#### 19.109.1.3 plV

CK\_BYTE\_PTR pIV

## 19.110 CK WTLS KEY MAT PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_MECHANISM\_TYPE DigestMechanism
- CK\_ULONG ulMacSizeInBits
- CK\_ULONG ulKeySizeInBits
- CK\_ULONG ullVSizeInBits
- CK\_ULONG ulSequenceNumber
- CK\_BBOOL blsExport
- CK\_WTLS\_RANDOM\_DATA RandomInfo
- CK\_WTLS\_KEY\_MAT\_OUT\_PTR pReturnedKeyMaterial

#### 19.110.1 Field Documentation

## 19.110.1.1 blsExport

CK\_BBOOL bIsExport

### 19.110.1.2 DigestMechanism

CK\_MECHANISM\_TYPE DigestMechanism

#### 19.110.1.3 pReturnedKeyMaterial

 ${\tt CK\_WTLS\_KEY\_MAT\_OUT\_PTR} \ \, {\tt pReturnedKeyMaterial}$ 

#### 19.110.1.4 RandomInfo

CK\_WTLS\_RANDOM\_DATA RandomInfo

## 19.110.1.5 ullVSizeInBits

CK\_ULONG ullVSizeInBits

## 19.110.1.6 ulKeySizeInBits

CK\_ULONG ulKeySizeInBits

#### 19.110.1.7 ulMacSizeInBits

CK\_ULONG ulMacSizeInBits

#### 19.110.1.8 ulSequenceNumber

CK\_ULONG ulSequenceNumber

# 19.111 CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_MECHANISM\_TYPE DigestMechanism
- CK\_WTLS\_RANDOM\_DATA RandomInfo
- CK\_BYTE\_PTR pVersion

## 19.111.1 Field Documentation

### 19.111.1.1 DigestMechanism

CK\_MECHANISM\_TYPE DigestMechanism

## 19.111.1.2 pVersion

CK\_BYTE\_PTR pVersion

#### 19.111.1.3 RandomInfo

CK\_WTLS\_RANDOM\_DATA RandomInfo

## 19.112 CK\_WTLS\_PRF\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_MECHANISM\_TYPE DigestMechanism
- CK\_BYTE\_PTR pSeed
- CK\_ULONG ulSeedLen
- CK\_BYTE\_PTR pLabel
- CK\_ULONG ulLabelLen
- CK\_BYTE\_PTR pOutput
- CK\_ULONG\_PTR pulOutputLen

## 19.112.1 Field Documentation

#### 19.112.1.1 DigestMechanism

 ${\tt CK\_MECHANISM\_TYPE\ DigestMechanism}$ 

#### 19.112.1.2 pLabel

CK\_BYTE\_PTR pLabel

## 19.112.1.3 pOutput

CK\_BYTE\_PTR pOutput

#### 19.112.1.4 pSeed

CK\_BYTE\_PTR pSeed

## 19.112.1.5 pulOutputLen

CK\_ULONG\_PTR pulOutputLen

#### 19.112.1.6 ulLabelLen

CK\_ULONG ullabelLen

## 19.112.1.7 ulSeedLen

CK\_ULONG ulSeedLen

# 19.113 CK\_WTLS\_RANDOM\_DATA Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK\_BYTE\_PTR pClientRandom
- CK\_ULONG ulClientRandomLen
- CK\_BYTE\_PTR pServerRandom
- CK\_ULONG ulServerRandomLen

### 19.113.1 Field Documentation

## 19.113.1.1 pClientRandom

CK\_BYTE\_PTR pClientRandom

## 19.113.1.2 pServerRandom

CK\_BYTE\_PTR pServerRandom

#### 19.113.1.3 ulClientRandomLen

CK\_ULONG ulClientRandomLen

#### 19.113.1.4 ulServerRandomLen

CK\_ULONG ulServerRandomLen

# 19.114 CK\_X9\_42\_DH1\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_X9\_42\_DH\_KDF\_TYPE kdf
- CK\_ULONG ulOtherInfoLen
- CK\_BYTE\_PTR pOtherInfo
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData

## 19.114.1 Field Documentation

#### 19.114.1.1 kdf

CK\_X9\_42\_DH\_KDF\_TYPE kdf

## 19.114.1.2 pOtherInfo

CK\_BYTE\_PTR pOtherInfo

#### 19.114.1.3 pPublicData

CK\_BYTE\_PTR pPublicData

#### 19.114.1.4 ulOtherInfoLen

CK\_ULONG ulOtherInfoLen

#### 19.114.1.5 ulPublicDataLen

CK\_ULONG ulPublicDataLen

## 19.115 CK\_X9\_42\_DH2\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

#### **Data Fields**

- CK\_X9\_42\_DH\_KDF\_TYPE kdf
- CK\_ULONG ulOtherInfoLen
- CK\_BYTE\_PTR pOtherInfo
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData
- CK\_ULONG ulPrivateDataLen
- CK\_OBJECT\_HANDLE hPrivateData
- CK\_ULONG ulPublicDataLen2
- CK\_BYTE\_PTR pPublicData2

#### 19.115.1 Field Documentation

### 19.115.1.1 hPrivateData

CK\_OBJECT\_HANDLE hPrivateData

## 19.115.1.2 kdf

CK\_X9\_42\_DH\_KDF\_TYPE kdf

## 19.115.1.3 pOtherInfo

CK\_BYTE\_PTR pOtherInfo

#### 19.115.1.4 pPublicData

CK\_BYTE\_PTR pPublicData

## 19.115.1.5 pPublicData2

CK\_BYTE\_PTR pPublicData2

#### 19.115.1.6 ulOtherInfoLen

CK\_ULONG ulOtherInfoLen

## 19.115.1.7 ulPrivateDataLen

CK\_ULONG ulPrivateDataLen

## 19.115.1.8 ulPublicDataLen

CK\_ULONG ulPublicDataLen

#### 19.115.1.9 ulPublicDataLen2

 ${\tt CK\_ULONG} \ {\tt ulPublicDataLen2}$ 

## 19.116 CK\_X9\_42\_MQV\_DERIVE\_PARAMS Struct Reference

#include <pkcs11t.h>

## **Data Fields**

- CK X9 42 DH KDF TYPE kdf
- CK\_ULONG ulOtherInfoLen
- CK\_BYTE\_PTR pOtherInfo
- CK\_ULONG ulPublicDataLen
- CK\_BYTE\_PTR pPublicData
- CK ULONG ulPrivateDataLen
- CK\_OBJECT\_HANDLE hPrivateData
- CK\_ULONG ulPublicDataLen2
- CK\_BYTE\_PTR pPublicData2
- CK\_OBJECT\_HANDLE publicKey

## 19.116.1 Field Documentation

#### 19.116.1.1 hPrivateData

CK\_OBJECT\_HANDLE hPrivateData

#### 19.116.1.2 kdf

CK\_X9\_42\_DH\_KDF\_TYPE kdf

#### 19.116.1.3 pOtherInfo

CK\_BYTE\_PTR pOtherInfo

#### 19.116.1.4 pPublicData

CK\_BYTE\_PTR pPublicData

## 19.116.1.5 pPublicData2

CK\_BYTE\_PTR pPublicData2

## 19.116.1.6 publicKey

CK\_OBJECT\_HANDLE publicKey

#### 19.116.1.7 ulOtherInfoLen

CK\_ULONG ulOtherInfoLen

#### 19.116.1.8 ulPrivateDataLen

CK\_ULONG ulPrivateDataLen

## 19.116.1.9 ulPublicDataLen

CK\_ULONG ulPublicDataLen

## 19.116.1.10 ulPublicDataLen2

CK\_ULONG ulPublicDataLen2

## 19.117 CL\_HashContext Struct Reference

#include <shal\_routines.h>

## **Data Fields**

- uint32\_t h [20/4]
- uint32\_t buf [64/4]
- uint32\_t byteCount
- uint32\_t byteCountHi

## 19.117.1 Field Documentation

#### 19.117.1.1 buf

uint32\_t buf[64/4]

## 19.117.1.2 byteCount

uint32\_t byteCount

### 19.117.1.3 byteCountHi

uint32\_t byteCountHi

## 19.117.1.4 h

uint32\_t h[20/4]

## 19.118 hw\_sha256\_ctx Struct Reference

## **Data Fields**

• uint32\_t total\_msg\_size

Total number of message bytes processed.

• uint32\_t block\_size

Number of bytes in current block.

uint8\_t block [ATCA\_SHA256\_BLOCK\_SIZE \*2]

Unprocessed message storage.

## 19.118.1 Field Documentation

#### 19.118.1.1 block

uint8\_t block[ATCA\_SHA256\_BLOCK\_SIZE \*2]

Unprocessed message storage.

#### 19.118.1.2 block\_size

```
uint32_t block_size
```

Number of bytes in current block.

## 19.118.1.3 total\_msg\_size

```
uint32_t total_msg_size
```

Total number of message bytes processed.

## 19.119 i2c\_sam0\_instance Struct Reference

```
#include <hal_sam0_i2c_asf.h>
```

### **Data Fields**

- struct i2c\_master\_module \* i2c\_instance
- sam0\_change\_baudrate change\_baudrate

## 19.119.1 Field Documentation

#### 19.119.1.1 change\_baudrate

sam0\_change\_baudrate change\_baudrate

#### 19.119.1.2 i2c\_instance

struct i2c\_master\_module\* i2c\_instance

## 19.120 i2c\_sam\_instance Struct Reference

#include <hal\_sam\_i2c\_asf.h>

#### **Data Fields**

- Twi \* i2c\_instance
- sam\_change\_baudrate change\_baudrate

## 19.120.1 Field Documentation

## 19.120.1.1 change\_baudrate

sam\_change\_baudrate change\_baudrate

## 19.120.1.2 i2c\_instance

Twi\* i2c\_instance

## 19.121 i2c\_start\_instance Struct Reference

#include <hal\_i2c\_start.h>

#### **Data Fields**

- struct i2c\_m\_sync\_desc \* i2c\_descriptor
- start\_change\_baudrate change\_baudrate

## 19.121.1 Field Documentation

## 19.121.1.1 change\_baudrate

start\_change\_baudrate change\_baudrate

## 19.121.1.2 i2c\_descriptor

struct i2c\_m\_sync\_desc\* i2c\_descriptor

# 19.122 memory\_parameters Struct Reference

#include <secure\_boot\_memory.h>

## **Data Fields**

- uint32 t start address
- uint32\_t memory\_size
- uint32\_t version\_info
- uint8\_t reserved [52]
- uint8\_t signature [ATCA\_SIG\_SIZE]

#### 19.122.1 Field Documentation

## 19.122.1.1 memory\_size

uint32\_t memory\_size

## 19.122.1.2 reserved

uint8\_t reserved[52]

## 19.122.1.3 signature

uint8\_t signature[ATCA\_SIG\_SIZE]

### 19.122.1.4 start\_address

uint32\_t start\_address

#### 19.122.1.5 version\_info

uint32\_t version\_info

# 19.123 secure\_boot\_config\_bits Struct Reference

#include <secure\_boot.h>

#### **Data Fields**

- uint16\_t secure\_boot\_mode: 2
- uint16\_t secure\_boot\_reserved1: 1
- uint16\_t secure\_boot\_persistent\_enable: 1
- uint16\_t secure\_boot\_rand\_nonce: 1
- uint16\_t secure\_boot\_reserved2: 3
- uint16\_t secure\_boot\_sig\_dig: 4
- uint16\_t secure\_boot\_pub\_key: 4

#### 19.123.1 Field Documentation

#### 19.123.1.1 secure\_boot\_mode

uint16\_t secure\_boot\_mode

#### 19.123.1.2 secure\_boot\_persistent\_enable

uint16\_t secure\_boot\_persistent\_enable

#### 19.123.1.3 secure\_boot\_pub\_key

uint16\_t secure\_boot\_pub\_key

### 19.123.1.4 secure\_boot\_rand\_nonce

uint16\_t secure\_boot\_rand\_nonce

## 19.123.1.5 secure\_boot\_reserved1

uint16\_t secure\_boot\_reserved1

## 19.123.1.6 secure\_boot\_reserved2

uint16\_t secure\_boot\_reserved2

## 19.123.1.7 secure\_boot\_sig\_dig

uint16\_t secure\_boot\_sig\_dig

# 19.124 secure\_boot\_parameters Struct Reference

#include <secure\_boot.h>

#### **Data Fields**

- memory\_parameters memory\_params
- atcac\_sha2\_256\_ctx s\_sha\_context
- uint8\_t app\_digest [ATCA\_SHA\_DIGEST\_SIZE]

#### 19.124.1 Field Documentation

#### 19.124.1.1 app\_digest

uint8\_t app\_digest[ATCA\_SHA\_DIGEST\_SIZE]

### 19.124.1.2 memory\_params

memory\_parameters memory\_params

#### 19.124.1.3 s\_sha\_context

atcac\_sha2\_256\_ctx s\_sha\_context

## 19.125 sw\_sha256\_ctx Struct Reference

#include <sha2\_routines.h>

#### **Data Fields**

• uint32\_t total\_msg\_size

Total number of message bytes processed.

• uint32\_t block\_size

Number of bytes in current block.

• uint8\_t block [(64) \*2]

Unprocessed message storage.

• uint32\_t hash [8]

Hash state.

## 19.125.1 Field Documentation

### 19.125.1.1 block

uint8\_t block[(64) \*2]

Unprocessed message storage.

### 19.125.1.2 block\_size

uint32\_t block\_size

Number of bytes in current block.

#### 19.125.1.3 hash

uint32\_t hash[8]

Hash state.

## 19.125.1.4 total\_msg\_size

```
uint32_t total_msg_size
```

Total number of message bytes processed.

## 19.126 tng\_cert\_map\_element Struct Reference

## **Data Fields**

- const char \* otpcode
- const atcacert\_def\_t \* cert\_def

## 19.126.1 Field Documentation

## 19.126.1.1 cert\_def

```
const atcacert_def_t* cert_def
```

## 19.126.1.2 otpcode

const char\* otpcode

# **Chapter 20**

# **File Documentation**

## 20.1 api\_206a.c File Reference

Provides APIs to use with ATSHA206A device.

```
#include <stdlib.h>
#include <stdio.h>
#include "cryptoauthlib.h"
#include "api_206a.h"
```

### **Functions**

- ATCA\_STATUS sha206a\_diversify\_parent\_key (uint8\_t \*parent\_key, uint8\_t \*diversified\_key)
  - Computes the diversified key based on the parent key provided and device serial number.
- ATCA\_STATUS sha206a\_generate\_derive\_key (uint8\_t \*parent\_key, uint8\_t \*derived\_key, uint8\_t param1, uint16\_t param2)
  - Generates the derived key based on the parent key and other parameters provided.
- ATCA\_STATUS sha206a\_generate\_challenge\_response\_pair (uint8\_t \*key, uint8\_t \*challenge, uint8\_←
  t \*response)
  - Generates the response based on Key and Challenge provided.
- ATCA\_STATUS sha206a\_authenticate (uint8\_t \*challenge, uint8\_t \*expected\_response, uint8\_t \*is\_

   authenticated)
  - verifies the challenge and provided response using key in device
- ATCA\_STATUS sha206a\_verify\_device\_consumption (uint8\_t \*is\_consumed)
  - verifies the device is fully consumed or not based on Parent and Derived Key use flags.
- ATCA\_STATUS sha206a\_check\_dk\_useflag\_validity (uint8\_t \*is\_consumed)
  - verifies Derived Key use flags for consumption
- ATCA\_STATUS sha206a\_check\_pk\_useflag\_validity (uint8\_t \*is\_consumed)
  - verifies Parent Key use flags for consumption
- ATCA\_STATUS sha206a\_get\_dk\_useflag\_count (uint8\_t \*dk\_available\_count)
  - calculates available Derived Key use counts
- ATCA\_STATUS sha206a\_get\_pk\_useflag\_count (uint8\_t \*pk\_available\_count)
  - calculates available Parent Key use counts
- ATCA\_STATUS sha206a\_get\_dk\_update\_count (uint8\_t \*dk\_update\_count)
  - Read Derived Key slot update count. It will be wraps around 256.

ATCA\_STATUS sha206a\_write\_data\_store (uint8\_t slot, uint8\_t \*data, uint8\_t block, uint8\_t offset, uint8\_t len, bool lock\_after\_write)

Update the data store slot with user data and lock it if necessary.

- ATCA\_STATUS sha206a\_read\_data\_store (uint8\_t slot, uint8\_t \*data, uint8\_t offset, uint8\_t len)

  Read the data stored in Data store.
- ATCA\_STATUS sha206a\_get\_data\_store\_lock\_status (uint8\_t slot, uint8\_t \*is\_locked)

Returns the lock status of the given data store.

## 20.1.1 Detailed Description

Provides APIs to use with ATSHA206A device.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.1.2 Function Documentation

#### 20.1.2.1 sha206a\_authenticate()

verifies the challenge and provided response using key in device

#### **Parameters**

| in <i>challenge</i> |                   | Challenge to be used in the response calculations      |  |
|---------------------|-------------------|--------------------------------------------------------|--|
| in                  | expected_response | Expected response from the device.                     |  |
| out                 | is_authenticated  | result of expected of response and calcualted response |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.1.2.2 sha206a\_check\_dk\_useflag\_validity()

verifies Derived Key use flags for consumption

#### **Parameters**

| out   is_consumed   indicates if DK is available for consumption. |
|-------------------------------------------------------------------|
|-------------------------------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.1.2.3 sha206a\_check\_pk\_useflag\_validity()

verifies Parent Key use flags for consumption

#### **Parameters**

| out | is_consumed | indicates if PK is available for consumption |
|-----|-------------|----------------------------------------------|
|-----|-------------|----------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code

## 20.1.2.4 sha206a\_diversify\_parent\_key()

Computes the diversified key based on the parent key provided and device serial number.

### **Parameters**

| in  | parent_key      | parent key to be diversified |
|-----|-----------------|------------------------------|
| out | diversified_key | diversified parent key       |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.1.2.5 sha206a\_generate\_challenge\_response\_pair()

Generates the response based on Key and Challenge provided.

#### **Parameters**

| in  | key       | Input data contains device's key                        |
|-----|-----------|---------------------------------------------------------|
| in  | challenge | Input data to be used in challenge response calculation |
| out | response  | response derived from key and challenge                 |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.1.2.6 sha206a\_generate\_derive\_key()

Generates the derived key based on the parent key and other parameters provided.

#### **Parameters**

| in  | parent_key  | Input data contains device's parent key         |  |
|-----|-------------|-------------------------------------------------|--|
| out | derived_key | Cey Output data derived from parent key         |  |
| in  | param1      | Input data to be used in derive key calculation |  |
| in  | param2      | Input data to be used in derive key calculation |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.1.2.7 sha206a\_get\_data\_store\_lock\_status()

Returns the lock status of the given data store.

#### **Parameters**

| in  | slot      | Slot number of the data store |
|-----|-----------|-------------------------------|
| out | is_locked | lock status of the data store |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.1.2.8 sha206a\_get\_dk\_update\_count()

Read Derived Key slot update count. It will be wraps around 256.

#### **Parameters**

| out | dk_update_count | returns number of times the slot has been updated with derived key |
|-----|-----------------|--------------------------------------------------------------------|
|-----|-----------------|--------------------------------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.1.2.9 sha206a\_get\_dk\_useflag\_count()

```
ATCA_STATUS sha206a_get_dk_useflag_count ( uint8_t * dk_available_count )
```

calculates available Derived Key use counts

### **Parameters**

| out | dk_available_count | counts available bit's as 1 |
|-----|--------------------|-----------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.1.2.10 sha206a\_get\_pk\_useflag\_count()

```
ATCA_STATUS sha206a_get_pk_useflag_count ( uint8_t * pk_available_count )
```

calculates available Parent Key use counts

#### **Parameters**

| out | pk_available_count | counts available bit's as 1 |
|-----|--------------------|-----------------------------|
|-----|--------------------|-----------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.1.2.11 sha206a\_read\_data\_store()

```
ATCA_STATUS sha206a_read_data_store (
    uint8_t slot,
    uint8_t * data,
    uint8_t offset,
    uint8_t len )
```

Read the data stored in Data store.

#### **Parameters**

| in                                              | slot Slot number to read from |                                           |
|-------------------------------------------------|-------------------------------|-------------------------------------------|
| in data Pointer to hold sl                      |                               | Pointer to hold slot data data            |
| in offset Byte offset within the zone to read f |                               | Byte offset within the zone to read from. |
| in len data length                              |                               | data length                               |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.1.2.12 sha206a\_verify\_device\_consumption()

verifies the device is fully consumed or not based on Parent and Derived Key use flags.

#### **Parameters**

| out | is_consumed | result of device consumption |
|-----|-------------|------------------------------|

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 542

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.1.2.13 sha206a\_write\_data\_store()

```
ATCA_STATUS sha206a_write_data_store (
    uint8_t slot,
    uint8_t * data,
    uint8_t block,
    uint8_t offset,
    uint8_t len,
    bool lock_after_write )
```

Update the data store slot with user data and lock it if necessary.

#### **Parameters**

| in | slot             | Slot number to be written with data                                                     |  |
|----|------------------|-----------------------------------------------------------------------------------------|--|
| in | data             | Pointer that holds the data                                                             |  |
| in | block            | 32-byte block to write to.                                                              |  |
| in | offset           | 4-byte word within the specified block to write to. If performing a 32-byte write, this |  |
|    |                  | should be 0.                                                                            |  |
| in | len              | data length                                                                             |  |
| in | lock_after_write | set 1 to lock slot after write, otherwise 0                                             |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2 api\_206a.h File Reference

Provides api interfaces to use with ATSHA206A device.

```
#include "atca_status.h"
#include "atca_command.h"
```

#### **Macros**

- #define ATCA\_SHA206A\_ZONE\_WRITE\_LOCK 0x20
- #define ATCA\_SHA206A\_DKEY\_CONSUMPTION\_MASK 0x01
- #define ATCA\_SHA206A\_PKEY\_CONSUMPTION\_MASK 0x02
- #define ATCA\_SHA206A\_SYMMETRIC\_KEY\_ID\_SLOT 0X07

### **Enumerations**

enum { SHA206A\_DATA\_STORE0 =8, SHA206A\_DATA\_STORE1, SHA206A\_DATA\_STORE2 }

#### **Functions**

ATCA\_STATUS sha206a\_diversify\_parent\_key (uint8\_t \*parent\_key, uint8\_t \*diversified\_key)

Computes the diversified key based on the parent key provided and device serial number.

ATCA\_STATUS sha206a\_generate\_derive\_key (uint8\_t \*parent\_key, uint8\_t \*derived\_key, uint8\_t param1, uint16 t param2)

Generates the derived key based on the parent key and other parameters provided.

ATCA\_STATUS sha206a\_generate\_challenge\_response\_pair (uint8\_t \*key, uint8\_t \*challenge, uint8\_
 t \*response)

Generates the response based on Key and Challenge provided.

ATCA\_STATUS sha206a\_authenticate (uint8\_t \*challenge, uint8\_t \*expected\_response, uint8\_t \*is\_

 authenticated)

verifies the challenge and provided response using key in device

ATCA\_STATUS sha206a\_verify\_device\_consumption (uint8\_t \*is\_consumed)

verifies the device is fully consumed or not based on Parent and Derived Key use flags.

ATCA\_STATUS sha206a\_check\_dk\_useflag\_validity (uint8\_t \*is\_valid)

verifies Derived Key use flags for consumption

ATCA\_STATUS sha206a\_check\_pk\_useflag\_validity (uint8\_t \*is\_valid)

verifies Parent Key use flags for consumption

ATCA STATUS sha206a get dk useflag count (uint8 t \*dk available count)

calculates available Derived Key use counts

ATCA\_STATUS sha206a\_get\_pk\_useflag\_count (uint8\_t \*pk\_available\_count)

calculates available Parent Key use counts

• ATCA\_STATUS sha206a\_get\_dk\_update\_count (uint8\_t \*dk\_update\_count)

Read Derived Key slot update count. It will be wraps around 256.

ATCA\_STATUS sha206a\_write\_data\_store (uint8\_t slot, uint8\_t \*data, uint8\_t block, uint8\_t offset, uint8\_t len, bool lock after write)

Update the data store slot with user data and lock it if necessary.

ATCA\_STATUS sha206a\_read\_data\_store (uint8\_t slot, uint8\_t \*data, uint8\_t offset, uint8\_t len)

Read the data stored in Data store.

ATCA\_STATUS sha206a\_get\_data\_store\_lock\_status (uint8\_t slot, uint8\_t \*is\_locked)

Returns the lock status of the given data store.

# 20.2.1 Detailed Description

Provides api interfaces to use with ATSHA206A device.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.2.2 Macro Definition Documentation

# 20.2.2.1 ATCA\_SHA206A\_DKEY\_CONSUMPTION\_MASK

#define ATCA\_SHA206A\_DKEY\_CONSUMPTION\_MASK 0x01

# 20.2.2.2 ATCA\_SHA206A\_PKEY\_CONSUMPTION\_MASK

#define ATCA\_SHA206A\_PKEY\_CONSUMPTION\_MASK 0x02

# 20.2.2.3 ATCA\_SHA206A\_SYMMETRIC\_KEY\_ID\_SLOT

#define ATCA\_SHA206A\_SYMMETRIC\_KEY\_ID\_SLOT 0X07

# 20.2.2.4 ATCA\_SHA206A\_ZONE\_WRITE\_LOCK

#define ATCA\_SHA206A\_ZONE\_WRITE\_LOCK 0x20

# 20.2.3 Enumeration Type Documentation

### 20.2.3.1 anonymous enum

anonymous enum

#### Enumerator

| SHA206A_DATA_STORE0 |  |
|---------------------|--|
| SHA206A_DATA_STORE1 |  |
| SHA206A DATA STORE2 |  |

### 20.2.4 Function Documentation

# 20.2.4.1 sha206a\_authenticate()

verifies the challenge and provided response using key in device

#### **Parameters**

| i | in <i>challenge</i>  |                   | Challenge to be used in the response calculations      |
|---|----------------------|-------------------|--------------------------------------------------------|
| i | in                   | expected_response | Expected response from the device.                     |
|   | out is_authenticated |                   | result of expected of response and calcualted response |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.2 sha206a\_check\_dk\_useflag\_validity()

verifies Derived Key use flags for consumption

#### **Parameters**

| out | is_consumed | indicates if DK is available for consumption. |
|-----|-------------|-----------------------------------------------|
|-----|-------------|-----------------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.3 sha206a\_check\_pk\_useflag\_validity()

verifies Parent Key use flags for consumption

### **Parameters**

| - |     |             |                                              |
|---|-----|-------------|----------------------------------------------|
| ſ | out | is_consumed | indicates if PK is available for consumption |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 546

### 20.2.4.4 sha206a\_diversify\_parent\_key()

Computes the diversified key based on the parent key provided and device serial number.

### **Parameters**

| in  | parent_key      | parent key to be diversified |
|-----|-----------------|------------------------------|
| out | diversified_key | diversified parent key       |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.2.4.5 sha206a\_generate\_challenge\_response\_pair()

Generates the response based on Key and Challenge provided.

### **Parameters**

| in                  | key | Input data contains device's key                        |  |
|---------------------|-----|---------------------------------------------------------|--|
| in <i>challenge</i> |     | Input data to be used in challenge response calculation |  |
| out <i>response</i> |     | response derived from key and challenge                 |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.6 sha206a\_generate\_derive\_key()

Generates the derived key based on the parent key and other parameters provided.

#### **Parameters**

| in  | parent_key  | Input data contains device's parent key         |
|-----|-------------|-------------------------------------------------|
| out | derived_key | Output data derived from parent key             |
| in  | param1      | Input data to be used in derive key calculation |
| in  | param2      | Input data to be used in derive key calculation |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.7 sha206a\_get\_data\_store\_lock\_status()

```
ATCA_STATUS sha206a_get_data_store_lock_status ( uint8_t slot, uint8_t * is_locked )
```

Returns the lock status of the given data store.

### **Parameters**

| ĺ | in  | slot      | Slot number of the data store |
|---|-----|-----------|-------------------------------|
|   | out | is_locked | lock status of the data store |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.8 sha206a\_get\_dk\_update\_count()

Read Derived Key slot update count. It will be wraps around 256.

# **Parameters**

| out | dk_update_count | returns number of times the slot has been updated with derived key |
|-----|-----------------|--------------------------------------------------------------------|
|-----|-----------------|--------------------------------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.2.4.9 sha206a\_get\_dk\_useflag\_count()

calculates available Derived Key use counts

#### **Parameters**

| out | dk_available_count | counts available bit's as 1 |
|-----|--------------------|-----------------------------|
|-----|--------------------|-----------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.10 sha206a\_get\_pk\_useflag\_count()

calculates available Parent Key use counts

### **Parameters**

| out pk_available_coun | counts available bit's as 1 |
|-----------------------|-----------------------------|
|-----------------------|-----------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.2.4.11 sha206a\_read\_data\_store()

Read the data stored in Data store.

#### **Parameters**

| in | slot   | Slot number to read from                  |
|----|--------|-------------------------------------------|
| in | data   | Pointer to hold slot data data            |
| in | offset | Byte offset within the zone to read from. |
| in | len    | data length                               |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.12 sha206a\_verify\_device\_consumption()

verifies the device is fully consumed or not based on Parent and Derived Key use flags.

#### **Parameters**

| out   is_consumed   result of device consumption |
|--------------------------------------------------|
|--------------------------------------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.2.4.13 sha206a\_write\_data\_store()

```
ATCA_STATUS sha206a_write_data_store (
    uint8_t slot,
    uint8_t * data,
    uint8_t block,
    uint8_t offset,
    uint8_t len,
    bool lock_after_write )
```

Update the data store slot with user data and lock it if necessary.

### **Parameters**

| in | slot             | Slot number to be written with data                                                     |
|----|------------------|-----------------------------------------------------------------------------------------|
| in | data             | Pointer that holds the data                                                             |
| in | block            | 32-byte block to write to.                                                              |
| in | offset           | 4-byte word within the specified block to write to. If performing a 32-byte write, this |
|    |                  | should be 0.                                                                            |
| in | len              | data length                                                                             |
| in | lock_after_write | set 1 to lock slot after write, otherwise 0                                             |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.3 atca basic.c File Reference

CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core crypto methods.

```
#include "atca_basic.h"
#include "atca_version.h"
```

#### **Functions**

ATCA\_STATUS atcab\_version (char \*ver\_str)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA\_STATUS atcab\_init\_ext (ATCADevice \*device, ATCAlfaceCfg \*cfg)

Creates and initializes a ATCADevice context.

ATCA\_STATUS atcab\_init (ATCAlfaceCfg \*cfg)

Creates a global ATCADevice object used by Basic API.

ATCA STATUS atcab init device (ATCADevice ca device)

Initialize the global ATCADevice object to point to one of your choosing for use with all the atcab basic API.

ATCA\_STATUS atcab\_release\_ext (ATCADevice \*device)

release (free) the an ATCADevice instance.

ATCA STATUS atcab release (void)

release (free) the global ATCADevice instance. This must be called in order to release or free up the interface.

ATCADevice atcab\_get\_device (void)

Get the global device object.

ATCADeviceType atcab\_get\_device\_type\_ext (ATCADevice device)

Get the selected device type of rthe device context.

ATCADeviceType atcab\_get\_device\_type (void)

Get the current device type configured for the global ATCADevice.

bool atcab\_is\_ca\_device (ATCADeviceType dev\_type)

Check whether the device is cryptoauth device.

bool atcab\_is\_ta\_device (ATCADeviceType dev\_type)

Check whether the device is Trust Anchor device.

ATCA\_STATUS atcab\_wakeup (void)

wakeup the CryptoAuth device

ATCA\_STATUS atcab\_idle (void)

idle the CryptoAuth device

ATCA\_STATUS atcab\_sleep (void)

invoke sleep on the CryptoAuth device

• ATCA\_STATUS atcab\_get\_zone\_size (uint8\_t zone, uint16\_t slot, size\_t \*size)

Gets the size of the specified zone in bytes.

• ATCA\_STATUS atcab\_aes (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8\_t \*aes\_out)

Compute the AES-128 encrypt, decrypt, or GFM calculation.

 ATCA\_STATUS atcab\_aes\_encrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

ATCA\_STATUS atcab\_aes\_encrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_←
t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

 ATCA\_STATUS atcab\_aes\_decrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*ciphertext, uint8 t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

ATCA\_STATUS atcab\_aes\_decrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

ATCA\_STATUS atcab\_aes\_gfm (const uint8\_t \*h, const uint8\_t \*input, uint8\_t \*output)

Perform a Galois Field Multiply (GFM) operation.

 ATCA\_STATUS atcab\_aes\_gcm\_init (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*iv, size t iv size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_init\_rand (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, size\_t rand\_size, const uint8\_t \*free\_field, size\_t free\_field\_size, uint8\_t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_aad\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32\_t aad
size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint32 t plaintext size, uint8 t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

- ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size\_t tag\_size)
   Complete a GCM encrypt operation returning the authentication tag.
- ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32 t ciphertext size, uint8 t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag
 size, bool \*is verified)

Complete a GCM decrypt operation verifying the authentication tag.

ATCA\_STATUS atcab\_checkmac (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, const uint8\_←
t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

• ATCA STATUS atcab counter (uint8 t mode, uint16 t counter id, uint32 t \*counter value)

Compute the Counter functions.

• ATCA\_STATUS atcab\_counter\_increment (uint16\_t counter\_id, uint32\_t \*counter\_value)

Increments one of the device's monotonic counters.

ATCA STATUS atcab counter read (uint16 t counter id, uint32 t \*counter value)

Read one of the device's monotonic counters.

• ATCA\_STATUS atcab\_derivekey (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*mac)

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

ATCA\_STATUS atcab\_ecdh\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, uint8\_t \*out\_nonce)

Base function for generating premaster secret key using ECDH.

ATCA\_STATUS atcab\_ecdh (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

ATCA\_STATUS atcab\_ecdh\_enc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*read\_key, uint16\_t read\_key\_id, const uint8\_t num\_in[(20)])

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

ATCA\_STATUS atcab\_ecdh\_ioenc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS atcab\_ecdh\_tempkey (const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

- ATCA\_STATUS atcab\_ecdh\_tempkey\_ioenc (const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)
   ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.
- ATCA\_STATUS atcab\_gendig (uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_t other\_data
   size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

ATCA\_STATUS atcab\_genkey\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_←
t \*public\_key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

ATCA\_STATUS atcab\_genkey (uint16\_t key\_id, uint8\_t \*public\_key)

Issues GenKey command, which generates a new random private key in slot/handle and returns the public key.

ATCA\_STATUS atcab\_get\_pubkey (uint16\_t key\_id, uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

• ATCA STATUS atcab hmac (uint8 t mode, uint16 t key id, uint8 t \*digest)

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS atcab\_info\_base (uint8\_t mode, uint16\_t param2, uint8\_t \*out\_data)

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

• ATCA\_STATUS atcab\_info (uint8\_t \*revision)

Use the Info command to get the device revision (DevRev).

• ATCA STATUS atcab info set latch (bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

ATCA\_STATUS atcab\_info\_get\_latch (bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

 ATCA\_STATUS atcab\_kdf (uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8\_t \*out\_data, uint8\_t \*out\_nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

ATCA\_STATUS atcab\_lock (uint8\_t mode, uint16\_t summary\_crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

ATCA\_STATUS atcab\_lock\_config\_zone (void)

Unconditionally (no CRC required) lock the config zone.

ATCA\_STATUS atcab\_lock\_config\_zone\_crc (uint16\_t summary\_crc)

Lock the config zone with summary CRC.

ATCA\_STATUS atcab\_lock\_data\_zone (void)

Unconditionally (no CRC required) lock the data zone (slots and OTP). for CryptoAuth devices and lock the setup for Trust Anchor device.

ATCA\_STATUS atcab\_lock\_data\_zone\_crc (uint16\_t summary\_crc)

Lock the data zone (slots and OTP) with summary CRC.

ATCA\_STATUS atcab\_lock\_data\_slot (uint16\_t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1) (for cryptoauth devices) or Lock an individual handle in shared data element on an Trust Anchor device (for Trust Anchor devices).

• ATCA STATUS atcab mac (uint8 t mode, uint16 t key id, const uint8 t \*challenge, uint8 t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS atcab\_nonce\_base (uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands

ATCA\_STATUS atcab\_nonce (const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS atcab\_nonce\_load (uint8\_t target, const uint8\_t \*num\_in, uint16\_t num\_in\_size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

ATCA\_STATUS atcab\_nonce\_rand (const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

• ATCA\_STATUS atcab\_challenge (const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS atcab\_challenge\_seed\_update (const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number.

• ATCA\_STATUS atcab\_priv\_write (uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write\_key\_id, const uint8\_t write\_key[32], const uint8\_t num\_in[(20)])

Executes PrivWrite command, to write externally generated ECC private keys into the device.

ATCA\_STATUS atcab\_random\_ext (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the device.

• ATCA STATUS atcab random (uint8 t \*rand out)

Executes Random command, which generates a 32 byte random number from the device.

ATCA\_STATUS atcab\_read\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint8\_t \*data, uint8\_t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

ATCA\_STATUS atcab\_is\_locked (uint8\_t zone, bool \*is\_locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

• ATCA\_STATUS atcab\_is\_config\_locked (bool \*is\_locked)

This function check whether configuration zone is locked or not.

ATCA\_STATUS atcab\_is\_data\_locked (bool \*is\_locked)

This function check whether data/setup zone is locked or not.

ATCA\_STATUS atcab\_is\_slot\_locked (uint16\_t slot, bool \*is\_locked)

This function check whether slot/handle is locked or not.

ATCA\_STATUS atcab\_read\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset, uint8\_t \*data, size\_
 t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

• ATCA STATUS atcab read serial number (uint8 t \*serial number)

This function returns serial number of the device.

ATCA\_STATUS atcab\_read\_pubkey (uint16\_t slot, uint8\_t \*public\_key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

• ATCA\_STATUS atcab\_read\_sig (uint16\_t slot, uint8\_t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

ATCA\_STATUS atcab\_read\_config\_zone (uint8\_t \*config\_data)

Executes Read command to read the complete device configuration zone.

ATCA\_STATUS atcab\_cmp\_config\_zone (uint8\_t \*config\_data, bool \*same\_config)

Compares a specified configuration zone with the configuration zone currently on the device.

• ATCA\_STATUS atcab\_read\_enc (uint16\_t key\_id, uint8\_t block, uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

ATCA\_STATUS atcab\_secureboot (uint8\_t mode, uint16\_t param2, const uint8\_t \*digest, const uint8\_←
t \*signature, uint8\_t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

ATCA\_STATUS atcab\_secureboot\_mac (uint8\_t mode, const uint8\_t \*digest, const uint8\_t \*signature, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

ATCA STATUS atcab selftest (uint8 t mode, uint16 t param2, uint8 t \*result)

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT← ECC608 chip.

ATCA\_STATUS atcab\_sha\_base (uint8\_t mode, uint16\_t length, const uint8\_t \*data\_in, uint8\_t \*data\_out, uint16\_t \*data\_out\_size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

ATCA STATUS atcab sha start (void)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA STATUS atcab sha update (const uint8 t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

• ATCA\_STATUS atcab\_sha\_end (uint8\_t \*digest, uint16\_t length, const uint8\_t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

• ATCA STATUS atcab sha read context (uint8 t \*context, uint16 t \*context size)

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

ATCA\_STATUS atcab\_sha\_write\_context (const uint8\_t \*context, uint16\_t context\_size)

Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.

ATCA STATUS atcab sha (uint16 t length, const uint8 t \*message, uint8 t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA STATUS atcab hw sha2 256 (const uint8 t \*data, size t data size, uint8 t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA STATUS atcab hw sha2 256 init (atca sha256 ctx t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

ATCA\_STATUS atcab\_hw\_sha2\_256\_update (atca\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data\_
 size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

ATCA\_STATUS atcab\_hw\_sha2\_256\_finish (atca\_sha256\_ctx\_t \*ctx, uint8\_t \*digest)

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

ATCA\_STATUS atcab\_sha\_hmac\_init (atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac\_update (atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data
 — size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

• ATCA\_STATUS atcab\_sha\_hmac\_finish (atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_t \*digest, uint8\_t target)

Executes SHA command to complete a HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac (const uint8\_t \*data, size\_t data\_size, uint16\_t key\_slot, uint8\_t \*digest, uint8\_t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

• ATCA STATUS atcab sign base (uint8 t mode, uint16 t key id, uint8 t \*signature)

Executes the Sign command, which generates a signature using the ECDSA algorithm.

• ATCA STATUS atcab sign (uint16 t key id, const uint8 t \*msg, uint8 t \*signature)

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA STATUS atcab sign internal (uint16 t key id, bool is invalidate, bool is full sn, uint8 t \*signature)

Executes Sign command to sign an internally generated message.

ATCA\_STATUS atcab\_updateextra (uint8\_t mode, uint16\_t new\_value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

ATCA\_STATUS atcab\_verify (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public
 \_key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS atcab\_verify\_extern (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_←
t \*public key, bool \*is verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

• ATCA\_STATUS atcab\_verify\_extern\_mac (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public\_key, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

 ATCA\_STATUS atcab\_verify\_stored (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp

Key for other devices.

ATCA\_STATUS atcab\_verify\_stored\_mac (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key
 id, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

ATCA\_STATUS atcab\_verify\_validate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

 ATCA\_STATUS atcab\_verify\_invalidate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

ATCA\_STATUS atcab\_write (uint8\_t zone, uint16\_t address, const uint8\_t \*value, const uint8\_t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

ATCA\_STATUS atcab\_write\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, const uint8\_←
t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

• ATCA\_STATUS atcab\_write\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

ATCA\_STATUS atcab\_write\_pubkey (uint16\_t slot, const uint8\_t \*public\_key)

Uses the write command to write a public key to a slot in the proper format.

ATCA\_STATUS atcab\_write\_config\_zone (const uint8\_t \*config\_data)

Executes the Write command, which writes the configuration zone.

 ATCA\_STATUS atcab\_write\_enc (uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

ATCA\_STATUS atcab\_write\_config\_counter (uint16\_t counter\_id, uint32\_t counter\_value)

Initialize one of the monotonic counters in device with a specific value.

#### **Variables**

- const char atca\_version [] = "20200912"
- SHARED\_LIB\_EXPORT ATCADevice \_gDevice = NULL

# 20.3.1 Detailed Description

CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core crypto methods.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.3.2 Variable Documentation

### 20.3.2.1 gDevice

```
SHARED_LIB_EXPORT ATCADevice _gDevice = NULL
```

### 20.3.2.2 atca\_version

```
const char atca_version[] = "20200912"
```

# 20.4 atca\_basic.h File Reference

CryptoAuthLib Basic API methods - a simple crypto authentication API. These methods manage a global ATCA← Device object behind the scenes. They also manage the wake/idle state transitions so callers don't need to.

```
#include "cryptoauthlib.h"
#include "crypto/atca_crypto_sw_sha2.h"
#include "crypto/atca_crypto_hw_aes.h"
```

### **Macros**

- #define atcab\_cfg\_discover(...) calib\_cfg\_discover(\_\_VA\_ARGS\_\_)
- #define atcab\_get\_addr(...) calib\_get\_addr(\_\_VA\_ARGS\_\_)
- #define atca\_execute\_command(...) calib\_execute\_command(\_\_VA\_ARGS\_\_)
- #define SHA\_CONTEXT\_MAX\_SIZE (109)

#### **Functions**

ATCA\_STATUS atcab\_version (char \*ver\_str)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA\_STATUS atcab\_init\_ext (ATCADevice \*device, ATCAlfaceCfg \*cfg)

Creates and initializes a ATCADevice context.

ATCA\_STATUS atcab\_init (ATCAlfaceCfg \*cfg)

Creates a global ATCADevice object used by Basic API.

ATCA\_STATUS atcab\_init\_device (ATCADevice ca\_device)

Initialize the global ATCADevice object to point to one of your choosing for use with all the atcab\_ basic API.

• ATCA STATUS atcab release ext (ATCADevice \*device)

release (free) the an ATCADevice instance.

ATCA\_STATUS atcab\_release (void)

release (free) the global ATCADevice instance. This must be called in order to release or free up the interface.

ATCADevice atcab get device (void)

Get the global device object.

ATCADeviceType atcab\_get\_device\_type\_ext (ATCADevice device)

Get the selected device type of rthe device context.

ATCADeviceType atcab get device type (void)

Get the current device type configured for the global ATCADevice.

bool atcab\_is\_ca\_device (ATCADeviceType dev\_type)

Check whether the device is cryptoauth device.

bool atcab\_is\_ta\_device (ATCADeviceType dev\_type)

Check whether the device is Trust Anchor device.

ATCA\_STATUS atcab\_aes\_cbc\_init\_ext (ATCADevice device, atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv)

Initialize context for AES CBC operation.

ATCA\_STATUS atcab\_aes\_cbc\_init (atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv)

Initialize context for AES CBC operation.

- ATCA\_STATUS atcab\_aes\_cbc\_encrypt\_block\_ext (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_t \*ciphertext)
- ATCA\_STATUS atcab\_aes\_cbc\_encrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Encrypt a block of data using CBC mode and a key within the device. atcab\_aes\_cbc\_init() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_cbc\_decrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Decrypt a block of data using CBC mode and a key within the device. atcab\_aes\_cbc\_init() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_cmac\_init\_ext (ATCADevice device, atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8 t key\_block)

Initialize a CMAC calculation using an AES-128 key in the device.

- ATCA\_STATUS atcab\_aes\_cmac\_init (atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block)
  - Initialize a CMAC calculation using an AES-128 key in the device.
- ATCA\_STATUS atcab\_aes\_cmac\_update (atca\_aes\_cmac\_ctx\_t \*ctx, const uint8\_t \*data, uint32\_t data\_
   size)

Add data to an initialized CMAC calculation.

• ATCA\_STATUS atcab\_aes\_cmac\_finish (atca\_aes\_cmac\_ctx\_t \*ctx, uint8\_t \*cmac, uint32\_t cmac\_size)

Finish a CMAC operation returning the CMAC value.

ATCA\_STATUS atcab\_aes\_ctr\_init\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_t counter\_size, const uint8\_t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_
 t counter\_size, const uint8\_t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8 t key block, uint8 t counter size, uint8 t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8 t counter size, uint8 t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*input, uint8\_t \*output)

Process a block of data using CTR mode and a key within the device. <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a>() or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_c

ATCA\_STATUS atcab\_aes\_ctr\_encrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_←
t \*ciphertext)

Encrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_ctr\_decrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_←
t \*plaintext)

Decrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

ATCA STATUS atcab aes ctr increment (atca aes ctr ctx t \*ctx)

Increments AES CTR counter value.

- ATCA\_STATUS \_atcab\_exit (void)
- ATCA\_STATUS atcab\_wakeup (void)

wakeup the CryptoAuth device

ATCA\_STATUS atcab\_idle (void)

idle the CryptoAuth device

ATCA\_STATUS atcab\_sleep (void)

invoke sleep on the CryptoAuth device

ATCA\_STATUS atcab\_get\_zone\_size (uint8\_t zone, uint16\_t slot, size\_t \*size)

Gets the size of the specified zone in bytes.

• ATCA\_STATUS atcab\_aes (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8\_t \*aes\_out)

Compute the AES-128 encrypt, decrypt, or GFM calculation.

ATCA\_STATUS atcab\_aes\_encrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_←
t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

 ATCA\_STATUS atcab\_aes\_encrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*plaintext, uint8 t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

ATCA\_STATUS atcab\_aes\_decrypt (uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

 ATCA\_STATUS atcab\_aes\_decrypt\_ext (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

ATCA STATUS atcab aes gfm (const uint8 t \*h, const uint8 t \*input, uint8 t \*output)

Perform a Galois Field Multiply (GFM) operation.

 ATCA\_STATUS atcab\_aes\_gcm\_init (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*iv, size t iv size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_init\_rand (atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, size t rand size, const uint8 t \*free field, size t free field size, uint8 t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_gcm\_aad\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32\_t aad
 \_size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

• ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint32\_t plaintext\_size, uint8\_t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

- ATCA\_STATUS atcab\_aes\_gcm\_encrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size\_t tag\_size)
  - Complete a GCM encrypt operation returning the authentication tag.
- ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_update (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32\_t ciphertext\_size, uint8\_t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_gcm\_decrypt\_finish (atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag
 —size, bool \*is\_verified)

Complete a GCM decrypt operation verifying the authentication tag.

ATCA\_STATUS atcab\_checkmac (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, const uint8\_←
 t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

ATCA\_STATUS atcab\_counter (uint8\_t mode, uint16\_t counter\_id, uint32\_t \*counter\_value)

Compute the Counter functions.

ATCA\_STATUS atcab\_counter\_increment (uint16\_t counter\_id, uint32\_t \*counter\_value)

Increments one of the device's monotonic counters.

ATCA STATUS atcab counter read (uint16 t counter id, uint32 t \*counter value)

Read one of the device's monotonic counters.

ATCA\_STATUS atcab\_derivekey (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*mac)

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

ATCA\_STATUS atcab\_ecdh\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, uint8\_t \*out nonce)

Base function for generating premaster secret key using ECDH.

• ATCA\_STATUS atcab\_ecdh (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

ATCA\_STATUS atcab\_ecdh\_enc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*read\_key, uint16\_t read\_key\_id, const uint8\_t num\_in[(20)])

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

ATCA\_STATUS atcab\_ecdh\_ioenc (uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS atcab\_ecdh\_tempkey (const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

- ATCA\_STATUS atcab\_ecdh\_tempkey\_ioenc (const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

  ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection.
  - ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.
- ATCA\_STATUS atcab\_gendig (uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_t other\_data 
   — size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

ATCA\_STATUS atcab\_genkey\_base (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_
 t \*public\_key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

• ATCA\_STATUS atcab\_genkey (uint16\_t key\_id, uint8\_t \*public\_key)

Issues GenKey command, which generates a new random private key in slot/handle and returns the public key.

ATCA STATUS atcab get pubkey (uint16 t key id, uint8 t \*public key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

ATCA STATUS atcab hmac (uint8 t mode, uint16 t key id, uint8 t \*digest)

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA STATUS atcab info base (uint8 t mode, uint16 t param2, uint8 t \*out data)

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

ATCA\_STATUS atcab\_info (uint8\_t \*revision)

Use the Info command to get the device revision (DevRev).

ATCA STATUS atcab info set latch (bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

ATCA STATUS atcab info get latch (bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

 ATCA\_STATUS atcab\_kdf (uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8\_t \*out\_data, uint8\_t \*out\_nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

ATCA\_STATUS atcab\_lock (uint8\_t mode, uint16\_t summary\_crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

• ATCA\_STATUS atcab\_lock\_config\_zone (void)

Unconditionally (no CRC required) lock the config zone.

ATCA\_STATUS atcab\_lock\_config\_zone\_crc (uint16\_t summary\_crc)

Lock the config zone with summary CRC.

ATCA STATUS atcab lock data zone (void)

Unconditionally (no CRC required) lock the data zone (slots and OTP). for CryptoAuth devices and lock the setup for Trust Anchor device.

ATCA\_STATUS atcab\_lock\_data\_zone\_crc (uint16\_t summary\_crc)

Lock the data zone (slots and OTP) with summary CRC.

ATCA\_STATUS atcab\_lock\_data\_slot (uint16\_t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1) (for cryptoauth devices) or Lock an individual handle in shared data element on an Trust Anchor device (for Trust Anchor devices).

ATCA STATUS atcab mac (uint8 t mode, uint16 t key id, const uint8 t \*challenge, uint8 t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS atcab\_nonce\_base (uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

ATCA STATUS atcab nonce (const uint8 t \*num in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS atcab\_nonce\_load (uint8\_t target, const uint8\_t \*num\_in, uint16\_t num\_in\_size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

ATCA\_STATUS atcab\_nonce\_rand (const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

ATCA STATUS atcab challenge (const uint8 t \*num in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA STATUS atcab challenge seed update (const uint8 t \*num in, uint8 t \*rand out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number.

ATCA\_STATUS atcab\_priv\_write (uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write\_key\_id, const uint8\_t write\_key[32], const uint8\_t num\_in[(20)])

Executes PrivWrite command, to write externally generated ECC private keys into the device.

ATCA\_STATUS atcab\_random (uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the device.

• ATCA\_STATUS atcab\_random\_ext (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the device.

ATCA\_STATUS atcab\_read\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint8\_t \*data, uint8\_t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

ATCA STATUS atcab is locked (uint8 t zone, bool \*is locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

ATCA\_STATUS atcab\_is\_config\_locked (bool \*is\_locked)

This function check whether configuration zone is locked or not.

ATCA STATUS atcab is data locked (bool \*is locked)

This function check whether data/setup zone is locked or not.

ATCA\_STATUS atcab\_is\_slot\_locked (uint16\_t slot, bool \*is\_locked)

This function check whether slot/handle is locked or not.

ATCA\_STATUS atcab\_read\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset, uint8\_t \*data, size\_
 t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

ATCA\_STATUS atcab\_read\_serial\_number (uint8\_t \*serial\_number)

This function returns serial number of the device.

ATCA\_STATUS atcab\_read\_pubkey (uint16\_t slot, uint8\_t \*public\_key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

ATCA\_STATUS atcab\_read\_sig (uint16\_t slot, uint8\_t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

ATCA\_STATUS atcab\_read\_config\_zone (uint8\_t \*config\_data)

Executes Read command to read the complete device configuration zone.

ATCA\_STATUS atcab\_cmp\_config\_zone (uint8\_t \*config\_data, bool \*same\_config)

Compares a specified configuration zone with the configuration zone currently on the device.

• ATCA\_STATUS atcab\_read\_enc (uint16\_t key\_id, uint8\_t block, uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

ATCA\_STATUS atcab\_secureboot (uint8\_t mode, uint16\_t param2, const uint8\_t \*digest, const uint8\_←
t \*signature, uint8\_t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

ATCA\_STATUS atcab\_secureboot\_mac (uint8\_t mode, const uint8\_t \*digest, const uint8\_t \*signature, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

ATCA STATUS atcab selftest (uint8 t mode, uint16 t param2, uint8 t \*result)

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT← ECC608 chip.

ATCA\_STATUS atcab\_sha\_base (uint8\_t mode, uint16\_t length, const uint8\_t \*data\_in, uint8\_t \*data\_out, uint16\_t \*data\_out\_size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

ATCA\_STATUS atcab\_sha\_start (void)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA\_STATUS atcab\_sha\_update (const uint8\_t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

ATCA\_STATUS atcab\_sha\_end (uint8\_t \*digest, uint16\_t length, const uint8\_t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_read\_context (uint8\_t \*context, uint16\_t \*context\_size)

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

ATCA\_STATUS atcab\_sha\_write\_context (const uint8\_t \*context, uint16\_t context\_size)

Executes SHA command to write (restore) a SHA-256 context into the device. Only supported for ATECC608 with SHA-256 contexts.

ATCA\_STATUS atcab\_sha (uint16\_t length, const uint8\_t \*message, uint8\_t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA STATUS atcab hw sha2 256 (const uint8 t \*data, size t data size, uint8 t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA\_STATUS atcab\_hw\_sha2\_256\_init (atca\_sha256\_ctx\_t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

ATCA\_STATUS atcab\_hw\_sha2\_256\_update (atca\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data\_
 size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

ATCA STATUS atcab hw sha2 256 finish (atca sha256 ctx t \*ctx, uint8 t \*digest)

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

ATCA\_STATUS atcab\_sha\_hmac\_init (atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac\_update (atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8\_t \*data, size\_t data
 — size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac\_finish (atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_t \*digest, uint8\_t target)

Executes SHA command to complete a HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sha\_hmac (const uint8\_t \*data, size\_t data\_size, uint16\_t key\_slot, uint8\_t \*digest, uint8\_t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

ATCA\_STATUS atcab\_sign\_base (uint8\_t mode, uint16\_t key\_id, uint8\_t \*signature)

Executes the Sign command, which generates a signature using the ECDSA algorithm.

ATCA\_STATUS atcab\_sign (uint16\_t key\_id, const uint8\_t \*msg, uint8\_t \*signature)

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS atcab\_sign\_internal (uint16\_t key\_id, bool is\_invalidate, bool is\_full\_sn, uint8\_t \*signature)

Executes Sign command to sign an internally generated message.

• ATCA STATUS atcab updateextra (uint8 t mode, uint16 t new value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

ATCA\_STATUS atcab\_verify (uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public
 \_key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS atcab\_verify\_extern (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_
 t \*public\_key, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS atcab\_verify\_extern\_mac (const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public\_key, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

 ATCA\_STATUS atcab\_verify\_stored (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp

Key for other devices.

ATCA\_STATUS atcab\_verify\_stored\_mac (const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key
 —id, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

 ATCA\_STATUS atcab\_verify\_validate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

 ATCA\_STATUS atcab\_verify\_invalidate (uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

ATCA STATUS atcab write (uint8 t zone, uint16 t address, const uint8 t \*value, const uint8 t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

ATCA\_STATUS atcab\_write\_zone (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, const uint8\_←
t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

ATCA\_STATUS atcab\_write\_bytes\_zone (uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

ATCA\_STATUS atcab\_write\_pubkey (uint16\_t slot, const uint8\_t \*public\_key)

Uses the write command to write a public key to a slot in the proper format.

ATCA\_STATUS atcab\_write\_config\_zone (const uint8\_t \*config\_data)

Executes the Write command, which writes the configuration zone.

ATCA\_STATUS atcab\_write\_enc (uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

ATCA STATUS atcab write config counter (uint16 t counter id, uint32 t counter value)

Initialize one of the monotonic counters in device with a specific value.

#### **Variables**

SHARED\_LIB\_IMPORT ATCADevice \_gDevice

### 20.4.1 Detailed Description

CryptoAuthLib Basic API methods - a simple crypto authentication API. These methods manage a global ATCA← Device object behind the scenes. They also manage the wake/idle state transitions so callers don't need to.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.5 atca bool.h File Reference

bool define for systems that don't have it

```
#include <stdbool.h>
```

# 20.5.1 Detailed Description

bool define for systems that don't have it

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.6 atca\_cfgs.c File Reference

a set of default configurations for various ATCA devices and interfaces

```
#include <stddef.h>
#include "cryptoauthlib.h"
#include "atca_cfgs.h"
#include "atca_iface.h"
#include "atca_device.h"
```

# 20.6.1 Detailed Description

a set of default configurations for various ATCA devices and interfaces

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.7 atca\_cfgs.h File Reference

a set of default configurations for various ATCA devices and interfaces

```
#include "atca_iface.h"
```

#### **Variables**

• ATCAlfaceCfg cfg\_ateccx08a\_i2c\_default

default configuration for an ECCx08A device on the first logical I2C bus

ATCAlfaceCfg cfg ateccx08a swi default

default configuration for an ECCx08A device on the logical SWI bus over UART

ATCAlfaceCfg cfg ateccx08a kitcdc default

default configuration for Kit protocol over a CDC interface

ATCAlfaceCfg cfg ateccx08a kithid default

default configuration for Kit protocol over a HID interface

ATCAlfaceCfg cfg\_atsha20xa\_i2c\_default

default configuration for a SHA204A device on the first logical I2C bus

ATCAlfaceCfg cfg\_atsha20xa\_swi\_default

default configuration for an SHA20xA device on the logical SWI bus over UART

ATCAlfaceCfg cfg\_atsha20xa\_kitcdc\_default

default configuration for Kit protocol over a CDC interface

ATCAlfaceCfg cfg\_atsha20xa\_kithid\_default

default configuration for Kit protocol over a HID interface for SHA204

# 20.7.1 Detailed Description

a set of default configurations for various ATCA devices and interfaces

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.7.2 Variable Documentation

### 20.7.2.1 cfg\_ateccx08a\_i2c\_default

ATCAIfaceCfg cfg\_ateccx08a\_i2c\_default

default configuration for an ECCx08A device on the first logical I2C bus

#### 20.7.2.2 cfg ateccx08a kitcdc default

ATCAIfaceCfg cfg\_ateccx08a\_kitcdc\_default

default configuration for Kit protocol over a CDC interface

#### 20.7.2.3 cfg\_ateccx08a\_kithid\_default

ATCAIfaceCfg cfg\_ateccx08a\_kithid\_default

default configuration for Kit protocol over a HID interface

#### 20.7.2.4 cfg ateccx08a swi default

ATCAIfaceCfg cfg\_ateccx08a\_swi\_default

default configuration for an ECCx08A device on the logical SWI bus over UART

#### 20.7.2.5 cfg\_atsha20xa\_i2c\_default

 ${\tt ATCAIfaceCfg\ cfg\_atsha20xa\_i2c\_default}$ 

default configuration for a SHA204A device on the first logical I2C bus

### 20.7.2.6 cfg\_atsha20xa\_kitcdc\_default

ATCAIfaceCfg cfg\_atsha20xa\_kitcdc\_default

default configuration for Kit protocol over a CDC interface

#### 20.7.2.7 cfg\_atsha20xa\_kithid\_default

 ${\tt ATCAIfaceCfg\ cfg\_atsha20xa\_kithid\_default}$ 

default configuration for Kit protocol over a HID interface for SHA204

### 20.7.2.8 cfg\_atsha20xa\_swi\_default

ATCAIfaceCfg cfg\_atsha20xa\_swi\_default

default configuration for an SHA20xA device on the logical SWI bus over UART

# 20.8 atca command.c File Reference

Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send that byte string through the device interface.

```
#include <stdlib.h>
#include <string.h>
#include "atca_command.h"
#include "cryptoauthlib.h"
```

### **Functions**

- ATCA\_STATUS initATCACommand (ATCADeviceType device\_type, ATCACommand ca\_cmd)
   Initializer for ATCACommand.
- ATCACommand newATCACommand (ATCADeviceType device\_type)

constructor for ATCACommand

void deleteATCACommand (ATCACommand \*ca\_cmd)

ATCACommand destructor.

# 20.8.1 Detailed Description

Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send that byte string through the device interface.

The primary goal of the command builder is to wrap the given parameters with the correct packet size and CRC. The caller should first fill in the parameters required in the ATCAPacket parameter given to the command. The command builder will deal with the mechanics of creating a valid packet using the parameter information.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.9 atca\_command.h File Reference

Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the ATCAIFace object to dispatch.

```
#include "atca_compiler.h"
#include "atca_status.h"
#include "atca_devtypes.h"
#include <stddef.h>
```

### **Data Structures**

struct atca\_command

atca\_command is the C object backing ATCACommand.

# **Typedefs**

typedef struct atca\_command \* ATCACommand

### **Functions**

- ATCA\_STATUS initATCACommand (ATCADeviceType device\_type, ATCACommand ca\_cmd)
   Initializer for ATCACommand.
- ATCACommand newATCACommand (ATCADeviceType device\_type)

constructor for ATCACommand

void deleteATCACommand (ATCACommand \*ca\_cmd)

ATCACommand destructor.

# 20.9.1 Detailed Description

Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the ATCAIFace object to dispatch.

This command object supports the ATSHA and ATECC device family. The command list is a superset of all device commands for this family. The command object differentiates the packet contents based on specific device type within the family.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.10 atca compiler.h File Reference

CryptoAuthLiub is meant to be portable across architectures, even non-Microchip architectures and compiler environments. This file is for isolating compiler specific macros.

### 20.10.1 Detailed Description

CryptoAuthLiub is meant to be portable across architectures, even non-Microchip architectures and compiler environments. This file is for isolating compiler specific macros.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.11 atca\_crypto\_hw\_aes.h File Reference

AES CTR, CBC & CMAC structure definitions.

#include "cryptoauthlib.h"

### **Data Structures**

- struct atca\_aes\_cbc\_ctx
- struct atca\_aes\_cmac\_ctx
- struct atca\_aes\_ctr\_ctx

# **Typedefs**

- typedef struct atca\_aes\_cbc\_ctx atca\_aes\_cbc\_ctx\_t
- typedef struct atca\_aes\_cmac\_ctx atca\_aes\_cmac\_ctx\_t
- typedef struct atca\_aes\_ctr\_ctx atca\_aes\_ctr\_ctx\_t

# 20.11.1 Detailed Description

AES CTR, CBC & CMAC structure definitions.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.11.2 Typedef Documentation

```
20.11.2.1 atca_aes_cbc_ctx_t
```

```
typedef struct atca_aes_cbc_ctx atca_aes_cbc_ctx_t
```

# 20.11.2.2 atca\_aes\_cmac\_ctx\_t

```
typedef struct atca_aes_cmac_ctx atca_aes_cmac_ctx_t
```

#### 20.11.2.3 atca\_aes\_ctr\_ctx\_t

```
typedef struct atca_aes_ctr_ctx atca_aes_ctr_ctx_t
```

# 20.12 atca\_crypto\_hw\_aes\_cbc.c File Reference

CryptoAuthLib Basic API methods for AES CBC mode.

```
#include "cryptoauthlib.h"
#include "atca_crypto_hw_aes.h"
```

#### **Functions**

ATCA\_STATUS atcab\_aes\_cbc\_init\_ext (ATCADevice device, atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*iv)

Initialize context for AES CBC operation.

ATCA\_STATUS atcab\_aes\_cbc\_init (atca\_aes\_cbc\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, const uint8 t \*iv)

Initialize context for AES CBC operation.

ATCA\_STATUS atcab\_aes\_cbc\_encrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Encrypt a block of data using CBC mode and a key within the device. <a href="atcab\_aes\_cbc\_init(">atcab\_aes\_cbc\_init()</a>) should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_cbc\_decrypt\_block (atca\_aes\_cbc\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Decrypt a block of data using CBC mode and a key within the device. atcab\_aes\_cbc\_init() should be called before the first use of this function.

### 20.12.1 Detailed Description

CryptoAuthLib Basic API methods for AES CBC mode.

The AES command supports 128-bit AES encryption or decryption of small messages or data packets in ECB mode.

Note

List of devices that support this command - ATECC608A, ATECC608B, & TA100. Refer to device datasheet for full details.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.13 atca\_crypto\_hw\_aes\_cmac.c File Reference

CryptoAuthLib Basic API methods for AES CBC\_MAC mode.

```
#include "cryptoauthlib.h"
#include "atca_crypto_hw_aes.h"
```

#### **Functions**

ATCA\_STATUS atcab\_aes\_cmac\_init\_ext (ATCADevice device, atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block)

Initialize a CMAC calculation using an AES-128 key in the device.

- ATCA\_STATUS atcab\_aes\_cmac\_init (atca\_aes\_cmac\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block)
   Initialize a CMAC calculation using an AES-128 key in the device.
- ATCA\_STATUS atcab\_aes\_cmac\_update (atca\_aes\_cmac\_ctx\_t \*ctx, const uint8\_t \*data, uint32\_t data\_
   size)

Add data to an initialized CMAC calculation.

• ATCA\_STATUS atcab\_aes\_cmac\_finish (atca\_aes\_cmac\_ctx\_t \*ctx, uint8\_t \*cmac, uint32\_t cmac\_size)

Finish a CMAC operation returning the CMAC value.

# 20.13.1 Detailed Description

CryptoAuthLib Basic API methods for AES CBC\_MAC mode.

The AES command supports 128-bit AES encryption or decryption of small messages or data packets in ECB mode.

Note

List of devices that support this command - ATECC608A, ATECC608B, & TA100. Refer to device datasheet for full details.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.14 atca\_crypto\_hw\_aes\_ctr.c File Reference

CryptoAuthLib Basic API methods for AES CTR mode.

```
#include "cryptoauthlib.h"
#include "atca_crypto_hw_aes.h"
```

#### **Functions**

• ATCA\_STATUS atcab\_aes\_ctr\_init\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8 t key block, uint8 t counter size, const uint8 t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

• ATCA\_STATUS atcab\_aes\_ctr\_init (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_← t counter\_size, const uint8\_t \*iv)

Initialize context for AES CTR operation with an existing IV, which is common when start a decrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand\_ext (ATCADevice device, atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_t counter\_size, uint8\_t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_init\_rand (atca\_aes\_ctr\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, uint8\_t counter\_size, uint8\_t \*iv)

Initialize context for AES CTR operation with a random nonce and counter set to 0 as the IV, which is common when starting an encrypt operation.

ATCA\_STATUS atcab\_aes\_ctr\_increment (atca\_aes\_ctr\_ctx\_t \*ctx)

Increments AES CTR counter value.

ATCA STATUS atcab aes ctr block (atca aes ctr ctx t \*ctx, const uint8 t \*input, uint8 t \*output)

Process a block of data using CTR mode and a key within the device. <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a> or <a href="atcab\_aes\_ctr\_init">atcab\_aes\_ctr\_init</a> rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_ctr\_encrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*plaintext, uint8\_←
t \*ciphertext)

Encrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS atcab\_aes\_ctr\_decrypt\_block (atca\_aes\_ctr\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint8\_←
t \*plaintext)

Decrypt a block of data using CTR mode and a key within the device. atcab\_aes\_ctr\_init() or atcab\_aes\_ctr\_init\_rand() should be called before the first use of this function.

# 20.14.1 Detailed Description

CryptoAuthLib Basic API methods for AES CTR mode.

The AES command supports 128-bit AES encryption or decryption of small messages or data packets in ECB mode.

Note

List of devices that support this command - ATECC608A, ATECC608B, & TA100. Refer to device datasheet for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.15 atca\_crypto\_sw.h File Reference

Common defines for CryptoAuthLib software crypto wrappers.

```
#include <stdint.h>
#include <stdlib.h>
#include "atca_config.h"
#include "atca_status.h"
#include "mbedtls/config.h"
#include <mbedtls/cipher.h>
#include <mbedtls/md.h>
```

#### **Macros**

- #define ATCA\_SHA1\_DIGEST\_SIZE (20)
- #define ATCA\_SHA2\_256\_DIGEST\_SIZE (32)
- #define ATCA\_SHA2\_256\_BLOCK\_SIZE (64)
- #define MBEDTLS CMAC C

# **Typedefs**

- typedef mbedtls\_cipher\_context\_t atcac\_aes\_cmac\_ctx
- typedef mbedtls\_md\_context\_t atcac\_hmac\_sha256\_ctx
- typedef mbedtls\_cipher\_context\_t atcac\_aes\_gcm\_ctx
- typedef mbedtls\_md\_context\_t atcac\_sha1\_ctx
- typedef mbedtls\_md\_context\_t atcac\_sha2\_256\_ctx

#### **Functions**

ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len, const uint8\_t \*iv, const uint8\_t iv\_len)

Initialize an AES-GCM context.

ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len, const uint8\_t \*iv, const uint8\_t iv\_len)

Initialize an AES-GCM context for decryption.

- ATCA\_STATUS atcac\_aes\_cmac\_init (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)

  Initialize context for performing CMAC in software.
- ATCA\_STATUS atcac\_aes\_cmac\_update (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*data, const size\_
   t data\_size)

Update CMAC context with input data.

- ATCA\_STATUS atcac\_aes\_cmac\_finish (atcac\_aes\_cmac\_ctx \*ctx, uint8\_t \*cmac, size\_t \*cmac\_size)

  Finish CMAC calculation and clear the CMAC context.
- ATCA\_STATUS atcac\_aes\_gcm\_aad\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*aad, const size\_ ← t aad len)

Update the GCM context with additional authentication data (AAD)

 ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*plaintext, const size\_t pt\_len, uint8\_t \*ciphertext, size\_t \*ct\_len)

Encrypt a data using the initialized context.

- ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, uint8\_t \*tag, size\_t tag\_len)

  Get the AES-GCM tag and free the context.
- ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*ciphertext, const size\_t ct\_len, uint8\_t \*plaintext, size\_t \*pt\_len)

Decrypt ciphertext using the initialized context.

ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*tag, size\_t tag\_len, bool \*is verified)

Compare the AES-GCM tag and free the context.

# 20.15.1 Detailed Description

Common defines for CryptoAuthLib software crypto wrappers.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.15.2 Macro Definition Documentation

### 20.15.2.1 ATCA SHA1 DIGEST SIZE

#define ATCA\_SHA1\_DIGEST\_SIZE (20)

# 20.15.2.2 ATCA\_SHA2\_256\_BLOCK\_SIZE

#define ATCA\_SHA2\_256\_BLOCK\_SIZE (64)

# 20.15.2.3 ATCA\_SHA2\_256\_DIGEST\_SIZE

#define ATCA\_SHA2\_256\_DIGEST\_SIZE (32)

# 20.15.2.4 MBEDTLS\_CMAC\_C

#define MBEDTLS\_CMAC\_C

# 20.15.3 Typedef Documentation

# 20.15.3.1 atcac\_aes\_cmac\_ctx

typedef mbedtls\_cipher\_context\_t atcac\_aes\_cmac\_ctx

### 20.15.3.2 atcac\_aes\_gcm\_ctx

 ${\tt typedef\ mbedtls\_cipher\_context\_t\ atcac\_aes\_gcm\_ctx}$ 

# 20.15.3.3 atcac\_hmac\_sha256\_ctx

 ${\tt typedef\ mbedtls\_md\_context\_t\ atcac\_hmac\_sha256\_ctx}$ 

# 20.15.3.4 atcac\_sha1\_ctx

typedef mbedtls\_md\_context\_t atcac\_shal\_ctx

#### 20.15.3.5 atcac\_sha2\_256\_ctx

```
typedef mbedtls_md_context_t atcac_sha2_256_ctx
```

# 20.15.4 Function Documentation

# 20.15.4.1 atcac\_aes\_cmac\_finish()

Finish CMAC calculation and clear the CMAC context.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.15.4.2 atcac\_aes\_cmac\_init()

```
ATCA_STATUS atcac_aes_cmac_init (
    atcac_aes_cmac_ctx * ctx,
    const uint8_t * key,
    const uint8_t key_len )
```

Initialize context for performing CMAC in software.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.15.4.3 atcac\_aes\_cmac\_update()

Update CMAC context with input data.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.15.4.4 atcac\_aes\_gcm\_aad\_update()

Update the GCM context with additional authentication data (AAD)

Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.15.4.5 atcac\_aes\_gcm\_decrypt\_finish()

```
ATCA_STATUS atcac_aes_gcm_decrypt_finish (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * tag,
    size_t tag_len,
    bool * is_verified )
```

Compare the AES-GCM tag and free the context.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.15.4.6 atcac\_aes\_gcm\_decrypt\_start()

Initialize an AES-GCM context for decryption.

Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.15.4.7 atcac\_aes\_gcm\_decrypt\_update()

Decrypt ciphertext using the initialized context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.15.4.8 atcac\_aes\_gcm\_encrypt\_finish()

Get the AES-GCM tag and free the context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.15.4.9 atcac\_aes\_gcm\_encrypt\_start()

```
ATCA_STATUS atcac_aes_gcm_encrypt_start (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * key,
    const uint8_t key_len,
    const uint8_t * iv,
    const uint8_t iv_len)
```

Initialize an AES-GCM context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.15.4.10 atcac\_aes\_gcm\_encrypt\_update()

```
ATCA_STATUS atcac_aes_gcm_encrypt_update (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * plaintext,
    const size_t pt_len,
    uint8_t * ciphertext,
    size_t * ct_len )
```

Encrypt a data using the initialized context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.16 atca crypto sw ecdsa.c File Reference

API wrapper for software ECDSA verify. Currently unimplemented but could be implemented via a 3rd party library such as MicroECC.

```
#include "atca_crypto_sw_ecdsa.h"
```

### **Functions**

• int atcac\_sw\_ecdsa\_verify\_p256 (const uint8\_t msg[(256/8)], const uint8\_t signature[((256/8) \*2)], const uint8\_t public key[((256/8) \*2)])

return software generated ECDSA verification result and the function is currently not implemented

## 20.16.1 Detailed Description

API wrapper for software ECDSA verify. Currently unimplemented but could be implemented via a 3rd party library such as MicroECC.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.17 atca\_crypto\_sw\_ecdsa.h File Reference

```
#include "atca_crypto_sw.h"
#include <stddef.h>
#include <stdint.h>
```

#### **Macros**

- #define ATCA\_ECC\_P256\_FIELD\_SIZE (256 / 8)
- #define ATCA\_ECC\_P256\_PRIVATE\_KEY\_SIZE (ATCA\_ECC\_P256\_FIELD\_SIZE)
- #define ATCA\_ECC\_P256\_PUBLIC\_KEY\_SIZE (ATCA\_ECC\_P256\_FIELD\_SIZE \* 2)
- #define ATCA\_ECC\_P256\_SIGNATURE\_SIZE (ATCA\_ECC\_P256\_FIELD\_SIZE \* 2)

### **Functions**

• int atcac\_sw\_ecdsa\_verify\_p256 (const uint8\_t msg[(256/8)], const uint8\_t signature[((256/8) \*2)], const uint8\_t public\_key[((256/8) \*2)])

return software generated ECDSA verification result and the function is currently not implemented

### 20.17.1 Detailed Description

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.18 atca\_crypto\_sw\_rand.c File Reference

API wrapper for software random.

```
#include "atca_crypto_sw_rand.h"
```

#### **Functions**

• int atcac\_sw\_random (uint8\_t \*data, size\_t data\_size)

return software generated random number and the function is currently not implemented

### 20.18.1 Detailed Description

API wrapper for software random.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.19 atca\_crypto\_sw\_rand.h File Reference

```
#include "atca_crypto_sw.h"
#include <stddef.h>
#include <stdint.h>
```

#### **Functions**

int atcac\_sw\_random (uint8\_t \*data, size\_t data\_size)
 return software generated random number and the function is currently not implemented

## 20.19.1 Detailed Description

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.20 atca\_crypto\_sw\_sha1.c File Reference

Wrapper API for SHA 1 routines.

```
#include "atca_crypto_sw_sha1.h"
#include "hashes/sha1_routines.h"
```

#### **Functions**

• int atcac\_sw\_sha1 (const uint8\_t \*data, size\_t data\_size, uint8\_t digest[(20)])

Perform SHA1 hash of data in software.

### 20.20.1 Detailed Description

Wrapper API for SHA 1 routines.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.21 atca\_crypto\_sw\_sha1.h File Reference

Wrapper API for SHA 1 routines.

```
#include "atca_crypto_sw.h"
#include <stddef.h>
#include <stdint.h>
```

#### **Functions**

```
int atcac_sw_sha1_init (atcac_sha1_ctx *ctx)
```

Initialize context for performing SHA1 hash in software.

- int atcac\_sw\_sha1\_update (atcac\_sha1\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)
   Add data to a SHA1 hash.
- int atcac sw sha1 finish (atcac sha1 ctx \*ctx, uint8 t digest[(20)])
- int atcac\_sw\_sha1 (const uint8\_t \*data, size\_t data\_size, uint8\_t digest[(20)])

Perform SHA1 hash of data in software.

## 20.21.1 Detailed Description

Wrapper API for SHA 1 routines.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.22 atca\_crypto\_sw\_sha2.c File Reference

Wrapper API for software SHA 256 routines.

```
#include "cryptoauthlib.h"
#include "atca_crypto_sw_sha2.h"
#include "hashes/sha2_routines.h"
```

### **Functions**

• int atcac\_sw\_sha2\_256 (const uint8\_t \*data, size\_t data\_size, uint8\_t digest[(32)])

single call convenience function which computes Hash of given data using SHA256 software

### 20.22.1 Detailed Description

Wrapper API for software SHA 256 routines.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.23 atca\_crypto\_sw\_sha2.h File Reference

Wrapper API for software SHA 256 routines.

```
#include "atca_crypto_sw.h"
#include <stddef.h>
#include <stdint.h>
```

#### **Functions**

- int atcac sw sha2 256 init (atcac sha2 256 ctx \*ctx)
  - Initialize context for performing SHA256 hash in software.
- int atcac\_sw\_sha2\_256\_update (atcac\_sha2\_256\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)
  - Add data to a SHA256 hash.
- int atcac\_sw\_sha2\_256\_finish (atcac\_sha2\_256\_ctx \*ctx, uint8\_t digest[(32)])
- int atcac\_sw\_sha2\_256 (const uint8\_t \*data, size\_t data\_size, uint8\_t digest[(32)])
  - single call convenience function which computes Hash of given data using SHA256 software
- ATCA\_STATUS atcac\_sha256\_hmac\_init (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)
  - Initialize context for performing HMAC (sha256) in software.
- ATCA\_STATUS atcac\_sha256\_hmac\_update (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*data, size\_← t data size)
  - Update HMAC context with input data.
- ATCA\_STATUS atcac\_sha256\_hmac\_finish (atcac\_hmac\_sha256\_ctx \*ctx, uint8\_t \*digest, size\_t \*digest ← len)

Finish CMAC calculation and clear the HMAC context.

### 20.23.1 Detailed Description

Wrapper API for software SHA 256 routines.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.24 atca\_debug.c File Reference

Debug/Trace for CryptoAuthLib calls.

```
#include <cryptoauthlib.h>
```

### **Functions**

- void atca trace config (FILE \*fp)
- ATCA STATUS atca trace (ATCA STATUS status)
- ATCA\_STATUS atca\_trace\_msg (ATCA\_STATUS status, const char \*msg)

### **Variables**

FILE \* g\_trace\_fp

## 20.24.1 Detailed Description

Debug/Trace for CryptoAuthLib calls.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.24.2 Function Documentation

### 20.24.2.1 atca\_trace()

```
ATCA_STATUS atca_trace (
ATCA_STATUS status)
```

### 20.24.2.2 atca\_trace\_config()

```
void atca_trace_config ( FILE * fp )
```

### 20.24.2.3 atca\_trace\_msg()

### 20.24.3 Variable Documentation

### 20.24.3.1 g\_trace\_fp

```
FILE* g_trace_fp
```

# 20.25 atca\_debug.h File Reference

```
#include "atca_status.h"
```

#### **Functions**

- void atca trace config (FILE \*fp)
- ATCA\_STATUS atca\_trace (ATCA\_STATUS status)
- ATCA\_STATUS atca\_trace\_msg (ATCA\_STATUS status, const char \*msg)

### 20.25.1 Function Documentation

#### 20.25.1.1 atca\_trace()

```
ATCA_STATUS atca_trace (

ATCA_STATUS status)
```

### 20.25.1.2 atca\_trace\_config()

```
void atca_trace_config ( FILE * fp )
```

## 20.25.1.3 atca\_trace\_msg()

## 20.26 atca\_device.c File Reference

Microchip CryptoAuth device object.

```
#include <cryptoauthlib.h>
```

### **Functions**

ATCADevice newATCADevice (ATCAlfaceCfg \*cfg)

constructor for a Microchip CryptoAuth device

void deleteATCADevice (ATCADevice \*ca\_dev)

destructor for a device NULLs reference after object is freed

ATCA\_STATUS initATCADevice (ATCAlfaceCfg \*cfg, ATCADevice ca\_dev)

Initializer for an Microchip CryptoAuth device.

ATCACommand atGetCommands (ATCADevice dev)

returns a reference to the ATCACommand object for the device

ATCAlface atGetIFace (ATCADevice dev)

returns a reference to the ATCAlface interface object for the device

ATCA\_STATUS releaseATCADevice (ATCADevice ca\_dev)

Release any resources associated with the device.

### 20.26.1 Detailed Description

Microchip CryptoAuth device object.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.27 atca device.h File Reference

Microchip Crypto Auth device object.

```
#include "atca_command.h"
#include "atca_iface.h"
```

#### **Data Structures**

- struct \_atsha204a\_config
- struct atecc508a config
- struct \_atecc608\_config
- · struct atca device

atca\_device is the C object backing ATCADevice. See the atca\_device.h file for details on the ATCADevice methods

#### **Macros**

- #define ATCA\_PACKED
- #define ATCA\_AES\_ENABLE\_EN\_SHIFT (0)
- #define ATCA AES ENABLE EN MASK (0x01u << ATCA AES ENABLE EN SHIFT)</li>
- #define ATCA I2C ENABLE EN SHIFT (0)
- #define ATCA\_I2C\_ENABLE\_EN\_MASK (0x01u << ATCA\_I2C\_ENABLE\_EN\_SHIFT)</li>
- #define ATCA\_COUNTER\_MATCH\_EN\_SHIFT (0)
- #define ATCA\_COUNTER\_MATCH\_EN\_MASK (0x01u << ATCA\_COUNTER\_MATCH\_EN\_SHIFT)</li>
- #define ATCA\_COUNTER\_MATCH\_KEY\_SHIFT (4)
- #define ATCA COUNTER MATCH KEY MASK (0x0Fu << ATCA COUNTER MATCH KEY SHIFT)</li>
- #define ATCA COUNTER MATCH KEY(v) (ATCA COUNTER MATCH KEY MASK & (v << ATCA COUNTER MATCH K
- #define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT (0)
- #define ATCA\_CHIP\_MODE\_I2C\_EXTRA\_MASK (0x01u << ATCA\_CHIP\_MODE\_I2C\_EXTRA\_SHIFT)</li>
- #define ATCA\_CHIP\_MODE\_TTL\_EN\_SHIFT (1)
- #define ATCA\_CHIP\_MODE\_TTL\_EN\_MASK (0x01u << ATCA\_CHIP\_MODE\_TTL\_EN\_SHIFT)
- #define ATCA CHIP MODE WDG LONG SHIFT (2)
- #define ATCA\_CHIP\_MODE\_WDG\_LONG\_MASK (0x01u << ATCA\_CHIP\_MODE\_WDG\_LONG\_SHIFT)
- #define ATCA CHIP MODE CLK DIV SHIFT (3)
- #define ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK (0x1Fu << ATCA\_CHIP\_MODE\_CLK\_DIV\_SHIFT)</li>
- #define ATCA\_CHIP\_MODE\_CLK\_DIV(v) (ATCA\_CHIP\_MODE\_CLK\_DIV\_MASK & (v << ATCA\_CHIP\_MODE\_CLK\_DIV\_S
- #define ATCA SLOT CONFIG READKEY SHIFT (0)
- #define ATCA\_SLOT\_CONFIG\_READKEY\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_READKEY(v) (ATCA\_SLOT\_CONFIG\_READKEY\_MASK & (v << ATCA\_SLOT\_CONFIG\_READKEY\_SHIFT))</li>
- #define ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT (4)

- #define ATCA\_SLOT\_CONFIG\_NOMAC\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_NOMAC\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_SHIFT (5)
- #define ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_LIMITED\_USE\_SHIFT)
- #define ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT (6)
- $\bullet \ \ \text{\#define ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_MASK} \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA\_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA_SLOT\_CONFIG\_ENCRYPTED\_READ\_SHIFT \ (0x01u << ATCA_SLOT\_CONFIG\_ENCRYPTED\_R$
- #define ATCA SLOT CONFIG IS SECRET SHIFT (7)
- #define ATCA SLOT CONFIG IS SECRET MASK (0x01u << ATCA SLOT CONFIG IS SECRET SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT (8)
- #define ATCA SLOT CONFIG WRITE KEY MASK (0x0Fu << ATCA SLOT CONFIG WRITE KEY SHIFT)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_KEY(v) (ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_MASK & (v << ATCA\_SLOT\_CONFIG\_WRITE\_KEY\_SHIFT))</li>
- #define ATCA SLOT CONFIG WRITE CONFIG SHIFT (12)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_MASK (0x0Fu << ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG(v) (ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_MASK & (v << ATCA\_SLOT\_CONFIG\_WRITE\_CONFIG\_SHIFT))</li>
- #define ATCA\_SLOT\_CONFIG\_EXT\_SIG\_SHIFT (0)
- #define ATCA SLOT CONFIG EXT SIG MASK (0x01u << ATCA SLOT CONFIG EXT SIG SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT (1)
- #define ATCA\_SLOT\_CONFIG\_INT\_SIG\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_INT\_SIG\_SHIFT)</li>
- #define ATCA SLOT CONFIG ECDH SHIFT (2)
- #define ATCA\_SLOT\_CONFIG\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_ECDH\_SHIFT)</li>
- #define ATCA SLOT CONFIG WRITE ECDH SHIFT (3)
- #define ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_WRITE\_ECDH\_SHIFT)
- #define ATCA SLOT CONFIG GEN KEY SHIFT (8)
- #define ATCA\_SLOT\_CONFIG\_GEN\_KEY\_MASK (0x01u << ATCA\_SLOT\_CONFIG\_GEN\_KEY\_SHIFT)</li>
- #define ATCA\_SLOT\_CONFIG\_PRIV\_WRITE\_SHIFT (9)
- #define ATCA SLOT CONFIG PRIV WRITE MASK (0x01u << ATCA SLOT CONFIG PRIV WRITE SHIFT)
- #define ATCA\_USE\_LOCK\_ENABLE\_SHIFT (0)
- #define ATCA\_USE\_LOCK\_ENABLE\_MASK (0x0Fu << ATCA\_USE\_LOCK\_ENABLE\_SHIFT)</li>
- #define ATCA USE LOCK KEY SHIFT (4)
- #define ATCA\_USE\_LOCK\_KEY\_MASK (0x0Fu << ATCA\_USE\_LOCK\_KEY\_SHIFT)</li>
- #define ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT (0)
- #define ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK (0x0Fu << ATCA\_VOL\_KEY\_PERM\_SLOT\_SHIFT)
- #define ATCA\_VOL\_KEY\_PERM\_SLOT(v) (ATCA\_VOL\_KEY\_PERM\_SLOT\_MASK & (v << ATCA\_VOL\_KEY\_PERM\_SLOT
- #define ATCA\_VOL\_KEY\_PERM\_EN\_SHIFT (7)
- #define ATCA\_VOL\_KEY\_PERM\_EN\_MASK (0x01u << ATCA\_VOL\_KEY\_PERM\_EN\_SHIFT)</li>
- #define ATCA\_SECURE\_BOOT\_MODE\_SHIFT (0)
- #define ATCA\_SECURE\_BOOT\_MODE\_MASK (0x03u << ATCA\_SECURE\_BOOT\_MODE\_SHIFT)</li>
- #define ATCA\_SECURE\_BOOT\_MODE(v) (ATCA\_SECURE\_BOOT\_MODE\_MASK & (v << ATCA\_SECURE\_BOOT\_MODE
- #define ATCA\_SECURE\_BOOT\_PERSIST\_EN\_SHIFT (3)
- #define ATCA SECURE BOOT PERSIST EN MASK (0x01u << ATCA SECURE BOOT PERSIST EN SHIFT)</li>
- #define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT (4)
- #define ATCA\_SECURE\_BOOT\_RAND\_NONCE\_MASK (0x01u << ATCA\_SECURE\_BOOT\_RAND\_NONCE\_SHIFT)
- #define ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT (8)
- #define ATCA\_SECURE\_BOOT\_DIGEST\_MASK (0x0Fu << ATCA\_SECURE\_BOOT\_DIGEST\_SHIFT)
- #define ATCA SECURE BOOT DIGEST(v) (ATCA SECURE BOOT DIGEST MASK & (v << ATCA SECURE BOOT DIG
- #define ATCA SECURE BOOT PUB KEY SHIFT (12)
- #define ATCA SECURE BOOT PUB KEY MASK (0x0Fu << ATCA SECURE BOOT PUB KEY SHIFT)
- #define ATCA\_SECURE\_BOOT\_PUB\_KEY(v) (ATCA\_SECURE\_BOOT\_PUB\_KEY\_MASK & (v << ATCA\_SECURE\_BOOT\_PUB\_KEY\_SHIFT))</li>
- #define ATCA\_SLOT\_LOCKED(v) ((0x01 << v) & 0xFFFFu)</li>
- #define ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT (0)
- #define ATCA\_CHIP\_OPT\_POST\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_POST\_EN\_SHIFT)</li>
- #define ATCA CHIP OPT IO PROT EN SHIFT (1)
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_IO\_PROT\_EN\_SHIFT)

- #define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT (2)
- #define ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_MASK (0x01u << ATCA\_CHIP\_OPT\_KDF\_AES\_EN\_SHIFT)</li>
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT (8)
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK (0x03u << ATCA\_CHIP\_OPT\_ECDH\_PROT\_SHIFT)</li>
- #define ATCA\_CHIP\_OPT\_ECDH\_PROT(v) (ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK & (v << ATCA\_CHIP\_OPT\_ECDH\_PROT\_MASK _OPT\_KDF\_PROT\_SHIFT (10)
- #define ATCA CHIP OPT KDF PROT MASK (0x03u << ATCA CHIP OPT KDF PROT SHIFT)
- #define ATCA\_CHIP\_OPT\_KDF\_PROT(v) (ATCA\_CHIP\_OPT\_KDF\_PROT\_MASK & (v << ATCA\_CHIP\_OPT\_KDF\_PROT\_S
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT (12)
- #define ATCA CHIP OPT IO PROT KEY MASK (0x0Fu << ATCA CHIP OPT IO PROT KEY SHIFT)</li>
- #define ATCA\_CHIP\_OPT\_IO\_PROT\_KEY(v) (ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_MASK & (v << ATCA\_CHIP\_OPT\_IO\_PROT\_KEY\_SHIFT))</li>
- #define ATCA KEY CONFIG PRIVATE SHIFT (0)
- #define ATCA\_KEY\_CONFIG\_PRIVATE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PRIVATE\_SHIFT)</li>
- #define ATCA KEY CONFIG PUB INFO SHIFT (1)
- #define ATCA\_KEY\_CONFIG\_PUB\_INFO\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PUB\_INFO\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_KEY\_TYPE\_SHIFT (2)
- #define ATCA\_KEY\_CONFIG\_KEY\_TYPE\_MASK (0x07u << ATCA\_KEY\_CONFIG\_KEY\_TYPE\_SHIFT)
- #define ATCA\_KEY\_CONFIG\_KEY\_TYPE(v) (ATCA\_KEY\_CONFIG\_KEY\_TYPE\_MASK & (v << ATCA\_KEY\_CONFIG\_KEY\_TYPE\_SHIFT))</li>
- #define ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT (5)
- #define ATCA\_KEY\_CONFIG\_LOCKABLE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_LOCKABLE\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT (6)
- #define ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_MASK (0x01u << ATCA\_KEY\_CONFIG\_REQ\_RANDOM\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_REQ\_AUTH\_SHIFT (7)
- #define ATCA\_KEY\_CONFIG\_REQ\_AUTH\_MASK (0x01u << ATCA\_KEY\_CONFIG\_REQ\_AUTH\_SHIFT)
- #define ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT (8)
- #define ATCA\_KEY\_CONFIG\_AUTH\_KEY\_MASK (0x0Fu << ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_AUTH\_KEY(v) (ATCA\_KEY\_CONFIG\_AUTH\_KEY\_MASK & (v << ATCA\_KEY\_CONFIG\_AUTH\_KEY\_SHIFT))</li>
- #define ATCA KEY CONFIG PERSIST DISABLE SHIFT (12)
- #define ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_MASK (0x01u << ATCA\_KEY\_CONFIG\_PERSIST\_DISABLE\_SHIFT)</li>
- #define ATCA KEY CONFIG RFU SHIFT (13)
- #define ATCA\_KEY\_CONFIG\_RFU\_MASK (0x01u << ATCA\_KEY\_CONFIG\_RFU\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT (14)
- #define ATCA\_KEY\_CONFIG\_X509\_ID\_MASK (0x03u << ATCA\_KEY\_CONFIG\_X509\_ID\_SHIFT)</li>
- #define ATCA\_KEY\_CONFIG\_X509\_ID(v) (ATCA\_KEY\_CONFIG\_X509\_ID\_MASK & (v << ATCA\_KEY\_CONFIG\_X509\_ID\_

### **Typedefs**

- typedef struct atsha204a config atsha204a config t
- typedef struct \_atecc508a\_config atecc508a\_config\_t
- typedef struct \_atecc608\_config atecc608\_config\_t
- typedef struct atca\_device \* ATCADevice

#### **Functions**

- ATCA\_STATUS initATCADevice (ATCAlfaceCfg \*cfg, ATCADevice ca\_dev)
  - Initializer for an Microchip CryptoAuth device.
- ATCADevice newATCADevice (ATCAlfaceCfg \*cfg)
  - constructor for a Microchip CryptoAuth device
- ATCA\_STATUS releaseATCADevice (ATCADevice ca\_dev)

Release any resources associated with the device.

void deleteATCADevice (ATCADevice \*ca\_dev)

destructor for a device NULLs reference after object is freed

ATCACommand atGetCommands (ATCADevice dev)

returns a reference to the ATCACommand object for the device

ATCAlface atGetIFace (ATCADevice dev)

returns a reference to the ATCAlface interface object for the device

### 20.27.1 Detailed Description

Microchip Crypto Auth device object.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.28 atca\_devtypes.h File Reference

Microchip Crypto Auth.

### **Enumerations**

```
    enum ATCADeviceType {
    ATSHA204A = 0, ATECC108A = 1, ATECC508A = 2, ATECC608A = 3,
    ATECC608B = 3, ATECC608 = 3, ATSHA206A = 4, TA100 = 0x10,
    ATCA_DEV_UNKNOWN = 0x20 }
```

The supported Device type in Cryptoauthlib library.

### 20.28.1 Detailed Description

Microchip Crypto Auth.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.29 atca hal.c File Reference

low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation.

```
#include "cryptoauthlib.h"
#include "atca_hal.h"
```

### **Functions**

- ATCA\_STATUS hal\_iface\_register\_hal (ATCAlfaceType iface\_type, ATCAHAL\_t \*hal, ATCAHAL\_t \*\*old)
   Register/Replace a HAL with a.
- ATCA\_STATUS hal\_iface\_init (ATCAlfaceCfg \*cfg, ATCAHAL\_t \*\*hal)

Standard HAL API for ATCA to initialize a physical interface.

- ATCA STATUS hal iface release (ATCAlfaceType iface type, void \*hal data)
  - releases a physical interface, HAL knows how to interpret hal\_data
- ATCA\_STATUS hal\_check\_wake (const uint8\_t \*response, int response\_size)

Utility function for hal wake to check the reply.

### 20.29.1 Detailed Description

low-level HAL - methods used to setup indirection to physical layer interface. this level does the dirty work of abstracting the higher level ATCAlFace methods from the low-level physical interfaces. Its main goal is to keep low-level details from bleeding into the logical interface implementation.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.30 atca\_hal.h File Reference

low-level HAL - methods used to setup indirection to physical layer interface

```
#include <stdlib.h>
#include "atca_config.h"
#include "atca_status.h"
#include "atca_iface.h"
#include "atca_start_config.h"
#include "atca_start_iface.h"
```

### **Data Structures**

struct ATCAHAL t

an intermediary data structure to allow the HAL layer to point the standard API functions used by the upper layers to the HAL implementation for the interface. This isolates the upper layers and loosely couples the ATCAlface object from the physical implementation.

#### **Macros**

- #define ATCA POLLING INIT TIME MSEC 1
- #define ATCA POLLING FREQUENCY TIME MSEC 2
- #define ATCA\_POLLING\_MAX\_TIME\_MSEC 2500
- #define hal\_memset\_s atcab\_memset\_s

### **Functions**

ATCA\_STATUS hal\_iface\_init (ATCAlfaceCfg \*, ATCAHAL\_t \*\*hal)

Standard HAL API for ATCA to initialize a physical interface.

ATCA\_STATUS hal\_iface\_release (ATCAlfaceType, void \*hal\_data)

releases a physical interface, HAL knows how to interpret hal\_data

• ATCA\_STATUS hal\_check\_wake (const uint8\_t \*response, int response\_size)

Utility function for hal wake to check the reply.

void atca\_delay\_ms (uint32\_t ms)

Timer API for legacy implementations.

void atca\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

· void hal rtos delay ms (uint32 t ms)

Timer API implemented at the HAL level.

void hal\_delay\_ms (uint32\_t delay)

This function delays for a number of milliseconds.

void hal delay us (uint32 t delay)

This function delays for a number of microseconds.

ATCA\_STATUS hal\_create\_mutex (void \*\*ppMutex, char \*pName)

Optional hal interfaces.

- ATCA\_STATUS hal\_destroy\_mutex (void \*pMutex)
- ATCA STATUS hal lock mutex (void \*pMutex)
- ATCA\_STATUS hal\_unlock\_mutex (void \*pMutex)
- void \* hal\_malloc (size\_t size)
- void hal\_free (void \*ptr)
- ATCA\_STATUS hal\_iface\_register\_hal (ATCAlfaceType iface\_type, ATCAHAL\_t \*hal, ATCAHAL\_t \*\*old)
   Register/Replace a HAL with a.

#### 20.30.1 Detailed Description

low-level HAL - methods used to setup indirection to physical layer interface

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.31 atca\_helpers.c File Reference

Helpers to support the CryptoAuthLib Basic API methods.

```
#include <stdlib.h>
#include <stdio.h>
#include <ctype.h>
#include "cryptoauthlib.h"
#include "atca_helpers.h"
```

#### **Macros**

- #define B64 IS EQUAL (uint8 t)64
- #define B64\_IS\_INVALID (uint8\_t)0xFF

#### **Functions**

- ATCA\_STATUS atcab\_bin2hex (const uint8\_t \*bin, size\_t bin\_size, char \*hex, size\_t \*hex\_size)

  Convert a binary buffer to a hex string for easy reading.
- ATCA\_STATUS atcab\_reversal (const uint8\_t \*bin, size\_t bin\_size, uint8\_t \*dest, size\_t \*dest\_size)
   To reverse the input data.
- ATCA\_STATUS atcab\_bin2hex\_ (const uint8\_t \*bin, size\_t bin\_size, char \*hex, size\_t \*hex\_size, bool is\_
  pretty, bool is\_space, bool is\_upper)

Function that converts a binary buffer to a hex string suitable for easy reading.

- ATCA\_STATUS atcab\_hex2bin (const char \*hex, size\_t hex\_size, uint8\_t \*bin, size\_t \*bin\_size)

Function that converts a hex string to binary buffer.

bool isDigit (char c)

Checks to see if a character is an ASCII representation of a digit ((c ge '0') and (c le '9'))

bool isWhiteSpace (char c)

Checks to see if a character is whitespace.

• bool isAlpha (char c)

Checks to see if a character is an ASCII representation of hex ((c >= 'A')) and (c <= 'F') | ((c >= 'a')) and (c <= 'f')

• bool isHexAlpha (char c)

Checks to see if a character is an ASCII representation of hex ((c >= 'A')) and (c <= 'F') || ((c >= 'a')) and (c <= 'f')

• bool isHex (char c)

Returns true if this character is a valid hex character or if this is whitespace (The character can be included in a valid hexstring).

bool isHexDigit (char c)

Returns true if this character is a valid hex character.

ATCA\_STATUS packHex (const char \*ascii\_hex, size\_t ascii\_hex\_len, char \*packed\_hex, size\_t \*packed
len)

Remove white space from a ASCII hex string.

• bool isBase64 (char c, const uint8\_t \*rules)

Returns true if this character is a valid base 64 character or if this is whitespace (A character can be included in a valid base 64 string).

bool isBase64Digit (char c, const uint8\_t \*rules)

Returns true if this character is a valid base 64 character.

uint8\_t base64Index (char c, const uint8\_t \*rules)

Returns the base 64 index of the given character.

char base64Char (uint8\_t id, const uint8\_t \*rules)

Returns the base 64 character of the given index.

ATCA\_STATUS atcab\_base64decode\_ (const char \*encoded, size\_t encoded\_size, uint8\_t \*data, size\_t
 \*data size, const uint8 t \*rules)

Decode base64 string to data with ruleset option.

ATCA\_STATUS atcab\_base64encode\_ (const uint8\_t \*data, size\_t data\_size, char \*encoded, size\_
 t \*encoded\_size, const uint8\_t \*rules)

Encode data as base64 string with ruleset option.

ATCA\_STATUS atcab\_base64encode (const uint8\_t \*byte\_array, size\_t array\_len, char \*encoded, size\_t \*encoded len)

Encode data as base64 string.

ATCA\_STATUS atcab\_base64decode (const char \*encoded, size\_t encoded\_len, uint8\_t \*byte\_array, size
 \_t \*array\_len)

Decode base64 string to data.

int atcab\_memset\_s (void \*dest, size\_t destsz, int ch, size\_t count)

Guaranteed to perform memory writes regardless of optimization level. Matches memset\_s signature.

### **Variables**

```
uint8_t atcab_b64rules_default [4] = { '+', '/', '=', 64 }
uint8_t atcab_b64rules_mime [4] = { '+', '/', '=', 76 }
uint8_t atcab_b64rules_urlsafe [4] = { '-', '_', 0, 0 }
```

### 20.31.1 Detailed Description

Helpers to support the CryptoAuthLib Basic API methods.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.31.2 Macro Definition Documentation

```
20.31.2.1 B64_IS_EQUAL
```

```
#define B64_IS_EQUAL (uint8_t)64
```

### 20.31.2.2 B64\_IS\_INVALID

```
#define B64_IS_INVALID (uint8_t)0xFF
```

### 20.31.3 Function Documentation

### 20.31.3.1 atcab\_base64decode()

Decode base64 string to data.

#### **Parameters**

| in     | encoded                                                                                    | Base64 string to be decoded. |  |
|--------|--------------------------------------------------------------------------------------------|------------------------------|--|
| in     | encoded_len Size of the base64 string in bytes.                                            |                              |  |
| out    | byte_array Decoded data will be returned here.                                             |                              |  |
| in,out | array_len As input, the size of the byte_array buffer. As output, the length of the decode |                              |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.31.3.2 atcab\_base64decode\_()

Decode base64 string to data with ruleset option.

### **Parameters**

| in     | encoded                                          | ncoded Base64 string to be decoded.                                                   |  |
|--------|--------------------------------------------------|---------------------------------------------------------------------------------------|--|
| in     | encoded_size Size of the base64 string in bytes. |                                                                                       |  |
| out    | data                                             | Decoded data will be returned here.                                                   |  |
| in,out | data_size                                        | As input, the size of the byte_array buffer. As output, the length of the decoded de- |  |
| in     | rules                                            | base64 ruleset to use                                                                 |  |

### 20.31.3.3 atcab\_base64encode()

Encode data as base64 string.

### **Parameters**

| in               | byte_array Data to be encode in base64. |                                                                                |     |
|------------------|-----------------------------------------|--------------------------------------------------------------------------------|-----|
| in               | array_len                               | Size of byte_array in bytes.                                                   |     |
| in               | encoded                                 | Base64 output is returned here.                                                |     |
| in,out           | encoded_len                             | As input, the size of the encoded buffer. As output, the length of the encoded |     |
| © 2020 Microchip | Technology Inc                          | base64 character string.                                                       | 594 |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.31.3.4 atcab\_base64encode\_()

Encode data as base64 string with ruleset option.

#### **Parameters**

| in     | data         | [in] The input byte array that will be converted to base 64 encoded characters   |  |
|--------|--------------|----------------------------------------------------------------------------------|--|
| in     | data_size    | [in] The length of the byte array                                                |  |
| in     | encoded      | [in] The output converted to base 64 encoded characters.                         |  |
| in,out | encoded_size | [inout] Input: The size of the encoded buffer, Output: The length of the encoded |  |
|        |              | base 64 character string                                                         |  |
| in     | rules        | [in] ruleset to use during encoding                                              |  |

### 20.31.3.5 atcab\_bin2hex()

Convert a binary buffer to a hex string for easy reading.

#### **Parameters**

| in     | bin      | Input data to convert.                                                  |  |
|--------|----------|-------------------------------------------------------------------------|--|
| in     | bin_size | _size Size of data to convert.                                          |  |
| out    | hex      | Buffer that receives hex string.                                        |  |
| in,out | hex_size | As input, the size of the hex buffer. As output, the size of the output |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.31.3.6 atcab\_bin2hex\_()

Function that converts a binary buffer to a hex string suitable for easy reading.

#### **Parameters**

| in     | bin       | Input data to convert.                                                               |  |
|--------|-----------|--------------------------------------------------------------------------------------|--|
| in     | bin_size  | Size of data to convert.                                                             |  |
| out    | hex       | Buffer that receives hex string.                                                     |  |
| in,out | hex_size  | hex_size As input, the size of the hex buffer. As output, the size of the output hex |  |
| in     | is_pretty | pretty Indicates whether new lines should be added for pretty printing.              |  |
| in     | is_space  | ace Convert the output hex with space between it.                                    |  |
| in     | is_upper  | Convert the output hex to upper case.                                                |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.31.3.7 atcab\_hex2bin()

Function that converts a hex string to binary buffer.

#### **Parameters**

| in     | hex Input buffer to convert |                                                                         |  |
|--------|-----------------------------|-------------------------------------------------------------------------|--|
| in     | hex_size                    | nex_size Length of buffer to convert                                    |  |
| out    | bin                         | bin Buffer that receives binary                                         |  |
| in,out | bin_size                    | As input, the size of the bin buffer. As output, the size of the bin da |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.31.3.8 atcab\_hex2bin\_()

### 20.31.3.9 atcab\_memset\_s()

```
int atcab_memset_s (
    void * dest,
    size_t destsz,
    int ch,
    size_t count )
```

Guaranteed to perform memory writes regardless of optimization level. Matches memset\_s signature.

### 20.31.3.10 atcab\_reversal()

To reverse the input data.

#### **Parameters**

| in  | bin       | Input data to reverse.                |
|-----|-----------|---------------------------------------|
| in  | bin_size  | Size of data to reverse.              |
| out | dest      | Buffer to store reversed binary data. |
| in  | dest_size | The size of the dest buffer.          |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.31.3.11 base64Char()

```
char base64Char (  \mbox{uint8\_t } id, \\ \mbox{const uint8\_t } * rules \; ) \label{eq:char_loss}
```

Returns the base 64 character of the given index.

#### **Parameters**

| in | id    | index to check        |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

#### Returns

the base 64 character of the given index

### 20.31.3.12 base64Index()

```
uint8_t base64Index ( \label{charc} \mbox{char $c$,} \\ \mbox{const uint8\_t * $rules$ )}
```

Returns the base 64 index of the given character.

#### **Parameters**

| in | С     | character to check    |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

### Returns

the base 64 index of the given character

### 20.31.3.13 isAlpha()

```
bool isAlpha (
```

Checks to see if a character is an ASCII representation of hex ((c >= 'A') and (c <= 'F')) || ((c >= 'a') and (c <= 'f'))

#### **Parameters**

| in | С | character to check |
|----|---|--------------------|

### Returns

True if the character is a hex

### 20.31.3.14 isBase64()

```
bool isBase64 ( \label{charc} \mbox{char}\ c, \mbox{const uint8\_t * rules}\ )
```

Returns true if this character is a valid base 64 character or if this is whitespace (A character can be included in a valid base 64 string).

#### **Parameters**

| in | С     | character to check    |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

#### **Returns**

True if the character can be included in a valid base 64 string

### 20.31.3.15 isBase64Digit()

```
bool isBase64Digit ( \label{eq:charc} \mbox{char}\ c, \\ \mbox{const uint8\_t}\ *\ rules\ )
```

Returns true if this character is a valid base 64 character.

#### **Parameters**

| in | С     | character to check    |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

## Returns

True if the character can be included in a valid base 64 string

#### 20.31.3.16 isDigit()

```
bool is
Digit ( {\tt char}\ c\ )
```

Checks to see if a character is an ASCII representation of a digit ((c ge '0') and (c le '9'))

### **Parameters**

| in | c | character to check |
|----|---|--------------------|

#### Returns

True if the character is a digit

### 20.31.3.17 isHex()

```
bool is
Hex ( $\operatorname{char}\ c )
```

Returns true if this character is a valid hex character or if this is whitespace (The character can be included in a valid hexstring).

#### **Parameters**

```
in c character to check
```

#### Returns

True if the character can be included in a valid hexstring

### 20.31.3.18 isHexAlpha()

```
bool isHexAlpha ( {\tt char}\ c\ )
```

Checks to see if a character is an ASCII representation of hex ((c >= 'A') and (c <= 'F')) || ((c >= 'a') and (c <= 'f'))

### **Parameters**

| ın | C | character to check |
|----|---|--------------------|

## Returns

True if the character is a hex

### 20.31.3.19 isHexDigit()

```
bool isHexDigit ( {\tt char}\ c\ )
```

Returns true if this character is a valid hex character.

#### **Parameters**

| in c character to c | check |
|---------------------|-------|
|---------------------|-------|

### Returns

True if the character can be included in a valid hexstring

## 20.31.3.20 isWhiteSpace()

```
bool isWhiteSpace ( {\tt char}\ c\ )
```

Checks to see if a character is whitespace.

#### **Parameters**

| in $oldsymbol{c}$ | character to check |
|-------------------|--------------------|
|-------------------|--------------------|

#### Returns

True if the character is whitespace

### 20.31.3.21 packHex()

Remove white space from a ASCII hex string.

### **Parameters**

| in     | ascii_hex     | Initial hex string to remove white space from                               |
|--------|---------------|-----------------------------------------------------------------------------|
| in     | ascii_hex_len | Length of the initial hex string                                            |
| in     | packed_hex    | Resulting hex string without white space                                    |
| in,out | packed_len    | In: Size to packed_hex buffer Out: Number of bytes in the packed hex string |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.31.4 Variable Documentation

### 20.31.4.1 atcab\_b64rules\_default

```
uint8_t atcab_b64rules_default[4] = { '+', '/', '=', 64 }
```

#### 20.31.4.2 atcab b64rules mime

```
uint8_t atcab_b64rules_mime[4] = { '+', '/', '=', 76 }
```

#### 20.31.4.3 atcab b64rules urlsafe

```
uint8_t atcab_b64rules_urlsafe[4] = { '-', '_', 0, 0 }
```

## 20.32 atca helpers.h File Reference

Helpers to support the CryptoAuthLib Basic API methods.

```
#include "cryptoauthlib.h"
```

- SHARED\_LIB\_IMPORT uint8\_t atcab\_b64rules\_default [4]
- SHARED\_LIB\_IMPORT uint8\_t atcab\_b64rules\_mime [4]
- SHARED\_LIB\_IMPORT uint8\_t atcab\_b64rules\_urlsafe [4]
- ATCA STATUS atcab printbin (uint8 t \*binary, size t bin len, bool add space)
- ATCA STATUS atcab bin2hex (const uint8 t \*bin, size t bin size, char \*hex, size t \*hex size)

Convert a binary buffer to a hex string for easy reading.

ATCA\_STATUS atcab\_bin2hex\_ (const uint8\_t \*bin, size\_t bin\_size, char \*hex, size\_t \*hex\_size, bool is\_
 pretty, bool is\_space, bool is\_upper)

Function that converts a binary buffer to a hex string suitable for easy reading.

- ATCA\_STATUS atcab\_hex2bin (const char \*ascii\_hex, size\_t ascii\_hex\_len, uint8\_t \*binary, size\_t \*bin\_len) Function that converts a hex string to binary buffer.
- ATCA\_STATUS atcab\_printbin\_sp (uint8\_t \*binary, size\_t bin\_len)
- ATCA STATUS atcab printbin label (const char \*label, uint8 t \*binary, size t bin len)
- ATCA\_STATUS packHex (const char \*ascii\_hex, size\_t ascii\_hex\_len, char \*packed\_hex, size\_t \*packed 
   \_\_len)

Remove white space from a ASCII hex string.

bool isDigit (char c)

Checks to see if a character is an ASCII representation of a digit ((c ge '0') and (c le '9'))

• bool isWhiteSpace (char c)

Checks to see if a character is whitespace.

bool isAlpha (char c)

Checks to see if a character is an ASCII representation of hex ((c >= 'A')) and  $(c <= 'F')) \mid ((c >= 'a'))$  and (c <= 'f'))

bool isHexAlpha (char c)

Checks to see if a character is an ASCII representation of hex ((c >= 'A') and  $(c <= 'F')) \mid ((c >= 'a')$  and (c <= 'f')

bool isHex (char c)

Returns true if this character is a valid hex character or if this is whitespace (The character can be included in a valid hexstring).

bool isHexDigit (char c)

Returns true if this character is a valid hex character.

bool isBase64 (char c, const uint8\_t \*rules)

Returns true if this character is a valid base 64 character or if this is whitespace (A character can be included in a valid base 64 string).

bool isBase64Digit (char c, const uint8 t \*rules)

Returns true if this character is a valid base 64 character.

uint8\_t base64Index (char c, const uint8\_t \*rules)

Returns the base 64 index of the given character.

• char base64Char (uint8 t id, const uint8 t \*rules)

Returns the base 64 character of the given index.

ATCA\_STATUS atcab\_base64decode\_ (const char \*encoded, size\_t encoded\_size, uint8\_t \*data, size\_t \*data\_size, const uint8\_t \*rules)

Decode base64 string to data with ruleset option.

ATCA\_STATUS atcab\_base64decode (const char \*encoded, size\_t encoded\_size, uint8\_t \*data, size\_
 t \*data\_size)

Decode base64 string to data.

• ATCA\_STATUS atcab\_base64encode\_ (const uint8\_t \*data, size\_t data\_size, char \*encoded, size\_← t \*encoded\_size, const uint8\_t \*rules)

Encode data as base64 string with ruleset option.

ATCA\_STATUS atcab\_base64encode (const uint8\_t \*data, size\_t data\_size, char \*encoded, size\_
 t \*encoded\_size)

Encode data as base64 string.

• ATCA\_STATUS atcab\_reversal (const uint8\_t \*bin, size\_t bin\_size, uint8\_t \*dest, size\_t \*dest\_size)

To reverse the input data.

• int atcab\_memset\_s (void \*dest, size\_t destsz, int ch, size\_t count)

Guaranteed to perform memory writes regardless of optimization level. Matches memset\_s signature.

### 20.32.1 Detailed Description

Helpers to support the CryptoAuthLib Basic API methods.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.32.2 Function Documentation

### 20.32.2.1 atcab\_base64decode()

Decode base64 string to data.

#### **Parameters**

| in     | encoded     | Base64 string to be decoded.                                                            |
|--------|-------------|-----------------------------------------------------------------------------------------|
| in     | encoded_len | Size of the base64 string in bytes.                                                     |
| out    | byte_array  | Decoded data will be returned here.                                                     |
| in,out | array_len   | As input, the size of the byte_array buffer. As output, the length of the decoded data. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.2 atcab\_base64decode\_()

Decode base64 string to data with ruleset option.

#### **Parameters**

| in     | encoded      | Base64 string to be decoded.                                                            |
|--------|--------------|-----------------------------------------------------------------------------------------|
| in     | encoded_size | Size of the base64 string in bytes.                                                     |
| out    | data         | Decoded data will be returned here.                                                     |
| in,out | data_size    | As input, the size of the byte_array buffer. As output, the length of the decoded data. |
| in     | rules        | base64 ruleset to use                                                                   |

### 20.32.2.3 atcab\_base64encode()

```
char * encoded,
size_t * encoded_len )
```

### Encode data as base64 string.

#### **Parameters**

| in     | byte_array  | Data to be encode in base64.                                                                            |
|--------|-------------|---------------------------------------------------------------------------------------------------------|
| in     | array_len   | Size of byte_array in bytes.                                                                            |
| in     | encoded     | Base64 output is returned here.                                                                         |
| in,out | encoded_len | As input, the size of the encoded buffer. As output, the length of the encoded base64 character string. |
|        |             | bases i sharaster string.                                                                               |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.4 atcab\_base64encode\_()

Encode data as base64 string with ruleset option.

### 20.32.2.5 atcab\_bin2hex()

Convert a binary buffer to a hex string for easy reading.

## **Parameters**

| in     | bin      | Input data to convert.                                                       |
|--------|----------|------------------------------------------------------------------------------|
| in     | bin_size | Size of data to convert.                                                     |
| out    | hex      | Buffer that receives hex string.                                             |
| in,out | hex_size | As input, the size of the hex buffer. As output, the size of the output hex. |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 606

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.6 atcab\_bin2hex\_()

Function that converts a binary buffer to a hex string suitable for easy reading.

### **Parameters**

| in     | bin       | Input data to convert.                                                       |
|--------|-----------|------------------------------------------------------------------------------|
| in     | bin_size  | Size of data to convert.                                                     |
| out    | hex       | Buffer that receives hex string.                                             |
| in,out | hex_size  | As input, the size of the hex buffer. As output, the size of the output hex. |
| in     | is_pretty | Indicates whether new lines should be added for pretty printing.             |
| in     | is_space  | Convert the output hex with space between it.                                |
| in     | is_upper  | Convert the output hex to upper case.                                        |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.7 atcab\_hex2bin()

Function that converts a hex string to binary buffer.

#### **Parameters**

| in     | hex      | Input buffer to convert                                                    |
|--------|----------|----------------------------------------------------------------------------|
| in     | hex_size | Length of buffer to convert                                                |
| out    | bin      | Buffer that receives binary                                                |
| in,out | bin_size | As input, the size of the bin buffer. As output, the size of the bin data. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.8 atcab\_hex2bin\_()

### 20.32.2.9 atcab\_memset\_s()

```
int atcab_memset_s (
     void * dest,
     size_t destsz,
     int ch,
     size_t count )
```

Guaranteed to perform memory writes regardless of optimization level. Matches memset\_s signature.

### 20.32.2.10 atcab\_printbin\_label()

### 20.32.2.11 atcab\_printbin\_sp()

### 20.32.2.12 atcab\_reversal()

To reverse the input data.

### **Parameters**

| in  | bin       | Input data to reverse.                |
|-----|-----------|---------------------------------------|
| in  | bin_size  | Size of data to reverse.              |
| out | dest      | Buffer to store reversed binary data. |
| in  | dest_size | The size of the dest buffer.          |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.2.13 base64Char()

```
char base64Char (  \mbox{uint8\_t } id, \\ \mbox{const uint8\_t } * rules \mbox{)}
```

Returns the base 64 character of the given index.

### **Parameters**

| in | id    | index to check        |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

### Returns

the base 64 character of the given index

## 20.32.2.14 base64Index()

Returns the base 64 index of the given character.

#### **Parameters**

|   | in | С     | character to check    |
|---|----|-------|-----------------------|
| ſ | in | rules | base64 ruleset to use |

### Returns

the base 64 index of the given character

### 20.32.2.15 isAlpha()

```
bool isAlpha ( {\tt char}\ c\ )
```

Checks to see if a character is an ASCII representation of hex ((c >= 'A') and (c <= 'F')) || ((c >= 'a') and (c <= 'f'))

#### **Parameters**

| in c charac | ter to check |
|-------------|--------------|
|-------------|--------------|

#### Returns

True if the character is a hex

### 20.32.2.16 isBase64()

```
bool isBase64 ( \label{charc} \mbox{char}\ c, \mbox{const uint8\_t * rules}\ )
```

Returns true if this character is a valid base 64 character or if this is whitespace (A character can be included in a valid base 64 string).

#### **Parameters**

| in | С     | character to check    |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

## Returns

True if the character can be included in a valid base 64 string

### 20.32.2.17 isBase64Digit()

```
bool isBase64Digit ( \label{eq:char} \operatorname{char}\ c, \operatorname{const}\ \operatorname{uint8\_t}\ *\ rules\ )
```

Returns true if this character is a valid base 64 character.

#### **Parameters**

| in | С     | character to check    |
|----|-------|-----------------------|
| in | rules | base64 ruleset to use |

#### Returns

True if the character can be included in a valid base 64 string

### 20.32.2.18 isDigit()

```
bool isDigit ( {\tt char}\ c\ )
```

Checks to see if a character is an ASCII representation of a digit ((c ge '0') and (c le '9'))

### **Parameters**

#### Returns

True if the character is a digit

### 20.32.2.19 isHex()

```
bool is
Hex ( $\operatorname{char}\ c )
```

Returns true if this character is a valid hex character or if this is whitespace (The character can be included in a valid hexstring).

### **Parameters**

| in $c$ | character to check |
|--------|--------------------|
|--------|--------------------|

## Returns

True if the character can be included in a valid hexstring

### 20.32.2.20 isHexAlpha()

```
bool isHexAlpha ( {\tt char}\ c\ )
```

Checks to see if a character is an ASCII representation of hex ((c >= 'A') and (c <= 'F')) || ((c >= 'a') and (c <= 'f'))

### **Parameters**

```
in c character to check
```

### Returns

True if the character is a hex

### 20.32.2.21 isHexDigit()

```
bool isHexDigit ( {\tt char}\ c\ )
```

Returns true if this character is a valid hex character.

### **Parameters**

| in | С | character to check |
|----|---|--------------------|
|----|---|--------------------|

### Returns

True if the character can be included in a valid hexstring

### 20.32.2.22 isWhiteSpace()

```
bool isWhiteSpace ( {\tt char}\ c\ )
```

Checks to see if a character is whitespace.

### **Parameters**

| in | С | character to check |
|----|---|--------------------|

### Returns

True if the character is whitespace

### 20.32.2.23 packHex()

Remove white space from a ASCII hex string.

#### **Parameters**

| in     | ascii_hex     | Initial hex string to remove white space from                               |  |
|--------|---------------|-----------------------------------------------------------------------------|--|
| in     | ascii_hex_len | Length of the initial hex string                                            |  |
| in     | packed_hex    | Resulting hex string without white space                                    |  |
| in,out | packed_len    | In: Size to packed_hex buffer Out: Number of bytes in the packed hex string |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.32.3 Variable Documentation

### 20.32.3.1 atcab\_b64rules\_default

```
SHARED_LIB_IMPORT uint8_t atcab_b64rules_default[4]
```

### 20.32.3.2 atcab\_b64rules\_mime

```
SHARED_LIB_IMPORT uint8_t atcab_b64rules_mime[4]
```

### 20.32.3.3 atcab\_b64rules\_urlsafe

SHARED\_LIB\_IMPORT uint8\_t atcab\_b64rules\_urlsafe[4]

# 20.33 atca host.c File Reference

Host side methods to support CryptoAuth computations.

```
#include "atca_host.h"
#include "crypto/atca_crypto_sw_sha2.h"
```

#### **Functions**

uint8\_t \* atcah\_include\_data (struct atca\_include\_data\_in\_out \*param)

This function copies otp and sn data into a command buffer.

ATCA\_STATUS atcah\_nonce (struct atca\_nonce\_in\_out \*param)

This function calculates host side nonce with the parameters passed.

ATCA\_STATUS atcah\_io\_decrypt (struct atca\_io\_decrypt\_in\_out \*param)

Decrypt data that's been encrypted by the IO protection key. The ECDH and KDF commands on the ATECC608 are the only ones that support this operation.

ATCA\_STATUS atcah\_verify\_mac (atca\_verify\_mac\_in\_out\_t \*param)

Calculate the expected MAC on the host side for the Verify command.

ATCA\_STATUS atcah\_secureboot\_enc (atca\_secureboot\_enc\_in\_out\_t \*param)

Encrypts the digest for the SecureBoot command when using the encrypted digest / validating mac option.

ATCA\_STATUS atcah\_secureboot\_mac (atca\_secureboot\_mac\_in\_out\_t \*param)

Calculates the expected MAC returned from the SecureBoot command when verification is a success.

ATCA\_STATUS atcah\_mac (struct atca\_mac\_in\_out \*param)

This function generates an SHA-256 digest (MAC) of a key, challenge, and other information.

ATCA\_STATUS atcah\_check\_mac (struct atca\_check\_mac\_in\_out \*param)

This function performs the checkmac operation to generate client response on the host side .

ATCA STATUS atcah hmac (struct atca hmac in out \*param)

This function generates an HMAC / SHA-256 hash of a key and other information.

ATCA\_STATUS atcah\_gen\_dig (struct atca\_gen\_dig\_in\_out \*param)

This function combines the current TempKey with a stored value.

ATCA\_STATUS atcah\_gen\_mac (struct atca\_gen\_dig\_in\_out \*param)

This function generates mac with session key with a plain text.

ATCA\_STATUS atcah\_write\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the Write command.

ATCA\_STATUS atcah\_privwrite\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the PrivWrite command.

ATCA\_STATUS atcah\_derive\_key (struct atca\_derive\_key\_in\_out \*param)

This function derives a key with a key and TempKey.

• ATCA STATUS atcah derive key mac (struct atca derive key mac in out \*param)

This function calculates the input MAC for a DeriveKey command.

ATCA\_STATUS atcah\_decrypt (struct atca\_decrypt\_in\_out \*param)

This function decrypts 32-byte encrypted data received with the Read command.

ATCA STATUS atcah sha256 (int32 t len, const uint8 t \*message, uint8 t \*digest)

This function creates a SHA256 digest on a little-endian system.

ATCA\_STATUS atcah\_gen\_key\_msg (struct atca\_gen\_key\_in\_out \*param)

Calculate the PubKey digest created by GenKey and saved to TempKey.

 ATCA\_STATUS atcah\_config\_to\_sign\_internal (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param, const uint8\_t \*config)

Populate the slot\_config, key\_config, and is\_slot\_locked fields in the atca\_sign\_internal\_in\_out structure from the provided config zone.

 ATCA\_STATUS atcah\_sign\_internal\_msg (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param)

Builds the full message that would be signed by the Sign(Internal) command.

• ATCA\_STATUS atcah\_encode\_counter\_match (uint32\_t counter\_value, uint8\_t \*counter\_match\_value)

Builds the counter match value that needs to be stored in a slot.

# 20.33.1 Detailed Description

Host side methods to support CryptoAuth computations.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.34 atca host.h File Reference

Definitions and Prototypes for ATCA Utility Functions.

```
#include <stdint.h>
#include "cryptoauthlib.h"
#include "calib/calib_basic.h"
```

#### **Data Structures**

```
    struct atca_temp_key
```

Structure to hold TempKey fields.

· struct atca include data in out

 ${\it Input / output \ parameters \ for \ function \ atca\_include\_data()}.$ 

struct atca\_nonce\_in\_out

Input/output parameters for function atca\_nonce().

- struct atca\_io\_decrypt\_in\_out
- struct atca\_verify\_mac
- struct atca\_secureboot\_enc\_in\_out
- struct atca\_secureboot\_mac\_in\_out
- struct atca\_mac\_in\_out

 ${\it Input/output\ parameters\ for\ function\ atca\_mac()}.$ 

• struct atca\_hmac\_in\_out

Input/output parameters for function atca\_hmac().

struct atca\_gen\_dig\_in\_out

Input/output parameters for function atcah\_gen\_dig().

· struct atca write mac in out

Input/output parameters for function atcah\_write\_auth\_mac() and atcah\_privwrite\_auth\_mac().

struct atca\_derive\_key\_in\_out

Input/output parameters for function atcah\_derive\_key().

· struct atca derive key mac in out

Input/output parameters for function atcah\_derive\_key\_mac().

struct atca\_decrypt\_in\_out

Input/output parameters for function atca\_decrypt().

· struct atca\_check\_mac\_in\_out

Input/output parameters for function atcah\_check\_mac().

· struct atca verify in out

Input/output parameters for function atcah\_verify().

struct atca\_gen\_key\_in\_out

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the atcah gen key msg() function.

· struct atca sign internal in out

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the <a href="atcah\_sign\_internal\_msg">atcah\_sign\_internal\_msg</a>() function.

#### **Macros**

#### **Definitions for ATECC Message Sizes to Calculate a SHA256 Hash**

"||" is the concatenation operator. The number in braces is the length of the hash input value in bytes.

```
    #define ATCA_MSG_SIZE_NONCE (55)
```

RandOut{32} || NumIn{20} || OpCode{1} || Mode{1} || LSB of Param2{1}.

• #define ATCA\_MSG\_SIZE\_MAC (88)

 $\begin{tabular}{ll} $$(Key\ or\ TempKey)\{32\} \mid\mid (Challenge\ or\ TempKey)\{32\} \mid\mid OpCode\{1\} \mid\mid Mode\{1\} \mid\mid Param2\{2\} \mid\mid (OTP0\_7\ or\ 0)\{8\} \mid\mid (OTP8\_10\ or\ 0)\{3\} \mid\mid SN8\{1\} \mid\mid (SN4\_7\ or\ 0)\{4\} \mid\mid SN0\_1\{2\} \mid\mid (SN2\_3\ or\ 0)\{2\} \end{tabular}$ 

- #define ATCA\_MSG\_SIZE\_HMAC (88)
- #define ATCA MSG SIZE GEN DIG (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0\_1{2} || 0{25} || TempKey{32}.

• #define ATCA\_MSG\_SIZE\_DERIVE\_KEY (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0\_1{2} || 0{25} || TempKey{32}.

• #define ATCA MSG SIZE DERIVE KEY MAC (39)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2} || SN8{1} || SN0\_1{2}.

#define ATCA\_MSG\_SIZE\_ENCRYPT\_MAC (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2}|| SN8{1} || SN0\_1{2} || 0{25} || TempKey{32}.

• #define ATCA\_MSG\_SIZE\_PRIVWRITE\_MAC (96)

Keyld{32} || OpCode{1} || Param1{1} || Param2{2}|| SN8{1} || SN0\_1{2} || 0{21} || PlainText{36}.

- #define ATCA COMMAND HEADER SIZE (4)
- #define ATCA\_GENDIG\_ZEROS\_SIZE (25)
- #define ATCA\_WRITE\_MAC\_ZEROS\_SIZE (25)
- #define ATCA PRIVWRITE MAC ZEROS SIZE (21)
- #define ATCA\_PRIVWRITE\_PLAIN\_TEXT\_SIZE (36)
- #define ATCA\_DERIVE\_KEY\_ZEROS\_SIZE (25)
- #define ATCA\_HMAC\_BLOCK\_SIZE (64)
- #define ENCRYPTION\_KEY\_SIZE (64)

#### Default Fixed Byte Values of Serial Number (SN[0:1] and SN[8])

- #define ATCA\_SN\_0\_DEF (0x01)
- #define ATCA\_SN\_1\_DEF (0x23)
- #define ATCA\_SN\_8\_DEF (0xEE)

#### **Definition for TempKey Mode**

#define MAC\_MODE\_USE\_TEMPKEY\_MASK ((uint8\_t)0x03)
 mode mask for MAC command when using TempKey

# **Typedefs**

typedef struct atca\_temp\_key atca\_temp\_key\_t

Structure to hold TempKey fields.

- typedef struct atca nonce in out atca nonce in out t
- typedef struct atca io decrypt in out atca io decrypt in out t
- typedef struct atca\_verify\_mac atca\_verify\_mac\_in\_out\_t
- typedef struct atca\_secureboot\_enc\_in\_out atca\_secureboot\_enc\_in\_out\_t
- · typedef struct atca secureboot mac in out atca secureboot mac in out t
- · typedef struct atca mac in out atca mac in out t
- typedef struct atca gen dig in out atca gen dig in out t

Input/output parameters for function atcah\_gen\_dig().

typedef struct atca\_write\_mac\_in\_out atca\_write\_mac\_in\_out\_t

Input/output parameters for function atcah write auth mac() and atcah privwrite auth mac().

typedef struct atca\_check\_mac\_in\_out atca\_check\_mac\_in\_out\_t

Input/output parameters for function atcah check mac().

- typedef struct atca\_verify\_in\_out atca\_verify\_in\_out\_t
- typedef struct atca\_gen\_key\_in\_out atca\_gen\_key\_in\_out\_t

Input/output parameters for calculating the PubKey digest put into TempKey by the GenKey command with the atcah\_gen\_key\_msg() function.

typedef struct atca\_sign\_internal\_in\_out atca\_sign\_internal\_in\_out\_t

Input/output parameters for calculating the message and digest used by the Sign(internal) command. Used with the atcah\_sign\_internal\_msg() function.

#### **Functions**

ATCA STATUS atcah nonce (struct atca nonce in out \*param)

This function calculates host side nonce with the parameters passed.

ATCA\_STATUS atcah\_mac (struct atca\_mac\_in\_out \*param)

This function generates an SHA-256 digest (MAC) of a key, challenge, and other information.

ATCA\_STATUS atcah\_check\_mac (struct atca\_check\_mac\_in\_out \*param)

This function performs the checkmac operation to generate client response on the host side .

ATCA\_STATUS atcah\_hmac (struct atca\_hmac\_in\_out \*param)

This function generates an HMAC / SHA-256 hash of a key and other information.

ATCA\_STATUS atcah\_gen\_dig (struct atca\_gen\_dig\_in\_out \*param)

This function combines the current TempKey with a stored value.

• ATCA\_STATUS atcah\_gen\_mac (struct atca\_gen\_dig\_in\_out \*param)

This function generates mac with session key with a plain text.

ATCA\_STATUS atcah\_write\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the Write command.

ATCA\_STATUS atcah\_privwrite\_auth\_mac (struct atca\_write\_mac\_in\_out \*param)

This function calculates the input MAC for the PrivWrite command.

ATCA\_STATUS atcah\_derive\_key (struct atca\_derive\_key\_in\_out \*param)

This function derives a key with a key and TempKey.

ATCA STATUS atcah derive key mac (struct atca derive key mac in out \*param)

This function calculates the input MAC for a DeriveKey command.

ATCA\_STATUS atcah\_decrypt (struct atca\_decrypt\_in\_out \*param)

This function decrypts 32-byte encrypted data received with the Read command.

ATCA STATUS atcah sha256 (int32 t len, const uint8 t \*message, uint8 t \*digest)

This function creates a SHA256 digest on a little-endian system.

uint8\_t \* atcah\_include\_data (struct atca\_include\_data\_in\_out \*param)

This function copies otp and sn data into a command buffer.

ATCA\_STATUS atcah\_gen\_key\_msg (struct atca\_gen\_key\_in\_out \*param)

Calculate the PubKey digest created by GenKey and saved to TempKey.

 ATCA\_STATUS atcah\_config\_to\_sign\_internal (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param, const uint8\_t \*config)

Populate the slot\_config, key\_config, and is\_slot\_locked fields in the atca\_sign\_internal\_in\_out structure from the provided config zone.

 ATCA\_STATUS atcah\_sign\_internal\_msg (ATCADeviceType device\_type, struct atca\_sign\_internal\_in\_out \*param)

Builds the full message that would be signed by the Sign(Internal) command.

ATCA\_STATUS atcah\_verify\_mac (atca\_verify\_mac\_in\_out\_t \*param)

Calculate the expected MAC on the host side for the Verify command.

ATCA\_STATUS atcah\_secureboot\_enc (atca\_secureboot\_enc\_in\_out\_t \*param)

Encrypts the digest for the SecureBoot command when using the encrypted digest / validating mac option.

• ATCA\_STATUS atcah\_secureboot\_mac (atca\_secureboot\_mac\_in\_out\_t \*param)

Calculates the expected MAC returned from the SecureBoot command when verification is a success.

ATCA\_STATUS atcah\_encode\_counter\_match (uint32\_t counter, uint8\_t \*counter\_match)

Builds the counter match value that needs to be stored in a slot.

ATCA\_STATUS atcah\_io\_decrypt (struct atca\_io\_decrypt\_in\_out \*param)

Decrypt data that's been encrypted by the IO protection key. The ECDH and KDF commands on the ATECC608 are the only ones that support this operation.

# 20.34.1 Detailed Description

Definitions and Prototypes for ATCA Utility Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.35 atca iface.c File Reference

Microchip CryptoAuthLib hardware interface object.

```
#include <stdlib.h>
#include "atca_iface.h"
#include "hal/atca_hal.h"
#include "atca_config.h"
```

### **Functions**

ATCA\_STATUS initATCAlface (ATCAlfaceCfg \*cfg, ATCAlface ca\_iface)

Initializer for ATCAlface objects.

ATCAlface newATCAlface (ATCAlfaceCfg \*cfg)

Constructor for ATCAlface objects.

• ATCA\_STATUS atinit (ATCAlface ca\_iface)

Performs the HAL initialization by calling intermediate HAL wrapper function. If using the basic API, the atcab\_init() function should be called instead.

- ATCA\_STATUS atsend (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)
  - Sends the data to the device by calling intermediate HAL wrapper function.
- ATCA\_STATUS atreceive (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

Receives data from the device by calling intermediate HAL wrapper function.

ATCA\_STATUS atwake (ATCAlface ca\_iface)

Wakes up the device by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_wakeup()">atcab\_wakeup()</a> function should be used instead.

ATCA STATUS atidle (ATCAlface ca iface)

Puts the device into idle state by calling intermediate HAL wrapper function. If using the basic API, the atcab\_idle() function should be used instead.

• ATCA STATUS atsleep (ATCAlface ca\_iface)

Puts the device into sleep state by calling intermediate HAL wrapper function. If using the basic API, the atcab\_sleep() function should be used instead.

ATCAlfaceCfg \* atgetifacecfg (ATCAlface ca iface)

Returns the logical interface configuration for the device.

void \* atgetifacehaldat (ATCAlface ca\_iface)

Returns the HAL data pointer for the device.

• ATCA\_STATUS releaseATCAlface (ATCAlface ca\_iface)

Instruct the HAL driver to release any resources associated with this interface.

void deleteATCAlface (ATCAlface \*ca\_iface)

Instruct the HAL driver to release any resources associated with this interface, then delete the object.

# 20.35.1 Detailed Description

Microchip CryptoAuthLib hardware interface object.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.36 atca iface.h File Reference

Microchip Crypto Auth hardware interface object.

```
#include "atca_devtypes.h"
#include <stdint.h>
#include "atca_status.h"
```

# **Data Structures**

- struct ATCAlfaceCfg
- · struct atca iface

atca\_iface is the C object backing ATCAlface. See the atca\_iface.h file for details on the ATCAlface methods

### **Typedefs**

typedef struct atca\_iface \* ATCAlface

#### **Enumerations**

- enum ATCAlfaceType {
   ATCA\_I2C\_IFACE, ATCA\_SWI\_IFACE, ATCA\_UART\_IFACE, ATCA\_SPI\_IFACE,
   ATCA\_HID\_IFACE, ATCA\_CUSTOM\_IFACE, ATCA\_UNKNOWN\_IFACE;
   }
- enum ATCAKitType {
   ATCA\_KIT\_AUTO\_IFACE, ATCA\_KIT\_I2C\_IFACE, ATCA\_KIT\_SWI\_IFACE, ATCA\_KIT\_SPI\_IFACE,
   ATCA\_KIT\_UNKNOWN\_IFACE }

#### **Functions**

ATCA STATUS initATCAlface (ATCAlfaceCfg \*cfg, ATCAlface ca iface)

Initializer for ATCAlface objects.

ATCAlface newATCAlface (ATCAlfaceCfg \*cfg)

Constructor for ATCAlface objects.

ATCA\_STATUS releaseATCAlface (ATCAlface ca\_iface)

Instruct the HAL driver to release any resources associated with this interface.

• void deleteATCAlface (ATCAlface \*ca\_iface)

Instruct the HAL driver to release any resources associated with this interface, then delete the object.

ATCA\_STATUS atinit (ATCAlface ca\_iface)

Performs the HAL initialization by calling intermediate HAL wrapper function. If using the basic API, the atcab\_init() function should be called instead.

- ATCA\_STATUS atpostinit (ATCAlface ca\_iface)
- ATCA\_STATUS atsend (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

Sends the data to the device by calling intermediate HAL wrapper function.

• ATCA\_STATUS atreceive (ATCAlface ca\_iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

Receives data from the device by calling intermediate HAL wrapper function.

ATCA STATUS atwake (ATCAlface ca iface)

Wakes up the device by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_wakeup()">atcab\_wakeup()</a> function should be used instead.

• ATCA\_STATUS atidle (ATCAlface ca\_iface)

Puts the device into idle state by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_idle()">atcab\_idle()</a> function should be used instead.

• ATCA STATUS atsleep (ATCAlface ca iface)

Puts the device into sleep state by calling intermediate HAL wrapper function. If using the basic API, the <a href="atcab\_sleep()">atcab\_sleep()</a> function should be used instead.

ATCAlfaceCfg \* atgetifacecfg (ATCAlface ca iface)

Returns the logical interface configuration for the device.

void \* atgetifacehaldat (ATCAlface ca\_iface)

Returns the HAL data pointer for the device.

### 20.36.1 Detailed Description

Microchip Crypto Auth hardware interface object.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.37 atca\_jwt.c File Reference

Utilities to create and verify a JSON Web Token (JWT)

```
#include "cryptoauthlib.h"
#include "atca_helpers.h"
#include "crypto/atca_crypto_sw_sha2.h"
#include "jwt/atca_jwt.h"
#include <stdio.h>
```

#### **Functions**

- void atca\_jwt\_check\_payload\_start (atca\_jwt\_t \*jwt)
  - Check the provided context to see what character needs to be added in order to append a claim.
- ATCA\_STATUS atca\_jwt\_init (atca\_jwt\_t \*jwt, char \*buf, uint16\_t buflen)

Initialize a JWT structure.

- ATCA\_STATUS atca\_jwt\_finalize (atca\_jwt\_t \*jwt, uint16\_t key\_id)
  - Close the claims of a token, encode them, then sign the result.
- ATCA\_STATUS atca\_jwt\_add\_claim\_string (atca\_jwt\_t \*jwt, const char \*claim, const char \*value)
   Add a string claim to a token.
- ATCA\_STATUS atca\_jwt\_add\_claim\_numeric (atca\_jwt\_t \*jwt, const char \*claim, int32\_t value)
   Add a numeric claim to a token.
- ATCA\_STATUS atca\_jwt\_verify (const char \*buf, uint16\_t buflen, const uint8\_t \*pubkey)
   Verifies the signature of a jwt using the provided public key.

# 20.37.1 Detailed Description

Utilities to create and verify a JSON Web Token (JWT)

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.38 atca jwt.h File Reference

Utilities to create and verify a JSON Web Token (JWT)

```
#include "cryptoauthlib.h"
```

# **Data Structures**

• struct atca\_jwt\_t

Structure to hold metadata information about the jwt being built.

- ATCA\_STATUS atca\_jwt\_init (atca\_jwt\_t \*jwt, char \*buf, uint16\_t buflen)
  - Initialize a JWT structure.
- $\bullet \ \ \mathsf{ATCA\_STATUS} \ \ \mathsf{atca\_jwt\_add\_claim\_string} \ \ (\mathsf{atca\_jwt\_t} \ *\mathsf{jwt}, \ \mathsf{const} \ \mathsf{char} \ *\mathsf{claim}, \ \mathsf{const} \ \mathsf{char} \ *\mathsf{value})$ 
  - Add a string claim to a token.
- ATCA\_STATUS atca\_jwt\_add\_claim\_numeric (atca\_jwt\_t \*jwt, const char \*claim, int32\_t value)
  - Add a numeric claim to a token.
- ATCA STATUS atca jwt finalize (atca jwt t\*jwt, uint16 t key id)
  - Close the claims of a token, encode them, then sign the result.
- void atca\_jwt\_check\_payload\_start (atca\_jwt\_t \*jwt)
  - Check the provided context to see what character needs to be added in order to append a claim.
- ATCA\_STATUS atca\_jwt\_verify (const char \*buf, uint16\_t buflen, const uint8\_t \*pubkey)

Verifies the signature of a jwt using the provided public key.

## 20.38.1 Detailed Description

Utilities to create and verify a JSON Web Token (JWT)

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.39 atca mbedtls ecdh.c File Reference

```
#include "mbedtls/config.h"
```

# 20.40 atca mbedtls ecdsa.c File Reference

```
#include "mbedtls/config.h"
```

# 20.41 atca mbedtls wrap.c File Reference

Wrapper functions to replace cryptoauthlib software crypto functions with the mbedTLS equivalent.

```
#include "mbedtls/config.h"
#include <stdlib.h>
#include "mbedtls/cmac.h"
#include "mbedtls/pk.h"
#include "mbedtls/ecp.h"
#include "mbedtls/x509_crt.h"
#include "cryptoauthlib.h"
#include "crypto/atca_crypto_sw.h"
#include "atcacert/atcacert_client.h"
#include "atcacert/atcacert_def.h"
```

#### **Macros**

- #define mbedtls calloc calloc
- #define mbedtls free free

#### **Functions**

• ATCA\_STATUS atcac\_aes\_gcm\_aad\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*aad, const size\_ ← t aad len)

Update the GCM context with additional authentication data (AAD)

ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len, const uint8\_t \*iv, const uint8\_t iv\_len)

Initialize an AES-GCM context.

 ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*plaintext, const size\_t pt\_len, uint8\_t \*ciphertext, size\_t \*ct\_len)

Encrypt a data using the initialized context.

- ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, uint8\_t \*tag, size\_t tag\_len)

  Get the AES-GCM tag and free the context.
- ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len, const uint8\_t \*iv, const uint8\_t iv\_len)

Initialize an AES-GCM context for decryption.

 ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*ciphertext, const size\_t ct\_len, uint8\_t \*plaintext, size\_t \*pt\_len)

Decrypt ciphertext using the initialized context.

 ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*tag, size\_t tag\_len, bool \*is verified)

Compare the AES-GCM tag and free the context.

• int atcac sw sha1 init (atcac sha1 ctx \*ctx)

Initialize context for performing SHA1 hash in software.

int atcac\_sw\_sha1\_update (atcac\_sha1\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)

Add data to a SHA1 hash.

• int atcac\_sw\_sha1\_finish (atcac\_sha1\_ctx \*ctx, uint8\_t digest[ATCA\_SHA1\_DIGEST\_SIZE])

Complete the SHA1 hash in software and return the digest.

int atcac\_sw\_sha2\_256\_init (atcac\_sha2\_256\_ctx \*ctx)

Initialize context for performing SHA256 hash in software.

• int atcac\_sw\_sha2\_256\_update (atcac\_sha2\_256\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)

Add data to a SHA256 hash.

- int atcac\_sw\_sha2\_256\_finish (atcac\_sha2\_256\_ctx \*ctx, uint8\_t digest[ATCA\_SHA2\_256\_DIGEST\_SIZE])
   Complete the SHA256 hash in software and return the digest.
- ATCA\_STATUS atcac\_aes\_cmac\_init (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)

  Initialize context for performing CMAC in software.
- ATCA\_STATUS atcac\_aes\_cmac\_update (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*data, const size\_
   t data\_size)

Update CMAC context with input data.

- ATCA\_STATUS atcac\_aes\_cmac\_finish (atcac\_aes\_cmac\_ctx \*ctx, uint8\_t \*cmac, size\_t \*cmac\_size) Finish CMAC calculation and clear the CMAC context.
- ATCA\_STATUS atcac\_sha256\_hmac\_init (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)

Initialize context for performing HMAC (sha256) in software.

ATCA\_STATUS atcac\_sha256\_hmac\_update (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*data, size\_
 t data\_size)

Update HMAC context with input data.

ATCA\_STATUS atcac\_sha256\_hmac\_finish (atcac\_hmac\_sha256\_ctx \*ctx, uint8\_t \*digest, size\_t \*digest ← \_ len)

Finish CMAC calculation and clear the HMAC context.

• int atca\_mbedtls\_pk\_init (mbedtls\_pk\_context \*pkey, const uint16\_t slotid)

Initializes an mbedtls pk context for use with EC operations.

• int atca\_mbedtls\_cert\_add (mbedtls\_x509\_crt \*cert, const atcacert\_def\_t \*cert\_def)

Rebuild a certificate from an atcacert\_def\_t structure, and then add it to an mbedtls cert chain.

# 20.41.1 Detailed Description

Wrapper functions to replace cryptoauthlib software crypto functions with the mbedTLS equivalent.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.41.2 Macro Definition Documentation

#### 20.41.2.1 mbedtls calloc

```
#define mbedtls_calloc calloc
```

#### 20.41.2.2 mbedtls free

```
#define mbedtls_free free
```

#### 20.41.3 Function Documentation

## 20.41.3.1 atca\_mbedtls\_cert\_add()

Rebuild a certificate from an atcacert\_def\_t structure, and then add it to an mbedtls cert chain.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 624

#### **Parameters**

| in,out | cert     | mbedtls cert chain. Must have already been initialized |
|--------|----------|--------------------------------------------------------|
| in     | cert_def | Certificate definition that will be rebuilt and added  |

### Returns

0 on success, otherwise an error code.

# 20.41.3.2 atcac\_aes\_cmac\_finish()

Finish CMAC calculation and clear the CMAC context.

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | ctx       | [in] pointer to a aes-cmac context |
|--------|-----------|------------------------------------|
| out    | cmac      | [out] cmac value                   |
| in,out | cmac_size | [inout] length of cmac             |

# 20.41.3.3 atcac\_aes\_cmac\_init()

Initialize context for performing CMAC in software.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx     | [in] pointer to a aes-cmac context |
|----|---------|------------------------------------|
| in | key     | [in] key value to use              |
| in | key_len | [in] length of the key             |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 625

### 20.41.3.4 atcac\_aes\_cmac\_update()

Update CMAC context with input data.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

|   | in | ctx       | [in] pointer to a aes-cmac context |
|---|----|-----------|------------------------------------|
|   | in | data      | [in] input data                    |
| ĺ | in | data_size | [in] length of input data          |

# 20.41.3.5 atcac\_aes\_gcm\_aad\_update()

Update the GCM context with additional authentication data (AAD)

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx     | [in] AES-GCM Context                |
|----|---------|-------------------------------------|
| in | aad     | [in] Additional Authentication Data |
| in | aad_len | [in] Length of AAD                  |

# 20.41.3.6 atcac\_aes\_gcm\_decrypt\_finish()

```
ATCA_STATUS atcac_aes_gcm_decrypt_finish ( atcac_aes_gcm_ctx * ctx,
```

```
const uint8_t * tag,
size_t tag_len,
bool * is_verified )
```

Compare the AES-GCM tag and free the context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx         | [in] AES-GCM Context           |
|-----|-------------|--------------------------------|
| in  | tag         | [in] GCM Tag to Verify         |
| in  | tag_len     | [in] Length of the GCM tag     |
| out | is_verified | [out] Tag verified as matching |

### 20.41.3.7 atcac\_aes\_gcm\_decrypt\_start()

```
ATCA_STATUS atcac_aes_gcm_decrypt_start (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * key,
    const uint8_t key_len,
    const uint8_t * iv,
    const uint8_t iv_len)
```

Initialize an AES-GCM context for decryption.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# **Parameters**

| in | ctx     | [in] AES-GCM Context                            |
|----|---------|-------------------------------------------------|
| in | key     | [in] AES Key                                    |
| in | key_len | [in] Length of the AES key - should be 16 or 32 |
| in | iv      | [in] Initialization vector input                |
| in | iv_len  | [in] Length of the initialization vector        |

### 20.41.3.8 atcac\_aes\_gcm\_decrypt\_update()

```
ATCA_STATUS atcac_aes_gcm_decrypt_update ( atcac_aes_gcm_ctx * ctx,
```

```
const uint8_t * ciphertext,
const size_t ct_len,
uint8_t * plaintext,
size_t * pt_len )
```

Decrypt ciphertext using the initialized context.

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | ctx        | [in] AES-GCM Context                   |
|--------|------------|----------------------------------------|
| in     | ciphertext | [in] Ciphertext to decrypt             |
| in     | ct_len     | [in] Length of the ciphertext          |
| out    | plaintext  | [out] Resulting decrypted plaintext    |
| in,out | pt_len     | [inout] Length of the plaintext buffer |

# 20.41.3.9 atcac\_aes\_gcm\_encrypt\_finish()

Get the AES-GCM tag and free the context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx     | [in] AES-GCM Context       |
|-----|---------|----------------------------|
| out | tag     | [out] GCM Tag Result       |
| in  | tag_len | [in] Length of the GCM tag |

# 20.41.3.10 atcac\_aes\_gcm\_encrypt\_start()

```
const uint8_t * iv,
const uint8_t iv_len )
```

Initialize an AES-GCM context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx     | [in] AES-GCM Context                            |
|----|---------|-------------------------------------------------|
| in | key     | [in] AES Key                                    |
| in | key_len | [in] Length of the AES key - should be 16 or 32 |
| in | iv      | [in] Initialization vector input                |
| in | iv_len  | [in] Length of the initialization vector        |

## 20.41.3.11 atcac\_aes\_gcm\_encrypt\_update()

Encrypt a data using the initialized context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# Parameters

| in     | ctx        | [in] AES-GCM Context                    |
|--------|------------|-----------------------------------------|
| in     | plaintext  | [in] Input buffer to encrypt            |
| in     | pt_len     | [in] Length of the input                |
| out    | ciphertext | [out] Output buffer                     |
| in,out | ct_len     | [inout] Length of the ciphertext buffer |

# 20.41.3.12 atcac\_sw\_sha1\_finish()

Complete the SHA1 hash in software and return the digest.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx    | [in] pointer to a hash context |
|-----|--------|--------------------------------|
| out | digest | [out] output buffer (20 bytes) |

# 20.41.3.13 atcac\_sw\_sha2\_256\_finish()

Complete the SHA256 hash in software and return the digest.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx    | [in] pointer to a hash context |
|-----|--------|--------------------------------|
| out | digest | [out] output buffer (32 bytes) |

# 20.42 atca\_mbedtls\_wrap.h File Reference

# **Functions**

- int atca\_mbedtls\_pk\_init (struct mbedtls\_pk\_context \*pkey, const uint16\_t slotid)
   Initializes an mbedtls pk context for use with EC operations.
- int atca\_mbedtls\_cert\_add (struct mbedtls\_x509\_crt \*cert, const struct atcacert\_def\_s \*cert\_def)
- int atca\_mbedtls\_ecdh\_slot\_cb (void)

ECDH Callback to obtain the "slot" used in ECDH operations from the application.

int atca\_mbedtls\_ecdh\_ioprot\_cb (uint8\_t secret[32])

ECDH Callback to obtain the IO Protection secret from the application.

# 20.43 atca\_openssl\_interface.c File Reference

Crypto abstraction functions for external host side cryptography.

```
#include "atca_config.h"
#include "atca_status.h"
```

```
#include "crypto/atca_crypto_sw.h"
#include <openssl/cmac.h>
#include <openssl/evp.h>
#include <openssl/hmac.h>
```

ATCA\_STATUS atcac\_aes\_gcm\_aad\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*aad, const size\_
 t aad len)

Update the GCM context with additional authentication data (AAD)

• ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key len, const uint8\_t \*iv, const uint8\_t t iv len)

Initialize an AES-GCM context.

 ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*plaintext, const size t pt len, uint8 t \*ciphertext, size t \*ct len)

Encrypt a data using the initialized context.

- ATCA\_STATUS atcac\_aes\_gcm\_encrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, uint8\_t \*tag, size\_t tag\_len)

  Get the AES-GCM tag and free the context.
- ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_start (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len, const uint8\_t \*iv, const uint8\_t iv\_len)

Initialize an AES-GCM context for decryption.

• ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_update (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*ciphertext, const size\_t ct\_len, uint8\_t \*plaintext, size\_t \*pt\_len)

Decrypt ciphertext using the initialized context.

 ATCA\_STATUS atcac\_aes\_gcm\_decrypt\_finish (atcac\_aes\_gcm\_ctx \*ctx, const uint8\_t \*tag, size\_t tag\_len, bool \*is\_verified)

Compare the AES-GCM tag and free the context.

int atcac\_sw\_sha1\_init (atcac\_sha1\_ctx \*ctx)

Initialize context for performing SHA1 hash in software.

int atcac\_sw\_sha1\_update (atcac\_sha1\_ctx \*ctx, const uint8\_t \*data, size\_t data\_size)

Add data to a SHA1 hash.

• int atcac sw sha1 finish (atcac sha1 ctx \*ctx, uint8 t digest[ATCA SHA1 DIGEST SIZE])

Complete the SHA1 hash in software and return the digest.

int atcac\_sw\_sha2\_256\_init (atcac\_sha2\_256\_ctx \*ctx)

Initialize context for performing SHA256 hash in software.

• int atcac sw sha2 256 update (atcac sha2 256 ctx \*ctx, const uint8 t \*data, size t data size)

Add data to a SHA256 hash.

- int atcac\_sw\_sha2\_256\_finish (atcac\_sha2\_256\_ctx \*ctx, uint8\_t digest[ATCA\_SHA2\_256\_DIGEST\_SIZE])

  Complete the SHA256 hash in software and return the digest.
- ATCA\_STATUS atcac\_aes\_cmac\_init (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key\_len)

  Initialize context for performing CMAC in software.
- ATCA\_STATUS atcac\_aes\_cmac\_update (atcac\_aes\_cmac\_ctx \*ctx, const uint8\_t \*data, const size\_
   t data\_size)

Update CMAC context with input data.

- ATCA\_STATUS atcac\_aes\_cmac\_finish (atcac\_aes\_cmac\_ctx \*ctx, uint8\_t \*cmac, size\_t \*cmac\_size)

  Finish CMAC calculation and clear the CMAC context.
- ATCA\_STATUS atcac\_sha256\_hmac\_init (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*key, const uint8\_t key len)

Initialize context for performing HMAC (sha256) in software.

ATCA\_STATUS atcac\_sha256\_hmac\_update (atcac\_hmac\_sha256\_ctx \*ctx, const uint8\_t \*data, size\_
 t data\_size)

Update HMAC context with input data.

ATCA\_STATUS atcac\_sha256\_hmac\_finish (atcac\_hmac\_sha256\_ctx \*ctx, uint8\_t \*digest, size\_t \*digest ← \_ len)

Finish CMAC calculation and clear the HMAC context.

# 20.43.1 Detailed Description

Crypto abstraction functions for external host side cryptography.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.43.2 Function Documentation

## 20.43.2.1 atcac\_aes\_cmac\_finish()

Finish CMAC calculation and clear the CMAC context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | ctx       | [in] pointer to a aes-cmac context |
|--------|-----------|------------------------------------|
| out    | cmac      | [out] cmac value                   |
| in,out | cmac_size | [inout] length of cmac             |

#### 20.43.2.2 atcac\_aes\_cmac\_init()

Initialize context for performing CMAC in software.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx     | [in] pointer to a aes-cmac context |
|----|---------|------------------------------------|
| in | key     | [in] key value to use              |
| in | key_len | [in] length of the key             |

# 20.43.2.3 atcac\_aes\_cmac\_update()

Update CMAC context with input data.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx       | [in] pointer to a aes-cmac context |
|----|-----------|------------------------------------|
| in | data      | [in] input data                    |
| in | data_size | [in] length of input data          |

### 20.43.2.4 atcac\_aes\_gcm\_aad\_update()

Update the GCM context with additional authentication data (AAD)

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx | [in] AES-GCM Context                |
|----|-----|-------------------------------------|
| in | aad | [in] Additional Authentication Data |

### 20.43.2.5 atcac\_aes\_gcm\_decrypt\_finish()

```
ATCA_STATUS atcac_aes_gcm_decrypt_finish (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * tag,
    size_t tag_len,
    bool * is_verified )
```

Compare the AES-GCM tag and free the context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx         | [in] AES-GCM Context           |
|-----|-------------|--------------------------------|
| in  | tag         | [in] GCM Tag to Verify         |
| in  | tag_len     | [in] Length of the GCM tag     |
| out | is_verified | [out] Tag verified as matching |

# 20.43.2.6 atcac\_aes\_gcm\_decrypt\_start()

```
ATCA_STATUS atcac_aes_gcm_decrypt_start (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * key,
    const uint8_t key_len,
    const uint8_t * iv,
    const uint8_t iv_len)
```

Initialize an AES-GCM context for decryption.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# **Parameters**

| in | ctx              | [in] AES-GCM Context                            |
|----|------------------|-------------------------------------------------|
| in | key [in] AES Key |                                                 |
| in | key_len          | [in] Length of the AES key - should be 16 or 32 |
| in | iv               | [in] Initialization vector input                |
| in | iv_len           | [in] Length of the initialization vector        |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 634

## 20.43.2.7 atcac\_aes\_gcm\_decrypt\_update()

```
ATCA_STATUS atcac_aes_gcm_decrypt_update (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * ciphertext,
    const size_t ct_len,
    uint8_t * plaintext,
    size_t * pt_len )
```

Decrypt ciphertext using the initialized context.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | ctx        | [in] AES-GCM Context                   |
|--------|------------|----------------------------------------|
| in     | ciphertext | [in] Ciphertext to decrypt             |
| in     | ct_len     | [in] Length of the ciphertext          |
| out    | plaintext  | [out] Resulting decrypted plaintext    |
| in,out | pt_len     | [inout] Length of the plaintext buffer |

# 20.43.2.8 atcac\_aes\_gcm\_encrypt\_finish()

Get the AES-GCM tag and free the context.

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx     | [in] AES-GCM Context       |
|-----|---------|----------------------------|
| out | tag     | [out] GCM Tag Result       |
| in  | tag_len | [in] Length of the GCM tag |

## 20.43.2.9 atcac\_aes\_gcm\_encrypt\_start()

```
ATCA_STATUS atcac_aes_gcm_encrypt_start ( atcac_aes_gcm_ctx * ctx,
```

```
const uint8_t * key,
const uint8_t key_len,
const uint8_t * iv,
const uint8_t iv_len )
```

Initialize an AES-GCM context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | ctx              | [in] AES-GCM Context                            |
|----|------------------|-------------------------------------------------|
| in | key [in] AES Key |                                                 |
| in | key_len          | [in] Length of the AES key - should be 16 or 32 |
| in | iv               | [in] Initialization vector input                |
| in | iv_len           | [in] Length of the initialization vector        |

### 20.43.2.10 atcac\_aes\_gcm\_encrypt\_update()

```
ATCA_STATUS atcac_aes_gcm_encrypt_update (
    atcac_aes_gcm_ctx * ctx,
    const uint8_t * plaintext,
    const size_t pt_len,
    uint8_t * ciphertext,
    size_t * ct_len )
```

Encrypt a data using the initialized context.

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in     | ctx        | [in] AES-GCM Context                    |
|--------|------------|-----------------------------------------|
| in     | plaintext  | [in] Input buffer to encrypt            |
| in     | pt_len     | [in] Length of the input                |
| out    | ciphertext | [out] Output buffer                     |
| in,out | ct_len     | [inout] Length of the ciphertext buffer |

# 20.43.2.11 atcac\_sw\_sha1\_finish()

```
int atcac\_sw\_sha1\_finish (
```

```
atcac_shal_ctx * ctx,
uint8_t digest[ATCA_SHA1_DIGEST_SIZE] )
```

Complete the SHA1 hash in software and return the digest.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx    | [in] pointer to a hash context |
|-----|--------|--------------------------------|
| out | digest | [out] output buffer (20 bytes) |

# 20.43.2.12 atcac\_sw\_sha2\_256\_finish()

Complete the SHA256 hash in software and return the digest.

# Returns

ATCA SUCCESS on success, otherwise an error code.

#### **Parameters**

| in  | ctx    | [in] pointer to a hash context |
|-----|--------|--------------------------------|
| out | digest | [out] output buffer (32 bytes) |

- 20.44 atca\_start\_config.h File Reference
- 20.45 atca start iface.h File Reference
- 20.46 atca\_status.h File Reference

Microchip Crypto Auth status codes.

```
#include <stdint.h>
#include "atca_bool.h"
```

#### **Macros**

• #define ATCA STATUS AUTH BIT 0x40

#### **Enumerations**

```
• enum ATCA_STATUS {
 ATCA_SUCCESS = 0x00, ATCA_CONFIG_ZONE_LOCKED = 0x01, ATCA_DATA_ZONE_LOCKED =
 0x02, ATCA_INVALID_POINTER,
 ATCA_INVALID_LENGTH, ATCA_WAKE_FAILED = 0xD0, ATCA_CHECKMAC_VERIFY_FAILED = 0xD1,
 ATCA_PARSE_ERROR = 0xD2,
 ATCA STATUS CRC = 0xD4, ATCA STATUS UNKNOWN = 0xD5, ATCA STATUS ECC = 0xD6,
 ATCA STATUS SELFTEST ERROR = 0xD7,
 ATCA FUNC FAIL = 0xE0, ATCA GEN FAIL = 0xE1, ATCA BAD PARAM = 0xE2, ATCA INVALID ID =
 0xE3,
 ATCA_INVALID_SIZE = 0xE4, ATCA_RX_CRC_ERROR = 0xE5, ATCA_RX_FAIL = 0xE6, ATCA_RX_NO_RESPONSE
 = 0xE7,
 ATCA_RESYNC_WITH_WAKEUP = 0xE8, ATCA_PARITY_ERROR = 0xE9, ATCA_TX_TIMEOUT = 0xEA,
 ATCA_RX_TIMEOUT = 0xEB,
 ATCA_TOO_MANY_COMM_RETRIES = 0xEC, ATCA_SMALL_BUFFER = 0xED, ATCA_COMM_FAIL =
 0xF0, ATCA TIMEOUT = 0xF1,
 ATCA BAD OPCODE = 0xF2, ATCA WAKE SUCCESS = 0xF3, ATCA EXECUTION ERROR = 0xF4,
 ATCA UNIMPLEMENTED = 0xF5,
 ATCA ASSERT FAILURE = 0xF6, ATCA TX FAIL = 0xF7, ATCA NOT LOCKED = 0xF8, ATCA NO DEVICES
 = 0xF9.
 ATCA HEALTH TEST ERROR = 0xFA, ATCA ALLOC FAILURE = 0xFB, ATCA USE FLAGS CONSUMED
 = 0xFC, ATCA_NOT_INITIALIZED = 0xFD }
```

### 20.46.1 Detailed Description

Microchip Crypto Auth status codes.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.46.2 Macro Definition Documentation

#### 20.46.2.1 ATCA STATUS AUTH BIT

#define ATCA\_STATUS\_AUTH\_BIT 0x40

# 20.46.3 Enumeration Type Documentation

# 20.46.3.1 ATCA STATUS

enum ATCA\_STATUS

# Enumerator

| ATCA_SUCCESS                | Function succeeded.                                                                                                                     |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| ATCA_CONFIG_ZONE_LOCKED     |                                                                                                                                         |
| ATCA_DATA_ZONE_LOCKED       |                                                                                                                                         |
| ATCA_INVALID_POINTER        |                                                                                                                                         |
| ATCA_INVALID_LENGTH         | waanana atatus kuta indiaataa OhaaliMaa failuus (atatus kuta                                                                            |
| ATCA_WAKE_FAILED            | response status byte indicates CheckMac failure (status byte = 0x01)                                                                    |
| ATCA_CHECKMAC_VERIFY_FAILED | response status byte indicates CheckMac failure (status byte = 0x01)                                                                    |
| ATCA_PARSE_ERROR            | response status byte indicates parsing error (status byte = 0x03)                                                                       |
| ATCA_STATUS_CRC             | response status byte indicates DEVICE did not receive data properly (status byte = 0xFF)                                                |
| ATCA_STATUS_UNKNOWN         | response status byte is unknown                                                                                                         |
| ATCA_STATUS_ECC             | response status byte is ECC fault (status byte = 0x05)                                                                                  |
| ATCA_STATUS_SELFTEST_ERROR  | response status byte is Self Test Error, chip in failure mode (status byte = 0x07)                                                      |
| ATCA_FUNC_FAIL              | Function could not execute due to incorrect condition / state.                                                                          |
| ATCA_GEN_FAIL               | unspecified error                                                                                                                       |
| ATCA_BAD_PARAM              | bad argument (out of range, null pointer, etc.)                                                                                         |
| ATCA_INVALID_ID             | invalid device id, id not set                                                                                                           |
| ATCA_INVALID_SIZE           | Count value is out of range or greater than buffer size.                                                                                |
| ATCA_RX_CRC_ERROR           | CRC error in data received from device.                                                                                                 |
| ATCA_RX_FAIL                | Timed out while waiting for response. Number of bytes received is > 0.                                                                  |
| ATCA_RX_NO_RESPONSE         | Not an error while the Command layer is polling for a command response.                                                                 |
| ATCA_RESYNC_WITH_WAKEUP     | Re-synchronization succeeded, but only after generating a Wake-up.                                                                      |
| ATCA_PARITY_ERROR           | for protocols needing parity                                                                                                            |
| ATCA_TX_TIMEOUT             | for Microchip PHY protocol, timeout on transmission waiting for master                                                                  |
| ATCA_RX_TIMEOUT             | for Microchip PHY protocol, timeout on receipt waiting for master                                                                       |
| ATCA_TOO_MANY_COMM_RETRIES  | Device did not respond too many times during a transmission. Could indicate no device present.                                          |
| ATCA_SMALL_BUFFER           | Supplied buffer is too small for data required.                                                                                         |
| ATCA_COMM_FAIL              | Communication with device failed. Same as in hardware dependent modules.                                                                |
| ATCA_TIMEOUT                | Timed out while waiting for response. Number of bytes received is 0.                                                                    |
| ATCA_BAD_OPCODE             | opcode is not supported by the device                                                                                                   |
| ATCA_WAKE_SUCCESS           | received proper wake token                                                                                                              |
| ATCA_EXECUTION_ERROR        | chip was in a state where it could not execute the command, response status byte indicates command execution error (status byte = 0x0F) |
| ATCA_UNIMPLEMENTED          | Function or some element of it hasn't been implemented yet.                                                                             |
| ATCA_ASSERT_FAILURE         | Code failed run-time consistency check.                                                                                                 |
| ATCA_TX_FAIL                | Failed to write.                                                                                                                        |
| ATCA_NOT_LOCKED             | required zone was not locked                                                                                                            |
| ATCA_NO_DEVICES             | For protocols that support device discovery (kit protocol), no devices were found.                                                      |
| ATCA_HEALTH_TEST_ERROR      | random number generator health test error                                                                                               |

#### Enumerator

| ATCA_ALLOC_FAILURE      | Couldn't allocate required memory.                               |
|-------------------------|------------------------------------------------------------------|
| ATCA_USE_FLAGS_CONSUMED | Use flags on the device indicates its consumed fully.            |
| ATCA_NOT_INITIALIZED    | The library has not been initialized so the command could not be |
|                         | executed.                                                        |

# 20.47 atca\_version.h File Reference

Microchip CryptoAuth Library Version.

### **Macros**

- #define ATCA\_LIBRARY\_VERSION\_DATE "20200912"
- #define ATCA\_LIBRARY\_VERSION\_MAJOR 3
- #define ATCA\_LIBRARY\_VERSION\_MINOR 2
- #define ATCA\_LIBRARY\_VERSION\_BUILD 3

# 20.47.1 Detailed Description

Microchip CryptoAuth Library Version.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.47.2 Macro Definition Documentation

# 20.47.2.1 ATCA\_LIBRARY\_VERSION\_BUILD

#define ATCA\_LIBRARY\_VERSION\_BUILD 3

# 20.47.2.2 ATCA\_LIBRARY\_VERSION\_DATE

#define ATCA\_LIBRARY\_VERSION\_DATE "20200912"

## 20.47.2.3 ATCA\_LIBRARY\_VERSION\_MAJOR

#define ATCA\_LIBRARY\_VERSION\_MAJOR 3

### 20.47.2.4 ATCA\_LIBRARY\_VERSION\_MINOR

#define ATCA\_LIBRARY\_VERSION\_MINOR 2

# 20.48 atca\_wolfssl\_interface.c File Reference

Crypto abstraction functions for external host side cryptography.

```
#include "atca_config.h"
#include "atca_status.h"
#include "crypto/atca_crypto_sw.h"
```

# 20.48.1 Detailed Description

Crypto abstraction functions for external host side cryptography.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.49 atcacert.h File Reference

Declarations common to all atcacert code.

```
#include <stddef.h>
#include <stdint.h>
```

#### **Macros**

```
#define FALSE (0)#define TRUE (1)
```

#define ATCACERT E SUCCESS 0

Operation completed successfully.

• #define ATCACERT\_E\_ERROR 1

General error.

• #define ATCACERT E BAD PARAMS 2

Invalid/bad parameter passed to function.

• #define ATCACERT E BUFFER TOO SMALL 3

Supplied buffer for output is too small to hold the result.

#define ATCACERT\_E\_DECODING\_ERROR 4

Data being decoded/parsed has an invalid format.

• #define ATCACERT\_E\_INVALID\_DATE 5

Date is invalid.

• #define ATCACERT\_E\_UNIMPLEMENTED 6

Function is unimplemented for the current configuration.

#define ATCACERT E UNEXPECTED ELEM SIZE 7

A certificate element size was not what was expected.

• #define ATCACERT\_E\_ELEM\_MISSING 8

The certificate element isn't defined for the certificate definition.

#define ATCACERT\_E\_ELEM\_OUT\_OF\_BOUNDS 9

Certificate element is out of bounds for the given certificate.

• #define ATCACERT E BAD CERT 10

Certificate structure is bad in some way.

- #define ATCACERT E WRONG CERT DEF 11
- #define ATCACERT\_E\_VERIFY\_FAILED 12

Certificate or challenge/response verification failed.

#define ATCACERT\_E\_INVALID\_TRANSFORM 13

Invalid transform passed to function.

# 20.49.1 Detailed Description

Declarations common to all atcacert code.

These are common definitions used by all the atcacert code.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.50 atcacert\_client.c File Reference

Client side cert i/o methods. These declarations deal with the client-side, the node being authenticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication device (e.g. ATECC508A) and the certificates are stored on that device.

```
#include <stdlib.h>
#include "atcacert_client.h"
#include "atcacert_der.h"
#include "atcacert_pem.h"
#include "cryptoauthlib.h"
#include "calib/calib_basic.h"
```

int atcacert\_get\_response (uint8\_t device\_private\_key\_slot, const uint8\_t challenge[32], uint8\_←
t response[64])

Calculates the response to a challenge sent from the host.

• int atcacert\_read\_device\_loc (const atcacert\_device\_loc\_t \*device\_loc, uint8\_t \*data)

Read the data from a device location.

int atcacert\_read\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t ca\_public\_key[64], uint8\_t \*cert, size\_t \*cert\_size)

Reads the certificate specified by the certificate definition from the ATECC508A device.

int atcacert\_write\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size)

Take a full certificate and write it to the ATECC508A device according to the certificate definition.

• int atcacert create csr pem (const atcacert def t \*csr def, char \*csr, size t \*csr size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

• int atcacert create csr (const atcacert def t \*csr def, uint8 t \*csr, size t \*csr size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

int atcacert read subj key id (const atcacert def t \*cert def, uint8 t subj key id[20])

Reads the subject key ID based on a certificate definition.

• int atcacert\_read\_cert\_size (const atcacert\_def\_t \*cert\_def, size\_t \*cert\_size)

Return the actual certificate size in bytes for a given cert def. Certificate can be variable size, so this gives the absolute buffer size when reading the certificates.

#### 20.50.1 Detailed Description

Client side cert i/o methods. These declarations deal with the client-side, the node being authenticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication device (e.g. ATECC508A) and the certificates are stored on that device.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.51 atcacert client.h File Reference

Client side cert i/o methods. These declarations deal with the client-side, the node being authenticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication device (e.g. ATECC508A) and the certificates are stored on that device.

```
#include <stddef.h>
#include <stdint.h>
#include "atcacert_def.h"
```

• int atcacert\_read\_device\_loc (const atcacert\_device\_loc\_t \*device\_loc, uint8\_t \*data)

Read the data from a device location.

int atcacert\_read\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t ca\_public\_key[64], uint8\_t \*cert, size\_t \*cert size)

Reads the certificate specified by the certificate definition from the ATECC508A device.

• int atcacert\_write\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size)

Take a full certificate and write it to the ATECC508A device according to the certificate definition.

• int atcacert\_create\_csr (const atcacert\_def\_t \*csr\_def, uint8\_t \*csr, size\_t \*csr\_size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

int atcacert\_create\_csr\_pem (const atcacert\_def\_t \*csr\_def, char \*csr, size\_t \*csr\_size)

Creates a CSR specified by the CSR definition from the ATECC508A device. This process involves reading the dynamic CSR data from the device and combining it with the template found in the CSR definition, then signing it. Return the CSR int der format.

int atcacert\_get\_response (uint8\_t device\_private\_key\_slot, const uint8\_t challenge[32], uint8\_
 t response[64])

Calculates the response to a challenge sent from the host.

int atcacert\_read\_subj\_key\_id (const atcacert\_def\_t \*cert\_def, uint8\_t subj\_key\_id[20])

Reads the subject key ID based on a certificate definition.

• int atcacert\_read\_cert\_size (const atcacert\_def\_t \*cert\_def, size\_t \*cert\_size)

Return the actual certificate size in bytes for a given cert def. Certificate can be variable size, so this gives the absolute buffer size when reading the certificates.

### 20.51.1 Detailed Description

Client side cert i/o methods. These declarations deal with the client-side, the node being authenticated, of the authentication process. It is assumed the client has an ECC CryptoAuthentication device (e.g. ATECC508A) and the certificates are stored on that device.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.52 atcacert\_date.c File Reference

Date handling with regard to certificates.

```
#include <string.h>
#include "atcacert_date.h"
```

int atcacert\_date\_enc (atcacert\_date\_format\_t format, const atcacert\_tm\_utc\_t \*timestamp, uint8\_←
t \*formatted date, size t \*formatted date size)

Format a timestamp according to the format type.

int atcacert\_date\_dec (atcacert\_date\_format\_t format, const uint8\_t \*formatted\_date, size\_t formatted\_
 date size, atcacert tm utc t \*timestamp)

Parse a formatted timestamp according to the specified format.

int atcacert\_date\_get\_max\_date (atcacert\_date\_format\_t format, atcacert\_tm\_utc\_t \*timestamp)

Return the maximum date available for the given format.

- int atcacert\_date\_enc\_iso8601\_sep (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(20)])
- int atcacert date dec iso8601 sep (const uint8 t formatted date[(20)], atcacert tm utc t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_utc (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(13)])
- int atcacert\_date\_dec\_rfc5280\_utc (const uint8\_t formatted\_date[(13)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_gen (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(15)])
- int atcacert date dec rfc5280 gen (const uint8 t formatted date[(15)], atcacert tm utc t \*timestamp)
- int atcacert date enc posix uint32 be (const atcacert tm utc t \*timestamp, uint8 t formatted date[(4)])
- int atcacert date dec posix uint32 be (const uint8 t formatted date[(4)], atcacert tm utc t \*timestamp)
- int atcacert\_date\_enc\_posix\_uint32\_le (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(4)])
- int atcacert\_date\_dec\_posix\_uint32\_le (const uint8\_t formatted\_date[(4)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_compcert (const atcacert\_tm\_utc\_t \*issue\_date, uint8\_t expire\_years, uint8\_t enc\_
  dates[3])

Encode the issue and expire dates in the format used by the compressed certificate.

 int atcacert\_date\_dec\_compcert (const uint8\_t enc\_dates[3], atcacert\_date\_format\_t expire\_date\_format, atcacert\_tm\_utc\_t \*issue\_date, atcacert\_tm\_utc\_t \*expire\_date)

Decode the issue and expire dates from the format used by the compressed certificate.

#### **Variables**

• const size\_t ATCACERT\_DATE\_FORMAT\_SIZES [5]

## 20.52.1 Detailed Description

Date handling with regard to certificates.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.53 atcacert date.h File Reference

Declarations for date handling with regard to certificates.

```
#include <stddef.h>
#include "atcacert.h"
```

# **Data Structures**

• struct atcacert\_tm\_utc\_s

#### **Macros**

- #define DATEFMT ISO8601 SEP SIZE (20)
- #define DATEFMT\_RFC5280\_UTC\_SIZE (13)
- #define DATEFMT POSIX UINT32 BE SIZE (4)
- #define DATEFMT POSIX UINT32 LE SIZE (4)
- #define DATEFMT RFC5280 GEN SIZE (15)
- #define DATEFMT MAX SIZE DATEFMT ISO8601 SEP SIZE
- #define ATCACERT\_DATE\_FORMAT\_SIZES\_COUNT 5

# **Typedefs**

- typedef struct atcacert\_tm\_utc\_s atcacert\_tm\_utc\_t
- typedef enum atcacert\_date\_format\_e atcacert\_date\_format\_t

#### **Enumerations**

enum atcacert\_date\_format\_e {
 DATEFMT\_ISO8601\_SEP, DATEFMT\_RFC5280\_UTC, DATEFMT\_POSIX\_UINT32\_BE, DATEFMT\_POSIX\_UINT32\_LE,
 DATEFMT\_RFC5280\_GEN }

#### **Functions**

int atcacert\_date\_enc (atcacert\_date\_format\_t format, const atcacert\_tm\_utc\_t \*timestamp, uint8\_←
 t \*formatted\_date, size\_t \*formatted\_date\_size)

Format a timestamp according to the format type.

int atcacert\_date\_dec (atcacert\_date\_format\_t format, const uint8\_t \*formatted\_date, size\_t formatted\_
 date\_size, atcacert\_tm\_utc\_t \*timestamp)

Parse a formatted timestamp according to the specified format.

int atcacert\_date\_enc\_compcert (const atcacert\_tm\_utc\_t \*issue\_date, uint8\_t expire\_years, uint8\_t enc\_
dates[3])

Encode the issue and expire dates in the format used by the compressed certificate.

• int atcacert\_date\_dec\_compcert (const uint8\_t enc\_dates[3], atcacert\_date\_format\_t expire\_date\_format, atcacert\_tm\_utc\_t \*issue\_date, atcacert\_tm\_utc\_t \*expire\_date)

Decode the issue and expire dates from the format used by the compressed certificate.

• int atcacert\_date\_get\_max\_date (atcacert\_date\_format\_t format, atcacert\_tm\_utc\_t \*timestamp)

Return the maximum date available for the given format.

- int atcacert date enc iso8601 sep (const atcacert tm utc t \*timestamp, uint8 t formatted date[(20)])
- int atcacert date dec iso8601 sep (const uint8 t formatted date[(20)], atcacert tm utc t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_utc (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(13)])
- int atcacert\_date\_dec\_rfc5280\_utc (const uint8\_t formatted\_date[(13)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_rfc5280\_gen (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(15)])
- int atcacert\_date\_dec\_rfc5280\_gen (const uint8\_t formatted\_date[(15)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_posix\_uint32\_be (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(4)])
- int atcacert\_date\_dec\_posix\_uint32\_be (const uint8\_t formatted\_date[(4)], atcacert\_tm\_utc\_t \*timestamp)
- int atcacert\_date\_enc\_posix\_uint32\_le (const atcacert\_tm\_utc\_t \*timestamp, uint8\_t formatted\_date[(4)])
- int atcacert\_date\_dec\_posix\_uint32\_le (const uint8\_t formatted\_date[(4)], atcacert\_tm\_utc\_t \*timestamp)

#### **Variables**

• const size\_t ATCACERT\_DATE\_FORMAT\_SIZES [5]

# 20.53.1 Detailed Description

Declarations for date handling with regard to certificates.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.54 atcacert\_def.c File Reference

Main certificate definition implementation.

```
#include "atcacert_def.h"
#include "crypto/atca_crypto_sw_sha1.h"
#include "crypto/atca_crypto_sw_sha2.h"
#include "atcacert_der.h"
#include "atcacert_date.h"
#include <string.h>
#include "atca_helpers.h"
```

#### **Macros**

- #define ATCACERT\_MIN(x, y) ((x) < (y) ? (x) : (y))
- #define ATCACERT MAX(x, y) ((x) >= (y) ? (x) : (y))

# **Functions**

int atcacert\_merge\_device\_loc (atcacert\_device\_loc\_t \*device\_locs, size\_t \*device\_locs\_count, size\_
 t device\_locs\_max\_count, const atcacert\_device\_loc\_t \*device\_loc, size\_t block\_size)

Merge a new device location into a list of device locations. If the new location overlaps with an existing location, the existing one will be modified to encompass both. Otherwise the new location is appended to the end of the list.

int atcacert\_get\_device\_locs (const atcacert\_def\_t \*cert\_def, atcacert\_device\_loc\_t \*device\_locs, size\_
 t \*device locs count, size t device locs max count, size t block size)

Add all the device locations required to rebuild the specified certificate (cert\_def) to a device locations list.

int atcacert\_cert\_build\_start (atcacert\_build\_state\_t \*build\_state, const atcacert\_def\_t \*cert\_def, uint8\_

 t \*cert, size\_t \*cert\_size, const uint8\_t ca\_public\_key[64])

Starts the certificate rebuilding process.

• int atcacert\_cert\_build\_process (atcacert\_build\_state\_t \*build\_state, const atcacert\_device\_loc\_t \*device ← \_loc, const uint8\_t \*device\_data)

Process information read from the ATECC device. If it contains information for the certificate, it will be incorporated into the certificate.

• int atcacert cert build finish (atcacert build state t \*build state)

Completes any final certificate processing required after all data from the device has been incorporated.

• int atcacert\_is\_device\_loc\_overlap (const atcacert\_device\_loc\_t \*device\_loc1, const atcacert\_device\_loc\_t \*device\_loc2)

Determines if the two device locations overlap.

• int atcacert\_get\_device\_data (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const atcacert\_device\_loc\_t \*device\_loc, uint8\_t \*device\_data)

Gets the dynamic data that would be saved to the specified device location. This function is primarily used to break down a full certificate into the dynamic components to be saved to a device.

• int atcacert\_set\_subj\_public\_key (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t subj\_public\_key[64])

Sets the subject public key and subject key ID in a certificate.

• int atcacert\_get\_subj\_public\_key (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t subj\_public\_key[64])

Gets the subject public key from a certificate.

int atcacert\_get\_subj\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t subj key id[20])

Gets the subject key ID from a certificate.

int atcacert\_set\_signature (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_
 cert\_size, const uint8\_t signature[64])

Sets the signature in a certificate. This may alter the size of the X.509 certificates.

int atcacert\_get\_signature (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t signature[64])

Gets the signature from a certificate.

• int atcacert\_set\_issue\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert\_tm\_utc\_t \*timestamp)

Sets the issue date (notBefore) in a certificate. Will be formatted according to the date format specified in the certificate definition.

• int atcacert\_get\_issue\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert\_tm\_utc\_t \*timestamp)

Gets the issue date from a certificate. Will be parsed according to the date format specified in the certificate definition.

• int atcacert\_set\_expire\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert\_tm\_utc\_t \*timestamp)

Sets the expire date (notAfter) in a certificate. Will be formatted according to the date format specified in the certificate definition.

• int atcacert\_get\_expire\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert tm utc t \*timestamp)

Gets the expire date from a certificate. Will be parsed according to the date format specified in the certificate definition.

int atcacert\_set\_signer\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_
 t signer\_id[2])

Sets the signer ID in a certificate. Will be formatted as 4 upper-case hex digits.

int atcacert\_get\_signer\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t signer id[2])

Gets the signer ID from a certificate. Will be parsed as 4 upper-case hex digits.

int atcacert\_set\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_cert
 \_size, const uint8\_t \*cert\_sn, size\_t cert\_sn\_size)

Sets the certificate serial number in a certificate.

• int atcacert\_gen\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_← t device\_sn[9])

Sets the certificate serial number by generating it from other information in the certificate using the scheme specified by sn source in cert def. See the.

int atcacert\_get\_cert\_sn (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t \*cert sn, size t \*cert sn size)

Gets the certificate serial number from a certificate.

int atcacert\_set\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t auth\_public\_key[64])

Sets the authority key ID in a certificate. Note that this takes the actual public key creates a key ID from it.

• int atcacert\_set\_auth\_key\_id\_raw (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8 t \*auth key id)

Sets the authority key ID in a certificate.

• int atcacert\_get\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t auth key id[20])

Gets the authority key ID from a certificate.

int atcacert\_set\_comp\_cert (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_
 cert size, const uint8 t comp\_cert[72])

Sets the signature, issue date, expire date, and signer ID found in the compressed certificate. This also checks fields common between the cert def and the compressed certificate to make sure they match.

int atcacert\_get\_comp\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t comp\_cert[72])

Generate the compressed certificate for the given certificate.

• int atcacert\_get\_tbs (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*\*tbs, size\_t \*tbs\_size)

Get a pointer to the TBS data in a certificate.

int atcacert\_get\_tbs\_digest (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t tbs\_digest[32])

Get the SHA256 digest of certificate's TBS data.

• int atcacert\_set\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, uint8\_t \*cert, size t cert size, const uint8 t \*data, size t data size)

Sets an element in a certificate. The data\_size must match the size in cert\_loc.

• int atcacert\_get\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, const uint8\_t \*cert\_size\_t cert\_size, uint8\_t \*data, size\_t data\_size)

Gets an element from a certificate.

int atcacert\_get\_key\_id (const uint8\_t public\_key[64], uint8\_t key\_id[20])

Calculates the key ID for a given public ECC P256 key.

void atcacert public key add padding (const uint8 t raw key[64], uint8 t padded key[72])

Takes a raw P256 ECC public key and converts it to the padded version used by ATECC devices. Input and output buffers can point to the same location to do an in-place transform.

void atcacert public key remove padding (const uint8 t padded key[72], uint8 t raw key[64])

Takes a padded public key used by ATECC devices and converts it to a raw P256 ECC public key. Input and output buffers can point to the same location to do an in-place transform.

• int atcacert\_transform\_data (atcacert\_transform\_t transform, const uint8\_t \*data, size\_t data\_size, uint8\_t \*destination, size t \*destination size)

Apply the specified transform to the specified data.

• int atcacert\_max\_cert\_size (const atcacert\_def\_t \*cert\_def, size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a given cert def. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificates.

### 20.54.1 Detailed Description

Main certificate definition implementation.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.54.2 Macro Definition Documentation

#### 20.54.2.1 ATCACERT\_MAX

### 20.54.2.2 ATCACERT\_MIN

```
#define ATCACERT_MIN(  x, \\ y ) \ ((x) < (y) \ ? \ (x) : \ (y))
```

# 20.55 atcacert\_def.h File Reference

Declarations for certificates related to ECC CryptoAuthentication devices. These are the definitions required to define a certificate and its various elements with regards to the CryptoAuthentication ECC devices.

```
#include <stddef.h>
#include <stdint.h>
#include "atca_compiler.h"
#include "atcacert.h"
#include "atcacert_date.h"
#include "atca_helpers.h"
```

### **Data Structures**

- struct atcacert\_device\_loc\_s
- struct atcacert\_cert\_loc\_s
- · struct atcacert cert element s
- · struct atcacert def s
- · struct atcacert\_build\_state\_s

#### **Macros**

- #define ATCA\_MAX\_TRANSFORMS 2
- #define ATCA\_PACKED

# **Typedefs**

- typedef enum atcacert cert type e atcacert cert type t
- typedef enum atcacert\_cert\_sn\_src\_e atcacert\_cert\_sn\_src\_t
- typedef enum atcacert\_device\_zone\_e atcacert\_device\_zone\_t
- typedef enum atcacert\_transform\_e atcacert\_transform\_t

How to transform the data from the device to the certificate.

- typedef enum atcacert\_std\_cert\_element\_e atcacert\_std\_cert\_element\_t
- typedef struct atcacert device loc s atcacert device loc t
- typedef struct atcacert\_cert\_loc\_s atcacert\_cert\_loc\_t
- typedef struct atcacert cert element s atcacert cert element t
- typedef struct atcacert\_def\_s atcacert\_def\_t
- typedef struct atcacert\_build\_state\_s atcacert\_build\_state\_t

#### **Enumerations**

```
enum atcacert_cert_type_e { CERTTYPE_X509, CERTTYPE_CUSTOM }
```

```
• enum atcacert cert sn src e {
 SNSRC STORED = 0x0, SNSRC STORED DYNAMIC = 0x7, SNSRC DEVICE SN = 0x8, SNSRC SIGNER ID
 SNSRC PUB KEY HASH = 0xA, SNSRC DEVICE SN HASH = 0xB, SNSRC PUB KEY HASH POS =
 0xC, SNSRC DEVICE SN HASH POS = 0xD,
 SNSRC PUB KEY HASH RAW = 0xE, SNSRC DEVICE SN HASH RAW = 0xF }

    enum atcacert_device_zone_e { DEVZONE_CONFIG = 0x00, DEVZONE_OTP = 0x01, DEVZONE_DATA =

 0x02, DEVZONE NONE = 0x07 }
• enum atcacert transform e {
```

```
TF_NONE, TF_REVERSE, TF_BIN2HEX_UC, TF_BIN2HEX_LC,
TF_HEX2BIN_UC, TF_HEX2BIN_LC, TF_BIN2HEX_SPACE_UC, TF_BIN2HEX_SPACE_LC,
TF_HEX2BIN_SPACE_UC, TF_HEX2BIN_SPACE_LC }
```

How to transform the data from the device to the certificate.

• enum atcacert std cert element e { STDCERT PUBLIC KEY, STDCERT SIGNATURE, STDCERT ISSUE DATE, STDCERT EXPIRE DATE, STDCERT\_SIGNER\_ID, STDCERT\_CERT\_SN, STDCERT\_AUTH\_KEY\_ID, STDCERT\_SUBJ\_KEY\_ID, STDCERT\_NUM\_ELEMENTS }

#### **Functions**

 int atcacert get device locs (const atcacert def t \*cert def, atcacert device loc t \*device locs, size ← t \*device locs count, size t device locs max count, size t block size)

Add all the device locations required to rebuild the specified certificate (cert def) to a device locations list.

 int atcacert cert build start (atcacert build state t \*build state, const atcacert def t \*cert def, uint8 ← t \*cert, size t \*cert size, const uint8 t ca public key[64])

Starts the certificate rebuilding process.

 int atcacert\_cert\_build\_process (atcacert\_build\_state\_t \*build\_state, const atcacert\_device\_loc\_t \*device← loc, const uint8 t \*device data)

Process information read from the ATECC device. If it contains information for the certificate, it will be incorporated into the certificate.

int atcacert cert build finish (atcacert build state t \*build state)

Completes any final certificate processing required after all data from the device has been incorporated.

• int atcacert get device data (const atcacert def t \*cert def, const uint8 t \*cert, size t cert size, const atcacert device loc t \*device loc, uint8 t \*device data)

Gets the dynamic data that would be saved to the specified device location. This function is primarily used to break down a full certificate into the dynamic components to be saved to a device.

• int atcacert\_set\_subj\_public\_key (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8 t subj public key[64])

Sets the subject public key and subject key ID in a certificate.

• int atcacert get subj public key (const atcacert def t \*cert def, const uint8 t \*cert, size t cert size, uint8 t subj public key[64])

Gets the subject public key from a certificate.

• int atcacert\_get\_subj\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t subj key id[20])

Gets the subject key ID from a certificate.

 int atcacert set signature (const atcacert def t \*cert def, uint8 t \*cert, size t \*cert size, size t max ← cert\_size, const uint8\_t signature[64])

Sets the signature in a certificate. This may alter the size of the X.509 certificates.

 int atcacert get signature (const atcacert def t \*cert def, const uint8 t \*cert, size t cert size, uint8 ← t signature[64])

Gets the signature from a certificate.

• int atcacert\_set\_issue\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert tm utc t \*timestamp)

Sets the issue date (notBefore) in a certificate. Will be formatted according to the date format specified in the certificate definition.

int atcacert\_get\_issue\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert tm utc t\*timestamp)

Gets the issue date from a certificate. Will be parsed according to the date format specified in the certificate definition.

• int atcacert\_set\_expire\_date (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const atcacert\_tm\_utc\_t \*timestamp)

Sets the expire date (notAfter) in a certificate. Will be formatted according to the date format specified in the certificate definition

int atcacert\_get\_expire\_date (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, atcacert\_tm\_utc\_t \*timestamp)

Gets the expire date from a certificate. Will be parsed according to the date format specified in the certificate definition.

int atcacert\_set\_signer\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_
 t signer\_id[2])

Sets the signer ID in a certificate. Will be formatted as 4 upper-case hex digits.

int atcacert\_get\_signer\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_
 t signer\_id[2])

Gets the signer ID from a certificate. Will be parsed as 4 upper-case hex digits.

int atcacert\_set\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_cert
 size, const uint8 t \*cert sn, size t cert sn size)

Sets the certificate serial number in a certificate.

• int atcacert\_gen\_cert\_sn (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_← t device\_sn[9])

Sets the certificate serial number by generating it from other information in the certificate using the scheme specified by sn\_source in cert\_def. See the.

int atcacert\_get\_cert\_sn (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t \*cert
 \_sn, size\_t \*cert\_sn\_size)

Gets the certificate serial number from a certificate.

• int atcacert\_set\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t auth public key[64])

Sets the authority key ID in a certificate. Note that this takes the actual public key creates a key ID from it.

• int atcacert\_set\_auth\_key\_id\_raw (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*auth\_key\_id)

Sets the authority key ID in a certificate.

int atcacert\_get\_auth\_key\_id (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_t auth key id[20])

Gets the authority key ID from a certificate.

int atcacert\_set\_comp\_cert (const atcacert\_def\_t \*cert\_def, uint8\_t \*cert, size\_t \*cert\_size, size\_t max\_
 cert size, const uint8 t comp\_cert[72])

Sets the signature, issue date, expire date, and signer ID found in the compressed certificate. This also checks fields common between the cert\_def and the compressed certificate to make sure they match.

int atcacert\_get\_comp\_cert (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t comp\_cert[72])

Generate the compressed certificate for the given certificate.

• int atcacert\_get\_tbs (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*\*tbs, size\_t \*tbs\_size)

Get a pointer to the TBS data in a certificate.

int atcacert\_get\_tbs\_digest (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, uint8\_←
t tbs\_digest[32])

Get the SHA256 digest of certificate's TBS data.

• int atcacert\_set\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, uint8\_t \*cert, size\_t cert\_size, const uint8\_t \*data, size\_t data\_size)

Sets an element in a certificate. The data\_size must match the size in cert\_loc.

• int atcacert\_get\_cert\_element (const atcacert\_def\_t \*cert\_def, const atcacert\_cert\_loc\_t \*cert\_loc, const uint8\_t \*cert\_size\_t cert\_size, uint8\_t \*data, size\_t data\_size)

Gets an element from a certificate.

int atcacert\_get\_key\_id (const uint8\_t public\_key[64], uint8\_t key\_id[20])

Calculates the key ID for a given public ECC P256 key.

• int atcacert\_merge\_device\_loc (atcacert\_device\_loc\_t \*device\_locs, size\_t \*device\_locs\_count, size\_← t device\_locs\_max\_count, const atcacert\_device\_loc\_t \*device\_loc, size\_t block\_size)

Merge a new device location into a list of device locations. If the new location overlaps with an existing location, the existing one will be modified to encompass both. Otherwise the new location is appended to the end of the list.

• int atcacert\_is\_device\_loc\_overlap (const atcacert\_device\_loc\_t \*device\_loc1, const atcacert\_device\_loc\_t \*device\_loc2)

Determines if the two device locations overlap.

void atcacert\_public\_key\_add\_padding (const uint8\_t raw\_key[64], uint8\_t padded\_key[72])

Takes a raw P256 ECC public key and converts it to the padded version used by ATECC devices. Input and output buffers can point to the same location to do an in-place transform.

void atcacert\_public\_key\_remove\_padding (const uint8\_t padded\_key[72], uint8\_t raw\_key[64])

Takes a padded public key used by ATECC devices and converts it to a raw P256 ECC public key. Input and output buffers can point to the same location to do an in-place transform.

• int atcacert\_transform\_data (atcacert\_transform\_t transform, const uint8\_t \*data, size\_t data\_size, uint8\_t \*destination, size\_t \*destination\_size)

Apply the specified transform to the specified data.

• int atcacert max cert size (const atcacert def t \*cert def, size t \*max cert size)

Return the maximum possible certificate size in bytes for a given cert def. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificates.

### 20.55.1 Detailed Description

Declarations for certificates related to ECC CryptoAuthentication devices. These are the definitions required to define a certificate and its various elements with regards to the CryptoAuthentication ECC devices.

Only the dynamic elements of a certificate (the parts of the certificate that change from device to device) are stored on the ATECC device. The definitions here describe the form of the certificate, and where the dynamic elements can be found both on the ATECC device itself and in the certificate template.

This also defines utility functions for working with the certificates and their definitions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.55.2 Macro Definition Documentation

### 20.55.2.1 ATCA\_MAX\_TRANSFORMS

#define ATCA\_MAX\_TRANSFORMS 2

# 20.56 atcacert der.c File Reference

functions required to work with DER encoded data related to X.509 certificates.

```
#include "atcacert_der.h"
#include <string.h>
```

#### **Functions**

- int atcacert\_der\_enc\_length (uint32\_t length, uint8\_t \*der\_length, size\_t \*der\_length\_size)

  Encode a length in DER format.
- int atcacert\_der\_dec\_length (const uint8\_t \*der\_length, size\_t \*der\_length\_size, uint32\_t \*length)

  Decode a DER format length.
- int atcacert\_der\_adjust\_length (uint8\_t \*der\_length, size\_t \*der\_length\_size, int delta\_length, uint32\_
   t \*new\_length)
- int atcacert\_der\_enc\_integer (const uint8\_t \*int\_data, size\_t int\_data\_size, uint8\_t is\_unsigned, uint8\_← t \*der\_int, size\_t \*der\_int\_size)

Encode an ASN.1 integer in DER format, including tag and length fields.

int atcacert\_der\_dec\_integer (const uint8\_t \*der\_int, size\_t \*der\_int\_size, uint8\_t \*int\_data, size\_t \*int\_data, size\_t \*int\_data, size\_t \*int\_data, size\_t \*int\_data, size\_t \*int\_data

Decode an ASN.1 DER encoded integer.

- int atcacert\_der\_enc\_ecdsa\_sig\_value (const uint8\_t raw\_sig[64], uint8\_t \*der\_sig, size\_t \*der\_sig\_size)

  Formats a raw ECDSA P256 signature in the DER encoding found in X.509 certificates.
- int atcacert\_der\_dec\_ecdsa\_sig\_value (const uint8\_t \*der\_sig, size\_t \*der\_sig\_size, uint8\_t raw\_sig[64])

  Parses an ECDSA P256 signature in the DER encoding as found in X.509 certificates.

## 20.56.1 Detailed Description

functions required to work with DER encoded data related to X.509 certificates.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.57 atcacert der.h File Reference

function declarations required to work with DER encoded data related to X.509 certificates.

```
#include <stddef.h>
#include <stdint.h>
#include "atcacert.h"
```

#### **Functions**

- int atcacert\_der\_enc\_length (uint32\_t length, uint8\_t \*der\_length, size\_t \*der\_length\_size)

  Encode a length in DER format.
- int atcacert\_der\_dec\_length (const uint8\_t \*der\_length, size\_t \*der\_length\_size, uint32\_t \*length)

  Decode a DER format length.
- int atcacert\_der\_adjust\_length (uint8\_t \*der\_length, size\_t \*der\_length\_size, int delta\_length, uint32\_←
  t \*new length)
- int atcacert\_der\_enc\_integer (const uint8\_t \*int\_data, size\_t int\_data\_size, uint8\_t is\_unsigned, uint8\_←
  t \*der\_int, size\_t \*der\_int\_size)

Encode an ASN.1 integer in DER format, including tag and length fields.

int atcacert\_der\_dec\_integer (const uint8\_t \*der\_int, size\_t \*der\_int\_size, uint8\_t \*int\_data, size\_t \*int\_data size)

Decode an ASN.1 DER encoded integer.

- int atcacert\_der\_enc\_ecdsa\_sig\_value (const uint8\_t raw\_sig[64], uint8\_t \*der\_sig, size\_t \*der\_sig\_size)

  Formats a raw ECDSA P256 signature in the DER encoding found in X.509 certificates.
- int atcacert\_der\_dec\_ecdsa\_sig\_value (const uint8\_t \*der\_sig, size\_t \*der\_sig\_size, uint8\_t raw\_sig[64])

  Parses an ECDSA P256 signature in the DER encoding as found in X.509 certificates.

# 20.57.1 Detailed Description

function declarations required to work with DER encoded data related to X.509 certificates.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.58 atcacert host hw.c File Reference

host side methods using CryptoAuth hardware

```
#include "atcacert_host_hw.h"
#include "atca_basic.h"
#include "crypto/atca_crypto_sw_sha2.h"
```

#### **Functions**

• int atcacert\_verify\_cert\_hw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t ca\_public\_key[64])

Verify a certificate against its certificate authority's public key using the host's ATECC device for crypto functions.

- int atcacert\_gen\_challenge\_hw (uint8\_t challenge[32])
  - Generate a random challenge to be sent to the client using the RNG on the host's ATECC device.
- int atcacert\_verify\_response\_hw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8 t response[64])

Verify a client's response to a challenge using the host's ATECC device for crypto functions.

# 20.58.1 Detailed Description

host side methods using CryptoAuth hardware

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.59 atcacert host hw.h File Reference

host side methods using CryptoAuth hardware

```
#include <stddef.h>
#include <stdint.h>
#include "atcacert_def.h"
```

# **Functions**

• int atcacert\_verify\_cert\_hw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t ca\_public\_key[64])

Verify a certificate against its certificate authority's public key using the host's ATECC device for crypto functions.

- int atcacert\_gen\_challenge\_hw (uint8\_t challenge[32])
  - Generate a random challenge to be sent to the client using the RNG on the host's ATECC device.
- int atcacert\_verify\_response\_hw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8\_t response[64])

Verify a client's response to a challenge using the host's ATECC device for crypto functions.

# 20.59.1 Detailed Description

host side methods using CryptoAuth hardware

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.60 atcacert\_host\_sw.c File Reference

host side methods using software implementations

```
#include "atcacert_host_sw.h"
#include "crypto/atca_crypto_sw_sha2.h"
#include "crypto/atca_crypto_sw_ecdsa.h"
#include "crypto/atca_crypto_sw_rand.h"
```

#### **Functions**

• int atcacert\_verify\_cert\_sw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t ca\_public\_key[64])

Verify a certificate against its certificate authority's public key using software crypto functions. The function is currently not implemented.

int atcacert gen challenge sw (uint8 t challenge[32])

Generate a random challenge to be sent to the client using a software PRNG. The function is currently not implemented

• int atcacert\_verify\_response\_sw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8 t response[64])

Verify a client's response to a challenge using software crypto functions. The function is currently not implemented.

## 20.60.1 Detailed Description

host side methods using software implementations

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.61 atcacert\_host\_sw.h File Reference

Host side methods using software implementations. host-side, the one authenticating a client, of the authentication process. Crypto functions are performed using a software library.

```
#include <stddef.h>
#include <stdint.h>
#include "atcacert_def.h"
```

#### **Functions**

• int atcacert\_verify\_cert\_sw (const atcacert\_def\_t \*cert\_def, const uint8\_t \*cert, size\_t cert\_size, const uint8\_t ca\_public\_key[64])

Verify a certificate against its certificate authority's public key using software crypto functions. The function is currently not implemented.

int atcacert\_gen\_challenge\_sw (uint8\_t challenge[32])

Generate a random challenge to be sent to the client using a software PRNG. The function is currently not implemented.

• int atcacert\_verify\_response\_sw (const uint8\_t device\_public\_key[64], const uint8\_t challenge[32], const uint8\_t response[64])

Verify a client's response to a challenge using software crypto functions. The function is currently not implemented.

## 20.61.1 Detailed Description

Host side methods using software implementations. host-side, the one authenticating a client, of the authentication process. Crypto functions are performed using a software library.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.62 atcacert pem.c File Reference

Functions required to work with PEM encoded data related to X.509 certificates.

```
#include <string.h>
#include "atcacert.h"
#include "atcacert_pem.h"
#include "atca_helpers.h"
```

#### **Functions**

• int atcacert\_encode\_pem (const uint8\_t \*der, size\_t der\_size, char \*pem, size\_t \*pem\_size, const char \*header, const char \*footer)

Encode a DER data in PEM format.

• int atcacert\_decode\_pem (const char \*pem, size\_t pem\_size, uint8\_t \*der, size\_t \*der\_size, const char \*header, const char \*footer)

Decode PEM data into DER format.

int atcacert\_encode\_pem\_cert (const uint8\_t \*der\_cert, size\_t der\_cert\_size, char \*pem\_cert, size\_t \*pem←
cert\_size)

Encode a DER certificate in PEM format.

int atcacert\_encode\_pem\_csr (const uint8\_t \*der\_csr, size\_t der\_csr\_size, char \*pem\_csr, size\_t \*pem\_
 csr\_size)

Encode a DER CSR in PEM format.

int atcacert\_decode\_pem\_cert (const char \*pem\_cert, size\_t pem\_cert\_size, uint8\_t \*der\_cert, size\_t \*der ← cert\_size)

Decode a PEM certificate into DER format.

int atcacert\_decode\_pem\_csr (const char \*pem\_csr, size\_t pem\_csr\_size, uint8\_t \*der\_csr, size\_t \*der\_ ← csr\_size)

Extract the CSR certificate bytes from a PEM encoded CSR certificate.

## 20.62.1 Detailed Description

Functions required to work with PEM encoded data related to X.509 certificates.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.62.2 Function Documentation

#### 20.62.2.1 atcacert decode pem()

Decode PEM data into DER format.

| in     | pem      | PEM data to decode to DER.                                                 |
|--------|----------|----------------------------------------------------------------------------|
| in     | pem_size | PEM data size in bytes.                                                    |
| out    | der      | DER data is returned here.                                                 |
| in,out | der_size | As input, the size of the der buffer. As output, the size of the DER data. |
| in     | header   | Header to find the beginning of the PEM data.                              |
| in     | footer   | Footer to find the end of the PEM data.                                    |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.62.2.2 atcacert\_decode\_pem\_cert()

Decode a PEM certificate into DER format.

# **Parameters**

| in     | pem_cert      | PEM certificate to decode to DER.                                                      |
|--------|---------------|----------------------------------------------------------------------------------------|
| in     | pem_cert_size | PEM certificate size in bytes.                                                         |
| out    | der_cert      | DER certificate is returned here.                                                      |
| in,out | der_cert_size | As input, the size of the der_cert buffer. As output, the size of the DER certificate. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.62.2.3 atcacert\_decode\_pem\_csr()

Extract the CSR certificate bytes from a PEM encoded CSR certificate.

| in     | pem_csr      | PEM CSR to decode to DER.                                                     |
|--------|--------------|-------------------------------------------------------------------------------|
| in     | pem_csr_size | PEM CSR size in bytes.                                                        |
| out    | der_csr      | DER CSR is returned here.                                                     |
| in,out | der_csr_size | As input, the size of the der_csr buffer. As output, the size of the DER CSR. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.62.2.4 atcacert\_encode\_pem()

#### Encode a DER data in PEM format.

# **Parameters**

| in     | der      | DER data to be encoded as PEM.                                             |
|--------|----------|----------------------------------------------------------------------------|
| out    | der_size | DER data size in bytes.                                                    |
| out    | pem      | PEM encoded data is returned here.                                         |
| in,out | pem_size | As input, the size of the pem buffer. As output, the size of the PEM data. |
| in     | header   | Header to place at the beginning of the PEM data.                          |
| in     | footer   | Footer to place at the end of the PEM data.                                |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.62.2.5 atcacert\_encode\_pem\_cert()

Encode a DER certificate in PEM format.

| in     | der_cert      | DER certificate to be encoded as PEM.                                                  |
|--------|---------------|----------------------------------------------------------------------------------------|
| out    | der_cert_size | DER certificate size in bytes.                                                         |
| out    | pem_cert      | PEM encoded certificate is returned here.                                              |
| in,out | pem_cert_size | As input, the size of the pem_cert buffer. As output, the size of the PEM certificate. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.62.2.6 atcacert\_encode\_pem\_csr()

# Encode a DER CSR in PEM format.

#### **Parameters**

| in     | der_csr      | DER CSR to be encoded as PEM.                                                 |
|--------|--------------|-------------------------------------------------------------------------------|
| out    | der_csr_size | DER CSR size in bytes.                                                        |
| out    | pem_csr      | PEM encoded CSR is returned here.                                             |
| in,out | pem_csr_size | As input, the size of the pem_csr buffer. As output, the size of the PEM CSR. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63 atcacert\_pem.h File Reference

Functions for converting between DER and PEM formats.

```
#include <stdint.h>
```

## **Macros**

- #define PEM\_CERT\_BEGIN "-----BEGIN CERTIFICATE-----"
- #define PEM\_CERT\_END "-----END CERTIFICATE-----"
- #define PEM\_CSR\_BEGIN "-----BEGIN CERTIFICATE REQUEST-----"
- #define PEM\_CSR\_END "-----END CERTIFICATE REQUEST-----"

#### **Functions**

• int atcacert\_encode\_pem (const uint8\_t \*der, size\_t der\_size, char \*pem, size\_t \*pem\_size, const char \*header, const char \*footer)

Encode a DER data in PEM format.

• int atcacert\_decode\_pem (const char \*pem, size\_t pem\_size, uint8\_t \*der, size\_t \*der\_size, const char \*header, const char \*footer)

Decode PEM data into DER format.

int atcacert\_encode\_pem\_cert (const uint8\_t \*der\_cert, size\_t der\_cert\_size, char \*pem\_cert, size\_t \*pem←
cert\_size)

Encode a DER certificate in PEM format.

int atcacert\_decode\_pem\_cert (const char \*pem\_cert, size\_t pem\_cert\_size, uint8\_t \*der\_cert, size\_t \*der ← cert\_size)

Decode a PEM certificate into DER format.

int atcacert\_encode\_pem\_csr (const uint8\_t \*der\_csr, size\_t der\_csr\_size, char \*pem\_csr, size\_t \*pem\_←
 csr size)

Encode a DER CSR in PEM format.

int atcacert\_decode\_pem\_csr (const char \*pem\_csr, size\_t pem\_csr\_size, uint8\_t \*der\_csr, size\_t \*der\_←
csr\_size)

Extract the CSR certificate bytes from a PEM encoded CSR certificate.

# 20.63.1 Detailed Description

Functions for converting between DER and PEM formats.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.63.2 Macro Definition Documentation

## 20.63.2.1 PEM\_CERT\_BEGIN

```
#define PEM_CERT_BEGIN "----BEGIN CERTIFICATE----"
```

# 20.63.2.2 PEM\_CERT\_END

```
#define PEM_CERT_END "----END CERTIFICATE----"
```

## 20.63.2.3 PEM\_CSR\_BEGIN

```
#define PEM_CSR_BEGIN "----BEGIN CERTIFICATE REQUEST-----"
```

# 20.63.2.4 PEM\_CSR\_END

```
#define PEM_CSR_END "----END CERTIFICATE REQUEST----"
```

#### 20.63.3 Function Documentation

# 20.63.3.1 atcacert\_decode\_pem()

#### Decode PEM data into DER format.

## **Parameters**

| in     | pem      | PEM data to decode to DER.                                                 |
|--------|----------|----------------------------------------------------------------------------|
| in     | pem_size | PEM data size in bytes.                                                    |
| out    | der      | DER data is returned here.                                                 |
| in,out | der_size | As input, the size of the der buffer. As output, the size of the DER data. |
| in     | header   | Header to find the beginning of the PEM data.                              |
| in     | footer   | Footer to find the end of the PEM data.                                    |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63.3.2 atcacert\_decode\_pem\_cert()

## Decode a PEM certificate into DER format.

| in     | pem_cert      | PEM certificate to decode to DER.                                                      |
|--------|---------------|----------------------------------------------------------------------------------------|
| in     | pem_cert_size | PEM certificate size in bytes.                                                         |
| out    | der_cert      | DER certificate is returned here.                                                      |
| in,out | der_cert_size | As input, the size of the der_cert buffer. As output, the size of the DER certificate. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63.3.3 atcacert\_decode\_pem\_csr()

Extract the CSR certificate bytes from a PEM encoded CSR certificate.

#### **Parameters**

| in    | pem_csr         | PEM CSR to decode to DER.                                                     |
|-------|-----------------|-------------------------------------------------------------------------------|
| in    | pem_csr_size    | PEM CSR size in bytes.                                                        |
| out   | der_csr         | DER CSR is returned here.                                                     |
| in,ou | it der_csr_size | As input, the size of the der_csr buffer. As output, the size of the DER CSR. |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63.3.4 atcacert\_encode\_pem()

Encode a DER data in PEM format.

| in     | der      | DER data to be encoded as PEM.                                             |
|--------|----------|----------------------------------------------------------------------------|
| out    | der_size | DER data size in bytes.                                                    |
| out    | pem      | PEM encoded data is returned here.                                         |
| in,out | pem_size | As input, the size of the pem buffer. As output, the size of the PEM data. |
| in     | header   | Header to place at the beginning of the PEM data.                          |
| in     | footer   | Footer to place at the end of the PEM data.                                |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63.3.5 atcacert\_encode\_pem\_cert()

Encode a DER certificate in PEM format.

#### **Parameters**

| in     | der_cert      | DER certificate to be encoded as PEM.                                                  |
|--------|---------------|----------------------------------------------------------------------------------------|
| out    | der_cert_size | DER certificate size in bytes.                                                         |
| out    | pem_cert      | PEM encoded certificate is returned here.                                              |
| in,out | pem_cert_size | As input, the size of the pem_cert buffer. As output, the size of the PEM certificate. |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.63.3.6 atcacert\_encode\_pem\_csr()

Encode a DER CSR in PEM format.

| in     | der_csr      | DER CSR to be encoded as PEM.                                                 |
|--------|--------------|-------------------------------------------------------------------------------|
| out    | der_csr_size | DER CSR size in bytes.                                                        |
| out    | pem_csr      | PEM encoded CSR is returned here.                                             |
| in,out | pem_csr_size | As input, the size of the pem_csr buffer. As output, the size of the PEM CSR. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.64 calib\_aes.c File Reference

CryptoAuthLib Basic API methods for AES command.

#include "cryptoauthlib.h"

## **Functions**

ATCA\_STATUS calib\_aes (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8←
 \_t \*aes\_out)

Compute the AES-128 encrypt, decrypt, or GFM calculation.

ATCA\_STATUS calib\_aes\_encrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8\_t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

ATCA\_STATUS calib\_aes\_decrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

• ATCA\_STATUS calib\_aes\_gfm (ATCADevice device, const uint8\_t \*h, const uint8\_t \*input, uint8\_t \*output)

Perform a Galois Field Multiply (GFM) operation.

## 20.64.1 Detailed Description

CryptoAuthLib Basic API methods for AES command.

The AES command supports 128-bit AES encryption or decryption of small messages or data packets in ECB mode. Also can perform GFM (Galois Field Multiply) calculation in support of AES-GCM.

Note

List of devices that support this command - ATECC608A/B. Refer to device edatasheet for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 666

# 20.65 calib aes gcm.c File Reference

CryptoAuthLib Basic API methods for AES GCM mode.

```
#include "cryptoauthlib.h"
#include "calib_aes_gcm.h"
```

- #define RETURN return ATCA TRACE
- const char \* atca\_basic\_aes\_gcm\_version = "2.0"
- ATCA\_STATUS calib\_aes\_gcm\_init (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8
   — t key\_block, const uint8\_t \*iv, size\_t iv\_size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

ATCA\_STATUS calib\_aes\_gcm\_init\_rand (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, size\_t rand\_size, const uint8\_t \*free\_field, size\_t free\_field\_size, uint8\_t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS calib\_aes\_gcm\_aad\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32\_t aad\_size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

 ATCA\_STATUS calib\_aes\_gcm\_encrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8 t \*plaintext, uint32 t plaintext size, uint8 t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS calib\_aes\_gcm\_encrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size\_t tag\_size)

Complete a GCM encrypt operation returning the authentication tag.

 ATCA\_STATUS calib\_aes\_gcm\_decrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32\_t ciphertext\_size, uint8\_t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

 ATCA\_STATUS calib\_aes\_gcm\_decrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag\_size, bool \*is\_verified)

Complete a GCM decrypt operation verifying the authentication tag.

## 20.65.1 Detailed Description

CryptoAuthLib Basic API methods for AES GCM mode.

The AES command supports 128-bit AES encryption or decryption of small messages or data packets in ECB mode. Also can perform GFM (Galois Field Multiply) calculation in support of AES-GCM.

Note

List of devices that support this command - ATECC608A/B. Refer to device datasheet for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.65.2 Macro Definition Documentation

#### 20.65.2.1 RETURN

```
#define RETURN return ATCA_TRACE
```

## 20.65.3 Function Documentation

## 20.65.3.1 calib\_aes\_gcm\_aad\_update()

```
ATCA_STATUS calib_aes_gcm_aad_update (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * aad,
    uint32_t aad_size)
```

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

This can be called multiple times. <a href="atcab\_aes\_gcm\_init">atcab\_aes\_gcm\_init</a>() or <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function. When there is AAD to include, this should be called before <a href="atcab\_aes\_gcm\_encrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_encrypt\_update</a>() or <a href="atcab\_aes\_gcm\_decrypt\_update">atcab\_aes\_gcm\_decrypt\_update</a>().

#### **Parameters**

| in | device   | Device context pointer                    |
|----|----------|-------------------------------------------|
| in | ctx      | AES GCM context                           |
| in | aad      | Additional authenticated data to be added |
| in | aad_size | Size of aad in bytes                      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.65.3.2 calib\_aes\_gcm\_decrypt\_finish()

Complete a GCM decrypt operation verifying the authentication tag.

| in                 | device      | Device context pointer                   |
|--------------------|-------------|------------------------------------------|
| in                 | ctx         | AES GCM context structure.               |
| in                 | tag         | Expected authentication tag.             |
| in <i>tag_size</i> |             | Size of tag in bytes (12 to 16 bytes).   |
| out                | is_verified | Returns whether or not the tag verified. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.65.3.3 calib\_aes\_gcm\_decrypt\_update()

Decrypt data using GCM mode and a key within the ATECC608 device. <a href="atcab\_aes\_gcm\_init\_rand">atcab\_aes\_gcm\_init\_rand</a>() should be called before the first use of this function.

#### **Parameters**

| in  | device          | Device context pointer           |
|-----|-----------------|----------------------------------|
| in  | ctx             | AES GCM context structure.       |
| in  | ciphertext      | Ciphertext to be decrypted.      |
| in  | ciphertext_size | Size of ciphertext in bytes.     |
| out | plaintext       | Decrypted data is returned here. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.65.3.4 calib\_aes\_gcm\_encrypt\_finish()

Complete a GCM encrypt operation returning the authentication tag.

| in  | device   | Device context pointer               |
|-----|----------|--------------------------------------|
| in  | ctx      | AES GCM context structure.           |
| out | tag      | Authentication tag is returned here. |
| in  | tag_size | Tag size in bytes (12 to 16 bytes).  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.65.3.5 calib\_aes\_gcm\_encrypt\_update()

```
ATCA_STATUS calib_aes_gcm_encrypt_update (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    const uint8_t * plaintext,
    uint32_t plaintext_size,
    uint8_t * ciphertext)
```

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init rand() should be called before the first use of this function.

#### **Parameters**

| in                       | device     | Device context pointer                |
|--------------------------|------------|---------------------------------------|
| in                       | ctx        | AES GCM context structure.            |
| in                       | plaintext  | Plaintext to be encrypted (16 bytes). |
| in <i>plaintext_size</i> |            | Size of plaintext in bytes.           |
| out                      | ciphertext | Encrypted data is returned here.      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.65.3.6 calib\_aes\_gcm\_init()

```
ATCA_STATUS calib_aes_gcm_init (
    ATCADevice device,
    atca_aes_gcm_ctx_t * ctx,
    uint16_t key_id,
    uint8_t key_block,
    const uint8_t * iv,
    size_t iv_size )
```

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

| in | device    | Device context pointer                                                        |
|----|-----------|-------------------------------------------------------------------------------|
| in | ctx       | AES GCM context to be initialized.                                            |
| in | key_id    | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.  |
| in | key_block | Index of the 16-byte block to use within the key location for the actual key. |
| in | iv        | Initialization vector.                                                        |
| in | iv_size   | Size of IV in bytes. Standard is 12 bytes.                                    |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.65.3.7 calib\_aes\_gcm\_init\_rand()

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

## **Parameters**

| in  | device          | Device context pointer                                                                           |
|-----|-----------------|--------------------------------------------------------------------------------------------------|
| in  | ctx             | AES CTR context to be initialized.                                                               |
| in  | key_id          | Key location. Can either be a slot number or ATCA_TEMPKEY_KEYID for TempKey.                     |
| in  | key_block       | Index of the 16-byte block to use within the key location for the actual key.                    |
| in  | rand_size       | Size of the random field in bytes. Minimum and recommended size is 12 bytes. Max is 32 bytes.    |
| in  | free_field      | Fixed data to include in the IV after the random field. Can be NULL if not used.                 |
| in  | free_field_size | Size of the free field in bytes.                                                                 |
| out | iv              | Initialization vector is returned here. Its size will be rand_size and free_field_size combined. |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.66 calib\_aes\_gcm.h File Reference

Unity tests for the cryptoauthlib AES GCM functions.

#### **Data Structures**

- struct atca\_aes\_gcm\_ctx
- #define ATCA\_AES\_GCM\_IV\_STD\_LENGTH 12
- typedef struct atca\_aes\_gcm\_ctx atca\_aes\_gcm\_ctx\_t
- const char \* atca basic aes gcm version
- ATCA\_STATUS calib\_aes\_gcm\_init (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8← t key block, const uint8 t \*iv, size t iv size)

Initialize context for AES GCM operation with an existing IV, which is common when starting a decrypt operation.

ATCA\_STATUS calib\_aes\_gcm\_init\_rand (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint16\_t key\_id, uint8\_t key\_block, size\_t rand\_size, const uint8\_t \*free\_field, size\_t free\_field\_size, uint8\_t \*iv)

Initialize context for AES GCM operation with a IV composed of a random and optional fixed(free) field, which is common when starting an encrypt operation.

ATCA\_STATUS calib\_aes\_gcm\_aad\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*aad, uint32 t aad size)

Process Additional Authenticated Data (AAD) using GCM mode and a key within the ATECC608 device.

• ATCA\_STATUS calib\_aes\_gcm\_encrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8 t \*plaintext, uint32 t plaintext size, uint8 t \*ciphertext)

Encrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

ATCA\_STATUS calib\_aes\_gcm\_encrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, uint8\_t \*tag, size\_t tag\_size)

Complete a GCM encrypt operation returning the authentication tag.

• ATCA\_STATUS calib\_aes\_gcm\_decrypt\_update (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*ciphertext, uint32\_t ciphertext\_size, uint8\_t \*plaintext)

Decrypt data using GCM mode and a key within the ATECC608 device. atcab\_aes\_gcm\_init() or atcab\_aes\_gcm\_init\_rand() should be called before the first use of this function.

• ATCA\_STATUS calib\_aes\_gcm\_decrypt\_finish (ATCADevice device, atca\_aes\_gcm\_ctx\_t \*ctx, const uint8\_t \*tag, size\_t tag\_size, bool \*is\_verified)

Complete a GCM decrypt operation verifying the authentication tag.

# 20.66.1 Detailed Description

Unity tests for the cryptoauthlib AES GCM functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.67 calib\_basic.c File Reference

CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core crypto methods.

```
#include "cryptoauthlib.h"
```

#### **Macros**

• #define MAX BUSES 4

#### **Functions**

ATCA\_STATUS calib\_wakeup (ATCADevice device)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA\_STATUS calib\_idle (ATCADevice device)

idle the CryptoAuth device

ATCA STATUS calib sleep (ATCADevice device)

invoke sleep on the CryptoAuth device

ATCA\_STATUS calib\_cfg\_discover (ATCAlfaceCfg cfg\_array[], int max\_ifaces)

auto discovery of crypto auth devices

ATCA\_STATUS \_calib\_exit (ATCADevice device)

common cleanup code which idles the device after any operation

• ATCA\_STATUS calib\_get\_addr (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint16\_t \*addr)

Compute the address given the zone, slot, block, and offset.

• ATCA\_STATUS calib\_get\_zone\_size (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t \*size)

Gets the size of the specified zone in bytes.

## 20.67.1 Detailed Description

CryptoAuthLib Basic API methods. These methods provide a simpler way to access the core crypto methods.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.67.2 Macro Definition Documentation

### 20.67.2.1 MAX BUSES

```
#define MAX_BUSES 4
```

# 20.68 calib\_basic.h File Reference

```
#include "calib_command.h"
#include "calib_execution.h"
```

#### **Data Structures**

struct atca\_sha256\_ctx

# **Typedefs**

- typedef struct atca sha256 ctx atca sha256 ctx t
- typedef atca\_sha256\_ctx\_t atca\_hmac\_sha256\_ctx\_t

#### **Functions**

ATCA STATUS calib\_wakeup (ATCADevice device)

basic API methods are all prefixed with atcab\_ (CryptoAuthLib Basic) the fundamental premise of the basic API is it is based on a single interface instance and that instance is global, so all basic API commands assume that one global device is the one to operate on.

ATCA STATUS calib idle (ATCADevice device)

idle the CryptoAuth device

ATCA\_STATUS calib\_sleep (ATCADevice device)

invoke sleep on the CryptoAuth device

ATCA STATUS calib exit (ATCADevice device)

common cleanup code which idles the device after any operation

ATCA\_STATUS calib\_cfg\_discover (ATCAlfaceCfg cfg\_array[], int max)

auto discovery of crypto auth devices

- ATCA\_STATUS calib\_get\_addr (uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_t offset, uint16\_t \*addr)
   Compute the address given the zone, slot, block, and offset.
- ATCA\_STATUS calib\_get\_zone\_size (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t \*size)

  Gets the size of the specified zone in bytes.
- ATCA\_STATUS calib\_aes (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*aes\_in, uint8←
   \_t \*aes\_out)

Compute the AES-128 encrypt, decrypt, or GFM calculation.

ATCA\_STATUS calib\_aes\_encrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*plaintext, uint8 t \*ciphertext)

Perform an AES-128 encrypt operation with a key in the device.

 ATCA\_STATUS calib\_aes\_decrypt (ATCADevice device, uint16\_t key\_id, uint8\_t key\_block, const uint8\_t \*ciphertext, uint8\_t \*plaintext)

Perform an AES-128 decrypt operation with a key in the device.

- ATCA\_STATUS calib\_aes\_gfm (ATCADevice device, const uint8\_t \*h, const uint8\_t \*input, uint8\_t \*output)

  Perform a Galois Field Multiply (GFM) operation.
- ATCA\_STATUS calib\_checkmac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_←
   t \*challenge, const uint8\_t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

ATCA\_STATUS calib\_counter (ATCADevice device, uint8\_t mode, uint16\_t counter\_id, uint32\_t \*counter 
 \_value)

Compute the Counter functions.

ATCA\_STATUS calib\_counter\_increment (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_
 value)

Increments one of the device's monotonic counters.

- ATCA\_STATUS calib\_counter\_read (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_value)

  Read one of the device's monotonic counters.
- ATCA\_STATUS calib\_derivekey (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*mac)

  Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.
- ATCA\_STATUS calib\_ecdh\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_← t \*public\_key, uint8\_t \*pms, uint8\_t \*out\_nonce)

Base function for generating premaster secret key using ECDH.

• ATCA\_STATUS calib\_ecdh (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in a slot and the premaster secret is returned in the clear.

- ATCA\_STATUS calib\_ecdh\_enc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_←
  t \*pms, const uint8\_t \*read\_key, uint16\_t read\_key\_id, const uint8\_t num\_in[(20)])
- ATCA\_STATUS calib\_ecdh\_ioenc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS calib\_ecdh\_tempkey (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms)

ECDH command with a private key in TempKey and the premaster secret is returned in the clear.

ATCA\_STATUS calib\_ecdh\_tempkey\_ioenc (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key.

ATCA\_STATUS calib\_gendig (ATCADevice device, uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8 t other data size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

ATCA\_STATUS calib\_genkey\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_←
t \*other data, uint8 t \*public key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

ATCA\_STATUS calib\_genkey (ATCADevice device, uint16\_t key\_id, uint8\_t \*public\_key)

Issues GenKey command, which generates a new random private key in slot and returns the public key.

ATCA\_STATUS calib\_get\_pubkey (ATCADevice device, uint16\_t key\_id, uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

ATCA\_STATUS calib\_hmac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, uint8\_t \*digest)

Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

ATCA\_STATUS calib\_info\_base (ATCADevice device, uint8\_t mode, uint16\_t param2, uint8\_t \*out\_data)

Issues an Info command, which return internal device information and can control GPIO and the persistent latch.

ATCA\_STATUS calib\_info (ATCADevice device, uint8\_t \*revision)

Use the Info command to get the device revision (DevRev).

ATCA\_STATUS calib\_info\_set\_latch (ATCADevice device, bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

ATCA\_STATUS calib\_info\_get\_latch (ATCADevice device, bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

 ATCA\_STATUS calib\_kdf (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8\_t \*out\_data, uint8\_t \*out\_nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

• ATCA STATUS calib lock (ATCADevice device, uint8 t mode, uint16 t summary crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

• ATCA\_STATUS calib\_lock\_config\_zone (ATCADevice device)

Unconditionally (no CRC required) lock the config zone.

• ATCA\_STATUS calib\_lock\_config\_zone\_crc (ATCADevice device, uint16\_t summary\_crc)

Lock the config zone with summary CRC.

• ATCA STATUS calib lock data zone (ATCADevice device)

Unconditionally (no CRC required) lock the data zone (slots and OTP).

• ATCA STATUS calib lock data zone crc (ATCADevice device, uint16 t summary crc)

Lock the data zone (slots and OTP) with summary CRC.

ATCA STATUS calib lock data slot (ATCADevice device, uint16 t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1).

 ATCA\_STATUS calib\_mac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, uint8\_t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

• ATCA\_STATUS calib\_nonce\_base (ATCADevice device, uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

ATCA\_STATUS calib\_nonce (ATCADevice device, const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_nonce\_load (ATCADevice device, uint8\_t target, const uint8\_t \*num\_in, uint16\_
 t num\_in\_size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

• ATCA STATUS calib nonce rand (ATCADevice device, const uint8 t \*num in, uint8 t \*rand out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number

• ATCA STATUS calib challenge (ATCADevice device, const uint8 t \*num in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_challenge\_seed\_update (ATCADevice device, const uint8\_t \*num\_in, uint8\_t \*rand
 — out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number

- ATCA\_STATUS calib\_priv\_write (ATCADevice device, uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write\_key\_id, const uint8\_t write\_key[32], const uint8\_t num\_in[(20)])
- ATCA\_STATUS calib\_random (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the CryptoAuth device.

ATCA\_STATUS calib\_read\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_←
t offset, uint8 t \*data, uint8 t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone

ATCA STATUS calib is locked (ATCADevice device, uint8 t zone, bool \*is locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

ATCA\_STATUS calib\_is\_slot\_locked (ATCADevice device, uint16\_t slot, bool \*is\_locked)

Executes Read command, which reads the configuration zone to see if the specified slot is locked.

ATCA\_STATUS calib\_read\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset, uint8 t \*data, size t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

ATCA\_STATUS calib\_read\_serial\_number (ATCADevice device, uint8\_t \*serial\_number)

Executes Read command, which reads the 9 byte serial number of the device from the config zone.

ATCA\_STATUS calib\_read\_pubkey (ATCADevice device, uint16\_t slot, uint8\_t \*public\_key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

• ATCA\_STATUS calib\_read\_sig (ATCADevice device, uint16\_t slot, uint8\_t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

ATCA\_STATUS calib\_read\_config\_zone (ATCADevice device, uint8\_t \*config\_data)

Executes Read command to read the complete device configuration zone.

• ATCA\_STATUS calib\_cmp\_config\_zone (ATCADevice device, uint8\_t \*config\_data, bool \*same\_config)

Compares a specified configuration zone with the configuration zone currently on the device.

- ATCA\_STATUS calib\_read\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])
- ATCA\_STATUS calib\_secureboot (ATCADevice device, uint8\_t mode, uint16\_t param2, const uint8\_← t \*digest, const uint8 t \*signature, uint8 t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

• ATCA\_STATUS calib\_secureboot\_mac (ATCADevice device, uint8\_t mode, const uint8\_t \*digest, const uint8\_t \*signature, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

ATCA STATUS calib selftest (ATCADevice device, uint8 t mode, uint16 t param2, uint8 t \*result)

Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT← ECC608 chip.

ATCA\_STATUS calib\_sha\_base (ATCADevice device, uint8\_t mode, uint16\_t length, const uint8\_t \*data\_in, uint8\_t \*data\_out, uint16\_t \*data\_out\_size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

ATCA\_STATUS calib\_sha\_start (ATCADevice device)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA\_STATUS calib\_sha\_update (ATCADevice device, const uint8\_t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

ATCA\_STATUS calib\_sha\_end (ATCADevice device, uint8\_t \*digest, uint16\_t length, const uint8\_←
t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

- ATCA\_STATUS calib\_sha\_read\_context (ATCADevice device, uint8\_t \*context, uint16\_t \*context\_size)
  - Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.
- ATCA\_STATUS calib\_sha\_write\_context (ATCADevice device, const uint8\_t \*context, uint16\_t context\_size)
   Executes SHA command to write (restore) a SHA-256 context into the device. Only supported for ATECC608 with SHA-256 contexts.
- ATCA\_STATUS calib\_sha (ATCADevice device, uint16\_t length, const uint8\_t \*message, uint8\_t \*digest)

  Use the SHA command to compute a SHA-256 digest.
- ATCA\_STATUS calib\_hw\_sha2\_256 (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint8\_←
  t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA\_STATUS calib\_hw\_sha2\_256\_init (ATCADevice device, atca\_sha256\_ctx\_t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

• ATCA\_STATUS calib\_hw\_sha2\_256\_update (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, const uint8\_← t \*data, size t data size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

- ATCA\_STATUS calib\_hw\_sha2\_256\_finish (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, uint8\_t \*digest)

  Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.
- ATCA\_STATUS calib\_sha\_hmac\_init (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_
   slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_update (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8
 —
 t \*data, size\_t data\_size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_finish (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_←
 t \*digest, uint8 t target)

Executes SHA command to complete a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint16\_t key
 slot, uint8\_t \*digest, uint8\_t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

- ATCA\_STATUS calib\_sign\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, uint8\_t \*signature)

  Executes the Sign command, which generates a signature using the ECDSA algorithm.
- ATCA\_STATUS calib\_sign (ATCADevice device, uint16\_t key\_id, const uint8\_t \*msg, uint8\_t \*signature)

Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

 ATCA\_STATUS calib\_sign\_internal (ATCADevice device, uint16\_t key\_id, bool is\_invalidate, bool is\_full\_sn, uint8\_t \*signature)

Executes Sign command to sign an internally generated message.

ATCA\_STATUS calib\_updateextra (ATCADevice device, uint8\_t mode, uint16\_t new\_value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

ATCA\_STATUS calib\_verify (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS calib\_verify\_extern (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public key, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS calib\_verify\_extern\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_←
t \*signature, const uint8\_t \*public\_key, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

 ATCA\_STATUS calib\_verify\_stored (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp

Key for other devices.

ATCA\_STATUS calib\_verify\_stored\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_←
t \*signature, uint16 t key id, const uint8 t \*num in, const uint8 t \*io key, bool \*is verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

 ATCA\_STATUS calib\_verify\_validate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8 t \*other data, bool \*is verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

ATCA\_STATUS calib\_verify\_invalidate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

 ATCA\_STATUS calib\_write (ATCADevice device, uint8\_t zone, uint16\_t address, const uint8\_t \*value, const uint8\_t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

• ATCA\_STATUS calib\_write\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_ t offset, const uint8\_t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

• ATCA\_STATUS calib\_write\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

ATCA\_STATUS calib\_write\_pubkey (ATCADevice device, uint16\_t slot, const uint8\_t \*public\_key)

Uses the write command to write a public key to a slot in the proper format.

ATCA\_STATUS calib\_write\_config\_zone (ATCADevice device, const uint8\_t \*config\_data)

Executes the Write command, which writes the configuration zone.

- ATCA\_STATUS calib\_write\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[(20)])
- ATCA\_STATUS calib\_write\_config\_counter (ATCADevice device, uint16\_t counter\_id, uint32\_t counter\_
   value)

Initialize one of the monotonic counters in device with a specific value.

# 20.69 calib checkmac.c File Reference

CryptoAuthLib Basic API methods for CheckMAC command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

• ATCA\_STATUS calib\_checkmac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_← t \*challenge, const uint8\_t \*response, const uint8\_t \*other\_data)

Compares a MAC response with input values.

# 20.69.1 Detailed Description

CryptoAuthLib Basic API methods for CheckMAC command.

The CheckMac command calculates a MAC response that would have been generated on a different Crypto ← Authentication device and then compares the result with input value.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.70 calib\_command.c File Reference

Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send that byte string through the device interface.

```
#include "cryptoauthlib.h"
```

#### **Functions**

ATCA\_STATUS atCheckMAC (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand CheckMAC method.

ATCA STATUS atCounter (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Counter method.

ATCA\_STATUS atDeriveKey (ATCACommand ca\_cmd, ATCAPacket \*packet, bool has\_mac)

ATCACommand DeriveKey method.

ATCA STATUS atECDH (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand ECDH method.

ATCA\_STATUS atGenDig (ATCACommand ca\_cmd, ATCAPacket \*packet, bool is\_no\_mac\_key)

ATCACommand Generate Digest method.

ATCA\_STATUS atGenKey (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Generate Key method.

ATCA\_STATUS atHMAC (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand HMAC method.

ATCA\_STATUS atInfo (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Info method.

• ATCA\_STATUS atLock (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Lock method.

ATCA\_STATUS atMAC (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand MAC method.

ATCA STATUS atNonce (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Nonce method.

ATCA\_STATUS atPause (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Pause method.

ATCA STATUS atPrivWrite (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand PrivWrite method.

ATCA\_STATUS atRandom (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Random method.

ATCA STATUS atRead (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Read method.

• ATCA\_STATUS atSecureBoot (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand SecureBoot method.

ATCA STATUS atSHA (ATCACommand ca cmd, ATCAPacket \*packet, uint16 t write context size)

ATCACommand SHA method.

ATCA\_STATUS atSign (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Sign method.

ATCA\_STATUS atUpdateExtra (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand UpdateExtra method.

• ATCA STATUS atVerify (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand ECDSA Verify method.

ATCA\_STATUS atWrite (ATCACommand ca\_cmd, ATCAPacket \*packet, bool has\_mac)

ATCACommand Write method.

ATCA STATUS atAES (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand AES method.

ATCA\_STATUS atSelfTest (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand AES method.

ATCA STATUS atKDF (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand KDF method.

• void atCRC (size\_t length, const uint8\_t \*data, uint8\_t \*crc\_le)

Calculates CRC over the given raw data and returns the CRC in little-endian byte order.

void atCalcCrc (ATCAPacket \*packet)

This function calculates CRC and adds it to the correct offset in the packet data.

ATCA\_STATUS atCheckCrc (const uint8\_t \*response)

This function checks the consistency of a response.

bool atIsSHAFamily (ATCADeviceType device\_type)

determines if a given device type is a SHA device or a superset of a SHA device

bool atIsECCFamily (ATCADeviceType device type)

determines if a given device type is an ECC device or a superset of a ECC device

• ATCA\_STATUS is ATCAError (uint8\_t \*data)

checks for basic error frame in data

# 20.70.1 Detailed Description

Microchip CryptoAuthentication device command builder - this is the main object that builds the command byte strings for the given device. It does not execute the command. The basic flow is to call a command method to build the command you want given the parameters and then send that byte string through the device interface.

The primary goal of the command builder is to wrap the given parameters with the correct packet size and CRC. The caller should first fill in the parameters required in the ATCAPacket parameter given to the command. The command builder will deal with the mechanics of creating a valid packet using the parameter information.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.70.2 Function Documentation

#### 20.70.2.1 atAES()

```
ATCA_STATUS atAES (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand AES method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

# 20.70.2.2 atCalcCrc()

This function calculates CRC and adds it to the correct offset in the packet data.

## **Parameters**

|  | in | packet | Packet to calculate CRC data for |  |
|--|----|--------|----------------------------------|--|
|--|----|--------|----------------------------------|--|

# 20.70.2.3 atCheckCrc()

This function checks the consistency of a response.

#### **Parameters**

| in | response | pointer to response |
|----|----------|---------------------|
|----|----------|---------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise ATCA\_RX\_CRC\_ERROR

# 20.70.2.4 atCheckMAC()

```
ATCA_STATUS atCheckMAC (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand CheckMAC method.

# **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS

# 20.70.2.5 atCounter()

```
ATCA_STATUS atCounter (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

# ATCACommand Counter method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.70.2.6 atCRC()

Calculates CRC over the given raw data and returns the CRC in little-endian byte order.

## **Parameters**

| in  | length | Size of data not including the CRC byte positions                                             |
|-----|--------|-----------------------------------------------------------------------------------------------|
| in  | data   | Pointer to the data over which to compute the CRC                                             |
| out | crc←   | Pointer to the place where the two-bytes of CRC will be returned in little-endian byte order. |
|     | _le    |                                                                                               |

## 20.70.2.7 atDeriveKey()

```
ATCA_STATUS atDeriveKey (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool has_mac )
```

## ATCACommand DeriveKey method.

### **Parameters**

| in | ca_cmd  | instance                                                     |
|----|---------|--------------------------------------------------------------|
| in | packet  | pointer to the packet containing the command being built     |
| in | has_mac | hasMAC determines if MAC data is present in the packet input |

#### Returns

ATCA\_SUCCESS

# 20.70.2.8 atECDH()

```
ATCA_STATUS atECDH (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand ECDH method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

# 20.70.2.9 atGenDig()

```
ATCA_STATUS atGenDig (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool is_no_mac_key )
```

ATCACommand Generate Digest method.

## **Parameters**

| in | ca_cmd        | instance                                                                              |
|----|---------------|---------------------------------------------------------------------------------------|
| in | packet        | pointer to the packet containing the command being built                              |
| in | is_no_mac_key | Should be true if GenDig is being run on a slot that has its SlotConfig.NoMac bit set |

## Returns

ATCA\_SUCCESS

# 20.70.2.10 atGenKey()

```
ATCA_STATUS atGenKey (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand Generate Key method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

# 20.70.2.11 atHMAC()

```
ATCA_STATUS atHMAC (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand HMAC method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS

## 20.70.2.12 atInfo()

```
ATCA_STATUS atInfo (
ATCACommand ca_cmd,
ATCAPacket * packet )
```

# ATCACommand Info method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS

# 20.70.2.13 atlsECCFamily()

determines if a given device type is an ECC device or a superset of a ECC device

## **Parameters**

|  | in | device_type | Type of device to check for family type |  |
|--|----|-------------|-----------------------------------------|--|
|--|----|-------------|-----------------------------------------|--|

### Returns

boolean indicating whether the given device is an ECC family device.

## 20.70.2.14 atIsSHAFamily()

determines if a given device type is a SHA device or a superset of a SHA device

### **Parameters**

|  | in | device_type | Type of device to check for family type | 1 |
|--|----|-------------|-----------------------------------------|---|
|--|----|-------------|-----------------------------------------|---|

### Returns

boolean indicating whether the given device is a SHA family device.

## 20.70.2.15 atKDF()

```
ATCA_STATUS atKDF (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand KDF method.

### **Parameters**

| in | ca_cmd | Instance                                                  |
|----|--------|-----------------------------------------------------------|
| in | packet | Pointer to the packet containing the command being built. |

## Returns

ATCA\_SUCCESS

# 20.70.2.16 atLock()

```
ATCA_STATUS atLock (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand Lock method.

# **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.70.2.17 atMAC()

```
ATCA_STATUS atMAC (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand MAC method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

# 20.70.2.18 atNonce()

```
ATCA_STATUS atNonce (
ATCACommand ca_cmd,
ATCAPacket * packet )
```

ATCACommand Nonce method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.70.2.19 atPause()

```
ATCA_STATUS atPause (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand Pause method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.70.2.20 atPrivWrite()

## ATCACommand PrivWrite method.

# **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS

# 20.70.2.21 atRandom()

```
ATCA_STATUS atRandom (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

# ATCACommand Random method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.70.2.22 atRead()

```
ATCA_STATUS atRead (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand Read method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

# 20.70.2.23 atSecureBoot()

```
ATCA_STATUS atSecureBoot (  \begin{tabular}{lll} ATCACommand & ca\_cmd, \\ ATCAPacket & *packet \end{tabular} \label{eq:atcapacket} \end{tabular}
```

## ATCACommand SecureBoot method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.70.2.24 atSelfTest()

```
ATCA_STATUS atSelfTest (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand AES method.

## **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

## 20.70.2.25 atSHA()

```
ATCA_STATUS atSHA (

ATCACommand ca_cmd,

ATCAPacket * packet,

uint16_t write_context_size )
```

## ATCACommand SHA method.

# **Parameters**

| in               | ca_cmd             | instance                                                 |  |
|------------------|--------------------|----------------------------------------------------------|--|
| in <i>packet</i> |                    | pointer to the packet containing the command being built |  |
| in               | write_context_size | the length of the sha write_context data                 |  |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.70.2.26 atSign()

```
ATCA_STATUS atSign (  \begin{tabular}{ll} ATCACommand $ca\_cmd$, \\ ATCAPacket * packet \end{tabular} )
```

ATCACommand Sign method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.70.2.27 atUpdateExtra()

```
ATCA_STATUS atUpdateExtra (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand UpdateExtra method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

# Returns

ATCA\_SUCCESS

# 20.70.2.28 atVerify()

```
ATCA_STATUS atVerify (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand ECDSA Verify method.

# **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.70.2.29 atWrite()

```
ATCA_STATUS atWrite (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool has_mac )
```

ATCACommand Write method.

#### **Parameters**

|   | in | ca_cmd  | instance                                                 |
|---|----|---------|----------------------------------------------------------|
| ſ | in | packet  | pointer to the packet containing the command being built |
| Ī | in | has_mac | Flag to indicate whether a mac is present or not         |

### Returns

ATCA\_SUCCESS

## 20.70.2.30 isATCAError()

```
ATCA_STATUS isATCAError ( uint8_t * data )
```

checks for basic error frame in data

#### **Parameters**

| in | data | pointer to received data - expected to be in the form of a CA device response frame |  |
|----|------|-------------------------------------------------------------------------------------|--|
|----|------|-------------------------------------------------------------------------------------|--|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.71 calib\_command.h File Reference

Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the ATCAIFace object to dispatch.

```
#include <stddef.h>
#include "atca_command.h"
```

### **Data Structures**

struct ATCAPacket

#### **Macros**

```
    #define ATCA_CMD_SIZE_MIN ((uint8_t)7)
```

minimum number of bytes in command (from count byte to second CRC byte)

#define ATCA\_CMD\_SIZE\_MAX ((uint8\_t)4 \* 36 + 7)

maximum size of command packet (Verify)

#define CMD\_STATUS\_SUCCESS ((uint8\_t)0x00)

status byte for success

#define CMD\_STATUS\_WAKEUP ((uint8\_t)0x11)

status byte after wake-up

• #define CMD STATUS BYTE PARSE ((uint8 t)0x03)

command parse error

• #define CMD\_STATUS\_BYTE\_ECC ((uint8\_t)0x05)

command ECC error

• #define CMD STATUS BYTE EXEC ((uint8 t)0x0F)

command execution error

#define CMD\_STATUS\_BYTE\_COMM ((uint8\_t)0xFF)

communication error

### **Opcodes for Crypto Authentication device commands**

```
• #define ATCA CHECKMAC ((uint8 t)0x28)
```

CheckMac command op-code.

• #define ATCA DERIVE KEY ((uint8 t)0x1C)

DeriveKey command op-code.

#define ATCA\_INFO ((uint8\_t)0x30)

Info command op-code.

#define ATCA\_GENDIG ((uint8\_t)0x15)

GenDig command op-code.

#define ATCA\_GENKEY ((uint8\_t)0x40)

GenKey command op-code.

• #define ATCA HMAC ((uint8 t)0x11)

HMAC command op-code.

• #define ATCA\_LOCK ((uint8\_t)0x17)

Lock command op-code.

#define ATCA\_MAC ((uint8\_t)0x08)

MAC command op-code.

#define ATCA\_NONCE ((uint8\_t)0x16)

Nonce command op-code.

#define ATCA\_PAUSE ((uint8\_t)0x01)

Pause command op-code.

• #define ATCA\_PRIVWRITE ((uint8\_t)0x46)

PrivWrite command op-code.

• #define ATCA\_RANDOM ((uint8\_t)0x1B)

Random command op-code.

#define ATCA\_READ ((uint8\_t)0x02)

Read command op-code.

• #define ATCA SIGN ((uint8 t)0x41)

Sign command op-code.

• #define ATCA\_UPDATE\_EXTRA ((uint8\_t)0x20)

UpdateExtra command op-code.

• #define ATCA VERIFY ((uint8 t)0x45)

GenKey command op-code.

#define ATCA WRITE ((uint8 t)0x12)

Write command op-code.

#define ATCA\_ECDH ((uint8\_t)0x43)

ECDH command op-code.

#define ATCA COUNTER ((uint8 t)0x24)

Counter command op-code.

• #define ATCA SHA ((uint8 t)0x47)

SHA command op-code.

• #define ATCA\_AES ((uint8\_t)0x51)

AES command op-code.

#define ATCA\_KDF ((uint8\_t)0x56)

KDF command op-code.

#define ATCA SECUREBOOT ((uint8 t)0x80)

Secure Boot command op-code.

#define ATCA\_SELFTEST ((uint8\_t)0x77)

Self test command op-code.

#### **Definitions of Data and Packet Sizes**

• #define ATCA BLOCK SIZE (32)

size of a block

#define ATCA WORD SIZE (4)

size of a word

• #define ATCA PUB KEY PAD (4)

size of the public key pad

#define ATCA\_SERIAL\_NUM\_SIZE (9)

number of bytes in the device serial number

• #define ATCA\_RSP\_SIZE\_VAL ((uint8\_t)7)

size of response packet containing four bytes of data

#define ATCA KEY COUNT (16)

number of keys

• #define ATCA\_ECC\_CONFIG\_SIZE (128)

size of configuration zone

#define ATCA\_SHA\_CONFIG\_SIZE (88)

size of configuration zone

#define ATCA\_OTP\_SIZE (64)

size of OTP zone

#define ATCA\_DATA\_SIZE (ATCA\_KEY\_COUNT \* ATCA\_KEY\_SIZE)

size of data zone

· #define ATCA AES GFM SIZE ATCA BLOCK SIZE

size of GFM data

• #define ATCA\_CHIPMODE\_OFFSET (19)

ChipMode byte offset within the configuration zone.

#define ATCA\_CHIPMODE\_I2C\_ADDRESS\_FLAG ((uint8\_t)0x01)

ChipMode I2C Address in UserExtraAdd flag.

#define ATCA\_CHIPMODE\_TTL\_ENABLE\_FLAG ((uint8\_t)0x02)

ChipMode TTLenable flag.

• #define ATCA CHIPMODE WATCHDOG MASK ((uint8 t)0x04)

ChipMode watchdog duration mask.

#define ATCA\_CHIPMODE\_WATCHDOG\_SHORT ((uint8\_t)0x00)

ChipMode short watchdog ( $\sim$  1.3s)

#define ATCA\_CHIPMODE\_WATCHDOG\_LONG ((uint8\_t)0x04)

ChipMode long watchdog ( $\sim$ 13s)

#define ATCA\_CHIPMODE\_CLOCK\_DIV\_MASK ((uint8\_t)0xF8)

ChipMode clock divider mask.

```
    #define ATCA_CHIPMODE_CLOCK_DIV_M0 ((uint8_t)0x00)

     ChipMode clock divider M0.

    #define ATCA CHIPMODE CLOCK DIV M1 ((uint8 t)0x28)

     ChipMode clock divider M1.

    #define ATCA_CHIPMODE_CLOCK_DIV_M2 ((uint8_t)0x68)

     ChipMode clock divider M2.

    #define ATCA_COUNT_SIZE ((uint8_t)1)

     Number of bytes in the command packet Count.
• #define ATCA CRC SIZE ((uint8 t)2)
     Number of bytes in the command packet CRC.
• #define ATCA_PACKET_OVERHEAD (ATCA_COUNT_SIZE + ATCA_CRC_SIZE)
     Number of bytes in the command packet.
• #define ATCA PUB KEY SIZE (64)
     size of a p256 public key

    #define ATCA_PRIV_KEY_SIZE (32)

     size of a p256 private key

    #define ATCA SIG SIZE (64)

     size of a p256 signature
• #define ATCA_KEY_SIZE (32)
     size of a symmetric SHA key

    #define RSA2048 KEY SIZE (256)

     size of a RSA private key
• #define ATCA_RSP_SIZE_MIN ((uint8_t)4)
     minimum number of bytes in response
• #define ATCA_RSP_SIZE_4 ((uint8_t)7)
     size of response packet containing 4 bytes data

    #define ATCA RSP SIZE 72 ((uint8 t)75)

     size of response packet containing 64 bytes data

    #define ATCA_RSP_SIZE_64 ((uint8_t)67)

     size of response packet containing 64 bytes data
• #define ATCA_RSP_SIZE_32 ((uint8_t)35)
     size of response packet containing 32 bytes data
• #define ATCA_RSP_SIZE_16 ((uint8_t)19)
     size of response packet containing 16 bytes data
• #define ATCA RSP SIZE MAX ((uint8 t)75)
     maximum size of response packet (GenKey and Verify command)
• #define OUTNONCE SIZE (32)
```

# **Definitions for Command Parameter Ranges**

```
    #define ATCA_KEY_ID_MAX ((uint8_t)15)
        maximum value for key id
    #define ATCA_OTP_BLOCK_MAX ((uint8_t)1)
        maximum value for OTP block
```

Size of the OutNonce response expected from several commands.

### **Definitions for Indexes Common to All Commands**

```
    #define ATCA_COUNT_IDX (0)
        command packet index for count
    #define ATCA_OPCODE_IDX (1)
        command packet index for op-code
    #define ATCA_PARAM1_IDX (2)
        command packet index for first parameter
    #define ATCA_PARAM2_IDX (3)
        command packet index for second parameter
    #define ATCA_DATA_IDX (5)
        command packet index for data load
```

#define ATCA\_RSP\_DATA\_IDX (1)

buffer index of data in response

#### **Definitions for Zone and Address Parameters**

#define ATCA\_ZONE\_MASK ((uint8\_t)0x03)

Zone mask.

#define ATCA ZONE ENCRYPTED ((uint8 t)0x40)

Zone bit 6 set: Write is encrypted with an unlocked data zone.

#define ATCA ZONE READWRITE 32 ((uint8 t)0x80)

Zone bit 7 set: Access 32 bytes, otherwise 4 bytes.

#define ATCA ADDRESS MASK CONFIG (0x001F)

Address bits 5 to 7 are 0 for Configuration zone.

• #define ATCA\_ADDRESS\_MASK\_OTP (0x000F)

Address bits 4 to 7 are 0 for OTP zone.

#define ATCA ADDRESS MASK (0x007F)

Address bit 7 to 15 are always 0.

#define ATCA\_TEMPKEY\_KEYID (0xFFFF)

KeyID when referencing TempKey.

## **Definitions for Key types**

• #define ATCA\_B283\_KEY\_TYPE 0

B283 NIST ECC key.

#define ATCA K283 KEY TYPE 1

K283 NIST ECC key.

#define ATCA\_P256\_KEY\_TYPE 4

P256 NIST ECC key.

• #define ATCA\_AES\_KEY\_TYPE 6

AES-128 Kev.

• #define ATCA\_SHA\_KEY\_TYPE 7

SHA key or other data.

### **Definitions for the AES Command**

• #define AES MODE IDX ATCA PARAM1 IDX

AES command index for mode.

• #define AES\_KEYID\_IDX ATCA\_PARAM2\_IDX

AES command index for key id.

• #define AES INPUT IDX ATCA DATA IDX

AES command index for input data.

• #define AES\_COUNT (23)

AES command packet size.

#define AES\_MODE\_MASK ((uint8\_t)0xC7)

AES mode bits 3 to 5 are 0.

• #define AES\_MODE\_KEY\_BLOCK\_MASK ((uint8\_t)0xC0)

AES mode mask for key block field.

#define AES\_MODE\_OP\_MASK ((uint8\_t)0x07)

AES mode operation mask.

• #define AES\_MODE\_ENCRYPT ((uint8\_t)0x00)

AES mode: Encrypt.

#define AES\_MODE\_DECRYPT ((uint8\_t)0x01)

AES mode: Decrypt.

#define AES\_MODE\_GFM ((uint8\_t)0x03)

AES mode: GFM calculation.

• #define AES\_MODE\_KEY\_BLOCK\_POS (6)

Bit shift for key block in mode.

#define AES\_DATA\_SIZE (16)

size of AES encrypt/decrypt data

#define AES\_RSP\_SIZE ATCA\_RSP\_SIZE\_16

AES command response packet size.

### **Definitions for the CheckMac Command**

• #define CHECKMAC MODE IDX ATCA PARAM1 IDX

CheckMAC command index for mode.

#define CHECKMAC KEYID IDX ATCA PARAM2 IDX

CheckMAC command index for key identifier.

#define CHECKMAC CLIENT CHALLENGE IDX ATCA DATA IDX

CheckMAC command index for client challenge.

• #define CHECKMAC CLIENT RESPONSE IDX (37)

CheckMAC command index for client response.

#define CHECKMAC DATA IDX (69)

CheckMAC command index for other data.

• #define CHECKMAC COUNT (84)

CheckMAC command packet size.

#define CHECKMAC\_MODE\_CHALLENGE ((uint8\_t)0x00)

CheckMAC mode 0: first SHA block from key id.

• #define CHECKMAC MODE BLOCK2 TEMPKEY ((uint8 t)0x01)

CheckMAC mode bit 0: second SHA block from TempKey.

#define CHECKMAC\_MODE\_BLOCK1\_TEMPKEY ((uint8\_t)0x02)

CheckMAC mode bit 1: first SHA block from TempKev.

• #define CHECKMAC MODE SOURCE FLAG MATCH ((uint8 t)0x04)

CheckMAC mode bit 2: match TempKey.SourceFlag.

• #define CHECKMAC\_MODE\_INCLUDE\_OTP\_64 ((uint8\_t)0x20)

CheckMAC mode bit 5: include first 64 OTP bits.

#define CHECKMAC\_MODE\_MASK ((uint8\_t)0x27)

CheckMAC mode bits 3, 4, 6, and 7 are 0.

• #define CHECKMAC\_CLIENT\_CHALLENGE\_SIZE (32)

CheckMAC size of client challenge.

• #define CHECKMAC\_CLIENT\_RESPONSE\_SIZE (32)

CheckMAC size of client response.

• #define CHECKMAC OTHER DATA SIZE (13)

CheckMAC size of "other data".

• #define CHECKMAC CLIENT COMMAND SIZE (4)

CheckMAC size of client command header size inside "other data".

• #define CHECKMAC CMD MATCH (0)

CheckMAC return value when there is a match.

• #define CHECKMAC\_CMD\_MISMATCH (1)

CheckMAC return value when there is a mismatch.

#define CHECKMAC\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

CheckMAC response packet size.

## **Definitions for the Counter command**

- #define COUNTER COUNT ATCA CMD SIZE MIN
- #define COUNTER\_MODE\_IDX ATCA\_PARAM1\_IDX

Counter command index for mode.

• #define COUNTER\_KEYID\_IDX ATCA\_PARAM2\_IDX

Counter command index for key id.

#define COUNTER MODE MASK ((uint8 t)0x01)

Counter mode bits 1 to 7 are 0.

• #define COUNTER\_MAX\_VALUE ((uint32\_t)2097151)

Counter maximum value of the counter.

• #define COUNTER MODE READ ((uint8 t)0x00)

Counter command mode for reading.

• #define COUNTER MODE INCREMENT ((uint8 t)0x01)

Counter command mode for incrementing.

#define COUNTER RSP SIZE ATCA RSP SIZE 4

Counter command response packet size.

#define COUNTER\_SIZE ATCA\_RSP\_SIZE\_MIN

Counter size in binary.

#### **Definitions for the DeriveKey Command**

• #define DERIVE KEY RANDOM IDX ATCA PARAM1 IDX

DeriveKev command index for random bit.

• #define DERIVE KEY TARGETKEY IDX ATCA PARAM2 IDX

DeriveKey command index for target slot.

#define DERIVE KEY MAC IDX ATCA DATA IDX

DeriveKey command index for optional MAC.

#define DERIVE\_KEY\_COUNT\_SMALL ATCA\_CMD\_SIZE\_MIN

DeriveKey command packet size without MAC.

#define DERIVE\_KEY\_MODE ((uint8\_t)0x04)

DeriveKey command mode set to 4 as in datasheet.

• #define DERIVE KEY COUNT LARGE (39)

DeriveKey command packet size with MAC.

• #define DERIVE KEY RANDOM FLAG ((uint8 t)4)

DeriveKey 1. parameter; has to match TempKey.SourceFlag.

• #define DERIVE KEY MAC SIZE (32)

DeriveKey MAC size.

· #define DERIVE KEY RSP SIZE ATCA RSP SIZE MIN

DeriveKey response packet size.

#### **Definitions for the ECDH Command**

- #define ECDH\_PREFIX\_MODE ((uint8\_t)0x00)
- #define ECDH\_COUNT (ATCA\_CMD\_SIZE\_MIN + ATCA\_PUB\_KEY\_SIZE)
- #define ECDH\_MODE\_SOURCE\_MASK ((uint8\_t)0x01)
- #define ECDH\_MODE\_SOURCE\_EEPROM\_SLOT ((uint8\_t)0x00)
- #define ECDH\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x01)
- #define ECDH\_MODE\_OUTPUT\_MASK ((uint8\_t)0x02)
- #define ECDH\_MODE\_OUTPUT\_CLEAR ((uint8\_t)0x00)
- #define ECDH\_MODE\_OUTPUT\_ENC ((uint8\_t)0x02)
- #define ECDH\_MODE\_COPY\_MASK ((uint8\_t)0x0C)
- #define ECDH MODE COPY COMPATIBLE ((uint8 t)0x00)
- #define ECDH\_MODE\_COPY\_EEPROM\_SLOT ((uint8\_t)0x04)
- #define ECDH\_MODE\_COPY\_TEMP\_KEY ((uint8\_t)0x08)
- #define ECDH\_MODE\_COPY\_OUTPUT\_BUFFER ((uint8\_t)0x0C)
- #define ECDH\_KEY\_SIZE ATCA\_BLOCK\_SIZE

ECDH output data size.

#define ECDH\_RSP\_SIZE ATCA\_RSP\_SIZE\_64

ECDH command packet size.

### **Definitions for the GenDig Command**

• #define GENDIG\_ZONE\_IDX ATCA\_PARAM1\_IDX

GenDig command index for zone.

#define GENDIG KEYID IDX ATCA PARAM2 IDX

GenDig command index for key id.

• #define GENDIG\_DATA\_IDX ATCA\_DATA\_IDX

GenDig command index for optional data.

• #define GENDIG COUNT ATCA CMD SIZE MIN

GenDig command packet size without "other data".

• #define GENDIG ZONE CONFIG ((uint8 t)0)

GenDig zone id config. Use KeyID to specify any of the four 256-bit blocks of the Configuration zone.

#define GENDIG ZONE OTP ((uint8 t)1)

GenDig zone id OTP. Use KeyID to specify either the first or second 256-bit block of the OTP zone.

#define GENDIG ZONE DATA ((uint8 t)2)

GenDig zone id data. Use KeyID to specify a slot in the Data zone or a transport key in the hardware array.

#define GENDIG ZONE SHARED NONCE ((uint8 t)3)

GenDig zone id shared nonce. KeyID specifies the location of the input value in the message generation.

• #define GENDIG ZONE COUNTER ((uint8 t)4)

GenDig zone id counter. KeyID specifies the monotonic counter ID to be included in the message generation.

• #define GENDIG\_ZONE\_KEY\_CONFIG ((uint8\_t)5)

GenDig zone id key config. KeyID specifies the slot for which the configuration information is to be included in the message generation.

#define GENDIG RSP SIZE ATCA RSP SIZE MIN

GenDig command response packet size.

## **Definitions for the GenKey Command**

• #define GENKEY MODE IDX ATCA PARAM1 IDX

GenKey command index for mode.

#define GENKEY\_KEYID\_IDX ATCA\_PARAM2\_IDX

GenKey command index for key id.

#define GENKEY DATA IDX (5)

GenKey command index for other data.

#define GENKEY\_COUNT ATCA\_CMD\_SIZE\_MIN

GenKey command packet size without "other data".

• #define GENKEY\_COUNT\_DATA (10)

GenKey command packet size with "other data".

#define GENKEY\_OTHER\_DATA\_SIZE (3)

GenKey size of "other data".

• #define GENKEY MODE MASK ((uint8 t)0x1C)

GenKey mode bits 0 to 1 and 5 to 7 are 0.

#define GENKEY\_MODE\_PRIVATE ((uint8\_t)0x04)

GenKey mode: private key generation.

#define GENKEY\_MODE\_PUBLIC ((uint8\_t)0x00)

GenKey mode: public key calculation.

#define GENKEY\_MODE\_DIGEST ((uint8\_t)0x08)

GenKey mode: PubKey digest will be created after the public key is calculated.

#define GENKEY\_MODE\_PUBKEY\_DIGEST ((uint8\_t)0x10)

GenKey mode: Calculate PubKey digest on the public key in Keyld.

#define GENKEY\_PRIVATE\_TO\_TEMPKEY ((uint16\_t)0xFFFF)

GenKey Create private key and store to tempkey (608 only)

#define GENKEY\_RSP\_SIZE\_SHORT ATCA\_RSP\_SIZE\_MIN

GenKey response packet size in Digest mode.

#define GENKEY RSP SIZE LONG ATCA RSP SIZE 64

GenKey response packet size when returning a public key.

# **Definitions for the HMAC Command**

#define HMAC MODE IDX ATCA PARAM1 IDX

HMAC command index for mode.

#define HMAC\_KEYID\_IDX ATCA\_PARAM2\_IDX

HMAC command index for key id.

• #define HMAC COUNT ATCA CMD SIZE MIN

HMAC command packet size.

• #define HMAC MODE FLAG TK RAND ((uint8 t)0x00)

HMAC mode bit 2: The value of this bit must match the value in TempKey. SourceFlag or the command will return an error.

#define HMAC\_MODE\_FLAG\_TK\_NORAND ((uint8\_t)0x04)

HMAC mode bit 2: The value of this bit must match the value in TempKey. SourceFlag or the command will return an error.

#define HMAC MODE FLAG OTP88 ((uint8 t)0x10)

HMAC mode bit 4: Include the first 88 OTP bits (OTP[0] through OTP[10]) in the message.; otherwise, the corresponding message bits are set to zero. Not applicable for ATECC508A.

#define HMAC\_MODE\_FLAG\_OTP64 ((uint8\_t)0x20)

HMAC mode bit 5: Include the first 64 OTP bits (OTP[0] through OTP[7]) in the message.; otherwise, the corresponding message bits are set to zero. If Mode[4] is set, the value of this mode bit is ignored. Not applicable for ATECC508A.

#define HMAC MODE FLAG FULLSN ((uint8 t)0x40)

HMAC mode bit 6: If set, include the 48 bits SN[2:3] and SN[4:7] in the message.; otherwise, the corresponding message bits are set to zero.

• #define HMAC MODE MASK ((uint8 t)0x74)

HMAC mode bits 0, 1, 3, and 7 are 0.

#define HMAC DIGEST SIZE (32)

HMAC size of digest response.

#define HMAC\_RSP\_SIZE ATCA\_RSP\_SIZE\_32

HMAC command response packet size.

#### **Definitions for the Info Command**

#define INFO\_PARAM1\_IDX ATCA\_PARAM1\_IDX

Info command index for 1. parameter.

#define INFO PARAM2 IDX ATCA PARAM2 IDX

Info command index for 2. parameter.

#define INFO COUNT ATCA CMD SIZE MIN

Info command packet size.

• #define INFO\_MODE\_REVISION ((uint8\_t)0x00)

Info mode Revision.

#define INFO\_MODE\_KEY\_VALID ((uint8\_t)0x01)

Info mode KeyValid.

• #define INFO\_MODE\_STATE ((uint8\_t)0x02)

Info mode State.

• #define INFO\_MODE\_GPIO ((uint8\_t)0x03)

Info mode GPIO.

• #define INFO\_MODE\_VOL\_KEY\_PERMIT ((uint8\_t)0x04)

Info mode GPIO.

• #define INFO\_MODE\_MAX ((uint8\_t)0x03)

Info mode maximum value.

#define INFO NO STATE ((uint8 t)0x00)

Info mode is not the state mode.

#define INFO\_OUTPUT\_STATE\_MASK ((uint8\_t)0x01)

Info output state mask.

#define INFO\_DRIVER\_STATE\_MASK ((uint8\_t)0x02)

Info driver state mask.

#define INFO\_PARAM2\_SET\_LATCH\_STATE ((uint16\_t)0x0002)

Info param2 to set the persistent latch state.

• #define INFO\_PARAM2\_LATCH\_SET ((uint16\_t)0x0001)

Info param2 to set the persistent latch.

#define INFO\_PARAM2\_LATCH\_CLEAR ((uint16\_t)0x0000)

Info param2 to clear the persistent latch.

• #define INFO\_SIZE ((uint8\_t)0x04)

Info return size.

· #define INFO RSP SIZE ATCA RSP SIZE VAL

Info command response packet size.

#### **Definitions for the KDF Command**

```
• #define KDF MODE IDX ATCA PARAM1 IDX
     KDF command index for mode.
 #define KDF KEYID IDX ATCA PARAM2 IDX
     KDF command index for key id.
• #define KDF_DETAILS_IDX ATCA_DATA_IDX
     KDF command index for details.
• #define KDF DETAILS_SIZE 4
     KDF details (param3) size.

    #define KDF MESSAGE IDX (ATCA DATA IDX + KDF DETAILS SIZE)

• #define KDF MODE_SOURCE_MASK ((uint8_t)0x03)
     KDF mode source key mask.
• #define KDF MODE SOURCE TEMPKEY ((uint8 t)0x00)
     KDF mode source key in TempKey.
• #define KDF MODE SOURCE TEMPKEY UP ((uint8 t)0x01)
     KDF mode source key in upper TempKey.

    #define KDF MODE SOURCE SLOT ((uint8 t)0x02)

     KDF mode source key in a slot.
• #define KDF MODE SOURCE ALTKEYBUF ((uint8 t)0x03)
     KDF mode source key in alternate key buffer.
• #define KDF MODE TARGET MASK ((uint8 t)0x1C)
     KDF mode target key mask.
• #define KDF MODE TARGET TEMPKEY ((uint8 t)0x00)
     KDF mode target key in TempKey.
• #define KDF MODE TARGET TEMPKEY UP ((uint8 t)0x04)
     KDF mode target key in upper TempKey.
• #define KDF MODE TARGET SLOT ((uint8 t)0x08)
     KDF mode target key in slot.
• #define KDF MODE TARGET ALTKEYBUF ((uint8 t)0x0C)
     KDF mode target key in alternate key buffer.

    #define KDF MODE TARGET OUTPUT ((uint8 t)0x10)

     KDF mode target key in output buffer.
• #define KDF MODE TARGET OUTPUT ENC ((uint8 t)0x14)
     KDF mode target key encrypted in output buffer.

    #define KDF MODE ALG MASK ((uint8 t)0x60)

     KDF mode algorithm mask.
• #define KDF MODE ALG PRF ((uint8 t)0x00)
     KDF mode PRF algorithm.

    #define KDF MODE ALG AES ((uint8 t)0x20)

     KDF mode AES algorithm.
• #define KDF_MODE_ALG_HKDF ((uint8_t)0x40)
     KDF mode HKDF algorithm.

    #define KDF DETAILS PRF KEY LEN MASK ((uint32 t)0x00000003)

     KDF details for PRF, source key length mask.
• #define KDF DETAILS PRF KEY LEN 16 ((uint32 t)0x00000000)
     KDF details for PRF, source key length is 16 bytes.

    #define KDF DETAILS PRF KEY LEN 32 ((uint32 t)0x00000001)

     KDF details for PRF, source key length is 32 bytes.

    #define KDF_DETAILS_PRF_KEY_LEN_48 ((uint32_t)0x00000002)

     KDF details for PRF, source key length is 48 bytes.

    #define KDF DETAILS PRF KEY LEN 64 ((uint32 t)0x00000003)

     KDF details for PRF, source key length is 64 bytes.
• #define KDF DETAILS PRF TARGET LEN MASK ((uint32 t)0x00000100)
     KDF details for PRF, target length mask.

    #define KDF DETAILS PRF TARGET LEN 32 ((uint32 t)0x00000000)

     KDF details for PRF, target length is 32 bytes.
 #define KDF_DETAILS_PRF_TARGET_LEN_64 ((uint32_t)0x00000100)
```

KDF details for PRF, target length is 64 bytes.

#define KDF\_DETAILS\_PRF\_AEAD\_MASK ((uint32\_t)0x00000600)

KDF details for PRF, AEAD processing mask.

#define KDF DETAILS PRF AEAD MODE0 ((uint32 t)0x00000000)

KDF details for PRF, AEAD no processing.

#define KDF\_DETAILS\_PRF\_AEAD\_MODE1 ((uint32\_t)0x00000200)

KDF details for PRF, AEAD First 32 go to target, second 32 go to output buffer.

#define KDF\_DETAILS\_AES\_KEY\_LOC\_MASK ((uint32\_t)0x00000003)

KDF details for AES, key location mask.

#define KDF DETAILS HKDF MSG LOC MASK ((uint32 t)0x00000003)

KDF details for HKDF, message location mask.

#define KDF\_DETAILS\_HKDF\_MSG\_LOC\_SLOT ((uint32\_t)0x00000000)

KDF details for HKDF, message location in slot.

#define KDF DETAILS HKDF MSG LOC TEMPKEY ((uint32 t)0x00000001)

KDF details for HKDF, message location in TempKey.

#define KDF\_DETAILS\_HKDF\_MSG\_LOC\_INPUT ((uint32\_t)0x00000002)

KDF details for HKDF, message location in input parameter.

#define KDF\_DETAILS\_HKDF\_MSG\_LOC\_IV ((uint32\_t)0x00000003)

KDF details for HKDF, message location is a special IV function.

• #define KDF\_DETAILS\_HKDF\_ZERO\_KEY ((uint32\_t)0x00000004)

KDF details for HKDF, key is 32 bytes of zero.

#### **Definitions for the Lock Command**

• #define LOCK ZONE IDX ATCA PARAM1 IDX

Lock command index for zone.

#define LOCK SUMMARY IDX ATCA PARAM2 IDX

Lock command index for summary.

#define LOCK\_COUNT ATCA\_CMD\_SIZE\_MIN

Lock command packet size.

#define LOCK\_ZONE\_CONFIG ((uint8\_t)0x00)

Lock zone is Config.

#define LOCK ZONE DATA ((uint8 t)0x01)

Lock zone is OTP or Data.

#define LOCK\_ZONE\_DATA\_SLOT ((uint8\_t)0x02)

Lock slot of Data.

• #define LOCK ZONE NO CRC ((uint8 t)0x80)

Lock command: Ignore summary.

• #define LOCK\_ZONE\_MASK (0xBF)

Lock parameter 1 bits 6 are 0.

• #define ATCA\_UNLOCKED (0x55)

Value indicating an unlocked zone.

#define ATCA LOCKED (0x00)

Value indicating a locked zone.

#define LOCK\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

Lock command response packet size.

### **Definitions for the MAC Command**

• #define MAC MODE IDX ATCA PARAM1 IDX

MAC command index for mode.

• #define MAC\_KEYID\_IDX ATCA\_PARAM2\_IDX

MAC command index for key id.

#define MAC CHALLENGE IDX ATCA DATA IDX

MAC command index for optional challenge.

#define MAC\_COUNT\_SHORT ATCA\_CMD\_SIZE\_MIN

MAC command packet size without challenge.

• #define MAC\_COUNT\_LONG (39)

MAC command packet size with challenge.

• #define MAC\_MODE\_CHALLENGE ((uint8\_t)0x00)

MAC mode 0: first SHA block from data slot.

#define MAC MODE BLOCK2 TEMPKEY ((uint8 t)0x01)

MAC mode bit 0: second SHA block from TempKey.

#define MAC\_MODE\_BLOCK1\_TEMPKEY ((uint8\_t)0x02)

MAC mode bit 1: first SHA block from TempKey.

• #define MAC MODE SOURCE FLAG MATCH ((uint8 t)0x04)

MAC mode bit 2: match TempKey.SourceFlag.

• #define MAC MODE PTNONCE TEMPKEY ((uint8 t)0x06)

MAC mode bit 0: second SHA block from TempKey.

#define MAC MODE PASSTHROUGH ((uint8 t)0x07)

MAC mode bit 0-2: pass-through mode.

#define MAC\_MODE\_INCLUDE\_OTP\_88 ((uint8\_t)0x10)

MAC mode bit 4: include first 88 OTP bits.

• #define MAC\_MODE\_INCLUDE\_OTP\_64 ((uint8\_t)0x20)

MAC mode bit 5: include first 64 OTP bits.

#define MAC MODE INCLUDE SN ((uint8 t)0x40)

MAC mode bit 6: include serial number.

• #define MAC CHALLENGE SIZE (32)

MAC size of challenge.

#define MAC SIZE (32)

MAC size of response.

• #define MAC\_MODE\_MASK ((uint8\_t)0x77)

MAC mode bits 3 and 7 are 0.

#define MAC\_RSP\_SIZE ATCA\_RSP\_SIZE\_32

MAC command response packet size.

#### **Definitions for the Nonce Command**

#define NONCE\_MODE\_IDX ATCA\_PARAM1\_IDX

Nonce command index for mode.

#define NONCE PARAM2 IDX ATCA PARAM2 IDX

Nonce command index for 2. parameter.

• #define NONCE INPUT IDX ATCA DATA IDX

Nonce command index for input data.

• #define NONCE COUNT SHORT (ATCA CMD SIZE MIN + 20)

Nonce command packet size for 20 bytes of NumIn.

#define NONCE\_COUNT\_LONG (ATCA\_CMD\_SIZE\_MIN + 32)

Nonce command packet size for 32 bytes of NumIn.

• #define NONCE COUNT LONG 64 (ATCA CMD SIZE MIN + 64)

Nonce command packet size for 64 bytes of NumIn.

• #define NONCE MODE MASK ((uint8 t)0x03)

Nonce mode bits 2 to 7 are 0.

• #define NONCE\_MODE\_SEED\_UPDATE ((uint8\_t)0x00)

Nonce mode: update seed.

#define NONCE\_MODE\_NO\_SEED\_UPDATE ((uint8\_t)0x01)

Nonce mode: do not update seed.

#define NONCE MODE INVALID ((uint8 t)0x02)

Nonce mode 2 is invalid.

• #define NONCE\_MODE\_PASSTHROUGH ((uint8\_t)0x03)

Nonce mode: pass-through.

• #define NONCE\_MODE\_INPUT\_LEN\_MASK ((uint8\_t)0x20)

Nonce mode: input size mask.

#define NONCE MODE INPUT LEN 32 ((uint8 t)0x00)

Nonce mode: input size is 32 bytes.

• #define NONCE MODE INPUT LEN 64 ((uint8 t)0x20)

Nonce mode: input size is 64 bytes.

#define NONCE MODE TARGET MASK ((uint8 t)0xC0)

Nonce mode: target mask.

• #define NONCE MODE TARGET TEMPKEY ((uint8 t)0x00)

Nonce mode: target is TempKey.

#define NONCE\_MODE\_TARGET\_MSGDIGBUF ((uint8\_t)0x40)

Nonce mode: target is Message Digest Buffer.

• #define NONCE\_MODE\_TARGET\_ALTKEYBUF ((uint8\_t)0x80)

Nonce mode: target is Alternate Key Buffer.

#define NONCE ZERO CALC MASK ((uint16 t)0x8000)

Nonce zero (param2): calculation mode mask.

• #define NONCE\_ZERO\_CALC\_RANDOM ((uint16\_t)0x0000)

Nonce zero (param2): calculation mode random, use RNG in calculation and return RNG output.

#define NONCE ZERO CALC TEMPKEY ((uint16 t)0x8000)

Nonce zero (param2): calculation mode TempKey, use TempKey in calculation and return new TempKey value.

• #define NONCE NUMIN SIZE (20)

Nonce NumIn size for random modes.

#define NONCE NUMIN SIZE PASSTHROUGH (32)

Nonce NumIn size for 32-byte pass-through mode.

• #define NONCE\_RSP\_SIZE\_SHORT ATCA\_RSP\_SIZE\_MIN

Nonce command response packet size with no output.

#define NONCE\_RSP\_SIZE\_LONG ATCA\_RSP\_SIZE\_32

Nonce command response packet size with output.

#### **Definitions for the Pause Command**

#define PAUSE SELECT IDX ATCA PARAM1 IDX

Pause command index for Selector.

#define PAUSE\_PARAM2\_IDX ATCA\_PARAM2\_IDX

Pause command index for 2. parameter.

#define PAUSE COUNT ATCA CMD SIZE MIN

Pause command packet size.

#define PAUSE\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

Pause command response packet size.

### **Definitions for the PrivWrite Command**

• #define PRIVWRITE ZONE IDX ATCA PARAM1 IDX

PrivWrite command index for zone.

#define PRIVWRITE\_KEYID\_IDX ATCA\_PARAM2\_IDX

PrivWrite command index for KeyID.

• #define PRIVWRITE\_VALUE\_IDX (5)

PrivWrite command index for value.

• #define PRIVWRITE MAC IDX (41)

PrivWrite command index for MAC.

#define PRIVWRITE\_COUNT (75)

PrivWrite command packet size.

#define PRIVWRITE ZONE MASK ((uint8 t)0x40)

PrivWrite zone bits 0 to 5 and 7 are 0.

• #define PRIVWRITE\_MODE\_ENCRYPT ((uint8\_t)0x40)

PrivWrite mode: encrypted.

#define PRIVWRITE\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

PrivWrite command response packet size.

### **Definitions for the Random Command**

• #define RANDOM MODE IDX ATCA PARAM1 IDX

Random command index for mode.

#define RANDOM\_PARAM2\_IDX ATCA\_PARAM2\_IDX

Random command index for 2. parameter.

#define RANDOM COUNT ATCA CMD SIZE MIN

Random command packet size.

#define RANDOM SEED UPDATE ((uint8 t)0x00)

Random mode for automatic seed update.

#define RANDOM\_NO\_SEED\_UPDATE ((uint8\_t)0x01)

Random mode for no seed update.

• #define RANDOM NUM SIZE ((uint8 t)32)

Number of bytes in the data packet of a random command.

• #define RANDOM\_RSP\_SIZE ATCA\_RSP\_SIZE\_32

Random command response packet size.

#### **Definitions for the Read Command**

#define READ ZONE IDX ATCA PARAM1 IDX

Read command index for zone.

#define READ\_ADDR\_IDX ATCA\_PARAM2\_IDX

Read command index for address.

#define READ COUNT ATCA CMD SIZE MIN

Read command packet size.

#define READ\_ZONE\_MASK ((uint8\_t)0x83)

Read zone bits 2 to 6 are 0.

#define READ\_4\_RSP\_SIZE ATCA\_RSP\_SIZE\_VAL

Read command response packet size when reading 4 bytes.

• #define READ\_32\_RSP\_SIZE ATCA\_RSP\_SIZE\_32

Read command response packet size when reading 32 bytes.

#### **Definitions for the SecureBoot Command**

#define SECUREBOOT MODE IDX ATCA PARAM1 IDX

SecureBoot command index for mode.

• #define SECUREBOOT DIGEST SIZE (32)

SecureBoot digest input size.

• #define SECUREBOOT SIGNATURE SIZE (64)

SecureBoot signature input size.

• #define SECUREBOOT\_COUNT\_DIG (ATCA\_CMD\_SIZE\_MIN + SECUREBOOT\_DIGEST\_SIZE)

SecureBoot command packet size for just a digest.

 #define SECUREBOOT\_COUNT\_DIG\_SIG (ATCA\_CMD\_SIZE\_MIN + SECUREBOOT\_DIGEST\_SIZE + SECUREBOOT\_SIGNATURE\_SIZE)

SecureBoot command packet size for a digest and signature.

• #define SECUREBOOT MAC SIZE (32)

SecureBoot MAC output size.

• #define SECUREBOOT\_RSP\_SIZE\_NO\_MAC ATCA\_RSP\_SIZE\_MIN

SecureBoot response packet size for no MAC.

#define SECUREBOOT RSP SIZE MAC (ATCA PACKET OVERHEAD + SECUREBOOT MAC SIZE)

SecureBoot response packet size with MAC.

#define SECUREBOOT\_MODE\_MASK ((uint8\_t)0x07)

SecureBoot mode mask.

• #define SECUREBOOT\_MODE\_FULL ((uint8\_t)0x05)

SecureBoot mode Full.

• #define SECUREBOOT\_MODE\_FULL\_STORE ((uint8\_t)0x06)

SecureBoot mode FullStore.

• #define SECUREBOOT MODE FULL COPY ((uint8 t)0x07)

SecureBoot mode FullCopy.

#define SECUREBOOT MODE PROHIBIT FLAG ((uint8 t)0x40)

SecureBoot mode flag to prohibit SecureBoot until next power cycle.

#define SECUREBOOT\_MODE\_ENC\_MAC\_FLAG ((uint8\_t)0x80)

SecureBoot mode flag for encrypted digest and returning validating MAC.

#define SECUREBOOTCONFIG\_OFFSET (70)

SecureBootConfig byte offset into the configuration zone.

#define SECUREBOOTCONFIG MODE MASK ((uint16 t)0x0003)

Mask for SecureBootMode field in SecureBootConfig value.

• #define SECUREBOOTCONFIG\_MODE\_DISABLED ((uint16\_t)0x0000)

Disabled SecureBootMode in SecureBootConfig value.

#define SECUREBOOTCONFIG MODE FULL BOTH ((uint16 t)0x0001)

Both digest and signature always required SecureBootMode in SecureBootConfig value.

• #define SECUREBOOTCONFIG MODE FULL SIG ((uint16 t)0x0002)

Signature stored SecureBootMode in SecureBootConfig value.

#define SECUREBOOTCONFIG MODE FULL DIG ((uint16 t)0x0003)

Digest stored SecureBootMode in SecureBootConfig value.

#### **Definitions for the SelfTest Command**

#define SELFTEST MODE IDX ATCA PARAM1 IDX

SelfTest command index for mode.

#define SELFTEST\_COUNT ATCA\_CMD\_SIZE\_MIN

SelfTest command packet size.

#define SELFTEST\_MODE\_RNG ((uint8\_t)0x01)

SelfTest mode RNG DRBG function.

• #define SELFTEST MODE ECDSA SIGN VERIFY ((uint8 t)0x02)

SelfTest mode ECDSA verify function.

#define SELFTEST MODE ECDH ((uint8 t)0x08)

SelfTest mode ECDH function.

#define SELFTEST\_MODE\_AES ((uint8\_t)0x10)

SelfTest mode AES encrypt function.

#define SELFTEST MODE SHA ((uint8 t)0x20)

SelfTest mode SHA function.

#define SELFTEST\_MODE\_ALL ((uint8\_t)0x3B)

SelfTest mode all algorithms.

• #define SELFTEST\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

SelfTest command response packet size.

### **Definitions for the SHA Command**

- #define SHA\_COUNT\_SHORT ATCA\_CMD\_SIZE\_MIN
- #define SHA COUNT LONG ATCA CMD SIZE MIN

Just a starting size.

- #define ATCA\_SHA\_DIGEST\_SIZE (32)
- #define SHA\_DATA\_MAX (64)
- #define SHA\_MODE\_MASK ((uint8\_t)0x07)

Mask the bit 0-2.

#define SHA\_MODE\_SHA256\_START ((uint8\_t)0x00)

Initialization, does not accept a message.

• #define SHA MODE SHA256 UPDATE ((uint8 t)0x01)

Add 64 bytes in the meesage to the SHA context.

#define SHA\_MODE\_SHA256\_END ((uint8\_t)0x02)

Complete the calculation and return the digest.

#define SHA\_MODE\_SHA256\_PUBLIC ((uint8\_t)0x03)

Add 64 byte ECC public key in the slot to the SHA context.

#define SHA\_MODE\_HMAC\_START ((uint8\_t)0x04)

Initialization, HMAC calculation.

#define SHA MODE HMAC UPDATE ((uint8 t)0x01)

Add 64 bytes in the meesage to the SHA context.

• #define SHA MODE HMAC END ((uint8 t)0x05)

Complete the HMAC computation and return digest.

#define SHA\_MODE\_608\_HMAC\_END ((uint8\_t)0x02)

Complete the HMAC computation and return digest... Different command on 608.

• #define SHA MODE READ CONTEXT ((uint8 t)0x06)

Read current SHA-256 context out of the device.

#define SHA MODE WRITE CONTEXT ((uint8 t)0x07)

Restore a SHA-256 context into the device.

#define SHA\_MODE\_TARGET\_MASK ((uint8\_t)0xC0)

Resulting digest target location mask.

#define SHA RSP SIZE ATCA RSP SIZE 32

SHA command response packet size.

• #define SHA RSP SIZE SHORT ATCA RSP SIZE MIN

SHA command response packet size only status code.

• #define SHA RSP SIZE LONG ATCA RSP SIZE 32

SHA command response packet size.

### **Definitions for the Sign Command**

• #define SIGN MODE IDX ATCA PARAM1 IDX

Sign command index for mode.

#define SIGN KEYID IDX ATCA PARAM2 IDX

Sign command index for key id.

• #define SIGN COUNT ATCA CMD SIZE MIN

Sign command packet size.

• #define SIGN\_MODE\_MASK ((uint8\_t)0xE1)

Sign mode bits 1 to 4 are 0.

• #define SIGN MODE INTERNAL ((uint8 t)0x00)

Sign mode 0: internal.

#define SIGN MODE INVALIDATE ((uint8 t)0x01)

Sign mode bit 1: Signature will be used for Verify(Invalidate)

#define SIGN\_MODE\_INCLUDE\_SN ((uint8\_t)0x40)

Sign mode bit 6: include serial number.

#define SIGN\_MODE\_EXTERNAL ((uint8\_t)0x80)

Sign mode bit 7: external.

#define SIGN\_MODE\_SOURCE\_MASK ((uint8\_t)0x20)

Sign mode message source mask.

• #define SIGN\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x00)

Sign mode message source is TempKey.

#define SIGN\_MODE\_SOURCE\_MSGDIGBUF ((uint8\_t)0x20)

Sign mode message source is the Message Digest Buffer.

#define SIGN\_RSP\_SIZE ATCA\_RSP\_SIZE\_MAX

Sign command response packet size.

## **Definitions for the UpdateExtra Command**

#define UPDATE MODE IDX ATCA PARAM1 IDX

UpdateExtra command index for mode.

#define UPDATE VALUE IDX ATCA PARAM2 IDX

UpdateExtra command index for new value.

#define UPDATE\_COUNT ATCA\_CMD\_SIZE\_MIN

UpdateExtra command packet size.

• #define UPDATE\_MODE\_USER\_EXTRA ((uint8\_t)0x00)

UpdateExtra mode update UserExtra (config byte 84)

• #define UPDATE\_MODE\_SELECTOR ((uint8\_t)0x01)

UpdateExtra mode update Selector (config byte 85)

#define UPDATE MODE USER EXTRA ADD UPDATE MODE SELECTOR

UpdateExtra mode update UserExtraAdd (config byte 85)

• #define UPDATE MODE DEC COUNTER ((uint8 t)0x02)

UpdateExtra mode: decrement counter.

• #define UPDATE RSP SIZE ATCA RSP SIZE MIN

UpdateExtra command response packet size.

#### **Definitions for the Verify Command**

```
    #define VERIFY MODE IDX ATCA PARAM1 IDX
```

Verify command index for mode.

#define VERIFY\_KEYID\_IDX ATCA\_PARAM2\_IDX

Verify command index for key id.

• #define VERIFY DATA IDX (5)

Verify command index for data.

#define VERIFY 256 STORED COUNT (71)

Verify command packet size for 256-bit key in stored mode.

• #define VERIFY 283 STORED COUNT (79)

Verify command packet size for 283-bit key in stored mode.

#define VERIFY 256 VALIDATE COUNT (90)

Verify command packet size for 256-bit key in validate mode.

#define VERIFY 283 VALIDATE COUNT (98)

Verify command packet size for 283-bit key in validate mode.

#define VERIFY 256 EXTERNAL COUNT (135)

Verify command packet size for 256-bit key in external mode.

#define VERIFY\_283\_EXTERNAL\_COUNT (151)

Verify command packet size for 283-bit key in external mode.

• #define VERIFY 256 KEY SIZE (64)

Verify key size for 256-bit key.

#define VERIFY 283 KEY SIZE (72)

Verify key size for 283-bit key.

#define VERIFY 256 SIGNATURE SIZE (64)

Verify signature size for 256-bit key.

#define VERIFY\_283\_SIGNATURE\_SIZE (72)

Verify signature size for 283-bit key.

#define VERIFY\_OTHER\_DATA\_SIZE (19)

Verify size of "other data".

#define VERIFY MODE MASK ((uint8 t)0x07)

Verify mode bits 3 to 7 are 0.

• #define VERIFY MODE STORED ((uint8 t)0x00)

Verify mode: stored.

#define VERIFY\_MODE\_VALIDATE\_EXTERNAL ((uint8\_t)0x01)

Verify mode: validate external.

• #define VERIFY\_MODE\_EXTERNAL ((uint8\_t)0x02)

Verify mode: external.

#define VERIFY\_MODE\_VALIDATE ((uint8\_t)0x03)

Verify mode: validate.

#define VERIFY\_MODE\_INVALIDATE ((uint8\_t)0x07)

Verify mode: invalidate.

• #define VERIFY\_MODE\_SOURCE\_MASK ((uint8\_t)0x20)

Verify mode message source mask.

#define VERIFY\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x00)

Verify mode message source is TempKey.

#define VERIFY\_MODE\_SOURCE\_MSGDIGBUF ((uint8\_t)0x20)

Verify mode message source is the Message Digest Buffer.

• #define VERIFY MODE MAC FLAG ((uint8 t)0x80)

Verify mode: MAC.

#define VERIFY\_KEY\_B283 ((uint16\_t)0x0000)

Verify key type: B283.

#define VERIFY\_KEY\_K283 ((uint16\_t)0x0001)

Verify key type: K283.

#define VERIFY\_KEY\_P256 ((uint16\_t)0x0004)

Verify key type: P256.

#define VERIFY\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

Verify command response packet size.

#define VERIFY\_RSP\_SIZE\_MAC ATCA\_RSP\_SIZE\_32

Verify command response packet size with validating MAC.

### **Definitions for the Write Command**

• #define WRITE ZONE IDX ATCA PARAM1 IDX

Write command index for zone.

• #define WRITE\_ADDR\_IDX ATCA\_PARAM2\_IDX

Write command index for address.

#define WRITE VALUE IDX ATCA DATA IDX

Write command index for data.

#define WRITE\_MAC\_VS\_IDX (9)

Write command index for MAC following short data.

#define WRITE\_MAC\_VL\_IDX (37)

Write command index for MAC following long data.

• #define WRITE MAC SIZE (32)

Write MAC size.

• #define WRITE ZONE MASK ((uint8 t)0xC3)

Write zone bits 2 to 5 are 0.

#define WRITE\_ZONE\_WITH\_MAC ((uint8\_t)0x40)

Write zone bit 6: write encrypted with MAC.

#define WRITE ZONE OTP ((uint8 t)1)

Write zone id OTP.

• #define WRITE\_ZONE\_DATA ((uint8\_t)2)

Write zone id data.

#define WRITE\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

Write command response packet size.

### **Functions**

• ATCA\_STATUS atCheckMAC (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand CheckMAC method.

ATCA\_STATUS atCounter (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Counter method.

ATCA\_STATUS atDeriveKey (ATCACommand ca\_cmd, ATCAPacket \*packet, bool has\_mac)

ATCACommand DeriveKey method.

ATCA STATUS atECDH (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand ECDH method.

ATCA\_STATUS atGenDig (ATCACommand ca\_cmd, ATCAPacket \*packet, bool is\_no\_mac\_key)

ATCACommand Generate Digest method.

ATCA STATUS atGenKey (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Generate Key method.

ATCA\_STATUS atHMAC (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand HMAC method.

ATCA STATUS atInfo (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Info method.

• ATCA\_STATUS atLock (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Lock method.

ATCA STATUS atMAC (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand MAC method.

ATCA\_STATUS atNonce (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Nonce method.

ATCA STATUS atPause (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Pause method.

ATCA STATUS atPrivWrite (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand PrivWrite method.

ATCA\_STATUS atRandom (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Random method.

ATCA STATUS atRead (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand Read method.

ATCA\_STATUS atSecureBoot (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand SecureBoot method.

ATCA\_STATUS atSHA (ATCACommand ca\_cmd, ATCAPacket \*packet, uint16\_t write\_context\_size)

ATCACommand SHA method.

ATCA\_STATUS atSign (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand Sign method.

• ATCA\_STATUS atUpdateExtra (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand UpdateExtra method.

ATCA\_STATUS atVerify (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand ECDSA Verify method.

ATCA STATUS atWrite (ATCACommand ca cmd, ATCAPacket \*packet, bool has mac)

ATCACommand Write method.

ATCA\_STATUS atAES (ATCACommand ca\_cmd, ATCAPacket \*packet)

ATCACommand AES method.

ATCA STATUS atSelfTest (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand AES method.

• ATCA STATUS atKDF (ATCACommand ca cmd, ATCAPacket \*packet)

ATCACommand KDF method.

bool atIsSHAFamily (ATCADeviceType device type)

determines if a given device type is a SHA device or a superset of a SHA device

bool atIsECCFamily (ATCADeviceType device\_type)

determines if a given device type is an ECC device or a superset of a ECC device

ATCA\_STATUS isATCAError (uint8\_t \*data)

checks for basic error frame in data

void atCRC (size\_t length, const uint8\_t \*data, uint8\_t \*crc\_le)

Calculates CRC over the given raw data and returns the CRC in little-endian byte order.

void atCalcCrc (ATCAPacket \*pkt)

This function calculates CRC and adds it to the correct offset in the packet data.

ATCA\_STATUS atCheckCrc (const uint8\_t \*response)

This function checks the consistency of a response.

# 20.71.1 Detailed Description

Microchip Crypto Auth device command object - this is a command builder only, it does not send the command. The result of a command method is a fully formed packet, ready to send to the ATCAIFace object to dispatch.

This command object supports the ATSHA and ATECC device family. The command list is a superset of all device commands for this family. The command object differentiates the packet contents based on specific device type within the family.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.71.2 Macro Definition Documentation

# 20.71.2.1 AES\_COUNT

#define AES\_COUNT (23)

AES command packet size.

# 20.71.2.2 AES\_DATA\_SIZE

#define AES\_DATA\_SIZE (16)

size of AES encrypt/decrypt data

# 20.71.2.3 AES\_INPUT\_IDX

#define AES\_INPUT\_IDX ATCA\_DATA\_IDX

AES command index for input data.

# 20.71.2.4 AES\_KEYID\_IDX

#define AES\_KEYID\_IDX ATCA\_PARAM2\_IDX

AES command index for key id.

# 20.71.2.5 AES\_MODE\_DECRYPT

#define AES\_MODE\_DECRYPT ((uint8\_t)0x01)

AES mode: Decrypt.

# 20.71.2.6 AES\_MODE\_ENCRYPT

#define AES\_MODE\_ENCRYPT ((uint8\_t)0x00)

AES mode: Encrypt.

# 20.71.2.7 AES\_MODE\_GFM

#define AES\_MODE\_GFM ((uint8\_t)0x03)

AES mode: GFM calculation.

# 20.71.2.8 AES\_MODE\_IDX

#define AES\_MODE\_IDX ATCA\_PARAM1\_IDX

AES command index for mode.

# 20.71.2.9 AES\_MODE\_KEY\_BLOCK\_MASK

#define AES\_MODE\_KEY\_BLOCK\_MASK ((uint8\_t)0xC0)

AES mode mask for key block field.

# 20.71.2.10 AES\_MODE\_KEY\_BLOCK\_POS

#define AES\_MODE\_KEY\_BLOCK\_POS (6)

Bit shift for key block in mode.

# 20.71.2.11 AES\_MODE\_MASK

#define AES\_MODE\_MASK ((uint8\_t)0xC7)

AES mode bits 3 to 5 are 0.

# 20.71.2.12 AES\_MODE\_OP\_MASK

#define AES\_MODE\_OP\_MASK ((uint8\_t)0x07)

AES mode operation mask.

## 20.71.2.13 AES\_RSP\_SIZE

#define AES\_RSP\_SIZE ATCA\_RSP\_SIZE\_16

AES command response packet size.

# 20.71.2.14 ATCA\_ADDRESS\_MASK

#define ATCA\_ADDRESS\_MASK (0x007F)

Address bit 7 to 15 are always 0.

# 20.71.2.15 ATCA\_ADDRESS\_MASK\_CONFIG

#define ATCA\_ADDRESS\_MASK\_CONFIG (0x001F)

Address bits 5 to 7 are 0 for Configuration zone.

# 20.71.2.16 ATCA\_ADDRESS\_MASK\_OTP

#define ATCA\_ADDRESS\_MASK\_OTP (0x000F)

Address bits 4 to 7 are 0 for OTP zone.

# 20.71.2.17 ATCA\_AES

#define ATCA\_AES ((uint8\_t)0x51)

AES command op-code.

# 20.71.2.18 ATCA\_AES\_GFM\_SIZE

#define ATCA\_AES\_GFM\_SIZE ATCA\_BLOCK\_SIZE

size of GFM data

# 20.71.2.19 ATCA\_AES\_KEY\_TYPE

#define ATCA\_AES\_KEY\_TYPE 6

AES-128 Key.

# 20.71.2.20 ATCA\_B283\_KEY\_TYPE

#define ATCA\_B283\_KEY\_TYPE 0

B283 NIST ECC key.

# 20.71.2.21 ATCA\_BLOCK\_SIZE

#define ATCA\_BLOCK\_SIZE (32)

size of a block

# 20.71.2.22 ATCA\_CHECKMAC

#define ATCA\_CHECKMAC ((uint8\_t)0x28)

CheckMac command op-code.

# 20.71.2.23 ATCA\_CHIPMODE\_CLOCK\_DIV\_M0

#define ATCA\_CHIPMODE\_CLOCK\_DIV\_M0 ((uint8\_t)0x00)

ChipMode clock divider M0.

# 20.71.2.24 ATCA\_CHIPMODE\_CLOCK\_DIV\_M1

#define ATCA\_CHIPMODE\_CLOCK\_DIV\_M1 ((uint8\_t)0x28)

ChipMode clock divider M1.

### 20.71.2.25 ATCA\_CHIPMODE\_CLOCK\_DIV\_M2

#define ATCA\_CHIPMODE\_CLOCK\_DIV\_M2 ((uint8\_t)0x68)

ChipMode clock divider M2.

# 20.71.2.26 ATCA\_CHIPMODE\_CLOCK\_DIV\_MASK

#define ATCA\_CHIPMODE\_CLOCK\_DIV\_MASK ((uint8\_t)0xF8)

ChipMode clock divider mask.

# 20.71.2.27 ATCA\_CHIPMODE\_I2C\_ADDRESS\_FLAG

#define ATCA\_CHIPMODE\_I2C\_ADDRESS\_FLAG ((uint8\_t)0x01)

ChipMode I2C Address in UserExtraAdd flag.

# 20.71.2.28 ATCA\_CHIPMODE\_OFFSET

#define ATCA\_CHIPMODE\_OFFSET (19)

ChipMode byte offset within the configuration zone.

# 20.71.2.29 ATCA\_CHIPMODE\_TTL\_ENABLE\_FLAG

#define ATCA\_CHIPMODE\_TTL\_ENABLE\_FLAG ((uint8\_t)0x02)

ChipMode TTLenable flag.

## 20.71.2.30 ATCA\_CHIPMODE\_WATCHDOG\_LONG

#define ATCA\_CHIPMODE\_WATCHDOG\_LONG ((uint8\_t)0x04)

ChipMode long watchdog ( $\sim$ 13s)

### 20.71.2.31 ATCA\_CHIPMODE\_WATCHDOG\_MASK

 $\verb|#define ATCA_CHIPMODE_WATCHDOG_MASK ((uint8_t)0x04)|\\$ 

ChipMode watchdog duration mask.

# 20.71.2.32 ATCA\_CHIPMODE\_WATCHDOG\_SHORT

#define ATCA\_CHIPMODE\_WATCHDOG\_SHORT ((uint8\_t)0x00)

ChipMode short watchdog (∼1.3s)

# 20.71.2.33 ATCA\_CMD\_SIZE\_MAX

```
\#define ATCA_CMD_SIZE_MAX ((uint8_t)4 * 36 + 7)
```

maximum size of command packet (Verify)

# 20.71.2.34 ATCA\_CMD\_SIZE\_MIN

```
#define ATCA_CMD_SIZE_MIN ((uint8_t)7)
```

minimum number of bytes in command (from count byte to second CRC byte)

# 20.71.2.35 ATCA\_COUNT\_IDX

#define ATCA\_COUNT\_IDX (0)

command packet index for count

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 716

# 20.71.2.36 ATCA\_COUNT\_SIZE

```
#define ATCA_COUNT_SIZE ((uint8_t)1)
```

Number of bytes in the command packet Count.

## 20.71.2.37 ATCA\_COUNTER

```
#define ATCA_COUNTER ((uint8_t)0x24)
```

Counter command op-code.

# 20.71.2.38 ATCA\_CRC\_SIZE

```
#define ATCA_CRC_SIZE ((uint8_t)2)
```

Number of bytes in the command packet CRC.

# 20.71.2.39 ATCA\_DATA\_IDX

```
#define ATCA_DATA_IDX (5)
```

command packet index for data load

# 20.71.2.40 ATCA\_DATA\_SIZE

```
#define ATCA_DATA_SIZE (ATCA_KEY_COUNT * ATCA_KEY_SIZE)
```

size of data zone

# 20.71.2.41 ATCA\_DERIVE\_KEY

```
#define ATCA_DERIVE_KEY ((uint8_t)0x1C)
```

DeriveKey command op-code.

# 20.71.2.42 ATCA\_ECC\_CONFIG\_SIZE

#define ATCA\_ECC\_CONFIG\_SIZE (128)

size of configuration zone

## 20.71.2.43 ATCA\_ECDH

#define ATCA\_ECDH ((uint8\_t)0x43)

ECDH command op-code.

# 20.71.2.44 ATCA\_GENDIG

#define ATCA\_GENDIG ((uint8\_t)0x15)

GenDig command op-code.

# 20.71.2.45 ATCA\_GENKEY

#define ATCA\_GENKEY ((uint8\_t)0x40)

GenKey command op-code.

# 20.71.2.46 ATCA\_HMAC

#define ATCA\_HMAC ((uint8\_t)0x11)

HMAC command op-code.

# 20.71.2.47 ATCA\_INFO

#define ATCA\_INFO ((uint8\_t)0x30)

Info command op-code.

# 20.71.2.48 ATCA\_K283\_KEY\_TYPE

#define ATCA\_K283\_KEY\_TYPE 1

K283 NIST ECC key.

## 20.71.2.49 ATCA\_KDF

#define ATCA\_KDF ((uint8\_t)0x56)

KDF command op-code.

# 20.71.2.50 ATCA\_KEY\_COUNT

#define ATCA\_KEY\_COUNT (16)

number of keys

# 20.71.2.51 ATCA\_KEY\_ID\_MAX

#define ATCA\_KEY\_ID\_MAX ((uint8\_t)15)

maximum value for key id

# 20.71.2.52 ATCA\_KEY\_SIZE

#define ATCA\_KEY\_SIZE (32)

size of a symmetric SHA key

# 20.71.2.53 ATCA\_LOCK

#define ATCA\_LOCK ((uint8\_t)0x17)

Lock command op-code.

# 20.71.2.54 ATCA\_LOCKED

#define ATCA\_LOCKED (0x00)

Value indicating a locked zone.

## 20.71.2.55 ATCA\_MAC

#define ATCA\_MAC ((uint8\_t)0x08)

MAC command op-code.

# 20.71.2.56 ATCA\_NONCE

#define ATCA\_NONCE ((uint8\_t)0x16)

Nonce command op-code.

# 20.71.2.57 ATCA\_OPCODE\_IDX

#define ATCA\_OPCODE\_IDX (1)

command packet index for op-code

# 20.71.2.58 ATCA\_OTP\_BLOCK\_MAX

#define ATCA\_OTP\_BLOCK\_MAX ((uint8\_t)1)

maximum value for OTP block

# 20.71.2.59 ATCA\_OTP\_SIZE

#define ATCA\_OTP\_SIZE (64)

size of OTP zone

# 20.71.2.60 ATCA\_P256\_KEY\_TYPE

#define ATCA\_P256\_KEY\_TYPE 4

P256 NIST ECC key.

# 20.71.2.61 ATCA\_PACKET\_OVERHEAD

```
#define ATCA_PACKET_OVERHEAD (ATCA_COUNT_SIZE + ATCA_CRC_SIZE)
```

Number of bytes in the command packet.

# 20.71.2.62 ATCA\_PARAM1\_IDX

```
#define ATCA_PARAM1_IDX (2)
```

command packet index for first parameter

# 20.71.2.63 ATCA\_PARAM2\_IDX

```
#define ATCA_PARAM2_IDX (3)
```

command packet index for second parameter

# 20.71.2.64 ATCA\_PAUSE

```
#define ATCA_PAUSE ((uint8_t)0x01)
```

Pause command op-code.

# 20.71.2.65 ATCA\_PRIV\_KEY\_SIZE

```
#define ATCA_PRIV_KEY_SIZE (32)
```

size of a p256 private key

### 20.71.2.66 ATCA\_PRIVWRITE

#define ATCA\_PRIVWRITE ((uint8\_t)0x46)

PrivWrite command op-code.

### 20.71.2.67 ATCA\_PUB\_KEY\_PAD

#define ATCA\_PUB\_KEY\_PAD (4)

size of the public key pad

### 20.71.2.68 ATCA\_PUB\_KEY\_SIZE

#define ATCA\_PUB\_KEY\_SIZE (64)

size of a p256 public key

### 20.71.2.69 ATCA\_RANDOM

#define ATCA\_RANDOM ((uint8\_t)0x1B)

Random command op-code.

## 20.71.2.70 ATCA\_READ

#define ATCA\_READ ((uint8\_t)0x02)

Read command op-code.

## 20.71.2.71 ATCA\_RSP\_DATA\_IDX

#define ATCA\_RSP\_DATA\_IDX (1)

buffer index of data in response

### 20.71.2.72 ATCA\_RSP\_SIZE\_16

```
#define ATCA_RSP_SIZE_16 ((uint8_t)19)
```

size of response packet containing 16 bytes data

#### 20.71.2.73 ATCA\_RSP\_SIZE\_32

```
#define ATCA_RSP_SIZE_32 ((uint8_t)35)
```

size of response packet containing 32 bytes data

### 20.71.2.74 ATCA\_RSP\_SIZE\_4

```
#define ATCA_RSP_SIZE_4 ((uint8_t)7)
```

size of response packet containing 4 bytes data

# 20.71.2.75 ATCA\_RSP\_SIZE\_64

```
#define ATCA_RSP_SIZE_64 ((uint8_t)67)
```

size of response packet containing 64 bytes data

## 20.71.2.76 ATCA\_RSP\_SIZE\_72

```
#define ATCA_RSP_SIZE_72 ((uint8_t)75)
```

size of response packet containing 64 bytes data

## 20.71.2.77 ATCA\_RSP\_SIZE\_MAX

```
#define ATCA_RSP_SIZE_MAX ((uint8_t)75)
```

maximum size of response packet (GenKey and Verify command)

### 20.71.2.78 ATCA\_RSP\_SIZE\_MIN

```
#define ATCA_RSP_SIZE_MIN ((uint8_t)4)
```

minimum number of bytes in response

### 20.71.2.79 ATCA\_RSP\_SIZE\_VAL

```
#define ATCA_RSP_SIZE_VAL ((uint8_t)7)
```

size of response packet containing four bytes of data

## 20.71.2.80 ATCA\_SECUREBOOT

```
#define ATCA_SECUREBOOT ((uint8_t)0x80)
```

Secure Boot command op-code.

### 20.71.2.81 ATCA\_SELFTEST

```
#define ATCA_SELFTEST ((uint8_t)0x77)
```

Self test command op-code.

## 20.71.2.82 ATCA\_SERIAL\_NUM\_SIZE

```
#define ATCA_SERIAL_NUM_SIZE (9)
```

number of bytes in the device serial number

## 20.71.2.83 ATCA\_SHA

```
#define ATCA_SHA ((uint8_t)0x47)
```

SHA command op-code.

### 20.71.2.84 ATCA\_SHA\_CONFIG\_SIZE

#define ATCA\_SHA\_CONFIG\_SIZE (88)

size of configuration zone

### 20.71.2.85 ATCA\_SHA\_DIGEST\_SIZE

#define ATCA\_SHA\_DIGEST\_SIZE (32)

## 20.71.2.86 ATCA\_SHA\_KEY\_TYPE

#define ATCA\_SHA\_KEY\_TYPE 7

SHA key or other data.

## 20.71.2.87 ATCA\_SIG\_SIZE

#define ATCA\_SIG\_SIZE (64)

size of a p256 signature

## 20.71.2.88 ATCA\_SIGN

#define ATCA\_SIGN ((uint8\_t)0x41)

Sign command op-code.

## 20.71.2.89 ATCA\_TEMPKEY\_KEYID

#define ATCA\_TEMPKEY\_KEYID (0xFFFF)

KeyID when referencing TempKey.

### 20.71.2.90 ATCA\_UNLOCKED

```
#define ATCA_UNLOCKED (0x55)
```

Value indicating an unlocked zone.

### 20.71.2.91 ATCA\_UPDATE\_EXTRA

```
#define ATCA_UPDATE_EXTRA ((uint8_t)0x20)
```

UpdateExtra command op-code.

### 20.71.2.92 ATCA\_VERIFY

```
#define ATCA_VERIFY ((uint8_t)0x45)
```

GenKey command op-code.

# 20.71.2.93 ATCA\_WORD\_SIZE

```
#define ATCA_WORD_SIZE (4)
```

size of a word

## 20.71.2.94 ATCA\_WRITE

```
#define ATCA_WRITE ((uint8_t)0x12)
```

Write command op-code.

# 20.71.2.95 ATCA\_ZONE\_ENCRYPTED

```
#define ATCA_ZONE_ENCRYPTED ((uint8_t)0x40)
```

Zone bit 6 set: Write is encrypted with an unlocked data zone.

### 20.71.2.96 ATCA\_ZONE\_MASK

#define ATCA\_ZONE\_MASK ((uint8\_t)0x03)

Zone mask.

#### 20.71.2.97 ATCA\_ZONE\_READWRITE\_32

```
#define ATCA_ZONE_READWRITE_32 ((uint8_t)0x80)
```

Zone bit 7 set: Access 32 bytes, otherwise 4 bytes.

### 20.71.2.98 CHECKMAC\_CLIENT\_CHALLENGE\_IDX

```
#define CHECKMAC_CLIENT_CHALLENGE_IDX ATCA_DATA_IDX
```

CheckMAC command index for client challenge.

### 20.71.2.99 CHECKMAC\_CLIENT\_CHALLENGE\_SIZE

```
#define CHECKMAC_CLIENT_CHALLENGE_SIZE (32)
```

CheckMAC size of client challenge.

## 20.71.2.100 CHECKMAC\_CLIENT\_COMMAND\_SIZE

```
#define CHECKMAC_CLIENT_COMMAND_SIZE (4)
```

CheckMAC size of client command header size inside "other data".

## 20.71.2.101 CHECKMAC\_CLIENT\_RESPONSE\_IDX

#define CHECKMAC\_CLIENT\_RESPONSE\_IDX (37)

CheckMAC command index for client response.

### 20.71.2.102 CHECKMAC\_CLIENT\_RESPONSE\_SIZE

#define CHECKMAC\_CLIENT\_RESPONSE\_SIZE (32)

CheckMAC size of client response.

#### 20.71.2.103 CHECKMAC\_CMD\_MATCH

```
#define CHECKMAC_CMD_MATCH (0)
```

CheckMAC return value when there is a match.

### 20.71.2.104 CHECKMAC\_CMD\_MISMATCH

```
#define CHECKMAC_CMD_MISMATCH (1)
```

CheckMAC return value when there is a mismatch.

# 20.71.2.105 CHECKMAC\_COUNT

```
#define CHECKMAC_COUNT (84)
```

CheckMAC command packet size.

## 20.71.2.106 CHECKMAC\_DATA\_IDX

```
#define CHECKMAC_DATA_IDX (69)
```

CheckMAC command index for other data.

## 20.71.2.107 CHECKMAC\_KEYID\_IDX

#define CHECKMAC\_KEYID\_IDX ATCA\_PARAM2\_IDX

CheckMAC command index for key identifier.

### 20.71.2.108 CHECKMAC\_MODE\_BLOCK1\_TEMPKEY

#define CHECKMAC\_MODE\_BLOCK1\_TEMPKEY ((uint8\_t)0x02)

CheckMAC mode bit 1: first SHA block from TempKey.

#### 20.71.2.109 CHECKMAC\_MODE\_BLOCK2\_TEMPKEY

#define CHECKMAC\_MODE\_BLOCK2\_TEMPKEY ((uint8\_t)0x01)

CheckMAC mode bit 0: second SHA block from TempKey.

### 20.71.2.110 CHECKMAC\_MODE\_CHALLENGE

#define CHECKMAC\_MODE\_CHALLENGE ((uint8\_t)0x00)

CheckMAC mode 0: first SHA block from key id.

### 20.71.2.111 CHECKMAC\_MODE\_IDX

#define CHECKMAC\_MODE\_IDX ATCA\_PARAM1\_IDX

CheckMAC command index for mode.

### 20.71.2.112 CHECKMAC MODE INCLUDE OTP 64

#define CHECKMAC\_MODE\_INCLUDE\_OTP\_64 ((uint8\_t)0x20)

CheckMAC mode bit 5: include first 64 OTP bits.

## 20.71.2.113 CHECKMAC\_MODE\_MASK

#define CHECKMAC\_MODE\_MASK ((uint8\_t)0x27)

CheckMAC mode bits 3, 4, 6, and 7 are 0.

### 20.71.2.114 CHECKMAC\_MODE\_SOURCE\_FLAG\_MATCH

 $\texttt{\#define CHECKMAC\_MODE\_SOURCE\_FLAG\_MATCH ((uint8\_t)0x04)}$ 

CheckMAC mode bit 2: match TempKey.SourceFlag.

### 20.71.2.115 CHECKMAC\_OTHER\_DATA\_SIZE

#define CHECKMAC\_OTHER\_DATA\_SIZE (13)

CheckMAC size of "other data".

### 20.71.2.116 CHECKMAC\_RSP\_SIZE

#define CHECKMAC\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

CheckMAC response packet size.

### 20.71.2.117 CMD\_STATUS\_BYTE\_COMM

#define CMD\_STATUS\_BYTE\_COMM ((uint8\_t)0xFF)

communication error

## 20.71.2.118 CMD\_STATUS\_BYTE\_ECC

#define CMD\_STATUS\_BYTE\_ECC ((uint8\_t)0x05)

command ECC error

# 20.71.2.119 CMD\_STATUS\_BYTE\_EXEC

#define CMD\_STATUS\_BYTE\_EXEC ((uint8\_t)0x0F)

command execution error

### 20.71.2.120 CMD\_STATUS\_BYTE\_PARSE

#define CMD\_STATUS\_BYTE\_PARSE ((uint8\_t)0x03)

command parse error

### 20.71.2.121 CMD\_STATUS\_SUCCESS

#define CMD\_STATUS\_SUCCESS ((uint8\_t)0x00)

status byte for success

### 20.71.2.122 CMD\_STATUS\_WAKEUP

#define CMD\_STATUS\_WAKEUP ((uint8\_t)0x11)

status byte after wake-up

## 20.71.2.123 COUNTER\_COUNT

#define COUNTER\_COUNT ATCA\_CMD\_SIZE\_MIN

## 20.71.2.124 COUNTER\_KEYID\_IDX

#define COUNTER\_KEYID\_IDX ATCA\_PARAM2\_IDX

Counter command index for key id.

## 20.71.2.125 COUNTER\_MAX\_VALUE

#define COUNTER\_MAX\_VALUE ((uint32\_t)2097151)

Counter maximum value of the counter.

# 20.71.2.126 COUNTER\_MODE\_IDX

#define COUNTER\_MODE\_IDX ATCA\_PARAM1\_IDX

Counter command index for mode.

### 20.71.2.127 COUNTER\_MODE\_INCREMENT

```
\#define COUNTER_MODE_INCREMENT ((uint8_t)0x01)
```

Counter command mode for incrementing.

### 20.71.2.128 COUNTER\_MODE\_MASK

```
#define COUNTER_MODE_MASK ((uint8_t)0x01)
```

Counter mode bits 1 to 7 are 0.

### 20.71.2.129 COUNTER\_MODE\_READ

```
#define COUNTER_MODE_READ ((uint8_t)0x00)
```

Counter command mode for reading.

## 20.71.2.130 COUNTER\_RSP\_SIZE

```
#define COUNTER_RSP_SIZE ATCA_RSP_SIZE_4
```

Counter command response packet size.

## 20.71.2.131 COUNTER\_SIZE

#define COUNTER\_SIZE ATCA\_RSP\_SIZE\_MIN

Counter size in binary.

### 20.71.2.132 DERIVE\_KEY\_COUNT\_LARGE

```
#define DERIVE_KEY_COUNT_LARGE (39)
```

DeriveKey command packet size with MAC.

### 20.71.2.133 DERIVE\_KEY\_COUNT\_SMALL

```
#define DERIVE_KEY_COUNT_SMALL ATCA_CMD_SIZE_MIN
```

DeriveKey command packet size without MAC.

### 20.71.2.134 DERIVE\_KEY\_MAC\_IDX

```
#define DERIVE_KEY_MAC_IDX ATCA_DATA_IDX
```

DeriveKey command index for optional MAC.

# 20.71.2.135 DERIVE\_KEY\_MAC\_SIZE

```
#define DERIVE_KEY_MAC_SIZE (32)
```

DeriveKey MAC size.

## 20.71.2.136 DERIVE\_KEY\_MODE

```
\#define DERIVE_KEY_MODE ((uint8_t)0x04)
```

DeriveKey command mode set to 4 as in datasheet.

## 20.71.2.137 DERIVE\_KEY\_RANDOM\_FLAG

```
#define DERIVE_KEY_RANDOM_FLAG ((uint8_t)4)
```

DeriveKey 1. parameter; has to match TempKey.SourceFlag.

### 20.71.2.138 DERIVE\_KEY\_RANDOM\_IDX

#define DERIVE\_KEY\_RANDOM\_IDX ATCA\_PARAM1\_IDX

DeriveKey command index for random bit.

### 20.71.2.139 DERIVE\_KEY\_RSP\_SIZE

#define DERIVE\_KEY\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

DeriveKey response packet size.

### 20.71.2.140 DERIVE\_KEY\_TARGETKEY\_IDX

#define DERIVE\_KEY\_TARGETKEY\_IDX ATCA\_PARAM2\_IDX

DeriveKey command index for target slot.

### 20.71.2.141 ECDH\_COUNT

#define ECDH\_COUNT (ATCA\_CMD\_SIZE\_MIN + ATCA\_PUB\_KEY\_SIZE)

### 20.71.2.142 ECDH KEY SIZE

#define ECDH\_KEY\_SIZE ATCA\_BLOCK\_SIZE

ECDH output data size.

## 20.71.2.143 ECDH\_MODE\_COPY\_COMPATIBLE

#define ECDH\_MODE\_COPY\_COMPATIBLE ((uint8\_t)0x00)

### 20.71.2.144 ECDH\_MODE\_COPY\_EEPROM\_SLOT

 $\verb|#define ECDH_MODE_COPY_EEPROM_SLOT ((uint8\_t)0x04)|\\$ 

### 20.71.2.145 ECDH\_MODE\_COPY\_MASK

#define ECDH\_MODE\_COPY\_MASK ((uint8\_t)0x0C)

### 20.71.2.146 ECDH\_MODE\_COPY\_OUTPUT\_BUFFER

#define ECDH\_MODE\_COPY\_OUTPUT\_BUFFER ((uint8\_t)0x0C)

### 20.71.2.147 ECDH\_MODE\_COPY\_TEMP\_KEY

#define ECDH\_MODE\_COPY\_TEMP\_KEY ((uint8\_t)0x08)

### 20.71.2.148 ECDH\_MODE\_OUTPUT\_CLEAR

#define ECDH\_MODE\_OUTPUT\_CLEAR ((uint8\_t)0x00)

### 20.71.2.149 ECDH\_MODE\_OUTPUT\_ENC

#define ECDH\_MODE\_OUTPUT\_ENC ((uint8\_t)0x02)

### 20.71.2.150 ECDH MODE OUTPUT MASK

#define ECDH\_MODE\_OUTPUT\_MASK ((uint8\_t)0x02)

# 20.71.2.151 ECDH\_MODE\_SOURCE\_EEPROM\_SLOT

#define ECDH\_MODE\_SOURCE\_EEPROM\_SLOT ((uint8\_t)0x00)

### 20.71.2.152 ECDH\_MODE\_SOURCE\_MASK

#define ECDH\_MODE\_SOURCE\_MASK ((uint8\_t)0x01)

# 20.71.2.153 ECDH\_MODE\_SOURCE\_TEMPKEY

#define ECDH\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x01)

### 20.71.2.154 ECDH\_PREFIX\_MODE

#define ECDH\_PREFIX\_MODE ((uint8\_t)0x00)

### 20.71.2.155 ECDH\_RSP\_SIZE

#define ECDH\_RSP\_SIZE ATCA\_RSP\_SIZE\_64

ECDH command packet size.

### 20.71.2.156 GENDIG\_COUNT

#define GENDIG\_COUNT ATCA\_CMD\_SIZE\_MIN

GenDig command packet size without "other data".

### 20.71.2.157 **GENDIG\_DATA\_IDX**

#define GENDIG\_DATA\_IDX ATCA\_DATA\_IDX

GenDig command index for optional data.

### 20.71.2.158 GENDIG\_KEYID\_IDX

#define GENDIG\_KEYID\_IDX ATCA\_PARAM2\_IDX

GenDig command index for key id.

### 20.71.2.159 **GENDIG\_RSP\_SIZE**

```
#define GENDIG_RSP_SIZE ATCA_RSP_SIZE_MIN
```

GenDig command response packet size.

### 20.71.2.160 GENDIG\_ZONE\_CONFIG

```
#define GENDIG_ZONE_CONFIG ((uint8_t)0)
```

GenDig zone id config. Use KeyID to specify any of the four 256-bit blocks of the Configuration zone.

### 20.71.2.161 GENDIG\_ZONE\_COUNTER

```
#define GENDIG_ZONE_COUNTER ((uint8_t)4)
```

GenDig zone id counter. KeyID specifies the monotonic counter ID to be included in the message generation.

## 20.71.2.162 **GENDIG\_ZONE\_DATA**

```
#define GENDIG_ZONE_DATA ((uint8_t)2)
```

GenDig zone id data. Use KeyID to specify a slot in the Data zone or a transport key in the hardware array.

### 20.71.2.163 **GENDIG\_ZONE\_IDX**

```
#define GENDIG_ZONE_IDX ATCA_PARAM1_IDX
```

GenDig command index for zone.

#### 20.71.2.164 GENDIG ZONE KEY CONFIG

```
#define GENDIG_ZONE_KEY_CONFIG ((uint8_t)5)
```

GenDig zone id key config. KeyID specifies the slot for which the configuration information is to be included in the message generation.

### 

```
#define GENDIG_ZONE_OTP ((uint8_t)1)
```

GenDig zone id OTP. Use KeyID to specify either the first or second 256-bit block of the OTP zone.

#### 20.71.2.166 GENDIG\_ZONE\_SHARED\_NONCE

```
#define GENDIG_ZONE_SHARED_NONCE ((uint8_t)3)
```

GenDig zone id shared nonce. KeyID specifies the location of the input value in the message generation.

### 20.71.2.167 GENKEY\_COUNT

```
#define GENKEY_COUNT ATCA_CMD_SIZE_MIN
```

GenKey command packet size without "other data".

### 20.71.2.168 GENKEY\_COUNT\_DATA

```
#define GENKEY_COUNT_DATA (10)
```

GenKey command packet size with "other data".

## 20.71.2.169 **GENKEY\_DATA\_IDX**

```
#define GENKEY_DATA_IDX (5)
```

GenKey command index for other data.

## 20.71.2.170 GENKEY\_KEYID\_IDX

```
#define GENKEY_KEYID_IDX ATCA_PARAM2_IDX
```

GenKey command index for key id.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 738

### 20.71.2.171 GENKEY\_MODE\_DIGEST

```
#define GENKEY_MODE_DIGEST ((uint8_t)0x08)
```

GenKey mode: PubKey digest will be created after the public key is calculated.

#### 20.71.2.172 **GENKEY\_MODE\_IDX**

```
#define GENKEY_MODE_IDX ATCA_PARAM1_IDX
```

GenKey command index for mode.

### 20.71.2.173 GENKEY\_MODE\_MASK

```
#define GENKEY_MODE_MASK ((uint8_t)0x1C)
```

GenKey mode bits 0 to 1 and 5 to 7 are 0.

### 20.71.2.174 GENKEY\_MODE\_PRIVATE

```
#define GENKEY_MODE_PRIVATE ((uint8_t)0x04)
```

GenKey mode: private key generation.

## 20.71.2.175 GENKEY\_MODE\_PUBKEY\_DIGEST

```
#define GENKEY_MODE_PUBKEY_DIGEST ((uint8_t)0x10)
```

GenKey mode: Calculate PubKey digest on the public key in Keyld.

## 20.71.2.176 GENKEY\_MODE\_PUBLIC

```
#define GENKEY_MODE_PUBLIC ((uint8_t)0x00)
```

GenKey mode: public key calculation.

### 20.71.2.177 GENKEY\_OTHER\_DATA\_SIZE

#define GENKEY\_OTHER\_DATA\_SIZE (3)

GenKey size of "other data".

## 20.71.2.178 GENKEY\_PRIVATE\_TO\_TEMPKEY

```
#define GENKEY_PRIVATE_TO_TEMPKEY ((uint16_t)0xFFFF)
```

GenKey Create private key and store to tempkey (608 only)

### 20.71.2.179 GENKEY\_RSP\_SIZE\_LONG

```
#define GENKEY_RSP_SIZE_LONG ATCA_RSP_SIZE_64
```

GenKey response packet size when returning a public key.

### 20.71.2.180 GENKEY\_RSP\_SIZE\_SHORT

```
#define GENKEY_RSP_SIZE_SHORT ATCA_RSP_SIZE_MIN
```

GenKey response packet size in Digest mode.

## 20.71.2.181 HMAC\_COUNT

```
#define HMAC_COUNT ATCA_CMD_SIZE_MIN
```

HMAC command packet size.

# 20.71.2.182 HMAC\_DIGEST\_SIZE

```
#define HMAC_DIGEST_SIZE (32)
```

HMAC size of digest response.

### 20.71.2.183 HMAC\_KEYID\_IDX

```
#define HMAC_KEYID_IDX ATCA_PARAM2_IDX
```

HMAC command index for key id.

### 20.71.2.184 HMAC\_MODE\_FLAG\_FULLSN

```
#define HMAC_MODE_FLAG_FULLSN ((uint8_t)0x40)
```

HMAC mode bit 6: If set, include the 48 bits SN[2:3] and SN[4:7] in the message.; otherwise, the corresponding message bits are set to zero.

#### 20.71.2.185 HMAC\_MODE\_FLAG\_OTP64

```
#define HMAC_MODE_FLAG_OTP64 ((uint8_t)0x20)
```

HMAC mode bit 5: Include the first 64 OTP bits (OTP[0] through OTP[7]) in the message.; otherwise, the corresponding message bits are set to zero. If Mode[4] is set, the value of this mode bit is ignored. Not applicable for ATECC508A.

### 20.71.2.186 HMAC\_MODE\_FLAG\_OTP88

```
#define HMAC_MODE_FLAG_OTP88 ((uint8_t)0x10)
```

HMAC mode bit 4: Include the first 88 OTP bits (OTP[0] through OTP[10]) in the message.; otherwise, the corresponding message bits are set to zero. Not applicable for ATECC508A.

### 20.71.2.187 HMAC\_MODE\_FLAG\_TK\_NORAND

```
#define HMAC_MODE_FLAG_TK_NORAND ((uint8_t)0x04)
```

HMAC mode bit 2: The value of this bit must match the value in TempKey.SourceFlag or the command will return an error.

### 20.71.2.188 HMAC\_MODE\_FLAG\_TK\_RAND

```
#define HMAC_MODE_FLAG_TK_RAND ((uint8_t)0x00)
```

HMAC mode bit 2: The value of this bit must match the value in TempKey.SourceFlag or the command will return an error.

### 20.71.2.189 HMAC\_MODE\_IDX

```
#define HMAC_MODE_IDX ATCA_PARAM1_IDX
```

HMAC command index for mode.

### 20.71.2.190 HMAC\_MODE\_MASK

```
\#define HMAC\_MODE\_MASK ((uint8_t)0x74)
```

HMAC mode bits 0, 1, 3, and 7 are 0.

### 20.71.2.191 HMAC\_RSP\_SIZE

```
#define HMAC_RSP_SIZE ATCA_RSP_SIZE_32
```

HMAC command response packet size.

# 20.71.2.192 INFO\_COUNT

```
#define INFO_COUNT ATCA_CMD_SIZE_MIN
```

Info command packet size.

## 20.71.2.193 INFO\_DRIVER\_STATE\_MASK

```
#define INFO_DRIVER_STATE_MASK ((uint8_t)0x02)
```

Info driver state mask.

## 20.71.2.194 INFO\_MODE\_GPIO

```
#define INFO_MODE_GPIO ((uint8_t)0x03)
```

Info mode GPIO.

## 20.71.2.195 INFO\_MODE\_KEY\_VALID

#define INFO\_MODE\_KEY\_VALID ((uint8\_t)0x01)

Info mode KeyValid.

### 20.71.2.196 INFO\_MODE\_MAX

#define INFO\_MODE\_MAX ((uint8\_t)0x03)

Info mode maximum value.

## 20.71.2.197 INFO\_MODE\_REVISION

#define INFO\_MODE\_REVISION ((uint8\_t)0x00)

Info mode Revision.

# 20.71.2.198 INFO\_MODE\_STATE

#define INFO\_MODE\_STATE ((uint8\_t)0x02)

Info mode State.

## 20.71.2.199 INFO\_MODE\_VOL\_KEY\_PERMIT

#define INFO\_MODE\_VOL\_KEY\_PERMIT ((uint8\_t)0x04)

Info mode GPIO.

## 20.71.2.200 INFO\_NO\_STATE

#define INFO\_NO\_STATE ((uint8\_t)0x00)

Info mode is not the state mode.

### 20.71.2.201 INFO\_OUTPUT\_STATE\_MASK

#define INFO\_OUTPUT\_STATE\_MASK ((uint8\_t)0x01)

Info output state mask.

#### 20.71.2.202 INFO\_PARAM1\_IDX

```
#define INFO_PARAM1_IDX ATCA_PARAM1_IDX
```

Info command index for 1. parameter.

### 20.71.2.203 INFO\_PARAM2\_IDX

```
#define INFO_PARAM2_IDX ATCA_PARAM2_IDX
```

Info command index for 2. parameter.

### 20.71.2.204 INFO\_PARAM2\_LATCH\_CLEAR

```
#define INFO_PARAM2_LATCH_CLEAR ((uint16_t)0x0000)
```

Info param2 to clear the persistent latch.

## 20.71.2.205 INFO\_PARAM2\_LATCH\_SET

```
#define INFO_PARAM2_LATCH_SET ((uint16_t)0x0001)
```

Info param2 to set the persistent latch.

## 20.71.2.206 INFO\_PARAM2\_SET\_LATCH\_STATE

```
#define INFO_PARAM2_SET_LATCH_STATE ((uint16_t)0x0002)
```

Info param2 to set the persistent latch state.

### 20.71.2.207 INFO\_RSP\_SIZE

```
#define INFO_RSP_SIZE ATCA_RSP_SIZE_VAL
```

Info command response packet size.

#### 20.71.2.208 INFO\_SIZE

```
#define INFO_SIZE ((uint8_t)0x04)
```

Info return size.

### 20.71.2.209 KDF\_DETAILS\_AES\_KEY\_LOC\_MASK

```
#define KDF_DETAILS_AES_KEY_LOC_MASK ((uint32_t)0x00000003)
```

KDF details for AES, key location mask.

### 20.71.2.210 KDF\_DETAILS\_HKDF\_MSG\_LOC\_INPUT

```
#define KDF_DETAILS_HKDF_MSG_LOC_INPUT ((uint32_t)0x00000002)
```

KDF details for HKDF, message location in input parameter.

## 20.71.2.211 KDF\_DETAILS\_HKDF\_MSG\_LOC\_IV

```
#define KDF_DETAILS_HKDF_MSG_LOC_IV ((uint32_t)0x0000003)
```

KDF details for HKDF, message location is a special IV function.

## 20.71.2.212 KDF\_DETAILS\_HKDF\_MSG\_LOC\_MASK

```
#define KDF_DETAILS_HKDF_MSG_LOC_MASK ((uint32_t)0x0000003)
```

KDF details for HKDF, message location mask.

### 20.71.2.213 KDF\_DETAILS\_HKDF\_MSG\_LOC\_SLOT

#define KDF\_DETAILS\_HKDF\_MSG\_LOC\_SLOT ((uint32\_t)0x0000000)

KDF details for HKDF, message location in slot.

#### 20.71.2.214 KDF\_DETAILS\_HKDF\_MSG\_LOC\_TEMPKEY

#define KDF\_DETAILS\_HKDF\_MSG\_LOC\_TEMPKEY ((uint32\_t)0x0000001)

KDF details for HKDF, message location in TempKey.

### 20.71.2.215 KDF\_DETAILS\_HKDF\_ZERO\_KEY

#define KDF\_DETAILS\_HKDF\_ZERO\_KEY ((uint32\_t)0x00000004)

KDF details for HKDF, key is 32 bytes of zero.

### 20.71.2.216 KDF\_DETAILS\_IDX

#define KDF\_DETAILS\_IDX ATCA\_DATA\_IDX

KDF command index for details.

## 20.71.2.217 KDF\_DETAILS\_PRF\_AEAD\_MASK

#define KDF\_DETAILS\_PRF\_AEAD\_MASK ((uint32\_t)0x00000600)

KDF details for PRF, AEAD processing mask.

## 20.71.2.218 KDF\_DETAILS\_PRF\_AEAD\_MODE0

#define KDF\_DETAILS\_PRF\_AEAD\_MODE0 ((uint32\_t)0x0000000)

KDF details for PRF, AEAD no processing.

### 20.71.2.219 KDF\_DETAILS\_PRF\_AEAD\_MODE1

#define KDF\_DETAILS\_PRF\_AEAD\_MODE1 ((uint32\_t)0x00000200)

KDF details for PRF, AEAD First 32 go to target, second 32 go to output buffer.

#### 20.71.2.220 KDF\_DETAILS\_PRF\_KEY\_LEN\_16

#define KDF\_DETAILS\_PRF\_KEY\_LEN\_16 ((uint32\_t)0x0000000)

KDF details for PRF, source key length is 16 bytes.

### 20.71.2.221 KDF\_DETAILS\_PRF\_KEY\_LEN\_32

#define KDF\_DETAILS\_PRF\_KEY\_LEN\_32 ((uint32\_t)0x00000001)

KDF details for PRF, source key length is 32 bytes.

### 20.71.2.222 KDF\_DETAILS\_PRF\_KEY\_LEN\_48

#define KDF\_DETAILS\_PRF\_KEY\_LEN\_48 ((uint32\_t)0x00000002)

KDF details for PRF, source key length is 48 bytes.

## 20.71.2.223 KDF\_DETAILS\_PRF\_KEY\_LEN\_64

#define KDF\_DETAILS\_PRF\_KEY\_LEN\_64 ((uint32\_t)0x0000003)

KDF details for PRF, source key length is 64 bytes.

# 20.71.2.224 KDF\_DETAILS\_PRF\_KEY\_LEN\_MASK

#define KDF\_DETAILS\_PRF\_KEY\_LEN\_MASK ((uint32\_t)0x0000003)

KDF details for PRF, source key length mask.

### 20.71.2.225 KDF\_DETAILS\_PRF\_TARGET\_LEN\_32

#define KDF\_DETAILS\_PRF\_TARGET\_LEN\_32 ((uint32\_t)0x0000000)

KDF details for PRF, target length is 32 bytes.

### 20.71.2.226 KDF DETAILS PRF TARGET LEN 64

```
#define KDF_DETAILS_PRF_TARGET_LEN_64 ((uint32_t)0x00000100)
```

KDF details for PRF, target length is 64 bytes.

### 20.71.2.227 KDF\_DETAILS\_PRF\_TARGET\_LEN\_MASK

```
#define KDF_DETAILS_PRF_TARGET_LEN_MASK ((uint32_t)0x0000100)
```

KDF details for PRF, target length mask.

## 20.71.2.228 KDF\_DETAILS\_SIZE

```
#define KDF_DETAILS_SIZE 4
```

KDF details (param3) size.

### 20.71.2.229 KDF\_KEYID\_IDX

```
#define KDF_KEYID_IDX ATCA_PARAM2_IDX
```

KDF command index for key id.

# 20.71.2.230 KDF\_MESSAGE\_IDX

#define KDF\_MESSAGE\_IDX (ATCA\_DATA\_IDX + KDF\_DETAILS\_SIZE)

### 20.71.2.231 KDF\_MODE\_ALG\_AES

#define KDF\_MODE\_ALG\_AES ((uint8\_t)0x20)

KDF mode AES algorithm.

# 20.71.2.232 KDF\_MODE\_ALG\_HKDF

```
#define KDF_MODE_ALG_HKDF ((uint8_t)0x40)
```

KDF mode HKDF algorithm.

### 20.71.2.233 KDF\_MODE\_ALG\_MASK

```
#define KDF_MODE_ALG_MASK ((uint8_t)0x60)
```

KDF mode algorithm mask.

# 20.71.2.234 KDF\_MODE\_ALG\_PRF

```
#define KDF_MODE_ALG_PRF ((uint8_t)0x00)
```

KDF mode PRF algorithm.

## 20.71.2.235 KDF\_MODE\_IDX

```
#define KDF_MODE_IDX ATCA_PARAM1_IDX
```

KDF command index for mode.

## 20.71.2.236 KDF\_MODE\_SOURCE\_ALTKEYBUF

```
#define KDF_MODE_SOURCE_ALTKEYBUF ((uint8_t)0x03)
```

KDF mode source key in alternate key buffer.

### 20.71.2.237 KDF\_MODE\_SOURCE\_MASK

#define KDF\_MODE\_SOURCE\_MASK ((uint8\_t)0x03)

KDF mode source key mask.

### 20.71.2.238 KDF\_MODE\_SOURCE\_SLOT

#define KDF\_MODE\_SOURCE\_SLOT ((uint8\_t)0x02)

KDF mode source key in a slot.

### 20.71.2.239 KDF\_MODE\_SOURCE\_TEMPKEY

#define KDF\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x00)

KDF mode source key in TempKey.

# 20.71.2.240 KDF\_MODE\_SOURCE\_TEMPKEY\_UP

 $\verb|#define KDF_MODE_SOURCE_TEMPKEY_UP ((uint8\_t)0x01)|\\$ 

KDF mode source key in upper TempKey.

## 20.71.2.241 KDF\_MODE\_TARGET\_ALTKEYBUF

#define KDF\_MODE\_TARGET\_ALTKEYBUF ((uint8\_t)0x0C)

KDF mode target key in alternate key buffer.

## 20.71.2.242 KDF\_MODE\_TARGET\_MASK

#define KDF\_MODE\_TARGET\_MASK ((uint8\_t)0x1C)

KDF mode target key mask.

### 20.71.2.243 KDF\_MODE\_TARGET\_OUTPUT

```
#define KDF_MODE_TARGET_OUTPUT ((uint8_t)0x10)
```

KDF mode target key in output buffer.

### 20.71.2.244 KDF\_MODE\_TARGET\_OUTPUT\_ENC

```
#define KDF_MODE_TARGET_OUTPUT_ENC ((uint8_t)0x14)
```

KDF mode target key encrypted in output buffer.

### 20.71.2.245 KDF\_MODE\_TARGET\_SLOT

```
#define KDF_MODE_TARGET_SLOT ((uint8_t)0x08)
```

KDF mode target key in slot.

# 20.71.2.246 KDF\_MODE\_TARGET\_TEMPKEY

```
#define KDF_MODE_TARGET_TEMPKEY ((uint8_t)0x00)
```

KDF mode target key in TempKey.

## 20.71.2.247 KDF\_MODE\_TARGET\_TEMPKEY\_UP

```
#define KDF_MODE_TARGET_TEMPKEY_UP ((uint8_t)0x04)
```

KDF mode target key in upper TempKey.

## 20.71.2.248 LOCK\_COUNT

#define LOCK\_COUNT ATCA\_CMD\_SIZE\_MIN

Lock command packet size.

### 20.71.2.249 LOCK\_RSP\_SIZE

```
#define LOCK_RSP_SIZE ATCA_RSP_SIZE_MIN
```

Lock command response packet size.

### 20.71.2.250 LOCK\_SUMMARY\_IDX

```
#define LOCK_SUMMARY_IDX ATCA_PARAM2_IDX
```

Lock command index for summary.

### 20.71.2.251 LOCK\_ZONE\_CONFIG

```
#define LOCK_ZONE_CONFIG ((uint8_t)0x00)
```

Lock zone is Config.

# 20.71.2.252 LOCK\_ZONE\_DATA

```
#define LOCK_ZONE_DATA ((uint8_t)0x01)
```

Lock zone is OTP or Data.

## 20.71.2.253 LOCK\_ZONE\_DATA\_SLOT

```
#define LOCK_ZONE_DATA_SLOT ((uint8_t)0x02)
```

Lock slot of Data.

## 20.71.2.254 LOCK\_ZONE\_IDX

```
#define LOCK_ZONE_IDX ATCA_PARAM1_IDX
```

Lock command index for zone.

### 20.71.2.255 LOCK\_ZONE\_MASK

```
#define LOCK_ZONE_MASK (0xBF)
```

Lock parameter 1 bits 6 are 0.

### 20.71.2.256 LOCK\_ZONE\_NO\_CRC

```
#define LOCK_ZONE_NO_CRC ((uint8_t)0x80)
```

Lock command: Ignore summary.

### 20.71.2.257 MAC\_CHALLENGE\_IDX

```
#define MAC_CHALLENGE_IDX ATCA_DATA_IDX
```

MAC command index for optional challenge.

# 20.71.2.258 MAC\_CHALLENGE\_SIZE

```
#define MAC_CHALLENGE_SIZE (32)
```

MAC size of challenge.

## 20.71.2.259 MAC\_COUNT\_LONG

```
#define MAC_COUNT_LONG (39)
```

MAC command packet size with challenge.

## 20.71.2.260 MAC\_COUNT\_SHORT

```
#define MAC_COUNT_SHORT ATCA_CMD_SIZE_MIN
```

MAC command packet size without challenge.

### 20.71.2.261 MAC\_KEYID\_IDX

#define MAC\_KEYID\_IDX ATCA\_PARAM2\_IDX

MAC command index for key id.

#### 20.71.2.262 MAC\_MODE\_BLOCK1\_TEMPKEY

#define MAC\_MODE\_BLOCK1\_TEMPKEY ((uint8\_t)0x02)

MAC mode bit 1: first SHA block from TempKey.

### 20.71.2.263 MAC\_MODE\_BLOCK2\_TEMPKEY

#define MAC\_MODE\_BLOCK2\_TEMPKEY ((uint8\_t)0x01)

MAC mode bit 0: second SHA block from TempKey.

### 20.71.2.264 MAC\_MODE\_CHALLENGE

#define MAC\_MODE\_CHALLENGE ((uint8\_t)0x00)

MAC mode 0: first SHA block from data slot.

## 20.71.2.265 MAC\_MODE\_IDX

#define MAC\_MODE\_IDX ATCA\_PARAM1\_IDX

MAC command index for mode.

## 20.71.2.266 MAC\_MODE\_INCLUDE\_OTP\_64

#define MAC\_MODE\_INCLUDE\_OTP\_64 ((uint8\_t)0x20)

MAC mode bit 5: include first 64 OTP bits.

### 20.71.2.267 MAC\_MODE\_INCLUDE\_OTP\_88

#define MAC\_MODE\_INCLUDE\_OTP\_88 ((uint8\_t)0x10)

MAC mode bit 4: include first 88 OTP bits.

#### 20.71.2.268 MAC\_MODE\_INCLUDE\_SN

#define MAC\_MODE\_INCLUDE\_SN ((uint8\_t)0x40)

MAC mode bit 6: include serial number.

### 20.71.2.269 MAC\_MODE\_MASK

#define MAC\_MODE\_MASK ((uint8\_t)0x77)

MAC mode bits 3 and 7 are 0.

# 20.71.2.270 MAC\_MODE\_PASSTHROUGH

#define MAC\_MODE\_PASSTHROUGH ((uint8\_t)0x07)

MAC mode bit 0-2: pass-through mode.

## 20.71.2.271 MAC\_MODE\_PTNONCE\_TEMPKEY

#define MAC\_MODE\_PTNONCE\_TEMPKEY ((uint8\_t)0x06)

MAC mode bit 0: second SHA block from TempKey.

## 20.71.2.272 MAC\_MODE\_SOURCE\_FLAG\_MATCH

#define MAC\_MODE\_SOURCE\_FLAG\_MATCH ((uint8\_t)0x04)

MAC mode bit 2: match TempKey.SourceFlag.

## 20.71.2.273 MAC\_RSP\_SIZE

```
#define MAC_RSP_SIZE ATCA_RSP_SIZE_32
```

MAC command response packet size.

#### 20.71.2.274 MAC\_SIZE

```
#define MAC_SIZE (32)
```

MAC size of response.

### 20.71.2.275 NONCE\_COUNT\_LONG

```
#define NONCE_COUNT_LONG (ATCA_CMD_SIZE_MIN + 32)
```

Nonce command packet size for 32 bytes of Numln.

### 20.71.2.276 NONCE\_COUNT\_LONG\_64

```
#define NONCE_COUNT_LONG_64 (ATCA_CMD_SIZE_MIN + 64)
```

Nonce command packet size for 64 bytes of Numln.

## 20.71.2.277 NONCE\_COUNT\_SHORT

```
#define NONCE_COUNT_SHORT (ATCA_CMD_SIZE_MIN + 20)
```

Nonce command packet size for 20 bytes of Numln.

## 20.71.2.278 NONCE\_INPUT\_IDX

```
#define NONCE_INPUT_IDX ATCA_DATA_IDX
```

Nonce command index for input data.

### 20.71.2.279 NONCE\_MODE\_IDX

#define NONCE\_MODE\_IDX ATCA\_PARAM1\_IDX

Nonce command index for mode.

### 20.71.2.280 NONCE\_MODE\_INPUT\_LEN\_32

#define NONCE\_MODE\_INPUT\_LEN\_32 ((uint8\_t)0x00)

Nonce mode: input size is 32 bytes.

### 20.71.2.281 NONCE\_MODE\_INPUT\_LEN\_64

#define NONCE\_MODE\_INPUT\_LEN\_64 ((uint8\_t)0x20)

Nonce mode: input size is 64 bytes.

### 20.71.2.282 NONCE\_MODE\_INPUT\_LEN\_MASK

#define NONCE\_MODE\_INPUT\_LEN\_MASK ((uint8\_t)0x20)

Nonce mode: input size mask.

## 20.71.2.283 NONCE\_MODE\_INVALID

#define NONCE\_MODE\_INVALID ((uint8\_t)0x02)

Nonce mode 2 is invalid.

## 20.71.2.284 NONCE\_MODE\_MASK

#define NONCE\_MODE\_MASK ((uint8\_t)0x03)

Nonce mode bits 2 to 7 are 0.

### 20.71.2.285 NONCE\_MODE\_NO\_SEED\_UPDATE

#define NONCE\_MODE\_NO\_SEED\_UPDATE ((uint8\_t)0x01)

Nonce mode: do not update seed.

#### 20.71.2.286 NONCE\_MODE\_PASSTHROUGH

#define NONCE\_MODE\_PASSTHROUGH ((uint8\_t)0x03)

Nonce mode: pass-through.

### 20.71.2.287 NONCE\_MODE\_SEED\_UPDATE

#define NONCE\_MODE\_SEED\_UPDATE ((uint8\_t)0x00)

Nonce mode: update seed.

## 20.71.2.288 NONCE\_MODE\_TARGET\_ALTKEYBUF

#define NONCE\_MODE\_TARGET\_ALTKEYBUF ((uint8\_t)0x80)

Nonce mode: target is Alternate Key Buffer.

# 20.71.2.289 NONCE\_MODE\_TARGET\_MASK

#define NONCE\_MODE\_TARGET\_MASK ((uint8\_t)0xC0)

Nonce mode: target mask.

# 20.71.2.290 NONCE\_MODE\_TARGET\_MSGDIGBUF

#define NONCE\_MODE\_TARGET\_MSGDIGBUF ((uint8\_t)0x40)

Nonce mode: target is Message Digest Buffer.

### 20.71.2.291 NONCE\_MODE\_TARGET\_TEMPKEY

#define NONCE\_MODE\_TARGET\_TEMPKEY ((uint8\_t)0x00)

Nonce mode: target is TempKey.

#### 20.71.2.292 NONCE\_NUMIN\_SIZE

```
#define NONCE_NUMIN_SIZE (20)
```

Nonce NumIn size for random modes.

### 20.71.2.293 NONCE\_NUMIN\_SIZE\_PASSTHROUGH

#define NONCE\_NUMIN\_SIZE\_PASSTHROUGH (32)

Nonce NumIn size for 32-byte pass-through mode.

## 20.71.2.294 NONCE\_PARAM2\_IDX

#define NONCE\_PARAM2\_IDX ATCA\_PARAM2\_IDX

Nonce command index for 2. parameter.

## 20.71.2.295 NONCE\_RSP\_SIZE\_LONG

#define NONCE\_RSP\_SIZE\_LONG ATCA\_RSP\_SIZE\_32

Nonce command response packet size with output.

# 20.71.2.296 NONCE\_RSP\_SIZE\_SHORT

#define NONCE\_RSP\_SIZE\_SHORT ATCA\_RSP\_SIZE\_MIN

Nonce command response packet size with no output.

### 20.71.2.297 NONCE\_ZERO\_CALC\_MASK

```
#define NONCE_ZERO_CALC_MASK ((uint16_t)0x8000)
```

Nonce zero (param2): calculation mode mask.

#### 20.71.2.298 NONCE\_ZERO\_CALC\_RANDOM

```
#define NONCE_ZERO_CALC_RANDOM ((uint16_t)0x0000)
```

Nonce zero (param2): calculation mode random, use RNG in calculation and return RNG output.

## 20.71.2.299 NONCE\_ZERO\_CALC\_TEMPKEY

```
#define NONCE_ZERO_CALC_TEMPKEY ((uint16_t)0x8000)
```

Nonce zero (param2): calculation mode TempKey, use TempKey in calculation and return new TempKey value.

## 20.71.2.300 OUTNONCE\_SIZE

```
#define OUTNONCE_SIZE (32)
```

Size of the OutNonce response expected from several commands.

## 20.71.2.301 PAUSE\_COUNT

```
#define PAUSE_COUNT ATCA_CMD_SIZE_MIN
```

Pause command packet size.

## 20.71.2.302 PAUSE\_PARAM2\_IDX

```
#define PAUSE_PARAM2_IDX ATCA_PARAM2_IDX
```

Pause command index for 2. parameter.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 760

## 20.71.2.303 PAUSE\_RSP\_SIZE

```
#define PAUSE_RSP_SIZE ATCA_RSP_SIZE_MIN
```

Pause command response packet size.

### 20.71.2.304 PAUSE\_SELECT\_IDX

```
#define PAUSE_SELECT_IDX ATCA_PARAM1_IDX
```

Pause command index for Selector.

## 20.71.2.305 PRIVWRITE\_COUNT

```
#define PRIVWRITE_COUNT (75)
```

PrivWrite command packet size.

# 20.71.2.306 PRIVWRITE\_KEYID\_IDX

```
#define PRIVWRITE_KEYID_IDX ATCA_PARAM2_IDX
```

PrivWrite command index for KeyID.

# 20.71.2.307 PRIVWRITE\_MAC\_IDX

```
#define PRIVWRITE_MAC_IDX (41)
```

PrivWrite command index for MAC.

# 20.71.2.308 PRIVWRITE\_MODE\_ENCRYPT

```
\#define PRIVWRITE_MODE_ENCRYPT ((uint8_t)0x40)
```

PrivWrite mode: encrypted.

## 20.71.2.309 PRIVWRITE\_RSP\_SIZE

#define PRIVWRITE\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

PrivWrite command response packet size.

### 20.71.2.310 PRIVWRITE\_VALUE\_IDX

```
#define PRIVWRITE_VALUE_IDX ( 5)
```

PrivWrite command index for value.

## 20.71.2.311 PRIVWRITE\_ZONE\_IDX

```
#define PRIVWRITE_ZONE_IDX ATCA_PARAM1_IDX
```

PrivWrite command index for zone.

# 20.71.2.312 PRIVWRITE\_ZONE\_MASK

```
\#define PRIVWRITE_ZONE_MASK ((uint8_t)0x40)
```

PrivWrite zone bits 0 to 5 and 7 are 0.

## 20.71.2.313 RANDOM\_COUNT

```
#define RANDOM_COUNT ATCA_CMD_SIZE_MIN
```

Random command packet size.

# 20.71.2.314 **RANDOM\_MODE\_IDX**

```
#define RANDOM_MODE_IDX ATCA_PARAM1_IDX
```

Random command index for mode.

## 20.71.2.315 RANDOM\_NO\_SEED\_UPDATE

```
#define RANDOM_NO_SEED_UPDATE ((uint8_t)0x01)
```

Random mode for no seed update.

#### 20.71.2.316 RANDOM\_NUM\_SIZE

```
#define RANDOM_NUM_SIZE ((uint8_t)32)
```

Number of bytes in the data packet of a random command.

### 

```
#define RANDOM_PARAM2_IDX ATCA_PARAM2_IDX
```

Random command index for 2. parameter.

## 20.71.2.318 RANDOM\_RSP\_SIZE

```
#define RANDOM_RSP_SIZE ATCA_RSP_SIZE_32
```

Random command response packet size.

## 20.71.2.319 RANDOM\_SEED\_UPDATE

```
#define RANDOM_SEED_UPDATE ((uint8_t)0x00)
```

Random mode for automatic seed update.

# 20.71.2.320 READ\_32\_RSP\_SIZE

```
#define READ_32_RSP_SIZE ATCA_RSP_SIZE_32
```

Read command response packet size when reading 32 bytes.

## 20.71.2.321 READ\_4\_RSP\_SIZE

```
#define READ_4_RSP_SIZE ATCA_RSP_SIZE_VAL
```

Read command response packet size when reading 4 bytes.

### 20.71.2.322 READ\_ADDR\_IDX

```
#define READ_ADDR_IDX ATCA_PARAM2_IDX
```

Read command index for address.

## 20.71.2.323 READ\_COUNT

```
#define READ_COUNT ATCA_CMD_SIZE_MIN
```

Read command packet size.

# 20.71.2.324 READ\_ZONE\_IDX

```
#define READ_ZONE_IDX ATCA_PARAM1_IDX
```

Read command index for zone.

## 20.71.2.325 READ\_ZONE\_MASK

```
#define READ_ZONE_MASK ((uint8_t)0x83)
```

Read zone bits 2 to 6 are 0.

# 20.71.2.326 RSA2048\_KEY\_SIZE

#define RSA2048\_KEY\_SIZE (256)

size of a RSA private key

### 20.71.2.327 SECUREBOOT\_COUNT\_DIG

```
#define SECUREBOOT_COUNT_DIG (ATCA_CMD_SIZE_MIN + SECUREBOOT_DIGEST_SIZE)
```

SecureBoot command packet size for just a digest.

#### 20.71.2.328 SECUREBOOT\_COUNT\_DIG\_SIG

```
#define SECUREBOOT_COUNT_DIG_SIG (ATCA_CMD_SIZE_MIN + SECUREBOOT_DIGEST_SIZE + SECUREBOOT_SIGNATURE_SIZE)
```

SecureBoot command packet size for a digest and signature.

### 20.71.2.329 SECUREBOOT\_DIGEST\_SIZE

```
#define SECUREBOOT_DIGEST_SIZE (32)
```

SecureBoot digest input size.

## 20.71.2.330 SECUREBOOT\_MAC\_SIZE

```
#define SECUREBOOT_MAC_SIZE (32)
```

SecureBoot MAC output size.

# 20.71.2.331 SECUREBOOT\_MODE\_ENC\_MAC\_FLAG

```
#define SECUREBOOT_MODE_ENC_MAC_FLAG ((uint8_t)0x80)
```

SecureBoot mode flag for encrypted digest and returning validating MAC.

# 20.71.2.332 SECUREBOOT\_MODE\_FULL

```
#define SECUREBOOT_MODE_FULL ((uint8_t)0x05)
```

SecureBoot mode Full.

## 20.71.2.333 SECUREBOOT\_MODE\_FULL\_COPY

#define SECUREBOOT\_MODE\_FULL\_COPY ((uint8\_t)0x07)

SecureBoot mode FullCopy.

#### 20.71.2.334 SECUREBOOT\_MODE\_FULL\_STORE

 $\#define SECUREBOOT\_MODE\_FULL\_STORE ((uint8_t)0x06)$ 

SecureBoot mode FullStore.

### 20.71.2.335 SECUREBOOT\_MODE\_IDX

#define SECUREBOOT\_MODE\_IDX ATCA\_PARAM1\_IDX

SecureBoot command index for mode.

## 20.71.2.336 SECUREBOOT\_MODE\_MASK

#define SECUREBOOT\_MODE\_MASK ((uint8\_t)0x07)

SecureBoot mode mask.

# 20.71.2.337 SECUREBOOT\_MODE\_PROHIBIT\_FLAG

#define SECUREBOOT\_MODE\_PROHIBIT\_FLAG ((uint8\_t)0x40)

SecureBoot mode flag to prohibit SecureBoot until next power cycle.

# 20.71.2.338 SECUREBOOT\_RSP\_SIZE\_MAC

#define SECUREBOOT\_RSP\_SIZE\_MAC (ATCA\_PACKET\_OVERHEAD + SECUREBOOT\_MAC\_SIZE)

SecureBoot response packet size with MAC.

### 20.71.2.339 SECUREBOOT\_RSP\_SIZE\_NO\_MAC

#define SECUREBOOT\_RSP\_SIZE\_NO\_MAC ATCA\_RSP\_SIZE\_MIN

SecureBoot response packet size for no MAC.

#### 20.71.2.340 SECUREBOOT\_SIGNATURE\_SIZE

#define SECUREBOOT\_SIGNATURE\_SIZE (64)

SecureBoot signature input size.

### 20.71.2.341 SECUREBOOTCONFIG\_MODE\_DISABLED

#define SECUREBOOTCONFIG\_MODE\_DISABLED ((uint16\_t)0x0000)

Disabled SecureBootMode in SecureBootConfig value.

## 20.71.2.342 SECUREBOOTCONFIG\_MODE\_FULL\_BOTH

 ${\tt \#define \ SECUREBOOTCONFIG\_MODE\_FULL\_BOTH \ ((uint16\_t)\,0x0001)}$ 

Both digest and signature always required SecureBootMode in SecureBootConfig value.

## 20.71.2.343 SECUREBOOTCONFIG MODE FULL DIG

 $\verb|#define SECUREBOOTCONFIG_MODE_FULL_DIG ((uint16\_t)0x0003)|$ 

Digest stored SecureBootMode in SecureBootConfig value.

# 20.71.2.344 SECUREBOOTCONFIG\_MODE\_FULL\_SIG

 $\texttt{\#define SECUREBOOTCONFIG\_MODE\_FULL\_SIG ((uint16\_t)0x0002)}$ 

Signature stored SecureBootMode in SecureBootConfig value.

### 20.71.2.345 SECUREBOOTCONFIG\_MODE\_MASK

#define SECUREBOOTCONFIG\_MODE\_MASK ((uint16\_t)0x0003)

Mask for SecureBootMode field in SecureBootConfig value.

#### 20.71.2.346 SECUREBOOTCONFIG\_OFFSET

```
#define SECUREBOOTCONFIG_OFFSET (70)
```

SecureBootConfig byte offset into the configuration zone.

## 20.71.2.347 SELFTEST\_COUNT

```
#define SELFTEST_COUNT ATCA_CMD_SIZE_MIN
```

SelfTest command packet size.

## 20.71.2.348 SELFTEST\_MODE\_AES

```
#define SELFTEST_MODE_AES ((uint8_t)0x10)
```

SelfTest mode AES encrypt function.

# 20.71.2.349 SELFTEST\_MODE\_ALL

```
#define SELFTEST_MODE_ALL ((uint8_t)0x3B)
```

SelfTest mode all algorithms.

# 20.71.2.350 SELFTEST\_MODE\_ECDH

```
#define SELFTEST_MODE_ECDH ((uint8_t)0x08)
```

SelfTest mode ECDH function.

## 20.71.2.351 SELFTEST\_MODE\_ECDSA\_SIGN\_VERIFY

#define SELFTEST\_MODE\_ECDSA\_SIGN\_VERIFY ((uint8\_t)0x02)

SelfTest mode ECDSA verify function.

#### 20.71.2.352 SELFTEST\_MODE\_IDX

```
#define SELFTEST_MODE_IDX ATCA_PARAM1_IDX
```

SelfTest command index for mode.

### 20.71.2.353 SELFTEST\_MODE\_RNG

```
#define SELFTEST_MODE_RNG ((uint8_t)0x01)
```

SelfTest mode RNG DRBG function.

## 20.71.2.354 SELFTEST\_MODE\_SHA

```
#define SELFTEST_MODE_SHA ((uint8_t)0x20)
```

SelfTest mode SHA function.

# 20.71.2.355 SELFTEST\_RSP\_SIZE

```
#define SELFTEST_RSP_SIZE ATCA_RSP_SIZE_MIN
```

SelfTest command response packet size.

# 20.71.2.356 SHA\_COUNT\_LONG

```
#define SHA_COUNT_LONG ATCA_CMD_SIZE_MIN
```

Just a starting size.

### 20.71.2.357 SHA\_COUNT\_SHORT

#define SHA\_COUNT\_SHORT ATCA\_CMD\_SIZE\_MIN

### 20.71.2.358 SHA\_DATA\_MAX

#define SHA\_DATA\_MAX (64)

#### 20.71.2.359 SHA\_MODE\_608\_HMAC\_END

#define SHA\_MODE\_608\_HMAC\_END ((uint8\_t)0x02)

Complete the HMAC computation and return digest... Different command on 608.

#### 20.71.2.360 SHA\_MODE\_HMAC\_END

#define SHA\_MODE\_HMAC\_END ((uint8\_t)0x05)

Complete the HMAC computation and return digest.

## 20.71.2.361 SHA\_MODE\_HMAC\_START

#define SHA\_MODE\_HMAC\_START ((uint8\_t)0x04)

Initialization, HMAC calculation.

## 20.71.2.362 SHA\_MODE\_HMAC\_UPDATE

#define SHA\_MODE\_HMAC\_UPDATE ((uint8\_t)0x01)

Add 64 bytes in the meesage to the SHA context.

### 20.71.2.363 SHA\_MODE\_MASK

#define SHA\_MODE\_MASK ((uint8\_t)0x07)

Mask the bit 0-2.

#### 20.71.2.364 SHA\_MODE\_READ\_CONTEXT

```
#define SHA_MODE_READ_CONTEXT ((uint8_t)0x06)
```

Read current SHA-256 context out of the device.

## 20.71.2.365 SHA\_MODE\_SHA256\_END

```
#define SHA_MODE_SHA256_END ((uint8_t)0x02)
```

Complete the calculation and return the digest.

# 20.71.2.366 SHA\_MODE\_SHA256\_PUBLIC

```
#define SHA_MODE_SHA256_PUBLIC ((uint8_t)0x03)
```

Add 64 byte ECC public key in the slot to the SHA context.

## 20.71.2.367 SHA\_MODE\_SHA256\_START

```
#define SHA_MODE_SHA256_START ((uint8_t)0x00)
```

Initialization, does not accept a message.

# 20.71.2.368 SHA\_MODE\_SHA256\_UPDATE

```
\#define SHA_MODE_SHA256_UPDATE ((uint8_t)0x01)
```

Add 64 bytes in the meesage to the SHA context.

# 20.71.2.369 SHA\_MODE\_TARGET\_MASK

```
#define SHA_MODE_TARGET_MASK ((uint8_t)0xC0)
```

Resulting digest target location mask.

# 20.71.2.370 SHA\_MODE\_WRITE\_CONTEXT

```
#define SHA_MODE_WRITE_CONTEXT ((uint8_t)0x07)
```

Restore a SHA-256 context into the device.

## 20.71.2.371 SHA\_RSP\_SIZE

```
#define SHA_RSP_SIZE ATCA_RSP_SIZE_32
```

SHA command response packet size.

## 20.71.2.372 SHA\_RSP\_SIZE\_LONG

```
#define SHA_RSP_SIZE_LONG ATCA_RSP_SIZE_32
```

SHA command response packet size.

## 20.71.2.373 SHA\_RSP\_SIZE\_SHORT

```
#define SHA_RSP_SIZE_SHORT ATCA_RSP_SIZE_MIN
```

SHA command response packet size only status code.

## 20.71.2.374 SIGN\_COUNT

#define SIGN\_COUNT ATCA\_CMD\_SIZE\_MIN

Sign command packet size.

## 20.71.2.375 SIGN\_KEYID\_IDX

#define SIGN\_KEYID\_IDX ATCA\_PARAM2\_IDX

Sign command index for key id.

### 20.71.2.376 SIGN\_MODE\_EXTERNAL

```
#define SIGN_MODE_EXTERNAL ((uint8_t)0x80)
```

Sign mode bit 7: external.

## 20.71.2.377 SIGN\_MODE\_IDX

```
#define SIGN_MODE_IDX ATCA_PARAM1_IDX
```

Sign command index for mode.

# 20.71.2.378 SIGN\_MODE\_INCLUDE\_SN

```
\#define SIGN_MODE_INCLUDE_SN ((uint8_t)0x40)
```

Sign mode bit 6: include serial number.

## 20.71.2.379 SIGN\_MODE\_INTERNAL

```
#define SIGN_MODE_INTERNAL ((uint8_t)0x00)
```

Sign mode 0: internal.

# 20.71.2.380 SIGN\_MODE\_INVALIDATE

```
#define SIGN_MODE_INVALIDATE ((uint8_t)0x01)
```

Sign mode bit 1: Signature will be used for Verify(Invalidate)

### 20.71.2.381 SIGN\_MODE\_MASK

#define SIGN\_MODE\_MASK ((uint8\_t)0xE1)

Sign mode bits 1 to 4 are 0.

### 20.71.2.382 SIGN\_MODE\_SOURCE\_MASK

#define SIGN\_MODE\_SOURCE\_MASK ((uint8\_t)0x20)

Sign mode message source mask.

## 20.71.2.383 SIGN\_MODE\_SOURCE\_MSGDIGBUF

#define SIGN\_MODE\_SOURCE\_MSGDIGBUF ((uint8\_t)0x20)

Sign mode message source is the Message Digest Buffer.

# 20.71.2.384 SIGN\_MODE\_SOURCE\_TEMPKEY

#define SIGN\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x00)

Sign mode message source is TempKey.

## 20.71.2.385 SIGN\_RSP\_SIZE

#define SIGN\_RSP\_SIZE ATCA\_RSP\_SIZE\_MAX

Sign command response packet size.

# 20.71.2.386 UPDATE\_COUNT

#define UPDATE\_COUNT ATCA\_CMD\_SIZE\_MIN

UpdateExtra command packet size.

### 20.71.2.387 UPDATE\_MODE\_DEC\_COUNTER

#define UPDATE\_MODE\_DEC\_COUNTER ((uint8\_t)0x02)

UpdateExtra mode: decrement counter.

#### 20.71.2.388 **UPDATE\_MODE\_IDX**

```
#define UPDATE_MODE_IDX ATCA_PARAM1_IDX
```

UpdateExtra command index for mode.

### 20.71.2.389 UPDATE\_MODE\_SELECTOR

```
#define UPDATE_MODE_SELECTOR ((uint8_t)0x01)
```

UpdateExtra mode update Selector (config byte 85)

## 20.71.2.390 UPDATE\_MODE\_USER\_EXTRA

```
#define UPDATE_MODE_USER_EXTRA ((uint8_t)0x00)
```

UpdateExtra mode update UserExtra (config byte 84)

# 20.71.2.391 UPDATE\_MODE\_USER\_EXTRA\_ADD

```
#define UPDATE_MODE_USER_EXTRA_ADD UPDATE_MODE_SELECTOR
```

UpdateExtra mode update UserExtraAdd (config byte 85)

# 20.71.2.392 UPDATE\_RSP\_SIZE

```
#define UPDATE_RSP_SIZE ATCA_RSP_SIZE_MIN
```

UpdateExtra command response packet size.

### 20.71.2.393 UPDATE\_VALUE\_IDX

```
#define UPDATE_VALUE_IDX ATCA_PARAM2_IDX
```

UpdateExtra command index for new value.

#### 20.71.2.394 VERIFY\_256\_EXTERNAL\_COUNT

```
#define VERIFY_256_EXTERNAL_COUNT (135)
```

Verify command packet size for 256-bit key in external mode.

## 20.71.2.395 VERIFY\_256\_KEY\_SIZE

```
#define VERIFY_256_KEY_SIZE ( 64)
```

Verify key size for 256-bit key.

## 20.71.2.396 VERIFY\_256\_SIGNATURE\_SIZE

```
#define VERIFY_256_SIGNATURE_SIZE ( 64)
```

Verify signature size for 256-bit key.

## 

```
#define VERIFY_256_STORED_COUNT ( 71)
```

Verify command packet size for 256-bit key in stored mode.

## 

```
#define VERIFY_256_VALIDATE_COUNT ( 90)
```

Verify command packet size for 256-bit key in validate mode.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 776

## 20.71.2.399 VERIFY\_283\_EXTERNAL\_COUNT

```
#define VERIFY_283_EXTERNAL_COUNT (151)
```

Verify command packet size for 283-bit key in external mode.

#### 20.71.2.400 VERIFY\_283\_KEY\_SIZE

```
#define VERIFY_283_KEY_SIZE ( 72)
```

Verify key size for 283-bit key.

## 20.71.2.401 VERIFY\_283\_SIGNATURE\_SIZE

```
#define VERIFY_283_SIGNATURE_SIZE ( 72)
```

Verify signature size for 283-bit key.

# 20.71.2.402 VERIFY\_283\_STORED\_COUNT

```
#define VERIFY_283_STORED_COUNT ( 79)
```

Verify command packet size for 283-bit key in stored mode.

# 20.71.2.403 VERIFY\_283\_VALIDATE\_COUNT

```
#define VERIFY_283_VALIDATE_COUNT ( 98)
```

Verify command packet size for 283-bit key in validate mode.

## 20.71.2.404 VERIFY\_DATA\_IDX

```
#define VERIFY_DATA_IDX ( 5)
```

Verify command index for data.

# 20.71.2.405 VERIFY\_KEY\_B283

#define VERIFY\_KEY\_B283 ((uint16\_t)0x0000)

Verify key type: B283.

## 20.71.2.406 VERIFY\_KEY\_K283

#define VERIFY\_KEY\_K283 ((uint16\_t)0x0001)

Verify key type: K283.

## 20.71.2.407 VERIFY\_KEY\_P256

#define VERIFY\_KEY\_P256 ((uint16\_t)0x0004)

Verify key type: P256.

# 20.71.2.408 VERIFY\_KEYID\_IDX

#define VERIFY\_KEYID\_IDX ATCA\_PARAM2\_IDX

Verify command index for key id.

## 20.71.2.409 VERIFY\_MODE\_EXTERNAL

#define VERIFY\_MODE\_EXTERNAL ((uint8\_t)0x02)

Verify mode: external.

# 20.71.2.410 VERIFY\_MODE\_IDX

#define VERIFY\_MODE\_IDX ATCA\_PARAM1\_IDX

Verify command index for mode.

## 20.71.2.411 VERIFY\_MODE\_INVALIDATE

#define VERIFY\_MODE\_INVALIDATE ((uint8\_t)0x07)

Verify mode: invalidate.

# 20.71.2.412 VERIFY\_MODE\_MAC\_FLAG

#define VERIFY\_MODE\_MAC\_FLAG ((uint8\_t)0x80)

Verify mode: MAC.

## 20.71.2.413 VERIFY\_MODE\_MASK

#define VERIFY\_MODE\_MASK ((uint8\_t)0x07)

Verify mode bits 3 to 7 are 0.

## 20.71.2.414 VERIFY\_MODE\_SOURCE\_MASK

#define VERIFY\_MODE\_SOURCE\_MASK ((uint8\_t)0x20)

Verify mode message source mask.

# 20.71.2.415 VERIFY\_MODE\_SOURCE\_MSGDIGBUF

#define VERIFY\_MODE\_SOURCE\_MSGDIGBUF ((uint8\_t)0x20)

Verify mode message source is the Message Digest Buffer.

## 20.71.2.416 VERIFY\_MODE\_SOURCE\_TEMPKEY

#define VERIFY\_MODE\_SOURCE\_TEMPKEY ((uint8\_t)0x00)

Verify mode message source is TempKey.

## 20.71.2.417 VERIFY\_MODE\_STORED

#define VERIFY\_MODE\_STORED ((uint8\_t)0x00)

Verify mode: stored.

### 20.71.2.418 VERIFY\_MODE\_VALIDATE

#define VERIFY\_MODE\_VALIDATE ((uint8\_t)0x03)

Verify mode: validate.

## 20.71.2.419 VERIFY\_MODE\_VALIDATE\_EXTERNAL

#define VERIFY\_MODE\_VALIDATE\_EXTERNAL ((uint8\_t) 0x01)

Verify mode: validate external.

# 20.71.2.420 VERIFY\_OTHER\_DATA\_SIZE

#define VERIFY\_OTHER\_DATA\_SIZE ( 19)

Verify size of "other data".

# 20.71.2.421 VERIFY\_RSP\_SIZE

#define VERIFY\_RSP\_SIZE ATCA\_RSP\_SIZE\_MIN

Verify command response packet size.

# 20.71.2.422 VERIFY\_RSP\_SIZE\_MAC

#define VERIFY\_RSP\_SIZE\_MAC ATCA\_RSP\_SIZE\_32

Verify command response packet size with validating MAC.

# 20.71.2.423 WRITE\_ADDR\_IDX

```
#define WRITE_ADDR_IDX ATCA_PARAM2_IDX
```

Write command index for address.

### 20.71.2.424 WRITE\_MAC\_SIZE

```
#define WRITE_MAC_SIZE (32)
```

Write MAC size.

## 20.71.2.425 WRITE\_MAC\_VL\_IDX

```
#define WRITE_MAC_VL_IDX (37)
```

Write command index for MAC following long data.

# 20.71.2.426 WRITE\_MAC\_VS\_IDX

```
#define WRITE_MAC_VS_IDX ( 9)
```

Write command index for MAC following short data.

## 20.71.2.427 WRITE\_RSP\_SIZE

```
#define WRITE_RSP_SIZE ATCA_RSP_SIZE_MIN
```

Write command response packet size.

# 20.71.2.428 WRITE\_VALUE\_IDX

```
#define WRITE_VALUE_IDX ATCA_DATA_IDX
```

Write command index for data.

## 20.71.2.429 WRITE\_ZONE\_DATA

```
#define WRITE_ZONE_DATA ((uint8_t)2)
```

Write zone id data.

## 20.71.2.430 WRITE\_ZONE\_IDX

```
#define WRITE_ZONE_IDX ATCA_PARAM1_IDX
```

Write command index for zone.

## 20.71.2.431 WRITE\_ZONE\_MASK

```
#define WRITE_ZONE_MASK ((uint8_t)0xC3)
```

Write zone bits 2 to 5 are 0.

### 20.71.2.432 WRITE\_ZONE\_OTP

```
#define WRITE_ZONE_OTP ((uint8_t)1)
```

Write zone id OTP.

## 20.71.2.433 WRITE\_ZONE\_WITH\_MAC

```
#define WRITE_ZONE_WITH_MAC ((uint8_t)0x40)
```

Write zone bit 6: write encrypted with MAC.

# 20.71.3 Function Documentation

#### 20.71.3.1 atAES()

```
ATCA_STATUS atAES (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand AES method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### **Returns**

ATCA\_SUCCESS

### 20.71.3.2 atCalcCrc()

This function calculates CRC and adds it to the correct offset in the packet data.

#### **Parameters**

|  | in | packet | Packet to calculate CRC data for |
|--|----|--------|----------------------------------|
|--|----|--------|----------------------------------|

# 20.71.3.3 atCheckCrc()

```
ATCA_STATUS atCheckCrc ( const uint8_t * response )
```

This function checks the consistency of a response.

#### **Parameters**

| in | response | pointer to response |
|----|----------|---------------------|
|----|----------|---------------------|

#### Returns

ATCA\_SUCCESS on success, otherwise ATCA\_RX\_CRC\_ERROR

# 20.71.3.4 atCheckMAC()

```
ATCA_STATUS atCheckMAC (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand CheckMAC method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.71.3.5 atCounter()

```
ATCA_STATUS atCounter (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand Counter method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.71.3.6 atCRC()

Calculates CRC over the given raw data and returns the CRC in little-endian byte order.

## **Parameters**

| in  | length | Size of data not including the CRC byte positions                                             |
|-----|--------|-----------------------------------------------------------------------------------------------|
| in  | data   | Pointer to the data over which to compute the CRC                                             |
| out | crc←   | Pointer to the place where the two-bytes of CRC will be returned in little-endian byte order. |
|     | _le    |                                                                                               |

## 20.71.3.7 atDeriveKey()

```
ATCA_STATUS atDeriveKey (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool has_mac )
```

ATCACommand DeriveKey method.

#### **Parameters**

| in | ca_cmd  | instance                                                     |
|----|---------|--------------------------------------------------------------|
| in | packet  | pointer to the packet containing the command being built     |
| in | has_mac | hasMAC determines if MAC data is present in the packet input |

#### Returns

ATCA\_SUCCESS

# 20.71.3.8 atECDH()

```
ATCA_STATUS atECDH (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand ECDH method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

## 20.71.3.9 atGenDig()

```
ATCA_STATUS atGenDig (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool is_no_mac_key )
```

ATCACommand Generate Digest method.

### **Parameters**

|   | in | ca_cmd        | instance                                                                              |
|---|----|---------------|---------------------------------------------------------------------------------------|
| - | in | packet        | pointer to the packet containing the command being built                              |
| - | in | is_no_mac_key | Should be true if GenDig is being run on a slot that has its SlotConfig.NoMac bit set |

#### Returns

ATCA\_SUCCESS

## 20.71.3.10 atGenKey()

```
ATCA_STATUS atGenKey (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

## ATCACommand Generate Key method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.71.3.11 atHMAC()

```
ATCA_STATUS atHMAC (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

## ATCACommand HMAC method.

# **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

## 20.71.3.12 atInfo()

```
ATCA_STATUS atInfo (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand Info method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

## 20.71.3.13 atlsECCFamily()

determines if a given device type is an ECC device or a superset of a ECC device

#### **Parameters**

|  | in | device_type | Type of device to check for family type |
|--|----|-------------|-----------------------------------------|
|--|----|-------------|-----------------------------------------|

### Returns

boolean indicating whether the given device is an ECC family device.

# 20.71.3.14 atIsSHAFamily()

```
bool atIsSHAFamily ( {\tt ATCADeviceType} \  \, device\_type \  \, )
```

determines if a given device type is a SHA device or a superset of a SHA device

### **Parameters**

| in | device_type | Type of device to check for family type |
|----|-------------|-----------------------------------------|
|----|-------------|-----------------------------------------|

#### Returns

boolean indicating whether the given device is a SHA family device.

# 20.71.3.15 atKDF()

```
ATCA_STATUS atKDF (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand KDF method.

### **Parameters**

| in | ca_cmd | Instance                                                  |
|----|--------|-----------------------------------------------------------|
| in | packet | Pointer to the packet containing the command being built. |

#### **Returns**

ATCA\_SUCCESS

## 20.71.3.16 atLock()

```
ATCA_STATUS atLock (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand Lock method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

# 20.71.3.17 atMAC()

```
ATCA_STATUS atMAC (
ATCACommand ca_cmd,
ATCAPacket * packet )
```

ATCACommand MAC method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

## 20.71.3.18 atNonce()

```
ATCA_STATUS atNonce (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand Nonce method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.71.3.19 atPause()

```
ATCA_STATUS atPause (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand Pause method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

## 20.71.3.20 atPrivWrite()

```
ATCA_STATUS atPrivWrite (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

## ATCACommand PrivWrite method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

## 20.71.3.21 atRandom()

```
ATCA_STATUS atRandom (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand Random method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

## 20.71.3.22 atRead()

```
ATCA_STATUS atRead (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

### ATCACommand Read method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

## 20.71.3.23 atSecureBoot()

```
ATCA_STATUS atSecureBoot (  \begin{tabular}{lll} ATCACommand & ca\_cmd, \\ ATCAPacket & *packet \end{tabular} \label{eq:atcapacket} \end{tabular}
```

#### ATCACommand SecureBoot method.

#### **Parameters**

| in | ca_cmd | instance                                                 |   |
|----|--------|----------------------------------------------------------|---|
| in | packet | pointer to the packet containing the command being built | Ì |

### Returns

ATCA\_SUCCESS

## 20.71.3.24 atSelfTest()

```
ATCA_STATUS atSelfTest (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

#### ATCACommand AES method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

### Returns

ATCA\_SUCCESS

## 20.71.3.25 atSHA()

```
ATCA_STATUS atSHA (

ATCACommand ca_cmd,
```

```
ATCAPacket * packet,
uint16_t write_context_size )
```

ATCACommand SHA method.

### **Parameters**

| in | ca_cmd             | instance                                                 |
|----|--------------------|----------------------------------------------------------|
| in | packet             | pointer to the packet containing the command being built |
| in | write_context_size | the length of the sha write_context data                 |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.71.3.26 atSign()

```
ATCA_STATUS atSign (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

## ATCACommand Sign method.

#### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

#### Returns

ATCA\_SUCCESS

# 20.71.3.27 atUpdateExtra()

### ATCACommand UpdateExtra method.

### **Parameters**

| in | ca_cmd | instance                                                 |
|----|--------|----------------------------------------------------------|
| in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS

# 20.71.3.28 atVerify()

```
ATCA_STATUS atVerify (

ATCACommand ca_cmd,

ATCAPacket * packet )
```

ATCACommand ECDSA Verify method.

## **Parameters**

|   | in | ca_cmd | instance                                                 |
|---|----|--------|----------------------------------------------------------|
| ĺ | in | packet | pointer to the packet containing the command being built |

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

## 20.71.3.29 atWrite()

```
ATCA_STATUS atWrite (

ATCACommand ca_cmd,

ATCAPacket * packet,

bool has_mac )
```

ATCACommand Write method.

## **Parameters**

| i | n | ca_cmd  | instance                                                 |
|---|---|---------|----------------------------------------------------------|
| i | n | packet  | pointer to the packet containing the command being built |
| i | n | has_mac | Flag to indicate whether a mac is present or not         |

## Returns

ATCA\_SUCCESS

## 20.71.3.30 isATCAError()

```
ATCA_STATUS isATCAError ( uint8_t * data )
```

checks for basic error frame in data

#### **Parameters**

| in data pointer to received data - expected to be in the form of a CA device response |
|---------------------------------------------------------------------------------------|
|---------------------------------------------------------------------------------------|

#### Returns

ATCA SUCCESS on success, otherwise an error code.

# 20.72 calib\_counter.c File Reference

CryptoAuthLib Basic API methods for Counter command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

ATCA\_STATUS calib\_counter (ATCADevice device, uint8\_t mode, uint16\_t counter\_id, uint32\_t \*counter 
 value)

Compute the Counter functions.

ATCA\_STATUS calib\_counter\_increment (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_
 value)

Increments one of the device's monotonic counters.

ATCA\_STATUS calib\_counter\_read (ATCADevice device, uint16\_t counter\_id, uint32\_t \*counter\_value)
 Read one of the device's monotonic counters.

# 20.72.1 Detailed Description

CryptoAuthLib Basic API methods for Counter command.

The Counter command reads or increments the binary count value for one of the two monotonic counters

Note

List of devices that support this command - ATECC508A and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.73 calib\_derivekey.c File Reference

CryptoAuthLib Basic API methods for DeriveKey command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

• ATCA\_STATUS calib\_derivekey (ATCADevice device, uint8\_t mode, uint16\_t target\_key, const uint8\_t \*mac)

Executes the DeviveKey command for deriving a new key from a nonce (TempKey) and an existing key.

# 20.73.1 Detailed Description

CryptoAuthLib Basic API methods for DeriveKey command.

The DeriveKey command combines the current value of a key with the nonce stored in TempKey using SHA-256 and derives a new key.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.74 calib\_ecdh.c File Reference

CryptoAuthLib Basic API methods for ECDH command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

## **Functions**

• ATCA\_STATUS calib\_ecdh\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_← t \*public\_key, uint8\_t \*pms, uint8\_t \*out\_nonce)

Base function for generating premaster secret key using ECDH.

- ATCA\_STATUS calib\_ecdh (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms)

  ECDH command with a private key in a slot and the premaster secret is returned in the clear.
- ATCA\_STATUS calib\_ecdh\_enc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_←
  t \*pms, const uint8\_t \*read\_key, uint16\_t read\_key\_id, const uint8\_t num\_in[NONCE\_NUMIN\_SIZE])

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

ATCA\_STATUS calib\_ecdh\_ioenc (ATCADevice device, uint16\_t key\_id, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in a slot and the premaster secret is returned encrypted using the IO protection key.

- ATCA\_STATUS calib\_ecdh\_tempkey (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms)
  - ECDH command with a private key in TempKey and the premaster secret is returned in the clear.
- ATCA\_STATUS calib\_ecdh\_tempkey\_ioenc (ATCADevice device, const uint8\_t \*public\_key, uint8\_t \*pms, const uint8\_t \*io\_key)

ECDH command with a private key in TempKey and the premaster secret is returned encrypted using the IO protection key

# 20.74.1 Detailed Description

CryptoAuthLib Basic API methods for ECDH command.

The ECDH command implements the Elliptic Curve Diffie-Hellman algorithm to combine an internal private key with an external public key to calculate a shared secret.

#### Note

List of devices that support this command - ATECC508A, ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.74.2 Function Documentation

## 20.74.2.1 calib\_ecdh\_enc()

ECDH command with a private key in a slot and the premaster secret is read from the next slot.

This function only works for even numbered slots with the proper configuration.

#### **Parameters**

| in  | device           | Device context pointer                                                                              |
|-----|------------------|-----------------------------------------------------------------------------------------------------|
| in  | key_id           | Slot of key for ECDH computation                                                                    |
| in  | public_key       | Public key input to ECDH calculation. X and Y integers in big-endian format. 64 bytes for P256 key. |
| out | pms              | Computed ECDH premaster secret is returned here (32 bytes).                                         |
| in  | read_key         | Read key for the premaster secret slot (key_id 1).                                                  |
| in  | read_key⊷<br>_id | Read key slot for read_key.                                                                         |
| in  | num_in           | 20 byte host nonce to inject into Nonce calculation                                                 |

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 797

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.75 calib\_execution.c File Reference

Implements an execution handler that executes a given command on a device and returns the results.

```
#include "atca_config.h"
#include <stdlib.h>
#include <string.h>
#include "atca_command.h"
#include "atca_device.h"
#include "calib_execution.h"
#include "atca_devtypes.h"
#include "hal/atca_hal.h"
```

## **Functions**

• ATCA STATUS calib execute command (ATCAPacket \*packet, ATCADevice device)

Wakes up device, sends the packet, waits for command completion, receives response, and puts the device into the idle state.

# 20.75.1 Detailed Description

Implements an execution handler that executes a given command on a device and returns the results.

This implementation wraps Polling and No polling (simple wait) schemes into a single method and use it across the library. Polling is used by default, however, by defining the ATCA\_NO\_POLL symbol the code will instead wait an estimated max execution time before requesting the result.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.75.2 Function Documentation

## 20.75.2.1 calib\_execute\_command()

Wakes up device, sends the packet, waits for command completion, receives response, and puts the device into the idle state.

#### **Parameters**

| in,out | packet | As input, the packet to be sent. As output, the data buffer in the packet structure will |
|--------|--------|------------------------------------------------------------------------------------------|
|        |        | contain the response.                                                                    |
| in     | device | CryptoAuthentication device to send the command to.                                      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.76 calib execution.h File Reference

Defines an execution handler that executes a given command on a device and returns the results.

```
#include "atca_status.h"
#include "calib_command.h"
#include "atca_device.h"
#include "atca_config.h"
```

# **Macros**

#define ATCA\_UNSUPPORTED\_CMD ((uint16\_t)0xFFFF)

#### **Functions**

• ATCA\_STATUS calib\_execute\_command (ATCAPacket \*packet, ATCADevice device)

Wakes up device, sends the packet, waits for command completion, receives response, and puts the device into the idle state.

# 20.76.1 Detailed Description

Defines an execution handler that executes a given command on a device and returns the results.

The basic flow is to wake the device, send the command, wait/poll for completion, and finally receives the response from the device and does basic checks before returning to caller.

This handler supports the ATSHA and ATECC device family.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.76.2 Macro Definition Documentation

#### 20.76.2.1 ATCA\_UNSUPPORTED\_CMD

```
#define ATCA_UNSUPPORTED_CMD ((uint16_t)0xFFFF)
```

## 20.76.3 Function Documentation

## 20.76.3.1 calib\_execute\_command()

Wakes up device, sends the packet, waits for command completion, receives response, and puts the device into the idle state.

#### **Parameters**

| in,out | packet | As input, the packet to be sent. As output, the data buffer in the packet structure will |
|--------|--------|------------------------------------------------------------------------------------------|
|        |        | contain the response.                                                                    |
| in     | device | CryptoAuthentication device to send the command to.                                      |

### Returns

ATCA SUCCESS on success, otherwise an error code.

# 20.77 calib\_gendig.c File Reference

CryptoAuthLib Basic API methods for GenDig command.

```
#include "cryptoauthlib.h"
```

## **Functions**

• ATCA\_STATUS calib\_gendig (ATCADevice device, uint8\_t zone, uint16\_t key\_id, const uint8\_t \*other\_data, uint8\_t other\_data\_size)

Issues a GenDig command, which performs a SHA256 hash on the source data indicated by zone with the contents of TempKey. See the CryptoAuth datasheet for your chip to see what the values of zone correspond to.

# 20.77.1 Detailed Description

CryptoAuthLib Basic API methods for GenDig command.

The GenDig command uses SHA-256 to combine a stored value with the contents of TempKey, which must have been valid prior to the execution of this command.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.78 calib genkey.c File Reference

CryptoAuthLib Basic API methods for GenKey command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

ATCA\_STATUS calib\_genkey\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_
 t \*other\_data, uint8\_t \*public\_key)

Issues GenKey command, which can generate a private key, compute a public key, nd/or compute a digest of a public key.

ATCA\_STATUS calib\_genkey (ATCADevice device, uint16\_t key\_id, uint8\_t \*public\_key)

Issues GenKey command, which generates a new random private key in slot and returns the public key.

ATCA\_STATUS calib\_get\_pubkey (ATCADevice device, uint16\_t key\_id, uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from an existing private key in a slot.

### 20.78.1 Detailed Description

CryptoAuthLib Basic API methods for GenKey command.

The GenKey command is used for creating ECC private keys, generating ECC public keys, and for digest calculations involving public keys.

Note

List of devices that support this command - ATECC108A, ATECC508A, ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.79 calib hmac.c File Reference

CryptoAuthLib Basic API methods for HMAC command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

ATCA\_STATUS calib\_hmac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, uint8\_t \*digest)
 Issues a HMAC command, which computes an HMAC/SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

# 20.79.1 Detailed Description

CryptoAuthLib Basic API methods for HMAC command.

The HMAC command computes an HMAC/SHA-256 digest using a key stored in the device over a challenge stored in the TempKey register, and/or other information stored within the device.

Note

List of devices that support this command - ATSHA204A, ATECC108A, and ATECC508A. There are differences in the modes that they support. Refer to device datasheets for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.80 calib info.c File Reference

CryptoAuthLib Basic API methods for Info command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

- ATCA\_STATUS calib\_info\_base (ATCADevice device, uint8\_t mode, uint16\_t param2, uint8\_t \*out\_data)
   Issues an Info command, which return internal device information and can control GPIO and the persistent latch.
- ATCA\_STATUS calib\_info (ATCADevice device, uint8\_t \*revision)

Use the Info command to get the device revision (DevRev).

ATCA\_STATUS calib\_info\_get\_latch (ATCADevice device, bool \*state)

Use the Info command to get the persistent latch current state for an ATECC608 device.

ATCA\_STATUS calib\_info\_set\_latch (ATCADevice device, bool state)

Use the Info command to set the persistent latch state for an ATECC608 device.

## 20.80.1 Detailed Description

CryptoAuthLib Basic API methods for Info command.

Info command returns a variety of static and dynamic information about the device and its state. Also is used to control the GPIO pin and the persistent latch.

Note

The ATSHA204A refers to this command as DevRev instead of Info, however, the OpCode and operation is the same.

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A & ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.81 calib kdf.c File Reference

CryptoAuthLib Basic API methods for KDF command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

 ATCA\_STATUS calib\_kdf (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint32\_t details, const uint8\_t \*message, uint8\_t \*out\_data, uint8\_t \*out\_nonce)

Executes the KDF command, which derives a new key in PRF, AES, or HKDF modes.

## 20.81.1 Detailed Description

CryptoAuthLib Basic API methods for KDF command.

The KDF command implements one of a number of Key Derivation Functions (KDF). Generally this function combines a source key with an input string and creates a result key/digest/array. Three algorithms are currently supported: PRF, HKDF and AES.

Note

List of devices that support this command - ATECC608A/B. Refer to device datasheet for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.82 calib\_lock.c File Reference

CryptoAuthLib Basic API methods for Lock command.

```
#include "cryptoauthlib.h"
```

### **Functions**

• ATCA STATUS calib lock (ATCADevice device, uint8 t mode, uint16 t summary crc)

The Lock command prevents future modifications of the Configuration and/or Data and OTP zones. If the device is so configured, then this command can be used to lock individual data slots. This command fails if the designated area is already locked.

ATCA\_STATUS calib\_lock\_config\_zone (ATCADevice device)

Unconditionally (no CRC required) lock the config zone.

· ATCA STATUS calib lock config zone crc (ATCADevice device, uint16 t summary crc)

Lock the config zone with summary CRC.

• ATCA\_STATUS calib\_lock\_data\_zone (ATCADevice device)

Unconditionally (no CRC required) lock the data zone (slots and OTP).

• ATCA\_STATUS calib\_lock\_data\_zone\_crc (ATCADevice device, uint16\_t summary\_crc)

Lock the data zone (slots and OTP) with summary CRC.

• ATCA STATUS calib lock data slot (ATCADevice device, uint16 t slot)

Lock an individual slot in the data zone on an ATECC device. Not available for ATSHA devices. Slot must be configured to be slot lockable (KeyConfig.Lockable=1).

# 20.82.1 Detailed Description

CryptoAuthLib Basic API methods for Lock command.

The Lock command prevents future modifications of the Configuration zone, enables configured policies for Data and OTP zones, and can render individual slots read-only regardless of configuration.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.83 calib\_mac.c File Reference

CryptoAuthLib Basic API methods for MAC command.

```
#include "cryptoauthlib.h"
```

# **Functions**

 ATCA\_STATUS calib\_mac (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*challenge, uint8\_t \*digest)

Executes MAC command, which computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device.

## 20.83.1 Detailed Description

CryptoAuthLib Basic API methods for MAC command.

The MAC command computes a SHA-256 digest of a key stored in the device, a challenge, and other information on the device. The output of this command is the digest of this message.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 804

# 20.84 calib nonce.c File Reference

CryptoAuthLib Basic API methods for Nonce command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

ATCA\_STATUS calib\_nonce\_base (ATCADevice device, uint8\_t mode, uint16\_t zero, const uint8\_t \*num\_in, uint8\_t \*rand\_out)

Executes Nonce command, which loads a random or fixed nonce/data into the device for use by subsequent commands.

• ATCA\_STATUS calib\_nonce (ATCADevice device, const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_nonce\_load (ATCADevice device, uint8\_t target, const uint8\_t \*num\_in, uint16\_
 t num\_in\_size)

Execute a Nonce command in pass-through mode to load one of the device's internal buffers with a fixed value.

• ATCA STATUS calib nonce rand (ATCADevice device, const uint8 t \*num in, uint8 t \*rand out)

Execute a Nonce command to generate a random nonce combining a host nonce (num\_in) and a device random number.

ATCA\_STATUS calib\_challenge (ATCADevice device, const uint8\_t \*num\_in)

Execute a Nonce command in pass-through mode to initialize TempKey to a specified value.

ATCA\_STATUS calib\_challenge\_seed\_update (ATCADevice device, const uint8\_t \*num\_in, uint8\_t \*rand
out)

Execute a Nonce command to generate a random challenge combining a host nonce (num\_in) and a device random number

## 20.84.1 Detailed Description

CryptoAuthLib Basic API methods for Nonce command.

The Nonce command generates a nonce for use by a subsequent commands of the device by combining an internally generated random number with an input value from the system.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.85 calib\_privwrite.c File Reference

CryptoAuthLib Basic API methods for PrivWrite command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

## **Functions**

ATCA\_STATUS calib\_priv\_write (ATCADevice device, uint16\_t key\_id, const uint8\_t priv\_key[36], uint16\_t write\_key\_id, const uint8\_t write\_key[32], const uint8\_t num\_in[NONCE\_NUMIN\_SIZE])

Executes PrivWrite command, to write externally generated ECC private keys into the device.

# 20.85.1 Detailed Description

CryptoAuthLib Basic API methods for PrivWrite command.

The PrivWrite command is used to write externally generated ECC private keys into the device.

#### Note

List of devices that support this command - ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.85.2 Function Documentation

## 20.85.2.1 calib\_priv\_write()

Executes PrivWrite command, to write externally generated ECC private keys into the device.

### **Parameters**

| in | device     | Device context pointer                                                                   |
|----|------------|------------------------------------------------------------------------------------------|
| in | key_id     | Slot to write the external private key into.                                             |
| in | priv_key   | External private key (36 bytes) to be written. The first 4 bytes should be zero for P256 |
|    |            | curve.                                                                                   |
| in | write_key⊷ | Write key slot. Ignored if write_key is NULL.                                            |
|    | _id        |                                                                                          |
| in | write_key  | Write key (32 bytes). If NULL, perform an unencrypted PrivWrite, which is only available |
|    |            | when the data zone is unlocked.                                                          |
| in | num_in     | 20 byte host nonce to inject into Nonce calculation                                      |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.86 calib\_random.c File Reference

CryptoAuthLib Basic API methods for Random command.

```
#include "cryptoauthlib.h"
```

## **Functions**

ATCA\_STATUS calib\_random (ATCADevice device, uint8\_t \*rand\_out)

Executes Random command, which generates a 32 byte random number from the CryptoAuth device.

# 20.86.1 Detailed Description

CryptoAuthLib Basic API methods for Random command.

The Random command generates a random number for use by the system.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.87 calib\_read.c File Reference

CryptoAuthLib Basic API methods for Read command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

#### **Functions**

ATCA\_STATUS calib\_read\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_
 t offset, uint8 t \*data, uint8 t len)

Executes Read command, which reads either 4 or 32 bytes of data from a given slot, configuration zone, or the OTP zone.

• ATCA\_STATUS calib\_read\_serial\_number (ATCADevice device, uint8\_t \*serial\_number)

Executes Read command, which reads the 9 byte serial number of the device from the config zone.

ATCA\_STATUS calib\_is\_slot\_locked (ATCADevice device, uint16\_t slot, bool \*is\_locked)

Executes Read command, which reads the configuration zone to see if the specified slot is locked.

• ATCA STATUS calib is locked (ATCADevice device, uint8 t zone, bool \*is locked)

Executes Read command, which reads the configuration zone to see if the specified zone is locked.

• ATCA\_STATUS calib\_read\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t block, uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[NONCE\_NUMIN\_SIZE])

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

ATCA STATUS calib read config zone (ATCADevice device, uint8 t \*config data)

Executes Read command to read the complete device configuration zone.

ATCA STATUS calib cmp config zone (ATCADevice device, uint8 t \*config data, bool \*same config)

Compares a specified configuration zone with the configuration zone currently on the device.

• ATCA\_STATUS calib\_read\_sig (ATCADevice device, uint16\_t slot, uint8\_t \*sig)

Executes Read command to read a 64 byte ECDSA P256 signature from a slot configured for clear reads.

• ATCA\_STATUS calib\_read\_pubkey (ATCADevice device, uint16\_t slot, uint8\_t \*public\_key)

Executes Read command to read an ECC P256 public key from a slot configured for clear reads.

 ATCA\_STATUS calib\_read\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset, uint8 t \*data, size t length)

Used to read an arbitrary number of bytes from any zone configured for clear reads.

## 20.87.1 Detailed Description

CryptoAuthLib Basic API methods for Read command.

The Read command reads words either 4-byte words or 32-byte blocks from one of the memory zones of the device. The data may optionally be encrypted before being returned to the system.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.87.2 Function Documentation

### 20.87.2.1 calib\_read\_enc()

```
ATCA_STATUS calib_read_enc (
    ATCADevice device,
    uint16_t key_id,
    uint8_t block,
    uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[NONCE_NUMIN_SIZE])
```

Executes Read command on a slot configured for encrypted reads and decrypts the data to return it as plaintext.

Data zone must be locked for this command to succeed. Can only read 32 byte blocks.

#### **Parameters**

| in  | device   | Device context pointer                                                |
|-----|----------|-----------------------------------------------------------------------|
| in  | key_id   | The slot ID to read from.                                             |
| in  | block    | Index of the 32 byte block within the slot to read.                   |
| out | data     | Decrypted (plaintext) data from the read is returned here (32 bytes). |
| in  | enc_key  | 32 byte ReadKey for the slot being read.                              |
| in  | enc_key⇔ | KeyID of the ReadKey being used.                                      |
|     | _id      |                                                                       |
| in  | num_in   | 20 byte host nonce to inject into Nonce calculation                   |

returns ATCA\_SUCCESS on success, otherwise an error code.

# 20.88 calib\_secureboot.c File Reference

CryptoAuthLib Basic API methods for SecureBoot command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

### **Functions**

ATCA\_STATUS calib\_secureboot (ATCADevice device, uint8\_t mode, uint16\_t param2, const uint8\_←
t \*digest, const uint8 t \*signature, uint8 t \*mac)

Executes Secure Boot command, which provides support for secure boot of an external MCU or MPU.

• ATCA\_STATUS calib\_secureboot\_mac (ATCADevice device, uint8\_t mode, const uint8\_t \*digest, const uint8\_t \*signature, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes Secure Boot command with encrypted digest and validated MAC response using the IO protection key.

# 20.88.1 Detailed Description

CryptoAuthLib Basic API methods for SecureBoot command.

The SecureBoot command provides support for secure boot of an external MCU or MPU.

Note

List of devices that support this command - ATECC608A/B. Refer to device datasheet for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.89 calib\_selftest.c File Reference

CryptoAuthLib Basic API methods for SelfTest command.

```
#include "cryptoauthlib.h"
```

## **Functions**

ATCA\_STATUS calib\_selftest (ATCADevice device, uint8\_t mode, uint16\_t param2, uint8\_t \*result)
 Executes the SelfTest command, which performs a test of one or more of the cryptographic engines within the AT← ECC608 chip.

## 20.89.1 Detailed Description

CryptoAuthLib Basic API methods for SelfTest command.

The SelfTest command performs a test of one or more of the cryptographic engines within the device.

Note

List of devices that support this command - ATECC608A/B. Refer to device datasheet for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.90 calib\_sha.c File Reference

CryptoAuthLib Basic API methods for SHA command.

```
#include "cryptoauthlib.h"
```

#### **Data Structures**

struct hw\_sha256\_ctx

#### **Functions**

ATCA\_STATUS calib\_sha\_base (ATCADevice device, uint8\_t mode, uint16\_t length, const uint8\_←
t \*message, uint8 t \*data out, uint16 t \*data out size)

Executes SHA command, which computes a SHA-256 or HMAC/SHA-256 digest for general purpose use by the host system.

ATCA\_STATUS calib\_sha\_start (ATCADevice device)

Executes SHA command to initialize SHA-256 calculation engine.

ATCA\_STATUS calib\_sha\_update (ATCADevice device, const uint8\_t \*message)

Executes SHA command to add 64 bytes of message data to the current context.

ATCA\_STATUS calib\_sha\_end (ATCADevice device, uint8\_t \*digest, uint16\_t length, const uint8\_←
t \*message)

Executes SHA command to complete SHA-256 or HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_read\_context (ATCADevice device, uint8\_t \*context, uint16\_t \*context\_size)

Executes SHA command to read the SHA-256 context back. Only for ATECC608 with SHA-256 contexts. HMAC not supported.

ATCA\_STATUS calib\_sha\_write\_context (ATCADevice device, const uint8\_t \*context, uint16\_t context\_size)

Executes SHA command to write (restore) a SHA-256 context into the the device. Only supported for ATECC608 with SHA-256 contexts.

ATCA\_STATUS calib\_sha (ATCADevice device, uint16\_t length, const uint8\_t \*message, uint8\_t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA\_STATUS calib\_hw\_sha2\_256\_init (ATCADevice device, atca\_sha256\_ctx\_t \*ctx)

Initialize a SHA context for performing a hardware SHA-256 operation on a device. Note that only one SHA operation can be run at a time.

ATCA\_STATUS calib\_hw\_sha2\_256\_update (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, const uint8\_
 t \*data, size t data size)

Add message data to a SHA context for performing a hardware SHA-256 operation on a device.

• ATCA\_STATUS calib\_hw\_sha2\_256\_finish (ATCADevice device, atca\_sha256\_ctx\_t \*ctx, uint8\_t \*digest)

Finish SHA-256 digest for a SHA context for performing a hardware SHA-256 operation on a device.

ATCA\_STATUS calib\_hw\_sha2\_256 (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint8\_
 t \*digest)

Use the SHA command to compute a SHA-256 digest.

ATCA\_STATUS calib\_sha\_hmac\_init (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint16\_t key\_
 slot)

Executes SHA command to start an HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_update (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, const uint8
 \_t \*data, size\_t data\_size)

Executes SHA command to add an arbitrary amount of message data to a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac\_finish (ATCADevice device, atca\_hmac\_sha256\_ctx\_t \*ctx, uint8\_←
 t \*digest, uint8 t target)

Executes SHA command to complete a HMAC/SHA-256 operation.

ATCA\_STATUS calib\_sha\_hmac (ATCADevice device, const uint8\_t \*data, size\_t data\_size, uint16\_t key
 — slot, uint8\_t \*digest, uint8\_t target)

Use the SHA command to compute an HMAC/SHA-256 operation.

# 20.90.1 Detailed Description

CryptoAuthLib Basic API methods for SHA command.

The SHA command Computes a SHA-256 or HMAC/SHA digest for general purpose use by the host system.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.91 calib\_sign.c File Reference

CryptoAuthLib Basic API methods for Sign command.

```
#include "cryptoauthlib.h"
```

#### **Functions**

- ATCA\_STATUS calib\_sign\_base (ATCADevice device, uint8\_t mode, uint16\_t key\_id, uint8\_t \*signature)

  Executes the Sign command, which generates a signature using the ECDSA algorithm.
- ATCA\_STATUS calib\_sign (ATCADevice device, uint16\_t key\_id, const uint8\_t \*msg, uint8\_t \*signature)
   Executes Sign command, to sign a 32-byte external message using the private key in the specified slot. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.
- ATCA\_STATUS calib\_sign\_internal (ATCADevice device, uint16\_t key\_id, bool is\_invalidate, bool is\_full\_sn, uint8\_t \*signature)

Executes Sign command to sign an internally generated message.

# 20.91.1 Detailed Description

CryptoAuthLib Basic API methods for Sign command.

The Sign command generates a signature using the private key in slot with ECDSA algorithm.

Note

List of devices that support this command - ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 812

# 20.92 calib updateextra.c File Reference

CryptoAuthLib Basic API methods for UpdateExtra command.

```
#include "cryptoauthlib.h"
```

## **Functions**

ATCA\_STATUS calib\_updateextra (ATCADevice device, uint8\_t mode, uint16\_t new\_value)

Executes UpdateExtra command to update the values of the two extra bytes within the Configuration zone (bytes 84 and 85).

# 20.92.1 Detailed Description

CryptoAuthLib Basic API methods for UpdateExtra command.

The UpdateExtra command is used to update the values of the two extra bytes within the Configuration zone after the Configuration zone has been locked.

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.93 calib\_verify.c File Reference

CryptoAuthLib Basic API methods for Verify command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

#### **Functions**

ATCA\_STATUS calib\_verify (ATCADevice device, uint8\_t mode, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*public\_key, const uint8\_t \*other\_data, uint8\_t \*mac)

Executes the Verify command, which takes an ECDSA [R,S] signature and verifies that it is correctly generated from a given message and public key. In all cases, the signature is an input to the command.

ATCA\_STATUS calib\_verify\_extern (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, const uint8\_t \*public\_key, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or TempKey for other devices.

ATCA\_STATUS calib\_verify\_extern\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_←
t \*signature, const uint8 t \*public key, const uint8 t \*num in, const uint8 t \*io key, bool \*is verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with all components (message, signature, and public key) supplied. This function is only available on the ATECC608.

 ATCA\_STATUS calib\_verify\_stored (ATCADevice device, const uint8\_t \*message, const uint8\_t \*signature, uint16\_t key\_id, bool \*is\_verified)

Executes the Verify command, which verifies a signature (ECDSA verify operation) with a public key stored in the device. The message to be signed will be loaded into the Message Digest Buffer to the ATECC608 device or Temp← Key for other devices.

ATCA\_STATUS calib\_verify\_stored\_mac (ATCADevice device, const uint8\_t \*message, const uint8\_←
 t \*signature, uint16\_t key\_id, const uint8\_t \*num\_in, const uint8\_t \*io\_key, bool \*is\_verified)

Executes the Verify command with verification MAC, which verifies a signature (ECDSA verify operation) with a public key stored in the device. This function is only available on the ATECC608.

ATCA\_STATUS calib\_verify\_validate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Validate mode to validate a public key stored in a slot.

• ATCA\_STATUS calib\_verify\_invalidate (ATCADevice device, uint16\_t key\_id, const uint8\_t \*signature, const uint8\_t \*other\_data, bool \*is\_verified)

Executes the Verify command in Invalidate mode which invalidates a previously validated public key stored in a slot.

#### 20.93.1 Detailed Description

CryptoAuthLib Basic API methods for Verify command.

The Verify command takes an ECDSA [R,S] signature and verifies that it is correctly generated given an input message digest and public key.

Note

List of devices that support this command - ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheet for full details.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.94 calib\_write.c File Reference

CryptoAuthLib Basic API methods for Write command.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
```

#### **Functions**

 ATCA\_STATUS calib\_write (ATCADevice device, uint8\_t zone, uint16\_t address, const uint8\_t \*value, const uint8\_t \*mac)

Executes the Write command, which writes either one four byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for this slot, the data may be required to be encrypted by the system prior to being sent to the device. This command cannot be used to write slots configured as ECC private keys.

ATCA\_STATUS calib\_write\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, uint8\_t block, uint8\_←
t offset, const uint8\_t \*data, uint8\_t len)

Executes the Write command, which writes either 4 or 32 bytes of data into a device zone.

ATCA\_STATUS calib\_write\_enc (ATCADevice device, uint16\_t key\_id, uint8\_t block, const uint8\_t \*data, const uint8\_t \*enc\_key, const uint16\_t enc\_key\_id, const uint8\_t num\_in[NONCE\_NUMIN\_SIZE])

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

ATCA\_STATUS calib\_write\_config\_zone (ATCADevice device, const uint8\_t \*config\_data)

Executes the Write command, which writes the configuration zone.

ATCA\_STATUS calib\_write\_pubkey (ATCADevice device, uint16\_t slot, const uint8\_t \*public\_key)

Uses the write command to write a public key to a slot in the proper format.

 ATCA\_STATUS calib\_write\_bytes\_zone (ATCADevice device, uint8\_t zone, uint16\_t slot, size\_t offset\_bytes, const uint8\_t \*data, size\_t length)

Executes the Write command, which writes data into the configuration, otp, or data zones with a given byte offset and length. Offset and length must be multiples of a word (4 bytes).

ATCA\_STATUS calib\_write\_config\_counter (ATCADevice device, uint16\_t counter\_id, uint32\_t counter\_
 value)

Initialize one of the monotonic counters in device with a specific value.

#### 20.94.1 Detailed Description

CryptoAuthLib Basic API methods for Write command.

The Write command writes either one 4-byte word or a 32-byte block to one of the EEPROM zones on the device. Depending upon the value of the WriteConfig byte for a slot, the data may be required to be encrypted by the system prior to being sent to the device

Note

List of devices that support this command - ATSHA204A, ATECC108A, ATECC508A, and ATECC608A/B. There are differences in the modes that they support. Refer to device datasheets for full details.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.94.2 Function Documentation

#### 20.94.2.1 calib\_write\_enc()

```
ATCA_STATUS calib_write_enc (
    ATCADevice device,
    uint16_t key_id,
    uint8_t block,
    const uint8_t * data,
    const uint8_t * enc_key,
    const uint16_t enc_key_id,
    const uint8_t num_in[NONCE_NUMIN_SIZE])
```

Executes the Write command, which performs an encrypted write of a 32 byte block into given slot.

The function takes clear text bytes and encrypts them for writing over the wire. Data zone must be locked and the slot configuration must be set to encrypted write for the block to be successfully written.

#### **Parameters**

| in | device   | Device context pointer                                |
|----|----------|-------------------------------------------------------|
| in | key_id   | Slot ID to write to.                                  |
| in | block    | Index of the 32 byte block to write in the slot.      |
| in | data     | 32 bytes of clear text data to be written to the slot |
| in | enc_key  | WriteKey to encrypt with for writing                  |
| in | enc_key⊷ | The KeyID of the WriteKey                             |
|    | _id      |                                                       |
| in | num_in   | 20 byte host nonce to inject into Nonce calculation   |

returns ATCA\_SUCCESS on success, otherwise an error code.

# 20.95 cryptoauthlib.h File Reference

Single aggregation point for all CryptoAuthLib header files.

```
#include <stdio.h>
#include <stdint.h>
#include <stddef.h>
#include <stdlib.h>
#include <string.h>
#include <stdarg.h>
#include "atca_config.h"
#include "atca_compiler.h"
#include "atca_version.h"
#include "atca_status.h"
#include "atca_debug.h"
#include "atca iface.h"
#include "atca_helpers.h"
#include "hal/atca_hal.h"
#include "atca_cfgs.h"
#include "atca_device.h"
#include "calib/calib_basic.h"
#include "calib/calib_command.h"
#include "calib/calib_aes_gcm.h"
```

```
#include "talib/talib_status.h"
#include "talib/talib_basic.h"
#include "atca_basic.h"
```

# **Macros**

- #define ATCA SHA SUPPORT 1
- #define ATCA ATECC608 SUPPORT
- #define ATCA\_ECC\_SUPPORT 1
- #define ATCA\_CA\_SUPPORT 1
- #define ATCA TA SUPPORT 1
- #define ATCA DLL SHARED LIB IMPORT
- #define ATCA\_SHA256\_BLOCK\_SIZE (64)
- #define ATCA\_SHA256\_DIGEST\_SIZE (32)
- #define ATCA\_AES128\_BLOCK\_SIZE (16)
- #define ATCA\_AES128\_KEY\_SIZE (16)
- #define ATCA\_ECCP256\_KEY\_SIZE (32)
- #define ATCA ECCP256 PUBKEY SIZE (64)
- #define ATCA\_ECCP256\_SIG\_SIZE (64)
- #define ATCA\_ZONE\_CONFIG ((uint8\_t)0x00)
- #define ATCA\_ZONE\_OTP ((uint8\_t)0x01)
- #define ATCA\_ZONE\_DATA ((uint8\_t)0x02)
- #define SHA\_MODE\_TARGET\_TEMPKEY ((uint8\_t)0x00)
- #define SHA\_MODE\_TARGET\_MSGDIGBUF ((uint8\_t)0x40)
- #define SHA\_MODE\_TARGET\_OUT\_ONLY ((uint8\_t)0xC0)
- #define ATCA\_STRINGIFY(x) #x
- #define ATCA\_TOSTRING(x) ATCA\_STRINGIFY(x)
- #define ATCA\_TRACE(s, m) atca\_trace(s)

## 20.95.1 Detailed Description

Single aggregation point for all CryptoAuthLib header files.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.95.2 Macro Definition Documentation

# 20.95.2.1 ATCA\_AES128\_BLOCK\_SIZE

```
#define ATCA_AES128_BLOCK_SIZE (16)
```

# 20.95.2.2 ATCA\_AES128\_KEY\_SIZE

#define ATCA\_AES128\_KEY\_SIZE (16)

# 20.95.2.3 ATCA\_ATECC608\_SUPPORT

#define ATCA\_ATECC608\_SUPPORT

# 20.95.2.4 ATCA\_CA\_SUPPORT

#define ATCA\_CA\_SUPPORT 1

## 20.95.2.5 ATCA\_DLL

#define ATCA\_DLL SHARED\_LIB\_IMPORT

# 20.95.2.6 ATCA\_ECC\_SUPPORT

#define ATCA\_ECC\_SUPPORT 1

# 20.95.2.7 ATCA\_ECCP256\_KEY\_SIZE

#define ATCA\_ECCP256\_KEY\_SIZE (32)

# 20.95.2.8 ATCA\_ECCP256\_PUBKEY\_SIZE

#define ATCA\_ECCP256\_PUBKEY\_SIZE (64)

# 20.95.2.9 ATCA\_ECCP256\_SIG\_SIZE

#define ATCA\_ECCP256\_SIG\_SIZE (64)

# 20.95.2.10 ATCA\_SHA256\_BLOCK\_SIZE

```
#define ATCA_SHA256_BLOCK_SIZE (64)
```

# 20.95.2.11 ATCA\_SHA256\_DIGEST\_SIZE

```
#define ATCA_SHA256_DIGEST_SIZE (32)
```

# 20.95.2.12 ATCA\_SHA\_SUPPORT

```
#define ATCA_SHA_SUPPORT 1
```

Library Configuration File - All build attributes should be included in atca\_config.h

# 20.95.2.13 ATCA\_STRINGIFY

```
#define ATCA_STRINGIFY( x ) \#x
```

# 20.95.2.14 ATCA\_TA\_SUPPORT

```
#define ATCA_TA_SUPPORT 1
```

# 20.95.2.15 ATCA\_TOSTRING

## 20.95.2.16 ATCA\_TRACE

## 20.95.2.17 ATCA\_ZONE\_CONFIG

#define ATCA\_ZONE\_CONFIG ((uint8\_t)0x00)

# 20.95.2.18 ATCA\_ZONE\_DATA

#define ATCA\_ZONE\_DATA ((uint8\_t)0x02)

#### 20.95.2.19 ATCA\_ZONE\_OTP

#define ATCA\_ZONE\_OTP ((uint8\_t)0x01)

# 20.95.2.20 SHA\_MODE\_TARGET\_MSGDIGBUF

 $\verb|#define SHA_MODE_TARGET_MSGDIGBUF ((uint8_t) 0x40)|\\$ 

Place resulting digest both in Output buffer and Message Digest Buffer

## 20.95.2.21 SHA\_MODE\_TARGET\_OUT\_ONLY

#define SHA\_MODE\_TARGET\_OUT\_ONLY ((uint8\_t)0xC0)

Place resulting digest both in Output buffer ONLY

## 20.95.2.22 SHA\_MODE\_TARGET\_TEMPKEY

#define SHA\_MODE\_TARGET\_TEMPKEY ((uint8\_t)0x00)

Place resulting digest both in Output buffer and TempKey

# 20.96 cryptoki.h File Reference

#include "pkcs11.h"

## **Macros**

- #define PKCS11\_HELPER\_DLL\_IMPORT
- #define PKCS11 HELPER DLL EXPORT
- #define PKCS11\_HELPER\_DLL\_LOCAL
- #define PKCS11 API
- #define PKCS11\_LOCAL PKCS11\_HELPER\_DLL\_LOCAL
- #define CK PTR \*
- #define CK DECLARE FUNCTION(returnType, name) returnType PKCS11 API name
- #define CK\_DECLARE\_FUNCTION\_POINTER(returnType, name) returnType PKCS11\_API(\*name)
- #define CK\_CALLBACK\_FUNCTION(returnType, name) returnType(\*name)
- #define NULL PTR 0

#### 20.96.1 Macro Definition Documentation

## 20.96.1.1 CK\_CALLBACK\_FUNCTION

# 20.96.1.2 CK\_DECLARE\_FUNCTION

#### 20.96.1.3 CK DECLARE FUNCTION POINTER

## 20.96.1.4 CK\_PTR

```
#define CK_PTR *
```

## 20.96.1.5 NULL\_PTR

#define NULL\_PTR 0

#### 20.96.1.6 PKCS11 API

#define PKCS11\_API

### 20.96.1.7 PKCS11\_HELPER\_DLL\_EXPORT

#define PKCS11\_HELPER\_DLL\_EXPORT

# 20.96.1.8 PKCS11\_HELPER\_DLL\_IMPORT

#define PKCS11\_HELPER\_DLL\_IMPORT

## 20.96.1.9 PKCS11\_HELPER\_DLL\_LOCAL

#define PKCS11\_HELPER\_DLL\_LOCAL

# 20.96.1.10 PKCS11\_LOCAL

#define PKCS11\_LOCAL PKCS11\_HELPER\_DLL\_LOCAL

# 20.97 example cert chain.c File Reference

```
#include "atcacert/atcacert_def.h"
#include "example_cert_chain.h"
```

## **Variables**

- const atcacert\_def\_t g\_cert\_def\_0\_root
- const atcacert\_cert\_element\_t g\_cert\_elements\_1\_signer []
- const uint8\_t g\_cert\_template\_1\_signer []
- const atcacert\_def\_t g\_cert\_def\_1\_signer
- const uint8\_t g\_cert\_template\_2\_device []
- const atcacert\_def\_t g\_cert\_def\_2\_device

# 20.97.1 Variable Documentation

# 20.97.1.1 g\_cert\_def\_0\_root

```
const atcacert_def_t g_cert_def_0_root
```

## Initial value:

# 20.97.1.2 g\_cert\_def\_1\_signer

```
{\tt const\ atcacert\_def\_t\ g\_cert\_def\_1\_signer}
```

# 20.97.1.3 g\_cert\_def\_2\_device

```
{\tt const\ atcacert\_def\_t\ g\_cert\_def\_2\_device}
```

## 20.97.1.4 g cert elements 1 signer

```
const atcacert_cert_element_t g_cert_elements_1_signer[]
```

# 20.97.1.5 g\_cert\_template\_1\_signer

```
const uint8_t g_cert_template_1_signer[]
```

#### 20.97.1.6 g\_cert\_template\_2\_device

```
const uint8_t g_cert_template_2_device[]
```

#### Initial value:

```
0x30, 0x82, 0x01, 0xa6, 0x30, 0x82, 0x01, 0x4b, 0xa0, 0x03, 0x02, 0x01, 0x02, 0x02, 0x10, 0x41,
0xa6, 0x8b, 0xe4, 0x36, 0xdd, 0xc3, 0xd8, 0x39, 0xfa,
   0xbd, 0xd7, 0x27, 0xd9, 0x74, 0xe7, 0x30,
0x0a, 0x06, 0x08, 0x2a, 0x86, 0x48, 0xce, 0x3d, 0x04,
   0x03, 0x02, 0x30, 0x34, 0x31,
   0x14.
0x12, 0x06, 0x03, 0x55, 0x04, 0x0a, 0x0c, 0x0b, 0x45,
   0x78, 0x61, 0x6d, 0x70, 0x6c, 0x65, 0x20,
0x49, 0x6e, 0x63, 0x31, 0x1c, 0x30, 0x1a, 0x06, 0x03,
   0x55, 0x04, 0x03, 0x0c, 0x13, 0x45, 0x78,
0x61, 0x6d, 0x70, 0x6c, 0x65, 0x20, 0x53, 0x69, 0x67,
   0x6e, 0x65, 0x72, 0x20, 0x46, 0x46, 0x46,
0x46, 0x30, 0x20, 0x17, 0x0d, 0x31, 0x37, 0x30, 0x37,
   0x31, 0x30, 0x32, 0x30, 0x30, 0x30, 0x30,
0x30, 0x5a, 0x18, 0x0f, 0x33, 0x30, 0x30, 0x30, 0x31,
   0x32, 0x33, 0x31, 0x32, 0x33, 0x35, 0x39,
0x35, 0x39, 0x5a, 0x30, 0x2f, 0x31, 0x14, 0x30, 0x12,
   0x06, 0x03, 0x55, 0x04, 0x0a, 0x0c, 0x0b,
   0x15,
0x45, 0x78, 0x61, 0x6d, 0x70, 0x6c, 0x65, 0x20, 0x49,
   0x6e, 0x63, 0x31, 0x17, 0x30,
0x03, 0x55, 0x04, 0x03, 0x0c, 0x0e, 0x45, 0x78, 0x61,
   0x6d, 0x70, 0x6c, 0x65, 0x20,
   0×44.
0x76, 0x69, 0x63, 0x65, 0x30, 0x59, 0x30, 0x13, 0x06,
   0x07, 0x2a, 0x86, 0x48, 0xce, 0x3d, 0x02,
0x01, 0x06, 0x08, 0x2a, 0x86, 0x48, 0xce, 0x3d, 0x03,
   0x01, 0x07, 0x03, 0x42, 0x00, 0x04, 0x96,
0x27, 0xf1, 0x3e, 0x80, 0xac, 0xf9, 0xd4, 0x12, 0xce,
   0x3b, 0x0d, 0x68, 0xf7, 0x4e,
0x07, 0x35, 0x00, 0xb7, 0x78, 0x5b, 0xac, 0xe6, 0x50,
   0x30, 0x54, 0x77, 0x7f, 0xc8, 0x62, 0x21,
0xce, 0xf2, 0x5a, 0x9a, 0x9e, 0x86, 0x40, 0xc2, 0x29,
   0xd6, 0x4a, 0x32, 0x1e, 0xb9,
0x1c, 0x94, 0xf5, 0x39, 0x88, 0xae, 0xfe, 0x49, 0xcc,
   0xfd, 0xbf, 0x8a, 0x0d, 0x34,
   0xb8, 0xa3,
0x42, 0x30, 0x40, 0x30, 0x1d, 0x06, 0x03, 0x55, 0x1d,
   0x0e, 0x04, 0x16, 0x04, 0x14, 0x2d, 0xda,
0x6c, 0x36, 0xd5, 0xa5, 0x5a, 0xce, 0x97, 0x10, 0x3d,
   0xbb, 0xaf, 0x9c, 0x66, 0x2a, 0xcd, 0x3e,
0xe6, 0xcf, 0x30, 0x1f, 0x06, 0x03, 0x55, 0x1d, 0x23,
   0x04, 0x18, 0x30, 0x16, 0x80, 0x14, 0xc6,
0x70, 0xe0, 0x5e, 0x8a, 0x45, 0x0d, 0xb8, 0x2c, 0x00,
   0x2a, 0x40, 0x06, 0x39, 0x4c, 0x19, 0x58,
0x04, 0x35, 0x76, 0x30, 0x0a, 0x06, 0x08, 0x2a, 0x86,
   0x48, 0xce, 0x3d, 0x04, 0x03,
   0x02,
0x49, 0x00, 0x30, 0x46, 0x02, 0x21, 0x00, 0xe1, 0xfc,
   0x00, 0x23, 0xc1, 0x3d, 0x01, 0x3f, 0x22,
0x31, 0x0b, 0xf0, 0xb8, 0xf4, 0xf4, 0x22, 0xfc, 0x95,
   0x96, 0x33, 0x9c, 0xb9, 0x62, 0xb1, 0xfc,
0x8a, 0x2d, 0xa8, 0x5c, 0xee, 0x67, 0x72, 0x02, 0x21,
   0x00, 0xa1, 0x0d, 0x47, 0xe4, 0xfd, 0x0d,
0x15, 0xd8, 0xde, 0xa1, 0xb5, 0x96, 0x28, 0x4e, 0x7a,
   0x0b, 0xbe, 0xcc, 0xec, 0xe8, 0x8e, 0xcc,
0x7a, 0x31, 0xb3, 0x00, 0x8b, 0xc0, 0x2e, 0x4f, 0x99,
```

# 20.98 example\_cert\_chain.h File Reference

```
#include "atcacert/atcacert_def.h"
```

## **Variables**

- · const atcacert def t g cert def 1 signer
- · const atcacert\_def\_t g\_cert\_def\_2\_device

#### 20.98.1 Variable Documentation

# 20.98.1.1 g\_cert\_def\_1\_signer

```
const atcacert_def_t g_cert_def_1_signer
```

#### 20.98.1.2 g\_cert\_def\_2\_device

```
{\tt const\ atcacert\_def\_t\ g\_cert\_def\_2\_device}
```

# 20.99 example pkcs11 config.c File Reference

```
#include "cryptoauthlib.h"
#include "pkcs11_config.h"
#include "pkcs11/pkcs11_object.h"
#include "pkcs11/pkcs11_slot.h"
#include "example_cert_chain.h"
```

#### **Macros**

- #define pkcs11configLABEL DEVICE CERTIFICATE FOR TLS "device"
- #define pkcs11configLABEL JITP CERTIFICATE "signer"
- #define pkcs11configLABEL\_DEVICE\_PRIVATE\_KEY\_FOR\_TLS pkcs11configLABEL\_DEVICE\_CERTIFICATE\_FOR\_TLS
- #define pkcs11configLABEL\_DEVICE\_PUBLIC\_KEY\_FOR\_TLS pkcs11configLABEL\_DEVICE\_CERTIFICATE\_FOR\_TLS

#### **Functions**

- CK\_RV pkcs11\_config\_cert (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p
   — Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK\_RV pkcs11\_config\_key (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p

  Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK RV pkcs11 config load objects (pkcs11 slot ctx ptr pSlot)

# **Variables**

• const uint8\_t atecc608\_config []

# 20.99.1 Macro Definition Documentation

#### 20.99.1.1 pkcs11configLABEL DEVICE CERTIFICATE FOR TLS

#define pkcsllconfigLABEL\_DEVICE\_CERTIFICATE\_FOR\_TLS "device"

#### 20.99.1.2 pkcs11configLABEL DEVICE PRIVATE KEY FOR TLS

#define pkcsllconfigLABEL\_DEVICE\_PRIVATE\_KEY\_FOR\_TLS pkcsllconfigLABEL\_DEVICE\_CERTIFICATE\_FOR\_TLS

# 20.99.1.3 pkcs11configLABEL\_DEVICE\_PUBLIC\_KEY\_FOR\_TLS

#define pkcs11configLABEL\_DEVICE\_PUBLIC\_KEY\_FOR\_TLS pkcs11configLABEL\_DEVICE\_CERTIFICATE\_FOR\_TLS

#### 20.99.1.4 pkcs11configLABEL JITP CERTIFICATE

```
#define pkcsllconfigLABEL_JITP_CERTIFICATE "signer"
```

# 20.99.2 Function Documentation

## 20.99.2.1 pkcs11\_config\_cert()

#### 20.99.2.2 pkcs11\_config\_key()

### 20.99.2.3 pkcs11\_config\_load\_objects()

## 20.99.3 Variable Documentation

#### 20.99.3.1 atecc608\_config

```
const uint8_t atecc608_config[]
```

#### Initial value:

```
0x01, 0x23, 0x00, 0x00, 0x00, 0x00, 0x60, 0x61, 0x01, 0x00, 0x00, 0x00, 0x00, 0xEE, 0x01, 0x01, 0x00, 0xC0, 0x00, 0x00, 0x01, 0x8F, 0x20, 0xC4, 0x44, 0x44, 0x87, 0x20, 0x87, 0x20, 0x8F, 0x0F, 0xC4, 0x36, 0x9F, 0x0F, 0x8E, 0x20, 0x0F, 0x0F, 0xC4, 0x44, 0x6F, 0x00, 0x00, 0x33, 0x00, 0x1C, 0x00, 0x1C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00, 0x3C, 0x00,
```

Standard Configuration Structure for ATECC608 devices

# 20.100 hal\_all\_platforms\_kit\_hidapi.c File Reference

HAL for kit protocol over HID for any platform.

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "hidapi.h"
#include "atca_hal.h"
#include "hal/kit_protocol.h"
```

#### **Macros**

#define HID PACKET MAX 512

## **Functions**

• ATCA STATUS hal kit hid discover buses (int hid buses[], int max buses)

discover cdc buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS hal\_kit\_hid\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_kit\_hid\_init (void \*hal, ATCAlfaceCfg \*cfg)

HAL implementation of Kit USB HID init.

ATCA\_STATUS hal\_kit\_hid\_post\_init (ATCAlface iface)

HAL implementation of Kit HID post init.

• ATCA\_STATUS kit\_phy\_send (ATCAlface iface, uint8\_t \*txdata, int txlength)

HAL implementation of send over USB HID.

ATCA\_STATUS kit\_phy\_receive (ATCAlface iface, uint8\_t \*rxdata, int \*rxsize)

HAL implementation of kit protocol send over USB HID.

ATCA\_STATUS kit\_phy\_num\_found (int8\_t \*num\_found)

Number of USB HID devices found.

• ATCA STATUS hal kit hid send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of kit protocol send over USB HID.

ATCA\_STATUS hal\_kit\_hid\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_
 t \*rxsize)

HAL implementation of send over USB HID.

• ATCA\_STATUS hal\_kit\_hid\_wake (ATCAlface iface)

Call the wake for kit protocol.

ATCA\_STATUS hal\_kit\_hid\_idle (ATCAlface iface)

Call the idle for kit protocol.

ATCA\_STATUS hal\_kit\_hid\_sleep (ATCAlface iface)

Call the sleep for kit protocol.

• ATCA STATUS hal kit hid release (void \*hal data)

Close the physical port for HID.

# 20.100.1 Detailed Description

HAL for kit protocol over HID for any platform.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.101 hal\_esp32\_i2c.c File Reference

```
#include <stdio.h>
#include <string.h>
#include <driver/i2c.h>
#include "esp_err.h"
#include "esp_log.h"
#include "cryptoauthlib.h"
```

### **Data Structures**

· struct atcal2Cmaster

this is the hal\_data for ATCA HAL for ASF SERCOM

# **Macros**

- #define SDA\_PIN 16
- #define SCL PIN 17
- #define ACK\_CHECK\_EN 0x1
- #define ACK\_CHECK\_DIS 0x0
- #define ACK\_VAL 0x0
- #define NACK VAL 0x1
- #define LOG LOCAL LEVEL ESP LOG INFO
- #define MAX\_I2C\_BUSES 2

## **Typedefs**

typedef struct atcal2Cmaster ATCAl2CMaster t

### **Functions**

void hal i2c change baud (ATCAlface iface, uint32 t speed)

method to change the bus speec of I2C

ATCA STATUS hal i2c init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAlFace instances using the same bus, and you can have multiple ATCAlFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAlFace is abstracted from the physical details.

ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA STATUS hal i2c send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of I2C send.

ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function.

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS hal\_i2c\_discover\_devices (int bus\_num, ATCAlfaceCfg \*cfg, int \*found)

discover any CryptoAuth devices on a given logical bus number

#### **Variables**

- ATCAl2CMaster\_t \* i2c\_hal\_data [2]
- int i2c\_bus\_ref\_ct = 0
- i2c\_config\_t conf
- const char \* TAG = "HAL\_I2C"

### 20.101.1 Macro Definition Documentation

#### 20.101.1.1 ACK\_CHECK\_DIS

#define ACK\_CHECK\_DIS 0x0

I2C master will not check ack from slave

# 20.101.1.2 ACK\_CHECK\_EN

#define ACK\_CHECK\_EN 0x1

I2C master will check ack from slave

# 20.101.1.3 ACK\_VAL

#define ACK\_VAL 0x0

I2C ack value

# 20.101.1.4 LOG\_LOCAL\_LEVEL

#define LOG\_LOCAL\_LEVEL ESP\_LOG\_INFO

# 20.101.1.5 MAX\_I2C\_BUSES

#define MAX\_I2C\_BUSES 2

# 20.101.1.6 NACK\_VAL

#define NACK\_VAL 0x1

I2C nack value

# 20.101.1.7 SCL\_PIN

#define SCL\_PIN 17

# 20.101.1.8 SDA\_PIN

#define SDA\_PIN 16

# 20.101.2 Typedef Documentation

### 20.101.2.1 ATCAI2CMaster\_t

```
typedef struct atcaI2Cmaster ATCAI2CMaster_t
```

# 20.101.3 Function Documentation

### 20.101.3.1 hal\_i2c\_change\_baud()

method to change the bus speec of I2C

#### **Parameters**

| in | iface | interface on which to change bus speed |
|----|-------|----------------------------------------|
| in | speed | baud rate (typically 100000 or 400000) |

### 20.101.3.2 hal\_i2c\_discover\_buses()

```
ATCA_STATUS hal_i2c_discover_buses ( int i2c_buses[], int max_buses )
```

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

This HAL implementation assumes you've included the ASF TWI libraries in your project, otherwise, the HAL layer will not compile because the ASF TWI drivers are a dependency.

logical to physical bus mapping structure

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge. This function is not implemented.

### **Parameters**

|  |  |  | - an array of logical bus numbers                              |
|--|--|--|----------------------------------------------------------------|
|  |  |  | - maximum number of buses the app wants to attempt to discover |

### Returns

ATCA SUCCESS

| in | i2c_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

#### Returns

# ATCA\_UNIMPLEMENTED

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

### **Parameters**

| in | i2c_buses | - an array of logical bus numbers                              |
|----|-----------|----------------------------------------------------------------|
| in | max_buses | - maximum number of buses the app wants to attempt to discover |

#### Returns

# ATCA\_SUCCESS

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

### **Parameters**

| i | in <i>i2c_buses</i> - an array of logical bus numbers in <i>max_buses</i> - maximum number of buses the app wants to attempt to discover return AT |  | - an array of logical bus numbers                                                  |
|---|----------------------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------------------------------------------------|
| i |                                                                                                                                                    |  | - maximum number of buses the app wants to attempt to discover return ATCA_SUCCESS |

# 20.101.3.3 hal\_i2c\_discover\_devices()

```
ATCA_STATUS hal_i2c_discover_devices (
    int bus_num,
    ATCAIfaceCfg * cfg,
    int * found )
```

discover any CryptoAuth devices on a given logical bus number

### **Parameters**

| in bus_num logical bus number on which to look for CryptoAuth devices |                                                                                                   | logical bus number on which to look for CryptoAuth devices |                                                                                               |
|-----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
|                                                                       | out cfg pointer to head of an array of interface config structures which get filled in by this me |                                                            | pointer to head of an array of interface config structures which get filled in by this method |
| out found number of devices found on this bus                         |                                                                                                   | number of devices found on this bus                        |                                                                                               |

#### Returns

ATCA\_SUCCESS

### 20.101.3.4 hal\_i2c\_idle()

idle CryptoAuth device using I2C bus

#### **Parameters**

| in | iface | interface to logical device to idle |
|----|-------|-------------------------------------|
|----|-------|-------------------------------------|

#### Returns

ATCA SUCCESS on success, otherwise an error code.

- < I2C master will check ack from slave
- < I2C master will not check ack from slave

### 20.101.3.5 hal\_i2c\_init()

```
ATCA_STATUS hal_i2c_init ( void * hal, ATCAIfaceCfg * cfg )
```

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c init manages these things and ATCAIFace is abstracted from the physical details.

hal\_i2c\_init manages requests to initialize a physical interface. It manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c init manages these things and ATCAIFace is abstracted from the physical details.

initialize an I2C interface using given config

HAL implementation of I2C init.

• this HAL implementation assumes you've included the START Twi libraries in your project, otherwise, the HAL layer will not compile because the START TWI drivers are a dependency \*

initialize an I2C interface using given config

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

this implementation assumes I2C peripheral has been enabled by user. It only initialize an I2C interface using given config.

#### **Parameters**

| i | in | hal | pointer to HAL specific data that is maintained by this HAL                    |  |
|---|----|-----|--------------------------------------------------------------------------------|--|
| i | in | cfg | pointer to HAL specific configuration data that is used to initialize this HAL |  |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

• this HAL implementation assumes you've included the ASF SERCOM I2C libraries in your project, otherwise, the HAL layer will not compile because the ASF I2C drivers are a dependency \*

### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

initialize an I2C interface using given config

#### **Parameters**

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

• this HAL implementation assumes you've included the ASF Twi libraries in your project, otherwise, the HAL layer will not compile because the ASF TWI drivers are a dependency \*

initialize an I2C interface using given config

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 834

| in | hal | - opaque ptr to HAL data  |
|----|-----|---------------------------|
| in | cfg | - interface configuration |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### 20.101.3.6 hal\_i2c\_post\_init()

HAL implementation of I2C post init.

### **Parameters**

| in | iface | instance |
|----|-------|----------|

### Returns

ATCA\_SUCCESS

### **Parameters**

| in | iface | instance |
|----|-------|----------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.101.3.7 hal\_i2c\_receive()

HAL implementation of I2C receive function.

HAL implementation of I2C receive function for ASF I2C.

HAL implementation of I2C receive function for START I2C.

| in     | iface        | Device to interact with.                                                          |
|--------|--------------|-----------------------------------------------------------------------------------|
| in     | word_address | device transaction type                                                           |
| out    | rxdata       | Data received will be returned here.                                              |
| in,out | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### **Parameters**

| in     | iface    | Device to interact with.                                                          |
|--------|----------|-----------------------------------------------------------------------------------|
| out    | rxdata   | Data received will be returned here.                                              |
| in,out | rxlength | As input, the size of the rxdata buffer. As output, the number of bytes received. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

### **Parameters**

| in     | iface        | Device to interact with.                                                          |
|--------|--------------|-----------------------------------------------------------------------------------|
| in     | word_address | device word address                                                               |
| out    | rxdata       | Data received will be returned here.                                              |
| in,out | rxlength     | As input, the size of the rxdata buffer. As output, the number of bytes received. |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

- < I2C master will check ack from slave
- < I2C nack value
- < I2C ack value
- < I2C ack value
- < I2C nack value

# 20.101.3.8 hal\_i2c\_release()

```
ATCA_STATUS hal_i2c_release ( void * hal_data )
```

manages reference count on given bus and releases resource if no more refences exist

manages reference count on given bus and releases resource if no more refernces exist

| ſ | in hal_c | data | - opaque pointer to hal data structure - known only to the HAL implementation |  |
|---|----------|------|-------------------------------------------------------------------------------|--|
|---|----------|------|-------------------------------------------------------------------------------|--|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

### **Parameters**

| in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation return ATCA_SUCCESS |
|----|----------|---------------------------------------------------------------------------------------------------|
| in | hal_data | - opaque pointer to hal data structure - known only to the HAL implementation                     |

### Returns

ATCA\_SUCCESS

# 20.101.3.9 hal\_i2c\_send()

HAL implementation of I2C send.

HAL implementation of I2C send over ASF.

HAL implementation of I2C send over START.

### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device transaction type           |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# **Parameters**

| in | iface    | instance                          |
|----|----------|-----------------------------------|
| in | txdata   | pointer to space to bytes to send |
| in | txlength | number of bytes to send           |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### **Parameters**

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | device word address               |
| in | txdata       | pointer to space to bytes to send |
| in | txlength     | number of bytes to send           |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

- < I2C master will check ack from slave
- < I2C master will check ack from slave

# 20.101.3.10 hal\_i2c\_sleep()

```
ATCA_STATUS hal_i2c_sleep (
ATCAIface iface)
```

sleep CryptoAuth device using I2C bus

### **Parameters**

| in | iface | interface to logical device to sleep |
|----|-------|--------------------------------------|

# Returns

ATCA\_SUCCESS on success, otherwise an error code.

- < I2C master will check ack from slave
- < I2C master will not check ack from slave

# 20.101.3.11 hal\_i2c\_wake()

```
ATCA_STATUS hal_i2c_wake (
ATCAIface iface)
```

wake up CryptoAuth device using I2C bus

### **Parameters**

| in | iface | interface to logical device to wakeup |
|----|-------|---------------------------------------|

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

< I2C master will not check ack from slave

### 20.101.4 Variable Documentation

# 20.101.4.1 conf

i2c\_config\_t conf

# 20.101.4.2 i2c\_bus\_ref\_ct

```
int i2c\_bus\_ref\_ct = 0
```

# 20.101.4.3 i2c\_hal\_data

```
ATCAI2CMaster_t* i2c_hal_data[2]
```

# 20.101.4.4 TAG

```
const char* TAG = "HAL_I2C"
```

# 20.102 hal\_esp32\_timer.c File Reference

```
#include "atca_hal.h"
#include "freertos/FreeRTOS.h"
#include "freertos/task.h"
```

# **Functions**

- void ets\_delay\_us (uint32\_t)
- void atca\_delay\_ms (uint32\_t msec)

### 20.102.1 Function Documentation

### 20.102.1.1 atca\_delay\_ms()

### 20.102.1.2 ets delay us()

# 20.103 hal\_freertos.c File Reference

FreeRTOS Hardware/OS Abstration Layer.

```
#include "atca_hal.h"
#include "FreeRTOS.h"
#include "semphr.h"
#include "task.h"
```

### **Macros**

• #define ATCA\_MUTEX\_TIMEOUT portMAX\_DELAY

# **Functions**

- void hal\_rtos\_delay\_ms (uint32\_t ms)
  - Timer API implemented at the HAL level.
- ATCA\_STATUS hal\_create\_mutex (void \*\*ppMutex, char \*pName)

Optional hal interfaces.

- ATCA\_STATUS hal\_destroy\_mutex (void \*pMutex)
- ATCA\_STATUS hal\_lock\_mutex (void \*pMutex)
- ATCA\_STATUS hal\_unlock\_mutex (void \*pMutex)

# 20.103.1 Detailed Description

FreeRTOS Hardware/OS Abstration Layer.

Copyright

### 20.103.2 Macro Definition Documentation

### 20.103.2.1 ATCA\_MUTEX\_TIMEOUT

```
#define ATCA_MUTEX_TIMEOUT portMAX_DELAY
```

# 20.104 hal\_i2c\_harmony.c File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over Harmony PLIB.

```
#include <string.h>
#include <stdio.h>
#include "cryptoauthlib.h"
```

### **Functions**

ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

ATCA STATUS hal i2c discover devices (int bus num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_i2c\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAIFace is abstracted from the physical details.

• ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

• ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

• ATCA\_STATUS change\_i2c\_speed (ATCAlface iface, uint32\_t speed)

method to change the bus speec of I2C

• ATCA STATUS hal i2c wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

• ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.104.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over Harmony PLIB.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical I2C implementation. Part 2 is the Harmony I2C primitives to set up the interface.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.105 hal i2c start.c File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

```
#include <string.h>
#include <stdio.h>
#include <atmel_start.h>
#include <hal_gpio.h>
#include <hal_delay.h>
#include "hal_i2c_start.h"
#include "atca_start_config.h"
#include "atca_start_iface.h"
#include "cryptoauthlib.h"
```

### **Functions**

ATCA STATUS hal i2c discover buses (int i2c buses[], int max buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

• ATCA STATUS hal i2c discover devices (int bus num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_i2c\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAIFace is abstracted from the physical details.

ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

• ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

• ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

• ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.105.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical I2C implementation. Part 2 is the START I2C primitives to set up the interface.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.106 hal i2c start.h File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

```
#include "atmel_start.h"
#include <stdlib.h>
#include "cryptoauthlib.h"
```

## **Data Structures**

• struct i2c\_start\_instance

# **Typedefs**

- typedef void(\* start\_change\_baudrate) (ATCAlface iface, uint32\_t speed)
- typedef struct i2c start instance i2c start instance t

# 20.106.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

## Copyright

# 20.107 hal linux.c File Reference

Timer Utility Functions for Linux.

```
#include <stdlib.h>
#include <stdint.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/stat.h>
#include <fcntl.h>
#include <fcntl.h>
#include <pthread.h>
#include <errno.h>
#include "atca_hal.h"
#include <semaphore.h>
```

### **Functions**

• void hal\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

void hal\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

void hal\_delay\_ms (uint32\_t delay)

This function delays for a number of milliseconds.

ATCA\_STATUS hal\_create\_mutex (void \*\*ppMutex, char \*pName)

Optional hal interfaces.

- ATCA\_STATUS hal\_destroy\_mutex (void \*pMutex)
- ATCA\_STATUS hal\_lock\_mutex (void \*pMutex)
- ATCA STATUS hal unlock mutex (void \*pMutex)

# 20.107.1 Detailed Description

Timer Utility Functions for Linux.

Copyright

(c) 2015-2018 Microchip Technology Inc. and its subsidiaries.

# 20.108 hal\_linux\_i2c\_userspace.c File Reference

ATCA Hardware abstraction layer for Linux using I2C.

```
#include <cryptoauthlib.h>
#include <linux/i2c-dev.h>
#include <unistd.h>
#include <sys/ioctl.h>
#include <sys/types.h>
#include <sys/stat.h>
#include <fcntl.h>
```

```
#include <errno.h>
#include <string.h>
#include <stdint.h>
#include <stdio.h>
#include <stdlib.h>
#include "atca_hal.h"
#include "hal_linux_i2c_userspace.h"
```

### **Functions**

• ATCA STATUS hal i2c discover buses (int i2c buses[], int max buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

ATCA\_STATUS hal\_i2c\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA STATUS hal i2c init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAIFace is abstracted from the physical details.

• ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA STATUS hal i2c send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of I2C send over START.

ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

ATCA\_STATUS change\_i2c\_speed (ATCAlface iface, uint32\_t speed)

method to change the bus speec of I2C

• ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

• ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.108.1 Detailed Description

ATCA Hardware abstraction layer for Linux using I2C.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.109 hal\_linux\_i2c\_userspace.h File Reference

ATCA Hardware abstraction layer for Linux using I2C.

### **Data Structures**

struct atcal2Cmaster

this is the hal\_data for ATCA HAL for ASF SERCOM

#### **Macros**

• #define MAX I2C BUSES 2

# **Typedefs**

typedef struct atcal2Cmaster ATCAl2CMaster\_t

# 20.109.1 Detailed Description

ATCA Hardware abstraction layer for Linux using I2C.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.110 hal\_linux\_spi\_userspace.c File Reference

```
#include "cryptoauthlib.h"
#include "atca_hal.h"
#include "hal_linux_spi_userspace.h"
#include <unistd.h>
#include <fcntl.h>
#include <sys/ioctl.h>
#include <linux/spi/spidev.h>
```

#### **Functions**

- ATCA\_STATUS hal\_spi\_discover\_buses (int spi\_buses[], int max\_buses)
- ATCA\_STATUS hal\_spi\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any TA100 devices on a given logical bus number

• ATCA\_STATUS hal\_spi\_open\_file (const char \*dev\_name, uint32\_t speed, int \*fd)

Open and configure the SPI device.

• ATCA\_STATUS hal\_spi\_init (void \*hal, ATCAlfaceCfg \*cfg)

HAL implementation of SPI init.

- ATCA\_STATUS hal\_spi\_post\_init (ATCAlface iface)
- ATCA\_STATUS hal\_spi\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*len)
   HAL implementation of SPI receive function.
- ATCA\_STATUS hal\_spi\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int len)

HAL implementation of SPI send.

• ATCA STATUS hal spi wake (ATCAlface iface)

wake up CryptoAuth device using SPI bus

• ATCA STATUS hal spi idle (ATCAlface iface)

idle TA100 device using SPI bus

ATCA\_STATUS hal\_spi\_sleep (ATCAlface iface)

sleep TA100 device using SPI bus

ATCA\_STATUS hal\_spi\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.110.1 Function Documentation

# 20.110.1.1 hal\_spi\_discover\_buses()

# 20.110.1.2 hal\_spi\_discover\_devices()

```
ATCA_STATUS hal_spi_discover_devices (
    int bus_num,
    ATCAIfaceCfg cfg[],
    int * found )
```

discover any TA100 devices on a given logical bus number

### **Parameters**

| in  | bus_num | logical bus number on which to look for TA100 devices                                         |
|-----|---------|-----------------------------------------------------------------------------------------------|
| out | cfg     | pointer to head of an array of interface config structures which get filled in by this method |
| out | found   | number of devices found on this bus                                                           |

## Returns

ATCA\_SUCCESS

# 20.110.1.3 hal\_spi\_idle()

```
ATCA_STATUS hal_spi_idle (
ATCAIface iface)
```

idle TA100 device using SPI bus

### **Parameters**

| in iface interface to logical device | to idle |
|--------------------------------------|---------|
|--------------------------------------|---------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.110.1.4 hal\_spi\_init()

```
ATCA_STATUS hal_spi_init ( void * hal, ATCAIfaceCfg * cfg )
```

HAL implementation of SPI init.

this implementation assumes SPI peripheral has been enabled by user . It only initialize an SPI interface using given config.

### **Parameters**

| in | hal | pointer to HAL specific data that is maintained by this HAL                    |
|----|-----|--------------------------------------------------------------------------------|
| in | cfg | pointer to HAL specific configuration data that is used to initialize this HAL |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.110.1.5 hal\_spi\_open\_file()

Open and configure the SPI device.

## **Parameters**

| in  | dev_name | File name in the form /dev/spidevX.Y |
|-----|----------|--------------------------------------|
| in  | speed    | Clock speed in Hz                    |
| out | fd       | resulting file descriptor            |

# 20.110.1.6 hal\_spi\_post\_init()

```
ATCA_STATUS hal_spi_post_init (
ATCAIface iface)
```

# 20.110.1.7 hal\_spi\_receive()

HAL implementation of SPI receive function.

#### **Parameters**

| in                | iface        | Device to interact with.                                                          |
|-------------------|--------------|-----------------------------------------------------------------------------------|
| in                | word_address | device transaction type                                                           |
| out <i>rxdata</i> |              | Data received will be returned here.                                              |
| in,out            | len          | As input, the size of the rxdata buffer. As output, the number of bytes received. |

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.110.1.8 hal\_spi\_release()

```
ATCA_STATUS hal_spi_release ( void * hal_data )
```

manages reference count on given bus and releases resource if no more refences exist

## **Parameters**

```
in hal_data - opaque pointer to hal data structure - known only to the HAL implementation
```

# Returns

ATCA SUCCESS on success, otherwise an error code.

# 20.110.1.9 hal\_spi\_send()

HAL implementation of SPI send.

| in | iface        | instance                          |
|----|--------------|-----------------------------------|
| in | word_address | transaction type                  |
| in | txdata       | data to be send to device         |
| in | txdata       | pointer to space to bytes to send |
| in | len          | number of bytes to send           |

### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.110.1.10 hal\_spi\_sleep()

```
ATCA_STATUS hal_spi_sleep (
ATCAIface iface)
```

sleep TA100 device using SPI bus

### **Parameters**

| in | iface | interface to logical device to sleep |
|----|-------|--------------------------------------|
|----|-------|--------------------------------------|

## Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.110.1.11 hal\_spi\_wake()

```
ATCA_STATUS hal_spi_wake (
ATCAIface iface)
```

wake up CryptoAuth device using SPI bus

## **Parameters**

| in | iface | interface to logical device to wakeup |
|----|-------|---------------------------------------|

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 850

Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.111 hal\_linux\_spi\_userspace.h File Reference

ATCA Hardware abstraction layer for Linux using SPI.

### **Data Structures**

struct atcaSPImaster

### **Macros**

• #define MAX\_SPI\_BUSES 2

# **Typedefs**

typedef struct atcaSPImaster ATCASPIMaster\_t

# 20.111.1 Detailed Description

ATCA Hardware abstraction layer for Linux using SPI.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.112 hal\_sam0\_i2c\_asf.c File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over ASF drivers.

```
#include <asf.h>
#include <string.h>
#include <stdio.h>
#include "hal_sam0_i2c_asf.h"
#include "cryptoauthlib.h"
```

### **Functions**

• ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

• ATCA\_STATUS hal\_i2c\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_i2c\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAlFace instances using the same bus, and you can have multiple ATCAlFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAlFace is abstracted from the physical details.

ATCA STATUS hal i2c post init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

• ATCA STATUS hal i2c idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

### 20.112.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over ASF drivers.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical I2C implementation. Part 2 is the ASF I2C primitives to set up the interface.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.113 hal\_sam0\_i2c\_asf.h File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over ASF drivers.

```
#include <asf.h>
#include "cryptoauthlib.h"
```

#### **Data Structures**

struct i2c\_sam0\_instance

# **Typedefs**

- typedef void(\* sam0\_change\_baudrate) (ATCAlface iface, uint32\_t speed)
- typedef struct i2c\_sam0\_instance i2c\_sam0\_instance\_t

# 20.113.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over ASF drivers.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.113.2 Typedef Documentation

# 20.113.2.1 i2c\_sam0\_instance\_t

```
typedef struct i2c_sam0_instance i2c_sam0_instance_t
```

## 20.113.2.2 sam0\_change\_baudrate

```
typedef void(* sam0_change_baudrate) (ATCAIface iface, uint32_t speed)
```

# 20.114 hal\_sam\_i2c\_asf.c File Reference

ATCA Hardware abstraction layer for SAM flexcom & twi I2C over ASF drivers.

```
#include <asf.h>
#include <string.h>
#include <stdio.h>
#include "cryptoauthlib.h"
#include "hal_sam_i2c_asf.h"
```

### **Functions**

• ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

• ATCA\_STATUS hal\_i2c\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_i2c\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAlFace instances using the same bus, and you can have multiple ATCAlFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAlFace is abstracted from the physical details.

ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

• ATCA STATUS hal i2c idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

### 20.114.1 Detailed Description

ATCA Hardware abstraction layer for SAM flexcom & twi I2C over ASF drivers.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical I2C implementation. Part 2 is the ASF I2C primitives to set up the interface.

Prerequisite: add "TWI - Two-Wire Interface (Common API) (service)" module to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.115 hal sam i2c asf.h File Reference

ATCA Hardware abstraction layer for SAMG55 I2C over ASF drivers.

```
#include <asf.h>
#include "cryptoauthlib.h"
```

#### **Data Structures**

struct i2c\_sam\_instance

# **Typedefs**

- typedef void(\* sam\_change\_baudrate) (ATCAlface iface, uint32\_t speed)
- typedef struct i2c\_sam\_instance i2c\_sam\_instance\_t

# 20.115.1 Detailed Description

ATCA Hardware abstraction layer for SAMG55 I2C over ASF drivers.

Prerequisite: add "TWI - Two-Wire Interface (Common API) (service)" module to application in Atmel Studio

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.116 hal\_sam\_timer\_asf.c File Reference

ATCA Hardware abstraction layer for SAMD21 timer/delay over ASF drivers.

```
#include <asf.h>
#include <delay.h>
#include "atca_hal.h"
```

# **Functions**

· void atca\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

void atca\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

void atca\_delay\_ms (uint32\_t ms)

Timer API for legacy implementations.

### 20.116.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 timer/delay over ASF drivers.

# Copyright

# 20.117 hal\_spi\_harmony.c File Reference

ATCA Hardware abstraction layer for SPI over Harmony PLIB.

```
#include <string.h>
#include <stdio.h>
#include "atca_config.h"
#include "cryptoauthlib.h"
#include "atca_hal.h"
#include "atca_device.h"
#include "definitions.h"
#include "talib/talib_defines.h"
```

#### **Functions**

• ATCA STATUS hal spi discover buses (int spi buses[], int max buses)

discover spi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

ATCA\_STATUS hal\_spi\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any TA100 devices on a given logical bus number

ATCA STATUS hal spi init (void \*hal, ATCAlfaceCfg \*cfg)

initialize an SPI interface using given config

ATCA\_STATUS hal\_spi\_post\_init (ATCAlface iface)

HAL implementation of SPI post init.

ATCA STATUS hal spi send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of SPI send over Harmony.

• ATCA\_STATUS hal\_spi\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of SPI receive function for HARMONY SPI.

ATCA\_STATUS hal\_spi\_wake (ATCAlface iface)

wake up TA100 device using SPI bus

• ATCA\_STATUS hal\_spi\_idle (ATCAlface iface)

idle TA100 device using SPI bus

ATCA STATUS hal spi sleep (ATCAlface iface)

sleep TA100 device using SPI bus

• ATCA\_STATUS hal\_spi\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.117.1 Detailed Description

ATCA Hardware abstraction layer for SPI over Harmony PLIB.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical SPI implementation. Part 2 is the Harmony SPI primitives to set up the interface.

Prerequisite: add SERCOM SPI Master Interrupt support to application in Mplab Harmony 3

Copyright

# 20.118 hal swi uart.c File Reference

ATCA Hardware abstraction layer for SWI over UART drivers.

```
#include <string.h>
#include <stdio.h>
#include "atca_hal.h"
#include "hal_swi_uart.h"
#include "atca_device.h"
#include "calib/calib_execution.h"
```

## **Functions**

• ATCA STATUS hal swi discover buses (int swi buses[], int max buses)

discover swi buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

ATCA\_STATUS hal\_swi\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA\_STATUS hal\_swi\_init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_swi\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple swi buses, so hal\_swi\_init manages these things and ATCAIFace is abstracted from the physical details.

ATCA STATUS hal swi post init (ATCAlface iface)

HAL implementation of SWI post init.

ATCA\_STATUS hal\_swi\_send\_flag (ATCAlface iface, uint8\_t data)

HAL implementation of SWI send one byte over UART.

• ATCA STATUS hal swi send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of SWI send command over UART.

ATCA\_STATUS hal\_swi\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_

 t \*rxlength)

HAL implementation of SWI receive function over UART.

ATCA\_STATUS hal\_swi\_wake (ATCAlface iface)

wake up CryptoAuth device using SWI interface

• ATCA\_STATUS hal\_swi\_idle (ATCAlface iface)

idle CryptoAuth device using SWI interface

• ATCA\_STATUS hal\_swi\_sleep (ATCAlface iface)

sleep CryptoAuth device using SWI interface

ATCA\_STATUS hal\_swi\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.118.1 Detailed Description

ATCA Hardware abstraction layer for SWI over UART drivers.

Copyright

# 20.119 hal swi uart.h File Reference

ATCA Hardware abstraction layer for SWI over UART drivers.

### **Macros**

```
• #define SWI_WAKE_TOKEN ((uint8_t)0x00)
```

flag preceding a command

• #define SWI FLAG CMD ((uint8 t)0x77)

flag preceding a command

#define SWI\_FLAG\_TX ((uint8\_t)0x88)

flag requesting a response

#define SWI\_FLAG\_IDLE ((uint8\_t)0xBB)

flag requesting to go into Idle mode

#define SWI\_FLAG\_SLEEP ((uint8\_t)0xCC)

flag requesting to go into Sleep mode

#### **Functions**

• ATCA STATUS hal swi send flag (ATCAlface iface, uint8 t data)

HAL implementation of SWI send one byte over UART.

# 20.119.1 Detailed Description

ATCA Hardware abstraction layer for SWI over UART drivers.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.120 hal\_timer\_start.c File Reference

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

```
#include <hal_delay.h>
#include "atca_hal.h"
```

# **Functions**

void atca\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

void atca\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

void atca\_delay\_ms (uint32\_t ms)

Timer API for legacy implementations.

# 20.120.1 Detailed Description

ATCA Hardware abstraction layer for SAMD21 I2C over START drivers.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.121 hal\_uc3\_i2c\_asf.c File Reference

ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers.

```
#include <asf.h>
#include <string.h>
#include <stdio.h>
#include "cryptoauthlib.h"
#include "hal_uc3_i2c_asf.h"
```

### **Functions**

ATCA\_STATUS hal\_i2c\_discover\_buses (int i2c\_buses[], int max\_buses)

discover i2c buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-prior knowledge

ATCA\_STATUS hal\_i2c\_discover\_devices (int bus\_num, ATCAlfaceCfg cfg[], int \*found)

discover any CryptoAuth devices on a given logical bus number

ATCA STATUS hal i2c init (void \*hal, ATCAlfaceCfg \*cfg)

hal\_i2c\_init manages requests to initialize a physical interface. it manages use counts so when an interface has released the physical layer, it will disable the interface for some other use. You can have multiple ATCAIFace instances using the same bus, and you can have multiple ATCAIFace instances on multiple i2c buses, so hal\_i2c\_init manages these things and ATCAIFace is abstracted from the physical details.

ATCA\_STATUS hal\_i2c\_post\_init (ATCAlface iface)

HAL implementation of I2C post init.

• ATCA\_STATUS hal\_i2c\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of I2C send over START.

• ATCA\_STATUS hal\_i2c\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxlength)

HAL implementation of I2C receive function for START I2C.

ATCA\_STATUS change\_i2c\_speed (ATCAlface iface, uint32\_t speed)

method to change the bus speec of I2C

ATCA\_STATUS hal\_i2c\_wake (ATCAlface iface)

wake up CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_idle (ATCAlface iface)

idle CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_sleep (ATCAlface iface)

sleep CryptoAuth device using I2C bus

ATCA\_STATUS hal\_i2c\_release (void \*hal\_data)

manages reference count on given bus and releases resource if no more refences exist

# 20.121.1 Detailed Description

ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers.

This code is structured in two parts. Part 1 is the connection of the ATCA HAL API to the physical I2C implementation. Part 2 is the ASF I2C primitives to set up the interface.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.122 hal\_uc3\_i2c\_asf.h File Reference

ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers.

```
#include <asf.h>
#include "twi.h"
```

# **Data Structures**

· struct atcal2Cmaster

this is the hal\_data for ATCA HAL for ASF SERCOM

### **Macros**

• #define MAX\_I2C\_BUSES 3

# **Typedefs**

typedef struct atcal2Cmaster ATCAl2CMaster\_t
 this is the hal\_data for ATCA HAL for ASF SERCOM

### **Functions**

ATCA\_STATUS change\_i2c\_speed (ATCAlface iface, uint32\_t speed)

method to change the bus speec of I2C

## 20.122.1 Detailed Description

ATCA Hardware abstraction layer for SAMV71 I2C over ASF drivers.

Prerequisite: add SERCOM I2C Master Polled support to application in Atmel Studio

Copyright

# 20.123 hal uc3 timer asf.c File Reference

ATCA Hardware abstraction layer for SAM4S I2C over ASF drivers.

```
#include <asf.h>
#include <delay.h>
#include "atca_hal.h"
```

## **Functions**

· void atca delay us (uint32 t delay)

This function delays for a number of microseconds.

void atca\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

void atca\_delay\_ms (uint32\_t ms)

Timer API for legacy implementations.

# 20.123.1 Detailed Description

ATCA Hardware abstraction layer for SAM4S I2C over ASF drivers.

Prerequisite: add "Delay routines (service)" module to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.124 hal\_windows.c File Reference

ATCA Hardware abstraction layer for windows timer functions.

```
#include <windows.h>
#include <math.h>
#include "atca_hal.h"
```

## **Functions**

• void hal\_delay\_us (uint32\_t delay)

This function delays for a number of microseconds.

void hal\_delay\_10us (uint32\_t delay)

This function delays for a number of tens of microseconds.

void hal\_delay\_ms (uint32\_t delay)

This function delays for a number of milliseconds.

• ATCA\_STATUS hal\_create\_mutex (void \*\*ppMutex, char \*pName)

Optional hal interfaces.

- ATCA\_STATUS hal\_destroy\_mutex (void \*pMutex)
- ATCA STATUS hal lock mutex (void \*pMutex)
- ATCA\_STATUS hal\_unlock\_mutex (void \*pMutex)

# 20.124.1 Detailed Description

ATCA Hardware abstraction layer for windows timer functions.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.125 io\_protection\_key.h File Reference

Provides required interface to access IO protection key.

```
#include "atca_status.h"
```

# **Functions**

- ATCA\_STATUS io\_protection\_get\_key (uint8\_t \*io\_key)
- ATCA\_STATUS io\_protection\_set\_key (uint8\_t \*io\_key)

# 20.125.1 Detailed Description

Provides required interface to access IO protection key.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.125.2 Function Documentation

# 20.125.2.1 io\_protection\_get\_key()

### 20.125.2.2 io\_protection\_set\_key()

```
ATCA_STATUS io_protection_set_key ( uint8_t * io_key )
```

# 20.126 kit phy.h File Reference

ATCA Hardware abstraction layer physical send & receive function definitions.

```
#include "cryptoauthlib.h"
```

### **Functions**

- ATCA\_STATUS kit\_phy\_num\_found (int8\_t \*num\_found)
   Number of USB HID devices found.
- ATCA STATUS kit phy send (ATCAlface iface, const char \*txdata, int txlength)
- ATCA\_STATUS kit\_phy\_receive (ATCAlface iface, char \*rxdata, int \*rxlength)

# 20.126.1 Detailed Description

ATCA Hardware abstraction layer physical send & receive function definitions.

This is included for kit protocol implementations. It is included in the kit protocol callback to actually send and recieve bytes.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.127 kit\_protocol.c File Reference

Microchip Crypto Auth hardware interface object.

```
#include <stdlib.h>
#include <stdio.h>
#include "atca_compiler.h"
#include "kit_phy.h"
#include "kit_protocol.h"
#include "atca_helpers.h"
```

### **Macros**

- #define KIT\_MAX\_SCAN\_COUNT 4
- #define KIT\_MAX\_TX\_BUF 32

### **Functions**

- char \* strnchr (const char \*s, size\_t count, int c)
- const char \* kit\_id\_from\_devtype (ATCADeviceType devtype)
- const char \* kit\_interface\_from\_kittype (ATCAKitType kittype)
- ATCA\_STATUS kit\_init (ATCAlface iface)

HAL implementation of kit protocol init. This function calls back to the physical protocol to send the bytes.

ATCA STATUS kit send (ATCAlface iface, uint8 t word address, uint8 t \*txdata, int txlength)

HAL implementation of kit protocol send. This function calls back to the physical protocol to send the bytes.

• ATCA\_STATUS kit\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxsize)

HAL implementation to receive bytes and unwrap from kit protocol. This function calls back to the physical protocol to receive the bytes.

ATCA\_STATUS kit\_wake (ATCAlface iface)

Call the wake for kit protocol.

ATCA STATUS kit idle (ATCAlface iface)

Call the idle for kit protocol.

ATCA\_STATUS kit\_sleep (ATCAlface iface)

Call the sleep for kit protocol.

- ATCA\_STATUS kit\_wrap\_cmd (const uint8\_t \*txdata, int txlen, char \*pkitcmd, int \*nkitcmd, char target)
   Wrap binary bytes in ascii kit protocol.
- ATCA\_STATUS kit\_parse\_rsp (const char \*pkitbuf, int nkitbuf, uint8\_t \*kitstatus, uint8\_t \*rxdata, int \*datasize)

Parse the response ascii from the kit.

# 20.127.1 Detailed Description

Microchip Crypto Auth hardware interface object.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.128 kit\_protocol.h File Reference

```
#include "cryptoauthlib.h"
```

### **Macros**

- #define KIT\_TX\_WRAP\_SIZE (10)
- #define KIT MSG SIZE (32)
- #define KIT\_RX\_WRAP\_SIZE (KIT\_MSG\_SIZE + 6)

### **Functions**

ATCA STATUS kit init (ATCAlface iface)

HAL implementation of kit protocol init. This function calls back to the physical protocol to send the bytes.

ATCA\_STATUS kit\_send (ATCAlface iface, uint8\_t word\_address, uint8\_t \*txdata, int txlength)

HAL implementation of kit protocol send. This function calls back to the physical protocol to send the bytes.

ATCA\_STATUS kit\_receive (ATCAlface iface, uint8\_t word\_address, uint8\_t \*rxdata, uint16\_t \*rxsize)

HAL implementation to receive bytes and unwrap from kit protocol. This function calls back to the physical protocol to receive the bytes.

- ATCA\_STATUS kit\_wrap\_cmd (const uint8\_t \*txdata, int txlen, char \*pkitcmd, int \*nkitcmd, char target)
   Wrap binary bytes in ascii kit protocol.
- ATCA\_STATUS kit\_parse\_rsp (const char \*pkitbuf, int nkitbuf, uint8\_t \*kitstatus, uint8\_t \*rxdata, int \*datasize)

Parse the response ascii from the kit.

ATCA\_STATUS kit\_wake (ATCAlface iface)

Call the wake for kit protocol.

• ATCA\_STATUS kit\_idle (ATCAlface iface)

Call the idle for kit protocol.

ATCA\_STATUS kit\_sleep (ATCAlface iface)

Call the sleep for kit protocol.

# 20.128.1 Detailed Description

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.129 license.txt File Reference

### **Functions**

- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party software (including open source software) that may accompany Microchip software. THIS SOFTWARE IS SUPPLIED BY MICROCHIP "AS IS". NO WARRANTIES
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT

- LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCURUMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P← URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO T← HIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B↔ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EX↔ TENT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPY RIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR EVEN IF ADVISED OF THE POSSIBILITY OF SUCH this code has the following Version (the "License")
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation files (the
  "Software")

## **Variables**

- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these terms
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER EXPRESS

- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR STATUTORY
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS SOFTWARE
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON INFRINGEMENT
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON MERCHANTABILITY
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY SPECIAL
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY PUNITIVE
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL LOSS
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO T← HIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER CAUSED
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E← XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY LAW
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN

NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E 

XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN 
ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE 

NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS 
SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES

- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E← XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE← NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF ANY
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E← XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE ← NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROC ← HIP FOR THIS Alan Ott
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E← XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE← NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROC← HIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary forms
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E⇔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE⇔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROC⇔ HIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without modification
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E⇔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE⇔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROC⇔ HIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are met
- c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply

with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR EQUENCIAL COST OR EQUENCIAL COST OR EQUENCIAL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTEQUENT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright notice

- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED WARRANTIES
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUD← ING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED INCLUDING
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT

#### LIMITED TO

- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P← URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P← URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY INCIDENTAL
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P← URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY EXEMPLARY

- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P↔ URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN CONTRACT
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR E↔ XPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTE↔ NT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICRO← CHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY T← HE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR P↔ URPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT LIABILITY
- · c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO T← HIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B↔ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EX↔ TENT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPY RIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR EVEN IF ADVISED OF THE POSSIBILITY OF SUCH this code has the following license

- you may not use this file except in compliance with the License You may obtain a copy of the License at http
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS BASIS
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI← ONS OF ANY KIND
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI← ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the License
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI← ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark VanderVoord
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI

  ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby granted
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of charge
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without restriction
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to use
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to copy
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to modify
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
   ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to merge
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission

- is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to publish
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to distribute
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to sublicense
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to and or sell copies of the Software
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI

  ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do so
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI

  ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following conditions
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI

  ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR IMPLIED
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI⇔ ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM
- you may not use this file except in compliance with the License You may obtain a copy of the License at
  software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI
  ONS OF ANY either express or implied See the License for the specific language governing permissions and
  limitations under the this code depends on the unity library with the following Mark Greg Williams Permission
  is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the
  Software without including without limitation the rights to and or sell copies of the and to permit persons to

- whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER WHETHER IN AN ACTION OF TORT OR OTHERWISE
- you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITI

  ONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER WHETHER IN AN ACTION OF TORT OR ARISING FROM

## 20.129.1 Function Documentation

## 20.129.1.1 DAMAGES()

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B↔ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT↔ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL DAMAGES (

```
INCLUDING ,
BUT NOT LIMITED TO,
PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE,
DATA ,
OR PROFITS; OR BUSINESS INTERRUPTION )
```

## 20.129.1.2 files()

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing

permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation files (

```
the "Software" )
```

#### 20.129.1.3 software()

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party software (

including open source software )

## 20.129.1.4 TORT()

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT $\leftrightarrow$ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR TORT ( INCLUDING NEGLIGENCE OR OTHERWISE )

## 20.129.1.5 Version()

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI← AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B← EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO← WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI← LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal

Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT← NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR← IBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR EVEN IF ADVISED OF THE POSSI← BILITY OF SUCH this code has the following Version (

the "License")

#### 20.129.2 Variable Documentation

#### 20.129.2.1 ANY

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF ANY

## 20.129.2.2 BASIS

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS BASIS

## 20.129.2.3 CAUSED

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PHORICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL  $C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL C \leftarrow CONSEQUENTIAL$ 

## 20.129.2.4 charge

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of charge

### 20.129.2.5 CLAIM

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM

#### 20.129.2.6 conditions

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following conditions

## 20.129.2.7 CONTRACT

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER WHETHER IN AN ACTION OF CONT↔

## 20.129.2.8 copy

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to copy

#### 20.129.2.9 DAMAGE

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT $\leftrightarrow$ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY OR CONSEQUENTIAL WHETHER IN STRICT OR EVEN IF ADVISED OF THE POSSI← BILITY OF SUCH DAMAGE

## Initial value:

If using the Espressif ESP32 I2C driver (lib/hal/hal\_esp32\_i2c.c)

## 20.129.2.10 DIRECT

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WIELD LIABLE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of

conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT↔ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ TBUTORS BE LIABLE FOR ANY DIRECT

#### 20.129.2.11 distribute

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to distribute

#### 20.129.2.12 EXEMPLARY

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT $\leftrightarrow$ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY EXEMPLARY

#### 20.129.2.13 EXPRESS

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER EXPRESS

#### 20.129.2.14 FEES

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF FEES

#### 20.129.2.15 forms

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary forms

## 20.129.2.16 FROM

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER WHETHER IN AN ACTION OF TORT OR ARISING FROM

## 20.129.2.17 granted

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby granted

## 20.129.2.18 http

you may not use this file except in compliance with the License You may obtain a copy of the License at http

#### 20.129.2.19 IMPLIED

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR IMPLIED

### 20.129.2.20 INCIDENTAL

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT  $\leftrightarrow$ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY INCIDENTAL

#### 20.129.2.21 INCLUDING

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A

PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔
AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B↔
EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔
WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI↔
LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal
Software All rights reserved Redistribution and use in source and binary with or without are
permitted provided that the following conditions are this list of conditions and the following
disclaimer\* Redistributions in binary form must reproduce the above copyright this list of
conditions and the following disclaimer in the documentation and or other materials provided
with the distribution\* Neither the name of Signal Software nor the names of its contributors
may be used to endorse or promote products derived from this software without specific prior
written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS
AND ANY EXPRESS OR IMPLIED INCLUDING

#### 20.129.2.22 INDIRECT

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO $\leftrightarrow$ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT↔ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ IBUTORS BE LIABLE FOR ANY INDIRECT

## 20.129.2.23 INFRINGEMENT

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON INFRINGEMENT

#### 20.129.2.24 KIND

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY KIND

#### 20.129.2.25 LAW

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PHORE ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL CHOOST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVICTION OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY LAW

## 20.129.2.26 LIABILITY

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER LIABILITY

## 20.129.2.27 license

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following license

#### 20.129.2.28 License

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the License

#### Initial value:

If using the unit test code in the test folder

#### 20.129.2.29 LOSS

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PHORICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL LAGOSS

## 20.129.2.30 MERCHANTABILITY

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY

## 20.129.2.31 merge

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to merge

#### 20.129.2.32 met

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are met

#### 20.129.2.33 modification

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without modification

## 20.129.2.34 modify

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to modify

## 20.129.2.35 notice

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOW WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WIELD LIABLE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright notice

#### 20.129.2.36 OTHERWISE

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do subject to the following WITHOUT WARRANTY OF ANY EXPRESS OR INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES OR OTHER WHETHER IN AN ACTION OF TORT OR OTHERWISE

#### 20.129.2.37 Ott

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Ott

# 20.129.2.38 publish

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to publish

## 20.129.2.39 PUNITIVE

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A  $P \leftarrow$  ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY PUNITIVE

#### 20.129.2.40 restriction

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without restriction

#### 20.129.2.41 so

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the and to permit persons to whom the Software is furnished to do so

#### 20.129.2.42 SOFTWARE

C Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A P← ARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL C← OST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS BEEN ADV← ISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLOWED BY MICR← OCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WILL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS SOFTWARE

#### Initial value:

If using the cross-platform HID driver (lib/hal/hal\_all\_platforms\_kit\_hidapi.c) this code depends on the hidapi library with the following license:

Copyright (c) 2010

### 20.129.2.43 Software

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to and or sell copies of the Software

#### 20.129.2.44 SPECIAL

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer \*Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution \*Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FIT $\leftrightarrow$ NESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTR↔ TBUTORS BE LIABLE FOR ANY SPECIAL

#### 20.129.2.45 STATUTORY

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR STATUTORY

## 20.129.2.46 sublicense

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to sublicense

#### 20.129.2.47 terms

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these terms

#### 20.129.2.48 TO

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔ AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B $\leftrightarrow$ EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔ WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI $\leftrightarrow$ LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal Software All rights reserved Redistribution and use in source and binary with or without are permitted provided that the following conditions are this list of conditions and the following disclaimer\* Redistributions in binary form must reproduce the above copyright this list of conditions and the following disclaimer in the documentation and or other materials provided with the distribution\* Neither the name of Signal Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED BUT NOT LIMITED TO

#### 20.129.2.49 use

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark Greg Williams Permission is hereby free of to any person obtaining a copy of this software and associated documentation to deal in the Software without including without limitation the rights to use

#### 20.129.2.50 VanderVoord

you may not use this file except in compliance with the License You may obtain a copy of the License at software distributed under the License is distributed on an AS IS WITHOUT WARRANTIES OR CONDITIONS OF ANY either express or implied See the License for the specific language governing permissions and limitations under the this code depends on the unity library with the following Mark VanderVoord

#### 20.129.2.51 WARRANTIES

c Microchip Technology Inc and its subsidiaries Subject to your compliance with these you may use Microchip software and any derivatives exclusively with Microchip products It is your responsibility to comply with third party license terms applicable to your use of third party WHETHER IMPLIED OR APPLY TO THIS INCLUDING ANY IMPLIED WARRANTIES OF NON AND FITNESS FOR A

PARTICULAR PURPOSE IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTI↔
AL COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE HOWEVER EVEN IF MICROCHIP HAS B↔
EEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE TO THE FULLEST EXTENT ALLO↔
WED BY MICROCHIP S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THIS SOFTWARE WI↔
LL NOT EXCEED THE AMOUNT OF IF THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THIS Alan Signal
Software All rights reserved Redistribution and use in source and binary with or without are
permitted provided that the following conditions are this list of conditions and the following
disclaimer\* Redistributions in binary form must reproduce the above copyright this list of
conditions and the following disclaimer in the documentation and or other materials provided
with the distribution\* Neither the name of Signal Software nor the names of its contributors
may be used to endorse or promote products derived from this software without specific prior
written permission THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS
AND ANY EXPRESS OR IMPLIED WARRANTIES

# 20.130 pkcs11.h File Reference

```
#include "pkcs11t.h"
#include "pkcs11f.h"
```

#### **Data Structures**

struct CK FUNCTION LIST

## **Macros**

- #define \_\_\_PASTE(x, y) x ## y
- #define CK\_NEED\_ARG\_LIST 1
- #define CK\_PKCS11\_FUNCTION\_INFO(name) extern CK\_DECLARE\_FUNCTION(CK\_RV, name)
- #define CK NEED ARG LIST 1
- #define CK\_PKCS11\_FUNCTION\_INFO(name) typedef CK\_DECLARE\_FUNCTION\_POINTER (CK\_RV, \_\_PASTE (CK\_, name))
- #define CK\_PKCS11\_FUNCTION\_INFO(name) \_\_PASTE(CK\_, name) name;

## 20.130.1 Macro Definition Documentation

## 20.130.1.1 PASTE

## 20.130.1.2 CK\_NEED\_ARG\_LIST [1/2]

```
#define CK_NEED_ARG_LIST 1
```

## 20.130.1.3 CK\_NEED\_ARG\_LIST [2/2]

```
#define CK_NEED_ARG_LIST 1
```

## 20.130.1.4 CK\_PKCS11\_FUNCTION\_INFO [1/3]

## 20.130.1.5 CK\_PKCS11\_FUNCTION\_INFO [2/3]

## 20.130.1.6 CK\_PKCS11\_FUNCTION\_INFO [3/3]

# 20.131 pkcs11\_attrib.c File Reference

## PKCS11 Library Object Attributes Handling.

```
#include "pkcs11_config.h"
#include "pkcs11_attrib.h"
#include "cryptoauthlib.h"
```

## **Functions**

CK\_RV pkcs11\_attrib\_fill (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_VOID\_PTR pData, const CK\_ULONG ulSize)

Perform the nessasary checks and copy data into an attribute structure.

 CK\_RV pkcs11\_attrib\_value (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_ULONG ulValue, const CK\_ULONG ulSize)

Helper function to write a numerical value to an attribute buffer.

- CK\_RV pkcs11\_attrib\_false (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_attrib\_true (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_attrib\_empty (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)

## 20.131.1 Detailed Description

PKCS11 Library Object Attributes Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.132 pkcs11\_attrib.h File Reference

PKCS11 Library Object Attribute Handling.

```
#include "cryptoki.h"
```

## **Data Structures**

struct \_pkcs11\_attrib\_model

## **Typedefs**

- typedef CK\_RV(\* attrib\_f) (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- typedef struct \_pkcs11\_attrib\_model pkcs11\_attrib\_model
- typedef struct \_pkcs11\_attrib\_model \* pkcs11\_attrib\_model\_ptr

## **Functions**

• CK\_RV pkcs11\_attrib\_fill (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_VOID\_PTR pData, const CK\_ULONG ulSize)

Perform the nessasary checks and copy data into an attribute structure.

 CK\_RV pkcs11\_attrib\_value (CK\_ATTRIBUTE\_PTR pAttribute, const CK\_ULONG ulValue, const CK\_ULONG ulSize)

Helper function to write a numerical value to an attribute buffer.

- CK\_RV pkcs11\_attrib\_false (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK RV pkcs11 attrib true (const CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_attrib\_empty (const CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)

## 20.132.1 Detailed Description

PKCS11 Library Object Attribute Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.132.2 Typedef Documentation

# 20.132.2.1 attrib\_f typedef CK\_RV(\* attrib\_f) (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute) Populate an attribute based on the "object" 20.132.2.2 pkcs11\_attrib\_model typedef struct \_pkcs11\_attrib\_model pkcs11\_attrib\_model

# typedef struct \_pkcs11\_attrib\_model \* pkcs11\_attrib\_model\_ptr

# 20.133 pkcs11\_cert.c File Reference

## PKCS11 Library Certificate Handling.

20.132.2.3 pkcs11\_attrib\_model\_ptr

```
#include "cryptoauthlib.h"
#include "atcacert/atcacert_def.h"
#include "atcacert/atcacert_client.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_token.h"
#include "pkcs11_cert.h"
#include "pkcs11_cert.h"
#include "pkcs11_os.h"
#include "pkcs11_util.h"
```

## **Functions**

- CK RV pkcs11 cert get encoded (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK RV pkcs11 cert get type (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_subject (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_subject\_key\_id (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_cert\_get\_authority\_key\_id (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK RV pkcs11 cert get trusted flag (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_cert\_x509\_write (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)

#### **Variables**

- const pkcs11\_attrib\_model pkcs11\_cert\_x509public\_attributes []
- const CK\_ULONG pkcs11\_cert\_x509public\_attributes\_count = sizeof( pkcs11\_cert\_x509public\_attributes ) / sizeof( pkcs11\_cert\_x509public\_attributes [0])
- const pkcs11 attrib model pkcs11 cert wtlspublic attributes []
- const CK\_ULONG pkcs11\_cert\_wtlspublic\_attributes\_count = sizeof( pkcs11\_cert\_wtlspublic\_attributes ) / sizeof( pkcs11\_cert\_wtlspublic\_attributes [0])
- const pkcs11\_attrib\_model pkcs11\_cert\_x509\_attributes []
- const CK\_ULONG pkcs11\_cert\_x509\_attributes\_count = sizeof( pkcs11\_cert\_x509\_attributes ) / sizeof( pkcs11\_cert\_x509\_attributes [0])

# 20.133.1 Detailed Description

PKCS11 Library Certificate Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.134 pkcs11\_cert.h File Reference

PKCS11 Library Certificate Handling.

```
#include "pkcs11_object.h"
```

## **Functions**

• CK\_RV pkcs11\_cert\_x509\_write (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)

## **Variables**

- const pkcs11\_attrib\_model pkcs11\_cert\_x509public\_attributes []
- const CK\_ULONG pkcs11\_cert\_x509public\_attributes\_count
- const pkcs11\_attrib\_model pkcs11\_cert\_wtlspublic\_attributes []
- const CK\_ULONG pkcs11\_cert\_wtlspublic\_attributes\_count
- const pkcs11\_attrib\_model pkcs11\_cert\_x509\_attributes []
- const CK ULONG pkcs11 cert x509 attributes count

## 20.134.1 Detailed Description

PKCS11 Library Certificate Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.135 pkcs11 config.c File Reference

## PKCS11 Library Configuration.

```
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "cryptoauthlib.h"
#include "pkcs11_slot.h"
#include "pkcs11_object.h"
#include "pkcs11_key.h"
#include "pkcs11_cert.h"
#include "pkcs11_os.h"
#include <ctype.h>
#include <ctype.h>
#include <stdlib.h>
```

## **Functions**

- void pkcs11\_config\_init\_private (pkcs11\_object\_ptr pObject, char \*label, size\_t len)
- void pkcs11\_config\_init\_public (pkcs11\_object\_ptr pObject, char \*label, size\_t len)
- void pkcs11\_config\_init\_cert (pkcs11\_object\_ptr pObject, char \*label, size\_t len)
- CK\_RV pkcs11\_config\_cert (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p
   — Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK\_RV pkcs11\_config\_key (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr p
   — Object, CK\_ATTRIBUTE\_PTR pLabel)
- CK\_RV pkcs11\_config\_remove\_object (pkcs11\_lib\_ctx\_ptr pLibCtx, pkcs11\_slot\_ctx\_ptr pSlot, pkcs11\_object\_ptr pObject)
- CK\_RV pkcs11\_config\_load\_objects (pkcs11\_slot\_ctx\_ptr slot\_ctx)
- CK\_RV pkcs11\_config\_load (pkcs11\_slot\_ctx\_ptr slot\_ctx)

## 20.135.1 Detailed Description

PKCS11 Library Configuration.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.136 pkcs11 debug.c File Reference

## PKCS11 Library Debugging.

```
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_os.h"
#include "atca_helpers.h"
```

# 20.136.1 Detailed Description

PKCS11 Library Debugging.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.137 pkcs11\_debug.h File Reference

```
PKCS11 Library Debugging.
```

```
#include "pkcs11_config.h"
```

## **Macros**

- #define PKCS11\_DEBUG\_NOFILE(...)
- #define PKCS11 DEBUG(...)
- #define PKCS11\_DEBUG\_RETURN(x) { return x; }
- #define pkcs11\_debug\_attributes(x, y)

## 20.137.1 Detailed Description

PKCS11 Library Debugging.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.137.2 Macro Definition Documentation

# 20.137.2.1 PKCS11\_DEBUG

## 20.137.2.2 pkcs11\_debug\_attributes

```
#define pkcs11_debug_attributes( x, y )
```

## 20.137.2.3 PKCS11\_DEBUG\_NOFILE

## 20.137.2.4 PKCS11\_DEBUG\_RETURN

# 20.138 pkcs11 digest.c File Reference

```
#include "pkcs11_init.h"
#include "pkcs11_digest.h"
#include "pkcs11_object.h"
#include "pkcs11_session.h"
#include "pkcs11_util.h"
#include "cryptoauthlib.h"
#include "crypto/atca_crypto_sw_sha2.h"
```

## **Functions**

- CK\_RV pkcs11\_digest\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism)

  Initializes a message-digesting operation using the specified mechanism in the specified session.
- CK\_RV pkcs11\_digest (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Digest the specified data in a one-pass operation and return the resulting digest.

• CK\_RV pkcs11\_digest\_update (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ul ← PartLen)

Continues a multiple-part digesting operation.

CK\_RV pkcs11\_digest\_final (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Finishes a multiple-part digesting operation.

## 20.138.1 Function Documentation

## 20.138.1.1 pkcs11\_digest()

```
CK_RV pkcs11_digest (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pDigest,

CK_ULONG_PTR pulDigestLen )
```

Digest the specified data in a one-pass operation and return the resulting digest.

## 20.138.1.2 pkcs11\_digest\_final()

Finishes a multiple-part digesting operation.

## 20.138.1.3 pkcs11\_digest\_init()

```
CK_RV pkcs11_digest_init (

CK_SESSION_HANDLE hSession,

CK_MECHANISM_PTR pMechanism )
```

Initializes a message-digesting operation using the specified mechanism in the specified session.

#### 20.138.1.4 pkcs11 digest update()

Continues a multiple-part digesting operation.

# 20.139 pkcs11 digest.h File Reference

PKCS11 Library Digest (SHA256) Handling.

```
#include "cryptoki.h"
```

# **Functions**

- CK\_RV pkcs11\_digest\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism)

  Initializes a message-digesting operation using the specified mechanism in the specified session.
- CK\_RV pkcs11\_digest (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Digest the specified data in a one-pass operation and return the resulting digest.

CK\_RV pkcs11\_digest\_update (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ul
 — PartLen)

Continues a multiple-part digesting operation.

CK\_RV pkcs11\_digest\_final (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Finishes a multiple-part digesting operation.

## 20.139.1 Detailed Description

PKCS11 Library Digest (SHA256) Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.139.2 Function Documentation

# 20.139.2.1 pkcs11\_digest()

```
CK_RV pkcs11_digest (

CK_SESSION_HANDLE hSession,

CK_BYTE_PTR pData,

CK_ULONG ulDataLen,

CK_BYTE_PTR pDigest,

CK_ULONG_PTR pulDigestLen )
```

Digest the specified data in a one-pass operation and return the resulting digest.

## 20.139.2.2 pkcs11\_digest\_final()

Finishes a multiple-part digesting operation.

## 20.139.2.3 pkcs11\_digest\_init()

Initializes a message-digesting operation using the specified mechanism in the specified session.

## 20.139.2.4 pkcs11\_digest\_update()

Continues a multiple-part digesting operation.

# 20.140 pkcs11 find.c File Reference

PKCS11 Library Object Find/Searching.

```
#include "cryptoauthlib.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_os.h"
#include "pkcs11_slot.h"
#include "pkcs11_session.h"
#include "pkcs11_find.h"
#include "pkcs11_tind.h"
```

## **Functions**

- CK\_RV pkcs11\_find\_init (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_find\_continue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE\_PTR phObject, CK\_ULONG ulMaxObjectCount, CK\_ULONG\_PTR pulObjectCount)
- CK RV pkcs11 find finish (CK SESSION HANDLE hSession)
- CK\_RV pkcs11\_find\_get\_attribute (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

## 20.140.1 Detailed Description

PKCS11 Library Object Find/Searching.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.141 pkcs11 find.h File Reference

PKCS11 Library Object Find/Searching.

```
#include "cryptoki.h"
#include "pkcs11_object.h"
```

#### **Functions**

- CK\_RV pkcs11\_find\_init (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_find\_continue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE\_PTR phObject, CK\_ULONG ulMaxObjectCount, CK\_ULONG\_PTR pulObjectCount)
- CK RV pkcs11 find finish (CK SESSION HANDLE hSession)
- CK\_RV pkcs11\_find\_get\_attribute (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

## 20.141.1 Detailed Description

PKCS11 Library Object Find/Searching.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.142 pkcs11 info.c File Reference

PKCS11 Library Information Functions.

```
#include "cryptoauthlib.h"
#include "pkcs11_config.h"
#include "pkcs11_init.h"
#include "pkcs11_slot.h"
#include "pkcs11_session.h"
#include "pkcs11_util.h"
#include <stdio.h>
```

## **Functions**

• CK\_RV pkcs11\_get\_lib\_info (CK\_INFO\_PTR pInfo)

Obtains general information about Cryptoki.

## **Variables**

- const char pkcs11\_lib\_manufacturer\_id [] = "Microchip Technology Inc"
- const char pkcs11 lib description [] = "Cryptoauthlib PKCS11 Interface"

## 20.142.1 Detailed Description

PKCS11 Library Information Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.143 pkcs11 info.h File Reference

PKCS11 Library Information Functions.

```
#include "cryptoki.h"
```

#### **Functions**

CK\_RV pkcs11\_get\_lib\_info (CK\_INFO\_PTR pInfo)

Obtains general information about Cryptoki.

## **Variables**

- const char pkcs11\_lib\_manufacturer\_id []
- const char pkcs11\_lib\_description []

## 20.143.1 Detailed Description

PKCS11 Library Information Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.144 pkcs11\_init.c File Reference

## PKCS11 Library Init/Deinit.

```
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_os.h"
#include "pkcs11_slot.h"
#include "pkcs11_object.h"
#include "pkcs11_session.h"
#include "cryptoauthlib.h"
```

## **Functions**

- pkcs11\_lib\_ctx\_ptr pkcs11\_get\_context (void)
  - Retrieve the current library context.
- CK\_RV pkcs11\_lock\_context (pkcs11\_lib\_ctx\_ptr pContext)
- CK\_RV pkcs11\_unlock\_context (pkcs11\_lib\_ctx\_ptr pContext)
- CK\_RV pkcs11\_init\_check (pkcs11\_lib\_ctx\_ptr \*ppContext, CK\_BBOOL lock)

Check if the library is initialized properly.

CK RV pkcs11 init (CK C INITIALIZE ARGS PTR pInitArgs)

Initializes the PKCS11 API Library for Cryptoauthlib.

CK\_RV pkcs11\_deinit (CK\_VOID\_PTR pReserved)

## 20.144.1 Detailed Description

PKCS11 Library Init/Deinit.

Copyright (c) 2017 Microchip Technology Inc. All rights reserved.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.145 pkcs11\_init.h File Reference

PKCS11 Library Initialization & Context.

```
#include "cryptoki.h"
#include "pkcs11_config.h"
```

#### **Data Structures**

struct \_pkcs11\_lib\_ctx

# **Typedefs**

- typedef struct \_pkcs11\_lib\_ctx pkcs11\_lib\_ctx
- typedef struct \_pkcs11\_lib\_ctx \* pkcs11\_lib\_ctx\_ptr

## **Functions**

• CK\_RV pkcs11\_init (CK\_C\_INITIALIZE\_ARGS\_PTR plnitArgs)

Initializes the PKCS11 API Library for Cryptoauthlib.

- CK\_RV pkcs11\_deinit (CK\_VOID\_PTR pReserved)
- CK\_RV pkcs11\_init\_check (pkcs11\_lib\_ctx\_ptr \*ppContext, CK\_BBOOL lock)

Check if the library is initialized properly.

• pkcs11\_lib\_ctx\_ptr pkcs11\_get\_context (void)

Retrieve the current library context.

- CK\_RV pkcs11\_lock\_context (pkcs11\_lib\_ctx\_ptr pContext)
- CK\_RV pkcs11\_unlock\_context (pkcs11\_lib\_ctx\_ptr pContext)

## 20.145.1 Detailed Description

PKCS11 Library Initialization & Context.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.145.2 Typedef Documentation

```
20.145.2.1 pkcs11_lib_ctx

typedef struct _pkcs11_lib_ctx pkcs11_lib_ctx

Library Context

20.145.2.2 pkcs11_lib_ctx_ptr

typedef struct _pkcs11_lib_ctx * pkcs11_lib_ctx_ptr
```

# 20.146 pkcs11\_key.c File Reference

PKCS11 Library Key Object Handling.

```
#include "cryptoauthlib.h"
#include "crypto/atca_crypto_sw_shal.h"
#include "pkcsll_config.h"
#include "pkcsll_debug.h"
#include "pkcsll_token.h"
#include "pkcsll_attrib.h"
#include "pkcsll_key.h"
#include "pkcsll_session.h"
#include "pkcsll_slot.h"
#include "pkcsll_util.h"
#include "pkcsll_os.h"
```

#### **Functions**

- CK\_RV pkcs11\_key\_write (CK\_VOID\_PTR pSession, CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR p

  Attribute)
- CK\_RV pkcs11\_key\_generate\_pair (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p

  Mechanism, CK\_ATTRIBUTE\_PTR pPublicKeyTemplate, CK\_ULONG ulPublicKeyAttributeCount,

  CK\_ATTRIBUTE\_PTR pPrivateKeyTemplate, CK\_ULONG ulPrivateKeyAttributeCount, CK\_OBJECT\_HANDLE\_PTR

  phPublicKey, CK\_OBJECT\_HANDLE\_PTR phPrivateKey)
- CK\_RV pkcs11\_key\_derive (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hBaseKey, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

#### **Variables**

- const pkcs11 attrib model pkcs11 key public attributes []
- const CK\_ULONG pkcs11\_key\_public\_attributes\_count = sizeof( pkcs11\_key\_public\_attributes ) / sizeof( pkcs11 key public attributes [0])
- const pkcs11\_attrib\_model pkcs11\_key\_ec\_public\_attributes []
- const pkcs11 attrib model pkcs11 key private attributes[]
- const CK\_ULONG pkcs11\_key\_private\_attributes\_count = sizeof( pkcs11\_key\_private\_attributes ) / sizeof( pkcs11 key private attributes [0])
- const pkcs11\_attrib\_model pkcs11\_key\_rsa\_private\_attributes []
- const pkcs11\_attrib\_model pkcs11\_key\_ec\_private\_attributes []
- const pkcs11\_attrib\_model pkcs11\_key\_secret\_attributes []
- const CK\_ULONG pkcs11\_key\_secret\_attributes\_count = sizeof( pkcs11\_key\_secret\_attributes ) / sizeof( pkcs11\_key\_secret\_attributes [0])

## 20.146.1 Detailed Description

PKCS11 Library Key Object Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.147 pkcs11 key.h File Reference

PKCS11 Library Object Handling.

```
#include "pkcs11_object.h"
```

#### **Functions**

- CK\_RV pkcs11\_key\_write (CK\_VOID\_PTR pSession, CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR p

  Attribute)
- CK\_RV pkcs11\_key\_generate\_pair (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p
   Mechanism, CK\_ATTRIBUTE\_PTR pPublicKeyTemplate, CK\_ULONG ulPublicKeyAttributeCount,
   CK\_ATTRIBUTE\_PTR pPrivateKeyTemplate, CK\_ULONG ulPrivateKeyAttributeCount, CK\_OBJECT\_HANDLE\_PTR
   phPublicKey, CK\_OBJECT\_HANDLE\_PTR phPrivateKey)
- CK\_RV pkcs11\_key\_derive (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hBaseKey, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

#### **Variables**

- const pkcs11\_attrib\_model pkcs11\_key\_public\_attributes []
- const CK\_ULONG pkcs11\_key\_public\_attributes\_count
- const pkcs11\_attrib\_model pkcs11\_key\_private\_attributes []
- · const CK ULONG pkcs11 key private attributes count
- const pkcs11 attrib model pkcs11 key secret attributes []
- const CK\_ULONG pkcs11\_key\_secret\_attributes\_count

## 20.147.1 Detailed Description

PKCS11 Library Object Handling.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.148 pkcs11 main.c File Reference

PKCS11 Basic library redirects based on the 2.40 specification http://docs.oasis-open. ← org/pkcs11/pkcs11-base/v2.40/os/pkcs11-base-v2.40-os.html.

```
#include "cryptoki.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_info.h"
#include "pkcs11_slot.h"
#include "pkcs11_session.h"
#include "pkcs11_session.h"
#include "pkcs11_token.h"
#include "pkcs11_find.h"
#include "pkcs11_object.h"
#include "pkcs11_signature.h"
#include "pkcs11_digest.h"
#include "pkcs11_digest.h"
#include "pkcs11_key.h"
```

#### **Functions**

• CK\_RV C\_Initialize (CK\_VOID\_PTR pInitArgs)

Initializes Cryptoki library NOTES: If plnitArgs is a non-NULL\_PTR is must dereference to a CK\_C\_INITIALIZE\_ARGS structure.

CK\_RV C\_Finalize (CK\_VOID\_PTR pReserved)

Clean up miscellaneous Cryptoki-associated resources.

• CK RV C GetInfo (CK INFO PTR pInfo)

Obtains general information about Cryptoki.

• CK\_RV C\_GetFunctionList (CK\_FUNCTION\_LIST\_PTR\_PTR ppFunctionList)

Obtains entry points of Cryptoki library functions.

CK\_RV C\_GetSlotList (CK\_BBOOL tokenPresent, CK\_SLOT\_ID\_PTR pSlotList, CK\_ULONG\_PTR pul
 — Count)

Obtains a list of slots in the system.

• CK\_RV C\_GetSlotInfo (CK\_SLOT\_ID slotID, CK\_SLOT\_INFO\_PTR pInfo)

Obtains information about a particular slot.

CK\_RV C\_GetTokenInfo (CK\_SLOT\_ID slotID, CK\_TOKEN\_INFO\_PTR pInfo)

Obtains information about a particular token.

• CK\_RV C\_GetMechanismList (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE\_PTR pMechanismList, CK\_ULONG\_PTR\_pulCount)

Obtains a list of mechanisms supported by a token (in a slot)

CK\_RV C\_GetMechanismInfo (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE type, CK\_MECHANISM\_INFO\_PTR plnfo)

Obtains information about a particular mechanism of a token (in a slot)

• CK\_RV C\_InitToken (CK\_SLOT\_ID slotID, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen, CK\_UTF8CHAR\_PTR pLabel)

Initializes a token (in a slot)

- CK\_RV C\_InitPIN (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)
   Initializes the normal user's PIN.
- CK\_RV C\_SetPIN (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pOldPin, CK\_ULONG ulOld ← Len, CK\_UTF8CHAR\_PTR pNewPin, CK\_ULONG ulNewLen)

Modifies the PIN of the current user.

CK\_RV C\_OpenSession (CK\_SLOT\_ID slotID, CK\_FLAGS flags, CK\_VOID\_PTR pApplication, CK\_NOTIFY notify, CK\_SESSION\_HANDLE\_PTR phSession)

Opens a connection between an application and a particular token or sets up an application callback for token insertion

• CK RV C CloseSession (CK SESSION HANDLE hSession)

Close the given session.

• CK RV C CloseAllSessions (CK SLOT ID slotID)

Close all open sessions.

CK\_RV C\_GetSessionInfo (CK\_SESSION\_HANDLE hSession, CK\_SESSION\_INFO\_PTR pInfo)

Retrieve information about the specified session.

 CK\_RV C\_GetOperationState (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pOperationState, CK\_ULONG\_PTR\_pulOperationStateLen)

Obtains the cryptographic operations state of a session.

 CK\_RV C\_SetOperationState (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pOperationState, CK\_ULONG ulOperationStateLen, CK\_OBJECT\_HANDLE hEncryptionKey, CK\_OBJECT\_HANDLE h← AuthenticationKey)

Sets the cryptographic operations state of a session.

 CK\_RV C\_Login (CK\_SESSION\_HANDLE hSession, CK\_USER\_TYPE userType, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)

Login on the token in the specified session.

• CK RV C Logout (CK SESSION HANDLE hSession)

Log out of the token in the specified session.

 CK\_RV C\_CreateObject (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phObject)

Create a new object on the token in the specified session using the given attribute template.

CK\_RV C\_CopyObject (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR
 pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phNewObject)

Create a copy of the object with the specified handle.

CK\_RV C\_DestroyObject (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)

Destroy the specified object.

CK\_RV C\_GetObjectSize (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ULONG\_PTR pulSize)

Obtains the size of an object in bytes.

• CK\_RV C\_GetAttributeValue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK ATTRIBUTE PTR pTemplate, CK ULONG ulCount)

Obtains an attribute value of an object.

 CK\_RV C\_SetAttributeValue (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)

Change or set the value of the specified attributes on the specified object.

 CK\_RV C\_FindObjectsInit (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG\_ulCount)

Initializes an object search in the specified session using the specified attribute template as search parameters.

 CK\_RV C\_FindObjects (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE\_PTR phObject, CK\_ULONG\_ulMaxObjectCount, CK\_ULONG\_PTR\_pulObjectCount)

Continue the search for objects in the specified session.

CK RV C FindObjectsFinal (CK SESSION HANDLE hSession)

Finishes an object search operation (and cleans up)

 CK\_RV C\_EncryptInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hObject)

Initializes an encryption operation using the specified mechanism and session.

• CK\_RV C\_Encrypt (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Perform a single operation encryption operation in the specified session.

CK\_RV C\_EncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ul
 — DataLen, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Continues a multiple-part encryption operation.

CK\_RV C\_EncryptFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedData, CK\_ULONG\_PTR pulEncryptedDataLen)

Finishes a multiple-part encryption operation.

 CK\_RV C\_DecryptInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hObject)

Initialize decryption using the specified object.

Perform a single operation decryption in the given session.

• CK\_RV C\_DecryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedData, CK ULONG ulEncryptedDataLen, CK BYTE PTR pData, CK ULONG PTR pDataLen)

Continues a multiple-part decryption operation.

• CK\_RV C\_DecryptFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG\_PTR p

DataLen)

Finishes a multiple-part decryption operation.

CK\_RV C\_DigestInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism)

Initializes a message-digesting operation using the specified mechanism in the specified session.

• CK\_RV C\_Digest (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Digest the specified data in a one-pass operation and return the resulting digest.

- CK\_RV C\_DigestUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

  Continues a multiple-part digesting operation.
- CK\_RV C\_DigestKey (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)

Update a running digest operation by digesting a secret key with the specified handle.

• CK\_RV C\_DigestFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pDigest, CK\_ULONG\_PTR pulDigestLen)

Finishes a multiple-part digesting operation.

 CK\_RV C\_SignInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initialize a signing operation using the specified key and mechanism.

 CK\_RV C\_Sign (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Sign the data in a single pass operation.

- CK\_RV C\_SignUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen) Continues a multiple-part signature operation.
- CK\_RV C\_SignFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Finishes a multiple-part signature operation.

 CK\_RV C\_SignRecoverInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a signature operation, where the data can be recovered from the signature.

CK\_RV C\_SignRecover (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulData
 — Len, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Signs single-part data, where the data can be recovered from the signature.

CK\_RV C\_VerifyInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation using the specified key and mechanism.

 CK\_RV C\_Verify (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Verifies a signature on single-part data.

- CK\_RV C\_VerifyUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

  Continues a multiple-part verification operation.
- CK\_RV C\_VerifyFinal (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG ul
   — SignatureLen)

Finishes a multiple-part verification operation.

 CK\_RV C\_VerifyRecoverInit (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation where the data is recovered from the signature.

• CK\_RV C\_VerifyRecover (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG ul → SignatureLen, CK\_BYTE\_PTR pData, CK\_ULONG\_PTR pulDataLen)

Verifies a signature on single-part data, where the data is recovered from the signature.

• CK\_RV C\_DigestEncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen, CK\_BYTE\_PTR pEncryptedPart, CK\_ULONG\_PTR pulEncryptedPartLen)

Continues simultaneous multiple-part digesting and encryption operations.

• CK\_RV C\_DecryptDigestUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen, CK\_BYTE\_PTR pDecryptedPart, CK\_ULONG\_PTR pulDecryptedPartLen)

Continues simultaneous multiple-part decryption and digesting operations.

• CK\_RV C\_SignEncryptUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ul ← PartLen, CK\_BYTE\_PTR pEncryptedPart, CK\_ULONG\_PTR pulEncryptedPartLen)

Continues simultaneous multiple-part signature and encryption operations.

• CK\_RV C\_DecryptVerifyUpdate (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pEncryptedPart, CK\_ULONG\_ulEncryptedPartLen, CK\_BYTE\_PTR pPart, CK\_ULONG\_PTR pulPartLen)

Continues simultaneous multiple-part decryption and verification operations.

• CK\_RV C\_GenerateKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Generates a secret key using the specified mechanism.

 CK\_RV C\_GenerateKeyPair (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_ATTRIBUTE\_PTR pPublicKeyTemplate, CK\_ULONG ulPublicKeyAttributeCount, CK\_ATTRIBUTE\_PTR pPrivateKeyTemplate, CK\_ULONG ulPrivateKeyAttributeCount, CK\_OBJECT\_HANDLE\_PTR phPublicKey, CK\_OBJECT\_HANDLE\_PTR phPrivateKey)

Generates a public-key/private-key pair using the specified mechanism.

• CK\_RV C\_WrapKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hWrappingKey, CK\_OBJECT\_HANDLE hKey, CK\_BYTE\_PTR pWrappedKey, CK\_ULONG\_PTR pul → WrappedKeyLen)

Wraps (encrypts) the specified key using the specified wrapping key and mechanism.

• CK\_RV C\_UnwrapKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hUnwrappingKey, CK\_BYTE\_PTR pWrappedKey, CK\_ULONG ulWrappedKey ← Len, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Unwraps (decrypts) the specified key using the specified unwrapping key.

• CK\_RV C\_DeriveKey (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR pMechanism, CK\_OBJECT\_HANDLE hBaseKey, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phKey)

Derive a key from the specified base key.

Mixes in additional seed material to the random number generator.

 CK\_RV C\_GenerateRandom (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pRandomData, CK\_ULONG\_ulRandomLen)

Generate the specified amount of random data.

• CK\_RV C\_GetFunctionStatus (CK\_SESSION\_HANDLE hSession)

Legacy function - see PKCS#11 v2.40.

• CK RV C CancelFunction (CK SESSION HANDLE hSession)

Legacy function.

CK\_RV C\_WaitForSlotEvent (CK\_FLAGS flags, CK\_SLOT\_ID\_PTR pSlot, CK\_VOID\_PTR pReserved)

Wait for a slot event (token insertion, removal, etc) on the specified slot to occur.

## 20.148.1 Detailed Description

PKCS11 Basic library redirects based on the 2.40 specification http://docs.oasis-open. ← org/pkcs11/pkcs11-base/v2.40/os/pkcs11-base-v2.40-os.html.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.149 pkcs11 mech.c File Reference

PKCS11 Library Mechanism Handling.

```
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_mech.h"
#include "pkcs11_slot.h"
#include "cryptoauthlib.h"
```

## **Data Structures**

struct \_pcks11\_mech\_table\_e

### **Macros**

- #define PCKS11\_MECH\_ECC508\_EC\_CAPABILITY (CKF\_EC\_F\_P | CKF\_EC\_NAMEDCURVE | CKF\_EC\_UNCOMPRESS)
- #define TABLE\_SIZE(x) sizeof(x) / sizeof(x[0])

## **Typedefs**

- typedef struct \_pcks11\_mech\_table\_e pcks11\_mech\_table\_e
- typedef struct \_pcks11\_mech\_table\_e \* pcks11\_mech\_table\_ptr

## **Functions**

- CK\_RV pkcs11\_mech\_get\_list (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE\_PTR pMechanismList, CK\_ULONG\_PTR\_pulCount)
- CK\_RV pkcs\_mech\_get\_info (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE type, CK\_MECHANISM\_INFO\_PTR plnfo)

# 20.149.1 Detailed Description

PKCS11 Library Mechanism Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.150 pkcs11\_mech.h File Reference

PKCS11 Library Mechanism Handling.

```
#include "cryptoki.h"
```

#### **Functions**

- CK\_RV pkcs11\_mech\_get\_list (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE\_PTR pMechanismList, CK\_ULONG\_PTR\_pulCount)
- CK\_RV pkcs\_mech\_get\_info (CK\_SLOT\_ID slotID, CK\_MECHANISM\_TYPE type, CK\_MECHANISM\_INFO\_PTR plnfo)

## 20.150.1 Detailed Description

PKCS11 Library Mechanism Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.151 pkcs11\_object.c File Reference

## PKCS11 Library Object Handling Base.

```
#include "cryptoauthlib.h"
#include "cryptoki.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_session.h"
#include "pkcs11_util.h"
#include "pkcs11_object.h"
#include "pkcs11_os.h"
#include "pkcs11_find.h"
#include "pkcs11_key.h"
#include "pkcs11_cert.h"
```

#### **Functions**

- CK\_RV pkcs11\_object\_alloc (pkcs11\_object\_ptr \*ppObject)
  - \*\*
- CK\_RV pkcs11\_object\_free (pkcs11\_object\_ptr pObject)
- CK\_RV pkcs11\_object\_check (pkcs11\_object\_ptr \*ppObject, CK\_OBJECT\_HANDLE hObject)
- CK RV pkcs11 object get handle (pkcs11 object ptr pObject, CK OBJECT HANDLE PTR phObject)
- CK RV pkcs11 object get name (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK RV pkcs11 object get class (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_destroyable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_size (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ULONG\_PTR\_pulSize)
- CK\_RV pkcs11\_object\_find (pkcs11\_object\_ptr \*ppObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_object\_create (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG\_ulCount, CK\_OBJECT\_HANDLE\_PTR\_phObject)

Create a new object on the token in the specified session using the given attribute template.

- CK\_RV pkcs11\_object\_destroy (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)
  - Destroy the specified object.
- CK RV pkcs11 object deinit (pkcs11 lib ctx ptr pContext)
- CK\_RV pkcs11\_object\_load\_handle\_info (pkcs11\_lib\_ctx\_ptr pContext)

#### **Variables**

- pkcs11\_object\_cache\_t pkcs11\_object\_cache [PKCS11\_MAX\_OBJECTS\_ALLOWED]
- const pkcs11\_attrib\_model pkcs11\_object\_monotonic\_attributes []
- const CK\_ULONG pkcs11\_object\_monotonic\_attributes\_count = sizeof( pkcs11\_object\_monotonic\_attributes
   ) / sizeof( pkcs11\_object\_monotonic\_attributes [0])

### 20.151.1 Detailed Description

PKCS11 Library Object Handling Base.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.152 pkcs11\_object.h File Reference

PKCS11 Library Object Handling.

```
#include "cryptoauthlib.h"
#include "cryptoki.h"
#include "pkcs11_config.h"
#include "pkcs11_attrib.h"
```

#### **Data Structures**

- struct pkcs11 object
- struct \_pkcs11\_object\_cache\_t

#### **Macros**

- #define PKCS11\_OBJECT\_FLAG\_DESTROYABLE 0x01
- #define PKCS11 OBJECT FLAG MODIFIABLE 0x02
- #define PKCS11 OBJECT FLAG DYNAMIC 0x04
- #define PKCS11 OBJECT FLAG SENSITIVE 0x08
- #define PKCS11 OBJECT FLAG TA TYPE 0x10
- #define PKCS11 OBJECT FLAG TRUST TYPE 0x20

# **Typedefs**

- typedef struct \_pkcs11\_object pkcs11\_object
- typedef struct pkcs11 object \* pkcs11 object ptr
- typedef struct \_pkcs11\_object\_cache\_t pkcs11\_object\_cache\_t

## **Functions**

- CK\_RV pkcs11\_object\_alloc (pkcs11\_object\_ptr \*ppObject)
  - \*\*
- CK\_RV pkcs11\_object\_free (pkcs11\_object\_ptr pObject)
- CK\_RV pkcs11\_object\_check (pkcs11\_object\_ptr \*ppObject, CK\_OBJECT\_HANDLE handle)
- CK\_RV pkcs11\_object\_find (pkcs11\_object\_ptr \*ppObject, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount)
- CK\_RV pkcs11\_object\_get\_class (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK RV pkcs11 object get name (CK VOID PTR pObject, CK ATTRIBUTE PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_destroyable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_object\_get\_size (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject, CK\_ULONG\_PTR pulSize)
- CK\_RV pkcs11\_object\_get\_handle (pkcs11\_object\_ptr pObject, CK\_OBJECT\_HANDLE\_PTR phObject)
- CK\_RV pkcs11\_object\_create (CK\_SESSION\_HANDLE hSession, CK\_ATTRIBUTE\_PTR pTemplate, CK\_ULONG ulCount, CK\_OBJECT\_HANDLE\_PTR phObject)

Create a new object on the token in the specified session using the given attribute template.

- CK\_RV pkcs11\_object\_destroy (CK\_SESSION\_HANDLE hSession, CK\_OBJECT\_HANDLE hObject)
   Destroy the specified object.
- CK\_RV pkcs11\_object\_deinit (pkcs11\_lib\_ctx\_ptr pContext)
- CK\_RV pkcs11\_object\_load\_handle\_info (pkcs11\_lib\_ctx\_ptr pContext)

#### **Variables**

- pkcs11 object cache t pkcs11 object cache []
- const pkcs11 attrib model pkcs11 object monotonic attributes []
- const CK\_ULONG pkcs11\_object\_monotonic\_attributes\_count

# 20.152.1 Detailed Description

PKCS11 Library Object Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.152.2 Macro Definition Documentation

## 20.152.2.1 PKCS11\_OBJECT\_FLAG\_DESTROYABLE

#define PKCS11\_OBJECT\_FLAG\_DESTROYABLE 0x01

# 20.152.2.2 PKCS11\_OBJECT\_FLAG\_DYNAMIC

#define PKCS11\_OBJECT\_FLAG\_DYNAMIC 0x04

# 20.152.2.3 PKCS11\_OBJECT\_FLAG\_MODIFIABLE

#define PKCS11\_OBJECT\_FLAG\_MODIFIABLE 0x02

# 20.152.2.4 PKCS11\_OBJECT\_FLAG\_SENSITIVE

#define PKCS11\_OBJECT\_FLAG\_SENSITIVE 0x08

# 20.152.2.5 PKCS11\_OBJECT\_FLAG\_TA\_TYPE

#define PKCS11\_OBJECT\_FLAG\_TA\_TYPE 0x10

## 20.152.2.6 PKCS11\_OBJECT\_FLAG\_TRUST\_TYPE

#define PKCS11\_OBJECT\_FLAG\_TRUST\_TYPE 0x20

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 914

## 20.152.3 Typedef Documentation

## 20.152.3.1 pkcs11\_object

```
typedef struct _pkcs11_object pkcs11_object
```

## 20.152.3.2 pkcs11\_object\_cache\_t

```
typedef struct _pkcs11_object_cache_t pkcs11_object_cache_t
```

#### 20.152.3.3 pkcs11\_object\_ptr

```
typedef struct _pkcs11_object * pkcs11_object_ptr
```

# 20.153 pkcs11\_os.c File Reference

PKCS11 Library Operating System Abstraction Functions.

```
#include "pkcs11_os.h"
#include "pkcs11_util.h"
```

## **Functions**

- CK\_RV pkcs11\_os\_create\_mutex (CK\_VOID\_PTR\_PTR ppMutex)

  Application callback for creating a mutex object.
- CK\_RV pkcs11\_os\_destroy\_mutex (CK\_VOID\_PTR pMutex)
- CK\_RV pkcs11\_os\_lock\_mutex (CK\_VOID\_PTR pMutex)
- CK\_RV pkcs11\_os\_unlock\_mutex (CK\_VOID\_PTR pMutex)

## 20.153.1 Detailed Description

PKCS11 Library Operating System Abstraction Functions.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.154 pkcs11\_os.h File Reference

PKCS11 Library Operating System Abstraction.

```
#include "cryptoki.h"
#include "cryptoauthlib.h"
```

#### **Macros**

- #define pkcs11\_os\_malloc hal\_malloc
- #define pkcs11\_os\_free hal\_free

## **Functions**

- CK\_RV pkcs11\_os\_create\_mutex (CK\_VOID\_PTR\_PTR ppMutex)
   Application callback for creating a mutex object.
- CK\_RV pkcs11\_os\_destroy\_mutex (CK\_VOID\_PTR pMutex)
- CK\_RV pkcs11\_os\_lock\_mutex (CK\_VOID\_PTR pMutex)
- CK\_RV pkcs11\_os\_unlock\_mutex (CK\_VOID\_PTR pMutex)

## 20.154.1 Detailed Description

PKCS11 Library Operating System Abstraction.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.154.2 Macro Definition Documentation

#### 20.154.2.1 pkcs11\_os\_free

```
#define pkcs11_os_free hal_free
```

### 20.154.2.2 pkcs11\_os\_malloc

#define pkcs11\_os\_malloc hal\_malloc

# 20.155 pkcs11 session.c File Reference

## PKCS11 Library Session Handling.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_session.h"
#include "pkcs11_token.h"
#include "pkcs11_init.h"
#include "pkcs11_slot.h"
#include "pkcs11_object.h"
#include "pkcs11_os.h"
#include "pkcs11_util.h"
```

#### **Functions**

- pkcs11\_session\_ctx\_ptr pkcs11\_get\_session\_context (CK\_SESSION\_HANDLE hSession)
- CK\_RV pkcs11\_session\_check (pkcs11\_session\_ctx\_ptr \*pSession, CK\_SESSION\_HANDLE hSession)
   Check if the session is initialized properly.
- CK\_RV pkcs11\_session\_open (CK\_SLOT\_ID slotID, CK\_FLAGS flags, CK\_VOID\_PTR pApplication, CK\_← NOTIFY notify, CK\_SESSION\_HANDLE\_PTR phSession)
- CK\_RV pkcs11\_session\_close (CK\_SESSION\_HANDLE hSession)
- CK\_RV pkcs11\_session\_closeall (CK\_SLOT\_ID slotID)

Close all sessions for a given slot - not actually all open sessions.

- CK\_RV pkcs11\_session\_get\_info (CK\_SESSION\_HANDLE hSession, CK\_SESSION\_INFO\_PTR plnfo)
   Obtains information about a particular session.
- CK\_RV pkcs11\_session\_login (CK\_SESSION\_HANDLE hSession, CK\_USER\_TYPE userType, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)
- CK\_RV pkcs11\_session\_logout (CK\_SESSION\_HANDLE hSession)

## 20.155.1 Detailed Description

PKCS11 Library Session Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.156 pkcs11\_session.h File Reference

PKCS11 Library Session Management & Context.

```
#include "cryptoki.h"
#include "pkcs11_config.h"
```

#### **Data Structures**

struct \_pkcs11\_session\_ctx

## **Typedefs**

- typedef struct \_pkcs11\_session\_ctx pkcs11\_session\_ctx
- typedef struct \_pkcs11\_session\_ctx \* pkcs11\_session\_ctx\_ptr

#### **Functions**

- CK\_RV pkcs11\_session\_check (pkcs11\_session\_ctx\_ptr \*pSession, CK\_SESSION\_HANDLE hSession)

  Check if the session is initialized properly.
- CK\_RV pkcs11\_session\_get\_info (CK\_SESSION\_HANDLE hSession, CK\_SESSION\_INFO\_PTR plnfo)

  Obtains information about a particular session.
- CK\_RV pkcs11\_session\_open (CK\_SLOT\_ID slotID, CK\_FLAGS flags, CK\_VOID\_PTR pApplication, CK\_← NOTIFY notify, CK\_SESSION\_HANDLE\_PTR phSession)
- CK\_RV pkcs11\_session\_close (CK\_SESSION\_HANDLE hSession)
- CK\_RV pkcs11\_session\_closeall (CK\_SLOT\_ID slotID)

Close all sessions for a given slot - not actually all open sessions.

- CK\_RV pkcs11\_session\_login (CK\_SESSION\_HANDLE hSession, CK\_USER\_TYPE userType, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen)
- CK RV pkcs11 session logout (CK SESSION HANDLE hSession)
- CK\_RV pkcs11\_session\_authorize (pkcs11\_session\_ctx\_ptr pSession, CK\_VOID\_PTR pObject)

# 20.156.1 Detailed Description

PKCS11 Library Session Management & Context.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.156.2 Typedef Documentation

```
20.156.2.1 pkcs11_session_ctx
```

typedef struct \_pkcs11\_session\_ctx pkcs11\_session\_ctx

Session Context

#### 20.156.2.2 pkcs11\_session\_ctx\_ptr

typedef struct \_pkcs11\_session\_ctx \* pkcs11\_session\_ctx\_ptr

#### 20.156.3 Function Documentation

#### 20.156.3.1 pkcs11\_session\_authorize()

# 20.157 pkcs11\_signature.c File Reference

#### PKCS11 Library Sign/Verify Handling.

```
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_init.h"
#include "pkcs11_signature.h"
#include "pkcs11_object.h"
#include "pkcs11_session.h"
#include "pkcs11_util.h"
#include "cryptoauthlib.h"
#include "atcacert/atcacert_der.h"
```

## **Functions**

• CK\_RV pkcs11\_signature\_sign\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p← Mechanism, CK\_OBJECT\_HANDLE hKey)

Initialize a signing operation using the specified key and mechanism.

• CK\_RV pkcs11\_signature\_sign (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Sign the data in a single pass operation.

• CK\_RV pkcs11\_signature\_sign\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

Continues a multiple-part signature operation.

• CK\_RV pkcs11\_signature\_sign\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Finishes a multiple-part signature operation.

• CK\_RV pkcs11\_signature\_verify\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p↔ Mechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation using the specified key and mechanism.

CK\_RV pkcs11\_signature\_verify (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Verifies a signature on single-part data.

• CK\_RV pkcs11\_signature\_verify\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG\_ulPartLen)

Continues a multiple-part verification operation.

 CK\_RV pkcs11\_signature\_verify\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_ulSignatureLen)

Finishes a multiple-part verification operation.

## 20.157.1 Detailed Description

PKCS11 Library Sign/Verify Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.158 pkcs11 signature.h File Reference

PKCS11 Library Sign/Verify Handling.

#include "cryptoki.h"

#### **Functions**

CK\_RV pkcs11\_signature\_sign\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p
 — Mechanism, CK\_OBJECT\_HANDLE hKey)

Initialize a signing operation using the specified key and mechanism.

• CK\_RV pkcs11\_signature\_sign (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Sign the data in a single pass operation.

• CK\_RV pkcs11\_signature\_sign\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

Continues a multiple-part signature operation.

 CK\_RV pkcs11\_signature\_sign\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG\_PTR pulSignatureLen)

Finishes a multiple-part signature operation.

CK\_RV pkcs11\_signature\_verify\_init (CK\_SESSION\_HANDLE hSession, CK\_MECHANISM\_PTR p
 — Mechanism, CK\_OBJECT\_HANDLE hKey)

Initializes a verification operation using the specified key and mechanism.

CK\_RV pkcs11\_signature\_verify (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pData, CK\_ULONG ulDataLen, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Verifies a signature on single-part data.

 CK\_RV pkcs11\_signature\_verify\_continue (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pPart, CK\_ULONG ulPartLen)

Continues a multiple-part verification operation.

 CK\_RV pkcs11\_signature\_verify\_finish (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pSignature, CK\_ULONG ulSignatureLen)

Finishes a multiple-part verification operation.

## 20.158.1 Detailed Description

PKCS11 Library Sign/Verify Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.159 pkcs11 slot.c File Reference

PKCS11 Library Slot Handling.

```
#include "cryptoauthlib.h"
#include "pkcsl1_config.h"
#include "pkcsl1_debug.h"
#include "pkcsl1_init.h"
#include "pkcsl1_slot.h"
#include "pkcsl1_info.h"
#include "pkcsl1_util.h"
#include "pkcsl1_object.h"
#include "pkcsl1_os.h"
#include <stdio.h>
```

#### **Functions**

- pkcs11\_slot\_ctx\_ptr pkcs11\_slot\_get\_context (pkcs11\_lib\_ctx\_ptr lib\_ctx, CK\_SLOT\_ID slotID)
   Retrieve the current slot context.
- CK VOID PTR pkcs11 slot initslots (CK ULONG pulCount)
- CK RV pkcs11 slot config (CK SLOT ID slotID)
- CK\_RV pkcs11\_slot\_init (CK\_SLOT\_ID slotID)
- CK\_RV pkcs11\_slot\_get\_list (CK\_BBOOL tokenPresent, CK\_SLOT\_ID\_PTR pSlotList, CK\_ULONG\_PTR pulCount)
- CK\_RV pkcs11\_slot\_get\_info (CK\_SLOT\_ID slotID, CK\_SLOT\_INFO\_PTR plnfo)

Obtains information about a particular slot.

## 20.159.1 Detailed Description

PKCS11 Library Slot Handling.

The nomenclature here can lead to some confusion - the pkcs11 slot is not the same as a device slot. So for example each slot defined here is a specific device (most systems would have only one). The "slots" as defined by the device specification would be enumerated seperately as related to specific supported mechanisms as cryptographic "objects".

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.160 pkcs11\_slot.h File Reference

PKCS11 Library Slot Handling & Context.

```
#include "pkcs11_init.h"
#include "cryptoauthlib.h"
```

## **Data Structures**

• struct \_pkcs11\_slot\_ctx

# **Typedefs**

- typedef struct \_pkcs11\_slot\_ctx pkcs11\_slot\_ctx
- typedef struct \_pkcs11\_slot\_ctx \* pkcs11\_slot\_ctx\_ptr

## **Functions**

- CK\_RV pkcs11\_slot\_init (CK\_SLOT\_ID slotID)
- CK\_RV pkcs11\_slot\_config (CK\_SLOT\_ID slotID)
- CK\_VOID\_PTR pkcs11\_slot\_initslots (CK\_ULONG pulCount)
- pkcs11\_slot\_ctx\_ptr pkcs11\_slot\_get\_context (pkcs11\_lib\_ctx\_ptr lib\_ctx, CK\_SLOT\_lD slotID)

Retrieve the current slot context.

- CK\_RV pkcs11\_slot\_get\_list (CK\_BBOOL tokenPresent, CK\_SLOT\_ID\_PTR pSlotList, CK\_ULONG\_PTR pulCount)
- CK\_RV pkcs11\_slot\_get\_info (CK\_SLOT\_ID slotID, CK\_SLOT\_INFO\_PTR plnfo)

Obtains information about a particular slot.

## 20.160.1 Detailed Description

PKCS11 Library Slot Handling & Context.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.160.2 Typedef Documentation

```
20.160.2.1 pkcs11_slot_ctx
```

typedef struct \_pkcs11\_slot\_ctx pkcs11\_slot\_ctx

Slot Context

## 20.160.2.2 pkcs11\_slot\_ctx\_ptr

typedef struct \_pkcs11\_slot\_ctx \* pkcs11\_slot\_ctx\_ptr

# 20.161 pkcs11 token.c File Reference

#### PKCS11 Library Token Handling.

```
#include "cryptoauthlib.h"
#include "pkcs11_config.h"
#include "pkcs11_debug.h"
#include "pkcs11_token.h"
#include "pkcs11_slot.h"
#include "pkcs11_info.h"
#include "pkcs11_util.h"
#include "pkcs11_object.h"
#include "pkcs11_key.h"
#include "pkcs11_cert.h"
#include "pkcs11_session.h"
#include <stdio.h>
```

#### **Functions**

- CK\_RV pkcs11\_token\_init (CK\_SLOT\_ID slotID, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen, CK\_UTF8CHAR\_PTR pLabel)
- CK\_RV pkcs11\_token\_get\_access\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_writable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_storage (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_info (CK\_SLOT\_ID slotID, CK\_TOKEN\_INFO\_PTR pInfo)

Obtains information about a particular token.

 CK\_RV pkcs11\_token\_random (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pRandomData, CK\_ULONG ulRandomLen)

Generate the specified amount of random data.

- CK\_RV pkcs11\_token\_convert\_pin\_to\_key (const CK\_UTF8CHAR\_PTR pPin, const CK\_ULONG ulPinLen, const CK\_UTF8CHAR\_PTR pSalt, const CK\_ULONG ulSaltLen, CK\_BYTE\_PTR pKey, CK\_ULONG ulKey Len)
- CK\_RV pkcs11\_token\_set\_pin (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pOldPin, CK\_ULONG ulOldLen, CK\_UTF8CHAR\_PTR pNewPin, CK\_ULONG ulNewLen)

## 20.161.1 Detailed Description

PKCS11 Library Token Handling.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.162 pkcs11 token.h File Reference

PKCS11 Library Token Management & Context.

```
#include "pkcs11_init.h"
```

#### **Functions**

- CK\_RV pkcs11\_token\_init (CK\_SLOT\_ID slotID, CK\_UTF8CHAR\_PTR pPin, CK\_ULONG ulPinLen, CK\_UTF8CHAR\_PTR pLabel)
- CK\_RV pkcs11\_token\_get\_access\_type (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_writable (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_storage (CK\_VOID\_PTR pObject, CK\_ATTRIBUTE\_PTR pAttribute)
- CK\_RV pkcs11\_token\_get\_info (CK\_SLOT\_ID slotID, CK\_TOKEN\_INFO\_PTR plnfo)

Obtains information about a particular token.

- CK\_RV pkcs11\_token\_convert\_pin\_to\_key (const CK\_UTF8CHAR\_PTR pPin, const CK\_ULONG ulPinLen, const CK\_UTF8CHAR\_PTR pSalt, const CK\_ULONG ulSaltLen, CK\_BYTE\_PTR pKey, CK\_ULONG ulKey← Len)
- CK\_RV pkcs11\_token\_random (CK\_SESSION\_HANDLE hSession, CK\_BYTE\_PTR pRandomData, CK\_ULONG ulRandomLen)

Generate the specified amount of random data.

• CK\_RV pkcs11\_token\_set\_pin (CK\_SESSION\_HANDLE hSession, CK\_UTF8CHAR\_PTR pOldPin, CK\_ULONG ulOldLen, CK\_UTF8CHAR\_PTR pNewPin, CK\_ULONG ulNewLen)

## 20.162.1 Detailed Description

PKCS11 Library Token Management & Context.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.163 pkcs11 util.c File Reference

PKCS11 Library Utility Functions.

```
#include "pkcs11_util.h"
```

#### **Functions**

- void pkcs11\_util\_escape\_string (CK\_UTF8CHAR\_PTR buf, CK\_ULONG buf\_len)
- CK\_RV pkcs11\_util\_convert\_rv (ATCA\_STATUS status)
- int pkcs11\_util\_memset (void \*dest, size\_t destsz, int ch, size\_t count)

## 20.163.1 Detailed Description

PKCS11 Library Utility Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 924

# 20.164 pkcs11\_util.h File Reference

PKCS11 Library Utilities.

```
#include "pkcs11_config.h"
#include "cryptoki.h"
#include "cryptoauthlib.h"
```

#### **Macros**

#define PKCS11\_UTIL\_ARRAY\_SIZE(x) sizeof(x) / sizeof(x[0])

## **Functions**

- void pkcs11\_util\_escape\_string (CK\_UTF8CHAR\_PTR buf, CK\_ULONG buf\_len)
- CK\_RV pkcs11\_util\_convert\_rv (ATCA\_STATUS status)
- int pkcs11\_util\_memset (void \*dest, size\_t destsz, int ch, size\_t count)

# 20.164.1 Detailed Description

PKCS11 Library Utilities.

## Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

## 20.164.2 Macro Definition Documentation

## 20.164.2.1 PKCS11\_UTIL\_ARRAY\_SIZE

# 20.165 pkcs11f.h File Reference

# 20.166 pkcs11t.h File Reference

#### **Data Structures**

- struct CK\_VERSION
- struct CK\_INFO
- struct CK SLOT INFO
- struct CK TOKEN INFO
- · struct CK SESSION INFO
- struct CK\_ATTRIBUTE
- struct CK DATE
- struct CK\_MECHANISM
- struct CK MECHANISM INFO
- struct CK\_C\_INITIALIZE\_ARGS
- struct CK\_RSA\_PKCS\_OAEP\_PARAMS
- struct CK\_RSA\_PKCS\_PSS\_PARAMS
- struct CK\_ECDH1\_DERIVE\_PARAMS
- struct CK\_ECDH2\_DERIVE\_PARAMS
- struct CK\_ECMQV\_DERIVE\_PARAMS
- struct CK X9 42 DH1 DERIVE PARAMS
- struct CK X9 42 DH2 DERIVE PARAMS
- struct CK\_X9\_42\_MQV\_DERIVE\_PARAMS
- struct CK\_KEA\_DERIVE\_PARAMS
- struct CK\_RC2\_CBC\_PARAMS
- struct CK RC2 MAC GENERAL PARAMS
- struct CK\_RC5\_PARAMS
- struct CK\_RC5\_CBC\_PARAMS
- struct CK\_RC5\_MAC\_GENERAL\_PARAMS
- struct CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS
- struct CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS
- struct CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS
- struct CK\_SKIPJACK\_RELAYX\_PARAMS
- struct CK\_PBE\_PARAMS
- struct CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS
- struct CK\_SSL3\_RANDOM\_DATA
- struct CK SSL3 MASTER KEY DERIVE PARAMS
- struct CK\_SSL3\_KEY\_MAT\_OUT
- struct CK\_SSL3\_KEY\_MAT\_PARAMS
- struct CK\_TLS\_PRF\_PARAMS
- struct CK\_WTLS\_RANDOM\_DATA
- struct CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS
- struct CK WTLS PRF PARAMS
- · struct CK WTLS KEY MAT OUT
- struct CK\_WTLS\_KEY\_MAT\_PARAMS
- struct CK\_CMS\_SIG\_PARAMS
- struct CK\_KEY\_DERIVATION\_STRING\_DATA
- struct CK\_PKCS5\_PBKD2\_PARAMS
- struct CK PKCS5 PBKD2 PARAMS2
- struct CK OTP PARAM
- struct CK OTP PARAMS
- struct CK\_OTP\_SIGNATURE\_INFO

- struct CK\_KIP\_PARAMS
- struct CK\_AES\_CTR\_PARAMS
- struct CK\_GCM\_PARAMS
- struct CK CCM PARAMS
- struct CK AES GCM PARAMS
- struct CK\_AES\_CCM\_PARAMS
- struct CK CAMELLIA CTR PARAMS
- struct CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS
- struct CK\_ARIA\_CBC\_ENCRYPT\_DATA PARAMS
- struct CK DSA PARAMETER GEN PARAM
- struct CK ECDH AES KEY WRAP PARAMS
- struct CK RSA AES KEY WRAP PARAMS
- struct CK TLS12 MASTER KEY DERIVE PARAMS
- struct CK TLS12 KEY MAT PARAMS
- struct CK\_TLS\_KDF\_PARAMS
- struct CK TLS MAC PARAMS
- struct CK GOSTR3410 DERIVE PARAMS
- struct CK GOSTR3410 KEY WRAP PARAMS
- struct CK SEED CBC ENCRYPT DATA PARAMS

#### **Macros**

- #define CRYPTOKI\_VERSION\_MAJOR 2
- #define CRYPTOKI VERSION MINOR 40
- #define CRYPTOKI\_VERSION\_AMENDMENT 0
- #define CK TRUE 1
- #define CK FALSE 0
- #define FALSE CK FALSE
- #define TRUE CK TRUE
- #define CK\_UNAVAILABLE\_INFORMATION (~0UL)
- #define CK EFFECTIVELY INFINITE 0UL
- #define CK\_INVALID\_HANDLE OUL
- #define CKN\_SURRENDER 0UL
- #define CKN\_OTP\_CHANGED 1UL
- #define CKF TOKEN PRESENT 0x00000001UL /\* a token is there \*/
- #define CKF REMOVABLE DEVICE 0x00000002UL /\* removable devices\*/
- #define CKF HW SLOT 0x00000004UL /\* hardware slot \*/
- #define CKF RNG 0x0000001UL /\* has random # generator \*/
- #define CKF WRITE PROTECTED 0x00000002UL /\* token is write-protected \*/
- #define CKF LOGIN REQUIRED 0x00000004UL /\* user must login \*/
- #define CKF USER PIN INITIALIZED 0x00000008UL /\* normal user's PIN is set \*/
- #define CKF\_RESTORE\_KEY\_NOT\_NEEDED 0x00000020UL
- #define CKF\_CLOCK\_ON\_TOKEN 0x00000040UL
- #define CKF\_PROTECTED\_AUTHENTICATION\_PATH 0x00000100UL
- #define CKF\_DUAL\_CRYPTO\_OPERATIONS 0x00000200UL
- #define CKF TOKEN INITIALIZED 0x00000400UL
- #define CKF SECONDARY AUTHENTICATION 0x00000800UL
- #define CKF\_USER\_PIN\_COUNT\_LOW 0x00010000UL
- #define CKF\_USER\_PIN\_FINAL\_TRY 0x00020000UL
- #define CKF\_USER\_PIN\_LOCKED 0x00040000UL
- #define CKF\_USER\_PIN\_TO\_BE\_CHANGED 0x00080000UL
- #define CKF SO PIN COUNT LOW 0x00100000UL
- #define CKF SO PIN FINAL TRY 0x00200000UL
- #define CKF SO PIN LOCKED 0x00400000UL

- #define CKF\_SO\_PIN\_TO\_BE\_CHANGED 0x00800000UL
- #define CKF\_ERROR\_STATE 0x01000000UL
- #define CKU\_SO 0UL
- #define CKU USER 1UL
- #define CKU CONTEXT SPECIFIC 2UL
- #define CKS\_RO\_PUBLIC\_SESSION 0UL
- #define CKS RO USER FUNCTIONS 1UL
- #define CKS\_RW\_PUBLIC\_SESSION 2UL
- #define CKS\_RW\_USER\_FUNCTIONS 3UL
- #define CKS RW SO FUNCTIONS 4UL
- #define CKF RW SESSION 0x00000002UL /\* session is r/w \*/
- #define CKF\_SERIAL\_SESSION 0x00000004UL /\* no parallel \*/
- #define CKO DATA 0x00000000UL
- #define CKO CERTIFICATE 0x00000001UL
- #define CKO\_PUBLIC\_KEY 0x00000002UL
- #define CKO PRIVATE KEY 0x00000003UL
- #define CKO SECRET KEY 0x00000004UL
- #define CKO HW FEATURE 0x00000005UL
- #define CKO DOMAIN PARAMETERS 0x00000006UL
- #define CKO\_MECHANISM 0x00000007UL
- #define CKO\_OTP\_KEY 0x00000008UL
- #define CKO VENDOR DEFINED 0x80000000UL
- #define CKH MONOTONIC COUNTER 0x00000001UL
- #define CKH\_CLOCK 0x00000002UL
- #define CKH USER INTERFACE 0x00000003UL
- #define CKH\_VENDOR\_DEFINED 0x80000000UL
- #define CKK RSA 0x0000000UL
- #define CKK DSA 0x0000001UL
- #define CKK DH 0x00000002UL
- #define CKK ECDSA 0x00000003UL /\* Deprecated \*/
- #define CKK EC 0x00000003UL
- #define CKK X9 42 DH 0x00000004UL
- #define CKK\_KEA 0x00000005UL
- #define CKK GENERIC SECRET 0x00000010UL
- #define CKK RC2 0x00000011UL
- #define CKK RC4 0x00000012UL
- #define CKK DES 0x00000013UL
- #define CKK DES2 0x00000014UL
- #define CKK\_DES3 0x00000015UL
- #define CKK CAST 0x00000016UL
- #define CKK CAST3 0x00000017UL
- #define CKK\_CAST5 0x00000018UL /\* Deprecated \*/
- #define CKK\_CAST128 0x00000018UL
- #define CKK\_RC5 0x00000019UL
- #define CKK IDEA 0x0000001AUL
- #define CKK SKIPJACK 0x0000001BUL
- #define CKK BATON 0x0000001CUL
- #define CKK JUNIPER 0x0000001DUL
- #define CKK CDMF 0x0000001EUL
- #define CKK\_AES 0x0000001FUL
- #define CKK BLOWFISH 0x00000020UL
- #define CKK\_TWOFISH 0x00000021UL
- #define CKK SECURID 0x00000022UL
- #define CKK HOTP 0x00000023UL
- #define CKK ACTI 0x00000024UL

- #define CKK CAMELLIA 0x00000025UL
- #define CKK ARIA 0x00000026UL
- #define CKK\_MD5\_HMAC 0x00000027UL
- #define CKK SHA 1 HMAC 0x00000028UL
- #define CKK RIPEMD128 HMAC 0x00000029UL
- #define CKK RIPEMD160 HMAC 0x0000002AUL
- #define CKK SHA256 HMAC 0x0000002BUL
- #define CKK\_SHA384\_HMAC 0x0000002CUL
- #define CKK SHA512 HMAC 0x0000002DUL
- #define CKK SHA224 HMAC 0x0000002EUL
- #define CKK SEED 0x0000002FUL
- #define CKK GOSTR3410 0x00000030UL
- #define CKK GOSTR3411 0x00000031UL
- #define CKK GOST28147 0x00000032UL
- #define CKK\_VENDOR\_DEFINED 0x80000000UL
- #define CK CERTIFICATE CATEGORY UNSPECIFIED 0UL
- #define CK CERTIFICATE CATEGORY TOKEN USER 1UL
- #define CK CERTIFICATE CATEGORY AUTHORITY 2UL
- #define CK CERTIFICATE CATEGORY OTHER ENTITY 3UL
- #define CK\_SECURITY\_DOMAIN\_UNSPECIFIED 0UL
- #define CK\_SECURITY\_DOMAIN\_MANUFACTURER 1UL
- #define CK SECURITY DOMAIN OPERATOR 2UL
- #define CK SECURITY DOMAIN THIRD PARTY 3UL
- #define CKC\_X\_509 0x00000000UL
- #define CKC X 509 ATTR CERT 0x00000001UL
- #define CKC\_WTLS 0x00000002UL
- #define CKC VENDOR DEFINED 0x80000000UL
- #define CKC OPENPGP (CKC VENDOR DEFINED | 0x00504750)
- #define CKF ARRAY ATTRIBUTE 0x40000000UL
- #define CK\_OTP\_FORMAT\_DECIMAL 0UL
- #define CK\_OTP\_FORMAT\_HEXADECIMAL 1UL
- #define CK OTP FORMAT ALPHANUMERIC 2UL
- #define CK\_OTP\_FORMAT\_BINARY 3UL
- #define CK\_OTP\_PARAM\_IGNORED 0UL
- #define CK\_OTP\_PARAM\_OPTIONAL 1UL
- #define CK\_OTP\_PARAM\_MANDATORY 2UL
- #define CKA\_CLASS 0x00000000UL
- #define CKA\_TOKEN 0x00000001UL
- #define CKA PRIVATE 0x00000002UL
- #define CKA LABEL 0x00000003UL
- #define CKA APPLICATION 0x00000010UL
- #define CKA\_VALUE 0x00000011UL
- #define CKA\_OBJECT\_ID 0x00000012UL
- #define CKA\_CERTIFICATE\_TYPE 0x00000080UL
- #define CKA ISSUER 0x00000081UL
- #define CKA SERIAL NUMBER 0x00000082UL
- #define CKA AC ISSUER 0x00000083UL
- #define CKA OWNER 0x00000084UL
- #define CKA ATTR TYPES 0x00000085UL
- #define CKA\_TRUSTED 0x00000086UL
- #define CKA CERTIFICATE CATEGORY 0x00000087UL
- #define CKA\_JAVA\_MIDP\_SECURITY\_DOMAIN 0x00000088UL
- #define CKA URL 0x00000089UL
- #define CKA HASH OF SUBJECT PUBLIC KEY 0x0000008AUL
- #define CKA HASH OF ISSUER PUBLIC KEY 0x0000008BUL

- #define CKA NAME HASH ALGORITHM 0x0000008CUL
- #define CKA CHECK VALUE 0x00000090UL
- #define CKA\_KEY\_TYPE 0x00000100UL
- #define CKA SUBJECT 0x00000101UL
- #define CKA ID 0x00000102UL
- #define CKA SENSITIVE 0x00000103UL
- #define CKA ENCRYPT 0x00000104UL
- #define CKA\_DECRYPT 0x00000105UL
- #define CKA WRAP 0x00000106UL
- #define CKA UNWRAP 0x00000107UL
- #define CKA SIGN 0x00000108UL
- #define CKA SIGN RECOVER 0x00000109UL
- #define CKA VERIFY 0x0000010AUL
- #define CKA VERIFY RECOVER 0x0000010BUL
- #define CKA\_DERIVE 0x0000010CUL
- #define CKA START DATE 0x00000110UL
- #define CKA END DATE 0x00000111UL
- #define CKA MODULUS 0x00000120UL
- #define CKA MODULUS BITS 0x00000121UL
- #define CKA PUBLIC EXPONENT 0x00000122UL
- #define CKA\_PRIVATE\_EXPONENT 0x00000123UL
- #define CKA PRIME 1 0x00000124UL
- #define CKA PRIME 2 0x00000125UL
- #define CKA\_EXPONENT\_1 0x00000126UL
- #define CKA EXPONENT 2 0x00000127UL
- #define CKA\_COEFFICIENT 0x00000128UL
- #define CKA PUBLIC KEY INFO 0x00000129UL
- #define CKA PRIME 0x00000130UL
- #define CKA SUBPRIME 0x00000131UL
- #define CKA BASE 0x00000132UL
- #define CKA PRIME BITS 0x00000133UL
- #define CKA SUBPRIME BITS 0x00000134UL
- #define CKA\_SUB\_PRIME\_BITS CKA\_SUBPRIME\_BITS
- #define CKA VALUE BITS 0x00000160UL
- #define CKA\_VALUE\_LEN 0x00000161UL
- #define CKA\_EXTRACTABLE 0x00000162UL
- #define CKA\_LOCAL 0x00000163UL
- #define CKA NEVER EXTRACTABLE 0x00000164UL
- #define CKA ALWAYS SENSITIVE 0x00000165UL
- #define CKA KEY GEN MECHANISM 0x00000166UL
- #define CKA MODIFIABLE 0x00000170UL
- #define CKA COPYABLE 0x00000171UL
- #define CKA\_DESTROYABLE 0x00000172UL
- #define CKA\_ECDSA\_PARAMS 0x00000180UL /\* Deprecated \*/
- #define CKA EC PARAMS 0x00000180UL
- #define CKA EC POINT 0x00000181UL
- #define CKA SECONDARY AUTH 0x00000200UL /\* Deprecated \*/
- #define CKA\_AUTH\_PIN\_FLAGS 0x00000201UL /\* Deprecated \*/
- #define CKA\_ALWAYS\_AUTHENTICATE 0x00000202UL
- #define CKA\_WRAP\_WITH\_TRUSTED 0x00000210UL
- #define CKA WRAP TEMPLATE (CKF ARRAY ATTRIBUTE | 0x00000211UL)
- #define CKA\_UNWRAP\_TEMPLATE (CKF\_ARRAY\_ATTRIBUTE | 0x00000212UL)
- #define CKA DERIVE TEMPLATE (CKF ARRAY ATTRIBUTE | 0x00000213UL)
- #define CKA OTP FORMAT 0x00000220UL
- #define CKA OTP LENGTH 0x00000221UL

- #define CKA OTP TIME INTERVAL 0x00000222UL
- #define CKA\_OTP\_USER\_FRIENDLY\_MODE 0x00000223UL
- #define CKA OTP\_CHALLENGE\_REQUIREMENT 0x00000224UL
- #define CKA OTP TIME REQUIREMENT 0x00000225UL
- #define CKA OTP COUNTER REQUIREMENT 0x00000226UL
- #define CKA OTP PIN REQUIREMENT 0x00000227UL
- #define CKA OTP COUNTER 0x0000022EUL
- #define CKA\_OTP\_TIME 0x0000022FUL
- #define CKA\_OTP\_USER\_IDENTIFIER 0x0000022AUL
- #define CKA OTP SERVICE IDENTIFIER 0x0000022BUL
- #define CKA OTP SERVICE LOGO 0x0000022CUL
- #define CKA OTP SERVICE LOGO TYPE 0x0000022DUL
- #define CKA GOSTR3410 PARAMS 0x00000250UL
- #define CKA GOSTR3411 PARAMS 0x00000251UL
- #define CKA\_GOST28147\_PARAMS 0x00000252UL
- #define CKA HW FEATURE TYPE 0x00000300UL
- #define CKA RESET ON INIT 0x00000301UL
- #define CKA HAS RESET 0x00000302UL
- #define CKA PIXEL X 0x00000400UL
- #define CKA PIXEL Y 0x00000401UL
- #define CKA RESOLUTION 0x00000402UL
- #define CKA CHAR ROWS 0x00000403UL
- #define CKA CHAR COLUMNS 0x00000404UL
- #define CKA COLOR 0x00000405UL
- #define CKA BITS PER PIXEL 0x00000406UL
- #define CKA\_CHAR\_SETS 0x00000480UL
- #define CKA ENCODING METHODS 0x00000481UL
- #define CKA MIME TYPES 0x00000482UL
- #define CKA MECHANISM TYPE 0x00000500UL
- #define CKA REQUIRED CMS ATTRIBUTES 0x00000501UL
- #define CKA DEFAULT CMS ATTRIBUTES 0x00000502UL
- #define CKA SUPPORTED CMS ATTRIBUTES 0x00000503UL
- #define CKA\_ALLOWED\_MECHANISMS (CKF\_ARRAY\_ATTRIBUTE | 0x00000600UL)
- #define CKA\_VENDOR\_DEFINED 0x80000000UL
- #define CKM\_RSA\_PKCS\_KEY\_PAIR\_GEN 0x00000000UL
- #define CKM RSA PKCS 0x00000001UL
- #define CKM RSA 9796 0x00000002UL
- #define CKM RSA X 509 0x00000003UL
- #define CKM MD2 RSA PKCS 0x00000004UL
- #define CKM MD5 RSA PKCS 0x00000005UL
- #define CKM SHA1 RSA PKCS 0x00000006UL
- #define CKM\_RIPEMD128\_RSA\_PKCS 0x00000007UL
- #define CKM\_RIPEMD160\_RSA\_PKCS 0x00000008UL
- #define CKM\_RSA\_PKCS\_OAEP 0x00000009UL
- #define CKM\_RSA\_X9\_31\_KEY\_PAIR\_GEN 0x0000000AUL
- #define CKM RSA X9 31 0x0000000BUL
- #define CKM SHA1 RSA X9 31 0x0000000CUL
- #define CKM RSA PKCS PSS 0x0000000DUL
- #define CKM SHA1 RSA PKCS PSS 0x0000000EUL
- #define CKM\_DSA\_KEY\_PAIR\_GEN 0x00000010UL
- #define CKM DSA 0x00000011UL
- #define CKM\_DSA\_SHA1 0x00000012UL
- #define CKM DSA SHA224 0x00000013UL
- #define CKM DSA SHA256 0x00000014UL
- #define CKM DSA SHA384 0x00000015UL

- #define CKM\_DSA\_SHA512 0x00000016UL
- #define CKM\_DH\_PKCS\_KEY\_PAIR\_GEN 0x00000020UL
- #define CKM\_DH\_PKCS\_DERIVE 0x00000021UL
- #define CKM X9 42 DH KEY PAIR GEN 0x00000030UL
- #define CKM\_X9\_42\_DH\_DERIVE 0x00000031UL
- #define CKM\_X9\_42\_DH\_HYBRID\_DERIVE 0x00000032UL
- #define CKM X9 42 MQV DERIVE 0x00000033UL
- #define CKM\_SHA256\_RSA\_PKCS 0x00000040UL
- #define CKM\_SHA384\_RSA\_PKCS 0x00000041UL
- #define CKM SHA512 RSA PKCS 0x00000042UL
- #define CKM\_SHA256\_RSA\_PKCS\_PSS 0x00000043UL
- #define CKM SHA384 RSA PKCS PSS 0x00000044UL
- #define CKM\_SHA512\_RSA\_PKCS\_PSS 0x00000045UL
- #define CKM SHA224 RSA PKCS 0x00000046UL
- #define CKM\_SHA224\_RSA\_PKCS\_PSS 0x00000047UL
- #define CKM SHA512 224 0x00000048UL
- #define CKM SHA512 224 HMAC 0x00000049UL
- #define CKM SHA512 224 HMAC GENERAL 0x0000004AUL
- #define CKM SHA512 224 KEY DERIVATION 0x0000004BUL
- #define CKM\_SHA512\_256 0x0000004CUL
- #define CKM\_SHA512\_256\_HMAC 0x0000004DUL
- #define CKM SHA512 256 HMAC GENERAL 0x0000004EUL
- #define CKM SHA512 256 KEY DERIVATION 0x0000004FUL
- #define CKM\_SHA512\_T 0x00000050UL
- #define CKM SHA512 T HMAC 0x00000051UL
- #define CKM\_SHA512\_T\_HMAC\_GENERAL 0x00000052UL
- #define CKM\_SHA512\_T\_KEY\_DERIVATION 0x00000053UL
- #define CKM RC2 KEY GEN 0x00000100UL
- #define CKM RC2 ECB 0x00000101UL
- #define CKM\_RC2\_CBC 0x00000102UL
- #define CKM RC2 MAC 0x00000103UL
- #define CKM RC2 MAC GENERAL 0x00000104UL
- #define CKM\_RC2\_CBC\_PAD 0x00000105UL
- #define CKM\_RC4\_KEY\_GEN 0x00000110UL
- #define CKM\_RC4 0x00000111UL
- #define CKM\_DES\_KEY\_GEN 0x00000120UL
- #define CKM\_DES\_ECB 0x00000121UL
- #define CKM\_DES\_CBC 0x00000122UL
- #define CKM DES MAC 0x00000123UL
- #define CKM DES MAC GENERAL 0x00000124UL
- #define CKM DES CBC PAD 0x00000125UL
- #define CKM\_DES2\_KEY\_GEN 0x00000130UL
- #define CKM\_DES3\_KEY\_GEN 0x00000131UL
- #define CKM\_DES3\_ECB 0x00000132UL
- #define CKM\_DES3\_CBC 0x00000133UL
- #define CKM DES3 MAC 0x00000134UL
- #define CKM DES3 MAC GENERAL 0x00000135UL
- #define CKM DES3 CBC PAD 0x00000136UL
- #define CKM DES3 CMAC GENERAL 0x00000137UL
- #define CKM\_DES3\_CMAC 0x00000138UL
- #define CKM CDMF KEY GEN 0x00000140UL
- #define CKM\_CDMF\_ECB 0x00000141UL
- #define CKM CDMF CBC 0x00000142UL
- #define CKM\_CDMF\_MAC 0x00000143UL
- #define CKM\_CDMF\_MAC\_GENERAL 0x00000144UL

- #define CKM CDMF CBC PAD 0x00000145UL
- #define CKM DES OFB64 0x00000150UL
- #define CKM\_DES\_OFB8 0x00000151UL
- #define CKM DES CFB64 0x00000152UL
- #define CKM DES CFB8 0x00000153UL
- #define CKM MD2 0x00000200UL
- #define CKM MD2 HMAC 0x00000201UL
- #define CKM\_MD2\_HMAC\_GENERAL 0x00000202UL
- #define CKM\_MD5 0x00000210UL
- #define CKM MD5 HMAC 0x00000211UL
- #define CKM MD5 HMAC GENERAL 0x00000212UL
- #define CKM SHA 1 0x00000220UL
- #define CKM\_SHA\_1\_HMAC 0x00000221UL
- #define CKM SHA 1 HMAC GENERAL 0x00000222UL
- #define CKM\_RIPEMD128 0x00000230UL
- #define CKM RIPEMD128 HMAC 0x00000231UL
- #define CKM RIPEMD128 HMAC GENERAL 0x00000232UL
- #define CKM RIPEMD160 0x00000240UL
- #define CKM RIPEMD160 HMAC 0x00000241UL
- #define CKM RIPEMD160 HMAC GENERAL 0x00000242UL
- #define CKM\_SHA256 0x00000250UL
- #define CKM SHA256 HMAC 0x00000251UL
- #define CKM SHA256 HMAC GENERAL 0x00000252UL
- #define CKM\_SHA224 0x00000255UL
- #define CKM SHA224 HMAC 0x00000256UL
- #define CKM\_SHA224\_HMAC\_GENERAL 0x00000257UL
- #define CKM SHA384 0x00000260UL
- #define CKM SHA384 HMAC 0x00000261UL
- #define CKM SHA384 HMAC GENERAL 0x00000262UL
- #define CKM SHA512 0x00000270UL
- #define CKM SHA512 HMAC 0x00000271UL
- #define CKM SHA512 HMAC GENERAL 0x00000272UL
- #define CKM\_SECURID\_KEY\_GEN 0x00000280UL
- #define CKM\_SECURID 0x00000282UL
- #define CKM HOTP KEY GEN 0x00000290UL
- #define CKM HOTP 0x00000291UL
- #define CKM ACTI 0x000002A0UL
- #define CKM ACTI KEY GEN 0x000002A1UL
- #define CKM CAST KEY GEN 0x00000300UL
- #define CKM CAST ECB 0x00000301UL
- #define CKM CAST CBC 0x00000302UL
- #define CKM\_CAST\_MAC 0x00000303UL
- #define CKM\_CAST\_MAC\_GENERAL 0x00000304UL
- #define CKM\_CAST\_CBC\_PAD 0x00000305UL
- #define CKM\_CAST3\_KEY\_GEN 0x00000310UL
- #define CKM CAST3 ECB 0x00000311UL
- #define CKM CAST3 CBC 0x00000312UL
- #define CKM\_CAST3\_MAC 0x00000313UL
- #define CKM\_CAST3\_MAC\_GENERAL 0x00000314UL
- #define CKM\_CAST3\_CBC\_PAD 0x00000315UL
- #define CKM CAST5 KEY GEN 0x00000320UL
- #define CKM\_CAST128\_KEY\_GEN 0x00000320UL
- #define CKM CAST5 ECB 0x00000321UL
- #define CKM CAST128 ECB 0x00000321UL
- #define CKM CAST5 CBC 0x00000322UL /\* Deprecated \*/

- #define CKM CAST128 CBC 0x00000322UL
- #define CKM CAST5 MAC 0x00000323UL /\* Deprecated \*/
- #define CKM\_CAST128\_MAC 0x00000323UL
- #define CKM CAST5 MAC GENERAL 0x00000324UL /\* Deprecated \*/
- #define CKM CAST128 MAC GENERAL 0x00000324UL
- #define CKM\_CAST5\_CBC\_PAD 0x00000325UL /\* Deprecated \*/
- #define CKM CAST128 CBC PAD 0x00000325UL
- #define CKM\_RC5\_KEY\_GEN 0x00000330UL
- #define CKM RC5 ECB 0x00000331UL
- #define CKM\_RC5\_CBC 0x00000332UL
- #define CKM RC5 MAC 0x00000333UL
- #define CKM RC5 MAC GENERAL 0x00000334UL
- #define CKM\_RC5\_CBC\_PAD 0x00000335UL
- #define CKM IDEA KEY GEN 0x00000340UL
- #define CKM\_IDEA\_ECB 0x00000341UL
- #define CKM IDEA CBC 0x00000342UL
- #define CKM IDEA MAC 0x00000343UL
- #define CKM IDEA MAC GENERAL 0x00000344UL
- #define CKM IDEA CBC PAD 0x00000345UL
- #define CKM GENERIC SECRET KEY GEN 0x00000350UL
- #define CKM\_CONCATENATE\_BASE\_AND\_KEY 0x00000360UL
- #define CKM\_CONCATENATE\_BASE\_AND\_DATA 0x00000362UL
- #define CKM CONCATENATE DATA AND BASE 0x00000363UL
- #define CKM\_XOR\_BASE\_AND\_DATA 0x00000364UL
- #define CKM EXTRACT KEY FROM KEY 0x00000365UL
- #define CKM\_SSL3\_PRE\_MASTER\_KEY\_GEN 0x00000370UL
- #define CKM\_SSL3\_MASTER\_KEY\_DERIVE 0x00000371UL
- #define CKM\_SSL3\_KEY\_AND\_MAC\_DERIVE 0x00000372UL
- #define CKM\_SSL3\_MASTER\_KEY\_DERIVE\_DH 0x00000373UL
- #define CKM\_TLS\_PRE\_MASTER\_KEY\_GEN 0x00000374UL
- #define CKM TLS MASTER KEY DERIVE 0x00000375UL
- #define CKM TLS KEY AND MAC DERIVE 0x00000376UL
- #define CKM\_TLS\_MASTER\_KEY\_DERIVE\_DH 0x00000377UL
- #define CKM\_TLS\_PRF 0x00000378UL
- #define CKM SSL3 MD5 MAC 0x00000380UL
- #define CKM\_SSL3\_SHA1\_MAC 0x00000381UL
- #define CKM MD5 KEY DERIVATION 0x00000390UL
- #define CKM\_MD2\_KEY\_DERIVATION 0x00000391UL
- #define CKM\_SHA1\_KEY\_DERIVATION 0x00000392UL
- #define CKM\_SHA256\_KEY\_DERIVATION 0x00000393UL
- #define CKM\_SHA384\_KEY\_DERIVATION 0x00000394UL
   #UNITED NOTES OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE P
- #define CKM\_SHA512\_KEY\_DERIVATION 0x00000395UL
- #define CKM\_SHA224\_KEY\_DERIVATION 0x00000396UL
- #define CKM\_PBE\_MD2\_DES\_CBC 0x000003A0UL
- #define CKM\_PBE\_MD5\_DES\_CBC 0x000003A1UL
- #define CKM PBE MD5 CAST CBC 0x000003A2UL
- #define CKM PBE MD5 CAST3 CBC 0x000003A3UL
- #define CKM\_PBE\_MD5\_CAST5\_CBC 0x000003A4UL /\* Deprecated \*/
- #define CKM\_PBE\_MD5\_CAST128\_CBC 0x000003A4UL
- #define CKM\_PBE\_SHA1\_CAST5\_CBC 0x000003A5UL /\* Deprecated \*/
- #define CKM PBE SHA1 CAST128 CBC 0x000003A5UL
- #define CKM\_PBE\_SHA1\_RC4\_128 0x000003A6UL
- #define CKM PBE SHA1 RC4 40 0x000003A7UL
- #define CKM PBE SHA1 DES3 EDE CBC 0x000003A8UL
- #define CKM\_PBE\_SHA1\_DES2\_EDE\_CBC 0x000003A9UL

- #define CKM\_PBE\_SHA1\_RC2\_128\_CBC 0x000003AAUL
- #define CKM PBE SHA1 RC2 40 CBC 0x000003ABUL
- #define CKM\_PKCS5\_PBKD2 0x000003B0UL
- #define CKM PBA SHA1 WITH SHA1 HMAC 0x000003C0UL
- #define CKM WTLS PRE MASTER KEY GEN 0x000003D0UL
- #define CKM\_WTLS\_MASTER\_KEY\_DERIVE 0x000003D1UL
- #define CKM WTLS MASTER KEY DERIVE DH ECC 0x000003D2UL
- #define CKM\_WTLS\_PRF 0x000003D3UL
- #define CKM\_WTLS\_SERVER\_KEY\_AND\_MAC\_DERIVE 0x000003D4UL
- #define CKM WTLS CLIENT KEY AND MAC DERIVE 0x000003D5UL
- #define CKM TLS10 MAC SERVER 0x000003D6UL
- #define CKM TLS10 MAC CLIENT 0x000003D7UL
- #define CKM TLS12 MAC 0x000003D8UL
- #define CKM TLS12 KDF 0x000003D9UL
- #define CKM\_TLS12\_MASTER\_KEY\_DERIVE 0x000003E0UL
- #define CKM TLS12 KEY AND MAC DERIVE 0x000003E1UL
- #define CKM TLS12 MASTER KEY DERIVE DH 0x000003E2UL
- #define CKM TLS12 KEY SAFE DERIVE 0x000003E3UL
- #define CKM TLS MAC 0x000003E4UL
- #define CKM TLS KDF 0x000003E5UL
- #define CKM\_KEY\_WRAP\_LYNKS 0x00000400UL
- #define CKM KEY WRAP SET OAEP 0x00000401UL
- #define CKM CMS SIG 0x00000500UL
- #define CKM\_KIP\_DERIVE 0x00000510UL
- #define CKM KIP WRAP 0x00000511UL
- #define CKM\_KIP\_MAC 0x00000512UL
- #define CKM CAMELLIA KEY GEN 0x00000550UL
- #define CKM\_CAMELLIA\_ECB 0x00000551UL
- #define CKM\_CAMELLIA\_CBC 0x00000552UL
- #define CKM\_CAMELLIA\_MAC 0x00000553UL
- #define CKM\_CAMELLIA\_MAC\_GENERAL 0x00000554UL
- #define CKM CAMELLIA CBC PAD 0x00000555UL
- #define CKM\_CAMELLIA\_ECB\_ENCRYPT\_DATA 0x00000556UL
- #define CKM\_CAMELLIA\_CBC\_ENCRYPT\_DATA 0x00000557UL
- #define CKM\_CAMELLIA\_CTR 0x00000558UL
- #define CKM\_ARIA\_KEY\_GEN 0x00000560UL
- #define CKM\_ARIA\_ECB 0x00000561UL
- #define CKM\_ARIA\_CBC 0x00000562UL
- #define CKM ARIA MAC 0x00000563UL
- #define CKM ARIA MAC GENERAL 0x00000564UL
- #define CKM ARIA CBC PAD 0x00000565UL
- #define CKM\_ARIA\_ECB\_ENCRYPT\_DATA 0x00000566UL
- #define CKM\_ARIA\_CBC\_ENCRYPT\_DATA 0x00000567UL
- #define CKM\_SEED\_KEY\_GEN 0x00000650UL
- #define CKM\_SEED\_ECB 0x00000651UL
- #define CKM SEED CBC 0x00000652UL
- #define CKM SEED MAC 0x00000653UL
- #define CKM\_SEED\_MAC\_GENERAL 0x00000654UL
- #define CKM\_SEED\_CBC\_PAD 0x00000655UL
- #define CKM\_SEED\_ECB\_ENCRYPT\_DATA 0x00000656UL
- #define CKM SEED CBC ENCRYPT DATA 0x00000657UL
- #define CKM\_SKIPJACK\_KEY\_GEN 0x00001000UL
- #define CKM SKIPJACK ECB64 0x00001001UL
- #define CKM SKIPJACK CBC64 0x00001002UL
- #define CKM SKIPJACK OFB64 0x00001003UL

- #define CKM SKIPJACK CFB64 0x00001004UL
- #define CKM SKIPJACK CFB32 0x00001005UL
- #define CKM\_SKIPJACK\_CFB16 0x00001006UL
- #define CKM SKIPJACK CFB8 0x00001007UL
- #define CKM SKIPJACK WRAP 0x00001008UL
- #define CKM\_SKIPJACK\_PRIVATE\_WRAP 0x00001009UL
- #define CKM SKIPJACK RELAYX 0x0000100aUL
- #define CKM\_KEA\_KEY\_PAIR\_GEN 0x00001010UL
- #define CKM\_KEA\_KEY\_DERIVE 0x00001011UL
- #define CKM KEA DERIVE 0x00001012UL
- #define CKM FORTEZZA TIMESTAMP 0x00001020UL
- #define CKM BATON KEY GEN 0x00001030UL
- #define CKM\_BATON\_ECB128 0x00001031UL
- #define CKM BATON ECB96 0x00001032UL
- #define CKM\_BATON\_CBC128 0x00001033UL
- #define CKM BATON COUNTER 0x00001034UL
- #define CKM\_BATON\_SHUFFLE 0x00001035UL
- #define CKM BATON WRAP 0x00001036UL
- #define CKM ECDSA KEY PAIR GEN 0x00001040UL /\* Deprecated \*/
- #define CKM\_EC\_KEY\_PAIR\_GEN 0x00001040UL
- #define CKM\_ECDSA 0x00001041UL
- #define CKM ECDSA SHA1 0x00001042UL
- #define CKM ECDSA SHA224 0x00001043UL
- #define CKM\_ECDSA\_SHA256 0x00001044UL
- #define CKM ECDSA SHA384 0x00001045UL
- #define CKM\_ECDSA\_SHA512 0x00001046UL
- #define CKM\_ECDH1\_DERIVE 0x00001050UL
- #define CKM ECDH1 COFACTOR DERIVE 0x00001051UL
- #define CKM ECMQV DERIVE 0x00001052UL
- #define CKM\_ECDH\_AES\_KEY\_WRAP 0x00001053UL
- #define CKM\_RSA\_AES\_KEY\_WRAP 0x00001054UL
- #define CKM JUNIPER KEY GEN 0x00001060UL
- #define CKM\_JUNIPER\_ECB128 0x00001061UL
- #define CKM\_JUNIPER\_CBC128 0x00001062UL
- #define CKM\_JUNIPER\_COUNTER 0x00001063UL
- #define CKM\_JUNIPER\_SHUFFLE 0x00001064UL
- #define CKM JUNIPER WRAP 0x00001065UL
- #define CKM FASTHASH 0x00001070UL
- #define CKM AES KEY GEN 0x00001080UL
- #define CKM AES ECB 0x00001081UL
- #define CKM AES CBC 0x00001082UL
- #define CKM\_AES\_MAC 0x00001083UL
- #define CKM\_AES\_MAC\_GENERAL 0x00001084UL
- #define CKM\_AES\_CBC\_PAD 0x00001085UL
- #define CKM AES CTR 0x00001086UL
- #define CKM AES GCM 0x00001087UL
- #define CKM\_AES\_CCM 0x00001088UL
- #define CKM\_AES\_CTS 0x00001089UL
- #define CKM\_AES\_CMAC 0x0000108AUL
- #define CKM\_AES\_CMAC\_GENERAL 0x0000108BUL
- #define CKM AES XCBC MAC 0x0000108CUL
- #define CKM\_AES\_XCBC\_MAC\_96 0x0000108DUL
- #define CKM AES GMAC 0x0000108EUL
- #define CKM BLOWFISH KEY GEN 0x00001090UL
- #define CKM BLOWFISH CBC 0x00001091UL

- #define CKM TWOFISH KEY GEN 0x00001092UL
- #define CKM TWOFISH CBC 0x00001093UL
- #define CKM BLOWFISH CBC PAD 0x00001094UL
- #define CKM TWOFISH CBC PAD 0x00001095UL
- #define CKM DES ECB ENCRYPT DATA 0x00001100UL
- #define CKM DES CBC ENCRYPT DATA 0x00001101UL
- #define CKM DES3 ECB ENCRYPT DATA 0x00001102UL
- #define CKM\_DES3\_CBC\_ENCRYPT\_DATA 0x00001103UL
- #define CKM\_AES\_ECB\_ENCRYPT\_DATA 0x00001104UL
- #define CKM AES CBC ENCRYPT DATA 0x00001105UL
- #define CKM GOSTR3410 KEY PAIR GEN 0x00001200UL
- #define CKM GOSTR3410 0x00001201UL
- #define CKM GOSTR3410 WITH GOSTR3411 0x00001202UL
- #define CKM GOSTR3410 KEY WRAP 0x00001203UL
- #define CKM\_GOSTR3410\_DERIVE 0x00001204UL
- #define CKM GOSTR3411 0x00001210UL
- #define CKM GOSTR3411 HMAC 0x00001211UL
- #define CKM GOST28147 KEY GEN 0x00001220UL
- #define CKM GOST28147 ECB 0x00001221UL
- #define CKM GOST28147 0x00001222UL
- #define CKM\_GOST28147\_MAC 0x00001223UL
- #define CKM GOST28147 KEY WRAP 0x00001224UL
- #define CKM DSA PARAMETER GEN 0x00002000UL
- #define CKM\_DH\_PKCS\_PARAMETER\_GEN 0x00002001UL
- #define CKM X9 42 DH PARAMETER GEN 0x00002002UL
- #define CKM\_DSA\_PROBABLISTIC\_PARAMETER\_GEN 0x00002003UL
- #define CKM DSA SHAWE TAYLOR PARAMETER GEN 0x00002004UL
- #define CKM AES OFB 0x00002104UL
- #define CKM AES CFB64 0x00002105UL
- #define CKM\_AES\_CFB8 0x00002106UL
- #define CKM AES CFB128 0x00002107UL
- #define CKM AES CFB1 0x00002108UL
- #define CKM\_AES\_KEY\_WRAP 0x00002109UL /\* WAS: 0x00001090 \*/
- #define CKM\_AES\_KEY\_WRAP\_PAD 0x0000210AUL /\* WAS: 0x00001091 \*/
- #define CKM\_RSA\_PKCS\_TPM\_1\_1 0x00004001UL
- #define CKM\_RSA\_PKCS\_OAEP\_TPM\_1\_1 0x00004002UL
- #define CKM\_VENDOR\_DEFINED 0x80000000UL
- #define CKF HW 0x0000001UL /\* performed by HW \*/
- #define CKF ENCRYPT 0x00000100UL
- #define CKF DECRYPT 0x00000200UL
- #define CKF DIGEST 0x00000400UL
- #define CKF\_SIGN 0x00000800UL
- #define CKF\_SIGN\_RECOVER 0x00001000UL
- #define CKF\_VERIFY 0x00002000UL
- #define CKF\_VERIFY\_RECOVER 0x00004000UL
- #define CKF GENERATE 0x00008000UL
- #define CKF GENERATE KEY PAIR 0x00010000UL
- #define CKF WRAP 0x00020000UL
- #define CKF\_UNWRAP 0x00040000UL
- #define CKF\_DERIVE 0x00080000UL
- #define CKF EC F P 0x00100000UL
- #define CKF EC F 2M 0x00200000UL
- #define CKF EC ECPARAMETERS 0x00400000UL
- #define CKF EC NAMEDCURVE 0x00800000UL
- #define CKF EC UNCOMPRESS 0x01000000UL

- #define CKF EC COMPRESS 0x02000000UL
- #define CKF\_EXTENSION 0x80000000UL
- #define CKR\_OK 0x00000000UL
- #define CKR CANCEL 0x00000001UL
- #define CKR HOST MEMORY 0x00000002UL
- #define CKR\_SLOT\_ID\_INVALID 0x00000003UL
- #define CKR\_GENERAL\_ERROR 0x00000005UL
- #define CKR\_FUNCTION\_FAILED 0x00000006UL
- #define CKR ARGUMENTS BAD 0x00000007UL
- #define CKR NO EVENT 0x00000008UL
- #define CKR NEED TO CREATE THREADS 0x00000009UL
- #define CKR CANT LOCK 0x0000000AUL
- #define CKR ATTRIBUTE READ ONLY 0x00000010UL
- #define CKR ATTRIBUTE SENSITIVE 0x00000011UL
- #define CKR\_ATTRIBUTE\_TYPE\_INVALID 0x00000012UL
- #define CKR ATTRIBUTE VALUE INVALID 0x00000013UL
- #define CKR ACTION PROHIBITED 0x0000001BUL
- #define CKR DATA INVALID 0x00000020UL
- #define CKR DATA LEN RANGE 0x00000021UL
- #define CKR\_DEVICE\_ERROR 0x00000030UL
- #define CKR\_DEVICE\_MEMORY 0x00000031UL
- #define CKR\_DEVICE\_REMOVED 0x00000032UL
- #define CKR ENCRYPTED DATA INVALID 0x00000040UL
- #define CKR\_ENCRYPTED\_DATA\_LEN\_RANGE 0x00000041UL
- #define CKR FUNCTION CANCELED 0x00000050UL
- #define CKR\_FUNCTION\_NOT\_PARALLEL 0x00000051UL
- #define CKR FUNCTION NOT SUPPORTED 0x00000054UL
- #define CKR KEY HANDLE INVALID 0x00000060UL
- #define CKR KEY SIZE RANGE 0x00000062UL
- #define CKR\_KEY\_TYPE\_INCONSISTENT 0x00000063UL
- #define CKR\_KEY\_NOT\_NEEDED 0x00000064UL
- #define CKR KEY CHANGED 0x00000065UL
- #define CKR\_KEY\_NEEDED 0x00000066UL
- #define CKR\_KEY\_INDIGESTIBLE 0x00000067UL
- #define CKR\_KEY\_FUNCTION\_NOT\_PERMITTED 0x00000068UL
- #define CKR KEY NOT WRAPPABLE 0x00000069UL
- #define CKR\_KEY\_UNEXTRACTABLE 0x0000006AUL
- #define CKR\_MECHANISM\_INVALID 0x00000070UL
- #define CKR MECHANISM PARAM INVALID 0x00000071UL
- #define CKR OBJECT HANDLE INVALID 0x00000082UL
- #define CKR OPERATION ACTIVE 0x00000090UL
- #define CKR\_OPERATION\_NOT\_INITIALIZED 0x00000091UL
- #define CKR\_PIN\_INCORRECT 0x000000A0UL
- #define CKR\_PIN\_INVALID 0x000000A1UL
- #define CKR PIN LEN RANGE 0x000000A2UL
- #define CKR PIN EXPIRED 0x000000A3UL
- #define CKR PIN LOCKED 0x000000A4UL
- #define CKR SESSION CLOSED 0x000000B0UL
- #define CKR SESSION COUNT 0x000000B1UL
- #define CKR\_SESSION\_HANDLE\_INVALID 0x000000B3UL
- #define CKR SESSION PARALLEL NOT SUPPORTED 0x0000000B4UL
- #define CKR SESSION READ ONLY 0x000000B5UL
- #define CKR SESSION EXISTS 0x000000B6UL
- #define CKR SESSION READ ONLY EXISTS 0x000000B7UL
- #define CKR\_SESSION\_READ\_WRITE\_SO\_EXISTS 0x000000B8UL

- #define CKR SIGNATURE INVALID 0x000000C0UL
- #define CKR SIGNATURE LEN RANGE 0x000000C1UL
- #define CKR\_TEMPLATE\_INCOMPLETE 0x000000D0UL
- #define CKR TEMPLATE INCONSISTENT 0x000000D1UL
- #define CKR TOKEN NOT PRESENT 0x000000E0UL
- #define CKR TOKEN NOT RECOGNIZED 0x000000E1UL
- #define CKR TOKEN WRITE PROTECTED 0x000000E2UL
- #define CKR\_UNWRAPPING\_KEY\_HANDLE\_INVALID 0x000000F0UL
- #define CKR\_UNWRAPPING\_KEY\_SIZE\_RANGE 0x000000F1UL
- #define CKR UNWRAPPING KEY TYPE INCONSISTENT 0x000000F2UL
- #define CKR USER ALREADY LOGGED IN 0x00000100UL
- #define CKR USER NOT LOGGED IN 0x00000101UL
- #define CKR USER PIN NOT INITIALIZED 0x00000102UL
- #define CKR USER TYPE INVALID 0x00000103UL
- #define CKR\_USER\_ANOTHER\_ALREADY\_LOGGED\_IN 0x00000104UL
- #define CKR USER TOO MANY TYPES 0x00000105UL
- #define CKR WRAPPED KEY INVALID 0x00000110UL
- #define CKR WRAPPED KEY LEN RANGE 0x00000112UL
- #define CKR WRAPPING KEY HANDLE INVALID 0x00000113UL
- #define CKR\_WRAPPING\_KEY\_SIZE\_RANGE 0x00000114UL
- #define CKR\_WRAPPING\_KEY\_TYPE\_INCONSISTENT 0x00000115UL
- #define CKR RANDOM SEED NOT SUPPORTED 0x00000120UL
- #define CKR RANDOM NO RNG 0x00000121UL
- #define CKR\_DOMAIN\_PARAMS\_INVALID 0x00000130UL
- #define CKR CURVE NOT SUPPORTED 0x00000140UL
- #define CKR\_BUFFER\_TOO\_SMALL 0x00000150UL
- #define CKR\_SAVED\_STATE\_INVALID 0x00000160UL
- #define CKR INFORMATION SENSITIVE 0x00000170UL
- #define CKR STATE UNSAVEABLE 0x00000180UL
- #define CKR\_CRYPTOKI\_NOT\_INITIALIZED 0x00000190UL
- #define CKR CRYPTOKI ALREADY INITIALIZED 0x00000191UL
- #define CKR MUTEX BAD 0x000001A0UL
- #define CKR\_MUTEX\_NOT\_LOCKED 0x000001A1UL
- #define CKR\_NEW\_PIN\_MODE 0x000001B0UL
- #define CKR NEXT OTP 0x000001B1UL
- #define CKR EXCEEDED MAX ITERATIONS 0x000001B5UL
- #define CKR\_FIPS\_SELF\_TEST\_FAILED 0x000001B6UL
- #define CKR\_LIBRARY\_LOAD\_FAILED 0x000001B7UL
- #define CKR PIN TOO WEAK 0x000001B8UL
- #define CKR PUBLIC KEY INVALID 0x000001B9UL
- #define CKR FUNCTION REJECTED 0x00000200UL
- #define CKR VENDOR DEFINED 0x80000000UL
- #define CKF\_LIBRARY\_CANT\_CREATE\_OS\_THREADS 0x00000001UL
- #define CKF\_OS\_LOCKING\_OK 0x00000002UL
- #define CKF\_DONT\_BLOCK 1
- #define CKG MGF1 SHA1 0x00000001UL
- #define CKG MGF1 SHA256 0x00000002UL
- #define CKG MGF1 SHA384 0x00000003UL
- #define CKG MGF1 SHA512 0x00000004UL
- #define CKG\_MGF1\_SHA224 0x00000005UL
- #define CKZ DATA SPECIFIED 0x00000001UL
- #define CKD NULL 0x0000001UL
- #define CKD SHA1 KDF 0x00000002UL
- #define CKD SHA1 KDF ASN1 0x00000003UL
- #define CKD\_SHA1\_KDF\_CONCATENATE 0x00000004UL

- #define CKD SHA224 KDF 0x00000005UL
- #define CKD SHA256 KDF 0x00000006UL
- #define CKD\_SHA384\_KDF 0x00000007UL
- #define CKD SHA512 KDF 0x00000008UL
- #define CKD\_CPDIVERSIFY\_KDF 0x00000009UL
- #define CKP\_PKCS5\_PBKD2\_HMAC\_SHA1 0x00000001UL
- #define CKP PKCS5 PBKD2 HMAC GOSTR3411 0x00000002UL
- #define CKP\_PKCS5\_PBKD2\_HMAC\_SHA224 0x00000003UL
- #define CKP\_PKCS5\_PBKD2\_HMAC\_SHA256 0x00000004UL
- #define CKP PKCS5 PBKD2 HMAC SHA384 0x00000005UL
- #define CKP PKCS5 PBKD2 HMAC SHA512 0x00000006UL
- #define CKP PKCS5 PBKD2 HMAC SHA512 224 0x00000007UL
- #define CKP\_PKCS5\_PBKD2\_HMAC\_SHA512\_256 0x00000008UL
- #define CKZ SALT SPECIFIED 0x00000001UL
- #define CK\_OTP\_VALUE 0UL
- #define CK\_OTP\_PIN 1UL
- #define CK OTP CHALLENGE 2UL
- #define CK OTP TIME 3UL
- #define CK\_OTP\_COUNTER 4UL
- #define CK\_OTP\_FLAGS 5UL
- #define CK\_OTP\_OUTPUT\_LENGTH 6UL
- #define CK OTP OUTPUT FORMAT 7UL
- #define CKF NEXT OTP 0x00000001UL
- #define CKF\_EXCLUDE\_TIME 0x00000002UL
- #define CKF EXCLUDE COUNTER 0x00000004UL
- #define CKF\_EXCLUDE\_CHALLENGE 0x00000008UL
- #define CKF\_EXCLUDE\_PIN 0x00000010UL
- #define CKF USER FRIENDLY OTP 0x00000020UL

#### **Typedefs**

- typedef unsigned char CK\_BYTE
- typedef CK\_BYTE CK\_CHAR
- typedef CK\_BYTE CK\_UTF8CHAR
- typedef CK\_BYTE CK\_BBOOL
- typedef unsigned long int CK\_ULONG
- · typedef long int CK LONG
- · typedef CK ULONG CK FLAGS
- typedef CK BYTE CK PTR CK BYTE PTR
- typedef CK CHAR CK PTR CK CHAR PTR
- typedef CK\_UTF8CHAR CK\_PTR CK\_UTF8CHAR\_PTR
- typedef CK\_ULONG CK\_PTR CK\_ULONG\_PTR
- typedef void CK\_PTR CK\_VOID\_PTR
- typedef CK\_VOID\_PTR CK\_PTR CK\_VOID\_PTR\_PTR
- typedef struct CK VERSION CK VERSION
- typedef CK VERSION CK PTR CK VERSION PTR
- typedef struct CK INFO CK INFO
- typedef CK\_INFO CK\_PTR CK\_INFO\_PTR
- typedef CK\_ULONG CK\_NOTIFICATION
- · typedef CK ULONG CK SLOT ID
- typedef CK\_SLOT\_ID CK\_PTR CK\_SLOT\_ID\_PTR
- typedef struct CK SLOT INFO CK SLOT INFO
- typedef CK SLOT INFO CK PTR CK SLOT INFO PTR
- typedef struct CK\_TOKEN\_INFO CK\_TOKEN\_INFO

- typedef CK\_TOKEN\_INFO CK\_PTR CK\_TOKEN\_INFO\_PTR
- typedef CK ULONG CK SESSION HANDLE
- typedef CK\_SESSION\_HANDLE CK\_PTR CK\_SESSION\_HANDLE\_PTR
- typedef CK ULONG CK USER TYPE
- typedef CK ULONG CK STATE
- typedef struct CK SESSION INFO CK SESSION INFO
- typedef CK SESSION INFO CK PTR CK SESSION INFO PTR
- typedef CK\_ULONG CK\_OBJECT\_HANDLE
- typedef CK\_OBJECT\_HANDLE CK\_PTR CK\_OBJECT\_HANDLE\_PTR
- typedef CK ULONG CK OBJECT CLASS
- typedef CK OBJECT CLASS CK PTR CK OBJECT CLASS PTR
- typedef CK ULONG CK HW FEATURE TYPE
- typedef CK ULONG CK KEY TYPE
- typedef CK ULONG CK CERTIFICATE TYPE
- typedef CK\_ULONG CK\_ATTRIBUTE\_TYPE
- typedef struct CK ATTRIBUTE CK ATTRIBUTE
- typedef CK ATTRIBUTE CK PTR CK ATTRIBUTE PTR
- typedef struct CK DATE CK DATE
- typedef CK ULONG CK MECHANISM TYPE
- typedef CK\_MECHANISM\_TYPE CK\_PTR CK\_MECHANISM\_TYPE\_PTR
- typedef struct CK\_MECHANISM CK\_MECHANISM
- typedef CK MECHANISM CK PTR CK MECHANISM PTR
- typedef struct CK MECHANISM INFO CK MECHANISM INFO
- typedef CK\_MECHANISM\_INFO CK\_PTR CK\_MECHANISM\_INFO\_PTR
- typedef CK ULONG CK RV
- typedef CK\_NOTIFICATION event
- typedef CK\_NOTIFICATION CK\_VOID\_PTR pApplication
- typedef struct CK\_FUNCTION\_LIST CK\_FUNCTION\_LIST
- typedef CK\_FUNCTION\_LIST CK\_PTR CK\_FUNCTION\_LIST\_PTR
- typedef CK\_FUNCTION\_LIST\_PTR CK\_PTR CK\_FUNCTION\_LIST\_PTR\_PTR
- typedef struct CK\_C\_INITIALIZE\_ARGS CK\_C\_INITIALIZE\_ARGS
- typedef CK C INITIALIZE ARGS CK PTR CK C INITIALIZE ARGS PTR
- typedef CK\_ULONG CK\_RSA\_PKCS\_MGF\_TYPE
- typedef CK\_RSA\_PKCS\_MGF\_TYPE CK\_PTR CK\_RSA\_PKCS\_MGF\_TYPE\_PTR
- typedef CK\_ULONG CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE
- typedef CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE CK\_PTR CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE\_PTR
- typedef struct CK\_RSA\_PKCS\_OAEP\_PARAMS CK\_RSA\_PKCS\_OAEP\_PARAMS
- typedef CK\_RSA\_PKCS\_OAEP\_PARAMS CK\_PTR CK\_RSA\_PKCS\_OAEP\_PARAMS\_PTR
- typedef struct CK\_RSA\_PKCS\_PSS\_PARAMS CK\_RSA\_PKCS\_PSS\_PARAMS
- typedef CK RSA PKCS PSS PARAMS CK PTR CK RSA PKCS PSS PARAMS PTR
- typedef CK ULONG CK EC KDF TYPE
- typedef struct CK\_ECDH1\_DERIVE\_PARAMS CK\_ECDH1\_DERIVE\_PARAMS
- typedef CK\_ECDH1\_DERIVE\_PARAMS CK\_PTR CK\_ECDH1\_DERIVE\_PARAMS\_PTR
- typedef struct CK\_ECDH2\_DERIVE\_PARAMS CK\_ECDH2\_DERIVE\_PARAMS
- typedef CK\_ECDH2\_DERIVE\_PARAMS CK\_PTR CK\_ECDH2\_DERIVE\_PARAMS\_PTR
- typedef struct CK ECMQV DERIVE PARAMS CK ECMQV DERIVE PARAMS
- typedef CK ECMQV DERIVE PARAMS CK PTR CK ECMQV DERIVE PARAMS PTR
- typedef CK\_ULONG CK\_X9\_42\_DH\_KDF\_TYPE
- typedef CK\_X9\_42\_DH\_KDF\_TYPE CK\_PTR CK\_X9\_42\_DH\_KDF\_TYPE\_PTR
- typedef struct CK\_X9\_42\_DH1\_DERIVE\_PARAMS CK\_X9\_42\_DH1\_DERIVE\_PARAMS
- typedef struct CK X9 42 DH1 DERIVE PARAMS CK PTR CK X9 42 DH1 DERIVE PARAMS PTR
- typedef struct CK\_X9\_42\_DH2\_DERIVE\_PARAMS CK\_X9\_42\_DH2\_DERIVE\_PARAMS
- typedef CK X9 42 DH2 DERIVE PARAMS CK PTR CK X9 42 DH2 DERIVE PARAMS PTR
- typedef struct CK X9 42 MQV DERIVE PARAMS CK X9 42 MQV DERIVE PARAMS
- typedef CK\_X9\_42\_MQV\_DERIVE\_PARAMS CK\_PTR CK\_X9\_42\_MQV\_DERIVE\_PARAMS\_PTR

- typedef struct CK\_KEA\_DERIVE\_PARAMS CK\_KEA\_DERIVE\_PARAMS
- typedef CK\_KEA\_DERIVE\_PARAMS CK\_PTR CK\_KEA\_DERIVE\_PARAMS\_PTR
- typedef CK\_ULONG CK\_RC2\_PARAMS
- typedef CK\_RC2\_PARAMS CK\_PTR CK\_RC2\_PARAMS\_PTR
- typedef struct CK\_RC2\_CBC\_PARAMS CK\_RC2\_CBC\_PARAMS
- typedef CK\_RC2\_CBC\_PARAMS CK\_PTR CK\_RC2\_CBC\_PARAMS\_PTR
- typedef struct CK RC2 MAC GENERAL PARAMS CK RC2 MAC GENERAL PARAMS
- typedef CK\_RC2\_MAC\_GENERAL\_PARAMS CK\_PTR CK\_RC2\_MAC\_GENERAL\_PARAMS\_PTR
- typedef struct CK\_RC5\_PARAMS CK\_RC5\_PARAMS
- typedef CK RC5 PARAMS CK PTR CK RC5 PARAMS PTR
- typedef struct CK\_RC5\_CBC\_PARAMS CK\_RC5\_CBC\_PARAMS
- typedef CK RC5 CBC PARAMS CK PTR CK RC5 CBC PARAMS PTR
- typedef struct CK\_RC5\_MAC\_GENERAL\_PARAMS CK\_RC5\_MAC\_GENERAL\_PARAMS
- typedef CK RC5 MAC GENERAL PARAMS CK PTR CK RC5 MAC GENERAL PARAMS PTR
- typedef CK\_ULONG CK\_MAC\_GENERAL\_PARAMS
- typedef CK\_MAC\_GENERAL\_PARAMS CK\_PTR CK\_MAC\_GENERAL\_PARAMS\_PTR
- typedef struct CK DES CBC ENCRYPT DATA PARAMS CK DES CBC ENCRYPT DATA PARAMS
- typedef CK DES CBC ENCRYPT DATA PARAMS CK PTR CK DES CBC ENCRYPT DATA PARAMS PTR
- typedef struct CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS
- typedef CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR
- typedef struct CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS
- typedef CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS CK\_PTR CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS\_PTR
- typedef struct CK SKIPJACK RELAYX PARAMS CK SKIPJACK RELAYX PARAMS
- typedef CK\_SKIPJACK\_RELAYX\_PARAMS CK\_PTR CK\_SKIPJACK\_RELAYX\_PARAMS\_PTR
- typedef struct CK PBE PARAMS CK PBE PARAMS
- typedef CK\_PBE\_PARAMS CK\_PTR CK\_PBE\_PARAMS\_PTR
- typedef struct CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS
- typedef CK KEY WRAP SET OAEP PARAMS CK PTR CK KEY WRAP SET OAEP PARAMS PTR
- typedef struct CK SSL3 RANDOM DATA CK SSL3 RANDOM DATA
- typedef struct CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS
- typedef struct CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS CK\_PTR CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR
- typedef struct CK SSL3 KEY MAT OUT CK SSL3 KEY MAT OUT
- typedef CK\_SSL3\_KEY\_MAT\_OUT CK\_PTR CK\_SSL3\_KEY\_MAT\_OUT\_PTR
- typedef struct CK\_SSL3\_KEY\_MAT\_PARAMS CK\_SSL3\_KEY\_MAT\_PARAMS
- typedef CK\_SSL3\_KEY\_MAT\_PARAMS CK\_PTR CK\_SSL3\_KEY\_MAT\_PARAMS\_PTR
- typedef struct CK\_TLS\_PRF\_PARAMS CK\_TLS\_PRF\_PARAMS
- typedef CK\_TLS\_PRF\_PARAMS CK\_PTR CK\_TLS\_PRF\_PARAMS\_PTR
- typedef struct CK\_WTLS\_RANDOM\_DATA CK\_WTLS\_RANDOM\_DATA
- typedef CK\_WTLS\_RANDOM\_DATA\_CK\_PTR CK\_WTLS\_RANDOM\_DATA\_PTR
- typedef struct CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS
- typedef CK WTLS MASTER KEY DERIVE PARAMS CK PTR CK WTLS MASTER KEY DERIVE PARAMS PTR
- typedef struct CK\_WTLS\_PRF\_PARAMS CK\_WTLS\_PRF\_PARAMS
- typedef CK\_WTLS\_PRF\_PARAMS CK\_PTR CK\_WTLS\_PRF\_PARAMS\_PTR
- typedef struct CK\_WTLS\_KEY\_MAT\_OUT CK\_WTLS\_KEY\_MAT\_OUT
- typedef CK\_WTLS\_KEY\_MAT\_OUT CK\_PTR CK\_WTLS\_KEY\_MAT\_OUT\_PTR
- typedef struct CK\_WTLS\_KEY\_MAT\_PARAMS CK\_WTLS\_KEY\_MAT\_PARAMS
- typedef CK WTLS KEY MAT PARAMS CK PTR CK WTLS KEY MAT PARAMS PTR
- typedef struct CK\_CMS\_SIG\_PARAMS CK\_CMS\_SIG\_PARAMS
- typedef CK\_CMS\_SIG\_PARAMS CK\_PTR CK\_CMS\_SIG\_PARAMS\_PTR
- typedef struct CK\_KEY\_DERIVATION\_STRING\_DATA CK\_KEY\_DERIVATION\_STRING\_DATA
- typedef CK KEY DERIVATION STRING DATA CK PTR CK KEY DERIVATION STRING DATA PTR
- typedef CK\_ULONG CK\_EXTRACT\_PARAMS
- typedef CK EXTRACT PARAMS CK PTR CK EXTRACT PARAMS PTR
- typedef CK ULONG CK PKCS5 PBKD2 PSEUDO RANDOM FUNCTION TYPE
- typedef CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE CK\_PTR CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_F

- typedef CK ULONG CK PKCS5 PBKDF2 SALT SOURCE TYPE
- typedef CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE CK\_PTR CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE\_PTR
- typedef struct CK PKCS5 PBKD2 PARAMS CK PKCS5 PBKD2 PARAMS
- typedef CK PKCS5 PBKD2 PARAMS CK PTR CK PKCS5 PBKD2 PARAMS PTR
- typedef struct CK PKCS5 PBKD2 PARAMS2 CK PKCS5 PBKD2 PARAMS2
- typedef CK PKCS5 PBKD2 PARAMS2 CK PTR CK PKCS5 PBKD2 PARAMS2 PTR
- typedef CK\_ULONG CK\_OTP\_PARAM\_TYPE
- typedef CK\_OTP\_PARAM\_TYPE CK\_PARAM\_TYPE
- typedef struct CK OTP PARAM CK OTP PARAM
- typedef CK\_OTP\_PARAM CK\_PTR CK\_OTP\_PARAM\_PTR
- typedef struct CK\_OTP\_PARAMS CK\_OTP\_PARAMS
- typedef CK\_OTP\_PARAMS CK\_PTR CK\_OTP\_PARAMS\_PTR
- typedef struct CK\_OTP\_SIGNATURE\_INFO CK\_OTP\_SIGNATURE\_INFO
- typedef CK OTP SIGNATURE INFO CK PTR CK OTP SIGNATURE INFO PTR
- typedef struct CK KIP PARAMS CK KIP PARAMS
- typedef CK\_KIP\_PARAMS CK\_PTR CK\_KIP\_PARAMS\_PTR
- typedef struct CK AES CTR PARAMS CK AES CTR PARAMS
- typedef CK\_AES\_CTR\_PARAMS CK\_PTR CK\_AES\_CTR\_PARAMS\_PTR
- typedef struct CK GCM PARAMS CK GCM PARAMS
- typedef CK GCM PARAMS CK PTR CK GCM PARAMS PTR
- typedef struct CK\_CCM\_PARAMS CK\_CCM\_PARAMS
- typedef CK CCM PARAMS CK PTR CK CCM PARAMS PTR
- typedef struct CK\_AES\_GCM\_PARAMS CK\_AES\_GCM\_PARAMS
- typedef CK\_AES\_GCM\_PARAMS CK\_PTR CK\_AES\_GCM\_PARAMS\_PTR
- typedef struct CK AES CCM PARAMS CK AES CCM PARAMS
- typedef CK\_AES\_CCM\_PARAMS CK\_PTR CK\_AES\_CCM\_PARAMS\_PTR
- typedef struct CK\_CAMELLIA\_CTR\_PARAMS CK\_CAMELLIA\_CTR\_PARAMS
- typedef CK\_CAMELLIA\_CTR\_PARAMS CK\_PTR CK\_CAMELLIA\_CTR\_PARAMS\_PTR
- typedef struct CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS
- typedef CK CAMELLIA CBC ENCRYPT DATA PARAMS CK PTR CK CAMELLIA CBC ENCRYPT DATA PARAMS PTI
- typedef struct CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS
- typedef CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR
- typedef struct CK\_DSA\_PARAMETER\_GEN\_PARAM CK\_DSA\_PARAMETER\_GEN\_PARAM
- typedef CK\_DSA\_PARAMETER\_GEN\_PARAM CK\_PTR CK\_DSA\_PARAMETER\_GEN\_PARAM\_PTR
- typedef struct CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS
- typedef CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS CK\_PTR CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS\_PTR
- typedef CK\_ULONG CK\_JAVA\_MIDP\_SECURITY\_DOMAIN
- typedef CK\_ULONG CK\_CERTIFICATE\_CATEGORY
- typedef struct CK\_RSA\_AES\_KEY\_WRAP\_PARAMS CK\_RSA\_AES\_KEY\_WRAP\_PARAMS
- typedef CK RSA AES KEY WRAP PARAMS CK PTR CK RSA AES KEY WRAP PARAMS PTR
- typedef struct CK TLS12 MASTER KEY DERIVE PARAMS CK TLS12 MASTER KEY DERIVE PARAMS
- typedef CK TLS12 MASTER KEY DERIVE PARAMS CK PTR CK TLS12 MASTER KEY DERIVE PARAMS PTR
- typedef struct CK\_TLS12\_KEY\_MAT\_PARAMS CK\_TLS12\_KEY\_MAT\_PARAMS
- typedef CK\_TLS12\_KEY\_MAT\_PARAMS CK\_PTR CK\_TLS12\_KEY\_MAT\_PARAMS\_PTR
- typedef struct CK\_TLS\_KDF\_PARAMS CK\_TLS\_KDF\_PARAMS
- typedef CK\_TLS\_KDF\_PARAMS CK\_PTR CK\_TLS\_KDF\_PARAMS\_PTR
- typedef struct CK\_TLS\_MAC\_PARAMS CK\_TLS\_MAC\_PARAMS
- typedef CK\_TLS\_MAC\_PARAMS CK\_PTR CK\_TLS\_MAC\_PARAMS\_PTR
- typedef struct CK\_GOSTR3410\_DERIVE\_PARAMS CK\_GOSTR3410\_DERIVE\_PARAMS
- typedef CK\_GOSTR3410\_DERIVE\_PARAMS CK\_PTR CK\_GOSTR3410\_DERIVE\_PARAMS\_PTR
- typedef struct CK GOSTR3410 KEY WRAP PARAMS CK GOSTR3410 KEY WRAP PARAMS
- typedef CK GOSTR3410 KEY WRAP PARAMS CK PTR CK GOSTR3410 KEY WRAP PARAMS PTR
- typedef struct CK SEED CBC ENCRYPT DATA PARAMS CK SEED CBC ENCRYPT DATA PARAMS
- typedef CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

#### **Functions**

- typedef CK CALLBACK FUNCTION (CK RV, CK NOTIFY)(CK SESSION HANDLE hSession
- typedef CK\_CALLBACK\_FUNCTION (CK\_RV, CK\_CREATEMUTEX)(CK\_VOID\_PTR\_PTR ppMutex)
- typedef CK\_CALLBACK\_FUNCTION (CK\_RV, CK\_DESTROYMUTEX)(CK\_VOID\_PTR pMutex)
- typedef CK\_CALLBACK\_FUNCTION (CK\_RV, CK\_LOCKMUTEX)(CK\_VOID\_PTR pMutex)
- typedef CK CALLBACK FUNCTION (CK RV, CK UNLOCKMUTEX)(CK VOID PTR pMutex)

#### 20.166.1 Macro Definition Documentation

#### 20.166.1.1 CK CERTIFICATE CATEGORY AUTHORITY

#define CK\_CERTIFICATE\_CATEGORY\_AUTHORITY 2UL

#### 20.166.1.2 CK\_CERTIFICATE\_CATEGORY\_OTHER\_ENTITY

#define CK\_CERTIFICATE\_CATEGORY\_OTHER\_ENTITY 3UL

#### 20.166.1.3 CK\_CERTIFICATE\_CATEGORY\_TOKEN\_USER

#define CK\_CERTIFICATE\_CATEGORY\_TOKEN\_USER 1UL

#### 20.166.1.4 CK CERTIFICATE CATEGORY UNSPECIFIED

#define CK\_CERTIFICATE\_CATEGORY\_UNSPECIFIED OUL

## 20.166.1.5 CK\_EFFECTIVELY\_INFINITE

#define CK\_EFFECTIVELY\_INFINITE OUL

#### 20.166.1.6 CK\_FALSE

#define CK\_FALSE 0

### 20.166.1.7 CK\_INVALID\_HANDLE

#define CK\_INVALID\_HANDLE OUL

### 20.166.1.8 CK\_OTP\_CHALLENGE

#define CK\_OTP\_CHALLENGE 2UL

## 20.166.1.9 CK\_OTP\_COUNTER

#define CK\_OTP\_COUNTER 4UL

#### 20.166.1.10 CK\_OTP\_FLAGS

#define CK\_OTP\_FLAGS 5UL

## 20.166.1.11 CK\_OTP\_FORMAT\_ALPHANUMERIC

#define CK\_OTP\_FORMAT\_ALPHANUMERIC 2UL

### 20.166.1.12 CK\_OTP\_FORMAT\_BINARY

#define CK\_OTP\_FORMAT\_BINARY 3UL

## 20.166.1.13 CK\_OTP\_FORMAT\_DECIMAL

#define CK\_OTP\_FORMAT\_DECIMAL OUL

### 20.166.1.14 CK\_OTP\_FORMAT\_HEXADECIMAL

#define CK\_OTP\_FORMAT\_HEXADECIMAL 1UL

## 20.166.1.15 CK\_OTP\_OUTPUT\_FORMAT

#define CK\_OTP\_OUTPUT\_FORMAT 7UL

### 20.166.1.16 CK\_OTP\_OUTPUT\_LENGTH

#define CK\_OTP\_OUTPUT\_LENGTH 6UL

### 20.166.1.17 CK\_OTP\_PARAM\_IGNORED

#define CK\_OTP\_PARAM\_IGNORED OUL

#### 20.166.1.18 CK\_OTP\_PARAM\_MANDATORY

#define CK\_OTP\_PARAM\_MANDATORY 2UL

## 20.166.1.19 CK\_OTP\_PARAM\_OPTIONAL

#define CK\_OTP\_PARAM\_OPTIONAL 1UL

### 20.166.1.20 CK\_OTP\_PIN

#define CK\_OTP\_PIN 1UL

## 20.166.1.21 CK\_OTP\_TIME

#define CK\_OTP\_TIME 3UL

#### 20.166.1.22 CK\_OTP\_VALUE

#define CK\_OTP\_VALUE OUL

### 20.166.1.23 CK\_SECURITY\_DOMAIN\_MANUFACTURER

#define CK\_SECURITY\_DOMAIN\_MANUFACTURER 1UL

### 20.166.1.24 CK\_SECURITY\_DOMAIN\_OPERATOR

#define CK\_SECURITY\_DOMAIN\_OPERATOR 2UL

## 20.166.1.25 CK\_SECURITY\_DOMAIN\_THIRD\_PARTY

#define CK\_SECURITY\_DOMAIN\_THIRD\_PARTY 3UL

#### 20.166.1.26 CK\_SECURITY\_DOMAIN\_UNSPECIFIED

#define CK\_SECURITY\_DOMAIN\_UNSPECIFIED OUL

### 20.166.1.27 CK\_TRUE

#define CK\_TRUE 1

#### 20.166.1.28 CK UNAVAILABLE INFORMATION

#define CK\_UNAVAILABLE\_INFORMATION ( $\sim$ 0UL)

### 20.166.1.29 CKA\_AC\_ISSUER

#define CKA\_AC\_ISSUER 0x00000083UL

#### 20.166.1.30 CKA\_ALLOWED\_MECHANISMS

#define CKA\_ALLOWED\_MECHANISMS (CKF\_ARRAY\_ATTRIBUTE | 0x00000600UL)

#### 20.166.1.31 CKA\_ALWAYS\_AUTHENTICATE

#define CKA\_ALWAYS\_AUTHENTICATE 0x00000202UL

### 20.166.1.32 CKA\_ALWAYS\_SENSITIVE

#define CKA\_ALWAYS\_SENSITIVE 0x00000165UL

### 20.166.1.33 CKA\_APPLICATION

#define CKA\_APPLICATION 0x00000010UL

#### 20.166.1.34 CKA\_ATTR\_TYPES

#define CKA\_ATTR\_TYPES 0x00000085UL

## 20.166.1.35 CKA\_AUTH\_PIN\_FLAGS

 $\texttt{\#define CKA\_AUTH\_PIN\_FLAGS 0x00000201UL /* Deprecated */}$ 

#### 20.166.1.36 CKA BASE

#define CKA\_BASE 0x00000132UL

### 20.166.1.37 CKA\_BITS\_PER\_PIXEL

#define CKA\_BITS\_PER\_PIXEL 0x00000406UL

#### 20.166.1.38 CKA\_CERTIFICATE\_CATEGORY

#define CKA\_CERTIFICATE\_CATEGORY 0x00000087UL

### 20.166.1.39 CKA\_CERTIFICATE\_TYPE

#define CKA\_CERTIFICATE\_TYPE 0x00000080UL

### 20.166.1.40 CKA\_CHAR\_COLUMNS

#define CKA\_CHAR\_COLUMNS 0x00000404UL

## 20.166.1.41 CKA\_CHAR\_ROWS

#define CKA\_CHAR\_ROWS 0x00000403UL

#### 20.166.1.42 CKA\_CHAR\_SETS

#define CKA\_CHAR\_SETS 0x00000480UL

## 20.166.1.43 CKA\_CHECK\_VALUE

#define CKA\_CHECK\_VALUE 0x00000090UL

#### 20.166.1.44 CKA CLASS

#define CKA\_CLASS 0x0000000UL

### 20.166.1.45 CKA\_COEFFICIENT

#define CKA\_COEFFICIENT 0x00000128UL

#### 20.166.1.46 CKA\_COLOR

#define CKA\_COLOR 0x00000405UL

### 20.166.1.47 CKA\_COPYABLE

#define CKA\_COPYABLE 0x00000171UL

### 20.166.1.48 CKA\_DECRYPT

#define CKA\_DECRYPT 0x00000105UL

### 20.166.1.49 CKA\_DEFAULT\_CMS\_ATTRIBUTES

#define CKA\_DEFAULT\_CMS\_ATTRIBUTES 0x00000502UL

#### 20.166.1.50 CKA\_DERIVE

#define CKA\_DERIVE 0x0000010CUL

## 20.166.1.51 CKA\_DERIVE\_TEMPLATE

#define CKA\_DERIVE\_TEMPLATE (CKF\_ARRAY\_ATTRIBUTE | 0x00000213UL)

#### 20.166.1.52 CKA DESTROYABLE

#define CKA\_DESTROYABLE 0x00000172UL

## 20.166.1.53 CKA\_EC\_PARAMS

#define CKA\_EC\_PARAMS 0x00000180UL

#### 20.166.1.54 CKA\_EC\_POINT

#define CKA\_EC\_POINT 0x00000181UL

#### 20.166.1.55 CKA\_ECDSA\_PARAMS

#define CKA\_ECDSA\_PARAMS 0x00000180UL /\* Deprecated \*/

### 20.166.1.56 CKA\_ENCODING\_METHODS

#define CKA\_ENCODING\_METHODS 0x00000481UL

### 20.166.1.57 CKA\_ENCRYPT

#define CKA\_ENCRYPT 0x00000104UL

#### 20.166.1.58 CKA\_END\_DATE

#define CKA\_END\_DATE 0x00000111UL

## 20.166.1.59 CKA\_EXPONENT\_1

#define CKA\_EXPONENT\_1 0x00000126UL

### 20.166.1.60 CKA\_EXPONENT\_2

#define CKA\_EXPONENT\_2 0x00000127UL

## 20.166.1.61 CKA\_EXTRACTABLE

#define CKA\_EXTRACTABLE 0x00000162UL

#### 20.166.1.62 CKA\_GOST28147\_PARAMS

#define CKA\_GOST28147\_PARAMS 0x00000252UL

### 20.166.1.63 CKA\_GOSTR3410\_PARAMS

#define CKA\_GOSTR3410\_PARAMS 0x00000250UL

### 20.166.1.64 CKA\_GOSTR3411\_PARAMS

#define CKA\_GOSTR3411\_PARAMS 0x00000251UL

### 20.166.1.65 CKA\_HAS\_RESET

#define CKA\_HAS\_RESET 0x00000302UL

### 20.166.1.66 CKA\_HASH\_OF\_ISSUER\_PUBLIC\_KEY

#define CKA\_HASH\_OF\_ISSUER\_PUBLIC\_KEY 0x0000008BUL

### 20.166.1.67 CKA\_HASH\_OF\_SUBJECT\_PUBLIC\_KEY

#define CKA\_HASH\_OF\_SUBJECT\_PUBLIC\_KEY 0x0000008AUL

### 20.166.1.68 CKA\_HW\_FEATURE\_TYPE

#define CKA\_HW\_FEATURE\_TYPE 0x00000300UL

## 20.166.1.69 CKA\_ID

#define CKA\_ID 0x00000102UL

#### 20.166.1.70 CKA\_ISSUER

#define CKA\_ISSUER 0x00000081UL

## 20.166.1.71 CKA\_JAVA\_MIDP\_SECURITY\_DOMAIN

#define CKA\_JAVA\_MIDP\_SECURITY\_DOMAIN 0x00000088UL

### 20.166.1.72 CKA\_KEY\_GEN\_MECHANISM

#define CKA\_KEY\_GEN\_MECHANISM 0x00000166UL

### 20.166.1.73 CKA\_KEY\_TYPE

#define CKA\_KEY\_TYPE 0x00000100UL

#### 20.166.1.74 CKA\_LABEL

#define CKA\_LABEL 0x0000003UL

## 20.166.1.75 CKA\_LOCAL

#define CKA\_LOCAL 0x00000163UL

### 20.166.1.76 CKA\_MECHANISM\_TYPE

#define CKA\_MECHANISM\_TYPE 0x00000500UL

### 20.166.1.77 CKA\_MIME\_TYPES

#define CKA\_MIME\_TYPES 0x00000482UL

#### 20.166.1.78 CKA\_MODIFIABLE

#define CKA\_MODIFIABLE 0x00000170UL

### 20.166.1.79 CKA\_MODULUS

#define CKA\_MODULUS 0x00000120UL

### 20.166.1.80 CKA\_MODULUS\_BITS

#define CKA\_MODULUS\_BITS 0x00000121UL

### 20.166.1.81 CKA\_NAME\_HASH\_ALGORITHM

#define CKA\_NAME\_HASH\_ALGORITHM 0x0000008CUL

#### 20.166.1.82 CKA\_NEVER\_EXTRACTABLE

#define CKA\_NEVER\_EXTRACTABLE 0x00000164UL

## 20.166.1.83 CKA\_OBJECT\_ID

#define CKA\_OBJECT\_ID 0x00000012UL

#### 20.166.1.84 CKA\_OTP\_CHALLENGE\_REQUIREMENT

#define CKA\_OTP\_CHALLENGE\_REQUIREMENT 0x00000224UL

### 20.166.1.85 CKA\_OTP\_COUNTER

#define CKA\_OTP\_COUNTER 0x0000022EUL

#### 20.166.1.86 CKA\_OTP\_COUNTER\_REQUIREMENT

#define CKA\_OTP\_COUNTER\_REQUIREMENT 0x00000226UL

### 20.166.1.87 CKA\_OTP\_FORMAT

#define CKA\_OTP\_FORMAT 0x00000220UL

### 20.166.1.88 CKA\_OTP\_LENGTH

#define CKA\_OTP\_LENGTH 0x00000221UL

### 20.166.1.89 CKA\_OTP\_PIN\_REQUIREMENT

#define CKA\_OTP\_PIN\_REQUIREMENT 0x00000227UL

#### 20.166.1.90 CKA\_OTP\_SERVICE\_IDENTIFIER

#define CKA\_OTP\_SERVICE\_IDENTIFIER 0x0000022BUL

## 20.166.1.91 CKA\_OTP\_SERVICE\_LOGO

#define CKA\_OTP\_SERVICE\_LOGO 0x0000022CUL

### 20.166.1.92 CKA\_OTP\_SERVICE\_LOGO\_TYPE

#define CKA\_OTP\_SERVICE\_LOGO\_TYPE 0x0000022DUL

## 20.166.1.93 CKA\_OTP\_TIME

#define CKA\_OTP\_TIME 0x0000022FUL

#### 20.166.1.94 CKA\_OTP\_TIME\_INTERVAL

#define CKA\_OTP\_TIME\_INTERVAL 0x00000222UL

## 20.166.1.95 CKA\_OTP\_TIME\_REQUIREMENT

#define CKA\_OTP\_TIME\_REQUIREMENT 0x00000225UL

## 20.166.1.96 CKA\_OTP\_USER\_FRIENDLY\_MODE

#define CKA\_OTP\_USER\_FRIENDLY\_MODE 0x00000223UL

### 20.166.1.97 CKA\_OTP\_USER\_IDENTIFIER

#define CKA\_OTP\_USER\_IDENTIFIER 0x0000022AUL

#### 20.166.1.98 CKA\_OWNER

#define CKA\_OWNER 0x00000084UL

## 20.166.1.99 CKA\_PIXEL\_X

#define CKA\_PIXEL\_X 0x00000400UL

### 20.166.1.100 CKA\_PIXEL\_Y

#define CKA\_PIXEL\_Y 0x00000401UL

## 20.166.1.101 CKA\_PRIME

#define CKA\_PRIME 0x00000130UL

#### 20.166.1.102 CKA\_PRIME\_1

#define CKA\_PRIME\_1 0x00000124UL

#### 20.166.1.103 CKA\_PRIME\_2

#define CKA\_PRIME\_2 0x00000125UL

### 20.166.1.104 CKA\_PRIME\_BITS

#define CKA\_PRIME\_BITS 0x00000133UL

## 20.166.1.105 CKA\_PRIVATE

#define CKA\_PRIVATE 0x00000002UL

#### 20.166.1.106 CKA\_PRIVATE\_EXPONENT

#define CKA\_PRIVATE\_EXPONENT 0x00000123UL

## 20.166.1.107 CKA\_PUBLIC\_EXPONENT

#define CKA\_PUBLIC\_EXPONENT 0x00000122UL

### 20.166.1.108 CKA\_PUBLIC\_KEY\_INFO

#define CKA\_PUBLIC\_KEY\_INFO 0x00000129UL

## 20.166.1.109 CKA\_REQUIRED\_CMS\_ATTRIBUTES

#define CKA\_REQUIRED\_CMS\_ATTRIBUTES 0x00000501UL

### 20.166.1.110 CKA\_RESET\_ON\_INIT

#define CKA\_RESET\_ON\_INIT 0x00000301UL

### 20.166.1.111 CKA\_RESOLUTION

#define CKA\_RESOLUTION 0x00000402UL

### 20.166.1.112 CKA\_SECONDARY\_AUTH

#define CKA\_SECONDARY\_AUTH 0x00000200UL /\* Deprecated \*/

## 20.166.1.113 CKA\_SENSITIVE

#define CKA\_SENSITIVE 0x00000103UL

#### 20.166.1.114 CKA\_SERIAL\_NUMBER

#define CKA\_SERIAL\_NUMBER 0x00000082UL

## 20.166.1.115 CKA\_SIGN

#define CKA\_SIGN 0x00000108UL

### 20.166.1.116 CKA\_SIGN\_RECOVER

#define CKA\_SIGN\_RECOVER 0x00000109UL

# 20.166.1.117 CKA\_START\_DATE

#define CKA\_START\_DATE 0x00000110UL

## 20.166.1.118 CKA\_SUB\_PRIME\_BITS

#define CKA\_SUB\_PRIME\_BITS CKA\_SUBPRIME\_BITS

### 20.166.1.119 CKA\_SUBJECT

#define CKA\_SUBJECT 0x00000101UL

### 20.166.1.120 CKA\_SUBPRIME

#define CKA\_SUBPRIME 0x00000131UL

## 20.166.1.121 CKA\_SUBPRIME\_BITS

#define CKA\_SUBPRIME\_BITS 0x00000134UL

#### 20.166.1.122 CKA\_SUPPORTED\_CMS\_ATTRIBUTES

#define CKA\_SUPPORTED\_CMS\_ATTRIBUTES 0x00000503UL

## 20.166.1.123 CKA\_TOKEN

#define CKA\_TOKEN 0x0000001UL

### 20.166.1.124 CKA\_TRUSTED

#define CKA\_TRUSTED 0x00000086UL

## 20.166.1.125 CKA\_UNWRAP

#define CKA\_UNWRAP 0x00000107UL

## 20.166.1.126 CKA\_UNWRAP\_TEMPLATE

#define CKA\_UNWRAP\_TEMPLATE (CKF\_ARRAY\_ATTRIBUTE | 0x00000212UL)

## 20.166.1.127 CKA\_URL

#define CKA\_URL 0x00000089UL

### 20.166.1.128 CKA\_VALUE

#define CKA\_VALUE 0x00000011UL

### 20.166.1.129 CKA\_VALUE\_BITS

#define CKA\_VALUE\_BITS 0x00000160UL

### 20.166.1.130 CKA\_VALUE\_LEN

#define CKA\_VALUE\_LEN 0x00000161UL

## 20.166.1.131 CKA\_VENDOR\_DEFINED

 $\verb|#define CKA_VENDOR_DEFINED 0x8000000UL|\\$ 

### 20.166.1.132 CKA\_VERIFY

#define CKA\_VERIFY 0x0000010AUL

## 20.166.1.133 CKA\_VERIFY\_RECOVER

#define CKA\_VERIFY\_RECOVER 0x0000010BUL

#### 20.166.1.134 CKA\_WRAP

#define CKA\_WRAP 0x0000106UL

## 20.166.1.135 CKA\_WRAP\_TEMPLATE

#define CKA\_WRAP\_TEMPLATE (CKF\_ARRAY\_ATTRIBUTE | 0x00000211UL)

### 20.166.1.136 CKA\_WRAP\_WITH\_TRUSTED

#define CKA\_WRAP\_WITH\_TRUSTED 0x00000210UL

## 20.166.1.137 CKC\_OPENPGP

#define CKC\_OPENPGP (CKC\_VENDOR\_DEFINED | 0x00504750)

#### 20.166.1.138 CKC\_VENDOR\_DEFINED

#define CKC\_VENDOR\_DEFINED 0x8000000UL

## 20.166.1.139 CKC\_WTLS

#define CKC\_WTLS 0x00000002UL

#### 20.166.1.140 CKC X 509

#define CKC\_X\_509 0x0000000UL

### 20.166.1.141 CKC\_X\_509\_ATTR\_CERT

#define CKC\_X\_509\_ATTR\_CERT 0x00000001UL

#### 20.166.1.142 CKD\_CPDIVERSIFY\_KDF

#define CKD\_CPDIVERSIFY\_KDF 0x0000009UL

## 20.166.1.143 CKD\_NULL

#define CKD\_NULL 0x0000001UL

### 20.166.1.144 CKD\_SHA1\_KDF

#define CKD\_SHA1\_KDF 0x00000002UL

### 20.166.1.145 CKD\_SHA1\_KDF\_ASN1

#define CKD\_SHA1\_KDF\_ASN1 0x0000003UL

#### 20.166.1.146 CKD\_SHA1\_KDF\_CONCATENATE

#define CKD\_SHA1\_KDF\_CONCATENATE 0x00000004UL

## 20.166.1.147 CKD\_SHA224\_KDF

#define CKD\_SHA224\_KDF 0x00000005UL

### 20.166.1.148 CKD\_SHA256\_KDF

#define CKD\_SHA256\_KDF 0x00000006UL

### 20.166.1.149 CKD\_SHA384\_KDF

#define CKD\_SHA384\_KDF 0x0000007UL

## 20.166.1.150 CKD\_SHA512\_KDF

#define CKD\_SHA512\_KDF 0x00000008UL

## 20.166.1.151 CKF\_ARRAY\_ATTRIBUTE

#define CKF\_ARRAY\_ATTRIBUTE 0x4000000UL

### 20.166.1.152 CKF\_CLOCK\_ON\_TOKEN

#define CKF\_CLOCK\_ON\_TOKEN 0x00000040UL

## 20.166.1.153 CKF\_DECRYPT

#define CKF\_DECRYPT 0x00000200UL

#### 20.166.1.154 CKF\_DERIVE

#define CKF\_DERIVE 0x00080000UL

## 20.166.1.155 CKF\_DIGEST

#define CKF\_DIGEST 0x00000400UL

### 20.166.1.156 CKF\_DONT\_BLOCK

#define CKF\_DONT\_BLOCK 1

## 20.166.1.157 CKF\_DUAL\_CRYPTO\_OPERATIONS

#define CKF\_DUAL\_CRYPTO\_OPERATIONS 0x00000200UL

# 20.166.1.158 CKF\_EC\_COMPRESS

#define CKF\_EC\_COMPRESS 0x0200000UL

# 20.166.1.159 CKF\_EC\_ECPARAMETERS

#define CKF\_EC\_ECPARAMETERS 0x00400000UL

### 20.166.1.160 CKF\_EC\_F\_2M

#define CKF\_EC\_F\_2M 0x00200000UL

## 20.166.1.161 CKF\_EC\_F\_P

#define CKF\_EC\_F\_P 0x00100000UL

#### 20.166.1.162 CKF\_EC\_NAMEDCURVE

#define CKF\_EC\_NAMEDCURVE 0x00800000UL

## 20.166.1.163 CKF\_EC\_UNCOMPRESS

#define CKF\_EC\_UNCOMPRESS 0x01000000UL

### 20.166.1.164 CKF\_ENCRYPT

#define CKF\_ENCRYPT 0x00000100UL

## 20.166.1.165 CKF\_ERROR\_STATE

#define CKF\_ERROR\_STATE 0x01000000UL

## 20.166.1.166 CKF\_EXCLUDE\_CHALLENGE

#define CKF\_EXCLUDE\_CHALLENGE 0x00000008UL

### 20.166.1.167 CKF\_EXCLUDE\_COUNTER

#define CKF\_EXCLUDE\_COUNTER 0x00000004UL

### 20.166.1.168 CKF\_EXCLUDE\_PIN

#define CKF\_EXCLUDE\_PIN 0x00000010UL

## 20.166.1.169 CKF\_EXCLUDE\_TIME

#define CKF\_EXCLUDE\_TIME 0x00000002UL

#### 20.166.1.170 CKF\_EXTENSION

#define CKF\_EXTENSION 0x8000000UL

## 20.166.1.171 CKF\_GENERATE

#define CKF\_GENERATE 0x00008000UL

### 20.166.1.172 CKF\_GENERATE\_KEY\_PAIR

#define CKF\_GENERATE\_KEY\_PAIR 0x00010000UL

## 20.166.1.173 CKF\_HW

#define CKF\_HW 0x0000001UL /\* performed by HW \*/

### 20.166.1.174 CKF\_HW\_SLOT

#define CKF\_HW\_SLOT 0x00000004UL /\* hardware slot \*/

# 20.166.1.175 CKF\_LIBRARY\_CANT\_CREATE\_OS\_THREADS

#define CKF\_LIBRARY\_CANT\_CREATE\_OS\_THREADS 0x0000001UL

## 20.166.1.176 CKF\_LOGIN\_REQUIRED

#define CKF\_LOGIN\_REQUIRED 0x00000004UL /\* user must login \*/

### 20.166.1.177 CKF\_NEXT\_OTP

#define CKF\_NEXT\_OTP 0x0000001UL

#### 20.166.1.178 CKF\_OS\_LOCKING\_OK

#define CKF\_OS\_LOCKING\_OK 0x00000002UL

### 20.166.1.179 CKF\_PROTECTED\_AUTHENTICATION\_PATH

#define CKF\_PROTECTED\_AUTHENTICATION\_PATH 0x00000100UL

#### 20.166.1.180 CKF\_REMOVABLE\_DEVICE

#define CKF\_REMOVABLE\_DEVICE 0x00000002UL /\* removable devices\*/

## 20.166.1.181 CKF\_RESTORE\_KEY\_NOT\_NEEDED

#define CKF\_RESTORE\_KEY\_NOT\_NEEDED 0x00000020UL

#### 20.166.1.182 CKF\_RNG

 $\#define\ CKF\_RNG\ 0x0000001UL\ /* has random <math display="inline">\#\ generator\ */$ 

# 20.166.1.183 CKF\_RW\_SESSION

#define CKF\_RW\_SESSION  $0 \times 000000002$ UL /\* session is r/w \*/

### 20.166.1.184 CKF\_SECONDARY\_AUTHENTICATION

#define CKF\_SECONDARY\_AUTHENTICATION 0x00000800UL

### 20.166.1.185 CKF\_SERIAL\_SESSION

#define CKF\_SERIAL\_SESSION 0x00000004UL /\* no parallel \*/

#### 20.166.1.186 CKF\_SIGN

#define CKF\_SIGN 0x00000800UL

## 20.166.1.187 CKF\_SIGN\_RECOVER

#define CKF\_SIGN\_RECOVER 0x00001000UL

### 20.166.1.188 CKF\_SO\_PIN\_COUNT\_LOW

#define CKF\_SO\_PIN\_COUNT\_LOW 0x00100000UL

## 20.166.1.189 CKF\_SO\_PIN\_FINAL\_TRY

#define CKF\_SO\_PIN\_FINAL\_TRY 0x00200000UL

#### 20.166.1.190 CKF\_SO\_PIN\_LOCKED

#define CKF\_SO\_PIN\_LOCKED 0x0040000UL

# 20.166.1.191 CKF\_SO\_PIN\_TO\_BE\_CHANGED

#define CKF\_SO\_PIN\_TO\_BE\_CHANGED 0x00800000UL

### 20.166.1.192 CKF\_TOKEN\_INITIALIZED

#define CKF\_TOKEN\_INITIALIZED 0x00000400UL

### 20.166.1.193 CKF\_TOKEN\_PRESENT

#define CKF\_TOKEN\_PRESENT 0x0000001UL /\* a token is there \*/

#### 20.166.1.194 CKF\_UNWRAP

#define CKF\_UNWRAP 0x00040000UL

## 20.166.1.195 CKF\_USER\_FRIENDLY\_OTP

#define CKF\_USER\_FRIENDLY\_OTP 0x00000020UL

#### 20.166.1.196 CKF\_USER\_PIN\_COUNT\_LOW

#define CKF\_USER\_PIN\_COUNT\_LOW 0x00010000UL

### 20.166.1.197 CKF\_USER\_PIN\_FINAL\_TRY

#define CKF\_USER\_PIN\_FINAL\_TRY 0x00020000UL

#### 20.166.1.198 CKF\_USER\_PIN\_INITIALIZED

#define CKF\_USER\_PIN\_INITIALIZED 0x0000008UL /\* normal user's PIN is set \*/

### 20.166.1.199 CKF\_USER\_PIN\_LOCKED

#define CKF\_USER\_PIN\_LOCKED 0x00040000UL

## 20.166.1.200 CKF\_USER\_PIN\_TO\_BE\_CHANGED

#define CKF\_USER\_PIN\_TO\_BE\_CHANGED 0x00080000UL

## 20.166.1.201 CKF\_VERIFY

#define CKF\_VERIFY 0x00002000UL

#### 20.166.1.202 CKF\_VERIFY\_RECOVER

#define CKF\_VERIFY\_RECOVER 0x00004000UL

# 20.166.1.203 CKF\_WRAP

#define CKF\_WRAP 0x00020000UL

### 20.166.1.204 CKF\_WRITE\_PROTECTED

#define CKF\_WRITE\_PROTECTED 0x0000002UL /\* token is write-protected \*/

## 20.166.1.205 CKG\_MGF1\_SHA1

#define CKG\_MGF1\_SHA1 0x0000001UL

#### 20.166.1.206 CKG\_MGF1\_SHA224

 $\texttt{\#define CKG\_MGF1\_SHA224 0x00000005UL}$ 

## 20.166.1.207 CKG\_MGF1\_SHA256

#define CKG\_MGF1\_SHA256 0x00000002UL

### 20.166.1.208 CKG\_MGF1\_SHA384

#define CKG\_MGF1\_SHA384 0x00000003UL

### 20.166.1.209 CKG\_MGF1\_SHA512

#define CKG\_MGF1\_SHA512 0x00000004UL

#### 20.166.1.210 CKH\_CLOCK

#define CKH\_CLOCK 0x00000002UL

## 20.166.1.211 CKH\_MONOTONIC\_COUNTER

#define CKH\_MONOTONIC\_COUNTER 0x00000001UL

### 20.166.1.212 CKH\_USER\_INTERFACE

#define CKH\_USER\_INTERFACE 0x0000003UL

# 20.166.1.213 CKH\_VENDOR\_DEFINED

#define CKH\_VENDOR\_DEFINED 0x8000000UL

#### 20.166.1.214 CKK\_ACTI

#define CKK\_ACTI 0x00000024UL

### 20.166.1.215 CKK\_AES

#define CKK\_AES 0x000001FUL

### 20.166.1.216 CKK\_ARIA

#define CKK\_ARIA 0x00000026UL

## 20.166.1.217 CKK\_BATON

#define CKK\_BATON 0x000001CUL

#### 20.166.1.218 CKK\_BLOWFISH

#define CKK\_BLOWFISH 0x00000020UL

## 20.166.1.219 CKK\_CAMELLIA

#define CKK\_CAMELLIA 0x00000025UL

### 20.166.1.220 CKK\_CAST

#define CKK\_CAST 0x00000016UL

# 20.166.1.221 CKK\_CAST128

#define CKK\_CAST128 0x00000018UL

### 20.166.1.222 CKK\_CAST3

#define CKK\_CAST3 0x0000017UL

## 20.166.1.223 CKK\_CAST5

#define CKK\_CAST5 0x00000018UL /\* Deprecated \*/

### 20.166.1.224 CKK\_CDMF

#define CKK\_CDMF 0x000001EUL

## 20.166.1.225 CKK\_DES

#define CKK\_DES 0x00000013UL

#### 20.166.1.226 CKK\_DES2

#define CKK\_DES2 0x00000014UL

## 20.166.1.227 CKK\_DES3

#define CKK\_DES3 0x00000015UL

### 20.166.1.228 CKK\_DH

#define CKK\_DH 0x00000002UL

## 20.166.1.229 CKK\_DSA

#define CKK\_DSA 0x0000001UL

### 20.166.1.230 CKK\_EC

#define CKK\_EC 0x0000003UL

## 20.166.1.231 CKK\_ECDSA

#define CKK\_ECDSA 0x0000003UL /\* Deprecated \*/

### 20.166.1.232 CKK\_GENERIC\_SECRET

#define CKK\_GENERIC\_SECRET 0x00000010UL

## 20.166.1.233 CKK\_GOST28147

#define CKK\_GOST28147 0x00000032UL

#### 20.166.1.234 CKK\_GOSTR3410

#define CKK\_GOSTR3410 0x00000030UL

## 20.166.1.235 CKK\_GOSTR3411

#define CKK\_GOSTR3411 0x00000031UL

#### 20.166.1.236 CKK HOTP

#define CKK\_HOTP 0x00000023UL

## 20.166.1.237 CKK\_IDEA

#define CKK\_IDEA 0x0000001AUL

#### 20.166.1.238 CKK\_JUNIPER

#define CKK\_JUNIPER 0x000001DUL

## 20.166.1.239 CKK\_KEA

#define CKK\_KEA 0x0000005UL

## 20.166.1.240 CKK\_MD5\_HMAC

#define CKK\_MD5\_HMAC 0x00000027UL

## 20.166.1.241 CKK\_RC2

#define CKK\_RC2 0x00000011UL

### 20.166.1.242 CKK\_RC4

#define CKK\_RC4 0x00000012UL

## 20.166.1.243 CKK\_RC5

#define CKK\_RC5 0x00000019UL

## 20.166.1.244 CKK\_RIPEMD128\_HMAC

#define CKK\_RIPEMD128\_HMAC 0x00000029UL

# 20.166.1.245 CKK\_RIPEMD160\_HMAC

#define CKK\_RIPEMD160\_HMAC 0x0000002AUL

### 20.166.1.246 CKK\_RSA

#define CKK\_RSA 0x0000000UL

## 20.166.1.247 CKK\_SECURID

#define CKK\_SECURID 0x00000022UL

## 20.166.1.248 CKK\_SEED

#define CKK\_SEED 0x0000002FUL

## 20.166.1.249 CKK\_SHA224\_HMAC

#define CKK\_SHA224\_HMAC 0x0000002EUL

### 20.166.1.250 CKK\_SHA256\_HMAC

#define CKK\_SHA256\_HMAC 0x0000002BUL

## 20.166.1.251 CKK\_SHA384\_HMAC

#define CKK\_SHA384\_HMAC 0x0000002CUL

## 20.166.1.252 CKK\_SHA512\_HMAC

#define CKK\_SHA512\_HMAC 0x0000002DUL

# 20.166.1.253 CKK\_SHA\_1\_HMAC

#define CKK\_SHA\_1\_HMAC 0x00000028UL

### 20.166.1.254 CKK\_SKIPJACK

#define CKK\_SKIPJACK 0x000001BUL

## 20.166.1.255 CKK\_TWOFISH

#define CKK\_TWOFISH 0x00000021UL

## 20.166.1.256 CKK\_VENDOR\_DEFINED

#define CKK\_VENDOR\_DEFINED 0x8000000UL

## 20.166.1.257 CKK\_X9\_42\_DH

#define CKK\_X9\_42\_DH 0x0000004UL

### 20.166.1.258 CKM\_ACTI

#define CKM\_ACTI 0x000002A0UL

## 20.166.1.259 CKM\_ACTI\_KEY\_GEN

#define CKM\_ACTI\_KEY\_GEN 0x000002A1UL

## 20.166.1.260 CKM\_AES\_CBC

#define CKM\_AES\_CBC 0x00001082UL

## 20.166.1.261 CKM\_AES\_CBC\_ENCRYPT\_DATA

#define CKM\_AES\_CBC\_ENCRYPT\_DATA 0x00001105UL

### 20.166.1.262 CKM\_AES\_CBC\_PAD

#define CKM\_AES\_CBC\_PAD 0x00001085UL

## 20.166.1.263 CKM\_AES\_CCM

#define CKM\_AES\_CCM 0x00001088UL

## 20.166.1.264 CKM\_AES\_CFB1

#define CKM\_AES\_CFB1 0x00002108UL

## 20.166.1.265 CKM\_AES\_CFB128

#define CKM\_AES\_CFB128 0x00002107UL

### 20.166.1.266 CKM\_AES\_CFB64

#define CKM\_AES\_CFB64 0x00002105UL

## 20.166.1.267 CKM\_AES\_CFB8

#define CKM\_AES\_CFB8 0x00002106UL

## 20.166.1.268 CKM\_AES\_CMAC

#define CKM\_AES\_CMAC 0x0000108AUL

## 20.166.1.269 CKM\_AES\_CMAC\_GENERAL

#define CKM\_AES\_CMAC\_GENERAL 0x0000108BUL

## 20.166.1.270 CKM\_AES\_CTR

#define CKM\_AES\_CTR 0x00001086UL

## 20.166.1.271 CKM\_AES\_CTS

#define CKM\_AES\_CTS 0x00001089UL

## 20.166.1.272 CKM\_AES\_ECB

#define CKM\_AES\_ECB 0x00001081UL

## 20.166.1.273 CKM\_AES\_ECB\_ENCRYPT\_DATA

#define CKM\_AES\_ECB\_ENCRYPT\_DATA 0x00001104UL

### 20.166.1.274 CKM\_AES\_GCM

#define CKM\_AES\_GCM 0x00001087UL

## 20.166.1.275 CKM\_AES\_GMAC

#define CKM\_AES\_GMAC 0x0000108EUL

### 20.166.1.276 CKM\_AES\_KEY\_GEN

#define CKM\_AES\_KEY\_GEN 0x00001080UL

## 20.166.1.277 CKM\_AES\_KEY\_WRAP

#define CKM\_AES\_KEY\_WRAP 0x00002109UL /\* WAS: 0x00001090 \*/

## 20.166.1.278 CKM\_AES\_KEY\_WRAP\_PAD

 $\texttt{\#define CKM\_AES\_KEY\_WRAP\_PAD 0x0000210AUL /* WAS: 0x00001091 */ } \\$ 

## 20.166.1.279 CKM\_AES\_MAC

#define CKM\_AES\_MAC 0x00001083UL

## 20.166.1.280 CKM\_AES\_MAC\_GENERAL

#define CKM\_AES\_MAC\_GENERAL 0x00001084UL

## 20.166.1.281 CKM\_AES\_OFB

#define CKM\_AES\_OFB 0x00002104UL

### 20.166.1.282 CKM\_AES\_XCBC\_MAC

#define CKM\_AES\_XCBC\_MAC 0x0000108CUL

## 20.166.1.283 CKM\_AES\_XCBC\_MAC\_96

#define CKM\_AES\_XCBC\_MAC\_96 0x0000108DUL

## 20.166.1.284 CKM\_ARIA\_CBC

#define CKM\_ARIA\_CBC 0x00000562UL

## 20.166.1.285 CKM\_ARIA\_CBC\_ENCRYPT\_DATA

#define CKM\_ARIA\_CBC\_ENCRYPT\_DATA 0x00000567UL

### 20.166.1.286 CKM\_ARIA\_CBC\_PAD

#define CKM\_ARIA\_CBC\_PAD 0x00000565UL

## 20.166.1.287 CKM\_ARIA\_ECB

#define CKM\_ARIA\_ECB 0x00000561UL

## 20.166.1.288 CKM\_ARIA\_ECB\_ENCRYPT\_DATA

#define CKM\_ARIA\_ECB\_ENCRYPT\_DATA 0x00000566UL

## 20.166.1.289 CKM\_ARIA\_KEY\_GEN

#define CKM\_ARIA\_KEY\_GEN 0x00000560UL

### 20.166.1.290 CKM\_ARIA\_MAC

#define CKM\_ARIA\_MAC 0x00000563UL

## 20.166.1.291 CKM\_ARIA\_MAC\_GENERAL

#define CKM\_ARIA\_MAC\_GENERAL 0x00000564UL

### 20.166.1.292 CKM\_BATON\_CBC128

#define CKM\_BATON\_CBC128 0x00001033UL

## 20.166.1.293 CKM\_BATON\_COUNTER

#define CKM\_BATON\_COUNTER 0x00001034UL

### 20.166.1.294 CKM\_BATON\_ECB128

#define CKM\_BATON\_ECB128 0x00001031UL

### 20.166.1.295 CKM\_BATON\_ECB96

#define CKM\_BATON\_ECB96 0x00001032UL

## 20.166.1.296 CKM\_BATON\_KEY\_GEN

#define CKM\_BATON\_KEY\_GEN 0x00001030UL

## 20.166.1.297 CKM\_BATON\_SHUFFLE

#define CKM\_BATON\_SHUFFLE 0x00001035UL

### 20.166.1.298 CKM\_BATON\_WRAP

#define CKM\_BATON\_WRAP 0x00001036UL

## 20.166.1.299 CKM\_BLOWFISH\_CBC

#define CKM\_BLOWFISH\_CBC 0x00001091UL

## 20.166.1.300 CKM\_BLOWFISH\_CBC\_PAD

#define CKM\_BLOWFISH\_CBC\_PAD 0x00001094UL

## 20.166.1.301 CKM\_BLOWFISH\_KEY\_GEN

#define CKM\_BLOWFISH\_KEY\_GEN 0x00001090UL

## 20.166.1.302 CKM\_CAMELLIA\_CBC

#define CKM\_CAMELLIA\_CBC 0x00000552UL

## 20.166.1.303 CKM\_CAMELLIA\_CBC\_ENCRYPT\_DATA

#define CKM\_CAMELLIA\_CBC\_ENCRYPT\_DATA 0x00000557UL

## 20.166.1.304 CKM\_CAMELLIA\_CBC\_PAD

#define CKM\_CAMELLIA\_CBC\_PAD 0x00000555UL

## 20.166.1.305 CKM\_CAMELLIA\_CTR

#define CKM\_CAMELLIA\_CTR 0x00000558UL

### 20.166.1.306 CKM\_CAMELLIA\_ECB

#define CKM\_CAMELLIA\_ECB 0x00000551UL

# 20.166.1.307 CKM\_CAMELLIA\_ECB\_ENCRYPT\_DATA

#define CKM\_CAMELLIA\_ECB\_ENCRYPT\_DATA 0x00000556UL

#### 20.166.1.308 CKM CAMELLIA KEY GEN

#define CKM\_CAMELLIA\_KEY\_GEN 0x00000550UL

## 20.166.1.309 CKM\_CAMELLIA\_MAC

#define CKM\_CAMELLIA\_MAC 0x00000553UL

### 20.166.1.310 CKM\_CAMELLIA\_MAC\_GENERAL

#define CKM\_CAMELLIA\_MAC\_GENERAL 0x00000554UL

## 20.166.1.311 CKM\_CAST128\_CBC

#define CKM\_CAST128\_CBC 0x00000322UL

## 20.166.1.312 CKM\_CAST128\_CBC\_PAD

#define CKM\_CAST128\_CBC\_PAD 0x00000325UL

## 20.166.1.313 CKM\_CAST128\_ECB

#define CKM\_CAST128\_ECB 0x00000321UL

### 20.166.1.314 CKM\_CAST128\_KEY\_GEN

#define CKM\_CAST128\_KEY\_GEN 0x00000320UL

## 20.166.1.315 CKM\_CAST128\_MAC

#define CKM\_CAST128\_MAC 0x00000323UL

### 20.166.1.316 CKM\_CAST128\_MAC\_GENERAL

#define CKM\_CAST128\_MAC\_GENERAL 0x00000324UL

## 20.166.1.317 CKM\_CAST3\_CBC

#define CKM\_CAST3\_CBC 0x00000312UL

## 20.166.1.318 CKM\_CAST3\_CBC\_PAD

#define CKM\_CAST3\_CBC\_PAD 0x00000315UL

## 20.166.1.319 CKM\_CAST3\_ECB

#define CKM\_CAST3\_ECB 0x00000311UL

## 20.166.1.320 CKM\_CAST3\_KEY\_GEN

#define CKM\_CAST3\_KEY\_GEN 0x00000310UL

## 20.166.1.321 CKM\_CAST3\_MAC

#define CKM\_CAST3\_MAC 0x00000313UL

### 20.166.1.322 CKM\_CAST3\_MAC\_GENERAL

#define CKM\_CAST3\_MAC\_GENERAL 0x00000314UL

## 20.166.1.323 CKM\_CAST5\_CBC

#define CKM\_CAST5\_CBC 0x00000322UL /\* Deprecated \*/

### 20.166.1.324 CKM\_CAST5\_CBC\_PAD

#define CKM\_CAST5\_CBC\_PAD 0x00000325UL /\* Deprecated \*/

## 20.166.1.325 CKM\_CAST5\_ECB

#define CKM\_CAST5\_ECB 0x00000321UL

## 20.166.1.326 CKM\_CAST5\_KEY\_GEN

#define CKM\_CAST5\_KEY\_GEN 0x00000320UL

# 20.166.1.327 CKM\_CAST5\_MAC

#define CKM\_CAST5\_MAC 0x00000323UL /\* Deprecated \*/

## 20.166.1.328 CKM\_CAST5\_MAC\_GENERAL

#define CKM\_CAST5\_MAC\_GENERAL 0x00000324UL /\* Deprecated \*/

## 20.166.1.329 CKM\_CAST\_CBC

#define CKM\_CAST\_CBC 0x00000302UL

### 20.166.1.330 CKM\_CAST\_CBC\_PAD

#define CKM\_CAST\_CBC\_PAD 0x00000305UL

## 20.166.1.331 CKM\_CAST\_ECB

#define CKM\_CAST\_ECB 0x00000301UL

### 20.166.1.332 CKM\_CAST\_KEY\_GEN

#define CKM\_CAST\_KEY\_GEN 0x00000300UL

## 20.166.1.333 CKM\_CAST\_MAC

#define CKM\_CAST\_MAC 0x00000303UL

## 20.166.1.334 CKM\_CAST\_MAC\_GENERAL

#define CKM\_CAST\_MAC\_GENERAL 0x00000304UL

# 20.166.1.335 CKM\_CDMF\_CBC

#define CKM\_CDMF\_CBC 0x00000142UL

## 20.166.1.336 CKM\_CDMF\_CBC\_PAD

#define CKM\_CDMF\_CBC\_PAD 0x00000145UL

## 20.166.1.337 CKM\_CDMF\_ECB

#define CKM\_CDMF\_ECB 0x00000141UL

### 20.166.1.338 CKM\_CDMF\_KEY\_GEN

#define CKM\_CDMF\_KEY\_GEN 0x00000140UL

## 20.166.1.339 CKM\_CDMF\_MAC

#define CKM\_CDMF\_MAC 0x00000143UL

## 20.166.1.340 CKM\_CDMF\_MAC\_GENERAL

#define CKM\_CDMF\_MAC\_GENERAL 0x00000144UL

## 20.166.1.341 CKM\_CMS\_SIG

#define CKM\_CMS\_SIG 0x00000500UL

# 20.166.1.342 CKM\_CONCATENATE\_BASE\_AND\_DATA

#define CKM\_CONCATENATE\_BASE\_AND\_DATA 0x00000362UL

### 20.166.1.343 CKM\_CONCATENATE\_BASE\_AND\_KEY

#define CKM\_CONCATENATE\_BASE\_AND\_KEY 0x00000360UL

## 20.166.1.344 CKM\_CONCATENATE\_DATA\_AND\_BASE

#define CKM\_CONCATENATE\_DATA\_AND\_BASE 0x00000363UL

## 20.166.1.345 CKM\_DES2\_KEY\_GEN

#define CKM\_DES2\_KEY\_GEN 0x00000130UL

### 20.166.1.346 CKM\_DES3\_CBC

#define CKM\_DES3\_CBC 0x00000133UL

## 20.166.1.347 CKM\_DES3\_CBC\_ENCRYPT\_DATA

#define CKM\_DES3\_CBC\_ENCRYPT\_DATA 0x00001103UL

#### 20.166.1.348 CKM DES3 CBC PAD

#define CKM\_DES3\_CBC\_PAD 0x00000136UL

## 20.166.1.349 CKM\_DES3\_CMAC

#define CKM\_DES3\_CMAC 0x00000138UL

### 20.166.1.350 CKM\_DES3\_CMAC\_GENERAL

#define CKM\_DES3\_CMAC\_GENERAL 0x00000137UL

## 20.166.1.351 CKM\_DES3\_ECB

#define CKM\_DES3\_ECB 0x00000132UL

## 20.166.1.352 CKM\_DES3\_ECB\_ENCRYPT\_DATA

#define CKM\_DES3\_ECB\_ENCRYPT\_DATA 0x00001102UL

## 20.166.1.353 CKM\_DES3\_KEY\_GEN

#define CKM\_DES3\_KEY\_GEN 0x00000131UL

### 20.166.1.354 CKM\_DES3\_MAC

#define CKM\_DES3\_MAC 0x00000134UL

## 20.166.1.355 CKM\_DES3\_MAC\_GENERAL

#define CKM\_DES3\_MAC\_GENERAL 0x00000135UL

## 20.166.1.356 CKM\_DES\_CBC

#define CKM\_DES\_CBC 0x00000122UL

## 20.166.1.357 CKM\_DES\_CBC\_ENCRYPT\_DATA

#define CKM\_DES\_CBC\_ENCRYPT\_DATA 0x00001101UL

### 20.166.1.358 CKM\_DES\_CBC\_PAD

#define CKM\_DES\_CBC\_PAD 0x00000125UL

## 20.166.1.359 CKM\_DES\_CFB64

#define CKM\_DES\_CFB64 0x00000152UL

## 20.166.1.360 CKM\_DES\_CFB8

#define CKM\_DES\_CFB8 0x00000153UL

## 20.166.1.361 CKM\_DES\_ECB

#define CKM\_DES\_ECB 0x00000121UL

### 20.166.1.362 CKM\_DES\_ECB\_ENCRYPT\_DATA

#define CKM\_DES\_ECB\_ENCRYPT\_DATA 0x00001100UL

## 20.166.1.363 CKM\_DES\_KEY\_GEN

#define CKM\_DES\_KEY\_GEN 0x00000120UL

## 20.166.1.364 CKM\_DES\_MAC

#define CKM\_DES\_MAC 0x00000123UL

## 20.166.1.365 CKM\_DES\_MAC\_GENERAL

#define CKM\_DES\_MAC\_GENERAL 0x00000124UL

## 20.166.1.366 CKM\_DES\_OFB64

#define CKM\_DES\_OFB64 0x00000150UL

## 20.166.1.367 CKM\_DES\_OFB8

#define CKM\_DES\_OFB8 0x00000151UL

## 20.166.1.368 CKM\_DH\_PKCS\_DERIVE

#define CKM\_DH\_PKCS\_DERIVE 0x00000021UL

## 20.166.1.369 CKM\_DH\_PKCS\_KEY\_PAIR\_GEN

#define CKM\_DH\_PKCS\_KEY\_PAIR\_GEN 0x00000020UL

### 20.166.1.370 CKM\_DH\_PKCS\_PARAMETER\_GEN

#define CKM\_DH\_PKCS\_PARAMETER\_GEN 0x00002001UL

## 20.166.1.371 CKM\_DSA

#define CKM\_DSA 0x0000011UL

### 20.166.1.372 CKM\_DSA\_KEY\_PAIR\_GEN

#define CKM\_DSA\_KEY\_PAIR\_GEN 0x00000010UL

## 20.166.1.373 CKM\_DSA\_PARAMETER\_GEN

#define CKM\_DSA\_PARAMETER\_GEN 0x00002000UL

## 20.166.1.374 CKM\_DSA\_PROBABLISTIC\_PARAMETER\_GEN

#define CKM\_DSA\_PROBABLISTIC\_PARAMETER\_GEN 0x00002003UL

## 20.166.1.375 CKM\_DSA\_SHA1

#define CKM\_DSA\_SHA1 0x00000012UL

## 20.166.1.376 CKM\_DSA\_SHA224

#define CKM\_DSA\_SHA224 0x00000013UL

## 20.166.1.377 CKM\_DSA\_SHA256

#define CKM\_DSA\_SHA256 0x00000014UL

### 20.166.1.378 CKM\_DSA\_SHA384

#define CKM\_DSA\_SHA384 0x00000015UL

## 20.166.1.379 CKM\_DSA\_SHA512

#define CKM\_DSA\_SHA512 0x00000016UL

## 20.166.1.380 CKM\_DSA\_SHAWE\_TAYLOR\_PARAMETER\_GEN

#define CKM\_DSA\_SHAWE\_TAYLOR\_PARAMETER\_GEN 0x00002004UL

## 20.166.1.381 CKM\_EC\_KEY\_PAIR\_GEN

#define CKM\_EC\_KEY\_PAIR\_GEN 0x00001040UL

### 20.166.1.382 CKM\_ECDH1\_COFACTOR\_DERIVE

#define CKM\_ECDH1\_COFACTOR\_DERIVE 0x00001051UL

## 20.166.1.383 CKM\_ECDH1\_DERIVE

#define CKM\_ECDH1\_DERIVE 0x00001050UL

## 20.166.1.384 CKM\_ECDH\_AES\_KEY\_WRAP

#define CKM\_ECDH\_AES\_KEY\_WRAP 0x00001053UL

## 20.166.1.385 CKM\_ECDSA

#define CKM\_ECDSA 0x00001041UL

### 20.166.1.386 CKM\_ECDSA\_KEY\_PAIR\_GEN

#define CKM\_ECDSA\_KEY\_PAIR\_GEN 0x00001040UL /\* Deprecated \*/

## 20.166.1.387 CKM\_ECDSA\_SHA1

#define CKM\_ECDSA\_SHA1 0x00001042UL

### 20.166.1.388 CKM ECDSA SHA224

#define CKM\_ECDSA\_SHA224 0x00001043UL

## 20.166.1.389 CKM\_ECDSA\_SHA256

#define CKM\_ECDSA\_SHA256 0x00001044UL

### 20.166.1.390 CKM\_ECDSA\_SHA384

#define CKM\_ECDSA\_SHA384 0x00001045UL

### 20.166.1.391 CKM\_ECDSA\_SHA512

#define CKM\_ECDSA\_SHA512 0x00001046UL

## 20.166.1.392 CKM\_ECMQV\_DERIVE

#define CKM\_ECMQV\_DERIVE 0x00001052UL

## 20.166.1.393 CKM\_EXTRACT\_KEY\_FROM\_KEY

#define CKM\_EXTRACT\_KEY\_FROM\_KEY 0x00000365UL

### 20.166.1.394 CKM\_FASTHASH

#define CKM\_FASTHASH 0x00001070UL

## 20.166.1.395 CKM\_FORTEZZA\_TIMESTAMP

#define CKM\_FORTEZZA\_TIMESTAMP 0x00001020UL

### 20.166.1.396 CKM\_GENERIC\_SECRET\_KEY\_GEN

#define CKM\_GENERIC\_SECRET\_KEY\_GEN 0x00000350UL

## 20.166.1.397 CKM\_GOST28147

#define CKM\_GOST28147 0x00001222UL

### 20.166.1.398 CKM\_GOST28147\_ECB

#define CKM\_GOST28147\_ECB 0x00001221UL

## 20.166.1.399 CKM\_GOST28147\_KEY\_GEN

#define CKM\_GOST28147\_KEY\_GEN 0x00001220UL

## 20.166.1.400 CKM\_GOST28147\_KEY\_WRAP

#define CKM\_GOST28147\_KEY\_WRAP 0x00001224UL

## 20.166.1.401 CKM\_GOST28147\_MAC

#define CKM\_GOST28147\_MAC 0x00001223UL

### 20.166.1.402 CKM\_GOSTR3410

#define CKM\_GOSTR3410 0x00001201UL

## 20.166.1.403 CKM\_GOSTR3410\_DERIVE

#define CKM\_GOSTR3410\_DERIVE 0x00001204UL

#### 20.166.1.404 CKM GOSTR3410 KEY PAIR GEN

#define CKM\_GOSTR3410\_KEY\_PAIR\_GEN 0x00001200UL

## 20.166.1.405 CKM\_GOSTR3410\_KEY\_WRAP

#define CKM\_GOSTR3410\_KEY\_WRAP 0x00001203UL

### 20.166.1.406 CKM\_GOSTR3410\_WITH\_GOSTR3411

#define CKM\_GOSTR3410\_WITH\_GOSTR3411 0x00001202UL

## 20.166.1.407 CKM\_GOSTR3411

#define CKM\_GOSTR3411 0x00001210UL

## 20.166.1.408 CKM\_GOSTR3411\_HMAC

#define CKM\_GOSTR3411\_HMAC 0x00001211UL

## 20.166.1.409 CKM\_HOTP

#define CKM\_HOTP 0x00000291UL

### 20.166.1.410 CKM\_HOTP\_KEY\_GEN

#define CKM\_HOTP\_KEY\_GEN 0x00000290UL

## 20.166.1.411 CKM\_IDEA\_CBC

#define CKM\_IDEA\_CBC 0x00000342UL

### 20.166.1.412 CKM\_IDEA\_CBC\_PAD

#define CKM\_IDEA\_CBC\_PAD 0x00000345UL

# 20.166.1.413 CKM\_IDEA\_ECB

#define CKM\_IDEA\_ECB 0x00000341UL

## 20.166.1.414 CKM\_IDEA\_KEY\_GEN

#define CKM\_IDEA\_KEY\_GEN 0x00000340UL

### 20.166.1.415 CKM\_IDEA\_MAC

#define CKM\_IDEA\_MAC 0x00000343UL

## 20.166.1.416 CKM\_IDEA\_MAC\_GENERAL

#define CKM\_IDEA\_MAC\_GENERAL 0x00000344UL

## 20.166.1.417 CKM\_JUNIPER\_CBC128

#define CKM\_JUNIPER\_CBC128 0x00001062UL

### 20.166.1.418 CKM\_JUNIPER\_COUNTER

#define CKM\_JUNIPER\_COUNTER 0x00001063UL

## 20.166.1.419 CKM\_JUNIPER\_ECB128

#define CKM\_JUNIPER\_ECB128 0x00001061UL

### 20.166.1.420 CKM\_JUNIPER\_KEY\_GEN

#define CKM\_JUNIPER\_KEY\_GEN 0x00001060UL

## 20.166.1.421 CKM\_JUNIPER\_SHUFFLE

#define CKM\_JUNIPER\_SHUFFLE 0x00001064UL

### 20.166.1.422 CKM\_JUNIPER\_WRAP

#define CKM\_JUNIPER\_WRAP 0x00001065UL

### 20.166.1.423 CKM\_KEA\_DERIVE

#define CKM\_KEA\_DERIVE 0x00001012UL

## 20.166.1.424 CKM\_KEA\_KEY\_DERIVE

#define CKM\_KEA\_KEY\_DERIVE 0x00001011UL

## 20.166.1.425 CKM\_KEA\_KEY\_PAIR\_GEN

#define CKM\_KEA\_KEY\_PAIR\_GEN 0x00001010UL

### 20.166.1.426 CKM\_KEY\_WRAP\_LYNKS

#define CKM\_KEY\_WRAP\_LYNKS 0x00000400UL

## 20.166.1.427 CKM\_KEY\_WRAP\_SET\_OAEP

#define CKM\_KEY\_WRAP\_SET\_OAEP 0x00000401UL

## 20.166.1.428 CKM\_KIP\_DERIVE

#define CKM\_KIP\_DERIVE 0x00000510UL

## 20.166.1.429 CKM\_KIP\_MAC

#define CKM\_KIP\_MAC 0x00000512UL

### 20.166.1.430 CKM\_KIP\_WRAP

#define CKM\_KIP\_WRAP 0x00000511UL

## 20.166.1.431 CKM\_MD2

#define CKM\_MD2 0x00000200UL

## 20.166.1.432 CKM\_MD2\_HMAC

#define CKM\_MD2\_HMAC 0x00000201UL

## 20.166.1.433 CKM\_MD2\_HMAC\_GENERAL

#define CKM\_MD2\_HMAC\_GENERAL 0x00000202UL

### 20.166.1.434 CKM\_MD2\_KEY\_DERIVATION

#define CKM\_MD2\_KEY\_DERIVATION 0x00000391UL

## 20.166.1.435 CKM\_MD2\_RSA\_PKCS

#define CKM\_MD2\_RSA\_PKCS 0x00000004UL

### 20.166.1.436 CKM MD5

#define CKM\_MD5 0x00000210UL

# 20.166.1.437 CKM\_MD5\_HMAC

#define CKM\_MD5\_HMAC 0x00000211UL

### 20.166.1.438 CKM\_MD5\_HMAC\_GENERAL

#define CKM\_MD5\_HMAC\_GENERAL 0x00000212UL

### 20.166.1.439 CKM\_MD5\_KEY\_DERIVATION

#define CKM\_MD5\_KEY\_DERIVATION 0x00000390UL

## 20.166.1.440 CKM\_MD5\_RSA\_PKCS

#define CKM\_MD5\_RSA\_PKCS 0x00000005UL

## 20.166.1.441 CKM\_PBA\_SHA1\_WITH\_SHA1\_HMAC

#define CKM\_PBA\_SHA1\_WITH\_SHA1\_HMAC 0x000003C0UL

### 20.166.1.442 CKM\_PBE\_MD2\_DES\_CBC

#define CKM\_PBE\_MD2\_DES\_CBC 0x000003A0UL

# 20.166.1.443 CKM\_PBE\_MD5\_CAST128\_CBC

#define CKM\_PBE\_MD5\_CAST128\_CBC 0x000003A4UL

#### 20.166.1.444 CKM PBE MD5 CAST3 CBC

#define CKM\_PBE\_MD5\_CAST3\_CBC 0x000003A3UL

## 20.166.1.445 CKM\_PBE\_MD5\_CAST5\_CBC

#define CKM\_PBE\_MD5\_CAST5\_CBC 0x000003A4UL /\* Deprecated \*/

### 20.166.1.446 CKM\_PBE\_MD5\_CAST\_CBC

#define CKM\_PBE\_MD5\_CAST\_CBC 0x000003A2UL

## 20.166.1.447 CKM\_PBE\_MD5\_DES\_CBC

#define CKM\_PBE\_MD5\_DES\_CBC 0x000003A1UL

### 20.166.1.448 CKM\_PBE\_SHA1\_CAST128\_CBC

#define CKM\_PBE\_SHA1\_CAST128\_CBC 0x000003A5UL

## 20.166.1.449 CKM\_PBE\_SHA1\_CAST5\_CBC

#define CKM\_PBE\_SHA1\_CAST5\_CBC 0x000003A5UL /\* Deprecated \*/

### 20.166.1.450 CKM\_PBE\_SHA1\_DES2\_EDE\_CBC

#define CKM\_PBE\_SHA1\_DES2\_EDE\_CBC 0x000003A9UL

## 20.166.1.451 CKM\_PBE\_SHA1\_DES3\_EDE\_CBC

#define CKM\_PBE\_SHA1\_DES3\_EDE\_CBC 0x000003A8UL

#### 20.166.1.452 CKM PBE SHA1 RC2 128 CBC

#define CKM\_PBE\_SHA1\_RC2\_128\_CBC 0x000003AAUL

## 20.166.1.453 CKM\_PBE\_SHA1\_RC2\_40\_CBC

#define CKM\_PBE\_SHA1\_RC2\_40\_CBC 0x000003ABUL

### 20.166.1.454 CKM\_PBE\_SHA1\_RC4\_128

#define CKM\_PBE\_SHA1\_RC4\_128 0x000003A6UL

## 20.166.1.455 CKM\_PBE\_SHA1\_RC4\_40

#define CKM\_PBE\_SHA1\_RC4\_40 0x000003A7UL

## 20.166.1.456 CKM\_PKCS5\_PBKD2

#define CKM\_PKCS5\_PBKD2 0x000003B0UL

## 20.166.1.457 CKM\_RC2\_CBC

#define CKM\_RC2\_CBC 0x00000102UL

### 20.166.1.458 CKM\_RC2\_CBC\_PAD

#define CKM\_RC2\_CBC\_PAD 0x00000105UL

## 20.166.1.459 CKM\_RC2\_ECB

#define CKM\_RC2\_ECB 0x00000101UL

## 20.166.1.460 CKM\_RC2\_KEY\_GEN

#define CKM\_RC2\_KEY\_GEN 0x00000100UL

## 20.166.1.461 CKM\_RC2\_MAC

#define CKM\_RC2\_MAC 0x00000103UL

### 20.166.1.462 CKM\_RC2\_MAC\_GENERAL

#define CKM\_RC2\_MAC\_GENERAL 0x00000104UL

## 20.166.1.463 CKM\_RC4

#define CKM\_RC4 0x00000111UL

## 20.166.1.464 CKM\_RC4\_KEY\_GEN

#define CKM\_RC4\_KEY\_GEN 0x00000110UL

## 20.166.1.465 CKM\_RC5\_CBC

#define CKM\_RC5\_CBC 0x00000332UL

### 20.166.1.466 CKM\_RC5\_CBC\_PAD

#define CKM\_RC5\_CBC\_PAD 0x00000335UL

## 20.166.1.467 CKM\_RC5\_ECB

#define CKM\_RC5\_ECB 0x00000331UL

## 20.166.1.468 CKM\_RC5\_KEY\_GEN

#define CKM\_RC5\_KEY\_GEN 0x00000330UL

# 20.166.1.469 CKM\_RC5\_MAC

#define CKM\_RC5\_MAC 0x00000333UL

## 20.166.1.470 CKM\_RC5\_MAC\_GENERAL

#define CKM\_RC5\_MAC\_GENERAL 0x00000334UL

## 20.166.1.471 CKM\_RIPEMD128

#define CKM\_RIPEMD128 0x00000230UL

## 20.166.1.472 CKM\_RIPEMD128\_HMAC

#define CKM\_RIPEMD128\_HMAC 0x00000231UL

## 20.166.1.473 CKM\_RIPEMD128\_HMAC\_GENERAL

#define CKM\_RIPEMD128\_HMAC\_GENERAL 0x00000232UL

### 20.166.1.474 CKM\_RIPEMD128\_RSA\_PKCS

#define CKM\_RIPEMD128\_RSA\_PKCS 0x00000007UL

# 20.166.1.475 CKM\_RIPEMD160

#define CKM\_RIPEMD160 0x00000240UL

### 20.166.1.476 CKM RIPEMD160 HMAC

#define CKM\_RIPEMD160\_HMAC 0x00000241UL

## 20.166.1.477 CKM\_RIPEMD160\_HMAC\_GENERAL

#define CKM\_RIPEMD160\_HMAC\_GENERAL 0x00000242UL

### 20.166.1.478 CKM\_RIPEMD160\_RSA\_PKCS

#define CKM\_RIPEMD160\_RSA\_PKCS 0x00000008UL

## 20.166.1.479 CKM\_RSA\_9796

#define CKM\_RSA\_9796 0x00000002UL

### 20.166.1.480 CKM\_RSA\_AES\_KEY\_WRAP

#define CKM\_RSA\_AES\_KEY\_WRAP 0x00001054UL

## 20.166.1.481 CKM\_RSA\_PKCS

#define CKM\_RSA\_PKCS 0x0000001UL

### 20.166.1.482 CKM\_RSA\_PKCS\_KEY\_PAIR\_GEN

#define CKM\_RSA\_PKCS\_KEY\_PAIR\_GEN 0x0000000UL

# 20.166.1.483 CKM\_RSA\_PKCS\_OAEP

#define CKM\_RSA\_PKCS\_OAEP 0x00000009UL

### 20.166.1.484 CKM\_RSA\_PKCS\_OAEP\_TPM\_1\_1

#define CKM\_RSA\_PKCS\_OAEP\_TPM\_1\_1 0x00004002UL

## 20.166.1.485 CKM\_RSA\_PKCS\_PSS

#define CKM\_RSA\_PKCS\_PSS 0x0000000DUL

### 20.166.1.486 CKM\_RSA\_PKCS\_TPM\_1\_1

#define CKM\_RSA\_PKCS\_TPM\_1\_1 0x00004001UL

## 20.166.1.487 CKM\_RSA\_X9\_31

#define CKM\_RSA\_X9\_31 0x0000000BUL

## 20.166.1.488 CKM\_RSA\_X9\_31\_KEY\_PAIR\_GEN

#define CKM\_RSA\_X9\_31\_KEY\_PAIR\_GEN 0x0000000AUL

## 20.166.1.489 CKM\_RSA\_X\_509

#define CKM\_RSA\_X\_509 0x0000003UL

### 20.166.1.490 CKM\_SECURID

#define CKM\_SECURID 0x00000282UL

## 20.166.1.491 CKM\_SECURID\_KEY\_GEN

#define CKM\_SECURID\_KEY\_GEN 0x00000280UL

## 20.166.1.492 CKM\_SEED\_CBC

#define CKM\_SEED\_CBC 0x00000652UL

## 20.166.1.493 CKM\_SEED\_CBC\_ENCRYPT\_DATA

#define CKM\_SEED\_CBC\_ENCRYPT\_DATA 0x00000657UL

### 20.166.1.494 CKM\_SEED\_CBC\_PAD

#define CKM\_SEED\_CBC\_PAD 0x00000655UL

## 20.166.1.495 CKM\_SEED\_ECB

#define CKM\_SEED\_ECB 0x00000651UL

### 20.166.1.496 CKM\_SEED\_ECB\_ENCRYPT\_DATA

#define CKM\_SEED\_ECB\_ENCRYPT\_DATA 0x00000656UL

## 20.166.1.497 CKM\_SEED\_KEY\_GEN

#define CKM\_SEED\_KEY\_GEN 0x00000650UL

### 20.166.1.498 CKM\_SEED\_MAC

#define CKM\_SEED\_MAC 0x00000653UL

## 20.166.1.499 CKM\_SEED\_MAC\_GENERAL

#define CKM\_SEED\_MAC\_GENERAL 0x00000654UL

# 20.166.1.500 CKM\_SHA1\_KEY\_DERIVATION

#define CKM\_SHA1\_KEY\_DERIVATION 0x00000392UL

## 20.166.1.501 CKM\_SHA1\_RSA\_PKCS

#define CKM\_SHA1\_RSA\_PKCS 0x00000006UL

### 20.166.1.502 CKM\_SHA1\_RSA\_PKCS\_PSS

#define CKM\_SHA1\_RSA\_PKCS\_PSS 0x0000000EUL

## 20.166.1.503 CKM\_SHA1\_RSA\_X9\_31

#define CKM\_SHA1\_RSA\_X9\_31 0x000000CUL

## 20.166.1.504 CKM\_SHA224

#define CKM\_SHA224 0x00000255UL

## 20.166.1.505 CKM\_SHA224\_HMAC

#define CKM\_SHA224\_HMAC 0x00000256UL

### 20.166.1.506 CKM\_SHA224\_HMAC\_GENERAL

#define CKM\_SHA224\_HMAC\_GENERAL 0x00000257UL

## 20.166.1.507 CKM\_SHA224\_KEY\_DERIVATION

#define CKM\_SHA224\_KEY\_DERIVATION 0x00000396UL

### 20.166.1.508 CKM SHA224 RSA PKCS

#define CKM\_SHA224\_RSA\_PKCS 0x00000046UL

## 20.166.1.509 CKM\_SHA224\_RSA\_PKCS\_PSS

#define CKM\_SHA224\_RSA\_PKCS\_PSS 0x00000047UL

### 20.166.1.510 CKM\_SHA256

#define CKM\_SHA256 0x00000250UL

## 20.166.1.511 CKM\_SHA256\_HMAC

#define CKM\_SHA256\_HMAC 0x00000251UL

## 20.166.1.512 CKM\_SHA256\_HMAC\_GENERAL

#define CKM\_SHA256\_HMAC\_GENERAL 0x00000252UL

## 20.166.1.513 CKM\_SHA256\_KEY\_DERIVATION

#define CKM\_SHA256\_KEY\_DERIVATION 0x00000393UL

### 20.166.1.514 CKM\_SHA256\_RSA\_PKCS

#define CKM\_SHA256\_RSA\_PKCS 0x00000040UL

## 20.166.1.515 CKM\_SHA256\_RSA\_PKCS\_PSS

#define CKM\_SHA256\_RSA\_PKCS\_PSS 0x00000043UL

### 20.166.1.516 CKM SHA384

#define CKM\_SHA384 0x00000260UL

## 20.166.1.517 CKM\_SHA384\_HMAC

#define CKM\_SHA384\_HMAC 0x00000261UL

### 20.166.1.518 CKM\_SHA384\_HMAC\_GENERAL

#define CKM\_SHA384\_HMAC\_GENERAL 0x00000262UL

# 20.166.1.519 CKM\_SHA384\_KEY\_DERIVATION

#define CKM\_SHA384\_KEY\_DERIVATION 0x00000394UL

## 20.166.1.520 CKM\_SHA384\_RSA\_PKCS

#define CKM\_SHA384\_RSA\_PKCS 0x00000041UL

## 20.166.1.521 CKM\_SHA384\_RSA\_PKCS\_PSS

#define CKM\_SHA384\_RSA\_PKCS\_PSS 0x00000044UL

### 20.166.1.522 CKM\_SHA512

#define CKM\_SHA512 0x00000270UL

## 20.166.1.523 CKM\_SHA512\_224

#define CKM\_SHA512\_224 0x00000048UL

#### 20.166.1.524 CKM SHA512 224 HMAC

#define CKM\_SHA512\_224\_HMAC 0x00000049UL

## 20.166.1.525 CKM\_SHA512\_224\_HMAC\_GENERAL

#define CKM\_SHA512\_224\_HMAC\_GENERAL 0x0000004AUL

### 20.166.1.526 CKM\_SHA512\_224\_KEY\_DERIVATION

#define CKM\_SHA512\_224\_KEY\_DERIVATION 0x0000004BUL

### 20.166.1.527 CKM\_SHA512\_256

#define CKM\_SHA512\_256 0x0000004CUL

### 20.166.1.528 CKM\_SHA512\_256\_HMAC

#define CKM\_SHA512\_256\_HMAC 0x0000004DUL

# 20.166.1.529 CKM\_SHA512\_256\_HMAC\_GENERAL

#define CKM\_SHA512\_256\_HMAC\_GENERAL 0x0000004EUL

### 20.166.1.530 CKM\_SHA512\_256\_KEY\_DERIVATION

#define CKM\_SHA512\_256\_KEY\_DERIVATION 0x0000004FUL

# 20.166.1.531 CKM\_SHA512\_HMAC

#define CKM\_SHA512\_HMAC 0x00000271UL

### 20.166.1.532 CKM SHA512 HMAC GENERAL

#define CKM\_SHA512\_HMAC\_GENERAL 0x00000272UL

# 20.166.1.533 CKM\_SHA512\_KEY\_DERIVATION

#define CKM\_SHA512\_KEY\_DERIVATION 0x00000395UL

### 20.166.1.534 CKM\_SHA512\_RSA\_PKCS

#define CKM\_SHA512\_RSA\_PKCS 0x00000042UL

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 1010

# 20.166.1.535 CKM\_SHA512\_RSA\_PKCS\_PSS

#define CKM\_SHA512\_RSA\_PKCS\_PSS 0x00000045UL

# 20.166.1.536 CKM\_SHA512\_T

#define CKM\_SHA512\_T 0x00000050UL

# 20.166.1.537 CKM\_SHA512\_T\_HMAC

#define CKM\_SHA512\_T\_HMAC 0x00000051UL

### 20.166.1.538 CKM\_SHA512\_T\_HMAC\_GENERAL

#define CKM\_SHA512\_T\_HMAC\_GENERAL 0x00000052UL

# 20.166.1.539 CKM\_SHA512\_T\_KEY\_DERIVATION

#define CKM\_SHA512\_T\_KEY\_DERIVATION 0x00000053UL

# 20.166.1.540 CKM\_SHA\_1

#define CKM\_SHA\_1 0x00000220UL

# 20.166.1.541 CKM\_SHA\_1\_HMAC

#define CKM\_SHA\_1\_HMAC 0x00000221UL

### 20.166.1.542 CKM\_SHA\_1\_HMAC\_GENERAL

#define CKM\_SHA\_1\_HMAC\_GENERAL 0x00000222UL

# 20.166.1.543 CKM\_SKIPJACK\_CBC64

#define CKM\_SKIPJACK\_CBC64 0x00001002UL

# 20.166.1.544 CKM\_SKIPJACK\_CFB16

#define CKM\_SKIPJACK\_CFB16 0x00001006UL

# 20.166.1.545 CKM\_SKIPJACK\_CFB32

#define CKM\_SKIPJACK\_CFB32 0x00001005UL

### 20.166.1.546 CKM\_SKIPJACK\_CFB64

#define CKM\_SKIPJACK\_CFB64 0x00001004UL

# 20.166.1.547 CKM\_SKIPJACK\_CFB8

#define CKM\_SKIPJACK\_CFB8 0x00001007UL

### 20.166.1.548 CKM SKIPJACK ECB64

#define CKM\_SKIPJACK\_ECB64 0x00001001UL

# 20.166.1.549 CKM\_SKIPJACK\_KEY\_GEN

#define CKM\_SKIPJACK\_KEY\_GEN 0x00001000UL

### 20.166.1.550 CKM\_SKIPJACK\_OFB64

#define CKM\_SKIPJACK\_OFB64 0x00001003UL

# 20.166.1.551 CKM\_SKIPJACK\_PRIVATE\_WRAP

#define CKM\_SKIPJACK\_PRIVATE\_WRAP 0x00001009UL

### 20.166.1.552 CKM\_SKIPJACK\_RELAYX

#define CKM\_SKIPJACK\_RELAYX 0x0000100aUL

# 20.166.1.553 CKM\_SKIPJACK\_WRAP

#define CKM\_SKIPJACK\_WRAP 0x00001008UL

### 20.166.1.554 CKM\_SSL3\_KEY\_AND\_MAC\_DERIVE

#define CKM\_SSL3\_KEY\_AND\_MAC\_DERIVE 0x00000372UL

# 20.166.1.555 CKM\_SSL3\_MASTER\_KEY\_DERIVE

#define CKM\_SSL3\_MASTER\_KEY\_DERIVE 0x00000371UL

## 20.166.1.556 CKM SSL3 MASTER KEY DERIVE DH

#define CKM\_SSL3\_MASTER\_KEY\_DERIVE\_DH 0x00000373UL

# 20.166.1.557 CKM\_SSL3\_MD5\_MAC

#define CKM\_SSL3\_MD5\_MAC 0x00000380UL

### 20.166.1.558 CKM\_SSL3\_PRE\_MASTER\_KEY\_GEN

#define CKM\_SSL3\_PRE\_MASTER\_KEY\_GEN 0x00000370UL

# 20.166.1.559 CKM\_SSL3\_SHA1\_MAC

#define CKM\_SSL3\_SHA1\_MAC 0x00000381UL

# 20.166.1.560 CKM\_TLS10\_MAC\_CLIENT

#define CKM\_TLS10\_MAC\_CLIENT 0x000003D7UL

# 20.166.1.561 CKM\_TLS10\_MAC\_SERVER

#define CKM\_TLS10\_MAC\_SERVER 0x000003D6UL

### 20.166.1.562 CKM\_TLS12\_KDF

#define CKM\_TLS12\_KDF 0x000003D9UL

# 20.166.1.563 CKM\_TLS12\_KEY\_AND\_MAC\_DERIVE

#define CKM\_TLS12\_KEY\_AND\_MAC\_DERIVE 0x000003E1UL

### 20.166.1.564 CKM TLS12 KEY SAFE DERIVE

#define CKM\_TLS12\_KEY\_SAFE\_DERIVE 0x000003E3UL

# 20.166.1.565 CKM\_TLS12\_MAC

#define CKM\_TLS12\_MAC 0x000003D8UL

### 20.166.1.566 CKM\_TLS12\_MASTER\_KEY\_DERIVE

#define CKM\_TLS12\_MASTER\_KEY\_DERIVE 0x000003E0UL

# 20.166.1.567 CKM\_TLS12\_MASTER\_KEY\_DERIVE\_DH

#define CKM\_TLS12\_MASTER\_KEY\_DERIVE\_DH 0x000003E2UL

# 20.166.1.568 CKM\_TLS\_KDF

#define CKM\_TLS\_KDF 0x000003E5UL

# 20.166.1.569 CKM\_TLS\_KEY\_AND\_MAC\_DERIVE

#define CKM\_TLS\_KEY\_AND\_MAC\_DERIVE 0x00000376UL

### 20.166.1.570 CKM\_TLS\_MAC

#define CKM\_TLS\_MAC 0x000003E4UL

# 20.166.1.571 CKM\_TLS\_MASTER\_KEY\_DERIVE

#define CKM\_TLS\_MASTER\_KEY\_DERIVE 0x00000375UL

## 20.166.1.572 CKM TLS MASTER KEY DERIVE DH

#define CKM\_TLS\_MASTER\_KEY\_DERIVE\_DH 0x00000377UL

# 20.166.1.573 CKM\_TLS\_PRE\_MASTER\_KEY\_GEN

#define CKM\_TLS\_PRE\_MASTER\_KEY\_GEN 0x00000374UL

### 20.166.1.574 CKM\_TLS\_PRF

#define CKM\_TLS\_PRF 0x00000378UL

# 20.166.1.575 CKM\_TWOFISH\_CBC

#define CKM\_TWOFISH\_CBC 0x00001093UL

# 20.166.1.576 CKM\_TWOFISH\_CBC\_PAD

#define CKM\_TWOFISH\_CBC\_PAD 0x00001095UL

# 20.166.1.577 CKM\_TWOFISH\_KEY\_GEN

#define CKM\_TWOFISH\_KEY\_GEN 0x00001092UL

### 20.166.1.578 CKM\_VENDOR\_DEFINED

#define CKM\_VENDOR\_DEFINED 0x8000000UL

# 20.166.1.579 CKM\_WTLS\_CLIENT\_KEY\_AND\_MAC\_DERIVE

#define CKM\_WTLS\_CLIENT\_KEY\_AND\_MAC\_DERIVE 0x000003D5UL

## 20.166.1.580 CKM WTLS MASTER KEY DERIVE

#define CKM\_WTLS\_MASTER\_KEY\_DERIVE 0x000003D1UL

# 20.166.1.581 CKM\_WTLS\_MASTER\_KEY\_DERIVE\_DH\_ECC

#define CKM\_WTLS\_MASTER\_KEY\_DERIVE\_DH\_ECC 0x000003D2UL

### 20.166.1.582 CKM\_WTLS\_PRE\_MASTER\_KEY\_GEN

#define CKM\_WTLS\_PRE\_MASTER\_KEY\_GEN 0x000003D0UL

### 20.166.1.583 CKM\_WTLS\_PRF

#define CKM\_WTLS\_PRF 0x000003D3UL

### 20.166.1.584 CKM\_WTLS\_SERVER\_KEY\_AND\_MAC\_DERIVE

#define CKM\_WTLS\_SERVER\_KEY\_AND\_MAC\_DERIVE 0x000003D4UL

# 20.166.1.585 CKM\_X9\_42\_DH\_DERIVE

#define CKM\_X9\_42\_DH\_DERIVE 0x00000031UL

### 20.166.1.586 CKM\_X9\_42\_DH\_HYBRID\_DERIVE

#define CKM\_X9\_42\_DH\_HYBRID\_DERIVE 0x00000032UL

# 20.166.1.587 CKM\_X9\_42\_DH\_KEY\_PAIR\_GEN

#define CKM\_X9\_42\_DH\_KEY\_PAIR\_GEN 0x00000030UL

### 20.166.1.588 CKM X9 42 DH PARAMETER GEN

#define CKM\_X9\_42\_DH\_PARAMETER\_GEN 0x00002002UL

# 20.166.1.589 CKM\_X9\_42\_MQV\_DERIVE

#define CKM\_X9\_42\_MQV\_DERIVE 0x00000033UL

### 20.166.1.590 CKM\_XOR\_BASE\_AND\_DATA

#define CKM\_XOR\_BASE\_AND\_DATA 0x00000364UL

# 20.166.1.591 CKN\_OTP\_CHANGED

#define CKN\_OTP\_CHANGED 1UL

# 20.166.1.592 CKN\_SURRENDER

#define CKN\_SURRENDER OUL

# 20.166.1.593 CKO\_CERTIFICATE

#define CKO\_CERTIFICATE 0x0000001UL

### 20.166.1.594 CKO\_DATA

#define CKO\_DATA 0x0000000UL

# 20.166.1.595 CKO\_DOMAIN\_PARAMETERS

#define CKO\_DOMAIN\_PARAMETERS 0x00000006UL

# 20.166.1.596 CKO\_HW\_FEATURE

#define CKO\_HW\_FEATURE 0x0000005UL

# 20.166.1.597 CKO\_MECHANISM

#define CKO\_MECHANISM 0x0000007UL

# 20.166.1.598 CKO\_OTP\_KEY

#define CKO\_OTP\_KEY 0x00000008UL

# 20.166.1.599 CKO\_PRIVATE\_KEY

#define CKO\_PRIVATE\_KEY 0x0000003UL

# 20.166.1.600 CKO\_PUBLIC\_KEY

#define CKO\_PUBLIC\_KEY 0x00000002UL

# 20.166.1.601 CKO\_SECRET\_KEY

#define CKO\_SECRET\_KEY 0x00000004UL

### 20.166.1.602 CKO\_VENDOR\_DEFINED

#define CKO\_VENDOR\_DEFINED 0x8000000UL

# 20.166.1.603 CKP\_PKCS5\_PBKD2\_HMAC\_GOSTR3411

#define CKP\_PKCS5\_PBKD2\_HMAC\_GOSTR3411 0x00000002UL

# 20.166.1.604 CKP\_PKCS5\_PBKD2\_HMAC\_SHA1

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA1 0x0000001UL

# 20.166.1.605 CKP\_PKCS5\_PBKD2\_HMAC\_SHA224

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA224 0x0000003UL

### 20.166.1.606 CKP\_PKCS5\_PBKD2\_HMAC\_SHA256

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA256 0x00000004UL

# 20.166.1.607 CKP\_PKCS5\_PBKD2\_HMAC\_SHA384

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA384 0x0000005UL

# 20.166.1.608 CKP\_PKCS5\_PBKD2\_HMAC\_SHA512

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA512 0x00000006UL

# 20.166.1.609 CKP\_PKCS5\_PBKD2\_HMAC\_SHA512\_224

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA512\_224 0x0000007UL

### 20.166.1.610 CKP\_PKCS5\_PBKD2\_HMAC\_SHA512\_256

#define CKP\_PKCS5\_PBKD2\_HMAC\_SHA512\_256 0x00000008UL

# 20.166.1.611 CKR\_ACTION\_PROHIBITED

#define CKR\_ACTION\_PROHIBITED 0x0000001BUL

### 20.166.1.612 CKR ARGUMENTS BAD

#define CKR\_ARGUMENTS\_BAD 0x0000007UL

# 20.166.1.613 CKR\_ATTRIBUTE\_READ\_ONLY

#define CKR\_ATTRIBUTE\_READ\_ONLY 0x00000010UL

### 20.166.1.614 CKR\_ATTRIBUTE\_SENSITIVE

#define CKR\_ATTRIBUTE\_SENSITIVE 0x00000011UL

# 20.166.1.615 CKR\_ATTRIBUTE\_TYPE\_INVALID

#define CKR\_ATTRIBUTE\_TYPE\_INVALID 0x00000012UL

### 20.166.1.616 CKR\_ATTRIBUTE\_VALUE\_INVALID

#define CKR\_ATTRIBUTE\_VALUE\_INVALID 0x00000013UL

# 20.166.1.617 CKR\_BUFFER\_TOO\_SMALL

#define CKR\_BUFFER\_TOO\_SMALL 0x00000150UL

### 20.166.1.618 CKR\_CANCEL

#define CKR\_CANCEL 0x0000001UL

# 20.166.1.619 CKR\_CANT\_LOCK

#define CKR\_CANT\_LOCK 0x0000000AUL

## 20.166.1.620 CKR CRYPTOKI ALREADY INITIALIZED

#define CKR\_CRYPTOKI\_ALREADY\_INITIALIZED 0x00000191UL

# 20.166.1.621 CKR\_CRYPTOKI\_NOT\_INITIALIZED

#define CKR\_CRYPTOKI\_NOT\_INITIALIZED 0x00000190UL

### 20.166.1.622 CKR\_CURVE\_NOT\_SUPPORTED

#define CKR\_CURVE\_NOT\_SUPPORTED 0x00000140UL

# 20.166.1.623 CKR\_DATA\_INVALID

#define CKR\_DATA\_INVALID 0x00000020UL

# 20.166.1.624 CKR\_DATA\_LEN\_RANGE

#define CKR\_DATA\_LEN\_RANGE 0x00000021UL

# 20.166.1.625 CKR\_DEVICE\_ERROR

#define CKR\_DEVICE\_ERROR 0x00000030UL

### 20.166.1.626 CKR\_DEVICE\_MEMORY

#define CKR\_DEVICE\_MEMORY 0x00000031UL

# 20.166.1.627 CKR\_DEVICE\_REMOVED

#define CKR\_DEVICE\_REMOVED 0x00000032UL

### 20.166.1.628 CKR DOMAIN PARAMS INVALID

#define CKR\_DOMAIN\_PARAMS\_INVALID 0x00000130UL

# 20.166.1.629 CKR\_ENCRYPTED\_DATA\_INVALID

#define CKR\_ENCRYPTED\_DATA\_INVALID 0x00000040UL

### 20.166.1.630 CKR\_ENCRYPTED\_DATA\_LEN\_RANGE

#define CKR\_ENCRYPTED\_DATA\_LEN\_RANGE 0x00000041UL

# 20.166.1.631 CKR\_EXCEEDED\_MAX\_ITERATIONS

#define CKR\_EXCEEDED\_MAX\_ITERATIONS 0x000001B5UL

# 20.166.1.632 CKR\_FIPS\_SELF\_TEST\_FAILED

#define CKR\_FIPS\_SELF\_TEST\_FAILED 0x000001B6UL

# 20.166.1.633 CKR\_FUNCTION\_CANCELED

#define CKR\_FUNCTION\_CANCELED 0x00000050UL

### 20.166.1.634 CKR\_FUNCTION\_FAILED

#define CKR\_FUNCTION\_FAILED 0x00000006UL

# 20.166.1.635 CKR\_FUNCTION\_NOT\_PARALLEL

#define CKR\_FUNCTION\_NOT\_PARALLEL 0x00000051UL

## 20.166.1.636 CKR FUNCTION NOT SUPPORTED

#define CKR\_FUNCTION\_NOT\_SUPPORTED 0x00000054UL

# 20.166.1.637 CKR\_FUNCTION\_REJECTED

#define CKR\_FUNCTION\_REJECTED 0x00000200UL

## 20.166.1.638 CKR\_GENERAL\_ERROR

#define CKR\_GENERAL\_ERROR 0x0000005UL

# 20.166.1.639 CKR\_HOST\_MEMORY

#define CKR\_HOST\_MEMORY 0x00000002UL

# 20.166.1.640 CKR\_INFORMATION\_SENSITIVE

#define CKR\_INFORMATION\_SENSITIVE 0x00000170UL

# 20.166.1.641 CKR\_KEY\_CHANGED

#define CKR\_KEY\_CHANGED 0x00000065UL

### 20.166.1.642 CKR\_KEY\_FUNCTION\_NOT\_PERMITTED

#define CKR\_KEY\_FUNCTION\_NOT\_PERMITTED 0x00000068UL

# 20.166.1.643 CKR\_KEY\_HANDLE\_INVALID

#define CKR\_KEY\_HANDLE\_INVALID 0x00000060UL

# 20.166.1.644 CKR\_KEY\_INDIGESTIBLE

#define CKR\_KEY\_INDIGESTIBLE 0x00000067UL

# 20.166.1.645 CKR\_KEY\_NEEDED

#define CKR\_KEY\_NEEDED 0x00000066UL

### 20.166.1.646 CKR\_KEY\_NOT\_NEEDED

#define CKR\_KEY\_NOT\_NEEDED 0x00000064UL

# 20.166.1.647 CKR\_KEY\_NOT\_WRAPPABLE

#define CKR\_KEY\_NOT\_WRAPPABLE 0x00000069UL

# 20.166.1.648 CKR\_KEY\_SIZE\_RANGE

#define CKR\_KEY\_SIZE\_RANGE 0x00000062UL

# 20.166.1.649 CKR\_KEY\_TYPE\_INCONSISTENT

#define CKR\_KEY\_TYPE\_INCONSISTENT 0x00000063UL

### 20.166.1.650 CKR\_KEY\_UNEXTRACTABLE

#define CKR\_KEY\_UNEXTRACTABLE 0x0000006AUL

# 20.166.1.651 CKR\_LIBRARY\_LOAD\_FAILED

#define CKR\_LIBRARY\_LOAD\_FAILED 0x000001B7UL

## 20.166.1.652 CKR MECHANISM INVALID

#define CKR\_MECHANISM\_INVALID 0x00000070UL

# 20.166.1.653 CKR\_MECHANISM\_PARAM\_INVALID

#define CKR\_MECHANISM\_PARAM\_INVALID 0x00000071UL

### 20.166.1.654 CKR\_MUTEX\_BAD

#define CKR\_MUTEX\_BAD 0x000001A0UL

# 20.166.1.655 CKR\_MUTEX\_NOT\_LOCKED

#define CKR\_MUTEX\_NOT\_LOCKED 0x000001A1UL

# 20.166.1.656 CKR\_NEED\_TO\_CREATE\_THREADS

#define CKR\_NEED\_TO\_CREATE\_THREADS 0x00000009UL

# 20.166.1.657 CKR\_NEW\_PIN\_MODE

#define CKR\_NEW\_PIN\_MODE 0x000001B0UL

### 20.166.1.658 CKR\_NEXT\_OTP

#define CKR\_NEXT\_OTP 0x000001B1UL

# 20.166.1.659 CKR\_NO\_EVENT

#define CKR\_NO\_EVENT 0x0000008UL

# 20.166.1.660 CKR\_OBJECT\_HANDLE\_INVALID

#define CKR\_OBJECT\_HANDLE\_INVALID 0x00000082UL

# 20.166.1.661 CKR\_OK

#define CKR\_OK 0x0000000UL

### 20.166.1.662 CKR\_OPERATION\_ACTIVE

#define CKR\_OPERATION\_ACTIVE 0x00000090UL

# 20.166.1.663 CKR\_OPERATION\_NOT\_INITIALIZED

#define CKR\_OPERATION\_NOT\_INITIALIZED 0x00000091UL

# 20.166.1.664 CKR\_PIN\_EXPIRED

#define CKR\_PIN\_EXPIRED 0x000000A3UL

# 20.166.1.665 CKR\_PIN\_INCORRECT

#define CKR\_PIN\_INCORRECT 0x000000A0UL

### 20.166.1.666 CKR\_PIN\_INVALID

#define CKR\_PIN\_INVALID 0x000000A1UL

# 20.166.1.667 CKR\_PIN\_LEN\_RANGE

#define CKR\_PIN\_LEN\_RANGE 0x000000A2UL

## 20.166.1.668 CKR PIN LOCKED

#define CKR\_PIN\_LOCKED 0x000000A4UL

# 20.166.1.669 CKR\_PIN\_TOO\_WEAK

#define CKR\_PIN\_TOO\_WEAK 0x000001B8UL

### 20.166.1.670 CKR\_PUBLIC\_KEY\_INVALID

#define CKR\_PUBLIC\_KEY\_INVALID 0x000001B9UL

# 20.166.1.671 CKR\_RANDOM\_NO\_RNG

#define CKR\_RANDOM\_NO\_RNG 0x00000121UL

# 20.166.1.672 CKR\_RANDOM\_SEED\_NOT\_SUPPORTED

#define CKR\_RANDOM\_SEED\_NOT\_SUPPORTED 0x00000120UL

# 20.166.1.673 CKR\_SAVED\_STATE\_INVALID

#define CKR\_SAVED\_STATE\_INVALID 0x00000160UL

### 20.166.1.674 CKR\_SESSION\_CLOSED

#define CKR\_SESSION\_CLOSED 0x000000B0UL

# 20.166.1.675 CKR\_SESSION\_COUNT

#define CKR\_SESSION\_COUNT 0x000000B1UL

### 20.166.1.676 CKR SESSION EXISTS

#define CKR\_SESSION\_EXISTS 0x000000B6UL

# 20.166.1.677 CKR\_SESSION\_HANDLE\_INVALID

#define CKR\_SESSION\_HANDLE\_INVALID 0x000000B3UL

# 20.166.1.678 CKR\_SESSION\_PARALLEL\_NOT\_SUPPORTED

#define CKR\_SESSION\_PARALLEL\_NOT\_SUPPORTED 0x000000B4UL

# 20.166.1.679 CKR\_SESSION\_READ\_ONLY

#define CKR\_SESSION\_READ\_ONLY 0x000000B5UL

### 20.166.1.680 CKR\_SESSION\_READ\_ONLY\_EXISTS

#define CKR\_SESSION\_READ\_ONLY\_EXISTS 0x000000B7UL

# 20.166.1.681 CKR\_SESSION\_READ\_WRITE\_SO\_EXISTS

#define CKR\_SESSION\_READ\_WRITE\_SO\_EXISTS 0x000000B8UL

### 20.166.1.682 CKR\_SIGNATURE\_INVALID

#define CKR\_SIGNATURE\_INVALID 0x000000C0UL

# 20.166.1.683 CKR\_SIGNATURE\_LEN\_RANGE

#define CKR\_SIGNATURE\_LEN\_RANGE 0x000000C1UL

## 20.166.1.684 CKR SLOT ID INVALID

#define CKR\_SLOT\_ID\_INVALID 0x00000003UL

# 20.166.1.685 CKR\_STATE\_UNSAVEABLE

#define CKR\_STATE\_UNSAVEABLE 0x00000180UL

### 20.166.1.686 CKR\_TEMPLATE\_INCOMPLETE

#define CKR\_TEMPLATE\_INCOMPLETE 0x000000D0UL

# 20.166.1.687 CKR\_TEMPLATE\_INCONSISTENT

#define CKR\_TEMPLATE\_INCONSISTENT 0x000000D1UL

### 20.166.1.688 CKR\_TOKEN\_NOT\_PRESENT

#define CKR\_TOKEN\_NOT\_PRESENT 0x000000E0UL

# 20.166.1.689 CKR\_TOKEN\_NOT\_RECOGNIZED

#define CKR\_TOKEN\_NOT\_RECOGNIZED 0x000000E1UL

### 20.166.1.690 CKR\_TOKEN\_WRITE\_PROTECTED

#define CKR\_TOKEN\_WRITE\_PROTECTED 0x000000E2UL

# 20.166.1.691 CKR\_UNWRAPPING\_KEY\_HANDLE\_INVALID

#define CKR\_UNWRAPPING\_KEY\_HANDLE\_INVALID 0x000000F0UL

### 20.166.1.692 CKR UNWRAPPING KEY SIZE RANGE

#define CKR\_UNWRAPPING\_KEY\_SIZE\_RANGE 0x000000F1UL

# 20.166.1.693 CKR\_UNWRAPPING\_KEY\_TYPE\_INCONSISTENT

#define CKR\_UNWRAPPING\_KEY\_TYPE\_INCONSISTENT 0x000000F2UL

### 20.166.1.694 CKR\_USER\_ALREADY\_LOGGED\_IN

#define CKR\_USER\_ALREADY\_LOGGED\_IN 0x00000100UL

# 20.166.1.695 CKR\_USER\_ANOTHER\_ALREADY\_LOGGED\_IN

#define CKR\_USER\_ANOTHER\_ALREADY\_LOGGED\_IN 0x00000104UL

### 20.166.1.696 CKR\_USER\_NOT\_LOGGED\_IN

#define CKR\_USER\_NOT\_LOGGED\_IN 0x00000101UL

# 20.166.1.697 CKR\_USER\_PIN\_NOT\_INITIALIZED

#define CKR\_USER\_PIN\_NOT\_INITIALIZED 0x00000102UL

### 20.166.1.698 CKR\_USER\_TOO\_MANY\_TYPES

#define CKR\_USER\_TOO\_MANY\_TYPES 0x00000105UL

# 20.166.1.699 CKR\_USER\_TYPE\_INVALID

#define CKR\_USER\_TYPE\_INVALID 0x00000103UL

## 20.166.1.700 CKR VENDOR DEFINED

#define CKR\_VENDOR\_DEFINED 0x8000000UL

# 20.166.1.701 CKR\_WRAPPED\_KEY\_INVALID

#define CKR\_WRAPPED\_KEY\_INVALID 0x00000110UL

### 20.166.1.702 CKR\_WRAPPED\_KEY\_LEN\_RANGE

#define CKR\_WRAPPED\_KEY\_LEN\_RANGE 0x00000112UL

# 20.166.1.703 CKR\_WRAPPING\_KEY\_HANDLE\_INVALID

#define CKR\_WRAPPING\_KEY\_HANDLE\_INVALID 0x00000113UL

# 20.166.1.704 CKR\_WRAPPING\_KEY\_SIZE\_RANGE

#define CKR\_WRAPPING\_KEY\_SIZE\_RANGE 0x00000114UL

# 20.166.1.705 CKR\_WRAPPING\_KEY\_TYPE\_INCONSISTENT

#define CKR\_WRAPPING\_KEY\_TYPE\_INCONSISTENT 0x00000115UL

### 20.166.1.706 CKS\_RO\_PUBLIC\_SESSION

#define CKS\_RO\_PUBLIC\_SESSION OUL

# 20.166.1.707 CKS\_RO\_USER\_FUNCTIONS

#define CKS\_RO\_USER\_FUNCTIONS 1UL

### 20.166.1.708 CKS RW PUBLIC SESSION

#define CKS\_RW\_PUBLIC\_SESSION 2UL

# 20.166.1.709 CKS\_RW\_SO\_FUNCTIONS

#define CKS\_RW\_SO\_FUNCTIONS 4UL

### 20.166.1.710 CKS\_RW\_USER\_FUNCTIONS

#define CKS\_RW\_USER\_FUNCTIONS 3UL

# 20.166.1.711 CKU\_CONTEXT\_SPECIFIC

#define CKU\_CONTEXT\_SPECIFIC 2UL

# 20.166.1.712 CKU\_SO

#define CKU\_SO OUL

# 20.166.1.713 CKU\_USER

#define CKU\_USER 1UL

### 20.166.1.714 CKZ\_DATA\_SPECIFIED

#define CKZ\_DATA\_SPECIFIED 0x0000001UL

# 20.166.1.715 CKZ\_SALT\_SPECIFIED

#define CKZ\_SALT\_SPECIFIED 0x0000001UL

# 20.166.1.716 CRYPTOKI\_VERSION\_AMENDMENT

#define CRYPTOKI\_VERSION\_AMENDMENT 0

# 20.166.1.717 CRYPTOKI\_VERSION\_MAJOR

#define CRYPTOKI\_VERSION\_MAJOR 2

# 20.166.1.718 CRYPTOKI\_VERSION\_MINOR

#define CRYPTOKI\_VERSION\_MINOR 40

### 20.166.1.719 FALSE

#define FALSE CK\_FALSE

### 20.166.1.720 TRUE

#define TRUE CK\_TRUE

# 20.166.2 Typedef Documentation

# 20.166.2.1 CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS

typedef struct CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS

# 20.166.2.2 CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

typedef CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_AES\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

### 20.166.2.3 CK\_AES\_CCM\_PARAMS

typedef struct CK\_AES\_CCM\_PARAMS CK\_AES\_CCM\_PARAMS

# 20.166.2.4 CK\_AES\_CCM\_PARAMS\_PTR

typedef CK\_AES\_CCM\_PARAMS CK\_PTR CK\_AES\_CCM\_PARAMS\_PTR

# 20.166.2.5 CK\_AES\_CTR\_PARAMS

typedef struct CK\_AES\_CTR\_PARAMS CK\_AES\_CTR\_PARAMS

### 20.166.2.6 CK\_AES\_CTR\_PARAMS\_PTR

typedef CK\_AES\_CTR\_PARAMS CK\_PTR CK\_AES\_CTR\_PARAMS\_PTR

# 20.166.2.7 CK\_AES\_GCM\_PARAMS

typedef struct CK\_AES\_GCM\_PARAMS CK\_AES\_GCM\_PARAMS

# 20.166.2.8 CK\_AES\_GCM\_PARAMS\_PTR

typedef CK\_AES\_GCM\_PARAMS CK\_PTR CK\_AES\_GCM\_PARAMS\_PTR

### 20.166.2.9 CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS

typedef struct CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS

# 20.166.2.10 CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

typedef CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_ARIA\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

## 20.166.2.11 CK\_ATTRIBUTE

typedef struct CK\_ATTRIBUTE CK\_ATTRIBUTE

# 20.166.2.12 CK\_ATTRIBUTE\_PTR

typedef CK\_ATTRIBUTE CK\_PTR CK\_ATTRIBUTE\_PTR

## 20.166.2.13 CK\_ATTRIBUTE\_TYPE

typedef CK\_ULONG CK\_ATTRIBUTE\_TYPE

### 20.166.2.14 CK\_BBOOL

typedef CK\_BYTE CK\_BBOOL

# 20.166.2.15 CK\_BYTE

typedef unsigned char CK\_BYTE

# 20.166.2.16 CK\_BYTE\_PTR

typedef CK\_BYTE CK\_PTR CK\_BYTE\_PTR

### 20.166.2.17 CK\_C\_INITIALIZE\_ARGS

typedef struct CK\_C\_INITIALIZE\_ARGS CK\_C\_INITIALIZE\_ARGS

# 20.166.2.18 CK\_C\_INITIALIZE\_ARGS\_PTR

typedef CK\_C\_INITIALIZE\_ARGS CK\_PTR CK\_C\_INITIALIZE\_ARGS\_PTR

### 20.166.2.19 CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS

typedef struct CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS

# 20.166.2.20 CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

typedef CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_CAMELLIA\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

### 20.166.2.21 CK\_CAMELLIA\_CTR\_PARAMS

 ${\tt typedef\ struct\ CK\_CAMELLIA\_CTR\_PARAMS\ CK\_CAMELLIA\_CTR\_PARAMS}$ 

# 20.166.2.22 CK\_CAMELLIA\_CTR\_PARAMS\_PTR

typedef CK\_CAMELLIA\_CTR\_PARAMS CK\_PTR CK\_CAMELLIA\_CTR\_PARAMS\_PTR

# 20.166.2.23 CK\_CCM\_PARAMS

typedef struct CK\_CCM\_PARAMS CK\_CCM\_PARAMS

# 20.166.2.24 CK\_CCM\_PARAMS\_PTR

typedef CK\_CCM\_PARAMS CK\_PTR CK\_CCM\_PARAMS\_PTR

### 20.166.2.25 CK\_CERTIFICATE\_CATEGORY

typedef CK\_ULONG CK\_CERTIFICATE\_CATEGORY

# 20.166.2.26 CK\_CERTIFICATE\_TYPE

typedef CK\_ULONG CK\_CERTIFICATE\_TYPE

# 20.166.2.27 CK\_CHAR

typedef CK\_BYTE CK\_CHAR

# 20.166.2.28 CK\_CHAR\_PTR

typedef CK\_CHAR CK\_PTR CK\_CHAR\_PTR

# 20.166.2.29 CK\_CMS\_SIG\_PARAMS

typedef struct CK\_CMS\_SIG\_PARAMS CK\_CMS\_SIG\_PARAMS

# 20.166.2.30 CK\_CMS\_SIG\_PARAMS\_PTR

typedef CK\_CMS\_SIG\_PARAMS CK\_PTR CK\_CMS\_SIG\_PARAMS\_PTR

### 20.166.2.31 CK\_DATE

typedef struct CK\_DATE CK\_DATE

# 20.166.2.32 CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS

typedef struct CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS

### 20.166.2.33 CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

typedef CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_DES\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

### 20.166.2.34 CK\_DSA\_PARAMETER\_GEN\_PARAM

typedef struct CK\_DSA\_PARAMETER\_GEN\_PARAM CK\_DSA\_PARAMETER\_GEN\_PARAM

### 20.166.2.35 CK DSA PARAMETER GEN PARAM PTR

typedef CK\_DSA\_PARAMETER\_GEN\_PARAM CK\_PTR CK\_DSA\_PARAMETER\_GEN\_PARAM\_PTR

# 20.166.2.36 CK\_EC\_KDF\_TYPE

typedef CK\_ULONG CK\_EC\_KDF\_TYPE

### 20.166.2.37 CK\_ECDH1\_DERIVE\_PARAMS

typedef struct CK\_ECDH1\_DERIVE\_PARAMS CK\_ECDH1\_DERIVE\_PARAMS

### 20.166.2.38 CK\_ECDH1\_DERIVE\_PARAMS\_PTR

typedef CK\_ECDH1\_DERIVE\_PARAMS CK\_PTR CK\_ECDH1\_DERIVE\_PARAMS\_PTR

### 20.166.2.39 CK\_ECDH2\_DERIVE\_PARAMS

typedef struct CK\_ECDH2\_DERIVE\_PARAMS CK\_ECDH2\_DERIVE\_PARAMS

# 20.166.2.40 CK\_ECDH2\_DERIVE\_PARAMS\_PTR

typedef CK\_ECDH2\_DERIVE\_PARAMS CK\_PTR CK\_ECDH2\_DERIVE\_PARAMS\_PTR

### 20.166.2.41 CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS

typedef struct CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS

### 20.166.2.42 CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS\_PTR

typedef CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS CK\_PTR CK\_ECDH\_AES\_KEY\_WRAP\_PARAMS\_PTR

### 20.166.2.43 CK ECMQV DERIVE PARAMS

typedef struct CK\_ECMQV\_DERIVE\_PARAMS CK\_ECMQV\_DERIVE\_PARAMS

# 20.166.2.44 CK\_ECMQV\_DERIVE\_PARAMS\_PTR

typedef CK\_ECMQV\_DERIVE\_PARAMS CK\_PTR CK\_ECMQV\_DERIVE\_PARAMS\_PTR

### 20.166.2.45 CK\_EXTRACT\_PARAMS

typedef CK\_ULONG CK\_EXTRACT\_PARAMS

# 20.166.2.46 CK\_EXTRACT\_PARAMS\_PTR

typedef CK\_EXTRACT\_PARAMS CK\_PTR CK\_EXTRACT\_PARAMS\_PTR

# 20.166.2.47 CK\_FLAGS

typedef CK\_ULONG CK\_FLAGS

# 20.166.2.48 CK\_FUNCTION\_LIST

typedef struct CK\_FUNCTION\_LIST CK\_FUNCTION\_LIST

### 20.166.2.49 CK\_FUNCTION\_LIST\_PTR

typedef CK\_FUNCTION\_LIST CK\_PTR CK\_FUNCTION\_LIST\_PTR

# 20.166.2.50 CK\_FUNCTION\_LIST\_PTR\_PTR

typedef CK\_FUNCTION\_LIST\_PTR CK\_PTR CK\_FUNCTION\_LIST\_PTR\_PTR

# 20.166.2.51 CK\_GCM\_PARAMS

typedef struct CK\_GCM\_PARAMS CK\_GCM\_PARAMS

# 20.166.2.52 CK\_GCM\_PARAMS\_PTR

typedef CK\_GCM\_PARAMS CK\_PTR CK\_GCM\_PARAMS\_PTR

### 20.166.2.53 CK\_GOSTR3410\_DERIVE\_PARAMS

typedef struct CK\_GOSTR3410\_DERIVE\_PARAMS CK\_GOSTR3410\_DERIVE\_PARAMS

# 20.166.2.54 CK\_GOSTR3410\_DERIVE\_PARAMS\_PTR

typedef CK\_GOSTR3410\_DERIVE\_PARAMS CK\_PTR CK\_GOSTR3410\_DERIVE\_PARAMS\_PTR

# 20.166.2.55 CK\_GOSTR3410\_KEY\_WRAP\_PARAMS

typedef struct CK\_GOSTR3410\_KEY\_WRAP\_PARAMS CK\_GOSTR3410\_KEY\_WRAP\_PARAMS

# 20.166.2.56 CK\_GOSTR3410\_KEY\_WRAP\_PARAMS\_PTR

typedef CK\_GOSTR3410\_KEY\_WRAP\_PARAMS CK\_PTR CK\_GOSTR3410\_KEY\_WRAP\_PARAMS\_PTR

### 20.166.2.57 CK\_HW\_FEATURE\_TYPE

typedef CK\_ULONG CK\_HW\_FEATURE\_TYPE

# 20.166.2.58 CK\_INFO

typedef struct CK\_INFO CK\_INFO

## 20.166.2.59 CK INFO PTR

typedef CK\_INFO CK\_PTR CK\_INFO\_PTR

# 20.166.2.60 CK\_JAVA\_MIDP\_SECURITY\_DOMAIN

typedef CK\_ULONG CK\_JAVA\_MIDP\_SECURITY\_DOMAIN

### 20.166.2.61 CK\_KEA\_DERIVE\_PARAMS

typedef struct CK\_KEA\_DERIVE\_PARAMS CK\_KEA\_DERIVE\_PARAMS

# 20.166.2.62 CK\_KEA\_DERIVE\_PARAMS\_PTR

typedef CK\_KEA\_DERIVE\_PARAMS CK\_PTR CK\_KEA\_DERIVE\_PARAMS\_PTR

### 20.166.2.63 CK\_KEY\_DERIVATION\_STRING\_DATA

typedef struct CK\_KEY\_DERIVATION\_STRING\_DATA CK\_KEY\_DERIVATION\_STRING\_DATA

# 20.166.2.64 CK\_KEY\_DERIVATION\_STRING\_DATA\_PTR

typedef CK\_KEY\_DERIVATION\_STRING\_DATA CK\_PTR CK\_KEY\_DERIVATION\_STRING\_DATA\_PTR

### 20.166.2.65 CK\_KEY\_TYPE

typedef CK\_ULONG CK\_KEY\_TYPE

# 20.166.2.66 CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS

typedef struct CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS

### 20.166.2.67 CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS\_PTR

typedef CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS CK\_PTR CK\_KEY\_WRAP\_SET\_OAEP\_PARAMS\_PTR

# 20.166.2.68 CK\_KIP\_PARAMS

typedef struct CK\_KIP\_PARAMS CK\_KIP\_PARAMS

### 20.166.2.69 CK\_KIP\_PARAMS\_PTR

typedef CK\_KIP\_PARAMS CK\_PTR CK\_KIP\_PARAMS\_PTR

### 20.166.2.70 CK\_LONG

typedef long int CK\_LONG

# 20.166.2.71 CK\_MAC\_GENERAL\_PARAMS

typedef CK\_ULONG CK\_MAC\_GENERAL\_PARAMS

# 20.166.2.72 CK\_MAC\_GENERAL\_PARAMS\_PTR

typedef CK\_MAC\_GENERAL\_PARAMS CK\_PTR CK\_MAC\_GENERAL\_PARAMS\_PTR

### 20.166.2.73 CK\_MECHANISM

typedef struct CK\_MECHANISM CK\_MECHANISM

# 20.166.2.74 CK\_MECHANISM\_INFO

typedef struct CK\_MECHANISM\_INFO CK\_MECHANISM\_INFO

# 20.166.2.75 CK\_MECHANISM\_INFO\_PTR

typedef CK\_MECHANISM\_INFO CK\_PTR CK\_MECHANISM\_INFO\_PTR

# 20.166.2.76 CK\_MECHANISM\_PTR

typedef CK\_MECHANISM CK\_PTR CK\_MECHANISM\_PTR

### 20.166.2.77 CK\_MECHANISM\_TYPE

typedef CK\_ULONG CK\_MECHANISM\_TYPE

# 20.166.2.78 CK\_MECHANISM\_TYPE\_PTR

typedef CK\_MECHANISM\_TYPE CK\_PTR CK\_MECHANISM\_TYPE\_PTR

# 20.166.2.79 CK\_NOTIFICATION

typedef CK\_ULONG CK\_NOTIFICATION

# 20.166.2.80 CK\_OBJECT\_CLASS

typedef CK\_ULONG CK\_OBJECT\_CLASS

### 20.166.2.81 CK\_OBJECT\_CLASS\_PTR

typedef CK\_OBJECT\_CLASS CK\_PTR CK\_OBJECT\_CLASS\_PTR

# 20.166.2.82 CK\_OBJECT\_HANDLE

typedef CK\_ULONG CK\_OBJECT\_HANDLE

# 20.166.2.83 CK\_OBJECT\_HANDLE\_PTR

typedef CK\_OBJECT\_HANDLE CK\_PTR CK\_OBJECT\_HANDLE\_PTR

# 20.166.2.84 CK\_OTP\_PARAM

typedef struct CK\_OTP\_PARAM CK\_OTP\_PARAM

### 20.166.2.85 CK\_OTP\_PARAM\_PTR

typedef CK\_OTP\_PARAM CK\_PTR CK\_OTP\_PARAM\_PTR

# 20.166.2.86 CK\_OTP\_PARAM\_TYPE

typedef CK\_ULONG CK\_OTP\_PARAM\_TYPE

# 20.166.2.87 CK\_OTP\_PARAMS

typedef struct CK\_OTP\_PARAMS CK\_OTP\_PARAMS

# 20.166.2.88 CK\_OTP\_PARAMS\_PTR

typedef CK\_OTP\_PARAMS CK\_PTR CK\_OTP\_PARAMS\_PTR

### 20.166.2.89 CK\_OTP\_SIGNATURE\_INFO

typedef struct CK\_OTP\_SIGNATURE\_INFO CK\_OTP\_SIGNATURE\_INFO

# 20.166.2.90 CK\_OTP\_SIGNATURE\_INFO\_PTR

typedef CK\_OTP\_SIGNATURE\_INFO CK\_PTR CK\_OTP\_SIGNATURE\_INFO\_PTR

# 20.166.2.91 CK\_PARAM\_TYPE

typedef CK\_OTP\_PARAM\_TYPE CK\_PARAM\_TYPE

# 20.166.2.92 CK\_PBE\_PARAMS

typedef struct CK\_PBE\_PARAMS CK\_PBE\_PARAMS

## 20.166.2.93 CK\_PBE\_PARAMS\_PTR

typedef CK\_PBE\_PARAMS CK\_PTR CK\_PBE\_PARAMS\_PTR

### 20.166.2.94 CK\_PKCS5\_PBKD2\_PARAMS

typedef struct CK\_PKCS5\_PBKD2\_PARAMS CK\_PKCS5\_PBKD2\_PARAMS

#### 20.166.2.95 CK\_PKCS5\_PBKD2\_PARAMS2

typedef struct CK\_PKCS5\_PBKD2\_PARAMS2 CK\_PKCS5\_PBKD2\_PARAMS2

#### 20.166.2.96 CK PKCS5 PBKD2 PARAMS2 PTR

typedef CK\_PKCS5\_PBKD2\_PARAMS2 CK\_PTR CK\_PKCS5\_PBKD2\_PARAMS2\_PTR

#### 20.166.2.97 CK\_PKCS5\_PBKD2\_PARAMS\_PTR

typedef CK\_PKCS5\_PBKD2\_PARAMS CK\_PTR CK\_PKCS5\_PBKD2\_PARAMS\_PTR

### 20.166.2.98 CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE

typedef CK\_ULONG CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE

#### 20.166.2.99 CK PKCS5 PBKD2 PSEUDO RANDOM FUNCTION TYPE PTR

typedef CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE CK\_PTR CK\_PKCS5\_PBKD2\_PSEUDO\_RANDOM\_FUNCTION\_TYPE\_PTR

# 20.166.2.100 CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE

typedef CK\_ULONG CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE

### 20.166.2.101 CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE\_PTR

typedef CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE CK\_PTR CK\_PKCS5\_PBKDF2\_SALT\_SOURCE\_TYPE\_PTR

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 1046

# 20.166.2.102 CK\_RC2\_CBC\_PARAMS

typedef struct CK\_RC2\_CBC\_PARAMS CK\_RC2\_CBC\_PARAMS

# 20.166.2.103 CK\_RC2\_CBC\_PARAMS\_PTR

typedef CK\_RC2\_CBC\_PARAMS CK\_PTR CK\_RC2\_CBC\_PARAMS\_PTR

# 20.166.2.104 CK\_RC2\_MAC\_GENERAL\_PARAMS

typedef struct CK\_RC2\_MAC\_GENERAL\_PARAMS CK\_RC2\_MAC\_GENERAL\_PARAMS

#### 20.166.2.105 CK\_RC2\_MAC\_GENERAL\_PARAMS\_PTR

typedef CK\_RC2\_MAC\_GENERAL\_PARAMS CK\_PTR CK\_RC2\_MAC\_GENERAL\_PARAMS\_PTR

# 20.166.2.106 CK\_RC2\_PARAMS

typedef CK\_ULONG CK\_RC2\_PARAMS

### 20.166.2.107 CK RC2 PARAMS PTR

typedef CK\_RC2\_PARAMS CK\_PTR CK\_RC2\_PARAMS\_PTR

# 20.166.2.108 CK\_RC5\_CBC\_PARAMS

typedef struct CK\_RC5\_CBC\_PARAMS CK\_RC5\_CBC\_PARAMS

### 20.166.2.109 CK\_RC5\_CBC\_PARAMS\_PTR

typedef CK\_RC5\_CBC\_PARAMS CK\_PTR CK\_RC5\_CBC\_PARAMS\_PTR

# 20.166.2.110 CK\_RC5\_MAC\_GENERAL\_PARAMS

typedef struct CK\_RC5\_MAC\_GENERAL\_PARAMS CK\_RC5\_MAC\_GENERAL\_PARAMS

#### 20.166.2.111 CK\_RC5\_MAC\_GENERAL\_PARAMS\_PTR

typedef CK\_RC5\_MAC\_GENERAL\_PARAMS CK\_PTR CK\_RC5\_MAC\_GENERAL\_PARAMS\_PTR

# 20.166.2.112 CK\_RC5\_PARAMS

typedef struct CK\_RC5\_PARAMS CK\_RC5\_PARAMS

#### 20.166.2.113 CK\_RC5\_PARAMS\_PTR

typedef CK\_RC5\_PARAMS CK\_PTR CK\_RC5\_PARAMS\_PTR

# 20.166.2.114 CK\_RSA\_AES\_KEY\_WRAP\_PARAMS

typedef struct CK\_RSA\_AES\_KEY\_WRAP\_PARAMS CK\_RSA\_AES\_KEY\_WRAP\_PARAMS

#### 20.166.2.115 CK RSA AES KEY WRAP PARAMS PTR

typedef CK\_RSA\_AES\_KEY\_WRAP\_PARAMS CK\_PTR CK\_RSA\_AES\_KEY\_WRAP\_PARAMS\_PTR

# 20.166.2.116 CK\_RSA\_PKCS\_MGF\_TYPE

typedef CK\_ULONG CK\_RSA\_PKCS\_MGF\_TYPE

### 20.166.2.117 CK\_RSA\_PKCS\_MGF\_TYPE\_PTR

typedef CK\_RSA\_PKCS\_MGF\_TYPE CK\_PTR CK\_RSA\_PKCS\_MGF\_TYPE\_PTR

### 20.166.2.118 CK\_RSA\_PKCS\_OAEP\_PARAMS

typedef struct CK\_RSA\_PKCS\_OAEP\_PARAMS CK\_RSA\_PKCS\_OAEP\_PARAMS

# 20.166.2.119 CK\_RSA\_PKCS\_OAEP\_PARAMS\_PTR

typedef CK\_RSA\_PKCS\_OAEP\_PARAMS CK\_PTR CK\_RSA\_PKCS\_OAEP\_PARAMS\_PTR

# 20.166.2.120 CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE

typedef CK\_ULONG CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE

#### 20.166.2.121 CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE\_PTR

typedef CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE CK\_PTR CK\_RSA\_PKCS\_OAEP\_SOURCE\_TYPE\_PTR

### 20.166.2.122 CK\_RSA\_PKCS\_PSS\_PARAMS

typedef struct CK\_RSA\_PKCS\_PSS\_PARAMS CK\_RSA\_PKCS\_PSS\_PARAMS

#### 20.166.2.123 CK RSA PKCS PSS PARAMS PTR

typedef CK\_RSA\_PKCS\_PSS\_PARAMS CK\_PTR CK\_RSA\_PKCS\_PSS\_PARAMS\_PTR

# 20.166.2.124 CK\_RV

typedef CK\_ULONG CK\_RV

### 20.166.2.125 CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS

typedef struct CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS

# 20.166.2.126 CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

typedef CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS CK\_PTR CK\_SEED\_CBC\_ENCRYPT\_DATA\_PARAMS\_PTR

# 20.166.2.127 CK\_SESSION\_HANDLE

typedef CK\_ULONG CK\_SESSION\_HANDLE

# 20.166.2.128 CK\_SESSION\_HANDLE\_PTR

typedef CK\_SESSION\_HANDLE CK\_PTR CK\_SESSION\_HANDLE\_PTR

#### 20.166.2.129 CK\_SESSION\_INFO

typedef struct CK\_SESSION\_INFO CK\_SESSION\_INFO

### 20.166.2.130 CK\_SESSION\_INFO\_PTR

typedef CK\_SESSION\_INFO CK\_PTR CK\_SESSION\_INFO\_PTR

#### 20.166.2.131 CK SKIPJACK PRIVATE WRAP PARAMS

typedef struct CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS

# 20.166.2.132 CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS\_PTR

typedef CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS CK\_PTR CK\_SKIPJACK\_PRIVATE\_WRAP\_PARAMS\_PTR

### 20.166.2.133 CK\_SKIPJACK\_RELAYX\_PARAMS

typedef struct CK\_SKIPJACK\_RELAYX\_PARAMS CK\_SKIPJACK\_RELAYX\_PARAMS

# 20.166.2.134 CK\_SKIPJACK\_RELAYX\_PARAMS\_PTR

typedef CK\_SKIPJACK\_RELAYX\_PARAMS CK\_PTR CK\_SKIPJACK\_RELAYX\_PARAMS\_PTR

# 20.166.2.135 CK\_SLOT\_ID

typedef CK\_ULONG CK\_SLOT\_ID

# 20.166.2.136 CK\_SLOT\_ID\_PTR

typedef CK\_SLOT\_ID CK\_PTR CK\_SLOT\_ID\_PTR

#### 20.166.2.137 CK\_SLOT\_INFO

typedef struct CK\_SLOT\_INFO CK\_SLOT\_INFO

# 20.166.2.138 CK\_SLOT\_INFO\_PTR

typedef CK\_SLOT\_INFO CK\_PTR CK\_SLOT\_INFO\_PTR

# 20.166.2.139 CK\_SSL3\_KEY\_MAT\_OUT

typedef struct CK\_SSL3\_KEY\_MAT\_OUT CK\_SSL3\_KEY\_MAT\_OUT

# 20.166.2.140 CK\_SSL3\_KEY\_MAT\_OUT\_PTR

typedef CK\_SSL3\_KEY\_MAT\_OUT CK\_PTR CK\_SSL3\_KEY\_MAT\_OUT\_PTR

# 20.166.2.141 CK\_SSL3\_KEY\_MAT\_PARAMS

typedef struct CK\_SSL3\_KEY\_MAT\_PARAMS CK\_SSL3\_KEY\_MAT\_PARAMS

# 20.166.2.142 CK\_SSL3\_KEY\_MAT\_PARAMS\_PTR

typedef CK\_SSL3\_KEY\_MAT\_PARAMS CK\_PTR CK\_SSL3\_KEY\_MAT\_PARAMS\_PTR

#### 20.166.2.143 CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS

typedef struct CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS

# 20.166.2.144 CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

typedef struct CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS CK\_PTR CK\_SSL3\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

#### 20.166.2.145 CK\_SSL3\_RANDOM\_DATA

typedef struct CK\_SSL3\_RANDOM\_DATA CK\_SSL3\_RANDOM\_DATA

### 20.166.2.146 CK\_STATE

typedef CK\_ULONG CK\_STATE

### 20.166.2.147 CK TLS12 KEY MAT PARAMS

typedef struct CK\_TLS12\_KEY\_MAT\_PARAMS CK\_TLS12\_KEY\_MAT\_PARAMS

# 20.166.2.148 CK\_TLS12\_KEY\_MAT\_PARAMS\_PTR

typedef CK\_TLS12\_KEY\_MAT\_PARAMS CK\_PTR CK\_TLS12\_KEY\_MAT\_PARAMS\_PTR

### 20.166.2.149 CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS

typedef struct CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS

# 20.166.2.150 CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

typedef CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS CK\_PTR CK\_TLS12\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

# 20.166.2.151 CK\_TLS\_KDF\_PARAMS

typedef struct CK\_TLS\_KDF\_PARAMS CK\_TLS\_KDF\_PARAMS

# 20.166.2.152 CK\_TLS\_KDF\_PARAMS\_PTR

typedef CK\_TLS\_KDF\_PARAMS CK\_PTR CK\_TLS\_KDF\_PARAMS\_PTR

#### 20.166.2.153 CK\_TLS\_MAC\_PARAMS

typedef struct CK\_TLS\_MAC\_PARAMS CK\_TLS\_MAC\_PARAMS

# 20.166.2.154 CK\_TLS\_MAC\_PARAMS\_PTR

typedef CK\_TLS\_MAC\_PARAMS CK\_PTR CK\_TLS\_MAC\_PARAMS\_PTR

### 20.166.2.155 CK TLS PRF PARAMS

typedef struct CK\_TLS\_PRF\_PARAMS CK\_TLS\_PRF\_PARAMS

# 20.166.2.156 CK\_TLS\_PRF\_PARAMS\_PTR

typedef CK\_TLS\_PRF\_PARAMS CK\_PTR CK\_TLS\_PRF\_PARAMS\_PTR

### 20.166.2.157 CK\_TOKEN\_INFO

typedef struct CK\_TOKEN\_INFO CK\_TOKEN\_INFO

# 20.166.2.158 CK\_TOKEN\_INFO\_PTR

typedef CK\_TOKEN\_INFO CK\_PTR CK\_TOKEN\_INFO\_PTR

# 20.166.2.159 CK\_ULONG

typedef unsigned long int CK\_ULONG

# 20.166.2.160 CK\_ULONG\_PTR

typedef CK\_ULONG CK\_PTR CK\_ULONG\_PTR

#### 20.166.2.161 CK\_USER\_TYPE

typedef CK\_ULONG CK\_USER\_TYPE

# 20.166.2.162 CK\_UTF8CHAR

typedef CK\_BYTE CK\_UTF8CHAR

# 20.166.2.163 CK\_UTF8CHAR\_PTR

typedef CK\_UTF8CHAR CK\_PTR CK\_UTF8CHAR\_PTR

# 20.166.2.164 CK\_VERSION

typedef struct CK\_VERSION CK\_VERSION

# 20.166.2.165 CK\_VERSION\_PTR

typedef CK\_VERSION CK\_PTR CK\_VERSION\_PTR

#### 20.166.2.166 CK\_VOID\_PTR

typedef void CK\_PTR CK\_VOID\_PTR

# 20.166.2.167 CK\_VOID\_PTR\_PTR

typedef CK\_VOID\_PTR CK\_PTR CK\_VOID\_PTR\_PTR

# 20.166.2.168 CK\_WTLS\_KEY\_MAT\_OUT

typedef struct CK\_WTLS\_KEY\_MAT\_OUT CK\_WTLS\_KEY\_MAT\_OUT

#### 20.166.2.169 CK\_WTLS\_KEY\_MAT\_OUT\_PTR

typedef CK\_WTLS\_KEY\_MAT\_OUT CK\_PTR CK\_WTLS\_KEY\_MAT\_OUT\_PTR

# 20.166.2.170 CK\_WTLS\_KEY\_MAT\_PARAMS

typedef struct CK\_WTLS\_KEY\_MAT\_PARAMS CK\_WTLS\_KEY\_MAT\_PARAMS

#### 20.166.2.171 CK WTLS KEY MAT PARAMS PTR

typedef CK\_WTLS\_KEY\_MAT\_PARAMS CK\_PTR CK\_WTLS\_KEY\_MAT\_PARAMS\_PTR

# 20.166.2.172 CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS

typedef struct CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS

### 20.166.2.173 CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

typedef CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS CK\_PTR CK\_WTLS\_MASTER\_KEY\_DERIVE\_PARAMS\_PTR

### 20.166.2.174 CK\_WTLS\_PRF\_PARAMS

typedef struct CK\_WTLS\_PRF\_PARAMS CK\_WTLS\_PRF\_PARAMS

# 20.166.2.175 CK\_WTLS\_PRF\_PARAMS\_PTR

typedef CK\_WTLS\_PRF\_PARAMS CK\_PTR CK\_WTLS\_PRF\_PARAMS\_PTR

# 20.166.2.176 CK\_WTLS\_RANDOM\_DATA

typedef struct CK\_WTLS\_RANDOM\_DATA CK\_WTLS\_RANDOM\_DATA

#### 20.166.2.177 CK\_WTLS\_RANDOM\_DATA\_PTR

typedef CK\_WTLS\_RANDOM\_DATA CK\_PTR CK\_WTLS\_RANDOM\_DATA\_PTR

### 20.166.2.178 CK\_X9\_42\_DH1\_DERIVE\_PARAMS

typedef struct CK\_X9\_42\_DH1\_DERIVE\_PARAMS CK\_X9\_42\_DH1\_DERIVE\_PARAMS

#### 20.166.2.179 CK X9 42 DH1 DERIVE PARAMS PTR

typedef struct CK\_X9\_42\_DH1\_DERIVE\_PARAMS CK\_PTR CK\_X9\_42\_DH1\_DERIVE\_PARAMS\_PTR

# 20.166.2.180 CK\_X9\_42\_DH2\_DERIVE\_PARAMS

typedef struct CK\_X9\_42\_DH2\_DERIVE\_PARAMS CK\_X9\_42\_DH2\_DERIVE\_PARAMS

### 20.166.2.181 CK\_X9\_42\_DH2\_DERIVE\_PARAMS\_PTR

typedef CK\_X9\_42\_DH2\_DERIVE\_PARAMS CK\_PTR CK\_X9\_42\_DH2\_DERIVE\_PARAMS\_PTR

# 20.166.2.182 CK\_X9\_42\_DH\_KDF\_TYPE

```
typedef CK_ULONG CK_X9_42_DH_KDF_TYPE
```

# 20.166.2.183 CK\_X9\_42\_DH\_KDF\_TYPE\_PTR

```
typedef CK_X9_42_DH_KDF_TYPE CK_PTR CK_X9_42_DH_KDF_TYPE_PTR
```

# 20.166.2.184 CK\_X9\_42\_MQV\_DERIVE\_PARAMS

```
typedef struct CK_X9_42_MQV_DERIVE_PARAMS CK_X9_42_MQV_DERIVE_PARAMS
```

# 20.166.2.185 CK\_X9\_42\_MQV\_DERIVE\_PARAMS\_PTR

```
typedef CK_X9_42_MQV_DERIVE_PARAMS CK_PTR CK_X9_42_MQV_DERIVE_PARAMS_PTR
```

# 20.166.2.186 event

```
typedef CK_NOTIFICATION event
```

#### 20.166.2.187 pApplication

```
typedef CK_NOTIFICATION CK_VOID_PTR pApplication
```

# 20.166.3 Function Documentation

# 20.166.3.1 CK\_CALLBACK\_FUNCTION() [1/5]

# 20.166.3.2 CK\_CALLBACK\_FUNCTION() [2/5]

# 20.166.3.3 CK\_CALLBACK\_FUNCTION() [3/5]

# 20.166.3.4 CK\_CALLBACK\_FUNCTION() [4/5]

# 20.166.3.5 CK\_CALLBACK\_FUNCTION() [5/5]

- 20.167 readme.md File Reference
- 20.168 README.md File Reference
- 20.169 README.md File Reference
- 20.170 README.md File Reference
- 20.171 README.md File Reference
- 20.172 README.md File Reference
- 20.173 README.md File Reference
- 20.174 README.md File Reference
- 20.175 README.md File Reference
- 20.176 README.md File Reference
- 20.177 README.md File Reference
- 20.178 secure\_boot.c File Reference

Provides required APIs to manage secure boot under various scenarios.

```
#include <string.h>
#include "secure_boot.h"
#include "io_protection_key.h"
#include "basic/atca_basic.h"
```

#### **Functions**

ATCA\_STATUS secure\_boot\_process (void)

Handles secure boot functionality through initialization, execution, and de-initialization.

ATCA\_STATUS bind\_host\_and\_secure\_element\_with\_io\_protection (uint16\_t slot)

Binds host MCU and Secure element with IO protection key.

# 20.178.1 Detailed Description

Provides required APIs to manage secure boot under various scenarios.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.178.2 Function Documentation

### 20.178.2.1 bind\_host\_and\_secure\_element\_with\_io\_protection()

```
ATCA_STATUS bind_host_and_secure_element_with_io_protection ( \label{eq:atca} \mbox{uint16\_t } slot \mbox{)}
```

Binds host MCU and Secure element with IO protection key.

#### **Parameters**

| in | slot | The slot number of IO protection Key. |  |
|----|------|---------------------------------------|--|
|----|------|---------------------------------------|--|

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.178.2.2 secure\_boot\_process()

```
ATCA_STATUS secure_boot_process ( void )
```

Handles secure boot functionality through initialization, execution, and de-initialization.

### Returns

ATCA SUCCESS on success, otherwise an error code.

# 20.179 secure boot.h File Reference

Provides required APIs to manage secure boot under various scenarios.

```
#include "atca_status.h"
#include "secure_boot_memory.h"
#include "atca_command.h"
#include "crypto/atca_crypto_sw_sha2.h"
```

#### **Data Structures**

- struct secure\_boot\_config\_bits
- struct secure\_boot\_parameters

#### **Macros**

- #define SECURE BOOT CONFIG DISABLE 0
- #define SECURE BOOT CONFIG FULL BOTH 1
- #define SECURE\_BOOT\_CONFIG\_FULL\_SIGN 2
- #define SECURE\_BOOT\_CONFIG\_FULL\_DIG 3
- #define SECURE BOOT CONFIGURATION SECURE BOOT CONFIG FULL DIG
- #define SECURE\_BOOT\_DIGEST\_ENCRYPT\_ENABLED true
- #define SECURE BOOT UPGRADE SUPPORT true

#### **Functions**

- ATCA STATUS secure boot process (void)
  - Handles secure boot functionality through initialization, execution, and de-initialization.
- ATCA\_STATUS bind\_host\_and\_secure\_element\_with\_io\_protection (uint16\_t slot)
   Binds host MCU and Secure element with IO protection key.
- ATCA\_STATUS host\_generate\_random\_number (uint8\_t \*rand)

# 20.179.1 Detailed Description

Provides required APIs to manage secure boot under various scenarios.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.179.2 Macro Definition Documentation

### 20.179.2.1 SECURE\_BOOT\_CONFIG\_DISABLE

#define SECURE\_BOOT\_CONFIG\_DISABLE 0

### 20.179.2.2 SECURE\_BOOT\_CONFIG\_FULL\_BOTH

#define SECURE\_BOOT\_CONFIG\_FULL\_BOTH 1

# 20.179.2.3 SECURE\_BOOT\_CONFIG\_FULL\_DIG

#define SECURE\_BOOT\_CONFIG\_FULL\_DIG 3

#### 20.179.2.4 SECURE\_BOOT\_CONFIG\_FULL\_SIGN

#define SECURE\_BOOT\_CONFIG\_FULL\_SIGN 2

# 20.179.2.5 SECURE\_BOOT\_CONFIGURATION

#define SECURE\_BOOT\_CONFIGURATION SECURE\_BOOT\_CONFIG\_FULL\_DIG

#### 20.179.2.6 SECURE\_BOOT\_DIGEST\_ENCRYPT\_ENABLED

#define SECURE\_BOOT\_DIGEST\_ENCRYPT\_ENABLED true

# 20.179.2.7 SECURE\_BOOT\_UPGRADE\_SUPPORT

#define SECURE\_BOOT\_UPGRADE\_SUPPORT true

# 20.179.3 Function Documentation

# 20.179.3.1 bind\_host\_and\_secure\_element\_with\_io\_protection()

```
ATCA_STATUS bind_host_and_secure_element_with_io_protection ( \label{eq:atca} \mbox{uint16\_t } slot \; )
```

Binds host MCU and Secure element with IO protection key.

#### **Parameters**

| in | slot | The slot number of IO protection Key. |
|----|------|---------------------------------------|
|----|------|---------------------------------------|

© 2020 Microchip Technology Inc CryptoAuthLib v3.2.3 1062

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

#### 20.179.3.2 host generate random number()

#### 20.179.3.3 secure\_boot\_process()

```
ATCA_STATUS secure_boot_process ( void )
```

Handles secure boot functionality through initialization, execution, and de-initialization.

#### Returns

ATCA\_SUCCESS on success, otherwise an error code.

# 20.180 secure\_boot\_memory.h File Reference

Provides interface to memory component for the secure boot.

```
#include "atca_status.h"
#include "atca_command.h"
```

#### **Data Structures**

struct memory\_parameters

# **Functions**

- ATCA\_STATUS secure\_boot\_init\_memory (memory\_parameters \*memory\_params)
- ATCA\_STATUS secure\_boot\_read\_memory (uint8\_t \*pu8\_data, uint32\_t \*pu32\_target\_length)
- ATCA\_STATUS secure\_boot\_write\_memory (uint8\_t \*pu8\_data, uint32\_t \*pu32\_target\_length)
- void secure\_boot\_deinit\_memory (memory\_parameters \*memory\_params)
- ATCA STATUS secure boot mark full copy completion (void)
- bool secure\_boot\_check\_full\_copy\_completion (void)

# 20.180.1 Detailed Description

Provides interface to memory component for the secure boot.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.180.2 Function Documentation

#### 20.180.2.1 secure\_boot\_check\_full\_copy\_completion()

# 20.180.2.2 secure\_boot\_deinit\_memory()

### 20.180.2.3 secure\_boot\_init\_memory()

```
ATCA_STATUS secure_boot_init_memory (

memory_parameters * memory_params )
```

# 20.180.2.4 secure\_boot\_mark\_full\_copy\_completion()

```
ATCA_STATUS secure_boot_mark_full_copy_completion ( void )
```

## 20.180.2.5 secure\_boot\_read\_memory()

#### 20.180.2.6 secure\_boot\_write\_memory()

# 20.181 sha1\_routines.c File Reference

Software implementation of the SHA1 algorithm.

```
#include "shal_routines.h"
#include <string.h>
#include "atca_compiler.h"
```

### **Functions**

```
• void CL_hashInit (CL_HashContext *ctx)
```

Initialize context for performing SHA1 hash in software.

void CL\_hashUpdate (CL\_HashContext \*ctx, const uint8\_t \*src, int nbytes)

Add arbitrary data to a SHA1 hash.

void CL\_hashFinal (CL\_HashContext \*ctx, uint8\_t \*dest)

Complete the SHA1 hash in software and return the digest.

void CL\_hash (uint8\_t \*msg, int msgBytes, uint8\_t \*dest)

Perform SHA1 hash of data in software.

• void shaEngine (uint32\_t \*buf, uint32\_t \*h)

# 20.181.1 Detailed Description

Software implementation of the SHA1 algorithm.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.181.2 Function Documentation

#### 20.181.2.1 CL\_hash()

Perform SHA1 hash of data in software.

#### **Parameters**

| in  | msg      | Data to be hashed                  |
|-----|----------|------------------------------------|
| in  | msgBytes | Data size in bytes                 |
| out | dest     | Digest is returned here (20 bytes) |

# 20.181.2.2 CL\_hashFinal()

Complete the SHA1 hash in software and return the digest.

#### **Parameters**

| in  | ctx  | Hash context                       |
|-----|------|------------------------------------|
| out | dest | Digest is returned here (20 bytes) |

# 20.181.2.3 CL\_hashInit()

Initialize context for performing SHA1 hash in software.

#### **Parameters**

| in | ctx | Hash context |
|----|-----|--------------|

# 20.181.2.4 CL\_hashUpdate()

Add arbitrary data to a SHA1 hash.

#### **Parameters**

| in | ctx | Hash context                 |
|----|-----|------------------------------|
| in | src | Data to be added to the hash |
|    |     |                              |

CryptoAuthLib v3.2.3

#### 20.181.2.5 shaEngine()

# 20.182 sha1 routines.h File Reference

Software implementation of the SHA1 algorithm.

```
#include <stdio.h>
#include <stdlib.h>
#include <stddef.h>
#include <stdint.h>
```

# **Data Structures**

• struct CL\_HashContext

### **Macros**

```
#define U8 uint8_t
#define U16 uint16_t
#define U32 uint32_t
#define memcpy_P memmove
#define strcpy_P strcpy
#define _WDRESET()
#define _NOP()
#define leftRotate(x, n) (x) = (((x) << (n)) | ((x) >> (32 - (n))))
```

### **Functions**

```
    void shaEngine (uint32_t *buf, uint32_t *h)
    void CL_hashInit (CL_HashContext *ctx)
        Initialize context for performing SHA1 hash in software.

    void CL_hashUpdate (CL_HashContext *ctx, const uint8_t *src, int nbytes)
        Add arbitrary data to a SHA1 hash.

    void CL_hashFinal (CL_HashContext *ctx, uint8_t *dest)
        Complete the SHA1 hash in software and return the digest.

    void CL_hash (uint8_t *msg, int msgBytes, uint8_t *dest)
        Perform SHA1 hash of data in software.
```

# 20.182.1 Detailed Description

Software implementation of the SHA1 algorithm.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.182.2 Macro Definition Documentation

#### 20.182.2.1 NOP

```
#define _NOP()
```

# 20.182.2.2 \_WDRESET

```
#define _WDRESET( )
```

#### 20.182.2.3 leftRotate

#### 20.182.2.4 memcpy\_P

```
#define memcpy_P memmove
```

# 20.182.2.5 strcpy\_P

```
#define strcpy_P strcpy
```

# 20.182.2.6 U16

```
#define U16 uint16_t
```

#### 20.182.2.7 U32

```
#define U32 uint32_t
```

#### 20.182.2.8 U8

```
#define U8 uint8_t
```

# 20.182.3 Function Documentation

### 20.182.3.1 CL\_hash()

Perform SHA1 hash of data in software.

#### **Parameters**

| in  | msg      | Data to be hashed                  |
|-----|----------|------------------------------------|
| in  | msgBytes | Data size in bytes                 |
| out | dest     | Digest is returned here (20 bytes) |

# 20.182.3.2 CL\_hashFinal()

Complete the SHA1 hash in software and return the digest.

#### **Parameters**

| in  | ctx  | Hash context                       |
|-----|------|------------------------------------|
| out | dest | Digest is returned here (20 bytes) |

#### 20.182.3.3 CL\_hashInit()

Initialize context for performing SHA1 hash in software.

#### **Parameters**

| in c | tx Hash | n context |
|------|---------|-----------|
|------|---------|-----------|

### 20.182.3.4 CL\_hashUpdate()

Add arbitrary data to a SHA1 hash.

#### **Parameters**

| in | ctx    | Hash context                 |
|----|--------|------------------------------|
| in | src    | Data to be added to the hash |
| in | nbytes | Data size in bytes           |

# 20.182.3.5 shaEngine()

# 20.183 sha2\_routines.c File Reference

Software implementation of the SHA256 algorithm.

```
#include <string.h>
#include "sha2_routines.h"
#include "atca_compiler.h"
```

#### **Macros**

#define rotate\_right(value, places) ((value >> places) | (value << (32 - places)))</li>

#### **Functions**

- void sw\_sha256\_init (sw\_sha256\_ctx \*ctx)
  - Intialize the software SHA256.
- void sw\_sha256\_update (sw\_sha256\_ctx \*ctx, const uint8\_t \*msg, uint32\_t msg\_size)
   updates the running hash with the next block of data, called iteratively for the entire stream of data to be hashed using the SHA256 software
- void sw\_sha256\_final (sw\_sha256\_ctx \*ctx, uint8\_t digest[(32)])
  - completes the final SHA256 calculation and returns the final digest/hash
- void sw\_sha256 (const uint8\_t \*message, unsigned int len, uint8\_t digest[(32)])

  single call convenience function which computes Hash of given data using SHA256 software

# 20.183.1 Detailed Description

Software implementation of the SHA256 algorithm.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.183.2 Macro Definition Documentation

#### 20.183.2.1 rotate\_right

```
#define rotate_right( value, \\ places ) \mbox{ ((value >> places) | (value << (32 - places)))} \label{eq:places}
```

### 20.183.3 Function Documentation

#### 20.183.3.1 sw\_sha256()

single call convenience function which computes Hash of given data using SHA256 software

#### **Parameters**

| in  | message | pointer to stream of data to hash |
|-----|---------|-----------------------------------|
| in  | len     | size of data stream to hash       |
| out | digest  | result                            |

# 20.183.3.2 sw\_sha256\_final()

completes the final SHA256 calculation and returns the final digest/hash

#### **Parameters**

| in  | ctx    | ptr to context data structure               |
|-----|--------|---------------------------------------------|
| out | digest | receives the computed digest of the SHA 256 |

# 20.183.3.3 sw\_sha256\_init()

```
void sw_sha256_init (
    sw_sha256_ctx * ctx )
```

Intialize the software SHA256.

# **Parameters**

|--|

# 20.183.3.4 sw\_sha256\_update()

updates the running hash with the next block of data, called iteratively for the entire stream of data to be hashed using the SHA256 software

#### **Parameters**

| in | ctx      | SHA256 hash context            |
|----|----------|--------------------------------|
| in | msg      | Raw blocks to be processed     |
| in | msg_size | The size of the message passed |

# 20.184 sha2\_routines.h File Reference

Software implementation of the SHA256 algorithm.

```
#include <stdint.h>
```

#### **Data Structures**

• struct sw sha256 ctx

#### **Macros**

- #define SHA256 DIGEST SIZE (32)
- #define SHA256\_BLOCK\_SIZE (64)

### **Functions**

- void sw\_sha256\_init (sw\_sha256\_ctx \*ctx)
   Intialize the software SHA256.
- void sw\_sha256\_update (sw\_sha256\_ctx \*ctx, const uint8\_t \*message, uint32\_t len)
   updates the running hash with the next block of data, called iteratively for the entire stream of data to be hashed using the SHA256 software
- void sw\_sha256\_final (sw\_sha256\_ctx \*ctx, uint8\_t digest[(32)])
   completes the final SHA256 calculation and returns the final digest/hash
- void sw\_sha256 (const uint8\_t \*message, unsigned int len, uint8\_t digest[(32)])

  single call convenience function which computes Hash of given data using SHA256 software

# 20.184.1 Detailed Description

Software implementation of the SHA256 algorithm.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.184.2 Macro Definition Documentation

#### 20.184.2.1 SHA256\_BLOCK\_SIZE

```
#define SHA256_BLOCK_SIZE (64)
```

# 20.184.2.2 SHA256\_DIGEST\_SIZE

```
#define SHA256_DIGEST_SIZE (32)
```

# 20.184.3 Function Documentation

# 20.184.3.1 sw\_sha256()

single call convenience function which computes Hash of given data using SHA256 software

#### **Parameters**

| in  | message | pointer to stream of data to hash |
|-----|---------|-----------------------------------|
| in  | len     | size of data stream to hash       |
| out | digest  | result                            |

# 20.184.3.2 sw\_sha256\_final()

completes the final SHA256 calculation and returns the final digest/hash

### **Parameters**

| in  | ctx    | ptr to context data structure               |
|-----|--------|---------------------------------------------|
| out | digest | receives the computed digest of the SHA 256 |

#### 20.184.3.3 sw\_sha256\_init()

```
void sw_sha256_init (
    sw_sha256_ctx * ctx )
```

Intialize the software SHA256.

#### **Parameters**

| in ctx SHA256 hash conte | ext |
|--------------------------|-----|
|--------------------------|-----|

### 20.184.3.4 sw\_sha256\_update()

updates the running hash with the next block of data, called iteratively for the entire stream of data to be hashed using the SHA256 software

#### **Parameters**

| in | ctx      | SHA256 hash context            |
|----|----------|--------------------------------|
| in | msg      | Raw blocks to be processed     |
| in | msg_size | The size of the message passed |

# 20.185 swi\_uart\_samd21\_asf.c File Reference

ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers.

```
#include <stdlib.h>
#include <stdio.h>
#include "swi_uart_samd21_asf.h"
#include "atca_helpers.h"
```

#### **Functions**

- ATCA\_STATUS swi\_uart\_init (ATCASWIMaster\_t \*instance)
  - Implementation of SWI UART init.
- ATCA\_STATUS swi\_uart\_deinit (ATCASWIMaster\_t \*instance)

Implementation of SWI UART deinit.

- void swi uart setbaud (ATCASWIMaster t \*instance, uint32 t baudrate)
  - implementation of SWI UART change baudrate.
- void swi\_uart\_mode (ATCASWIMaster\_t \*instance, uint8\_t mode)

implementation of SWI UART change mode.

void swi\_uart\_discover\_buses (int swi\_uart\_buses[], int max\_buses)

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS swi\_uart\_send\_byte (ATCASWIMaster\_t \*instance, uint8\_t data)

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

• ATCA\_STATUS swi\_uart\_receive\_byte (ATCASWIMaster\_t \*instance, uint8\_t \*data)

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

#### **Variables**

struct port\_config pin\_conf

#### 20.185.1 Detailed Description

ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers.

Prerequisite: add UART Polled support to application in Atmel Studio

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.186 swi uart samd21 asf.h File Reference

ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers.

```
#include <asf.h>
#include "cryptoauthlib.h"
```

# **Data Structures**

struct atcaSWImaster

this is the hal data for ATCA HAL for ASF SERCOM

#### **Macros**

- #define MAX\_SWI\_BUSES 6
- #define RECEIVE MODE 0
- #define TRANSMIT\_MODE 1
- #define RX DELAY 10
- #define TX DELAY 90
- #define DEBUG PIN 1 EXT2 PIN 5
- #define DEBUG\_PIN\_2 EXT2\_PIN\_6

# **Typedefs**

typedef struct atcaSWImaster ATCASWIMaster\_t
 this is the hal\_data for ATCA HAL for ASF SERCOM

#### **Functions**

ATCA\_STATUS swi\_uart\_init (ATCASWIMaster\_t \*instance)

Implementation of SWI UART init.

ATCA\_STATUS swi\_uart\_deinit (ATCASWIMaster\_t \*instance)

Implementation of SWI UART deinit.

void swi uart setbaud (ATCASWIMaster t \*instance, uint32 t baudrate)

implementation of SWI UART change baudrate.

void swi\_uart\_mode (ATCASWIMaster\_t \*instance, uint8\_t mode)

implementation of SWI UART change mode.

void swi\_uart\_discover\_buses (int swi\_uart\_buses[], int max\_buses)

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS swi\_uart\_send\_byte (ATCASWIMaster\_t \*instance, uint8\_t data)

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

• ATCA\_STATUS swi\_uart\_receive\_byte (ATCASWIMaster\_t \*instance, uint8\_t \*data)

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

### 20.186.1 Detailed Description

ATXMEGA's ATCA Hardware abstraction layer for SWI interface over UART drivers.

Prerequisite: add UART Polled support to application in Atmel Studio

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.187 swi uart start.c File Reference

```
#include <stdlib.h>
#include <stdio.h>
#include <peripheral_clk_config.h>
#include "swi_uart_start.h"
#include "atca_helpers.h"
```

#### **Macros**

• #define USART\_BAUD\_RATE(baud, sercom\_freq) (65536 - ((65536 \* 16.0F \* baud) / sercom\_freq))

#### **Functions**

ATCA\_STATUS swi\_uart\_init (ATCASWIMaster\_t \*instance)

Implementation of SWI UART init.

ATCA STATUS swi uart deinit (ATCASWIMaster t \*instance)

Implementation of SWI UART deinit.

void swi uart setbaud (ATCASWIMaster t \*instance, uint32 t baudrate)

implementation of SWI UART change baudrate.

void swi uart mode (ATCASWIMaster t \*instance, uint8 t mode)

implementation of SWI UART change mode.

• void swi uart discover buses (int swi uart buses[], int max buses)

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

• ATCA\_STATUS swi\_uart\_send\_byte (ATCASWIMaster\_t \*instance, uint8\_t data)

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

ATCA\_STATUS swi\_uart\_receive\_byte (ATCASWIMaster\_t \*instance, uint8\_t \*data)

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

# 20.187.1 Detailed Description

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.187.2 Macro Definition Documentation

#### 20.187.2.1 USART BAUD RATE

# 20.188 swi uart start.h File Reference

```
#include <stdlib.h>
#include "atmel_start.h"
#include "cryptoauthlib.h"
```

#### **Data Structures**

• struct atcaSWImaster

this is the hal\_data for ATCA HAL for ASF SERCOM

### **Macros**

- #define MAX SWI BUSES 6
- #define RECEIVE MODE 0
- #define TRANSMIT MODE 1
- #define RX DELAY 10
- #define TX\_DELAY 93

# **Typedefs**

typedef struct atcaSWImaster ATCASWIMaster\_t

this is the hal\_data for ATCA HAL for ASF SERCOM

### **Functions**

ATCA\_STATUS swi\_uart\_init (ATCASWIMaster\_t \*instance)

Implementation of SWI UART init.

ATCA\_STATUS swi\_uart\_deinit (ATCASWIMaster\_t \*instance)

Implementation of SWI UART deinit.

• void swi\_uart\_setbaud (ATCASWIMaster\_t \*instance, uint32\_t baudrate)

implementation of SWI UART change baudrate.

void swi\_uart\_mode (ATCASWIMaster\_t \*instance, uint8\_t mode)

implementation of SWI UART change mode.

void swi uart discover buses (int swi uart buses[], int max buses)

discover UART buses available for this hardware this maintains a list of logical to physical bus mappings freeing the application of the a-priori knowledge

ATCA\_STATUS swi\_uart\_send\_byte (ATCASWIMaster\_t \*instance, uint8\_t data)

HAL implementation of SWI UART send byte over ASF. This function send one byte over UART.

• ATCA\_STATUS swi\_uart\_receive\_byte (ATCASWIMaster\_t \*instance, uint8\_t \*data)

HAL implementation of SWI UART receive bytes over ASF. This function receive one byte over UART.

#### 20.188.1 Detailed Description

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.189 symmetric\_authentication.c File Reference

Contains API for performing the symmetric Authentication between the Host and the device.

```
#include "cryptoauthlib.h"
#include "host/atca_host.h"
#include "symmetric_authentication.h"
```

#### **Functions**

ATCA\_STATUS symmetric\_authenticate (uint8\_t slot, const uint8\_t \*master\_key, const uint8\_t \*rand\_

 number)

Function which does the authentication between the host and device.

# 20.189.1 Detailed Description

Contains API for performing the symmetric Authentication between the Host and the device.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.189.2 Function Documentation

#### 20.189.2.1 symmetric\_authenticate()

Function which does the authentication between the host and device.

### Parameters

|   | in | slot        | The slot number used for the symmetric authentication.     |
|---|----|-------------|------------------------------------------------------------|
| Ī | in | master_key  | The master key used for the calculating the symmetric key. |
| Ī | in | rand_number | The 20 byte rand_number from the host.                     |

#### Returns

ATCA SUCCESS on successful authentication, otherwise an error code.

# 20.190 symmetric\_authentication.h File Reference

Contains API for performing the symmetric Authentication between the Host and the device.

```
#include "cryptoauthlib.h"
```

# **Functions**

ATCA\_STATUS symmetric\_authenticate (uint8\_t slot, const uint8\_t \*master\_key, const uint8\_t \*rand\_← number)

Function which does the authentication between the host and device.

# 20.190.1 Detailed Description

Contains API for performing the symmetric Authentication between the Host and the device.

# Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.190.2 Function Documentation

#### 20.190.2.1 symmetric\_authenticate()

Function which does the authentication between the host and device.

#### **Parameters**

| in | slot        | The slot number used for the symmetric authentication.     |
|----|-------------|------------------------------------------------------------|
| in | master_key  | The master key used for the calculating the symmetric key. |
| in | rand_number | The 20 byte rand_number from the host.                     |

#### Returns

ATCA\_SUCCESS on successful authentication, otherwise an error code.

# 20.191 tflxtls\_cert\_def\_4\_device.c File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_1_signer.h"
```

### **Variables**

- const uint8 t g tflxtls cert template 4 device [500]
- const atcacert\_cert\_element\_t g\_tflxtls\_cert\_elements\_4\_device []
- const atcacert\_def\_t g\_tflxtls\_cert\_def\_4\_device

# 20.191.1 Detailed Description

TNG TLS device certificate definition.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.191.2 Variable Documentation

### 20.191.2.1 g\_tflxtls\_cert\_elements\_4\_device

```
const atcacert_cert_element_t g_tflxtls_cert_elements_4_device[]
```

### 20.191.2.2 g\_tflxtls\_cert\_template\_4\_device

```
const uint8_t g_tflxtls_cert_template_4_device[500]
```

# 20.192 tflxtls\_cert\_def\_4\_device.h File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert_def.h"
```

#### **Variables**

· const atcacert\_def\_t g\_tflxtls\_cert\_def\_4\_device

### 20.192.1 Detailed Description

TNG TLS device certificate definition.

### Copyright

### 20.193 tng atca.c File Reference

TNG Helper Functions.

```
#include <string.h>
#include "cryptoauthlib.h"
#include "tng_atca.h"
#include "tnglora_cert_def_2_device.h"
#include "tnglora_cert_def_4_device.h"
#include "tngtls_cert_def_2_device.h"
#include "tngtls_cert_def_3_device.h"
#include "tflxtls_cert_def_4_device.h"
#include "atcacert/atcacert_def.h"
```

#### **Data Structures**

· struct tng\_cert\_map\_element

#### **Functions**

```
    const atcacert_def_t * tng_map_get_device_cert_def (int index)
```

Helper function to iterate through all trust cert definitions.

ATCA\_STATUS tng\_get\_device\_cert\_def (const atcacert\_def\_t \*\*cert\_def)

Get the TNG device certificate definition.

ATCA\_STATUS tng\_get\_device\_pubkey (uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from the primary device public key.

### 20.193.1 Detailed Description

TNG Helper Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.194 tng\_atca.h File Reference

TNG Helper Functions.

```
#include "atca_basic.h"
#include "atcacert/atcacert_def.h"
```

#### **Functions**

const atcacert\_def\_t \* tng\_map\_get\_device\_cert\_def (int index)

Helper function to iterate through all trust cert definitions.

ATCA STATUS tng get device cert def (const atcacert def t \*\*cert def)

Get the TNG device certificate definition.

ATCA\_STATUS tng\_get\_device\_pubkey (uint8\_t \*public\_key)

Uses GenKey command to calculate the public key from the primary device public key.

### 20.194.1 Detailed Description

TNG Helper Functions.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.195 tng atcacert client.c File Reference

Client side certificate I/O functions for TNG devices.

```
#include "tng_atca.h"
#include "atcacert/atcacert_client.h"
#include "tng_atcacert_client.h"
#include "tngtls_cert_def_1_signer.h"
#include "tng_root_cert.h"
```

#### **Functions**

int tng\_atcacert\_max\_device\_cert\_size (size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a TNG device certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

• int tng\_atcacert\_read\_device\_cert (uint8\_t \*cert, size\_t \*cert\_size, const uint8\_t \*signer\_cert)

Reads the device certificate for a TNG device.

• int tng\_atcacert\_device\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the device public key.

int tng\_atcacert\_max\_signer\_cert\_size (size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a TNG signer certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

• int tng\_atcacert\_read\_signer\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Reads the signer certificate for a TNG device.

int tng\_atcacert\_signer\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the signer public key.

• int tng atcacert root cert size (size t \*cert size)

Get the size of the TNG root cert.

• int tng\_atcacert\_root\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Get the TNG root cert.

int tng\_atcacert\_root\_public\_key (uint8\_t \*public\_key)

Gets the root public key.

# 20.195.1 Detailed Description

Client side certificate I/O functions for TNG devices.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.195.2 Function Documentation

### 20.195.2.1 tng\_atcacert\_device\_public\_key()

Reads the device public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve.             |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------|
| in  | cert       | If supplied, the device public key is used from this certificate. If set to NULL, the device public key is read from the device. |

### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 20.195.2.2 tng\_atcacert\_max\_signer\_cert\_size()

Return the maximum possible certificate size in bytes for a TNG signer certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

#### **Parameters**

| out max_cert_size Maximum certificate size will be returned here in bytes | <b>3</b> . |
|---------------------------------------------------------------------------|------------|
|---------------------------------------------------------------------------|------------|

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 20.195.2.3 tng\_atcacert\_read\_device\_cert()

Reads the device certificate for a TNG device.

#### **Parameters**

| out    | cert        | Buffer to received the certificate (DER format).                                                                                 |
|--------|-------------|----------------------------------------------------------------------------------------------------------------------------------|
| in,out | cert_size   | As input, the size of the cert buffer in bytes. As output, the size of the certificate returned in cert in bytes.                |
| in     | signer_cert | If supplied, the signer public key is used from this certificate. If set to NULL, the signer public key is read from the device. |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 20.195.2.4 tng\_atcacert\_read\_signer\_cert()

```
int tng_atcacert_read_signer_cert (
          uint8_t * cert,
          size_t * cert_size )
```

Reads the signer certificate for a TNG device.

#### **Parameters**

| out    | cert      | Buffer to received the certificate (DER format).                                       |
|--------|-----------|----------------------------------------------------------------------------------------|
| in,out | cert_size | As input, the size of the cert buffer in bytes. As output, the size of the certificate |
|        |           | returned in cert in bytes.                                                             |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 20.195.2.5 tng\_atcacert\_root\_cert()

```
int tng_atcacert_root_cert (
          uint8_t * cert,
          size_t * cert_size )
```

Get the TNG root cert.

#### **Parameters**

| out    | cert      | Buffer to received the certificate (DER format).                                       |  |
|--------|-----------|----------------------------------------------------------------------------------------|--|
| in,out | cert_size | As input, the size of the cert buffer in bytes. As output, the size of the certificate |  |
|        |           | returned in cert in bytes.                                                             |  |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 20.195.2.6 tng\_atcacert\_root\_cert\_size()

Get the size of the TNG root cert.

### Parameters

| C | ut | cert_size | Certificate size will be returned here in bytes. |
|---|----|-----------|--------------------------------------------------|
|---|----|-----------|--------------------------------------------------|

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

### 20.195.2.7 tng\_atcacert\_root\_public\_key()

Gets the root public key.

### **Parameters**

| 0 | ut | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian |  |
|---|----|------------|-------------------------------------------------------------------------------------|--|
|   |    |            | format. 64 bytes for P256 curve.                                                    |  |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

#### 20.195.2.8 tng\_atcacert\_signer\_public\_key()

Reads the signer public key.

#### **Parameters**

| out | public_key | Public key will be returned here. Format will be the X and Y integers in big-endian format. 64 bytes for P256 curve.             |
|-----|------------|----------------------------------------------------------------------------------------------------------------------------------|
| in  | cert       | If supplied, the signer public key is used from this certificate. If set to NULL, the signer public key is read from the device. |

#### Returns

ATCACERT\_E\_SUCCESS on success, otherwise an error code.

# 20.196 tng\_atcacert\_client.h File Reference

Client side certificate I/O functions for TNG devices.

```
#include <stdint.h>
#include "atcacert/atcacert.h"
```

### **Functions**

• int tng\_atcacert\_max\_device\_cert\_size (size\_t \*max\_cert\_size)

Return the maximum possible certificate size in bytes for a TNG device certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.

- int tng\_atcacert\_read\_device\_cert (uint8\_t \*cert, size\_t \*cert\_size, const uint8\_t \*signer\_cert)
  - Reads the device certificate for a TNG device.
- int tng\_atcacert\_device\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the device public key.

- int tng\_atcacert\_max\_signer\_cert\_size (size\_t \*max\_cert\_size)
  - Return the maximum possible certificate size in bytes for a TNG signer certificate. Certificate can be variable size, so this gives an appropriate buffer size when reading the certificate.
- int tng\_atcacert\_read\_signer\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Reads the signer certificate for a TNG device.

• int tng\_atcacert\_signer\_public\_key (uint8\_t \*public\_key, uint8\_t \*cert)

Reads the signer public key.

int tng\_atcacert\_root\_cert\_size (size\_t \*cert\_size)

Get the size of the TNG root cert.

• int tng\_atcacert\_root\_cert (uint8\_t \*cert, size\_t \*cert\_size)

Get the TNG root cert.

int tng\_atcacert\_root\_public\_key (uint8\_t \*public\_key)

Gets the root public key.

### 20.196.1 Detailed Description

Client side certificate I/O functions for TNG devices.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.197 tng\_root\_cert.c File Reference

TNG root certificate (DER)

```
#include <stdint.h>
#include <stddef.h>
```

#### **Variables**

- const uint8\_t g\_cryptoauth\_root\_ca\_002\_cert [501]
- const size\_t g\_cryptoauth\_root\_ca\_002\_cert\_size = sizeof(g\_cryptoauth\_root\_ca\_002\_cert)

### 20.197.1 Detailed Description

TNG root certificate (DER)

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.197.2 Variable Documentation

#### 20.197.2.1 g\_cryptoauth\_root\_ca\_002\_cert

```
const uint8_t g_cryptoauth_root_ca_002_cert[501]
```

#### 20.197.2.2 g\_cryptoauth\_root\_ca\_002\_cert\_size

```
const size_t g_cryptoauth_root_ca_002_cert_size = sizeof(g_cryptoauth_root_ca_002_cert)
```

# 20.198 tng\_root\_cert.h File Reference

TNG root certificate (DER)

```
#include <stdint.h>
```

- #define CRYPTOAUTH\_ROOT\_CA\_002\_PUBLIC\_KEY\_OFFSET 266
- const uint8\_t g\_cryptoauth\_root\_ca\_002\_cert []
- · const size t g cryptoauth root ca 002 cert size

### 20.198.1 Detailed Description

TNG root certificate (DER)

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.199 tnglora\_cert\_def\_1\_signer.c File Reference

TNG LORA signer certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_1_signer.h"
```

#### **Variables**

- const uint8\_t g\_tngtls\_cert\_template\_1\_signer []
- const atcacert\_cert\_element\_t g\_tngtls\_cert\_elements\_1\_signer []
- const atcacert\_def\_t g\_tnglora\_cert\_def\_1\_signer

# 20.199.1 Detailed Description

TNG LORA signer certificate definition.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.199.2 Variable Documentation

### 20.199.2.1 g\_tngtls\_cert\_elements\_1\_signer

```
const atcacert_cert_element_t g_tngtls_cert_elements_1_signer[]
```

### 20.199.2.2 g\_tngtls\_cert\_template\_1\_signer

```
const uint8_t g_tngtls_cert_template_1_signer[]
```

# 20.200 tnglora\_cert\_def\_1\_signer.h File Reference

TNG LORA signer certificate definition.

```
#include "atcacert/atcacert_def.h"
```

### **Variables**

• const atcacert\_def\_t g\_tnglora\_cert\_def\_1\_signer

### 20.200.1 Detailed Description

TNG LORA signer certificate definition.

### Copyright

# 20.201 tnglora cert def 2 device.c File Reference

TNG LORA device certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_2_device.h"
#include "tnglora_cert_def_1_signer.h"
```

#### **Variables**

- const uint8\_t g\_tngtls\_cert\_template\_2\_device []
- const atcacert\_cert\_element\_t g\_tngtls\_cert\_elements\_2\_device []
- const atcacert\_def\_t g\_tnglora\_cert\_def\_2\_device

### 20.201.1 Detailed Description

TNG LORA device certificate definition.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.201.2 Variable Documentation

### 20.201.2.1 g\_tngtls\_cert\_elements\_2\_device

```
const atcacert_cert_element_t g_tngtls_cert_elements_2_device[]
```

### 20.201.2.2 g\_tngtls\_cert\_template\_2\_device

```
const uint8_t g_tngtls_cert_template_2_device[]
```

# 20.202 tnglora\_cert\_def\_2\_device.h File Reference

TNG LORA device certificate definition.

```
#include "atcacert/atcacert_def.h"
```

#### **Variables**

• const atcacert\_def\_t g\_tnglora\_cert\_def\_2\_device

### 20.202.1 Detailed Description

TNG LORA device certificate definition.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.203 tnglora\_cert\_def\_4\_device.c File Reference

TNG LORA device certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tnglora_cert_def_4_device.h"
#include "tnglora_cert_def_1_signer.h"
```

### **Variables**

- const uint8\_t g\_tnglora\_cert\_template\_4\_device [552]
- const atcacert\_cert\_element\_t g\_tnglora\_cert\_elements\_4\_device []
- const atcacert\_def\_t g\_tnglora\_cert\_def\_4\_device

### 20.203.1 Detailed Description

TNG LORA device certificate definition.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

### 20.203.2 Variable Documentation

#### 20.203.2.1 g\_tnglora\_cert\_def\_4\_device

```
const atcacert_def_t g_tnglora_cert_def_4_device
```

#### 20.203.2.2 g\_tnglora\_cert\_elements\_4\_device

```
const atcacert_cert_element_t g_tnglora_cert_elements_4_device[]
```

### 20.203.2.3 g\_tnglora\_cert\_template\_4\_device

```
const uint8_t g_tnglora_cert_template_4_device[552]
```

# 20.204 tnglora\_cert\_def\_4\_device.h File Reference

TNG LORA device certificate definition.

```
#include "atcacert/atcacert_def.h"
```

- #define TNGLORA CERT TEMPLATE 4 DEVICE SIZE 552
- const atcacert\_def\_t g\_tnglora\_cert\_def\_4\_device

### 20.204.1 Detailed Description

TNG LORA device certificate definition.

### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.205 tngtls\_cert\_def\_1\_signer.c File Reference

TNG TLS signer certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_1_signer.h"
```

#### **Variables**

- const uint8\_t g\_tngtls\_cert\_template\_1\_signer [520]
- const atcacert\_cert\_element\_t g\_tngtls\_cert\_elements\_1\_signer []
- const atcacert\_def\_t g\_tngtls\_cert\_def\_1\_signer

### 20.205.1 Detailed Description

TNG TLS signer certificate definition.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.205.2 Variable Documentation

```
20.205.2.1 g_tngtls_cert_def_1_signer
```

```
const atcacert_def_t g_tngtls_cert_def_1_signer
```

### 20.205.2.2 g\_tngtls\_cert\_elements\_1\_signer

```
const atcacert_cert_element_t g_tngtls_cert_elements_1_signer[]
```

#### Initial value:

#### 20.205.2.3 g\_tngtls\_cert\_template\_1\_signer

```
const uint8_t g_tngtls_cert_template_1_signer[520]
```

# 20.206 tngtls\_cert\_def\_1\_signer.h File Reference

TNG TLS signer certificate definition.

```
#include "atcacert/atcacert_def.h"
```

- #define TNGTLS\_CERT\_TEMPLATE\_1\_SIGNER\_SIZE 520
- ATCA\_DLL const atcacert\_def\_t g\_tngtls\_cert\_def\_1\_signer

### 20.206.1 Detailed Description

TNG TLS signer certificate definition.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.207 tngtls\_cert\_def\_2\_device.c File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_2_device.h"
#include "tngtls_cert_def_1_signer.h"
```

#### **Variables**

- const uint8\_t g\_tngtls\_cert\_template\_2\_device [505]
- const atcacert\_cert\_element\_t g\_tngtls\_cert\_elements\_2\_device [2]
- const atcacert\_def\_t g\_tngtls\_cert\_def\_2\_device

### 20.207.1 Detailed Description

TNG TLS device certificate definition.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

#### 20.207.2 Variable Documentation

```
20.207.2.1 g_tngtls_cert_def_2_device
```

```
const atcacert_def_t g_tngtls_cert_def_2_device
```

#### 20.207.2.2 g\_tngtls\_cert\_elements\_2\_device

```
const atcacert_cert_element_t g_tngtls_cert_elements_2_device[2]
```

#### 20.207.2.3 g\_tngtls\_cert\_template\_2\_device

```
const uint8_t g_tngtls_cert_template_2_device[505]
```

# 20.208 tngtls\_cert\_def\_2\_device.h File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert def.h"
```

- #define TNGTLS CERT TEMPLATE 2 DEVICE SIZE 505
- #define TNGTLS\_CERT\_ELEMENTS\_2\_DEVICE\_COUNT 2
- const atcacert\_def\_t g\_tngtls\_cert\_def\_2\_device

### 20.208.1 Detailed Description

TNG TLS device certificate definition.

#### Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.209 tngtls cert def 3 device.c File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert_def.h"
#include "tngtls_cert_def_3_device.h"
#include "tngtls_cert_def_1_signer.h"
```

#### **Variables**

- const uint8\_t g\_tngtls\_cert\_template\_3\_device [546]
- const atcacert cert element t g tngtls cert elements 3 device []
- const atcacert\_def\_t g\_tngtls\_cert\_def\_3\_device

### 20.209.1 Detailed Description

TNG TLS device certificate definition.

### Copyright

#### 20.209.2 Variable Documentation

#### 20.209.2.1 g\_tngtls\_cert\_def\_3\_device

```
const atcacert_def_t g_tngtls_cert_def_3_device
```

#### 20.209.2.2 g tngtls cert elements 3 device

```
const atcacert_cert_element_t g_tngtls_cert_elements_3_device[]
```

#### 20.209.2.3 g tngtls cert template 3 device

```
const uint8_t g_tngtls_cert_template_3_device[546]
```

# 20.210 tngtls\_cert\_def\_3\_device.h File Reference

TNG TLS device certificate definition.

```
#include "atcacert/atcacert_def.h"
```

- #define TNGTLS CERT TEMPLATE 3 DEVICE SIZE 546
- const atcacert\_def\_t g\_tngtls\_cert\_def\_3\_device

#### 20.210.1 Detailed Description

TNG TLS device certificate definition.

Copyright

(c) 2015-2020 Microchip Technology Inc. and its subsidiaries.

# 20.211 trust\_pkcs11\_config.c File Reference

#### PKCS11 Trust Platform Configuration.

```
#include "cryptoauthlib.h"
#include "pkcs11_config.h"
#include "pkcs11/pkcs11_object.h"
#include "pkcs11/pkcs11_slot.h"
```

### 20.211.1 Detailed Description

PKCS11 Trust Platform Configuration.

Copyright

# Index

| _NOP                                  | RevNum, 387                                     |
|---------------------------------------|-------------------------------------------------|
| sha1_routines.h, 1068                 | SecureBoot, 387                                 |
| _WDRESET                              | SlotConfig, 387                                 |
| sha1_routines.h, 1068                 | SlotLocked, 388                                 |
| PASTE                                 | SN03, 388                                       |
| pkcs11.h, 890                         | SN47, 388                                       |
| _atcab_exit                           | SN8, 388                                        |
| Basic Crypto API methods (atcab_), 60 | UseLock, 388                                    |
| _atecc508a_config, 381                | UserExtra, 388                                  |
| ChipMode, 381                         | UserExtraAdd, 388                               |
| Counter0, 382                         | VolatileKeyPermission, 388                      |
| Counter1, 382                         | X509format, 389                                 |
| I2C_Address, 382                      | _atsha204a_config, 389                          |
| I2C_Enable, 382                       | ChipMode, 389                                   |
| KeyConfig, 382                        | Counter, 389                                    |
| LastKeyUse, 382                       | I2C_Address, 390                                |
| LockConfig, 382                       | I2C_Enable, 390                                 |
| LockValue, 382                        | LastKeyUse, 390                                 |
| OTPmode, 383                          | LockConfig, 390                                 |
| Reserved0, 383                        | LockValue, 390                                  |
| Reserved1, 383                        | OTPmode, 390                                    |
| Reserved2, 383                        | Reserved0, 390                                  |
| RevNum, 383                           | Reserved1, 390                                  |
| RFU, 383                              | Reserved2, 391                                  |
| Selector, 383                         | RevNum, 391                                     |
| SlotConfig, 383                       | Selector, 391                                   |
| SlotLocked, 384                       | SlotConfig, 391                                 |
| SN03, 384                             | SN03, 391                                       |
| SN47, 384                             | SN47, 391                                       |
| SN8, 384                              | SN8, 391                                        |
| UserExtra, 384                        | UserExtra, 391                                  |
| X509format, 384                       | _calib_exit                                     |
| _atecc608_config, 384                 | Basic Crypto API methods for CryptoAuth Devices |
| AES_Enable, 385                       | (calib_), 206                                   |
| ChipMode, 385                         | _gDevice                                        |
| ChipOptions, 385                      | atca_basic.c, 557                               |
| Counter0, 386                         | Basic Crypto API methods (atcab_), 120          |
| Counter1, 386                         | _pcks11_mech_table_e, 392                       |
| CountMatch, 386                       | info, 392                                       |
| I2C_Address, 386                      | type, 392                                       |
| I2C_Enable, 386                       | _pkcs11_attrib_model, 392                       |
| KdflvLoc, 386                         | func, 392                                       |
| KdflvStr, 386                         | type, 392                                       |
| KeyConfig, 386                        | _pkcs11_lib_ctx, 393                            |
| LockConfig, 387                       | config_path, 393                                |
| LockValue, 387                        | create_mutex, 393                               |
| Reserved1, 387                        | destroy_mutex, 393                              |
| Reserved2, 387                        | initialized, 393                                |
| Reserved3, 387                        | lock_mutex, 394                                 |
|                                       |                                                 |

| mutex, 394                  | calib_command.h, 711                          |
|-----------------------------|-----------------------------------------------|
| slot_cnt, 394               | AES_Enable                                    |
| slots, 394                  | _atecc608_config, 385                         |
| unlock_mutex, 394           | AES_INPUT_IDX                                 |
| _pkcs11_object, 394         | calib command.h, 711                          |
| attributes, 395             | AES_KEYID_IDX                                 |
| class_id, 395               | calib_command.h, 711                          |
| class_type, 395             | AES_MODE_DECRYPT                              |
| config, 395                 | calib_command.h, 711                          |
| count, 395                  |                                               |
|                             | AES_MODE_ENCRYPT                              |
| data, 395                   | calib_command.h, 711                          |
| flags, 396                  | AES_MODE_GFM                                  |
| handle_info, 396            | calib_command.h, 712                          |
| name, 396                   | AES_MODE_IDX                                  |
| size, 396                   | calib_command.h, 712                          |
| slot, 396                   | AES_MODE_KEY_BLOCK_MASK                       |
| _pkcs11_object_cache_t, 396 | calib_command.h, 712                          |
| handle, 397                 | AES_MODE_KEY_BLOCK_POS                        |
| object, 397                 | calib_command.h, 712                          |
| _pkcs11_session_ctx, 397    | AES_MODE_MASK                                 |
| active_object, 397          | calib command.h, 712                          |
| attrib_count, 398           | <del>-</del>                                  |
| attrib_list, 398            | AES_MODE_OP_MASK                              |
| error, 398                  | calib_command.h, 712                          |
| handle, 398                 | AES_RSP_SIZE                                  |
|                             | calib_command.h, 713                          |
| initialized, 398            | ANY                                           |
| logged_in, 398              | license.txt, 876                              |
| object_count, 398           | api_206a.c, 537                               |
| object_index, 398           | sha206a_authenticate, 538                     |
| read_key, 399               | sha206a_check_dk_useflag_validity, 538        |
| slot, 399                   | sha206a_check_pk_useflag_validity, 539        |
| state, 399                  | sha206a_diversify_parent_key, 539             |
| _pkcs11_slot_ctx, 399       | sha206a_generate_challenge_response_pair, 539 |
| cfg_zone, 400               | sha206a_generate_derive_key, 540              |
| device_ctx, 400             |                                               |
| flags, 400                  | sha206a_get_data_store_lock_status, 540       |
| initialized, 400            | sha206a_get_dk_update_count, 541              |
| interface_config, 400       | sha206a_get_dk_useflag_count, 541             |
| label, 400                  | sha206a_get_pk_useflag_count, 541             |
| session, 400                | sha206a_read_data_store, 542                  |
| slot_id, 400                | sha206a_verify_device_consumption, 542        |
| so_pin_handle, 401          | sha206a_write_data_store, 543                 |
| user pin handle, 401        | api_206a.h, 543                               |
| <b>—</b> —                  | ATCA_SHA206A_DKEY_CONSUMPTION_MASK            |
| _reserved                   | 544                                           |
| ATCAPacket, 458             | ATCA SHA206A PKEY CONSUMPTION MASK,           |
| aad size                    | 544                                           |
| <del>_</del>                | ATCA SHA206A SYMMETRIC KEY ID SLOT,           |
| atca_aes_gcm_ctx, 405       | 545                                           |
| ACK_CHECK_DIS               | ATCA_SHA206A_ZONE_WRITE_LOCK, 545             |
| hal_esp32_i2c.c, 829        |                                               |
| ACK_CHECK_EN                | sha206a_authenticate, 545                     |
| hal_esp32_i2c.c, 829        | sha206a_check_dk_useflag_validity, 546        |
| ACK_VAL                     | sha206a_check_pk_useflag_validity, 546        |
| hal_esp32_i2c.c, 830        | SHA206A_DATA_STORE0, 545                      |
| active_object               | SHA206A_DATA_STORE1, 545                      |
| _pkcs11_session_ctx, 397    | SHA206A_DATA_STORE2, 545                      |
| AES_COUNT                   | sha206a_diversify_parent_key, 546             |
| calib_command.h, 711        | sha206a_generate_challenge_response_pair, 547 |
| AES_DATA_SIZE               | sha206a_generate_derive_key, 547              |

| sha206a_get_data_store_lock_status, 548            | key_id, 406                            |
|----------------------------------------------------|----------------------------------------|
| sha206a_get_dk_update_count, 548                   | partial_aad, 407                       |
| sha206a_get_dk_useflag_count, 548                  | partial_aad_size, 407                  |
| sha206a_get_pk_useflag_count, 549                  | y, 407                                 |
| sha206a_read_data_store, 549                       | atca_aes_gcm_ctx_t                     |
| sha206a_verify_device_consumption, 550             | Basic Crypto API methods (atcab_), 59  |
| sha206a_write_data_store, 550                      | ATCA_AES_GCM_IV_STD_LENGTH             |
| app_digest                                         | Basic Crypto API methods (atcab_), 59  |
| secure_boot_parameters, 533                        | ATCA_AES_GFM_SIZE                      |
| atAES                                              | calib_command.h, 713                   |
| calib_command.c, 681                               | ATCA_AES_KEY_TYPE                      |
| calib_command.h, 782                               | calib_command.h, 714                   |
| ATCA_ADDRESS_MASK                                  | ATCA_ALLOC_FAILURE                     |
| calib_command.h, 713                               | atca_status.h, 640                     |
| ATCA_ADDRESS_MASK_CONFIG                           | ATCA_ASSERT_FAILURE                    |
| calib_command.h, 713                               | atca_status.h, 639                     |
| ATCA_ADDRESS_MASK_OTP                              | ATCA_ATECC608_SUPPORT                  |
| calib_command.h, 713                               | cryptoauthlib.h, 818                   |
| ATCA_AES                                           | ATCA B283 KEY TYPE                     |
| calib_command.h, 713                               | calib_command.h, 714                   |
| ATCA_AES128_BLOCK_SIZE                             | ATCA_BAD_OPCODE                        |
| cryptoauthlib.h, 817                               | atca status.h, 639                     |
| ATCA_AES128_KEY_SIZE                               | ATCA BAD PARAM                         |
| cryptoauthlib.h, 817                               | atca status.h, 639                     |
| atca_aes_cbc_ctx, 401                              | atca_basic.c, 551                      |
| ciphertext, 401                                    | _gDevice, 557                          |
| device, 401                                        | atca_version, 557                      |
| key_block, 402                                     | atca_basic.h, 557                      |
| key_id, 402                                        | atca_basic_aes_gcm_version             |
| atca_aes_cbc_ctx_t                                 | Basic Crypto API methods (atcab_), 120 |
| atca_crypto_hw_aes.h, 570                          | Basic Crypto API methods (areas        |
| atca_aes_cmac_ctx, 402                             | (calib_), 250                          |
| block, 402                                         | ATCA_BLOCK_SIZE                        |
| block_size, 402                                    | calib_command.h, 714                   |
| cbc ctx, 403                                       | atca_bool.h, 565                       |
| atca_aes_cmac_ctx_t                                | ATCA_CA_SUPPORT                        |
|                                                    | cryptoauthlib.h, 818                   |
| atca_crypto_hw_aes.h, 570<br>atca_aes_ctr_ctx, 403 | atca_cfgs.c, 565                       |
| cb, 403                                            | atca_cfgs.h, 565                       |
| counter_size, 403                                  | cfg ateccx08a i2c default, 566         |
| device, 404                                        | cfg_ateccx08a_kitcdc_default, 566      |
| key_block, 404                                     | cfg_ateccx08a_kithid_default, 566      |
| key_id, 404                                        | cfg_ateccx08a_swi_default, 567         |
| •                                                  | cfg_atsha20xa_i2c_default, 567         |
| atca_aes_ctr_ctx_t                                 | cfg_atsha20xa_izc_default, 567         |
| atca_crypto_hw_aes.h, 570                          | <del>-</del>                           |
| ATCA_AES_ENABLE_EN_MASK                            | cfg_atsha20xa_kithid_default, 567      |
| ATCA ATCA ATCA ATCA ATCA ATCA ATCA ATCA            | cfg_atsha20xa_swi_default, 567         |
| ATCA_AES_ENABLE_EN_SHIFT                           | atca_check_mac_in_out, 407             |
| ATCADevice (atca_), 127                            | client_chal, 408                       |
| atca_aes_gcm_ctx, 404                              | client_resp, 408                       |
| aad_size, 405                                      | key_id, 408                            |
| cb, 405                                            | mode, 408                              |
| ciphertext_block, 405                              | other_data, 408                        |
| data_size, 406                                     | otp, 408                               |
| enc_cb, 406                                        | slot_key, 409                          |
| h, 406                                             | sn, 409                                |
| j0, 406                                            | target_key, 409                        |
| key_block, 406                                     | temp_key, 409                          |

| atca_check_mac_in_out_t                | ATCA_CHIPMODE_CLOCK_DIV_M2             |
|----------------------------------------|----------------------------------------|
| Host side crypto methods (atcah_), 310 | calib_command.h, 715                   |
| ATCA_CHECKMAC                          | ATCA_CHIPMODE_CLOCK_DIV_MASK           |
| calib_command.h, 714                   | calib_command.h, 715                   |
| ATCA_CHECKMAC_VERIFY_FAILED            | ATCA_CHIPMODE_I2C_ADDRESS_FLAG         |
| atca_status.h, 639                     | calib_command.h, 715                   |
| ATCA_CHIP_MODE_CLK_DIV                 | ATCA_CHIPMODE_OFFSET                   |
| ATCADevice (atca_), 127                | calib_command.h, 715                   |
| ATCA_CHIP_MODE_CLK_DIV_MASK            | ATCA_CHIPMODE_TTL_ENABLE_FLAG          |
| ATCADevice (atca_), 127                | calib_command.h, 715                   |
| ATCA CHIP MODE CLK DIV SHIFT           | ATCA_CHIPMODE_WATCHDOG_LONG            |
| ATCADevice (atca_), 127                | calib command.h, 715                   |
| ATCA_CHIP_MODE_I2C_EXTRA_MASK          | ATCA_CHIPMODE_WATCHDOG_MASK            |
| ATCADevice (atca_), 127                | calib_command.h, 716                   |
| ATCA_CHIP_MODE_I2C_EXTRA_SHIFT         | ATCA_CHIPMODE_WATCHDOG_SHORT           |
|                                        |                                        |
| ATCA CHIP MODE THE EN MACK             | calib_command.h, 716                   |
| ATCA_CHIP_MODE_TTL_EN_MASK             | ATCA_CMD_SIZE_MAX                      |
| ATCADevice (atca_), 128                | calib_command.h, 716                   |
| ATCA_CHIP_MODE_TTL_EN_SHIFT            | ATCA_CMD_SIZE_MIN                      |
| ATCADevice (atca_), 128                | calib_command.h, 716                   |
| ATCA_CHIP_MODE_WDG_LONG_MASK           | ATCA_COMM_FAIL                         |
| ATCADevice (atca_), 128                | atca_status.h, 639                     |
| ATCA_CHIP_MODE_WDG_LONG_SHIFT          | atca_command, 409                      |
| ATCADevice (atca_), 128                | clock_divider, 410                     |
| ATCA_CHIP_OPT_ECDH_PROT                | dt, 410                                |
| ATCADevice (atca_), 128                | execution_time_msec, 410               |
| ATCA_CHIP_OPT_ECDH_PROT_MASK           | atca_command.c, 568                    |
| ATCADevice (atca_), 128                | atca_command.h, 568                    |
| ATCA_CHIP_OPT_ECDH_PROT_SHIFT          | ATCA_COMMAND_HEADER_SIZE               |
| ATCADevice (atca_), 128                | Host side crypto methods (atcah_), 307 |
| ATCA_CHIP_OPT_IO_PROT_EN_MASK          | atca_compiler.h, 569                   |
| ATCADevice (atca_), 129                | ATCA_CONFIG_ZONE_LOCKED                |
| ATCA_CHIP_OPT_IO_PROT_EN_SHIFT         | atca_status.h, 639                     |
| ATCADevice (atca_), 129                | ATCA_COUNT_IDX                         |
| ATCA_CHIP_OPT_IO_PROT_KEY              | calib_command.h, 716                   |
| ATCADevice (atca_), 129                | ATCA_COUNT_SIZE                        |
| ATCA_CHIP_OPT_IO_PROT_KEY_MASK         | calib_command.h, 716                   |
| ATCADevice (atca_), 129                | ATCA_COUNTER                           |
| ATCA CHIP OPT IO PROT KEY SHIFT        | calib command.h, 717                   |
|                                        | <del>-</del>                           |
| ATCA CUIP OPT KEE ASS EN MASK          | ATCA Davies (stee ) 100                |
| ATCA_CHIP_OPT_KDF_AES_EN_MASK          | ATCA COUNTED MATCH EN CHIET            |
| ATCADevice (atca_), 129                | ATCA_COUNTER_MATCH_EN_SHIFT            |
| ATCA_CHIP_OPT_KDF_AES_EN_SHIFT         | ATCADevice (atca_), 130                |
| ATCADevice (atca_), 129                | ATCA_COUNTER_MATCH_KEY                 |
| ATCA_CHIP_OPT_KDF_PROT                 | ATCADevice (atca_), 131                |
| ATCADevice (atca_), 130                | ATCA_COUNTER_MATCH_KEY_MASK            |
| ATCA_CHIP_OPT_KDF_PROT_MASK            | ATCADevice (atca_), 131                |
| ATCADevice (atca_), 130                | ATCA_COUNTER_MATCH_KEY_SHIFT           |
| ATCA_CHIP_OPT_KDF_PROT_SHIFT           | ATCADevice (atca_), 131                |
| ATCADevice (atca_), 130                | ATCA_CRC_SIZE                          |
| ATCA_CHIP_OPT_POST_EN_MASK             | calib_command.h, 717                   |
| ATCADevice (atca_), 130                | atca_crypto_hw_aes.h, 569              |
| ATCA_CHIP_OPT_POST_EN_SHIFT            | atca_aes_cbc_ctx_t, 570                |
| ATCADevice (atca_), 130                | atca_aes_cmac_ctx_t, 570               |
| ATCA_CHIPMODE_CLOCK_DIV_M0             | atca_aes_ctr_ctx_t, 570                |
| calib_command.h, 714                   | atca_crypto_hw_aes_cbc.c, 570          |
| ATCA_CHIPMODE_CLOCK_DIV_M1             | atca_crypto_hw_aes_cmac.c, 571         |
| calib command.h. 714                   | atca_crypto_nw_acs_crnac.c, 571        |

| atas arvets auch 579                   | on 411                                 |
|----------------------------------------|----------------------------------------|
| atca_crypto_sw.h, 573                  | sn, 411                                |
| ATCA_SHA1_DIGEST_SIZE, 574             | target_key, 412                        |
| ATCA_SHA2_256_BLOCK_SIZE, 574          | target_key_id, 412                     |
| ATCA_SHA2_256_DIGEST_SIZE, 575         | temp_key, 412                          |
| atcac_aes_cmac_ctx, 575                | atca_derive_key_mac_in_out, 412        |
| atcac_aes_cmac_finish, 576             | mac, 413                               |
| atcac_aes_cmac_init, 576               | mode, 413                              |
| atcac_aes_cmac_update, 576             | parent_key, 413                        |
| atcac_aes_gcm_aad_update, 576          | sn, 413                                |
| atcac_aes_gcm_ctx, 575                 | target_key_id, 413                     |
| atcac_aes_gcm_decrypt_finish, 577      | ATCA_DERIVE_KEY_ZEROS_SIZE             |
| atcac_aes_gcm_decrypt_start, 577       | Host side crypto methods (atcah_), 307 |
| atcac_aes_gcm_decrypt_update, 577      | ATCA_DEV_UNKNOWN                       |
| atcac_aes_gcm_encrypt_finish, 578      | ATCADevice (atca_), 143                |
| atcac_aes_gcm_encrypt_start, 578       | atca_device, 414                       |
| atcac_aes_gcm_encrypt_update, 578      | mCommands, 414                         |
| atcac_hmac_sha256_ctx, 575             | mlface, 414                            |
| atcac_sha1_ctx, 575                    | session_counter, 414                   |
| atcac_sha2_256_ctx, 575                | session_key, 414                       |
| MBEDTLS_CMAC_C, 575                    | session_key_id, 415                    |
| atca_crypto_sw_ecdsa.c, 579            | session key len, 415                   |
| atca_crypto_sw_ecdsa.h, 579            | session_state, 415                     |
| atca_crypto_sw_rand.c, 580             | atca device.c, 585                     |
| atca_crypto_sw_rand.h, 580             | atca device.h, 586                     |
| atca_crypto_sw_sha1.c, 581             | atca_devtypes.h, 589                   |
| atca_crypto_sw_sha1.h, 581             | ATCA_DLL                               |
| atca_crypto_sw_sha2.c, 582             | cryptoauthlib.h, 818                   |
| atca_crypto_sw_sha2.h, 582             | ATCA_ECC_CONFIG_SIZE                   |
| ATCA_CUSTOM_IFACE                      | calib_command.h, 717                   |
| ATCAlface (atca_), 147                 | ATCA_ECC_P256_FIELD_SIZE               |
| . —                                    |                                        |
| ATCA_DATA_IDX                          | Software crypto methods (atcac_), 251  |
| calib_command.h, 717                   | ATCA_ECC_P256_PRIVATE_KEY_SIZE         |
| ATCA_DATA_SIZE                         | Software crypto methods (atcac_), 252  |
| calib_command.h, 717                   | ATCA_ECC_P256_PUBLIC_KEY_SIZE          |
| ATCA_DATA_ZONE_LOCKED                  | Software crypto methods (atcac_), 252  |
| atca_status.h, 639                     | ATCA_ECC_P256_SIGNATURE_SIZE           |
| atca_debug.c, 583                      | Software crypto methods (atcac_), 252  |
| atca_trace, 584                        | ATCA_ECC_SUPPORT                       |
| atca_trace_config, 584                 | cryptoauthlib.h, 818                   |
| atca_trace_msg, 584                    | ATCA_ECCP256_KEY_SIZE                  |
| g_trace_fp, 584                        | cryptoauthlib.h, 818                   |
| atca_debug.h, 584                      | ATCA_ECCP256_PUBKEY_SIZE               |
| atca_trace, 585                        | cryptoauthlib.h, 818                   |
| atca_trace_config, 585                 | ATCA_ECCP256_SIG_SIZE                  |
| atca_trace_msg, 585                    | cryptoauthlib.h, 818                   |
| atca_decrypt_in_out, 410               | ATCA_ECDH                              |
| atca_delay_10us                        | calib_command.h, 718                   |
| Hardware abstraction layer (hal_), 267 | atca_execute_command                   |
| atca_delay_ms                          | Basic Crypto API methods (atcab_), 59  |
| hal_esp32_timer.c, 840                 | ATCA_EXECUTION_ERROR                   |
| Hardware abstraction layer (hal_), 268 | atca_status.h, 639                     |
| atca_delay_us                          | ATCA_FUNC_FAIL                         |
| Hardware abstraction layer (hal_), 268 | atca_status.h, 639                     |
| ATCA_DERIVE_KEY                        | atca_gen_dig_in_out, 415               |
| calib_command.h, 717                   | counter, 416                           |
| atca_derive_key_in_out, 411            | is_key_nomac, 416                      |
| mode, 411                              | key_conf, 416                          |
| parent_key, 411                        | key_id, 416                            |

| other_data, 416                        | atca_helpers.h, 603                             |
|----------------------------------------|-------------------------------------------------|
| slot_conf, 416                         | atcab_b64rules_default, 613                     |
| slot_locked, 417                       | atcab_b64rules_mime, 613                        |
| sn, 417                                | atcab_b64rules_urlsafe, 613                     |
| stored_value, 417                      | atcab_base64decode, 604                         |
| temp_key, 417                          | atcab_base64decode_, 605                        |
| zone, 417                              | atcab_base64encode, 605                         |
| atca_gen_dig_in_out_t                  | atcab_base64encode_, 606                        |
| Host side crypto methods (atcah_), 310 | atcab_bin2hex, 606                              |
| ATCA_GEN_FAIL                          | atcab_bin2hex_, 607                             |
| atca_status.h, 639                     | atcab_hex2bin, 607                              |
| atca_gen_key_in_out, 418               | atcab_hex2bin_, 608                             |
| key_id, 418                            | atcab_memset_s, 608                             |
| mode, 418                              | atcab_printbin_label, 608                       |
| other_data, 418                        | atcab_printbin_sp, 608                          |
| public_key, 419                        | atcab_reversal, 608                             |
| public_key_size, 419                   | base64Char, 609                                 |
| sn, 419                                | base64Index, 609                                |
| temp_key, 419                          | isAlpha, 610                                    |
| atca_gen_key_in_out_t                  | isBase64, 610                                   |
| Host side crypto methods (atcah_), 310 | isBase64Digit, 610                              |
| ATCA_GENDIG                            | isDigit, 611                                    |
| calib_command.h, 718                   | isHex, 611                                      |
| ATCA_GENDIG_ZEROS_SIZE                 | isHexAlpha, 611                                 |
| Host side crypto methods (atcah_), 307 | isHexDigit, 612                                 |
| ATCA_GENKEY                            | isWhiteSpace, 612                               |
| calib_command.h, 718                   | packHex, 613                                    |
| atca_hal.c, 590                        | ATCA_HID_IFACE                                  |
| atca_hal.h, 590                        | ATCAlface (atca_), 147                          |
| ATCA_HEALTH_TEST_ERROR                 | ATCA_HMAC                                       |
| atca_status.h, 639                     | calib_command.h, 718                            |
| atca_helpers.c, 591                    | ATCA_HMAC_BLOCK_SIZE                            |
| atcab_b64rules_default, 603            | Host side crypto methods (atcah_), 308          |
| atcab_b64rules_mime, 603               | atca_hmac_in_out, 419                           |
| atcab_b64rules_urlsafe, 603            | atca_hmac_sha256_ctx_t                          |
| atcab_base64decode, 593                | Basic Crypto API methods for CryptoAuth Devices |
| atcab_base64decode_, 594               | (calib_), 206                                   |
| atcab_base64encode, 594                | atca_host.c, 614                                |
| atcab_base64encode_, 595               | atca_host.h, 615                                |
| atcab_bin2hex, 595                     | ATCA_I2C_ENABLE_EN_MASK                         |
| atcab_bin2hex_, 595                    | ATCADevice (atca_), 131                         |
| atcab_hex2bin, 596                     | ATCA_I2C_ENABLE_EN_SHIFT                        |
| atcab_hex2bin_, 596                    | ATCADevice (atca_), 131                         |
| atcab_memset_s, 597                    | ATCA_I2C_IFACE                                  |
| atcab_reversal, 597                    | ATCAlface (atca_), 147                          |
| B64_IS_EQUAL, 593                      | atca_iface, 420                                 |
| B64_IS_INVALID, 593                    | atidle, 420                                     |
| base64Char, 597                        | atinit, 421                                     |
| base64Index, 599                       | atpostinit, 421                                 |
| isAlpha, 599                           | atreceive, 421                                  |
| isBase64, 599                          | atsend, 421                                     |
| isBase64Digit, 600                     | atsleep, 421                                    |
| isDigit, 600                           | atwake, 421                                     |
| isHex, 601                             | hal_data, 421                                   |
| isHexAlpha, 601                        | mlfaceCFG, 421                                  |
| isHexDigit, 601                        | mType, 422                                      |
| isWhiteSpace, 602                      | atca_iface.c, 618                               |
| packHex, 602                           | atca_iface.h, 619                               |
|                                        |                                                 |

| atca_include_data_in_out, 422                 | ATCADevice (atca_), 132               |
|-----------------------------------------------|---------------------------------------|
| mode, 422                                     | ATCA_KEY_CONFIG_PERSIST_DISABLE_SHIFT |
| ATCA_INFO                                     | ATCADevice (atca_), 133               |
| calib_command.h, 718                          | ATCA_KEY_CONFIG_PRIVATE_MASK          |
| ATCA_INVALID_ID                               | ATCADevice (atca_), 133               |
| atca_status.h, 639                            | ATCA_KEY_CONFIG_PRIVATE_SHIFT         |
| ATCA_INVALID_LENGTH                           | ATCADevice (atca_), 133               |
| atca_status.h, 639                            | ATCA_KEY_CONFIG_PUB_INFO_MASK         |
| ATCA_INVALID_POINTER                          | ATCADevice (atca_), 133               |
| atca_status.h, 639                            | ATCA_KEY_CONFIG_PUB_INFO_SHIFT        |
| ATCA INVALID SIZE                             | ATCADevice (atca ), 133               |
| atca status.h, 639                            | ATCA_KEY_CONFIG_REQ_AUTH_MASK         |
| atca_io_decrypt_in_out, 422                   | ATCADevice (atca_), 133               |
| data, 423                                     | ATCA_KEY_CONFIG_REQ_AUTH_SHIFT        |
| data_size, 423                                | ATCADevice (atca_), 133               |
|                                               | ATCA_KEY_CONFIG_REQ_RANDOM_MASK       |
| io_key, 423                                   | ATCADevice (atca ), 133               |
| out_nonce, 423                                | · —                                   |
| atca_io_decrypt_in_out_t                      | ATCA_KEY_CONFIG_REQ_RANDOM_SHIFT      |
| Host side crypto methods (atcah_), 311        | ATCADevice (atca_), 134               |
| atca_jwt.c, 621                               | ATCA_KEY_CONFIG_RFU_MASK              |
| atca_jwt.h, 621                               | ATCADevice (atca_), 134               |
| atca_jwt_add_claim_numeric                    | ATCA_KEY_CONFIG_RFU_SHIFT             |
| JSON Web Token (JWT) methods (atca_jwt_), 326 | ATCADevice (atca_), 134               |
| atca_jwt_add_claim_string                     | ATCA_KEY_CONFIG_X509_ID               |
| JSON Web Token (JWT) methods (atca_jwt_), 326 | ATCADevice (atca_), 134               |
| atca_jwt_check_payload_start                  | ATCA_KEY_CONFIG_X509_ID_MASK          |
| JSON Web Token (JWT) methods (atca_jwt_), 327 | ATCADevice (atca_), 134               |
| atca_jwt_finalize                             | ATCA_KEY_CONFIG_X509_ID_SHIFT         |
| JSON Web Token (JWT) methods (atca_jwt_), 327 | ATCADevice (atca_), 134               |
| atca_jwt_init                                 | ATCA_KEY_COUNT                        |
| JSON Web Token (JWT) methods (atca_jwt_), 327 | calib_command.h, 719                  |
| atca_jwt_t, 424                               | ATCA_KEY_ID_MAX                       |
| buf, 424                                      | calib_command.h, 719                  |
| buflen, 424                                   | ATCA_KEY_SIZE                         |
| cur, 424                                      | calib_command.h, 719                  |
| atca_jwt_verify                               | ATCA_KIT_AUTO_IFACE                   |
| JSON Web Token (JWT) methods (atca_jwt_), 327 | ATCAlface (atca ), 147                |
| ATCA_K283_KEY_TYPE                            | ATCA KIT I2C IFACE                    |
| calib_command.h, 718                          | ATCAlface (atca_), 147                |
| ATCA_KDF                                      | ATCA_KIT_SPI_IFACE                    |
| calib_command.h, 719                          | ATCAlface (atca.), 147                |
| ATCA KEY CONFIG AUTH KEY                      | ATCA KIT_SWI_IFACE                    |
|                                               |                                       |
| ATCADevice (atca_), 131                       | ATCA Idit I NIKA OMAN I IFA OF        |
| ATCA_KEY_CONFIG_AUTH_KEY_MASK                 | ATCA_KIT_UNKNOWN_IFACE                |
| ATCADevice (atca_), 131                       | ATCAIrace (atca_), 147                |
| ATCA_KEY_CONFIG_AUTH_KEY_SHIFT                | ATCA_LIBRARY_VERSION_BUILD            |
| ATCADevice (atca_), 132                       | atca_version.h, 640                   |
| ATCA_KEY_CONFIG_KEY_TYPE                      | ATCA_LIBRARY_VERSION_DATE             |
| ATCADevice (atca_), 132                       | atca_version.h, 640                   |
| ATCA_KEY_CONFIG_KEY_TYPE_MASK                 | ATCA_LIBRARY_VERSION_MAJOR            |
| ATCADevice (atca_), 132                       | atca_version.h, 640                   |
| ATCA_KEY_CONFIG_KEY_TYPE_SHIFT                | ATCA_LIBRARY_VERSION_MINOR            |
| ATCADevice (atca_), 132                       | atca_version.h, 641                   |
| ATCA_KEY_CONFIG_LOCKABLE_MASK                 | ATCA_LOCK                             |
| ATCADevice (atca_), 132                       | calib_command.h, 719                  |
| ATCA_KEY_CONFIG_LOCKABLE_SHIFT                | ATCA_LOCKED                           |
| ATCADevice (atca_), 132                       | calib_command.h, 719                  |
| ATCA KEY CONFIG PERSIST DISABLE MASK          | ATCA MAC                              |

| calib_command.h, 720                         | Host side crypto methods (atcah_), 311            |
|----------------------------------------------|---------------------------------------------------|
| atca_mac_in_out, 424                         | ATCA NOT INITIALIZED                              |
| atca_mac_in_out_t                            | atca_status.h, 640                                |
| Host side crypto methods (atcah_), 311       | ATCA NOT LOCKED                                   |
| ATCA_MAX_TRANSFORMS                          | atca status.h, 639                                |
| atcacert_def.h, 653                          | ATCA_OPCODE_IDX                                   |
| atca_mbedtls_cert_add                        | calib_command.h, 720                              |
| atca_mbedtls_wrap.c, 624                     | atca_openssl_interface.c, 630                     |
| mbedTLS Wrapper methods (atca mbedtls ), 328 | atcac_aes_cmac_finish, 632                        |
| atca_mbedtls_ecdh.c, 622                     | atcac_aes_cmac_init, 632                          |
| atca_mbedtls_ecdh_ioprot_cb                  | atcac_aes_cmac_update, 633                        |
| mbedTLS Wrapper methods (atca_mbedtls_), 328 | atcac_aes_gcm_aad_update, 633                     |
| atca_mbedtls_ecdh_slot_cb                    | atcac_aes_gcm_decrypt_finish, 634                 |
| mbedTLS Wrapper methods (atca_mbedtls_), 328 | atcac_aes_gcm_decrypt_start, 634                  |
| atca_mbedtls_ecdsa.c, 622                    | atcac_aes_gcm_decrypt_update, 634                 |
| atca_mbedtls_pk_init                         | atcac_aes_gcm_encrypt_finish, 635                 |
| mbedTLS Wrapper methods (atca_mbedtls_), 329 | atcac_aes_gcm_encrypt_start, 635                  |
| atca_mbedtls_wrap.c, 622                     | atcac_aes_gcm_encrypt_update, 636                 |
| atca_mbedtls_cert_add, 624                   | atcac_sw_sha1_finish, 636                         |
| atcac_aes_cmac_finish, 625                   | atcac_sw_sha2_256_finish, 637                     |
| atcac_aes_cmac_init, 625                     | ATCA_OTP_BLOCK_MAX                                |
| atcac_aes_cmac_update, 626                   | calib_command.h, 720                              |
| atcac_aes_gcm_aad_update, 626                | ATCA_OTP_SIZE                                     |
| atcac_aes_gcm_decrypt_finish, 626            | calib_command.h, 720                              |
| atcac_aes_gcm_decrypt_start, 627             | ATCA_P256_KEY_TYPE                                |
| atcac_aes_gcm_decrypt_update, 627            | calib_command.h, 720                              |
| atcac_aes_gcm_encrypt_finish, 628            | ATCA_PACKED                                       |
| atcac_aes_gcm_encrypt_start, 628             | ATCADevice (atca_), 134                           |
| atcac_aes_gcm_encrypt_update, 629            | Certificate manipulation methods (atcacert_), 158 |
| atcac_sw_sha1_finish, 629                    | ATCA_PACKET_OVERHEAD                              |
| atcac_sw_sha2_256_finish, 630                | calib_command.h, 721                              |
| mbedtls_calloc, 624                          | ATCA_PARAM1_IDX                                   |
| mbedtls_free, 624                            | calib_command.h, 721                              |
| atca_mbedtls_wrap.h, 630                     | ATCA_PARAM2_IDX                                   |
| ATCA_MSG_SIZE_DERIVE_KEY                     | calib_command.h, 721                              |
| Host side crypto methods (atcah_), 308       | ATCA_PARITY_ERROR                                 |
| ATCA_MSG_SIZE_DERIVE_KEY_MAC                 | atca_status.h, 639                                |
| Host side crypto methods (atcah_), 308       | ATCA_PARSE_ERROR                                  |
| ATCA_MSG_SIZE_ENCRYPT_MAC                    | atca_status.h, 639                                |
| Host side crypto methods (atcah_), 308       | ATCA_PAUSE                                        |
| ATCA_MSG_SIZE_GEN_DIG                        | calib_command.h, 721                              |
| Host side crypto methods (atcah_), 308       | ATCA_POLLING_FREQUENCY_TIME_MSEC                  |
| ATCA_MSG_SIZE_HMAC                           | Hardware abstraction layer (hal_), 262            |
| Host side crypto methods (atcah_), 308       | ATCA_POLLING_INIT_TIME_MSEC                       |
| ATCA_MSG_SIZE_MAC                            | Hardware abstraction layer (hal_), 262            |
| Host side crypto methods (atcah_), 308       | ATCA_POLLING_MAX_TIME_MSEC                        |
| ATCA_MSG_SIZE_NONCE                          | Hardware abstraction layer (hal_), 262            |
| Host side crypto methods (atcah_), 309       | ATCA_PRIV_KEY_SIZE                                |
| ATCA_MSG_SIZE_PRIVWRITE_MAC                  | calib_command.h, 721                              |
| Host side crypto methods (atcah_), 309       | ATCA_PRIVWRITE                                    |
| ATCA_MUTEX_TIMEOUT                           | calib_command.h, 721                              |
| hal_freertos.c, 841                          | ATCA_PRIVWRITE_MAC_ZEROS_SIZE                     |
| ATCA_NO_DEVICES                              | Host side crypto methods (atcah_), 309            |
| atca_status.h, 639                           | ATCA_PRIVWRITE_PLAIN_TEXT_SIZE                    |
| ATCA_NONCE                                   | Host side crypto methods (atcah_), 309            |
| calib_command.h, 720                         | ATCA_PUB_KEY_PAD                                  |
| atca_nonce_in_out, 425                       | calib_command.h, 722                              |
| atca_nonce_in_out_t                          | ATCA_PUB_KEY_SIZE                                 |

| calib_command.h, 722                             | ATCADevice (atca_), 136                         |
|--------------------------------------------------|-------------------------------------------------|
| ATCA_RANDOM                                      | ATCA_SECUREBOOT                                 |
| calib_command.h, 722                             | calib_command.h, 724                            |
| ATCA_READ                                        | atca_secureboot_enc_in_out, 426                 |
| calib_command.h, 722                             | digest, 426                                     |
| ATCA_RESYNC_WITH_WAKEUP                          | digest_enc, 426                                 |
| atca_status.h, 639                               | hashed_key, 426                                 |
| ATCA_RSP_DATA_IDX                                | io_key, 426                                     |
| calib_command.h, 722                             | temp_key, 427                                   |
| ATCA_RSP_SIZE_16                                 | atca_secureboot_enc_in_out_t                    |
| calib_command.h, 722                             | Host side crypto methods (atcah_), 311          |
| ATCA_RSP_SIZE_32                                 | atca_secureboot_mac_in_out, 427                 |
| calib_command.h, 723                             | digest, 427                                     |
| ATCA_RSP_SIZE_4                                  | hashed_key, 427                                 |
| calib_command.h, 723                             | mac, 428                                        |
| ATCA_RSP_SIZE_64                                 | mode, 428                                       |
| calib_command.h, 723                             | param2, 428                                     |
| ATCA_RSP_SIZE_72                                 | secure_boot_config, 428                         |
| calib_command.h, 723                             | signature, 428                                  |
| ATCA_RSP_SIZE_MAX                                | atca_secureboot_mac_in_out_t                    |
| calib_command.h, 723                             | Host side crypto methods (atcah_), 311          |
| ATCA RSP SIZE MIN                                | ATCA SELFTEST                                   |
| calib_command.h, 723                             | calib command.h, 724                            |
| ATCA_RSP_SIZE_VAL                                | ATCA_SERIAL_NUM_SIZE                            |
| calib_command.h, 724                             | calib_command.h, 724                            |
| ATCA_RX_CRC_ERROR                                | ATCA_SHA                                        |
| atca_status.h, 639                               | calib_command.h, 724                            |
| ATCA_RX_FAIL                                     | ATCA_SHA1_DIGEST_SIZE                           |
| atca_status.h, 639                               | atca_crypto_sw.h, 574                           |
| ATCA_RX_NO_RESPONSE                              | ATCA_SHA206A_DKEY_CONSUMPTION_MASK              |
| atca_status.h, 639                               | api_206a.h, 544                                 |
| ATCA_RX_TIMEOUT                                  | ATCA_SHA206A_PKEY_CONSUMPTION_MASK              |
| atca status.h, 639                               | api_206a.h, 544                                 |
| ATCA_SECURE_BOOT_DIGEST                          | ATCA_SHA206A_SYMMETRIC_KEY_ID_SLOT              |
| ATCA_SECONE_BOOT_BIGEST  ATCADevice (atca_), 135 |                                                 |
| ATCA SECURE BOOT DIGEST MASK                     | api_206a.h, 545                                 |
|                                                  | ATCA_SHA206A_ZONE_WRITE_LOCK                    |
| ATCA SECURE ROOT DIOEST SHIFT                    | api_206a.h, 545                                 |
| ATCA Device (etc.) 135                           | ATCA_SHA256_BLOCK_SIZE                          |
| ATCA SECURE ROOT MODE                            | cryptoauthlib.h, 818                            |
| ATCA_SECURE_BOOT_MODE                            | atca_sha256_ctx, 429                            |
| ATCADevice (atca_), 135                          | block, 429                                      |
| ATCA_SECURE_BOOT_MODE_MASK                       | block_size, 429                                 |
| ATCADevice (atca_), 135                          | total_msg_size, 429                             |
| ATCA_SECURE_BOOT_MODE_SHIFT                      | atca_sha256_ctx_t                               |
| ATCADevice (atca_), 135                          | Basic Crypto API methods for CryptoAuth Devices |
| ATCA_SECURE_BOOT_PERSIST_EN_MASK                 | (calib_), 206                                   |
| ATCADevice (atca_), 135                          | ATCA_SHA256_DIGEST_SIZE                         |
| ATCA_SECURE_BOOT_PERSIST_EN_SHIFT                | cryptoauthlib.h, 819                            |
| ATCADevice (atca_), 136                          | ATCA_SHA2_256_BLOCK_SIZE                        |
| ATCA_SECURE_BOOT_PUB_KEY                         | atca_crypto_sw.h, 574                           |
| ATCADevice (atca_), 136                          | ATCA_SHA2_256_DIGEST_SIZE                       |
| ATCA_SECURE_BOOT_PUB_KEY_MASK                    | atca_crypto_sw.h, 575                           |
| ATCADevice (atca_), 136                          | ATCA_SHA_CONFIG_SIZE                            |
| ATCA_SECURE_BOOT_PUB_KEY_SHIFT                   | calib_command.h, 724                            |
| ATCADevice (atca_), 136                          | ATCA_SHA_DIGEST_SIZE                            |
| ATCA_SECURE_BOOT_RAND_NONCE_MASK                 | calib_command.h, 725                            |
| ATCADevice (atca_), 136                          | ATCA_SHA_KEY_TYPE                               |
| ATCA_SECURE_BOOT_RAND_NONCE_SHIFT                | calib_command.h, 725                            |

| ATCA_SHA_SUPPORT                                         | ATCA SLOT CONFIG READKEY               |
|----------------------------------------------------------|----------------------------------------|
| cryptoauthlib.h, 819                                     | ATCADevice (atca_), 139                |
| ATCA SIG SIZE                                            | ATCA_SLOT_CONFIG_READKEY_MASK          |
| calib_command.h, 725                                     | ATCADevice (atca_), 139                |
| ATCA SIGN                                                | ATCA_SLOT_CONFIG_READKEY_SHIFT         |
| calib_command.h, 725                                     | ATCADevice (atca_), 139                |
| atca_sign_internal_in_out, 429                           | ATCA_SLOT_CONFIG_WRITE_CONFIG          |
| digest, 430                                              | ATCADevice (atca_), 139                |
| for_invalidate, 430                                      | ATCA_SLOT_CONFIG_WRITE_CONFIG_MASK     |
| is_slot_locked, 431                                      | ATCADevice (atca_), 139                |
| key config, 431                                          | ATCA_SLOT_CONFIG_WRITE_CONFIG_SHIFT    |
| key_id, 431                                              | ATCADevice (atca_), 139                |
| message, 431                                             | ATCA_SLOT_CONFIG_WRITE_ECDH_MASK       |
| mode, 431                                                | ATCADevice (atca ), 140                |
| slot_config, 431                                         | ATCA_SLOT_CONFIG_WRITE_ECDH_SHIFT      |
| sn, 432                                                  | ATCADevice (atca_), 140                |
| temp_key, 432                                            | ATCA_SLOT_CONFIG_WRITE_KEY             |
| update_count, 432                                        | ATCADevice (atca_), 140                |
| use_flag, 432                                            | ATCA_SLOT_CONFIG_WRITE_KEY_MASK        |
| verify_other_data, 432                                   | ATCADevice (atca_), 140                |
| atca_sign_internal_in_out_t                              | ATCA_SLOT_CONFIG_WRITE_KEY_SHIFT       |
| Host side crypto methods (atcah_), 311                   | ATCADevice (atca ), 140                |
| ATCA_SLOT_CONFIG_ECDH_MASK                               | ATCA_SLOT_LOCKED                       |
| ATCADevice (atca ), 136                                  | ATCADevice (atca_), 140                |
| ATCA_SLOT_CONFIG_ECDH_SHIFT                              | ATCA_SMALL_BUFFER                      |
| ATCADevice (atca_), 137                                  | atca_status.h, 639                     |
| ATCA_SLOT_CONFIG_ENCRYPTED_READ_MASK                     | ATCA_SN_0_DEF                          |
| ATCADevice (atca_), 137                                  | Host side crypto methods (atcah_), 309 |
| ATCA_SLOT_CONFIG_ENCRYPTED_READ_SHIFT                    | ATCA_SN_1_DEF                          |
| ATCADevice (atca_), 137                                  | Host side crypto methods (atcah_), 309 |
| ATCA_SLOT_CONFIG_EXT_SIG_MASK                            | ATCA_SN_8_DEF                          |
| ATCA_SLOT_CONFIG_EXT_SIG_WASK  ATCADevice (atca_), 137   | Host side crypto methods (atcah_), 309 |
|                                                          |                                        |
| ATCA_SLOT_CONFIG_EXT_SIG_SHIFT ATCADevice (atca ), 137   | ATCA SPI_IFACE                         |
| · —                                                      | ATCAlface (atca_), 147                 |
| ATCA_SLOT_CONFIG_GEN_KEY_MASK<br>ATCADevice (atca_), 137 | atca_start_config.h, 637               |
| ATCA SLOT CONFIG GEN KEY SHIFT                           | atca_start_iface.h, 637                |
|                                                          | ATCA_STATUS                            |
| ATCA CLOT CONFIG. INT. CIC. MACK                         | atca_status.h, 638                     |
| ATCA Davies (stee ) 107                                  | atca_status.h, 637                     |
| ATCADevice (atca_), 137                                  | ATCA_ALLOC_FAILURE, 640                |
| ATCA_SLOT_CONFIG_INT_SIG_SHIFT                           | ATCA_ASSERT_FAILURE, 639               |
| ATCADevice (atca_), 138                                  | ATCA_BAD_OPCODE, 639                   |
| ATCA_SLOT_CONFIG_IS_SECRET_MASK                          | ATCA_BAD_PARAM, 639                    |
| ATCADevice (atca_), 138                                  | ATCA_CHECKMAC_VERIFY_FAILED, 639       |
| ATCA_SLOT_CONFIG_IS_SECRET_SHIFT                         | ATCA_COMM_FAIL, 639                    |
| ATCADevice (atca_), 138                                  | ATCA_CONFIG_ZONE_LOCKED, 639           |
| ATCA_SLOT_CONFIG_LIMITED_USE_MASK                        | ATCA_DATA_ZONE_LOCKED, 639             |
| ATCADevice (atca_), 138                                  | ATCA_EXECUTION_ERROR, 639              |
| ATCA_SLOT_CONFIG_LIMITED_USE_SHIFT                       | ATCA_FUNC_FAIL, 639                    |
| ATCADevice (atca_), 138                                  | ATCA_GEN_FAIL, 639                     |
| ATCA_SLOT_CONFIG_NOMAC_MASK                              | ATCA_HEALTH_TEST_ERROR, 639            |
| ATCADevice (atca_), 138                                  | ATCA_INVALID_ID, 639                   |
| ATCA_SLOT_CONFIG_NOMAC_SHIFT                             | ATCA_INVALID_LENGTH, 639               |
| ATCADevice (atca_), 138                                  | ATCA_INVALID_POINTER, 639              |
| ATCA_SLOT_CONFIG_PRIV_WRITE_MASK                         | ATCA_INVALID_SIZE, 639                 |
| ATCADevice (atca_), 138                                  | ATCA_NO_DEVICES, 639                   |
| ATCA_SLOT_CONFIG_PRIV_WRITE_SHIFT                        | ATCA_NOT_INITIALIZED, 640              |
| ATCADevice (atca_), 139                                  | ATCA_NOT_LOCKED, 639                   |

| ATCA_PARITY_ERROR, 639                        | ATCA_TOSTRING                          |
|-----------------------------------------------|----------------------------------------|
| ATCA_PARSE_ERROR, 639                         | cryptoauthlib.h, 819                   |
| ATCA_RESYNC_WITH_WAKEUP, 639                  | ATCA_TRACE                             |
| ATCA_RX_CRC_ERROR, 639                        | cryptoauthlib.h, 819                   |
| ATCA_RX_FAIL, 639                             | atca_trace                             |
| ATCA_RX_NO_RESPONSE, 639                      | atca_debug.c, 584                      |
| ATCA_RX_TIMEOUT, 639                          | atca_debug.h, 585                      |
| ATCA SMALL BUFFER, 639                        | atca_trace_config                      |
| ATCA STATUS, 638                              | atca_debug.c, 584                      |
| ATCA_STATUS_AUTH_BIT, 638                     | atca debug.h, 585                      |
| ATCA STATUS CRC, 639                          | atca_trace_msg                         |
| ATCA_STATUS_ECC, 639                          | atca_debug.c, 584                      |
| ATCA_STATUS_SELFTEST_ERROR, 639               | atca_debug.h, 585                      |
| ATCA STATUS UNKNOWN, 639                      | ATCA TX FAIL                           |
| ATCA SUCCESS, 639                             | atca_status.h, 639                     |
| ATCA_TIMEOUT, 639                             | ATCA_TX_TIMEOUT                        |
| ATCA_TOO_MANY_COMM_RETRIES, 639               | atca_status.h, 639                     |
| ATCA TX FAIL, 639                             | ATCA_UART_IFACE                        |
| ATCA_TX_TIMEOUT, 639                          | ATCAlface (atca_), 147                 |
| ATCA_UNIMPLEMENTED, 639                       | ATCA UNIMPLEMENTED                     |
| ATCA USE FLAGS CONSUMED, 640                  | atca_status.h, 639                     |
| ATCA_WAKE_FAILED, 639                         | ATCA UNKNOWN IFACE                     |
| ATCA WAKE SUCCESS, 639                        | ATCAlface (atca ), 147                 |
| ATCA STATUS AUTH BIT                          | ATCA UNLOCKED                          |
| atca_status.h, 638                            | calib_command.h, 725                   |
| ATCA STATUS CRC                               | ATCA_UNSUPPORTED_CMD                   |
|                                               | calib execution.h, 799                 |
| atca_status.h, 639 ATCA STATUS ECC            | ATCA_UPDATE_EXTRA                      |
|                                               | calib_command.h, 726                   |
| atca_status.h, 639 ATCA_STATUS_SELFTEST_ERROR | ATCA_USE_FLAGS_CONSUMED                |
|                                               |                                        |
| atca_status.h, 639                            | atca_status.h, 640                     |
| ATCA_STATUS_UNKNOWN                           | ATCA_USE_LOCK_ENABLE_MASK              |
| atca_status.h, 639                            | ATCALLOS LOCK SNARLS OUTST             |
| ATCA_STRINGIFY                                | ATCA_USE_LOCK_ENABLE_SHIFT             |
| cryptoauthlib.h, 819                          | ATCADevice (atca_), 141                |
| ATCA_SUCCESS                                  | ATCA_USE_LOCK_KEY_MASK                 |
| atca_status.h, 639                            | ATCADevice (atca_), 141                |
| ATCA_SWI_IFACE                                | ATCA_USE_LOCK_KEY_SHIFT                |
| ATCAITA GUIDRODT                              | ATCADevice (atca_), 141                |
| ATCA_TA_SUPPORT                               | ATCA_VERIFY                            |
| cryptoauthlib.h, 819                          | calib_command.h, 726                   |
| atca_temp_key, 433                            | atca_verify_in_out, 435                |
| gen_dig_data, 433                             | atca_verify_in_out_t                   |
| gen_key_data, 433                             | Host side crypto methods (atcah_), 312 |
| is_64, 433                                    | atca_verify_mac, 435                   |
| key_id, 434                                   | io_key, 436                            |
| no_mac_flag, 434                              | key_id, 436                            |
| source_flag, 434                              | mac, 436                               |
| valid, 434                                    | mode, 436                              |
| value, 434                                    | msg_dig_buf, 436                       |
| atca_temp_key_t                               | other_data, 436                        |
| Host side crypto methods (atcah_), 311        | signature, 437                         |
| ATCA_TEMPKEY_KEYID                            | sn, 437                                |
| calib_command.h, 725                          | temp_key, 437                          |
| ATCA_TIMEOUT                                  | atca_verify_mac_in_out_t               |
| atca_status.h, 639                            | Host side crypto methods (atcah_), 312 |
| ATCA_TOO_MANY_COMM_RETRIES                    | atca_version                           |
| atca_status.h, 639                            | atca_basic.c, 557                      |

| atca_version.h, 640                    | atcab_aes_cbc_init_ext                |
|----------------------------------------|---------------------------------------|
| ATCA_LIBRARY_VERSION_BUILD, 640        | Basic Crypto API methods (atcab_), 62 |
| ATCA_LIBRARY_VERSION_DATE, 640         | atcab_aes_cmac_finish                 |
|                                        |                                       |
| ATCA_LIBRARY_VERSION_MAJOR, 640        | Basic Crypto API methods (atcab_), 62 |
| ATCA_LIBRARY_VERSION_MINOR, 641        | atcab_aes_cmac_init                   |
| ATCA_VOL_KEY_PERM_EN_MASK              | Basic Crypto API methods (atcab_), 63 |
| ATCADevice (atca_), 141                | atcab_aes_cmac_init_ext               |
| ATCA_VOL_KEY_PERM_EN_SHIFT             | Basic Crypto API methods (atcab_), 63 |
| ATCADevice (atca_), 141                | atcab_aes_cmac_update                 |
| ATCA_VOL_KEY_PERM_SLOT                 | Basic Crypto API methods (atcab_), 64 |
| ATCADevice (atca_), 141                | atcab_aes_ctr_block                   |
| ATCA_VOL_KEY_PERM_SLOT_MASK            | Basic Crypto API methods (atcab_), 64 |
| ATCADevice (atca_), 141                | atcab_aes_ctr_decrypt_block           |
| ATCA_VOL_KEY_PERM_SLOT_SHIFT           | Basic Crypto API methods (atcab_), 64 |
| ATCADevice (atca_), 142                | atcab_aes_ctr_encrypt_block           |
| ATCA_WAKE_FAILED                       | Basic Crypto API methods (atcab_), 65 |
| atca_status.h, 639                     | atcab_aes_ctr_increment               |
| ATCA_WAKE_SUCCESS                      | Basic Crypto API methods (atcab_), 65 |
| atca_status.h, 639                     | atcab_aes_ctr_init                    |
| atca_wolfssl_interface.c, 641          | Basic Crypto API methods (atcab_), 66 |
| ATCA_WORD_SIZE                         | atcab aes ctr init ext                |
| calib command.h, 726                   | Basic Crypto API methods (atcab_), 66 |
| ATCA_WRITE                             | atcab_aes_ctr_init_rand               |
| calib_command.h, 726                   | Basic Crypto API methods (atcab_), 67 |
| atca_write_mac_in_out, 437             | atcab_aes_ctr_init_rand_ext           |
| auth_mac, 438                          | Basic Crypto API methods (atcab_), 67 |
| encrypted_data, 438                    | atcab_aes_decrypt                     |
| input_data, 438                        | Basic Crypto API methods (atcab_), 68 |
| key_id, 438                            | atcab_aes_decrypt_ext                 |
| sn, 438                                | Basic Crypto API methods (atcab_), 68 |
| temp_key, 438                          | atcab_aes_encrypt                     |
| zone, 439                              | Basic Crypto API methods (atcab_), 69 |
| atca_write_mac_in_out_t                | atcab_aes_encrypt_ext                 |
| Host side crypto methods (atcah_), 312 | Basic Crypto API methods (atcab_), 69 |
| ATCA_WRITE_MAC_ZEROS_SIZE              | atcab_aes_gcm_aad_update              |
| Host side crypto methods (atcah_), 310 | Basic Crypto API methods (atcab_), 70 |
| ATCA_ZONE_CONFIG                       | atcab_aes_gcm_decrypt_finish          |
| cryptoauthlib.h, 819                   | Basic Crypto API methods (atcab ), 70 |
| ATCA_ZONE_DATA                         | atcab_aes_gcm_decrypt_update          |
| cryptoauthlib.h, 820                   | Basic Crypto API methods (atcab_), 71 |
| ATCA ZONE ENCRYPTED                    | atcab_aes_gcm_encrypt_finish          |
| calib_command.h, 726                   | Basic Crypto API methods (atcab_), 71 |
| ATCA ZONE MASK                         | atcab_aes_gcm_encrypt_update          |
| calib_command.h, 726                   |                                       |
|                                        | Basic Crypto API methods (atcab_), 72 |
| ATCA_ZONE_OTP                          | atcab_aes_gcm_init                    |
| cryptoauthlib.h, 820                   | Basic Crypto API methods (atcab_), 72 |
| ATCA_ZONE_READWRITE_32                 | atcab_aes_gcm_init_rand               |
| calib_command.h, 727                   | Basic Crypto API methods (atcab_), 73 |
| atcab_aes                              | atcab_aes_gfm                         |
| Basic Crypto API methods (atcab_), 60  | Basic Crypto API methods (atcab_), 73 |
| atcab_aes_cbc_decrypt_block            | atcab_b64rules_default                |
| Basic Crypto API methods (atcab_), 60  | atca_helpers.c, 603                   |
| atcab_aes_cbc_encrypt_block            | atca_helpers.h, 613                   |
| Basic Crypto API methods (atcab_), 61  | atcab_b64rules_mime                   |
| atcab_aes_cbc_encrypt_block_ext        | atca_helpers.c, 603                   |
| Basic Crypto API methods (atcab_), 61  | atca_helpers.h, 613                   |
| atcab_aes_cbc_init                     | atcab_b64rules_urlsafe                |
| Basic Crypto API methods (atcab_), 61  | atca_helpers.c, 603                   |

| atca_helpers.h, 613                   | Basic Crypto API methods (atcab_), 82 |
|---------------------------------------|---------------------------------------|
| atcab_base64decode                    | atcab_get_device_type                 |
| atca_helpers.c, 593                   | Basic Crypto API methods (atcab_), 82 |
| atca_helpers.h, 604                   | atcab_get_device_type_ext             |
| atcab_base64decode_                   | Basic Crypto API methods (atcab_), 82 |
| atca_helpers.c, 594                   | atcab_get_pubkey                      |
| atca_helpers.h, 605                   | Basic Crypto API methods (atcab_), 82 |
| atcab_base64encode                    | atcab_get_zone_size                   |
| atca_helpers.c, 594                   | Basic Crypto API methods (atcab_), 83 |
| atca_helpers.h, 605                   | atcab_hex2bin                         |
| atcab_base64encode_                   | atca_helpers.c, 596                   |
| atca_helpers.c, 595                   | atca_helpers.h, 607                   |
| atca_helpers.h, 606                   | atcab_hex2bin_                        |
| atcab_bin2hex                         | atca_helpers.c, 596                   |
| atca_helpers.c, 595                   | atca_helpers.h, 608                   |
| atca_helpers.h, 606                   | atcab_hmac                            |
| atcab_bin2hex_                        | Basic Crypto API methods (atcab_), 83 |
| atca_helpers.c, 595                   | atcab hw sha2 256                     |
| atca_helpers.h, 607                   | Basic Crypto API methods (atcab_), 84 |
| atcab_cfg_discover                    | atcab_hw_sha2_256_finish              |
| Basic Crypto API methods (atcab_), 59 | Basic Crypto API methods (atcab_), 84 |
| atcab_challenge                       | atcab_hw_sha2_256_init                |
| Basic Crypto API methods (atcab_), 74 | Basic Crypto API methods (atcab_), 84 |
| atcab challenge seed update           | atcab hw sha2 256 update              |
| Basic Crypto API methods (atcab_), 74 | Basic Crypto API methods (atcab_), 85 |
| atcab_checkmac                        | atcab_idle                            |
| Basic Crypto API methods (atcab_), 75 | Basic Crypto API methods (atcab_), 85 |
| atcab_cmp_config_zone                 | atcab_info                            |
| Basic Crypto API methods (atcab_), 75 | Basic Crypto API methods (atcab_), 85 |
| atcab_counter                         | atcab_info_base                       |
| Basic Crypto API methods (atcab_), 76 | Basic Crypto API methods (atcab_), 86 |
| atcab_counter_increment               | atcab_info_get_latch                  |
| Basic Crypto API methods (atcab_), 76 | Basic Crypto API methods (atcab ), 86 |
| atcab_counter_read                    | atcab_info_set_latch                  |
| Basic Crypto API methods (atcab_), 76 | Basic Crypto API methods (atcab_), 86 |
| atcab_derivekey                       | atcab init                            |
| Basic Crypto API methods (atcab_), 77 | Basic Crypto API methods (atcab_), 87 |
| atcab_ecdh                            | atcab_init_device                     |
| Basic Crypto API methods (atcab_), 77 | Basic Crypto API methods (atcab_), 87 |
| atcab_ecdh_base                       | atcab init ext                        |
| Basic Crypto API methods (atcab_), 78 | Basic Crypto API methods (atcab_), 88 |
| atcab_ecdh_enc                        | atcab_is_ca_device                    |
| Basic Crypto API methods (atcab_), 78 | Basic Crypto API methods (atcab_), 88 |
| atcab_ecdh_ioenc                      | atcab_is_config_locked                |
| Basic Crypto API methods (atcab_), 79 | Basic Crypto API methods (atcab_), 88 |
| atcab_ecdh_tempkey                    | atcab_is_data_locked                  |
| Basic Crypto API methods (atcab_), 79 | Basic Crypto API methods (atcab ), 89 |
| atcab_ecdh_tempkey_ioenc              | atcab_is_locked                       |
| Basic Crypto API methods (atcab_), 80 | Basic Crypto API methods (atcab_), 89 |
| atcab_gendig                          | atcab_is_slot_locked                  |
| Basic Crypto API methods (atcab_), 80 | Basic Crypto API methods (atcab_), 89 |
| atcab_genkey                          | atcab_is_ta_device                    |
| Basic Crypto API methods (atcab_), 81 | Basic Crypto API methods (atcab_), 90 |
| atcab_genkey_base                     | atcab_kdf                             |
| Basic Crypto API methods (atcab_), 81 | Basic Crypto API methods (atcab_), 90 |
| atcab_get_addr                        | atcab_lock                            |
| Basic Crypto API methods (atcab_), 59 | Basic Crypto API methods (atcab_), 91 |
| atcab_get_device                      | atcab_lock_config_zone                |
|                                       |                                       |

| Basic Crypto API methods (atcab_), 91 atcab_lock_config_zone_crc | Basic Crypto API methods (atcab_), 101 atcab selftest |
|------------------------------------------------------------------|-------------------------------------------------------|
| Basic Crypto API methods (atcab_), 91                            | Basic Crypto API methods (atcab_), 101                |
| atcab_lock_data_slot                                             | atcab sha                                             |
| Basic Crypto API methods (atcab_), 92                            | Basic Crypto API methods (atcab_), 102                |
| atcab_lock_data_zone                                             | atcab_sha_base                                        |
| Basic Crypto API methods (atcab_), 92                            | Basic Crypto API methods (atcab_), 102                |
| atcab_lock_data_zone_crc                                         | atcab_sha_end                                         |
| Basic Crypto API methods (atcab_), 92                            | Basic Crypto API methods (atcab_), 103                |
| atcab_mac                                                        | atcab sha hmac                                        |
| Basic Crypto API methods (atcab_), 93                            | Basic Crypto API methods (atcab_), 103                |
| atcab_memset_s                                                   | atcab_sha_hmac_finish                                 |
| atca_helpers.c, 597                                              | Basic Crypto API methods (atcab_), 104                |
| atca_helpers.h, 608                                              | atcab_sha_hmac_init                                   |
| atcab_nonce                                                      | Basic Crypto API methods (atcab_), 104                |
| Basic Crypto API methods (atcab_), 93                            | atcab_sha_hmac_update                                 |
| atcab_nonce_base                                                 | Basic Crypto API methods (atcab_), 104                |
| Basic Crypto API methods (atcab_), 94                            | atcab_sha_read_context                                |
| atcab_nonce_load                                                 | Basic Crypto API methods (atcab_), 105                |
| Basic Crypto API methods (atcab_), 94                            | atcab_sha_start                                       |
| atcab_nonce_rand                                                 | Basic Crypto API methods (atcab_), 105                |
| Basic Crypto API methods (atcab_), 95                            | atcab_sha_update                                      |
| atcab_printbin                                                   | Basic Crypto API methods (atcab_), 105                |
| Basic Crypto API methods (atcab_), 95                            | atcab sha write context                               |
| atcab_printbin_label                                             | Basic Crypto API methods (atcab_), 106                |
| atca_helpers.h, 608                                              | atcab_sign                                            |
| atcab_printbin_sp                                                | Basic Crypto API methods (atcab_), 106                |
| atca_helpers.h, 608                                              | atcab_sign_base                                       |
| atcab_priv_write                                                 | Basic Crypto API methods (atcab_), 107                |
| Basic Crypto API methods (atcab_), 95                            | atcab_sign_internal                                   |
| atcab_random                                                     | Basic Crypto API methods (atcab_), 107                |
| Basic Crypto API methods (atcab_), 96                            | atcab_sleep                                           |
| atcab_random_ext                                                 | Basic Crypto API methods (atcab_), 108                |
| Basic Crypto API methods (atcab_), 96                            | atcab_updateextra                                     |
| atcab_read_bytes_zone                                            | Basic Crypto API methods (atcab_), 108                |
| Basic Crypto API methods (atcab_), 96                            | atcab_verify                                          |
| atcab_read_config_zone                                           | Basic Crypto API methods (atcab_), 108                |
| Basic Crypto API methods (atcab_), 97                            | atcab_verify_extern                                   |
| atcab_read_enc                                                   | Basic Crypto API methods (atcab_), 109                |
| Basic Crypto API methods (atcab_), 97                            | atcab_verify_extern_mac                               |
| atcab_read_pubkey                                                | Basic Crypto API methods (atcab_), 110                |
| Basic Crypto API methods (atcab_), 98                            | atcab_verify_invalidate                               |
| atcab_read_serial_number                                         | Basic Crypto API methods (atcab_), 110                |
| Basic Crypto API methods (atcab_), 98                            | atcab_verify_stored                                   |
| atcab_read_sig                                                   | Basic Crypto API methods (atcab_), 111                |
| Basic Crypto API methods (atcab_), 99                            | atcab_verify_stored_mac                               |
| atcab_read_zone                                                  | Basic Crypto API methods (atcab_), 111                |
| Basic Crypto API methods (atcab_), 99                            | atcab_verify_validate                                 |
| atcab_release                                                    | Basic Crypto API methods (atcab_), 112                |
| Basic Crypto API methods (atcab_), 99                            | atcab_version                                         |
| atcab_release_ext                                                | Basic Crypto API methods (atcab_), 112                |
| Basic Crypto API methods (atcab_), 100                           | atcab_wakeup                                          |
| atcab_reversal                                                   | Basic Crypto API methods (atcab_), 113                |
| atca_helpers.c, 597                                              | atcab_write                                           |
| atca_helpers.h, 608                                              | Basic Crypto API methods (atcab_), 113                |
| atcab_secureboot                                                 | atcab_write_bytes_zone                                |
| Basic Crypto API methods (atcab_), 100                           | Basic Crypto API methods (atcab_), 113                |
| atcab_secureboot_mac                                             | atcab_write_config_counter                            |

| Basic Crypto API methods (atcab_), 114 | Software crypto methods (atcac_), 252             |
|----------------------------------------|---------------------------------------------------|
| atcab_write_config_zone                | atcac_sha256_hmac_init                            |
| Basic Crypto API methods (atcab_), 114 | Software crypto methods (atcac_), 252             |
| atcab_write_enc                        | atcac_sha256_hmac_update                          |
| Basic Crypto API methods (atcab_), 115 | Software crypto methods (atcac_), 253             |
| atcab_write_pubkey                     | atcac_sha2_256_ctx                                |
| Basic Crypto API methods (atcab_), 115 | atca_crypto_sw.h, 575                             |
| atcab_write_zone                       | atcac_sw_ecdsa_verify_p256                        |
| Basic Crypto API methods (atcab_), 116 | Software crypto methods (atcac_), 253             |
| atcac_aes_cmac_ctx                     | atcac_sw_random                                   |
| atca_crypto_sw.h, 575                  | Software crypto methods (atcac_), 253             |
| atcac_aes_cmac_finish                  | atcac_sw_sha1                                     |
| atca_crypto_sw.h, 576                  | Software crypto methods (atcac_), 254             |
| atca_mbedtls_wrap.c, 625               | atcac_sw_sha1_finish                              |
| atca_openssl_interface.c, 632          | atca_mbedtls_wrap.c, 629                          |
| atcac_aes_cmac_init                    | atca_openssl_interface.c, 636                     |
| atca_crypto_sw.h, 576                  | Software crypto methods (atcac_), 254             |
| atca_mbedtls_wrap.c, 625               | atcac_sw_sha1_init                                |
| atca_openssl_interface.c, 632          | Software crypto methods (atcac_), 254             |
| atcac_aes_cmac_update                  | atcac_sw_sha1_update                              |
| atca_crypto_sw.h, 576                  | Software crypto methods (atcac_), 255             |
| atca_mbedtls_wrap.c, 626               | atcac_sw_sha2_256                                 |
| atca_openssl_interface.c, 633          | Software crypto methods (atcac_), 255             |
| atcac_aes_gcm_aad_update               | atcac_sw_sha2_256_finish                          |
| atca_crypto_sw.h, 576                  | atca_mbedtls_wrap.c, 630                          |
| atca_mbedtls_wrap.c, 626               | atca_openssl_interface.c, 637                     |
| atca_openssl_interface.c, 633          | Software crypto methods (atcac_), 255             |
| atcac_aes_gcm_ctx                      | atcac_sw_sha2_256_init                            |
| atca_crypto_sw.h, 575                  | Software crypto methods (atcac_), 255             |
| atcac_aes_gcm_decrypt_finish           | atcac_sw_sha2_256_update                          |
| atca_crypto_sw.h, 577                  | Software crypto methods (atcac_), 256             |
| atca_mbedtls_wrap.c, 626               | atcacert.h, 641                                   |
| atca_openssl_interface.c, 634          | atcacert_build_state_s, 439                       |
| atcac_aes_gcm_decrypt_start            | cert, 439                                         |
| atca_crypto_sw.h, 577                  | cert_def, 440                                     |
| atca_mbedtls_wrap.c, 627               | cert_size, 440                                    |
| atca_openssl_interface.c, 634          | device_sn, 440                                    |
| atcac_aes_gcm_decrypt_update           | is_device_sn, 440                                 |
| atca_crypto_sw.h, 577                  | max_cert_size, 440                                |
| atca_mbedtls_wrap.c, 627               | atcacert_build_state_t                            |
| atca_openssl_interface.c, 634          | Certificate manipulation methods (atcacert_), 162 |
| atcac_aes_gcm_encrypt_finish           | atcacert_cert_build_finish                        |
| atca_crypto_sw.h, 578                  | Certificate manipulation methods (atcacert_), 168 |
| atca_mbedtls_wrap.c, 628               | atcacert_cert_build_process                       |
| atca_openssl_interface.c, 635          | Certificate manipulation methods (atcacert_), 168 |
| atcac_aes_gcm_encrypt_start            | atcacert_cert_build_start                         |
| atca_crypto_sw.h, 578                  | Certificate manipulation methods (atcacert_), 169 |
| atca_mbedtls_wrap.c, 628               | atcacert_cert_element_s, 441                      |
| atca_openssl_interface.c, 635          | cert_loc, 441                                     |
| atcac_aes_gcm_encrypt_update           | device_loc, 441                                   |
| atca_crypto_sw.h, 578                  | id, 441                                           |
| atca_mbedtls_wrap.c, 629               | transforms, 441                                   |
| atca_openssl_interface.c, 636          | atcacert_cert_element_t                           |
| atcac_hmac_sha256_ctx                  | Certificate manipulation methods (atcacert_), 162 |
| atca_crypto_sw.h, 575                  | atcacert_cert_loc_s, 442                          |
| atcac_sha1_ctx                         | count, 442                                        |
| atca_crypto_sw.h, 575                  | offset, 442                                       |
| atcac_sha256_hmac_finish               | atcacert_cert_loc_t                               |

| Certificate manipulation methods (atcacert_), 162 | atcacert_decode_pem_cert                          |
|---------------------------------------------------|---------------------------------------------------|
| atcacert_cert_sn_src_e                            | atcacert_pem.c, 659                               |
| Certificate manipulation methods (atcacert_), 164 | atcacert_pem.h, 663                               |
| atcacert_cert_sn_src_t                            | atcacert_decode_pem_csr                           |
| Certificate manipulation methods (atcacert_), 162 | atcacert_pem.c, 659                               |
| atcacert_cert_type_e                              | atcacert_pem.h, 664                               |
| Certificate manipulation methods (atcacert_), 165 | atcacert_def.c, 647                               |
| atcacert_cert_type_t                              | ATCACERT_MAX, 649                                 |
| Certificate manipulation methods (atcacert_), 162 | ATCACERT_MIN, 650                                 |
| atcacert_client.c, 642                            | atcacert_def.h, 650                               |
| atcacert_client.h, 643                            | ATCA MAX TRANSFORMS, 653                          |
| atcacert_create_csr                               | atcacert def s, 442                               |
| Certificate manipulation methods (atcacert_), 169 | ca_cert_def, 443                                  |
| atcacert_create_csr_pem                           | cert elements, 444                                |
| Certificate manipulation methods (atcacert_), 170 | cert_elements_count, 444                          |
| atcacert_date.c, 644                              | cert_sn_dev_loc, 444                              |
| atcacert_date.h, 645                              | cert_template, 444                                |
| atcacert date dec                                 | cert template size, 444                           |
| Certificate manipulation methods (atcacert_), 170 | chain_id, 444                                     |
| atcacert_date_dec_compcert                        | comp_cert_dev_loc, 445                            |
| Certificate manipulation methods (atcacert_), 171 | expire_date_format, 445                           |
| atcacert date dec iso8601 sep                     | expire_years, 445                                 |
| Certificate manipulation methods (atcacert_), 171 | issue_date_format, 445                            |
| atcacert_date_dec_posix_uint32_be                 | private_key_slot, 445                             |
| Certificate manipulation methods (atcacert_), 171 | public_key_dev_loc, 445                           |
| atcacert_date_dec_posix_uint32_le                 | sn_source, 446                                    |
| Certificate manipulation methods (atcacert_), 172 | std_cert_elements, 446                            |
| •                                                 |                                                   |
| atcacert_date_dec_rfc5280_gen                     | tbs_cert_loc, 446                                 |
| Certificate manipulation methods (atcacert_), 172 | template_id, 446                                  |
| atcacert_date_dec_rfc5280_utc                     | type, 446                                         |
| Certificate manipulation methods (atcacert_), 172 | atcacert_def_t                                    |
| atcacert_date_enc                                 | Certificate manipulation methods (atcacert_), 163 |
| Certificate manipulation methods (atcacert_), 172 | atcacert_der.c, 654                               |
| atcacert_date_enc_compcert                        | atcacert_der.h, 654                               |
| Certificate manipulation methods (atcacert_), 173 | atcacert_der_adjust_length                        |
| atcacert_date_enc_iso8601_sep                     | Certificate manipulation methods (atcacert_), 174 |
| Certificate manipulation methods (atcacert_), 173 | atcacert_der_dec_ecdsa_sig_value                  |
| atcacert_date_enc_posix_uint32_be                 | Certificate manipulation methods (atcacert_), 174 |
| Certificate manipulation methods (atcacert_), 173 | atcacert_der_dec_integer                          |
| atcacert_date_enc_posix_uint32_le                 | Certificate manipulation methods (atcacert_), 175 |
| Certificate manipulation methods (atcacert_), 173 | atcacert_der_dec_length                           |
| atcacert_date_enc_rfc5280_gen                     | Certificate manipulation methods (atcacert_), 176 |
| Certificate manipulation methods (atcacert_), 173 | atcacert_der_enc_ecdsa_sig_value                  |
| atcacert_date_enc_rfc5280_utc                     | Certificate manipulation methods (atcacert_), 176 |
| Certificate manipulation methods (atcacert_), 174 | atcacert_der_enc_integer                          |
| atcacert_date_format_e                            | Certificate manipulation methods (atcacert_), 177 |
| Certificate manipulation methods (atcacert_), 165 | atcacert_der_enc_length                           |
| ATCACERT_DATE_FORMAT_SIZES                        | Certificate manipulation methods (atcacert_), 177 |
| Certificate manipulation methods (atcacert_), 200 | atcacert_device_loc_s, 447                        |
| ATCACERT_DATE_FORMAT_SIZES_COUNT                  | count, 447                                        |
| Certificate manipulation methods (atcacert_), 158 | is_genkey, 447                                    |
| atcacert_date_format_t                            | offset, 447                                       |
| Certificate manipulation methods (atcacert_), 163 | slot, 447                                         |
| atcacert_date_get_max_date                        | zone, 448                                         |
| Certificate manipulation methods (atcacert_), 174 | atcacert_device_loc_t                             |
| atcacert_decode_pem                               | Certificate manipulation methods (atcacert_), 163 |
| atcacert_pem.c, 658                               | atcacert_device_zone_e                            |
| atcacert_pem.h, 663                               | Certificate manipulation methods (atcacert_), 166 |

| atcacert_device_zone_t                            | Certificate manipulation methods (atcacert_), 182 |
|---------------------------------------------------|---------------------------------------------------|
| Certificate manipulation methods (atcacert_), 163 | atcacert_get_issue_date                           |
| ATCACERT_E_BAD_CERT                               | Certificate manipulation methods (atcacert_), 183 |
| Certificate manipulation methods (atcacert_), 158 | atcacert_get_key_id                               |
| ATCACERT E BAD PARAMS                             | Certificate manipulation methods (atcacert_), 183 |
| Certificate manipulation methods (atcacert_), 159 | atcacert_get_response                             |
| ATCACERT_E_BUFFER_TOO_SMALL                       | Certificate manipulation methods (atcacert_), 184 |
| Certificate manipulation methods (atcacert_), 159 |                                                   |
|                                                   | atcacert_get_signature                            |
| ATCACERT_E_DECODING_ERROR                         | Certificate manipulation methods (atcacert_), 184 |
| Certificate manipulation methods (atcacert_), 159 | atcacert_get_signer_id                            |
| ATCACERT_E_ELEM_MISSING                           | Certificate manipulation methods (atcacert_), 185 |
| Certificate manipulation methods (atcacert_), 159 | atcacert_get_subj_key_id                          |
| ATCACERT_E_ELEM_OUT_OF_BOUNDS                     | Certificate manipulation methods (atcacert_), 185 |
| Certificate manipulation methods (atcacert_), 159 | atcacert_get_subj_public_key                      |
| ATCACERT_E_ERROR                                  | Certificate manipulation methods (atcacert_), 186 |
| Certificate manipulation methods (atcacert_), 159 | atcacert_get_tbs                                  |
| ATCACERT_E_INVALID_DATE                           | Certificate manipulation methods (atcacert_), 186 |
| Certificate manipulation methods (atcacert ), 160 | atcacert_get_tbs_digest                           |
| ATCACERT E INVALID TRANSFORM                      | Certificate manipulation methods (atcacert_), 187 |
| Certificate manipulation methods (atcacert_), 160 | atcacert_host_hw.c, 655                           |
| ATCACERT E SUCCESS                                | atcacert_host_hw.h, 656                           |
| Certificate manipulation methods (atcacert_), 160 | atcacert_host_sw.c, 656                           |
| ATCACERT E UNEXPECTED ELEM SIZE                   | atcacert_host_sw.h, 657                           |
| Certificate manipulation methods (atcacert_), 160 | atcacert is device loc overlap                    |
| •                                                 |                                                   |
| ATCACERT_E_UNIMPLEMENTED                          | Certificate manipulation methods (atcacert_), 187 |
| Certificate manipulation methods (atcacert_), 160 | ATCACERT_MAX                                      |
| ATCACERT_E_VERIFY_FAILED                          | atcacert_def.c, 649                               |
| Certificate manipulation methods (atcacert_), 160 | atcacert_max_cert_size                            |
| ATCACERT_E_WRONG_CERT_DEF                         | Certificate manipulation methods (atcacert_), 187 |
| Certificate manipulation methods (atcacert_), 161 | atcacert_merge_device_loc                         |
| atcacert_encode_pem                               | Certificate manipulation methods (atcacert_), 188 |
| atcacert_pem.c, 660                               | ATCACERT_MIN                                      |
| atcacert_pem.h, 664                               | atcacert_def.c, 650                               |
| atcacert_encode_pem_cert                          | atcacert_pem.c, 658                               |
| atcacert_pem.c, 660                               | atcacert_decode_pem, 658                          |
| atcacert_pem.h, 665                               | atcacert_decode_pem_cert, 659                     |
| atcacert_encode_pem_csr                           | atcacert_decode_pem_csr, 659                      |
| atcacert_pem.c, 661                               | atcacert_encode_pem, 660                          |
| atcacert_pem.h, 665                               | atcacert_encode_pem_cert, 660                     |
| atcacert_gen_cert_sn                              | atcacert_encode_pem_csr, 661                      |
| Certificate manipulation methods (atcacert_), 178 | atcacert pem.h, 661                               |
| atcacert_gen_challenge_hw                         | atcacert_decode_pem, 663                          |
| Certificate manipulation methods (atcacert_), 178 | atcacert_decode_pem_cert, 663                     |
| •                                                 |                                                   |
| atcacert_gen_challenge_sw                         | atcacert_decode_pem_csr, 664                      |
| Certificate manipulation methods (atcacert_), 179 | atcacert_encode_pem, 664                          |
| atcacert_get_auth_key_id                          | atcacert_encode_pem_cert, 665                     |
| Certificate manipulation methods (atcacert_), 179 | atcacert_encode_pem_csr, 665                      |
| atcacert_get_cert_element                         | PEM_CERT_BEGIN, 662                               |
| Certificate manipulation methods (atcacert_), 179 | PEM_CERT_END, 662                                 |
| atcacert_get_cert_sn                              | PEM_CSR_BEGIN, 662                                |
| Certificate manipulation methods (atcacert_), 180 | PEM_CSR_END, 663                                  |
| atcacert_get_comp_cert                            | atcacert_public_key_add_padding                   |
| Certificate manipulation methods (atcacert_), 180 | Certificate manipulation methods (atcacert_), 188 |
| atcacert_get_device_data                          | atcacert_public_key_remove_padding                |
| Certificate manipulation methods (atcacert_), 181 | Certificate manipulation methods (atcacert_), 189 |
| atcacert_get_device_locs                          | atcacert_read_cert                                |
| Certificate manipulation methods (atcacert_), 181 | Certificate manipulation methods (atcacert_), 189 |
| atcacert_get_expire_date                          | atcacert_read_cert_size                           |

| Certificate manipulation methods (atcacert_), 191 | deleteATCACommand, 122                                            |
|---------------------------------------------------|-------------------------------------------------------------------|
| atcacert_read_device_loc                          | initATCACommand, 123                                              |
| Certificate manipulation methods (atcacert_), 191 | newATCACommand, 123                                               |
| atcacert_read_subj_key_id                         | atcacustom                                                        |
| Certificate manipulation methods (atcacert_), 192 | ATCAlfaceCfg, 453                                                 |
| atcacert_set_auth_key_id                          | ATCADevice                                                        |
| Certificate manipulation methods (atcacert_), 192 | ATCADevice (atca_), 142                                           |
| atcacert_set_auth_key_id_raw                      | ATCADevice (atca_), 124                                           |
| Certificate manipulation methods (atcacert_), 192 | ATCA_AES_ENABLE_EN_MASK, 127                                      |
| atcacert_set_cert_element                         | ATCA_AES_ENABLE_EN_SHIFT, 127                                     |
| Certificate manipulation methods (atcacert_), 193 | ATCA_CHIP_MODE_CLK_DIV, 127                                       |
| atcacert_set_cert_sn                              | ATCA_CHIP_MODE_CLK_DIV_MASK, 127                                  |
| Certificate manipulation methods (atcacert_), 193 | ATCA_CHIP_MODE_CLK_DIV_SHIFT, 127                                 |
| atcacert_set_comp_cert                            | ATCA_CHIP_MODE_I2C_EXTRA_MASK, 127                                |
| Certificate manipulation methods (atcacert_), 194 | ATCA_CHIP_MODE_I2C_EXTRA_SHIFT, 127                               |
| atcacert_set_expire_date                          | ATCA_CHIP_MODE_TTL_EN_MASK, 128                                   |
| Certificate manipulation methods (atcacert_), 195 | ATCA_CHIP_MODE_TTL_EN_SHIFT, 128                                  |
| atcacert_set_issue_date                           | ATCA_CHIP_MODE_WDG_LONG_MASK, 128                                 |
| Certificate manipulation methods (atcacert_), 195 | ATCA_CHIP_MODE_WDG_LONG_SHIFT, 128                                |
| atcacert_set_signature                            | ATCA_CHIP_OPT_ECDH_PROT, 128                                      |
| Certificate manipulation methods (atcacert_), 196 | ATCA_CHIP_OPT_ECDH_PROT_MASK, 128                                 |
| atcacert_set_signer_id                            | ATCA_CHIP_OPT_ECDH_PROT_SHIFT, 128                                |
| Certificate manipulation methods (atcacert_), 196 | ATCA_CHIP_OPT_IO_PROT_EN_MASK, 129                                |
| atcacert_set_subj_public_key                      | ATCA_CHIP_OPT_IO_PROT_EN_SHIFT, 129                               |
| Certificate manipulation methods (atcacert_), 197 | ATCA_CHIP_OPT_IO_PROT_KEY, 129                                    |
| atcacert_std_cert_element_e                       | ATCA_CHIP_OPT_IO_PROT_KEY_MASK, 129                               |
| Certificate manipulation methods (atcacert_), 166 | ATCA_CHIP_OPT_IO_PROT_KEY_SHIFT, 129                              |
| atcacert_std_cert_element_t                       | ATCA_CHIP_OPT_KDF_AES_EN_MASK, 129                                |
| Certificate manipulation methods (atcacert_), 163 | ATCA_CHIP_OPT_KDF_AES_EN_SHIFT, 129                               |
| atcacert_tm_utc_s, 448                            | ATCA_CHIP_OPT_KDF_PROT, 130                                       |
| tm_hour, 448                                      | ATCA_CHIP_OPT_KDF_PROT_MASK, 130                                  |
| tm_mday, 448                                      | ATCA_CHIP_OPT_KDF_PROT_SHIFT, 130 ATCA_CHIP_OPT_POST_EN_MASK, 130 |
| tm_min, 448<br>tm_mon, 449                        | ATCA_CHIP_OPT_POST_EN_MASK, 130 ATCA_CHIP_OPT_POST_EN_SHIFT, 130  |
| tm_non, 449<br>tm_sec, 449                        | ATCA_COUNTER_MATCH_EN_MASK, 130                                   |
| tm_year, 449                                      | ATCA_COUNTER_MATCH_EN_SHIFT, 130                                  |
| atcacert_tm_utc_t                                 | ATCA_COUNTER_MATCH_EN_3fill*1, 130  ATCA_COUNTER_MATCH_KEY, 131   |
| Certificate manipulation methods (atcacert_), 163 | ATCA_COUNTER_MATCH_KEY_MASK, 131                                  |
| atcacert_transform_data                           | ATCA_COUNTER_MATCH_KEY_SHIFT, 131                                 |
| Certificate manipulation methods (atcacert_), 197 | ATCA_DEV_UNKNOWN, 143                                             |
| atcacert_transform_e                              | ATCA_I2C_ENABLE_EN_MASK, 131                                      |
| Certificate manipulation methods (atcacert_), 166 | ATCA_I2C_ENABLE_EN_SHIFT, 131                                     |
| atcacert_transform_t                              | ATCA_KEY_CONFIG_AUTH_KEY, 131                                     |
| Certificate manipulation methods (atcacert_), 163 | ATCA_KEY_CONFIG_AUTH_KEY_MASK, 131                                |
| atcacert_verify_cert_hw                           | ATCA_KEY_CONFIG_AUTH_KEY_SHIFT, 132                               |
| Certificate manipulation methods (atcacert_), 198 | ATCA_KEY_CONFIG_KEY_TYPE, 132                                     |
| atcacert_verify_cert_sw                           | ATCA_KEY_CONFIG_KEY_TYPE_MASK, 132                                |
| Certificate manipulation methods (atcacert_), 198 | ATCA_KEY_CONFIG_KEY_TYPE_SHIFT, 132                               |
| atcacert_verify_response_hw                       | ATCA_KEY_CONFIG_LOCKABLE_MASK, 132                                |
| Certificate manipulation methods (atcacert_), 199 | ATCA_KEY_CONFIG_LOCKABLE_SHIFT, 132                               |
| atcacert_verify_response_sw                       | ATCA_KEY_CONFIG_PERSIST_DISABLE_MASK                              |
| Certificate manipulation methods (atcacert_), 199 | 132                                                               |
| atcacert_write_cert                               | ATCA_KEY_CONFIG_PERSIST_DISABLE_SHIFT                             |
| Certificate manipulation methods (atcacert_), 200 | 133                                                               |
| ATCACommand                                       | ATCA_KEY_CONFIG_PRIVATE_MASK, 133                                 |
| ATCACommand (atca_), 122                          | ATCA_KEY_CONFIG_PRIVATE_SHIFT, 133                                |
| ATCACommand (atca_), 122                          | ATCA_KEY_CONFIG_PUB_INFO_MASK, 133                                |
| ATCACommand, 122                                  | ATCA_KEY_CONFIG_PUB_INFO_SHIFT, 133                               |
|                                                   |                                                                   |

| ATCA_KEY_CONFIG_REQ_AUTH_MASK, 133     | 139                                                           |
|----------------------------------------|---------------------------------------------------------------|
| ATCA_KEY_CONFIG_REQ_AUTH_SHIFT, 133    | ATCA_SLOT_CONFIG_WRITE_ECDH_MASK,                             |
| ATCA_KEY_CONFIG_REQ_RANDOM_MASK,       | 140                                                           |
| 133                                    | ATCA_SLOT_CONFIG_WRITE_ECDH_SHIFT,                            |
| ATCA_KEY_CONFIG_REQ_RANDOM_SHIFT,      | 140                                                           |
| 134                                    | ATCA_SLOT_CONFIG_WRITE_KEY, 140                               |
| ATCA_KEY_CONFIG_RFU_MASK, 134          | ATCA_SLOT_CONFIG_WRITE_KEY_MASK, 140                          |
| ATCA_KEY_CONFIG_RFU_SHIFT, 134         | ATCA_SLOT_CONFIG_WRITE_KEY_SHIFT, 140                         |
| ATCA_KEY_CONFIG_X509_ID, 134           | ATCA SLOT LOCKED, 140                                         |
| ATCA KEY CONFIG X509 ID MASK, 134      | ATCA USE LOCK ENABLE MASK, 140                                |
| ATCA_KEY_CONFIG_X509_ID_SHIFT, 134     | ATCA_USE_LOCK_ENABLE_SHIFT, 141                               |
| ATCA PACKED, 134                       | ATCA_USE_LOCK_KEY_MASK, 141                                   |
| ATCA_SECURE_BOOT_DIGEST, 135           | ATCA_USE_LOCK_KEY_SHIFT, 141                                  |
| ATCA_SECURE_BOOT_DIGEST_MASK, 135      | ATCA_VOL_KEY_PERM_EN_MASK, 141                                |
| ATCA_SECURE_BOOT_DIGEST_SHIFT, 135     | ATCA_VOL_KEY_PERM_EN_SHIFT, 141                               |
| ATCA SECURE BOOT MODE, 135             | ATCA_VOL_KEY_PERM_SLOT, 141                                   |
| ATCA SECURE BOOT MODE MASK, 135        | ATCA_VOL_KEY_PERM_SLOT, 141  ATCA_VOL_KEY_PERM_SLOT_MASK, 141 |
|                                        |                                                               |
| ATCA_SECURE_BOOT_MODE_SHIFT, 135       | ATCA_VOL_KEY_PERM_SLOT_SHIFT, 142                             |
| ATCA_SECURE_BOOT_PERSIST_EN_MASK,      | ATCADevice, 142                                               |
| 135                                    | ATCADeviceType, 142                                           |
| ATCA_SECURE_BOOT_PERSIST_EN_SHIFT,     | ATECC108A, 143                                                |
| 136                                    | ATECC508A, 143                                                |
| ATCA_SECURE_BOOT_PUB_KEY, 136          | atecc508a_config_t, 142                                       |
| ATCA_SECURE_BOOT_PUB_KEY_MASK, 136     | ATECC608, 143                                                 |
| ATCA_SECURE_BOOT_PUB_KEY_SHIFT, 136    | atecc608_config_t, 142                                        |
| ATCA_SECURE_BOOT_RAND_NONCE_MASK,      | ATECC608A, 143                                                |
| 136                                    | ATECC608B, 143                                                |
| ATCA_SECURE_BOOT_RAND_NONCE_SHIFT,     | atGetCommands, 143                                            |
| 136                                    | atGetIFace, 143                                               |
| ATCA_SLOT_CONFIG_ECDH_MASK, 136        | ATSHA204A, 143                                                |
| ATCA_SLOT_CONFIG_ECDH_SHIFT, 137       | atsha204a_config_t, 142                                       |
| ATCA_SLOT_CONFIG_ENCRYPTED_READ_MASI   | K, ATSHA206A, 143                                             |
| 137                                    | deleteATCADevice, 144                                         |
| ATCA_SLOT_CONFIG_ENCRYPTED_READ_SHIF   | T, initATCADevice, 144                                        |
| 137                                    | newATCADevice, 144                                            |
| ATCA_SLOT_CONFIG_EXT_SIG_MASK, 137     | releaseATCADevice, 145                                        |
| ATCA_SLOT_CONFIG_EXT_SIG_SHIFT, 137    | TA100, 143                                                    |
| ATCA_SLOT_CONFIG_GEN_KEY_MASK, 137     | ATCADeviceType                                                |
| ATCA SLOT CONFIG GEN KEY SHIFT, 137    | ATCADevice (atca_), 142                                       |
| ATCA_SLOT_CONFIG_INT_SIG_MASK, 137     | atcah_check_mac                                               |
| ATCA_SLOT_CONFIG_INT_SIG_SHIFT, 138    | Host side crypto methods (atcah_), 312                        |
| ATCA SLOT CONFIG IS SECRET MASK, 138   | atcah_config_to_sign_internal                                 |
| ATCA_SLOT_CONFIG_IS_SECRET_SHIFT, 138  | Host side crypto methods (atcah_), 312                        |
| ATCA SLOT CONFIG LIMITED USE MASK,     | atcah_decrypt                                                 |
| 138                                    | Host side crypto methods (atcah_), 313                        |
| ATCA SLOT CONFIG LIMITED USE SHIFT,    | atcah_derive_key                                              |
| 138                                    | Host side crypto methods (atcah_), 313                        |
| ATCA SLOT CONFIG NOMAC MASK, 138       | atcah derive key mac                                          |
| ATCA SLOT CONFIG NOMAC SHIFT, 138      | Host side crypto methods (atcah_), 314                        |
| ATCA_SLOT_CONFIG_PRIV_WRITE_MASK, 138  | atcah_encode_counter_match                                    |
| ATCA SLOT CONFIG PRIV WRITE SHIFT, 139 |                                                               |
|                                        | Host side crypto methods (atcah_), 314                        |
| ATCA_SLOT_CONFIG_READKEY, 139          | atcah_gen_dig                                                 |
| ATCA_SLOT_CONFIG_READKEY_MASK, 139     | Host side crypto methods (atcah_), 315                        |
| ATCA_SLOT_CONFIG_READKEY_SHIFT, 139    | atcah_gen_key_msg                                             |
| ATCA_SLOT_CONFIG_WRITE_CONFIG, 139     | Host side crypto methods (atcah_), 315                        |
| ATCA_SLOT_CONFIG_WRITE_CONFIG_MASK,    | atcah_gen_mac                                                 |
| 139                                    | Host side crypto methods (atcah_), 316                        |
| ATCA_SLOT_CONFIG_WRITE_CONFIG_SHIFT,   | atcah_hmac                                                    |

| Host side crypto methods (atcah_), 316                       | ATCA_SPI_IFACE, 147            |
|--------------------------------------------------------------|--------------------------------|
| atcah_include_data                                           | ATCA_SWI_IFACE, 147            |
| Host side crypto methods (atcah_), 316                       | ATCA_UART_IFACE, 147           |
| atcah_io_decrypt                                             | ATCA_UNKNOWN_IFACE, 147        |
| Host side crypto methods (atcah_), 317                       | ATCANA                         |
| atcah_mac                                                    | ATCAI/itime 147                |
| Host side crypto methods (atcah_), 317                       | ATCAKitType, 147               |
| atcah_nonce                                                  | atgetifacecfg, 148             |
| Host side crypto methods (atcah_), 318                       | atgetifacehaldat, 148          |
| atcah_privwrite_auth_mac                                     | atidle, 148                    |
| Host side crypto methods (atcah_), 318                       | atinit, 149<br>atpostinit, 149 |
| atcah_secureboot_enc  Host side crypto methods (atcah_), 318 | atreceive, 149                 |
| atcah_secureboot_mac                                         | atsend, 150                    |
| Host side crypto methods (atcah_), 319                       | atsleep, 150                   |
| atcah_sha256                                                 | atwake, 150                    |
| Host side crypto methods (atcah_), 319                       | deleteATCAlface, 151           |
| atcah sign internal msg                                      | initATCAlface, 151             |
| Host side crypto methods (atcah ), 319                       | newATCAlface, 151              |
| atcah_verify_mac                                             | releaseATCAlface, 152          |
| Host side crypto methods (atcah_), 320                       | ATCAlfaceCfg, 452              |
| atcah write auth mac                                         | atcacustom, 453                |
| Host side crypto methods (atcah_), 320                       | atcabid, 453                   |
| ATCAHAL_t, 449                                               | atcaild, 453                   |
| hal_data, 450                                                | atcaspi, 454                   |
| halidle, 450                                                 | atcaswi, 454                   |
| halinit, 450                                                 | atcaswi, 454                   |
| halpostinit, 450                                             |                                |
| •                                                            | baud, 454                      |
| halreceive, 450                                              | bus, 454                       |
| halrelease, 450                                              | cfg_data, 454                  |
| halsend, 450                                                 | dev_identity, 454              |
| halsleep, 450                                                | dev_interface, 454             |
| halwake, 451                                                 | devtype, 455                   |
| atcahid                                                      | halidle, 455                   |
| ATCAlfaceCfg, 453                                            | halinit, 455                   |
| atcai2c                                                      | halpostinit, 455               |
| ATCAlfaceCfg, 453                                            | halreceive, 455                |
| atcal2Cmaster, 451                                           | halrelease, 455                |
| bus_index, 451                                               | halsend, 455                   |
| i2c_file, 451                                                | halsleep, 455                  |
| id, 451                                                      | halwake, 456                   |
| ref_ct, 452                                                  | idx, 456                       |
| twi_id, 452                                                  | iface_type, 456                |
| twi_master_instance, 452                                     | packetsize, 456                |
| ATCAI2CMaster_t                                              | parity, 456                    |
| hal_esp32_i2c.c, 830                                         | pid, 456                       |
| Hardware abstraction layer (hal_), 266                       | port, 456                      |
| ATCAlface                                                    | rx_retries, 456                |
| ATCAlface (atca_), 147                                       | select_pin, 457                |
| ATCAlface (atca_), 146                                       | slave_address, 457             |
| ATCA_CUSTOM_IFACE, 147                                       | stopbits, 457                  |
| ATCA_HID_IFACE, 147                                          | vid, 457                       |
| ATCA_I2C_IFACE, 147                                          | wake_delay, 457                |
| ATCA_KIT_AUTO_IFACE, 147                                     | wordsize, 457                  |
| ATCA_KIT_I2C_IFACE, 147                                      | ATCAlfaceType                  |
| ATCA_KIT_SPI_IFACE, 147                                      | ATCAlface (atca_), 147         |
| ATCA_KIT_SWI_IFACE, 147                                      | ATCAKitType                    |
| ATCA_KIT_UNKNOWN_IFACE, 147                                  | ATCAlface (atca_), 147         |

| atCalcCrc                                 | ATCADevice (atca_), 143 |
|-------------------------------------------|-------------------------|
| calib_command.c, 681                      | ATECC608B               |
| calib_command.h, 783                      | ATCADevice (atca_), 143 |
| ATCAPacket, 457                           | atECDH                  |
| _reserved, 458                            | calib_command.c, 684    |
| data, 458                                 | calib_command.h, 785    |
| execTime, 458                             | atGenDig                |
| opcode, 458                               | calib_command.c, 684    |
| param1, 458                               | calib_command.h, 785    |
| param2, 458                               | atGenKey                |
| txsize, 459                               | calib_command.c, 684    |
| atcaspi                                   | calib_command.h, 786    |
| ATCAlfaceCfg, 454                         | atGetCommands           |
| atcaSPImaster, 459                        | ATCADevice (atca_), 143 |
| ref_ct, 459                               | atGetlFace              |
| spi_file, 459                             | ATCADevice (atca_), 143 |
| ATCASPIMaster_t                           | atgetifacecfg           |
| Hardware abstraction layer (hal_), 266    | ATCAlface (atca_), 148  |
| atcaswi                                   | atgetifacehaldat        |
| ATCAlfaceCfg, 454                         | ATCAlface (atca_), 148  |
| atcaSWImaster, 459                        | atHMAC                  |
| bus_index, 460                            | calib_command.c, 685    |
| ref_ct, 460                               | calib_command.h, 786    |
| sercom_core_freq, 460                     | atidle                  |
| usart_instance, 460                       | atca_iface, 420         |
| USART_SWI, 460                            | ATCAlface (atca_), 148  |
| ATCASWIMaster t                           | atInfo                  |
| Hardware abstraction layer (hal_), 266    | calib_command.c, 685    |
| atcauart                                  | calib_command.h, 786    |
| ATCAlfaceCfg, 454                         | atinit                  |
| atCheckCrc                                | atca_iface, 421         |
| calib_command.c, 682                      | ATCAlface (atca_), 149  |
| calib_command.h, 783                      | atIsECCFamily           |
| atCheckMAC                                | calib_command.c, 685    |
| calib_command.c, 682                      | calib_command.h, 787    |
| calib_command.h, 783                      | atIsSHAFamily           |
| atCounter                                 | calib_command.c, 686    |
| calib_command.c, 682                      | calib_command.h, 787    |
| calib_command.h, 784                      | atKDF                   |
| atCRC                                     | calib_command.c, 686    |
| calib_command.c, 683                      | calib command.h, 788    |
| calib_command.h, 784                      | atLock                  |
| atDeriveKey                               | calib_command.c, 687    |
| calib_command.c, 683                      | calib_command.h, 788    |
| calib_command.h, 784                      | atMAC                   |
| ATECC108A                                 | calib_command.c, 687    |
| ATCADevice (atca_), 143                   | calib_command.h, 788    |
| ATECC508A                                 | atNonce                 |
| ATCADevice (atca_), 143                   | calib_command.c, 687    |
| atecc508a_config_t                        | calib_command.h, 789    |
| ATCADevice (atca_), 142                   | atPause                 |
| ATECC608                                  | calib_command.c, 688    |
| ATCADevice (atca_), 143                   | calib_command.h, 789    |
| atecc608_config                           | atpostinit              |
| example_pkcs11_config.c, 826              |                         |
|                                           | •                       |
|                                           | atca_iface, 421         |
| atecc608_config_t ATCADevice (atca_), 142 | •                       |

| calib command b 780              | C DigestFinal, 341                    |
|----------------------------------|---------------------------------------|
| calib_command.h, 789<br>atRandom | C_Digest Irial, 341 C_DigestInit, 341 |
|                                  | C_Digestiffit, 341 C DigestKey, 342   |
| calib_command.c, 688             | — • • ·                               |
| calib_command.h, 790             | C_DigestUpdate, 342                   |
| atRead                           | C_Encrypt, 342                        |
| calib_command.c, 689             | C_EncryptFinal, 342                   |
| calib_command.h, 790             | C_EncryptInit, 342                    |
| atreceive                        | C_EncryptUpdate, 343                  |
| atca_iface, 421                  | C_Finalize, 343                       |
| ATCAlface (atca_), 149           | C_FindObjects, 343                    |
| atSecureBoot                     | C_FindObjectsFinal, 343               |
| calib_command.c, 689             | C_FindObjectsInit, 343                |
| calib_command.h, 791             | C_GenerateKey, 344                    |
| atSelfTest                       | C_GenerateKeyPair, 344                |
| calib_command.c, 690             | C_GenerateRandom, 344                 |
| calib_command.h, 791             | C_GetAttributeValue, 344              |
| atsend                           | C_GetFunctionList, 345                |
| atca_iface, 421                  | C_GetFunctionStatus, 345              |
| ATCAlface (atca_), 150           | C_GetInfo, 345                        |
| atSHA                            | C_GetMechanismInfo, 345               |
| calib_command.c, 690             | C_GetMechanismList, 345               |
| calib_command.h, 791             | C_GetObjectSize, 346                  |
| ATSHA204A                        | C_GetOperationState, 346              |
| ATCADevice (atca_), 143          | C_GetSessionInfo, 346                 |
| atsha204a_config_t               | C_GetSlotInfo, 346                    |
| ATCADevice (atca_), 142          | C_GetSlotList, 346                    |
| ATSHA206A                        | C_GetTokenInfo, 347                   |
| ATCADevice (atca_), 143          | C_Initialize, 347                     |
| atSign                           | C_InitPIN, 347                        |
| calib_command.c, 690             | C_InitToken, 347                      |
| calib_command.h, 793             | C_Login, 347                          |
| atsleep                          | C_Logout, 348                         |
| atca_iface, 421                  | C_OpenSession, 348                    |
| ATCAlface (atca_), 150           | C_SeedRandom, 348                     |
| attrib count                     | C SetAttributeValue, 348              |
| _pkcs11_session_ctx, 398         | C_SetOperationState, 349              |
| attrib f                         | C SetPIN, 349                         |
| pkcs11_attrib.h, 893             | C_Sign, 349                           |
| attrib_list                      | C_SignEncryptUpdate, 349              |
| _pkcs11_session_ctx, 398         | C_SignFinal, 350                      |
| attributes                       | C_SignInit, 350                       |
| _pkcs11_object, 395              | C SignRecover, 350                    |
| Attributes (pkcs11_attrib_), 330 | C_SignRecoverInit, 350                |
| C_CancelFunction, 338            | C_SignUpdate, 351                     |
| C CloseAllSessions, 338          | C_UnwrapKey, 351                      |
| C_CloseSession, 338              | C Verify, 351                         |
| C_CopyObject, 338                | C VerifyFinal, 351                    |
| C_CreateObject, 338              | C_VerifyInit, 352                     |
| C_Decrypt, 339                   | C_VerifyRecover, 352                  |
| C_DecryptDigestUpdate, 339       | C_VerifyRecoverInit, 352              |
| C_DecryptFinal, 339              | C_VerifyUpdate, 352                   |
| C_DecryptInit, 339               | C_WaitForSlotEvent, 352               |
|                                  |                                       |
| C_DecryptUpdate, 340             | C_WrapKey, 353                        |
| C_DecryptVerifyUpdate, 340       | PCKS11_MECH_ECC508_EC_CAPABILITY, 337 |
| C_DeriveKey, 340                 | pcks11_mech_table_e, 337              |
| C_DestroyObject, 340             | pcks11_mech_table_ptr, 337            |
| C_Digest, 341                    | pkcs11_attrib_empty, 353              |
| C_DigestEncryptUpdate, 341       | pkcs11_attrib_false, 353              |

| pkcs11_attrib_fill, 353                             | pkcs11_object_get_class, 360                                    |
|-----------------------------------------------------|-----------------------------------------------------------------|
| pkcs11_attrib_true, 353                             | pkcs11_object_get_destroyable, 361                              |
| pkcs11_attrib_value, 354                            | pkcs11_object_get_handle, 361                                   |
| pkcs11_cert_get_authority_key_id, 354               | pkcs11_object_get_name, 361                                     |
| pkcs11_cert_get_encoded, 354                        | pkcs11_object_get_size, 361                                     |
| pkcs11_cert_get_subject, 354                        | pkcs11_object_get_type, 361                                     |
| pkcs11_cert_get_subject_key_id, 354                 | pkcs11_object_load_handle_info, 361                             |
| pkcs11_cert_get_trusted_flag, 354                   | pkcs11_object_monotonic_attributes, 371                         |
| pkcs11_cert_get_type, 355                           | pkcs11_object_monotonic_attributes_count, 372                   |
| pkcs11_cert_wtlspublic_attributes, 369              | pkcs11_os_create_mutex, 362                                     |
| pkcs11_cert_wtlspublic_attributes_count, 369        | pkcs11_os_destroy_mutex, 362                                    |
| pkcs11_cert_x509_attributes, 369                    | pkcs11_os_lock_mutex, 362                                       |
| pkcs11_cert_x509_attributes_count, 369              | pkcs11_os_unlock_mutex, 362                                     |
| pkcs11_cert_x509_write, 355                         | pkcs11_session_check, 362                                       |
| pkcs11_cert_x509public_attributes, 369              | pkcs11_session_close, 362                                       |
| pkcs11_cert_x509public_attributes_count, 369        | pkcs11_session_closeall, 363                                    |
| pkcs11_config_cert, 355                             | pkcs11_session_get_info, 363                                    |
| pkcs11_config_init_cert, 355                        | pkcs11_session_login, 363                                       |
| pkcs11_config_init_private, 355                     | pkcs11_session_logout, 363                                      |
| pkcs11_config_init_public, 355                      | pkcs11_session_open, 363                                        |
| pkcs11_config_key, 356                              | pkcs11_signature_sign, 363                                      |
| pkcs11_config_load, 356                             | pkcs11_signature_sign_continue, 364                             |
| pkcs11_config_load_objects, 356                     | pkcs11_signature_sign_finish, 364                               |
| pkcs11_config_remove_object, 356                    | pkcs11_signature_sign_init, 364                                 |
| pkcs11_deinit, 356                                  | pkcs11_signature_verify, 364                                    |
| pkcs11_find_continue, 356                           | pkcs11_signature_verify_continue, 365                           |
| pkcs11_find_finish, 357                             | pkcs11_signature_verify_finish, 365                             |
| pkcs11_find_get_attribute, 357                      | pkcs11_signature_verify_init, 365                               |
| pkcs11_find_init, 357                               | pkcs11_slot_config, 365                                         |
| pkcs11_get_context, 357                             | pkcs11_slot_get_context, 365                                    |
| pkcs11_get_lib_info, 357                            | pkcs11_slot_get_info, 366                                       |
| pkcs11_get_ind, 357 pkcs11_get_session_context, 357 | pkcs11_slot_get_list, 366                                       |
| pkcs11_init, 358                                    | pkcs11_slot_get_list, 300<br>pkcs11_slot_init, 366              |
| pkcs11_init_check, 358                              | pkcs11_slot_initslots, 366                                      |
| pkcs11 key derive, 358                              | pkcs11_slot_initslots, 366 pkcs11_token_convert_pin_to_key, 366 |
|                                                     | . – – – – .                                                     |
| pkcs11_key_ec_private_attributes, 369               | pkcs11_token_get_access_type, 366                               |
| pkcs11_key_ec_public_attributes, 370                | pkcs11_token_get_info, 367<br>pkcs11_token_get_storage, 367     |
| pkcs11_key_generate_pair, 358                       |                                                                 |
| pkcs11_key_private_attributes, 370                  | pkcs11_token_get_writable, 367                                  |
| pkcs11_key_private_attributes_count, 370            | pkcs11_token_init, 367                                          |
| pkcs11_key_public_attributes, 370                   | pkcs11_token_random, 367                                        |
| pkcs11_key_public_attributes_count, 370             | pkcs11_token_set_pin, 367                                       |
| pkcs11_key_rsa_private_attributes, 370              | pkcs11_unlock_context, 368                                      |
| pkcs11_key_secret_attributes, 371                   | pkcs11_util_convert_rv, 368                                     |
| pkcs11_key_secret_attributes_count, 371             | pkcs11_util_escape_string, 368                                  |
| pkcs11_key_write, 359                               | pkcs11_util_memset, 368                                         |
| pkcs11_lib_description, 371                         | pkcs_mech_get_info, 368                                         |
| pkcs11_lib_manufacturer_id, 371                     | TABLE_SIZE, 337                                                 |
| pkcs11_lock_context, 359                            | atUpdateExtra                                                   |
| pkcs11_mech_get_list, 359                           | calib_command.c, 691                                            |
| pkcs11_object_alloc, 359                            | calib_command.h, 793                                            |
| pkcs11_object_cache, 371                            | atVerify                                                        |
| pkcs11_object_check, 359                            | calib_command.c, 691                                            |
| pkcs11_object_create, 360                           | calib_command.h, 793                                            |
| pkcs11_object_deinit, 360                           | atwake                                                          |
| pkcs11_object_destroy, 360                          | atca_iface, 421                                                 |
| pkcs11_object_find, 360                             | ATCAlface (atca_), 150                                          |
| pkcs11_object_free, 360                             | atWrite                                                         |

| calib_command.c, 692                                        | atcab_counter_read, 76         |
|-------------------------------------------------------------|--------------------------------|
| calib_command.h, 794                                        | atcab_derivekey, 77            |
| auth_mac                                                    | atcab_ecdh, 77                 |
|                                                             |                                |
| atca_write_mac_in_out, 438                                  | atcab_ecdh_base, 78            |
| B64 IS EQUAL                                                | atcab_ecdh_enc, 78             |
| atca_helpers.c, 593                                         | atcab_ecdh_ioenc, 79           |
| B64 IS INVALID                                              | atcab_ecdh_tempkey, 79         |
| <del></del>                                                 | atcab_ecdh_tempkey_ioenc, 80   |
| atca_helpers.c, 593<br>base64Char                           | atcab_gendig, 80               |
|                                                             | atcab_genkey, 81               |
| atca_helpers.c, 597                                         | atcab_genkey_base, 81          |
| atca_helpers.h, 609                                         | atcab_get_addr, 59             |
| base64Index                                                 | atcab_get_device, 82           |
| atca_helpers.c, 599                                         | atcab_get_device_type, 82      |
| atca_helpers.h, 609                                         | atcab_get_device_type_ext, 82  |
| Basic Crypto API methods (atcab_), 51                       | atcab_get_pubkey, 82           |
| _atcab_exit, 60                                             | atcab_get_zone_size, 83        |
| _gDevice, 120                                               | atcab_hmac, 83                 |
| atca_aes_gcm_ctx_t, 59                                      | atcab_hw_sha2_256, 84          |
| ATCA_AES_GCM_IV_STD_LENGTH, 59                              | atcab hw sha2 256 finish, 84   |
| atca_basic_aes_gcm_version, 120                             | atcab_hw_sha2_256_init, 84     |
| atca_execute_command, 59                                    |                                |
| atcab_aes, 60                                               | atcab_hw_sha2_256_update, 85   |
| atcab_aes_cbc_decrypt_block, 60                             | atcab_idle, 85                 |
| atcab_aes_cbc_encrypt_block, 61                             | atcab_info, 85                 |
| atcab_aes_cbc_encrypt_block_ext, 61                         | atcab_info_base, 86            |
| atcab_aes_cbc_init, 61                                      | atcab_info_get_latch, 86       |
| atcab_aes_cbc_init_ext, 62                                  | atcab_info_set_latch, 86       |
| atcab_aes_cmac_finish, 62                                   | atcab_init, 87                 |
| atcab_aes_cmac_init, 63                                     | atcab_init_device, 87          |
| atcab_aes_cmac_init_ext, 63                                 | atcab_init_ext, 88             |
| atcab_aes_cmac_update, 64                                   | atcab_is_ca_device, 88         |
| atcab_aes_ctr_block, 64                                     | atcab_is_config_locked, 88     |
| atcab_aes_ctr_decrypt_block, 64                             | atcab_is_data_locked, 89       |
| atcab_aes_ctr_encrypt_block, 65                             | atcab_is_locked, 89            |
| atcab_aes_ctr_increment, 65                                 | atcab_is_slot_locked, 89       |
| atcab_aes_ctr_init, 66                                      | atcab is ta device, 90         |
| atcab_aes_ctr_init_ext, 66                                  | atcab kdf, 90                  |
| atcab_aes_ctr_init_ext, 60 atcab_aes_ctr_init_rand, 67      | atcab_lock, 91                 |
| atcab_aes_ctr_init_rand, 67 atcab_aes_ctr_init_rand_ext, 67 | atcab_lock_config_zone, 91     |
| atcab_aes_cti_init_rand_ext, 07 atcab aes decrypt, 68       | atcab_lock_config_zone_crc, 91 |
|                                                             | atcab_lock_data_slot, 92       |
| atcab_aes_decrypt_ext, 68                                   | atcab_lock_data_zone, 92       |
| atcab_aes_encrypt, 69                                       | atcab lock data zone crc, 92   |
| atcab_aes_encrypt_ext, 69                                   | atcab_mac, 93                  |
| atcab_aes_gcm_aad_update, 70                                |                                |
| atcab_aes_gcm_decrypt_finish, 70                            | atcab_nonce, 93                |
| atcab_aes_gcm_decrypt_update, 71                            | atcab_nonce_base, 94           |
| atcab_aes_gcm_encrypt_finish, 71                            | atcab_nonce_load, 94           |
| atcab_aes_gcm_encrypt_update, 72                            | atcab_nonce_rand, 95           |
| atcab_aes_gcm_init, 72                                      | atcab_printbin, 95             |
| atcab_aes_gcm_init_rand, 73                                 | atcab_priv_write, 95           |
| atcab_aes_gfm, 73                                           | atcab_random, 96               |
| atcab_cfg_discover, 59                                      | atcab_random_ext, 96           |
| atcab_challenge, 74                                         | atcab_read_bytes_zone, 96      |
| atcab_challenge_seed_update, 74                             | atcab_read_config_zone, 97     |
| atcab_checkmac, 75                                          | atcab_read_enc, 97             |
| atcab_cmp_config_zone, 75                                   | atcab_read_pubkey, 98          |
| atcab_counter, 76                                           | atcab_read_serial_number, 98   |
| atcab_counter_increment, 76                                 | atcab_read_sig, 99             |

|      | atcab_read_zone, 99                         | calib_challenge_seed_update, 209 |
|------|---------------------------------------------|----------------------------------|
|      | atcab_release, 99                           | calib_checkmac, 210              |
|      | atcab_release_ext, 100                      | calib_cmp_config_zone, 210       |
|      | atcab_secureboot, 100                       | calib_counter, 211               |
|      | atcab_secureboot_mac, 101                   | calib_counter_increment, 211     |
|      | atcab_selftest, 101                         | calib_counter_read, 212          |
|      | atcab_sha, 102                              | calib_derivekey, 212             |
|      | atcab_sha_base, 102                         | calib_ecdh, 213                  |
|      | atcab_sha_end, 103                          | calib_ecdh_base, 213             |
|      | atcab_sha_hmac, 103                         | calib_ecdh_enc, 214              |
|      | atcab_sha_hmac_finish, 104                  | calib_ecdh_ioenc, 214            |
|      | atcab_sha_hmac_init, 104                    | calib_ecdh_tempkey, 215          |
|      | atcab_sha_hmac_update, 104                  | calib_ecdh_tempkey_ioenc, 215    |
|      | atcab_sha_read_context, 105                 | calib_gendig, 216                |
|      | atcab_sha_start, 105                        | calib_genkey, 216                |
|      | atcab_sha_update, 105                       | calib_genkey_base, 216           |
|      | atcab_sha_write_context, 106                | calib_get_addr, 217              |
|      | atcab_sign, 106                             | calib_get_pubkey, 217            |
|      | atcab_sign_base, 107                        | calib_get_zone_size, 218         |
|      | atcab_sign_internal, 107                    | calib_hmac, 218                  |
|      | atcab_sleep, 108                            | calib_hw_sha2_256, 219           |
|      | atcab_updateextra, 108                      | calib_hw_sha2_256_finish, 219    |
|      | atcab_verify, 108                           | calib_hw_sha2_256_init, 220      |
|      | atcab_verify_extern, 109                    | calib_hw_sha2_256_update, 220    |
|      | atcab_verify_extern_mac, 110                | calib_idle, 221                  |
|      | atcab_verify_invalidate, 110                | calib_info, 221                  |
|      | atcab_verify_stored, 111                    | calib_info_base, 221             |
|      | atcab_verify_stored_mac, 111                | calib_info_get_latch, 222        |
|      | atcab_verify_validate, 112                  | calib_info_set_latch, 222        |
|      | atcab_version, 112                          | calib_is_locked, 223             |
|      | atcab_wakeup, 113                           | calib_is_slot_locked, 223        |
|      | atcab_write, 113                            | calib_kdf, 223                   |
|      | atcab write bytes zone, 113                 | calib_lock, 224                  |
|      | atcab_write_config_counter, 114             | calib_lock_config_zone, 225      |
|      | atcab_write_config_zone, 114                | calib_lock_config_zone_crc, 225  |
|      | atcab_write_enc, 115                        | calib_lock_data_slot, 225        |
|      | atcab_write_pubkey, 115                     | calib_lock_data_zone, 226        |
|      | atcab_write_zone, 116                       | calib_lock_data_zone_crc, 226    |
|      | calib_aes_gcm_aad_update, 116               | calib_mac, 227                   |
|      | calib_aes_gcm_decrypt_finish, 117           | calib_nonce, 227                 |
|      | calib_aes_gcm_decrypt_update, 117           | calib_nonce_base, 227            |
|      | calib_aes_gcm_encrypt_finish, 118           | calib_nonce_load, 228            |
|      | calib_aes_gcm_encrypt_update, 118           | calib_nonce_rand, 229            |
|      | calib_aes_gcm_init, 119                     | calib_priv_write, 229            |
|      | calib_aes_gcm_init_rand, 119                | calib random, 229                |
|      | SHA_CONTEXT_MAX_SIZE, 59                    | calib_read_bytes_zone, 230       |
| Basi | c Crypto API methods for CryptoAuth Devices | calib_read_config_zone, 230      |
|      | (calib_), 201                               | calib_read_enc, 231              |
|      | _calib_exit, 206                            | calib_read_pubkey, 231           |
|      | atca_basic_aes_gcm_version, 250             | calib_read_serial_number, 231    |
|      | atca_hmac_sha256_ctx_t, 206                 | calib_read_sig, 232              |
|      | atca_sha256_ctx_t, 206                      | calib_read_zone, 232             |
|      | calib_aes, 207                              | calib_secureboot, 233            |
|      | calib_aes_decrypt, 207                      | calib_secureboot_mac, 233        |
|      | calib_aes_encrypt, 208                      | calib_selftest, 234              |
|      | calib_aes_gfm, 208                          | calib_sha, 235                   |
|      | calib_des_giff, 200 calib_cfg_discover, 209 | calib_sha_base, 235              |
|      | calib_challenge, 209                        | calib_sha_end, 236               |
|      | Cand Chancings, 203                         | ∪αιιυ_311α_511U, <b>∠3</b> U     |

| calib_sha_hmac, 236                                                                                                                                                                                                                                                                                                                                                                                  | bus_index                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| calib_sha_hmac_finish, 237                                                                                                                                                                                                                                                                                                                                                                           | atcal2Cmaster, 451                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| calib_sha_hmac_init, 237                                                                                                                                                                                                                                                                                                                                                                             | atcaSWImaster, 460                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| calib_sha_hmac_update, 238                                                                                                                                                                                                                                                                                                                                                                           | byteCount                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| calib_sha_read_context, 238                                                                                                                                                                                                                                                                                                                                                                          | CL_HashContext, 528                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| calib_sha_start, 239                                                                                                                                                                                                                                                                                                                                                                                 | byteCountHi                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| calib_sha_update, 239                                                                                                                                                                                                                                                                                                                                                                                | CL_HashContext, 528                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                                                                                                                                                                                                                                                                                                                                                      | GE_Hadridontoxt, GEO                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| calib_sha_write_context, 239                                                                                                                                                                                                                                                                                                                                                                         | C_CancelFunction                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_sign, 240                                                                                                                                                                                                                                                                                                                                                                                      | Attributes (pkcs11_attrib_), 338                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_sign_base, 240                                                                                                                                                                                                                                                                                                                                                                                 | C CloseAllSessions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| calib_sign_internal, 241                                                                                                                                                                                                                                                                                                                                                                             | Attributes (pkcs11_attrib_), 338                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_sleep, 241                                                                                                                                                                                                                                                                                                                                                                                     | C_CloseSession                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| calib_updateextra, 242                                                                                                                                                                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| calib_verify, 242                                                                                                                                                                                                                                                                                                                                                                                    | Attributes (pkcs11_attrib_), 338                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_verify_extern, 243                                                                                                                                                                                                                                                                                                                                                                             | C_CopyObject                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| calib_verify_extern_mac, 243                                                                                                                                                                                                                                                                                                                                                                         | Attributes (pkcs11_attrib_), 338                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_verify_invalidate, 244                                                                                                                                                                                                                                                                                                                                                                         | C_CreateObject                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| calib verify stored, 245                                                                                                                                                                                                                                                                                                                                                                             | Attributes (pkcs11_attrib_), 338                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_verify_stored_mac, 245                                                                                                                                                                                                                                                                                                                                                                         | C_Decrypt                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| calib verify validate, 246                                                                                                                                                                                                                                                                                                                                                                           | Attributes (pkcs11_attrib_), 339                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_wakeup, 246                                                                                                                                                                                                                                                                                                                                                                                    | C_DecryptDigestUpdate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| calib_write, 247                                                                                                                                                                                                                                                                                                                                                                                     | Attributes (pkcs11_attrib_), 339                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|                                                                                                                                                                                                                                                                                                                                                                                                      | C_DecryptFinal                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| calib_write_bytes_zone, 247                                                                                                                                                                                                                                                                                                                                                                          | Attributes (pkcs11_attrib_), 339                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_write_config_counter, 248                                                                                                                                                                                                                                                                                                                                                                      | C_DecryptInit                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| calib_write_config_zone, 248                                                                                                                                                                                                                                                                                                                                                                         | Attributes (pkcs11_attrib_), 339                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_write_enc, 249                                                                                                                                                                                                                                                                                                                                                                                 | C_DecryptUpdate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| calib_write_pubkey, 249                                                                                                                                                                                                                                                                                                                                                                              | Attributes (pkcs11_attrib_), 340                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_write_zone, 249                                                                                                                                                                                                                                                                                                                                                                                | C_DecryptVerifyUpdate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| BASIS                                                                                                                                                                                                                                                                                                                                                                                                | Attributes (pkcs11_attrib_), 340                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| license.txt, 876                                                                                                                                                                                                                                                                                                                                                                                     | C_DeriveKey                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| baud                                                                                                                                                                                                                                                                                                                                                                                                 | Attributes (pkcs11_attrib_), 340                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| ATCAlfaceCfg, 454                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| bBC                                                                                                                                                                                                                                                                                                                                                                                                  | C_DestroyObject                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| CK KEY WRAP SET OAEP PARAMS, 485                                                                                                                                                                                                                                                                                                                                                                     | Attributes (pkcs11_attrib_), 340                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| bind_host_and_secure_element_with_io_protection                                                                                                                                                                                                                                                                                                                                                      | C_Digest                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| bilid_flost_drid_scourc_cicfficfit_with_lo_protection                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| secure hootic 1060                                                                                                                                                                                                                                                                                                                                                                                   | Attributes (pkcs11_attrib_), 341                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| secure_boot.c, 1060                                                                                                                                                                                                                                                                                                                                                                                  | C_DigestEncryptUpdate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot.h, 1062                                                                                                                                                                                                                                                                                                                                                                                  | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| secure_boot.h, 1062<br>blsExport                                                                                                                                                                                                                                                                                                                                                                     | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| secure_boot.h, 1062<br>blsExport<br>CK_SSL3_KEY_MAT_PARAMS, 507                                                                                                                                                                                                                                                                                                                                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| secure_boot.h, 1062<br>blsExport<br>CK_SSL3_KEY_MAT_PARAMS, 507<br>CK_TLS12_KEY_MAT_PARAMS, 510                                                                                                                                                                                                                                                                                                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| secure_boot.h, 1062<br>blsExport<br>CK_SSL3_KEY_MAT_PARAMS, 507<br>CK_TLS12_KEY_MAT_PARAMS, 510<br>CK_WTLS_KEY_MAT_PARAMS, 519                                                                                                                                                                                                                                                                       | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot.h, 1062<br>blsExport<br>CK_SSL3_KEY_MAT_PARAMS, 507<br>CK_TLS12_KEY_MAT_PARAMS, 510                                                                                                                                                                                                                                                                                                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit                                                                                                                                                                                                                                                                                                                                                                                                                       |
| secure_boot.h, 1062<br>blsExport<br>CK_SSL3_KEY_MAT_PARAMS, 507<br>CK_TLS12_KEY_MAT_PARAMS, 510<br>CK_WTLS_KEY_MAT_PARAMS, 519                                                                                                                                                                                                                                                                       | C_DigestEncryptUpdate    Attributes (pkcs11_attrib_), 341 C_DigestFinal    Attributes (pkcs11_attrib_), 341 C_DigestInit    Attributes (pkcs11_attrib_), 341 C_DigestKey                                                                                                                                                                                                                                                                                                                                                                 |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block                                                                                                                                                                                                                                                                             | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342                                                                                                                                                                                                                                                                                                                                         |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block atca_aes_cmac_ctx, 402                                                                                                                                                                                                                                                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate                                                                                                                                                                                                                                                                                                                          |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block atca_aes_cmac_ctx, 402 atca_sha256_ctx, 429                                                                                                                                                                                                                                 | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342                                                                                                                                                                                                                                                                                         |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block atca_aes_cmac_ctx, 402 atca_sha256_ctx, 429 hw_sha256_ctx, 528 sw_sha256_ctx, 534                                                                                                                                                                                           | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt                                                                                                                                                                                                                                                                               |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block atca_aes_cmac_ctx, 402 atca_sha256_ctx, 429 hw_sha256_ctx, 528 sw_sha256_ctx, 534 block_size                                                                                                                                                                                | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342                                                                                                                                                                                                                                              |
| secure_boot.h, 1062 blsExport CK_SSL3_KEY_MAT_PARAMS, 507 CK_TLS12_KEY_MAT_PARAMS, 510 CK_WTLS_KEY_MAT_PARAMS, 519 block atca_aes_cmac_ctx, 402 atca_sha256_ctx, 429 hw_sha256_ctx, 528 sw_sha256_ctx, 528 sw_sha256_ctx, 534 block_size atca_aes_cmac_ctx, 402                                                                                                                                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal                                                                                                                                                                                                                               |
| secure_boot.h, 1062 blsExport     CK_SSL3_KEY_MAT_PARAMS, 507     CK_TLS12_KEY_MAT_PARAMS, 510     CK_WTLS_KEY_MAT_PARAMS, 519 block     atca_aes_cmac_ctx, 402     atca_sha256_ctx, 429     hw_sha256_ctx, 528     sw_sha256_ctx, 534 block_size     atca_aes_cmac_ctx, 402     atca_aes_cmac_ctx, 402     atca_aes_cmac_ctx, 402     atca_sha256_ctx, 429                                          | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342                                                                                                                                                                                              |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 534 block_size                                                                                        | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit                                                                                                                                                                                |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342                                                                                                                                               |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf                                                           | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate                                                                                                                               |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf  atca_jwt_t, 424                      | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 343                                             |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf  atca_jwt_t, 424  CL_HashContext, 528 | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_Finalize                                  |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf  atca_jwt_t, 424  CL_HashContext, 528 buflen              | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_Finalize Attributes (pkcs11_attrib_), 343 |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf  atca_jwt_t, 424  CL_HashContext, 528 | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_Finalize Attributes (pkcs11_attrib_), 343 C_FindObjects                                    |
| secure_boot.h, 1062 blsExport  CK_SSL3_KEY_MAT_PARAMS, 507  CK_TLS12_KEY_MAT_PARAMS, 510  CK_WTLS_KEY_MAT_PARAMS, 519 block  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 528  sw_sha256_ctx, 534 block_size  atca_aes_cmac_ctx, 402  atca_sha256_ctx, 429  hw_sha256_ctx, 529  sw_sha256_ctx, 529  sw_sha256_ctx, 534 buf  atca_jwt_t, 424  CL_HashContext, 528 buflen              | C_DigestEncryptUpdate Attributes (pkcs11_attrib_), 341 C_DigestFinal Attributes (pkcs11_attrib_), 341 C_DigestInit Attributes (pkcs11_attrib_), 341 C_DigestKey Attributes (pkcs11_attrib_), 342 C_DigestUpdate Attributes (pkcs11_attrib_), 342 C_Encrypt Attributes (pkcs11_attrib_), 342 C_EncryptFinal Attributes (pkcs11_attrib_), 342 C_EncryptInit Attributes (pkcs11_attrib_), 342 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_EncryptUpdate Attributes (pkcs11_attrib_), 343 C_Finalize Attributes (pkcs11_attrib_), 343 |

| Attributes (pkcs11_attrib_), 343                  | Attributes (pkcs11_attrib_), 350                                     |
|---------------------------------------------------|----------------------------------------------------------------------|
| C_FindObjectsInit                                 | C_SignInit                                                           |
| Attributes (pkcs11_attrib_), 343                  | Attributes (pkcs11_attrib_), 350                                     |
| C_GenerateKey                                     | C_SignRecover                                                        |
| Attributes (pkcs11_attrib_), 344                  | Attributes (pkcs11_attrib_), 350                                     |
| C_GenerateKeyPair                                 | C_SignRecoverInit                                                    |
| Attributes (pkcs11_attrib_), 344 C_GenerateRandom | Attributes (pkcs11_attrib_), 350                                     |
| Attributes (pkcs11_attrib_), 344                  | C_SignUpdate Attributes (pkcs11_attrib_), 351                        |
| C_GetAttributeValue                               | C UnwrapKey                                                          |
| Attributes (pkcs11_attrib_), 344                  | Attributes (pkcs11_attrib_), 351                                     |
| C_GetFunctionList                                 | C_Verify                                                             |
| Attributes (pkcs11_attrib_), 345                  | Attributes (pkcs11_attrib_), 351                                     |
| C GetFunctionStatus                               | C_VerifyFinal                                                        |
| Attributes (pkcs11_attrib_), 345                  | Attributes (pkcs11_attrib_), 351                                     |
| C_GetInfo                                         | C_VerifyInit                                                         |
| Attributes (pkcs11_attrib_), 345                  | Attributes (pkcs11_attrib_), 352                                     |
| C_GetMechanismInfo                                | C_VerifyRecover                                                      |
| Attributes (pkcs11_attrib_), 345                  | Attributes (pkcs11_attrib_), 352                                     |
| C_GetMechanismList                                | C_VerifyRecoverInit                                                  |
| Attributes (pkcs11_attrib_), 345                  | Attributes (pkcs11_attrib_), 352                                     |
| C_GetObjectSize                                   | C_VerifyUpdate                                                       |
| Attributes (pkcs11_attrib_), 346                  | Attributes (pkcs11_attrib_), 352                                     |
| C_GetOperationState                               | C_WaitForSlotEvent                                                   |
| Attributes (pkcs11_attrib_), 346                  | Attributes (pkcs11_attrib_), 352                                     |
| C_GetSessionInfo                                  | C_WrapKey                                                            |
| Attributes (pkcs11_attrib_), 346                  | Attributes (pkcs11_attrib_), 353                                     |
| C_GetSlotInfo                                     | ca_cert_def                                                          |
| Attributes (pkcs11_attrib_), 346                  | atcacert_def_s, 443                                                  |
| C_GetSlotList                                     | calib_aes                                                            |
| Attributes (pkcs11_attrib_), 346 C GetTokenInfo   | Basic Crypto API methods for CryptoAuth Devices (calib_), 207        |
| Attributes (pkcs11_attrib_), 347                  | calib_aes.c, 666                                                     |
| C_Initialize                                      | calib_aes_decrypt                                                    |
| Attributes (pkcs11_attrib_), 347                  | Basic Crypto API methods for CryptoAuth Devices                      |
| C_InitPIN                                         | (calib_), 207                                                        |
| Attributes (pkcs11_attrib_), 347                  | calib_aes_encrypt                                                    |
| C_InitToken                                       | Basic Crypto API methods for CryptoAuth Devices                      |
| Attributes (pkcs11_attrib_), 347                  | (calib_), 208                                                        |
| C_Login                                           | calib_aes_gcm.c, 667                                                 |
| Attributes (pkcs11_attrib_), 347                  | calib_aes_gcm_aad_update, 668                                        |
| C_Logout                                          | calib_aes_gcm_decrypt_finish, 668                                    |
| Attributes (pkcs11_attrib_), 348                  | calib_aes_gcm_decrypt_update, 669                                    |
| C_OpenSession                                     | calib_aes_gcm_encrypt_finish, 669                                    |
| Attributes (pkcs11_attrib_), 348                  | calib_aes_gcm_encrypt_update, 670                                    |
| C_SeedRandom                                      | calib_aes_gcm_init, 670                                              |
| Attributes (pkcs11_attrib_), 348                  | calib_aes_gcm_init_rand, 671                                         |
| C_SetAttributeValue                               | RETURN, 668                                                          |
| Attributes (pkcs11_attrib_), 348                  | calib_aes_gcm.h, 671                                                 |
| C_SetOperationState                               | calib_aes_gcm_aad_update                                             |
| Attributes (pkcs11_attrib_), 349                  | Basic Crypto API methods (atcab_), 116                               |
| C_SetPIN  Attributes (pleased a strib.) 240       | calib_aes_gcm.c, 668                                                 |
| Attributes (pkcs11_attrib_), 349                  | calib_aes_gcm_decrypt_finish  Basic Crypto API methods (ateab.), 117 |
| C_Sign Attributes (pkcs11_attrib_), 349           | Basic Crypto API methods (atcab_), 117 calib_aes_gcm.c, 668          |
| C_SignEncryptUpdate                               | calib_aes_gcm_decrypt_update                                         |
| Attributes (pkcs11_attrib_), 349                  | Basic Crypto API methods (atcab_), 117                               |
| C_SignFinal                                       | calib_aes_gcm.c, 669                                                 |
| - <u> </u>                                        |                                                                      |

| calib_aes_gcm_encrypt_finish                    | atSelfTest, 690                            |
|-------------------------------------------------|--------------------------------------------|
| Basic Crypto API methods (atcab_), 118          | atSHA, 690                                 |
| calib_aes_gcm.c, 669                            | atSign, 690                                |
| calib_aes_gcm_encrypt_update                    | atUpdateExtra, 691                         |
| Basic Crypto API methods (atcab_), 118          | atVerify, 691                              |
| calib_aes_gcm.c, 670                            | atWrite, 692                               |
| calib_aes_gcm_init                              | isATCAError, 692                           |
| Basic Crypto API methods (atcab_), 119          | calib_command.h, 692                       |
| calib_aes_gcm.c, 670                            | AES_COUNT, 711                             |
| calib_aes_gcm_init_rand                         | AES_DATA_SIZE, 711                         |
| Basic Crypto API methods (atcab_), 119          | AES_INPUT_IDX, 711                         |
| calib_aes_gcm.c, 671                            | AES_KEYID_IDX, 711                         |
| calib_aes_gfm                                   | AES_MODE_DECRYPT, 711                      |
| Basic Crypto API methods for CryptoAuth Devices | AES_MODE_ENCRYPT, 711                      |
| (calib_), 208                                   | AES_MODE_GFM, 712                          |
| calib_basic.c, 672                              | AES_MODE_IDX, 712                          |
| MAX_BUSES, 673                                  | AES_MODE_KEY_BLOCK_MASK, 712               |
| calib_basic.h, 673                              | AES_MODE_KEY_BLOCK_POS, 712                |
| calib_cfg_discover                              | AES_MODE_MASK, 712                         |
| Basic Crypto API methods for CryptoAuth Devices | AES_MODE_OP_MASK, 712                      |
| (calib_), 209                                   | AES_RSP_SIZE, 713                          |
| calib_challenge                                 | atAES, 782                                 |
| Basic Crypto API methods for CryptoAuth Devices | ATCA_ADDRESS_MASK, 713                     |
| (calib_), 209                                   | ATCA_ADDRESS_MASK_CONFIG, 713              |
| calib_challenge_seed_update                     | ATCA_ADDRESS_MASK_OTP, 713                 |
| Basic Crypto API methods for CryptoAuth Devices | ATCA_AES, 713                              |
| (calib_), 209                                   | ATCA_AES_GFM_SIZE, 713                     |
| calib_checkmac                                  | ATCA_AES_KEY_TYPE, 714                     |
| Basic Crypto API methods for CryptoAuth Devices | ATCA_B283_KEY_TYPE, 714                    |
| (calib_), 210<br>calib_checkmac.c, 679          | ATCA_BLOCK_SIZE, 714<br>ATCA_CHECKMAC, 714 |
| calib_cmp_config_zone                           | ATCA_CHIPMODE_CLOCK_DIV_M0, 714            |
| Basic Crypto API methods for CryptoAuth Devices | ATCA_CHIPMODE_CLOCK_DIV_M1, 714            |
| (calib_), 210                                   | ATCA CHIPMODE CLOCK DIV M2, 715            |
| calib_command.c, 679                            | ATCA_CHIPMODE_CLOCK_DIV_MASK, 715          |
| atAES, 681                                      | ATCA_CHIPMODE_I2C_ADDRESS_FLAG, 715        |
| atCalcCrc, 681                                  | ATCA_CHIPMODE_OFFSET, 715                  |
| atCheckCrc, 682                                 | ATCA_CHIPMODE_TTL_ENABLE_FLAG, 715         |
| atCheckMAC, 682                                 | ATCA_CHIPMODE_WATCHDOG_LONG, 715           |
| atCounter, 682                                  | ATCA_CHIPMODE_WATCHDOG_MASK, 716           |
| atCRC, 683                                      | ATCA CHIPMODE WATCHDOG SHORT, 716          |
| atDeriveKey, 683                                | ATCA CMD SIZE MAX, 716                     |
| atECDH, 684                                     | ATCA_CMD_SIZE_MIN, 716                     |
| atGenDig, 684                                   | ATCA_COUNT_IDX, 716                        |
| atGenKey, 684                                   | ATCA_COUNT_SIZE, 716                       |
| atHMAC, 685                                     | ATCA_COUNTER, 717                          |
| atInfo, 685                                     | ATCA_CRC_SIZE, 717                         |
| atIsECCFamily, 685                              | ATCA_DATA_IDX, 717                         |
| atIsSHAFamily, 686                              | ATCA_DATA_SIZE, 717                        |
| atKDF, 686                                      | ATCA_DERIVE_KEY, 717                       |
| atLock, 687                                     | ATCA_ECC_CONFIG_SIZE, 717                  |
| atMAC, 687                                      | ATCA_ECDH, 718                             |
| atNonce, 687                                    | ATCA_GENDIG, 718                           |
| atPause, 688                                    | ATCA_GENKEY, 718                           |
| atPrivWrite, 688                                | ATCA_HMAC, 718                             |
| atRandom, 688                                   | ATCA_INFO, 718                             |
| atRead, 689                                     | ATCA_K283_KEY_TYPE, 718                    |
| atSecureBoot, 689                               | ATCA_KDF, 719                              |

| ATCA KEY COUNT, 719         | atInfo, 786                         |
|-----------------------------|-------------------------------------|
| ATCA_KEY_ID_MAX, 719        | atIsECCFamily, 787                  |
| ATCA_KEY_SIZE, 719          | atIsSHAFamily, 787                  |
| ATCA LOCK, 719              | atKDF, 788                          |
| ATCA_LOCKED, 719            | atLock, 788                         |
|                             |                                     |
| ATCA_MAC, 720               | atMAC, 788                          |
| ATCA_NONCE, 720             | atNonce, 789                        |
| ATCA_OPCODE_IDX, 720        | atPause, 789                        |
| ATCA_OTP_BLOCK_MAX, 720     | atPrivWrite, 789                    |
| ATCA_OTP_SIZE, 720          | atRandom, 790                       |
| ATCA_P256_KEY_TYPE, 720     | atRead, 790                         |
| ATCA_PACKET_OVERHEAD, 721   | atSecureBoot, 791                   |
| ATCA_PARAM1_IDX, 721        | atSelfTest, 791                     |
| ATCA_PARAM2_IDX, 721        | atSHA, 791                          |
| ATCA_PAUSE, 721             | atSign, 793                         |
| ATCA_PRIV_KEY_SIZE, 721     | atUpdateExtra, 793                  |
| ATCA_PRIVWRITE, 721         | atVerify, 793                       |
| ATCA PUB KEY PAD, 722       | atWrite, 794                        |
| ATCA_PUB_KEY_SIZE, 722      | CHECKMAC_CLIENT_CHALLENGE_IDX, 727  |
| ATCA_RANDOM, 722            | CHECKMAC CLIENT CHALLENGE SIZE, 727 |
| ATCA READ, 722              | CHECKMAC_CLIENT_COMMAND_SIZE, 727   |
| ATCA RSP DATA IDX, 722      | CHECKMAC_CLIENT_RESPONSE_IDX, 727   |
| ATCA_RSP_SIZE_16, 722       | CHECKMAC_CLIENT_RESPONSE_SIZE, 727  |
| ATCA_RSP_SIZE_32, 723       | CHECKMAC_CMD_MATCH, 728             |
| ATCA_RSP_SIZE_4, 723        | CHECKMAC_CMD_MISMATCH, 728          |
| ATCA_RSP_SIZE_64, 723       |                                     |
|                             | CHECKMAC_COUNT, 728                 |
| ATCA_RSP_SIZE_72, 723       | CHECKMAC_DATA_IDX, 728              |
| ATCA_RSP_SIZE_MAX, 723      | CHECKMAC_KEYID_IDX, 728             |
| ATCA_RSP_SIZE_MIN, 723      | CHECKMAC_MODE_BLOCK1_TEMPKEY, 728   |
| ATCA_RSP_SIZE_VAL, 724      | CHECKMAC_MODE_BLOCK2_TEMPKEY, 729   |
| ATCA_SECUREBOOT, 724        | CHECKMAC_MODE_CHALLENGE, 729        |
| ATCA_SELFTEST, 724          | CHECKMAC_MODE_IDX, 729              |
| ATCA_SERIAL_NUM_SIZE, 724   | CHECKMAC_MODE_INCLUDE_OTP_64, 729   |
| ATCA_SHA, 724               | CHECKMAC_MODE_MASK, 729             |
| ATCA_SHA_CONFIG_SIZE, 724   | CHECKMAC_MODE_SOURCE_FLAG_MATCH,    |
| ATCA_SHA_DIGEST_SIZE, 725   | 729                                 |
| ATCA_SHA_KEY_TYPE, 725      | CHECKMAC_OTHER_DATA_SIZE, 730       |
| ATCA_SIG_SIZE, 725          | CHECKMAC_RSP_SIZE, 730              |
| ATCA_SIGN, 725              | CMD_STATUS_BYTE_COMM, 730           |
| ATCA_TEMPKEY_KEYID, 725     | CMD_STATUS_BYTE_ECC, 730            |
| ATCA_UNLOCKED, 725          | CMD_STATUS_BYTE_EXEC, 730           |
| ATCA_UPDATE_EXTRA, 726      | CMD_STATUS_BYTE_PARSE, 730          |
| ATCA_VERIFY, 726            | CMD_STATUS_SUCCESS, 731             |
| ATCA_WORD_SIZE, 726         | CMD_STATUS_WAKEUP, 731              |
| ATCA_WRITE, 726             | COUNTER_COUNT, 731                  |
| ATCA_ZONE_ENCRYPTED, 726    | COUNTER_KEYID_IDX, 731              |
| ATCA ZONE MASK, 726         | COUNTER MAX VALUE, 731              |
| ATCA_ZONE_READWRITE_32, 727 | COUNTER MODE IDX, 731               |
| atCalcCrc, 783              | COUNTER_MODE_INCREMENT, 732         |
| atCheckCrc, 783             | COUNTER_MODE_MASK, 732              |
| atCheckMAC, 783             | COUNTER MODE READ, 732              |
| atCounter, 784              | COUNTER_RSP_SIZE, 732               |
| atCRC, 784                  | COUNTER_SIZE, 732                   |
| atDeriveKey, 784            | DERIVE_KEY_COUNT_LARGE, 732         |
| atECDH, 785                 | DERIVE_KEY_COUNT_SMALL, 733         |
| atGenDig, 785               | DERIVE_KEY_MAC_IDX, 733             |
| _                           |                                     |
| atGenKey, 786               | DERIVE_KEY_MAC_SIZE, 733            |
| atHMAC, 786                 | DERIVE KEY MODE, 733                |

| DERIVE_KEY_RANDOM_FLAG, 733       | INFO_MODE_KEY_VALID, 742             |
|-----------------------------------|--------------------------------------|
| DERIVE KEY RANDOM IDX, 733        | INFO_MODE_MAX, 743                   |
| DERIVE KEY RSP SIZE, 734          | INFO_MODE_REVISION, 743              |
| DERIVE_KEY_TARGETKEY_IDX, 734     | INFO MODE STATE, 743                 |
| ECDH COUNT, 734                   | INFO_MODE_VOL_KEY_PERMIT, 743        |
| ECDH KEY SIZE, 734                | INFO_NO_STATE, 743                   |
| ECDH_MODE_COPY_COMPATIBLE, 734    | INFO_OUTPUT_STATE_MASK, 743          |
| ECDH_MODE_COPY_EEPROM_SLOT, 734   | INFO_PARAM1_IDX, 744                 |
| ECDH_MODE_COPY_MASK, 734          | INFO_PARAM2_IDX, 744                 |
| ECDH MODE COPY OUTPUT BUFFER, 735 | INFO_PARAM2_LATCH_CLEAR, 744         |
| ECDH_MODE_COPY_TEMP_KEY, 735      | INFO_PARAM2_LATCH_SET, 744           |
| ECDH_MODE_OUTPUT_CLEAR, 735       | INFO_PARAM2_SET_LATCH_STATE, 744     |
| ECDH_MODE_OUTPUT_ENC, 735         | INFO_RSP_SIZE, 744                   |
| ECDH_MODE_OUTPUT_MASK, 735        | INFO_SIZE, 745                       |
| ECDH_MODE_SOURCE_EEPROM_SLOT, 735 | isATCAError, 794                     |
| ECDH_MODE_SOURCE_MASK, 735        | KDF_DETAILS_AES_KEY_LOC_MASK, 745    |
| ECDH_MODE_SOURCE_TEMPKEY, 735     | KDF_DETAILS_HKDF_MSG_LOC_INPUT, 745  |
| ECDH_PREFIX_MODE, 736             | KDF_DETAILS_HKDF_MSG_LOC_IV, 745     |
| ECDH_RSP_SIZE, 736                | KDF_DETAILS_HKDF_MSG_LOC_MASK, 745   |
| GENDIG_COUNT, 736                 | KDF_DETAILS_HKDF_MSG_LOC_SLOT, 745   |
| GENDIG_DATA_IDX, 736              | KDF_DETAILS_HKDF_MSG_LOC_TEMPKEY,    |
| GENDIG_KEYID_IDX, 736             | 746                                  |
| GENDIG_RSP_SIZE, 736              | KDF_DETAILS_HKDF_ZERO_KEY, 746       |
| GENDIG_ZONE_CONFIG, 737           | KDF_DETAILS_IDX, 746                 |
| GENDIG_ZONE_COUNTER, 737          | KDF_DETAILS_PRF_AEAD_MASK, 746       |
| GENDIG_ZONE_DATA, 737             | KDF_DETAILS_PRF_AEAD_MODE0, 746      |
| GENDIG_ZONE_IDX, 737              | KDF_DETAILS_PRF_AEAD_MODE1, 746      |
| GENDIG_ZONE_KEY_CONFIG, 737       | KDF_DETAILS_PRF_KEY_LEN_16, 747      |
| GENDIG_ZONE_OTP, 737              | KDF_DETAILS_PRF_KEY_LEN_32, 747      |
| GENDIG_ZONE_SHARED_NONCE, 738     | KDF_DETAILS_PRF_KEY_LEN_48, 747      |
| GENKEY_COUNT, 738                 | KDF_DETAILS_PRF_KEY_LEN_64, 747      |
| GENKEY_COUNT_DATA, 738            | KDF_DETAILS_PRF_KEY_LEN_MASK, 747    |
| GENKEY_DATA_IDX, 738              | KDF_DETAILS_PRF_TARGET_LEN_32, 747   |
| GENKEY_KEYID_IDX, 738             | KDF_DETAILS_PRF_TARGET_LEN_64, 748   |
| GENKEY_MODE_DIGEST, 738           | KDF_DETAILS_PRF_TARGET_LEN_MASK, 748 |
| GENKEY_MODE_IDX, 739              | KDF_DETAILS_SIZE, 748                |
| GENKEY_MODE_MASK, 739             | KDF_KEYID_IDX, 748                   |
| GENKEY_MODE_PRIVATE, 739          | KDF_MESSAGE_IDX, 748                 |
| GENKEY_MODE_PUBKEY_DIGEST, 739    | KDF_MODE_ALG_AES, 748                |
| GENKEY_MODE_PUBLIC, 739           | KDF_MODE_ALG_HKDF, 749               |
| GENKEY_OTHER_DATA_SIZE, 739       | KDF_MODE_ALG_MASK, 749               |
| GENKEY_PRIVATE_TO_TEMPKEY, 740    | KDF_MODE_ALG_PRF, 749                |
| GENKEY_RSP_SIZE_LONG, 740         | KDF_MODE_IDX, 749                    |
| GENKEY_RSP_SIZE_SHORT, 740        | KDF_MODE_SOURCE_ALTKEYBUF, 749       |
| HMAC_COUNT, 740                   | KDF_MODE_SOURCE_MASK, 749            |
| HMAC_DIGEST_SIZE, 740             | KDF_MODE_SOURCE_SLOT, 750            |
| HMAC_KEYID_IDX, 740               | KDF_MODE_SOURCE_TEMPKEY, 750         |
| HMAC_MODE_FLAG_FULLSN, 741        | KDF_MODE_SOURCE_TEMPKEY_UP, 750      |
| HMAC_MODE_FLAG_OTP64, 741         | KDF_MODE_TARGET_ALTKEYBUF, 750       |
| HMAC_MODE_FLAG_OTP88, 741         | KDF_MODE_TARGET_MASK, 750            |
| HMAC_MODE_FLAG_TK_NORAND, 741     | KDF_MODE_TARGET_OUTPUT, 750          |
| HMAC_MODE_FLAG_TK_RAND, 741       | KDF_MODE_TARGET_OUTPUT_ENC, 751      |
| HMAC_MODE_IDX, 741                | KDF_MODE_TARGET_SLOT, 751            |
| HMAC_MODE_MASK, 742               | KDF_MODE_TARGET_TEMPKEY, 751         |
| HMAC_RSP_SIZE, 742                | KDF_MODE_TARGET_TEMPKEY_UP, 751      |
| INFO_COUNT, 742                   | LOCK_COUNT, 751                      |
| INFO_DRIVER_STATE_MASK, 742       | LOCK_RSP_SIZE, 751                   |
| INFO_MODE_GPIO, 742               | LOCK_SUMMARY_IDX, 752                |

| LOCK ZONE CONFIG, 752             | PRIVWRITE RSP SIZE, 761              |
|-----------------------------------|--------------------------------------|
| LOCK ZONE DATA, 752               | PRIVWRITE VALUE IDX, 762             |
| LOCK_ZONE_DATA_SLOT, 752          | PRIVWRITE_ZONE_IDX, 762              |
| LOCK ZONE IDX, 752                | PRIVWRITE ZONE MASK, 762             |
| LOCK ZONE MASK, 752               | RANDOM COUNT, 762                    |
|                                   | <del>-</del>                         |
| LOCK_ZONE_NO_CRC, 753             | RANDOM_MODE_IDX, 762                 |
| MAC_CHALLENGE_IDX, 753            | RANDOM_NO_SEED_UPDATE, 762           |
| MAC_CHALLENGE_SIZE, 753           | RANDOM_NUM_SIZE, 763                 |
| MAC_COUNT_LONG, 753               | RANDOM_PARAM2_IDX, 763               |
| MAC_COUNT_SHORT, 753              | RANDOM_RSP_SIZE, 763                 |
| MAC_KEYID_IDX, 753                | RANDOM_SEED_UPDATE, 763              |
| MAC_MODE_BLOCK1_TEMPKEY, 754      | READ_32_RSP_SIZE, 763                |
| MAC_MODE_BLOCK2_TEMPKEY, 754      | READ_4_RSP_SIZE, 763                 |
| MAC_MODE_CHALLENGE, 754           | READ_ADDR_IDX, 764                   |
| MAC_MODE_IDX, 754                 | READ_COUNT, 764                      |
| MAC_MODE_INCLUDE_OTP_64, 754      | READ_ZONE_IDX, 764                   |
| MAC_MODE_INCLUDE_OTP_88, 754      | READ ZONE MASK, 764                  |
| MAC MODE INCLUDE SN, 755          | RSA2048 KEY SIZE, 764                |
| MAC_MODE_MASK, 755                | SECUREBOOT_COUNT_DIG, 764            |
| MAC_MODE_PASSTHROUGH, 755         | SECUREBOOT_COUNT_DIG_SIG, 765        |
| MAC MODE PTNONCE TEMPKEY, 755     | SECUREBOOT DIGEST SIZE, 765          |
| MAC MODE SOURCE FLAG MATCH, 755   | SECUREBOOT MAC SIZE, 765             |
| MAC_RSP_SIZE, 755                 | SECUREBOOT_MODE_ENC_MAC_FLAG, 765    |
| MAC_SIZE, 756                     | SECUREBOOT MODE FULL, 765            |
| NONCE_COUNT_LONG, 756             | SECUREBOOT_MODE_FULL_COPY, 765       |
| NONCE_COUNT_LONG_64, 756          | SECUREBOOT_MODE_FULL_STORE, 766      |
|                                   |                                      |
| NONCE_COUNT_SHORT, 756            | SECUREBOOT_MODE_IDX, 766             |
| NONCE_INPUT_IDX, 756              | SECUREBOOT_MODE_MASK, 766            |
| NONCE_MODE_IDX, 756               | SECUREBOOT_MODE_PROHIBIT_FLAG, 766   |
| NONCE_MODE_INPUT_LEN_32, 757      | SECUREBOOT_RSP_SIZE_MAC, 766         |
| NONCE_MODE_INPUT_LEN_64, 757      | SECUREBOOT_RSP_SIZE_NO_MAC, 766      |
| NONCE_MODE_INPUT_LEN_MASK, 757    | SECUREBOOT_SIGNATURE_SIZE, 767       |
| NONCE_MODE_INVALID, 757           | SECUREBOOTCONFIG_MODE_DISABLED, 767  |
| NONCE_MODE_MASK, 757              | SECUREBOOTCONFIG_MODE_FULL_BOTH,     |
| NONCE_MODE_NO_SEED_UPDATE, 757    | 767                                  |
| NONCE_MODE_PASSTHROUGH, 758       | SECUREBOOTCONFIG_MODE_FULL_DIG, 767  |
| NONCE_MODE_SEED_UPDATE, 758       | SECUREBOOTCONFIG_MODE_FULL_SIG, 767  |
| NONCE_MODE_TARGET_ALTKEYBUF, 758  | SECUREBOOTCONFIG_MODE_MASK, 767      |
| NONCE_MODE_TARGET_MASK, 758       | SECUREBOOTCONFIG_OFFSET, 768         |
| NONCE_MODE_TARGET_MSGDIGBUF, 758  | SELFTEST_COUNT, 768                  |
| NONCE_MODE_TARGET_TEMPKEY, 758    | SELFTEST_MODE_AES, 768               |
| NONCE_NUMIN_SIZE, 759             | SELFTEST_MODE_ALL, 768               |
| NONCE NUMIN SIZE PASSTHROUGH, 759 | SELFTEST_MODE_ECDH, 768              |
| NONCE_PARAM2_IDX, 759             | SELFTEST_MODE_ECDSA_SIGN_VERIFY, 768 |
| NONCE RSP SIZE LONG, 759          | SELFTEST_MODE_IDX, 769               |
| NONCE_RSP_SIZE_SHORT, 759         | SELFTEST_MODE_RNG, 769               |
| NONCE ZERO CALC MASK, 759         | SELFTEST MODE SHA, 769               |
| NONCE ZERO CALC RANDOM, 760       | SELFTEST_RSP_SIZE, 769               |
| NONCE_ZERO_CALC_TEMPKEY, 760      | SHA_COUNT_LONG, 769                  |
| OUTNONCE SIZE, 760                | SHA_COUNT_SHORT, 769                 |
| PAUSE COUNT, 760                  | SHA DATA MAX, 770                    |
| PAUSE_PARAM2_IDX, 760             | SHA_MODE_608_HMAC_END, 770           |
|                                   |                                      |
| PAUSE_RSP_SIZE, 760               | SHA_MODE_HMAC_END, 770               |
| PAUSE_SELECT_IDX, 761             | SHA_MODE_HMAC_START, 770             |
| PRIVWRITE_COUNT, 761              | SHA_MODE_HMAC_UPDATE, 770            |
| PRIVWRITE_KEYID_IDX, 761          | SHA_MODE_MASK, 770                   |
| PRIVWRITE_MAC_IDX, 761            | SHA_MODE_READ_CONTEXT, 771           |
| PRIVWRITE_MODE_ENCRYPT, 761       | SHA_MODE_SHA256_END, 771             |

| SHA_MODE_SHA256_PUBLIC, 771        | WRITE MAC SIZE, 781                             |
|------------------------------------|-------------------------------------------------|
| SHA MODE SHA256 START, 771         | WRITE_MAC_VL_IDX, 781                           |
| SHA_MODE_SHA256_UPDATE, 771        | WRITE MAC VS IDX, 781                           |
| SHA_MODE_TARGET_MASK, 771          | WRITE_RSP_SIZE, 781                             |
| SHA_MODE_WRITE_CONTEXT, 772        | WRITE_VALUE_IDX, 781                            |
| SHA RSP SIZE, 772                  | WRITE_ZONE_DATA, 781                            |
| SHA_RSP_SIZE_LONG, 772             | WRITE_ZONE_IDX, 782                             |
| SHA_RSP_SIZE_SHORT, 772            | WRITE_ZONE_MASK, 782                            |
| SIGN_COUNT, 772                    | WRITE_ZONE_OTP, 782                             |
| SIGN_KEYID_IDX, 772                | WRITE_ZONE_WITH_MAC, 782                        |
| SIGN_MODE_EXTERNAL, 773            | calib_counter                                   |
| SIGN MODE IDX, 773                 | Basic Crypto API methods for CryptoAuth Devices |
| SIGN_MODE_INCLUDE_SN, 773          | (calib_), 211                                   |
| SIGN_MODE_INTERNAL, 773            | calib_counter.c, 795                            |
| SIGN_MODE_INVALIDATE, 773          | calib_counter_increment                         |
| SIGN_MODE_MASK, 773                | Basic Crypto API methods for CryptoAuth Devices |
| SIGN_MODE_SOURCE_MASK, 774         | (calib_), 211                                   |
| SIGN_MODE_SOURCE_MSGDIGBUF, 774    | . —                                             |
|                                    | calib_counter_read                              |
| SIGN_MODE_SOURCE_TEMPKEY, 774      | Basic Crypto API methods for CryptoAuth Devices |
| SIGN_RSP_SIZE, 774                 | (calib_), 212                                   |
| UPDATE_COUNT, 774                  | calib_derivekey                                 |
| UPDATE_MODE_DEC_COUNTER, 774       | Basic Crypto API methods for CryptoAuth Devices |
| UPDATE_MODE_IDX, 775               | (calib_), 212                                   |
| UPDATE_MODE_SELECTOR, 775          | calib_derivekey.c, 795                          |
| UPDATE_MODE_USER_EXTRA, 775        | calib_ecdh                                      |
| UPDATE_MODE_USER_EXTRA_ADD, 775    | Basic Crypto API methods for CryptoAuth Devices |
| UPDATE_RSP_SIZE, 775               | (calib_), 213                                   |
| UPDATE_VALUE_IDX, 775              | calib_ecdh.c, 796                               |
| VERIFY_256_EXTERNAL_COUNT, 776     | calib_ecdh_enc, 797                             |
| VERIFY_256_KEY_SIZE, 776           | calib_ecdh_base                                 |
| VERIFY_256_SIGNATURE_SIZE, 776     | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_256_STORED_COUNT, 776       | (calib_), 213                                   |
| VERIFY_256_VALIDATE_COUNT, 776     | calib_ecdh_enc                                  |
| VERIFY_283_EXTERNAL_COUNT, 776     | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_283_KEY_SIZE, 777           | (calib_), 214                                   |
| VERIFY_283_SIGNATURE_SIZE, 777     | calib_ecdh.c, 797                               |
| VERIFY_283_STORED_COUNT, 777       | calib_ecdh_ioenc                                |
| VERIFY_283_VALIDATE_COUNT, 777     | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_DATA_IDX, 777               | (calib_), 214                                   |
| VERIFY_KEY_B283, 777               | calib_ecdh_tempkey                              |
| VERIFY_KEY_K283, 778               | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_KEY_P256, 778               | (calib_), 215                                   |
| VERIFY_KEYID_IDX, 778              | calib_ecdh_tempkey_ioenc                        |
| VERIFY_MODE_EXTERNAL, 778          | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_MODE_IDX, 778               | (calib_), 215                                   |
| VERIFY_MODE_INVALIDATE, 778        | calib_execute_command                           |
| VERIFY MODE MAC FLAG, 779          | calib_execution.c, 798                          |
| VERIFY MODE MASK, 779              | calib_execution.h, 800                          |
| VERIFY_MODE_SOURCE_MASK, 779       | calib_execution.c, 798                          |
| VERIFY_MODE_SOURCE_MSGDIGBUF, 779  | calib_execute_command, 798                      |
| VERIFY_MODE_SOURCE_TEMPKEY, 779    | calib_execution.h, 799                          |
| VERIFY_MODE_STORED, 779            | ATCA_UNSUPPORTED_CMD, 799                       |
| VERIFY_MODE_VALIDATE, 780          | calib_execute_command, 800                      |
| VERIFY_MODE_VALIDATE_EXTERNAL, 780 | calib_gendig                                    |
| VERIFY_OTHER_DATA_SIZE, 780        | Basic Crypto API methods for CryptoAuth Devices |
| VERIFY_RSP_SIZE, 780               | (calib_), 216                                   |
| VERIFY_RSP_SIZE_MAC, 780           | calib_gendig.c, 800                             |
| WRITE_ADDR_IDX, 780                | calib_genkey                                    |
| *** L/\DDI \_\D\/, / \OU           | oano_gornoy                                     |

| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
|------------------------------------------------------------------------|----------------------------------------------------------------|
| (calib_), 216                                                          | (calib_), 224                                                  |
| calib_genkey.c, 801                                                    | calib_lock.c, 803                                              |
| calib_genkey_base                                                      | calib_lock_config_zone                                         |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 216                                                          | (calib_), 225                                                  |
| calib_get_addr                                                         | calib_lock_config_zone_crc                                     |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 217                                                          | (calib_), 225                                                  |
| calib_get_pubkey                                                       | calib_lock_data_slot                                           |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 217                                                          | (calib_), 225                                                  |
| calib_get_zone_size                                                    | calib_lock_data_zone                                           |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib ), 218                                                          | (calib_), 226                                                  |
| calib_hmac                                                             | calib_lock_data_zone_crc                                       |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib ), 218                                                          | (calib_), 226                                                  |
| calib_hmac.c, 801                                                      | calib_mac                                                      |
| calib_hw_sha2_256                                                      | Basic Crypto API methods for CryptoAuth Devices                |
| Basic Crypto API methods for CryptoAuth Devices                        | (calib_), 227                                                  |
| (calib_), 219                                                          | calib_mac.c, 804                                               |
| calib_hw_sha2_256_finish                                               | calib_nonce                                                    |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 219                                                          | (calib_), 227                                                  |
| calib_hw_sha2_256_init                                                 | calib_nonce.c, 805                                             |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_nonce_base                                               |
| (calib_), 220                                                          | Basic Crypto API methods for CryptoAuth Devices                |
| calib_hw_sha2_256_update                                               | (calib_), 227                                                  |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_nonce_load                                               |
| (calib_), 220                                                          | Basic Crypto API methods for CryptoAuth Devices                |
| calib_idle                                                             | (calib_), 228                                                  |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_nonce_rand                                               |
| (calib_), 221                                                          | Basic Crypto API methods for CryptoAuth Devices                |
| calib_info                                                             | (calib_), 229                                                  |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_priv_write                                               |
| (calib_), 221                                                          | Basic Crypto API methods for CryptoAuth Devices                |
| calib_info.c, 802                                                      | (calib_), 229                                                  |
| calib_info_base                                                        | calib_privwrite.c, 806                                         |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_privwrite.c, 805                                         |
| (calib ), 221                                                          | calib_priv_write, 806                                          |
| calib_info_get_latch                                                   | calib_random                                                   |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 222                                                          | (calib_), 229                                                  |
| calib_info_set_latch                                                   | calib_random.c, 807                                            |
| Basic Crypto API methods for CryptoAuth Devices                        | calib_read.c, 807                                              |
| (calib_), 222                                                          |                                                                |
| . —                                                                    | calib_read_enc, 808 calib_read_bytes_zone                      |
| calib_is_locked  Basic Crypto API methods for CryptoAuth Devices       |                                                                |
| Basic Crypto API methods for CryptoAuth Devices (calib_), 223          | Basic Crypto API methods for CryptoAuth Devices (calib_), 230  |
|                                                                        | calib_read_config_zone                                         |
| calib_is_slot_locked  Pagin Crypto API methods for Crypto Auth Devices |                                                                |
| Basic Crypto API methods for CryptoAuth Devices                        | Basic Crypto API methods for CryptoAuth Devices                |
| (calib_), 223 calib_kdf                                                | (calib_), 230                                                  |
|                                                                        | calib_read_enc Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices                        |                                                                |
| (calib_), 223<br>calib_kdf.c, 803                                      | (calib_), 231<br>calib_read.c, 808                             |
| calib_lock                                                             | calib_read_cc, 606                                             |
| Valle IUUN                                                             | CAIID IEAU DUDNEY                                              |

| Basic Crypto API methods for CryptoAuth Devices | (calib_), 240                                   |
|-------------------------------------------------|-------------------------------------------------|
| (calib_), 231                                   | calib_sign.c, 812                               |
| calib_read_serial_number                        | calib_sign_base                                 |
| Basic Crypto API methods for CryptoAuth Devices | Basic Crypto API methods for CryptoAuth Devices |
| (calib_), 231                                   | (calib_), 240                                   |
| calib_read_sig                                  | calib_sign_internal                             |
| Basic Crypto API methods for CryptoAuth Devices | Basic Crypto API methods for CryptoAuth Devices |
| (calib_), 232                                   | (calib_), 241                                   |
| calib_read_zone                                 | calib_sleep                                     |
| Basic Crypto API methods for CryptoAuth Devices | Basic Crypto API methods for CryptoAuth Devices |
| (calib_), 232 calib_secureboot                  | (calib_), 241 calib_updateextra                 |
| Basic Crypto API methods for CryptoAuth Devices | — ·                                             |
| (calib_), 233                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_secureboot.c, 809                         | (calib_), 242<br>calib_updateextra.c, 813       |
| calib_secureboot_mac                            | calib_verify                                    |
| Basic Crypto API methods for CryptoAuth Devices | Basic Crypto API methods for CryptoAuth Devices |
| (calib ), 233                                   | (calib_), 242                                   |
| calib_selftest                                  | calib_verify.c, 813                             |
| Basic Crypto API methods for CryptoAuth Devices | calib_verify_extern                             |
| (calib_), 234                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_selftest.c, 810                           | (calib_), 243                                   |
| calib_sha                                       | calib_verify_extern_mac                         |
| Basic Crypto API methods for CryptoAuth Devices | Basic Crypto API methods for CryptoAuth Devices |
| (calib_), 235                                   | (calib_), 243                                   |
| calib_sha.c, 810                                | calib_verify_invalidate                         |
| calib_sha_base                                  | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 244                                   |
| (calib_), 235                                   | calib_verify_stored                             |
| calib_sha_end                                   | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 245                                   |
| (calib_), 236                                   | calib_verify_stored_mac                         |
| calib_sha_hmac                                  | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 245                                   |
| (calib_), 236                                   | calib_verify_validate                           |
| calib_sha_hmac_finish                           | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 246                                   |
| (calib_), 237                                   | calib_wakeup                                    |
| calib_sha_hmac_init                             | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 246                                   |
| (calib_), 237                                   | calib_write                                     |
| calib_sha_hmac_update                           | Basic Crypto API methods for CryptoAuth Devices |
| Basic Crypto API methods for CryptoAuth Devices | (calib_), 247                                   |
| (calib_), 238                                   | calib_write.c, 814                              |
| calib_sha_read_context                          | calib_write_enc, 815                            |
| Basic Crypto API methods for CryptoAuth Devices | calib_write_bytes_zone                          |
| (calib_), 238                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_sha_start                                 | (calib_), 247                                   |
| Basic Crypto API methods for CryptoAuth Devices | calib_write_config_counter                      |
| (calib_), 239                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_sha_update                                | (calib_), 248                                   |
| Basic Crypto API methods for CryptoAuth Devices | calib_write_config_zone                         |
| (calib_), 239                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_sha_write_context                         | (calib_), 248                                   |
| Basic Crypto API methods for CryptoAuth Devices | calib_write_enc                                 |
| (calib_), 239                                   | Basic Crypto API methods for CryptoAuth Devices |
| calib_sign                                      | (calib_), 249                                   |
| Basic Crypto API methods for CryptoAuth Devices | calib_write.c, 815                              |

| calib_write_pubkey                                | atcacert_date_enc_posix_uint32_be, 173 |
|---------------------------------------------------|----------------------------------------|
| Basic Crypto API methods for CryptoAuth Devices   | atcacert_date_enc_posix_uint32_le, 173 |
| (calib_), 249                                     | atcacert_date_enc_rfc5280_gen, 173     |
| calib_write_zone                                  | atcacert_date_enc_rfc5280_utc, 174     |
| Basic Crypto API methods for CryptoAuth Devices   | atcacert_date_format_e, 165            |
| (calib_), 249                                     | ATCACERT_DATE_FORMAT_SIZES, 200        |
| CAUSED                                            | ATCACERT_DATE_FORMAT_SIZES_COUNT,      |
| license.txt, 876                                  | 158                                    |
| cb                                                | atcacert_date_format_t, 163            |
| atca_aes_ctr_ctx, 403                             | atcacert_date_get_max_date, 174        |
| atca_aes_gcm_ctx, 405                             | atcacert_def_t, 163                    |
| CK_AES_CTR_PARAMS, 463                            | atcacert_der_adjust_length, 174        |
| CK_CAMELLIA_CTR_PARAMS, 468                       | atcacert_der_dec_ecdsa_sig_value, 174  |
| cbc_ctx                                           | atcacert_der_dec_integer, 175          |
| atca_aes_cmac_ctx, 403                            | atcacert_der_dec_length, 176           |
| cert                                              | atcacert_der_enc_ecdsa_sig_value, 176  |
| atcacert build state s, 439                       | atcacert_der_enc_integer, 177          |
| cert_def                                          | atcacert der enc length, 177           |
| atcacert_build_state_s, 440                       | atcacert_device_loc_t, 163             |
| tng_cert_map_element, 535                         | atcacert_device_zone_e, 166            |
| cert_elements                                     | atcacert_device_zone_t, 163            |
| atcacert def s, 444                               | ATCACERT_E_BAD_CERT, 158               |
| cert elements count                               | ATCACERT E BAD PARAMS, 159             |
| atcacert_def_s, 444                               | ATCACERT_E_BUFFER_TOO_SMALL, 159       |
| cert_loc                                          | ATCACERT E DECODING ERROR, 159         |
| atcacert_cert_element_s, 441                      | ATCACERT_E_ELEM_MISSING, 159           |
| cert_size                                         | ATCACERT_E_ELEM_OUT_OF_BOUNDS, 159     |
| atcacert_build_state_s, 440                       | ATCACERT E ERROR, 159                  |
| cert_sn_dev_loc                                   | ATCACERT_E_INVALID_DATE, 160           |
| atcacert_def_s, 444                               | ATCACERT_E_INVALID_TRANSFORM, 160      |
| cert_template                                     | ATCACERT E SUCCESS, 160                |
| atcacert_def_s, 444                               | ATCACERT_E_UNEXPECTED_ELEM_SIZE, 160   |
| cert_template_size                                | ATCACERT_E_UNIMPLEMENTED, 160          |
| atcacert_def_s, 444                               | ATCACERT_E_VERIFY_FAILED, 160          |
| Certificate manipulation methods (atcacert ), 153 | ATCACERT_E_WRONG_CERT_DEF, 161         |
| ATCA_PACKED, 158                                  | atcacert gen cert sn, 178              |
| atcacert_build_state_t, 162                       | atcacert_gen_challenge_hw, 178         |
| atcacert cert build finish, 168                   | atcacert gen challenge sw, 179         |
| atcacert cert build process, 168                  | atcacert get auth key id, 179          |
| atcacert_cert_build_start, 169                    | atcacert_get_cert_element, 179         |
| atcacert_cert_element_t, 162                      | atcacert get cert sn, 180              |
| atcacert_cert_loc_t, 162                          | atcacert_get_comp_cert, 180            |
| atcacert_cert_sn_src_e, 164                       | atcacert get device data, 181          |
| atcacert_cert_sn_src_t, 162                       | atcacert_get_device_locs, 181          |
| atcacert_cert_type_e, 165                         | atcacert_get_expire_date, 182          |
| atcacert_cert_type_t, 162                         | atcacert_get_issue_date, 183           |
| atcacert_create_csr, 169                          | atcacert_get_key_id, 183               |
| atcacert create csr pem, 170                      | atcacert_get_response, 184             |
| atcacert_date_dec, 170                            | atcacert_get_signature, 184            |
| atcacert_date_dec_compcert, 171                   | atcacert_get_signer_id, 185            |
| atcacert_date_dec_iso8601_sep, 171                | atcacert_get_subj_key_id, 185          |
| atcacert_date_dec_posix_uint32_be, 171            | atcacert_get_subj_public_key, 186      |
| atcacert_date_dec_posix_uint32_le, 172            | atcacert_get_tbs, 186                  |
| atcacert_date_dec_rfc5280_gen, 172                | atcacert_get_tbs_digest, 187           |
| atcacert_date_dec_rfc5280_utc, 172                | atcacert_is_device_loc_overlap, 187    |
| atcacert_date_enc, 172                            | atcacert_max_cert_size, 187            |
| atcacert_date_enc_compcert, 173                   | atcacert_merge_device_loc, 188         |
| atcacert date enc iso8601 sep. 173                | atcacert public key add padding 188    |

|                                         | OTDOEDT NUM ELEMENTO 100                          |
|-----------------------------------------|---------------------------------------------------|
| atcacert_public_key_remove_padding, 189 | STDCERT_NUM_ELEMENTS, 166                         |
| atcacert_read_cert, 189                 | STDCERT_PUBLIC_KEY, 166                           |
| atcacert_read_cert_size, 191            | STDCERT_SIGNATURE, 166                            |
| atcacert_read_device_loc, 191           | STDCERT_SIGNER_ID, 166                            |
| atcacert_read_subj_key_id, 192          | STDCERT_SUBJ_KEY_ID, 166                          |
| atcacert_set_auth_key_id, 192           | TF_BIN2HEX_LC, 168                                |
| atcacert_set_auth_key_id_raw, 192       | TF_BIN2HEX_SPACE_LC, 168                          |
| atcacert_set_cert_element, 193          | TF_BIN2HEX_SPACE_UC, 168                          |
| atcacert_set_cert_sn, 193               | TF_BIN2HEX_UC, 168                                |
| atcacert_set_comp_cert, 194             | TF_HEX2BIN_LC, 168                                |
| atcacert_set_expire_date, 195           | TF_HEX2BIN_SPACE_LC, 168                          |
| atcacert_set_issue_date, 195            | TF_HEX2BIN_SPACE_UC, 168                          |
| atcacert_set_signature, 196             | TF_HEX2BIN_UC, 168                                |
| atcacert_set_signer_id, 196             | TF NONE, 168                                      |
| atcacert_set_subj_public_key, 197       | TF REVERSE, 168                                   |
| atcacert_std_cert_element_e, 166        | TRUE, 162                                         |
| atcacert_std_cert_element_t, 163        | certificateHandle                                 |
| atcacert_tm_utc_t, 163                  | CK_CMS_SIG_PARAMS, 470                            |
| atcacert_transform_data, 197            | CERTTYPE CUSTOM                                   |
| atcacert_transform_e, 166               | Certificate manipulation methods (atcacert ), 165 |
| atcacert_transform_t, 163               | CERTTYPE X509                                     |
|                                         | <del>_</del>                                      |
| atcacert_verify_cert_hw, 198            | Certificate manipulation methods (atcacert_), 165 |
| atcacert_verify_cert_sw, 198            | cfg_ateccx08a_i2c_default                         |
| atcacert_verify_response_hw, 199        | atca_cfgs.h, 566                                  |
| atcacert_verify_response_sw, 199        | cfg_ateccx08a_kitcdc_default                      |
| atcacert_write_cert, 200                | atca_cfgs.h, 566                                  |
| CERTTYPE_CUSTOM, 165                    | cfg_ateccx08a_kithid_default                      |
| CERTTYPE_X509, 165                      | atca_cfgs.h, 566                                  |
| DATEFMT_ISO8601_SEP, 165                | cfg_ateccx08a_swi_default                         |
| DATEFMT_ISO8601_SEP_SIZE, 161           | atca_cfgs.h, 567                                  |
| DATEFMT_MAX_SIZE, 161                   | cfg_atsha20xa_i2c_default                         |
| DATEFMT_POSIX_UINT32_BE, 165            | atca_cfgs.h, 567                                  |
| DATEFMT_POSIX_UINT32_BE_SIZE, 161       | cfg_atsha20xa_kitcdc_default                      |
| DATEFMT_POSIX_UINT32_LE, 166            | atca_cfgs.h, 567                                  |
| DATEFMT_POSIX_UINT32_LE_SIZE, 161       | cfg_atsha20xa_kithid_default                      |
| DATEFMT_RFC5280_GEN, 166                | atca_cfgs.h, 567                                  |
| DATEFMT_RFC5280_GEN_SIZE, 161           | cfg_atsha20xa_swi_default                         |
| DATEFMT_RFC5280_UTC, 165                | atca_cfgs.h, 567                                  |
| DATEFMT_RFC5280_UTC_SIZE, 161           | cfg_data                                          |
| DEVZONE_CONFIG, 166                     | ATCAlfaceCfg, 454                                 |
| DEVZONE_DATA, 166                       | cfg_zone                                          |
| DEVZONE_NONE, 166                       | _pkcs11_slot_ctx, 400                             |
| DEVZONE_OTP, 166                        | chain_id                                          |
| FALSE, 162                              | atcacert_def_s, 444                               |
| SNSRC_DEVICE_SN, 165                    | challenge                                         |
| SNSRC_DEVICE_SN_HASH, 165               | Host side crypto methods (atcah_), 321            |
| SNSRC_DEVICE_SN_HASH_POS, 165           | change_baudrate                                   |
| SNSRC_DEVICE_SN_HASH_RAW, 165           | i2c_sam0_instance, 529                            |
| SNSRC_PUB_KEY_HASH, 165                 | i2c_sam_instance, 530                             |
| SNSRC_PUB_KEY_HASH_POS, 165             | i2c_start_instance, 530                           |
| SNSRC_PUB_KEY_HASH_RAW, 165             | change_i2c_speed                                  |
| SNSRC_SIGNER_ID, 165                    | Hardware abstraction layer (hal_), 268            |
| SNSRC_STORED, 165                       | charge                                            |
| SNSRC_STORED_DYNAMIC, 165               | license.txt, 876                                  |
| STDCERT_AUTH_KEY_ID, 166                | CHECKMAC_CLIENT_CHALLENGE_IDX                     |
| STDCERT_CERT_SN, 166                    | calib_command.h, 727                              |
| STDCERT EXPIRE DATE, 166                | CHECKMAC_CLIENT_CHALLENGE_SIZE                    |
| STDCERT_ISSUE_DATE, 166                 | calib_command.h, 727                              |

| CHECKMAC_CLIENT_COMMAND_SIZE        | ulNonceLen, 462                          |
|-------------------------------------|------------------------------------------|
| calib_command.h, 727                | CK_AES_CCM_PARAMS_PTR                    |
| CHECKMAC_CLIENT_RESPONSE_IDX        | pkcs11t.h, 1034                          |
| calib_command.h, 727                | CK_AES_CTR_PARAMS, 462                   |
| CHECKMAC_CLIENT_RESPONSE_SIZE       | cb, 463                                  |
| calib_command.h, 727                | pkcs11t.h, 1034                          |
| CHECKMAC_CMD_MATCH                  | ulCounterBits, 463                       |
| calib_command.h, 728                | CK_AES_CTR_PARAMS_PTR                    |
| CHECKMAC_CMD_MISMATCH               | pkcs11t.h, 1034                          |
| calib_command.h, 728                | CK_AES_GCM_PARAMS, 463                   |
| CHECKMAC_COUNT                      | pAAD, 463                                |
| calib_command.h, 728                | plv, 463                                 |
| CHECKMAC_DATA_IDX                   | pkcs11t.h, 1035                          |
| calib_command.h, 728                | ulAADLen, 464                            |
| CHECKMAC_KEYID_IDX                  | ullvBits, 464                            |
| calib_command.h, 728                | ullvLen, 464                             |
| CHECKMAC_MODE_BLOCK1_TEMPKEY        | ulTagBits, 464                           |
| calib_command.h, 728                | CK_AES_GCM_PARAMS_PTR                    |
| CHECKMAC_MODE_BLOCK2_TEMPKEY        | pkcs11t.h, 1035                          |
| calib_command.h, 729                | CK_ARIA_CBC_ENCRYPT_DATA_PARAMS, 464     |
| CHECKMAC_MODE_CHALLENGE             | iv, 464                                  |
| calib_command.h, 729                | length, 465                              |
| CHECKMAC_MODE_IDX                   | pData, 465                               |
| calib_command.h, 729                | pkcs11t.h, 1035                          |
| CHECKMAC_MODE_INCLUDE_OTP_64        | CK_ARIA_CBC_ENCRYPT_DATA_PARAMS_PTR      |
| calib_command.h, 729                | pkcs11t.h, 1035                          |
| CHECKMAC_MODE_MASK                  | CK_ATTRIBUTE, 465                        |
| calib_command.h, 729                | pkcs11t.h, 1035                          |
| CHECKMAC_MODE_SOURCE_FLAG_MATCH     | pValue, 465                              |
| calib_command.h, 729                | type, 465                                |
| CHECKMAC_OTHER_DATA_SIZE            | ulValueLen, 465                          |
| calib_command.h, 730                | CK_ATTRIBUTE_PTR                         |
| CHECKMAC_RSP_SIZE                   | pkcs11t.h, 1035                          |
| calib_command.h, 730                | CK_ATTRIBUTE_TYPE                        |
| ChipMode                            | pkcs11t.h, 1035                          |
| _atecc508a_config, 381              | CK_BBOOL                                 |
| _atecc608_config, 385               | pkcs11t.h, 1035                          |
| _atsha204a_config, 389              | CK_BYTE                                  |
| ChipOptions                         | pkcs11t.h, 1036                          |
| _atecc608_config, 385               | CK_BYTE_PTR                              |
| ciphertext                          | pkcs11t.h, 1036                          |
| atca_aes_cbc_ctx, 401               | CK_C_INITIALIZE_ARGS, 466                |
| ciphertext_block                    | CreateMutex, 466                         |
| atca_aes_gcm_ctx, 405               | DestroyMutex, 466                        |
| CK_AES_CBC_ENCRYPT_DATA_PARAMS, 461 | flags, 466                               |
| iv, 461                             | LockMutex, 466                           |
| length, 461                         | pkcs11t.h, 1036                          |
| pData, 461                          | pReserved, 466                           |
| pkcs11t.h, 1034                     | UnlockMutex, 467                         |
| CK_AES_CBC_ENCRYPT_DATA_PARAMS_PTR  | CK_C_INITIALIZE_ARGS_PTR                 |
| pkcs11t.h, 1034                     | pkcs11t.h, 1036                          |
| CK_AES_CCM_PARAMS, 461              | CK_CALLBACK_FUNCTION                     |
| pAAD, 462                           | cryptoki.h, 821                          |
| pkcs11t.h, 1034                     | pkcs11t.h, 1057, 1058                    |
| pNonce, 462                         | CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS, 467 |
| ulAADLen, 462                       | iv, 467                                  |
| ulDataLen, 462                      | length, 467                              |
| ulMACLen, 462                       | pData, 467                               |

| pkcs11t.h, 1036                         | length, 472                        |
|-----------------------------------------|------------------------------------|
| CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS_PTR | pData, 472                         |
| pkcs11t.h, 1036                         | pkcs11t.h, 1038                    |
| CK_CAMELLIA_CTR_PARAMS, 468             | CK_DES_CBC_ENCRYPT_DATA_PARAMS_PTR |
| cb, 468                                 | pkcs11t.h, 1038                    |
| pkcs11t.h, 1036                         | CK_DSA_PARAMETER_GEN_PARAM, 472    |
| ulCounterBits, 468                      | hash, 472                          |
| CK_CAMELLIA_CTR_PARAMS_PTR              | pkcs11t.h, 1038                    |
| pkcs11t.h, 1036                         | pSeed, 472                         |
| CK_CCM_PARAMS, 468                      | ulIndex, 473                       |
| pAAD, 468                               | ulSeedLen, 473                     |
| pkcs11t.h, 1037                         | CK DSA PARAMETER GEN PARAM PTR     |
| pNonce, 469                             | pkcs11t.h, 1038                    |
| ulAADLen, 469                           | CK_EC_KDF_TYPE                     |
|                                         |                                    |
| ulDataLen, 469                          | pkcs11t.h, 1038                    |
| ulMACLen, 469                           | CK_ECDH1_DERIVE_PARAMS, 473        |
| ulNonceLen, 469                         | kdf, 473                           |
| CK_CCM_PARAMS_PTR                       | pkcs11t.h, 1038                    |
| pkcs11t.h, 1037                         | pPublicData, 473                   |
| CK_CERTIFICATE_CATEGORY                 | pSharedData, 473                   |
| pkcs11t.h, 1037                         | ulPublicDataLen, 474               |
| CK_CERTIFICATE_CATEGORY_AUTHORITY       | ulSharedDataLen, 474               |
| pkcs11t.h, 944                          | CK_ECDH1_DERIVE_PARAMS_PTR         |
| CK_CERTIFICATE_CATEGORY_OTHER_ENTITY    | pkcs11t.h, 1038                    |
| pkcs11t.h, 944                          | CK_ECDH2_DERIVE_PARAMS, 474        |
| CK_CERTIFICATE_CATEGORY_TOKEN_USER      | hPrivateData, 474                  |
| pkcs11t.h, 944                          | kdf, 474                           |
| CK_CERTIFICATE_CATEGORY_UNSPECIFIED     | pkcs11t.h, 1039                    |
| pkcs11t.h, 944                          | pPublicData, 475                   |
| CK_CERTIFICATE_TYPE                     | pPublicData2, 475                  |
| pkcs11t.h, 1037                         | pSharedData, 475                   |
| CK_CHAR                                 | ulPrivateDataLen, 475              |
| pkcs11t.h, 1037                         | ulPublicDataLen, 475               |
| CK_CHAR_PTR                             | ulPublicDataLen2, 475              |
| pkcs11t.h, 1037                         | ulSharedDataLen, 475               |
| CK_CMS_SIG_PARAMS, 469                  | CK_ECDH2_DERIVE_PARAMS_PTR         |
| certificateHandle, 470                  | pkcs11t.h, 1039                    |
| pContentType, 470                       | CK_ECDH_AES_KEY_WRAP_PARAMS, 476   |
| pDigestMechanism, 470                   | kdf, 476                           |
| phosestimechanism, 470                  | pkcs11t.h, 1039                    |
| •                                       | •                                  |
| pRequestedAttributes, 470               | pSharedData, 476                   |
| pRequiredAttributes, 470                | ulAESKeyBits, 476                  |
| pSigningMechanism, 470                  | ulSharedDataLen, 476               |
| ulRequestedAttributesLen, 470           | CK_ECDH_AES_KEY_WRAP_PARAMS_PTR    |
| ulRequiredAttributesLen, 470            | pkcs11t.h, 1039                    |
| CK_CMS_SIG_PARAMS_PTR                   | CK_ECMQV_DERIVE_PARAMS, 476        |
| pkcs11t.h, 1037                         | hPrivateData, 477                  |
| CK_DATE, 471                            | kdf, 477                           |
| day, 471                                | pkcs11t.h, 1039                    |
| month, 471                              | pPublicData, 477                   |
| pkcs11t.h, 1038                         | pPublicData2, 477                  |
| year, 471                               | pSharedData, 477                   |
| CK_DECLARE_FUNCTION                     | publicKey, 477                     |
| cryptoki.h, 821                         | ulPrivateDataLen, 478              |
| CK_DECLARE_FUNCTION_POINTER             | ulPublicDataLen, 478               |
| cryptoki.h, 821                         | ulPublicDataLen2, 478              |
| CK_DES_CBC_ENCRYPT_DATA_PARAMS, 471     | ulSharedDataLen, 478               |
| iv, 472                                 | CK_ECMQV_DERIVE_PARAMS_PTR         |

| pkcs11t.h, 1039                   | pkcs11t.h, 944                     |
|-----------------------------------|------------------------------------|
| CK_EFFECTIVELY_INFINITE           | CK_JAVA_MIDP_SECURITY_DOMAIN       |
| pkcs11t.h, 944                    | pkcs11t.h, 1041                    |
| CK_EXTRACT_PARAMS                 | CK_KEA_DERIVE_PARAMS, 483          |
| pkcs11t.h, 1039                   | isSender, 483                      |
| CK_EXTRACT_PARAMS_PTR             | pkcs11t.h, 1041                    |
| pkcs11t.h, 1039                   | pPublicData, 483                   |
| CK_FALSE                          | pRandomA, 483                      |
| pkcs11t.h, 944                    | pRandomB, 483                      |
| CK_FLAGS                          | ulPublicDataLen, 483               |
| pkcs11t.h, 1040                   | ulRandomLen, 484                   |
| CK_FUNCTION_LIST, 478             | CK_KEA_DERIVE_PARAMS_PTR           |
| pkcs11t.h, 1040                   | pkcs11t.h, 1041                    |
| version, 478                      | CK_KEY_DERIVATION_STRING_DATA, 484 |
| CK_FUNCTION_LIST_PTR              | pData, 484                         |
| pkcs11t.h, 1040                   | pkcs11t.h, 1042                    |
| CK_FUNCTION_LIST_PTR_PTR          | ulLen, 484                         |
| pkcs11t.h, 1040                   | CK_KEY_DERIVATION_STRING_DATA_PTR  |
| CK_GCM_PARAMS, 479                | pkcs11t.h, 1042                    |
| pAAD, 479                         | CK_KEY_TYPE                        |
| plv, 479                          | pkcs11t.h, 1042                    |
| pkcs11t.h, 1040                   | CK_KEY_WRAP_SET_OAEP_PARAMS, 484   |
| ulAADLen, 479                     | bBC, 485                           |
| ullvBits, 479                     | pkcs11t.h, 1042                    |
| ullvLen, 479                      | pX, 485                            |
| ulTagBits, 479                    | ulXLen, 485                        |
| CK_GCM_PARAMS_PTR                 | CK_KEY_WRAP_SET_OAEP_PARAMS_PTR    |
| pkcs11t.h, 1040                   | pkcs11t.h, 1042                    |
| ·                                 | •                                  |
| CK_GOSTR3410_DERIVE_PARAMS, 480   | CK_KIP_PARAMS, 485                 |
| kdf, 480                          | hKey, 485                          |
| pkcs11t.h, 1040                   | pkcs11t.h, 1042                    |
| pPublicData, 480                  | pMechanism, 485                    |
| pUKM, 480                         | pSeed, 486                         |
| ulPublicDataLen, 480              | ulSeedLen, 486                     |
| ulUKMLen, 480                     | CK_KIP_PARAMS_PTR                  |
| CK_GOSTR3410_DERIVE_PARAMS_PTR    | pkcs11t.h, 1042                    |
| pkcs11t.h, 1040                   | CK_LONG                            |
| CK_GOSTR3410_KEY_WRAP_PARAMS, 481 | pkcs11t.h, 1042                    |
| hKey, 481                         | CK_MAC_GENERAL_PARAMS              |
| pkcs11t.h, 1041                   | pkcs11t.h, 1043                    |
| pUKM, 481                         | CK_MAC_GENERAL_PARAMS_PTR          |
| pWrapOID, 481                     | pkcs11t.h, 1043                    |
| ulUKMLen, 481                     | CK_MECHANISM, 486                  |
| ulWrapOIDLen, 481                 | mechanism, 486                     |
| CK_GOSTR3410_KEY_WRAP_PARAMS_PTR  | pkcs11t.h, 1043                    |
| pkcs11t.h, 1041                   | pParameter, 486                    |
| CK HW FEATURE TYPE                | ulParameterLen, 486                |
| pkcs11t.h, 1041                   | CK_MECHANISM_INFO, 487             |
| CK_INFO, 482                      | flags, 487                         |
| cryptokiVersion, 482              | pkcs11t.h, 1043                    |
| flags, 482                        | ulMaxKeySize, 487                  |
| libraryDescription, 482           | ulMinKeySize, 487                  |
| libraryVersion, 482               | CK_MECHANISM_INFO_PTR              |
| manufacturerID, 482               | pkcs11t.h, 1043                    |
| pkcs11t.h, 1041                   | CK_MECHANISM_PTR                   |
| ·                                 |                                    |
| CK_INFO_PTR                       | pkcs11t.h, 1043                    |
| pkcs11t.h, 1041                   | CK_MECHANISM_TYPE                  |
| CK_INVALID_HANDLE                 | pkcs11t.h, 1043                    |

| CK_MECHANISM_TYPE_PTR      | ulCount, 489                                   |
|----------------------------|------------------------------------------------|
| pkcs11t.h, 1043            | CK_OTP_SIGNATURE_INFO_PTR                      |
| CK_NEED_ARG_LIST           | pkcs11t.h, 1045                                |
| pkcs11.h, 890, 891         | CK_OTP_TIME                                    |
| CK_NOTIFICATION            | pkcs11t.h, 946                                 |
| pkcs11t.h, 1044            | CK_OTP_VALUE                                   |
| CK_OBJECT_CLASS            | pkcs11t.h, 946                                 |
| pkcs11t.h, 1044            | CK_PARAM_TYPE                                  |
| CK_OBJECT_CLASS_PTR        | pkcs11t.h, 1045                                |
| pkcs11t.h, 1044            | CK_PBE_PARAMS, 489                             |
| CK_OBJECT_HANDLE           | plnitVector, 489                               |
| pkcs11t.h, 1044            | pkcs11t.h, 1045                                |
| CK_OBJECT_HANDLE_PTR       | pPassword, 490                                 |
| pkcs11t.h, 1044            | pSalt, 490                                     |
| CK_OTP_CHALLENGE           | ullteration, 490                               |
| pkcs11t.h, 945             | ulPasswordLen, 490                             |
| CK_OTP_COUNTER             | ulSaltLen, 490                                 |
| pkcs11t.h, 945             | CK_PBE_PARAMS_PTR                              |
| CK_OTP_FLAGS               | pkcs11t.h, 1045                                |
| pkcs11t.h, 945             | CK_PKCS11_FUNCTION_INFO                        |
| CK_OTP_FORMAT_ALPHANUMERIC | pkcs11.h, 891                                  |
| pkcs11t.h, 945             | CK_PKCS5_PBKD2_PARAMS, 490                     |
| CK OTP FORMAT BINARY       | iterations, 491                                |
| pkcs11t.h, 945             | pkcs11t.h, 1045                                |
| CK_OTP_FORMAT_DECIMAL      | pPassword, 491                                 |
| pkcs11t.h, 945             | pPrfData, 491                                  |
| CK_OTP_FORMAT_HEXADECIMAL  | prf, 491                                       |
| pkcs11t.h, 945             | pSaltSourceData, 491                           |
| CK_OTP_OUTPUT_FORMAT       | saltSource, 491                                |
| pkcs11t.h, 945             | ulPasswordLen, 491                             |
| CK_OTP_OUTPUT_LENGTH       | ulPrfDataLen, 491                              |
| pkcs11t.h, 946             | ulSaltSourceDataLen, 492                       |
| CK_OTP_PARAM, 487          | CK_PKCS5_PBKD2_PARAMS2, 492                    |
| pkcs11t.h, 1044            | iterations, 492                                |
| pValue, 488                | pkcs11t.h, 1046                                |
| type, 488                  | pPassword, 492                                 |
| ulValueLen, 488            | pPrfData, 492                                  |
| CK_OTP_PARAM_IGNORED       | prf, 493                                       |
| pkcs11t.h, 946             | pSaltSourceData, 493                           |
| CK_OTP_PARAM_MANDATORY     | saltSource, 493                                |
| pkcs11t.h, 946             | ulPasswordLen, 493                             |
| CK_OTP_PARAM_OPTIONAL      | ulPrfDataLen, 493                              |
| pkcs11t.h, 946             | ulSaltSourceDataLen, 493                       |
| •                          |                                                |
| CK_OTP_PARAM_PTR           | CK_PKCS5_PBKD2_PARAMS2_PTR                     |
| pkcs11t.h, 1044            | pkcs11t.h, 1046                                |
| CK_OTP_PARAM_TYPE          | CK_PKCS5_PBKD2_PARAMS_PTR                      |
| pkcs11t.h, 1044            | pkcs11t.h, 1046                                |
| CK_OTP_PARAMS, 488         | CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_TYPE     |
| pkcs11t.h, 1045            | pkcs11t.h, 1046                                |
| pParams, 488               | CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_TYPE_PTI |
| ulCount, 488               | pkcs11t.h, 1046                                |
| CK_OTP_PARAMS_PTR          | CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE               |
| pkcs11t.h, 1045            | pkcs11t.h, 1046                                |
| CK_OTP_PIN                 | CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE_PTR           |
| pkcs11t.h, 946             | pkcs11t.h, 1046                                |
| CK_OTP_SIGNATURE_INFO, 489 | CK_PTR                                         |
| pkcs11t.h, 1045            | cryptoki.h, 821                                |
| pParams, 489               | CK_RC2_CBC_PARAMS, 493                         |

| iv, 494                          | pkcs11t.h, 1049                      |
|----------------------------------|--------------------------------------|
| pkcs11t.h, 1046                  | CK_RSA_PKCS_PSS_PARAMS, 498          |
| ulEffectiveBits, 494             | hashAlg, 498                         |
| CK_RC2_CBC_PARAMS_PTR            | mgf, 499                             |
| pkcs11t.h, 1047                  | pkcs11t.h, 1049                      |
| CK_RC2_MAC_GENERAL_PARAMS, 494   | sLen, 499                            |
| pkcs11t.h, 1047                  | CK_RSA_PKCS_PSS_PARAMS_PTR           |
| ulEffectiveBits, 494             | pkcs11t.h, 1049                      |
| ulMacLength, 494                 | CK_RV                                |
| CK_RC2_MAC_GENERAL_PARAMS_PTR    | pkcs11t.h, 1049                      |
| pkcs11t.h, 1047                  | CK_SECURITY_DOMAIN_MANUFACTURER      |
| CK_RC2_PARAMS                    | pkcs11t.h, 946                       |
| pkcs11t.h, 1047                  | CK_SECURITY_DOMAIN_OPERATOR          |
| CK_RC2_PARAMS_PTR                | pkcs11t.h, 947                       |
| pkcs11t.h, 1047                  | CK_SECURITY_DOMAIN_THIRD_PARTY       |
| CK_RC5_CBC_PARAMS, 495           | pkcs11t.h, 947                       |
| plv, 495                         | CK_SECURITY_DOMAIN_UNSPECIFIED       |
| pkcs11t.h, 1047                  | pkcs11t.h, 947                       |
| ullvLen, 495                     | CK_SEED_CBC_ENCRYPT_DATA_PARAMS, 499 |
| ulRounds, 495                    | iv, 499                              |
| ulWordsize, 495                  | length, 499                          |
| CK_RC5_CBC_PARAMS_PTR            | pData, 499                           |
| pkcs11t.h, 1047                  | pkcs11t.h, 1049                      |
| CK_RC5_MAC_GENERAL_PARAMS, 495   | CK_SEED_CBC_ENCRYPT_DATA_PARAMS_PTR  |
| pkcs11t.h, 1047                  | pkcs11t.h, 1049                      |
| ulMacLength, 496                 | CK_SESSION_HANDLE                    |
| ulRounds, 496                    | pkcs11t.h, 1050                      |
| ulWordsize, 496                  | CK_SESSION_HANDLE_PTR                |
|                                  |                                      |
| CK_RC5_MAC_GENERAL_PARAMS_PTR    | pkcs11t.h, 1050                      |
| pkcs11t.h, 1048                  | CK_SESSION_INFO, 500                 |
| CK_RC5_PARAMS, 496               | flags, 500                           |
| pkcs11t.h, 1048                  | pkcs11t.h, 1050                      |
| ulRounds, 496                    | slotID, 500                          |
| ulWordsize, 496                  | state, 500                           |
| CK_RC5_PARAMS_PTR                | ulDeviceError, 500                   |
| pkcs11t.h, 1048                  | CK_SESSION_INFO_PTR                  |
| CK_RSA_AES_KEY_WRAP_PARAMS, 497  | pkcs11t.h, 1050                      |
| pkcs11t.h, 1048                  | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501 |
| pOAEPParams, 497                 | pBaseG, 501                          |
| ulAESKeyBits, 497                | pkcs11t.h, 1050                      |
| CK_RSA_AES_KEY_WRAP_PARAMS_PTR   | pPassword, 501                       |
| pkcs11t.h, 1048                  | pPrimeP, 501                         |
| CK_RSA_PKCS_MGF_TYPE             | pPublicData, 501                     |
| pkcs11t.h, 1048                  | pRandomA, 501                        |
| CK_RSA_PKCS_MGF_TYPE_PTR         | pSubprimeQ, 502                      |
| pkcs11t.h, 1048                  | ulPAndGLen, 502                      |
| CK_RSA_PKCS_OAEP_PARAMS, 497     | ulPasswordLen, 502                   |
| hashAlg, 497                     | ulPublicDataLen, 502                 |
| mgf, 498                         | ulQLen, 502                          |
| pkcs11t.h, 1048                  | ulRandomLen, 502                     |
| pSourceData, 498                 | CK_SKIPJACK_PRIVATE_WRAP_PARAMS_PTR  |
| source, 498                      | pkcs11t.h, 1050                      |
| ulSourceDataLen, 498             | CK_SKIPJACK_RELAYX_PARAMS, 502       |
| CK_RSA_PKCS_OAEP_PARAMS_PTR      | pkcs11t.h, 1050                      |
| pkcs11t.h, 1049                  | pNewPassword, 503                    |
| CK_RSA_PKCS_OAEP_SOURCE_TYPE     | pNewPublicData, 503                  |
| pkcs11t.h, 1049                  | pNewRandomA, 503                     |
| CK_RSA_PKCS_OAEP_SOURCE_TYPE_PTR | pOldPassword, 503                    |
| UN_NOA_FNUO_UAEF_OUUNUE_ITFE_FIK | polurassworu, sus                    |

| pOldPublicData, 503                   | pkcs11t.h, 1052                               |
|---------------------------------------|-----------------------------------------------|
| pOldRandomA, 504                      | CK_TLS12_KEY_MAT_PARAMS, 510                  |
| •                                     |                                               |
| pOldWrappedX, 504                     | blsExport, 510                                |
| ulNewPasswordLen, 504                 | pkcs11t.h, 1052                               |
| ulNewPublicDataLen, 504               | pReturnedKeyMaterial, 510                     |
| ulNewRandomLen, 504                   | prfHashMechanism, 510                         |
| ulOldPasswordLen, 504                 | RandomInfo, 510                               |
| ulOldPublicDataLen, 504               | uIIVSizeInBits, 510                           |
| ulOldRandomLen, 504                   | ulKeySizeInBits, 510                          |
| ulOldWrappedXLen, 505                 | ulMacSizeInBits, 511                          |
| CK_SKIPJACK_RELAYX_PARAMS_PTR         | CK_TLS12_KEY_MAT_PARAMS_PTR                   |
| pkcs11t.h, 1050                       | pkcs11t.h, 1052                               |
| CK_SLOT_ID                            | CK_TLS12_MASTER_KEY_DERIVE_PARAMS, 511        |
| pkcs11t.h, 1051                       | pkcs11t.h, 1052                               |
| CK_SLOT_ID_PTR                        | prfHashMechanism, 511                         |
| pkcs11t.h, 1051                       | pVersion, 511                                 |
| CK_SLOT_INFO, 505                     | RandomInfo, 511                               |
| firmwareVersion, 505                  | CK_TLS12_MASTER_KEY_DERIVE_PARAMS_PTR         |
| flags, 505                            | pkcs11t.h, 1052                               |
| hardwareVersion, 505                  | CK_TLS_KDF_PARAMS, 511                        |
| manufacturerID, 505                   | pContextData, 512                             |
| pkcs11t.h, 1051                       | pkcs11t.h, 1053                               |
| slotDescription, 506                  | pLabel, 512                                   |
| CK_SLOT_INFO_PTR                      | prfMechanism, 512                             |
| pkcs11t.h, 1051                       | RandomInfo, 512                               |
| CK_SSL3_KEY_MAT_OUT, 506              | ulContextDataLength, 512                      |
| hClientKey, 506                       | ulLabelLength, 512                            |
| hClientMacSecret, 506                 | CK_TLS_KDF_PARAMS_PTR                         |
| hServerKey, 506                       | pkcs11t.h, 1053                               |
| hServerMacSecret, 506                 | CK_TLS_MAC_PARAMS, 513                        |
| pIVClient, 507                        | pkcs11t.h, 1053                               |
| pIVServer, 507                        | prfHashMechanism, 513                         |
| pkcs11t.h, 1051                       | ulMacLength, 513                              |
| CK_SSL3_KEY_MAT_OUT_PTR               | ulServerOrClient, 513                         |
| pkcs11t.h, 1051                       | CK TLS MAC PARAMS PTR                         |
| CK_SSL3_KEY_MAT_PARAMS, 507           | pkcs11t.h, 1053                               |
| blsExport, 507                        | CK_TLS_PRF_PARAMS, 513                        |
| pkcs11t.h, 1051                       | pkcs11t.h, 1053                               |
| pReturnedKeyMaterial, 507             | pLabel, 514                                   |
| RandomInfo, 507                       | pOutput, 514                                  |
| ullVSizeInBits, 508                   | pSeed, 514                                    |
| ulKeySizeInBits, 508                  | pulOutputLen, 514                             |
| ulMacSizeInBits, 508                  | ulLabelLen, 514                               |
| CK_SSL3_KEY_MAT_PARAMS_PTR            | ulSeedLen, 514                                |
| pkcs11t.h, 1051                       | CK_TLS_PRF_PARAMS_PTR                         |
| CK_SSL3_MASTER_KEY_DERIVE_PARAMS, 508 | pkcs11t.h, 1053                               |
| pkcs11t.h, 1052                       | CK_TOKEN_INFO, 514                            |
| pVersion, 508                         | firmwareVersion, 515                          |
| RandomInfo, 508                       | flags, 515                                    |
| CK_SSL3_MASTER_KEY_DERIVE_PARAMS_PTR  | hardwareVersion, 515                          |
| pkcs11t.h, 1052                       | label, 515                                    |
| CK_SSL3_RANDOM_DATA, 509              | manufacturerID, 515                           |
| pClientRandom, 509                    | model, 516                                    |
| ·                                     |                                               |
| pkcs11t.h, 1052<br>pServerRandom, 509 | pkcs11t.h, 1053                               |
| ulClientRandomLen, 509                | serialNumber, 516<br>ulFreePrivateMemory, 516 |
|                                       |                                               |
| ulServerRandomLen, 509                | ulFreePublicMemory, 516                       |
| CK_STATE                              | ulMaxPinLen, 516                              |

| ulMaxRwSessionCount, 516<br>ulMaxSessionCount, 516 | CK_WTLS_MASTER_KEY_DERIVE_PARAMS_PTF pkcs11t.h, 1055 |
|----------------------------------------------------|------------------------------------------------------|
| ulMinPinLen, 516                                   | CK_WTLS_PRF_PARAMS, 521                              |
| ulRwSessionCount, 517                              | DigestMechanism, 521                                 |
| ulSessionCount, 517                                | pkcs11t.h, 1055                                      |
| ulTotalPrivateMemory, 517                          | pLabel, 521                                          |
| ulTotalPublicMemory, 517                           | pOutput, 521                                         |
| utcTime, 517                                       | pSeed, 521                                           |
| CK_TOKEN_INFO_PTR                                  | pulOutputLen, 522                                    |
| pkcs11t.h, 1053                                    | ulLabelLen, 522                                      |
| CK_TRUE                                            | ulSeedLen, 522                                       |
| pkcs11t.h, 947                                     | CK_WTLS_PRF_PARAMS_PTR                               |
| CK_ULONG                                           | pkcs11t.h, 1056                                      |
| pkcs11t.h, 1054                                    | CK_WTLS_RANDOM_DATA, 522                             |
| CK_ULONG_PTR                                       | pClientRandom, 522                                   |
| pkcs11t.h, 1054                                    | pkcs11t.h, 1056                                      |
| CK_UNAVAILABLE_INFORMATION                         | pServerRandom, 522                                   |
| pkcs11t.h, 947                                     | ulClientRandomLen, 523                               |
| CK_USER_TYPE                                       | ulServerRandomLen, 523                               |
| pkcs11t.h, 1054                                    | CK_WTLS_RANDOM_DATA_PTR                              |
| CK_UTF8CHAR                                        | pkcs11t.h, 1056                                      |
| pkcs11t.h, 1054                                    | CK_X9_42_DH1_DERIVE_PARAMS, 523                      |
| CK_UTF8CHAR_PTR                                    | kdf, 523                                             |
| pkcs11t.h, 1054                                    | pkcs11t.h, 1056                                      |
| CK_VERSION, 517                                    | pOtherInfo, 523                                      |
| major, 518                                         | pPublicData, 523                                     |
| minor, 518                                         | ulOtherInfoLen, 524                                  |
| pkcs11t.h, 1054                                    | ulPublicDataLen, 524                                 |
| CK_VERSION_PTR                                     | CK_X9_42_DH1_DERIVE_PARAMS_PTR                       |
| pkcs11t.h, 1054                                    | pkcs11t.h, 1056                                      |
| CK_VOID_PTR                                        | CK_X9_42_DH2_DERIVE_PARAMS, 524                      |
| pkcs11t.h, 1054                                    | hPrivateData, 524                                    |
| CK_VOID_PTR_PTR                                    | kdf, 524                                             |
| pkcs11t.h, 1055                                    | pkcs11t.h, 1056                                      |
| CK_WTLS_KEY_MAT_OUT, 518                           | pOtherInfo, 525                                      |
| hKey, 518                                          | pPublicData, 525                                     |
| hMacSecret, 518                                    | pPublicData2, 525                                    |
| pIV, 518                                           | ulOtherInfoLen, 525                                  |
| pkcs11t.h, 1055                                    | ulPrivateDataLen, 525                                |
| CK_WTLS_KEY_MAT_OUT_PTR                            | ulPublicDataLen, 525                                 |
| pkcs11t.h, 1055                                    | ulPublicDataLen2, 525                                |
| CK_WTLS_KEY_MAT_PARAMS, 519                        | CK_X9_42_DH2_DERIVE_PARAMS_PTR                       |
| blsExport, 519                                     | pkcs11t.h, 1056                                      |
| DigestMechanism, 519                               | CK_X9_42_DH_KDF_TYPE                                 |
| pkcs11t.h, 1055                                    | pkcs11t.h, 1056                                      |
| pReturnedKeyMaterial, 519                          | CK_X9_42_DH_KDF_TYPE_PTR                             |
| RandomInfo, 519                                    | pkcs11t.h, 1057                                      |
| ullVSizeInBits, 519                                | CK_X9_42_MQV_DERIVE_PARAMS, 526                      |
| ulKeySizeInBits, 520                               | hPrivateData, 526                                    |
| ulMacSizeInBits, 520                               | kdf, 526                                             |
| ulSequenceNumber, 520                              | pkcs11t.h, 1057                                      |
| CK_WTLS_KEY_MAT_PARAMS_PTR                         | pOtherInfo, 526                                      |
| pkcs11t.h, 1055                                    | pPublicData, 526                                     |
| CK_WTLS_MASTER_KEY_DERIVE_PARAMS, 520              | pPublicData2, 526                                    |
| DigestMechanism, 520                               | publicKey, 527                                       |
| pkcs11t.h, 1055                                    | ulOtherInfoLen, 527                                  |
| pVersion, 520                                      | ulPrivateDataLen, 527                                |
| RandomInfo, 521                                    | ulPublicDataLen, 527                                 |

| ulPublicDataLen2, 527          | pkcs11t.h, 951                   |
|--------------------------------|----------------------------------|
| CK_X9_42_MQV_DERIVE_PARAMS_PTR | CKA_ENCRYPT                      |
| pkcs11t.h, 1057                | pkcs11t.h, 951                   |
| CKA AC ISSUER                  | CKA END DATE                     |
| pkcs11t.h, 947                 | pkcs11t.h, 951                   |
| CKA_ALLOWED_MECHANISMS         | CKA_EXPONENT_1                   |
| pkcs11t.h, 947                 | pkcs11t.h, 951                   |
| CKA_ALWAYS_AUTHENTICATE        | CKA_EXPONENT_2                   |
| pkcs11t.h, 947                 | pkcs11t.h, 951                   |
| CKA_ALWAYS_SENSITIVE           | CKA EXTRACTABLE                  |
|                                | pkcs11t.h, 951                   |
| pkcs11t.h, 948                 | •                                |
| CKA_APPLICATION                | CKA_GOST28147_PARAMS             |
| pkcs11t.h, 948                 | pkcs11t.h, 951                   |
| CKA_ATTR_TYPES                 | CKA_GOSTR3410_PARAMS             |
| pkcs11t.h, 948                 | pkcs11t.h, 951                   |
| CKA_AUTH_PIN_FLAGS             | CKA_GOSTR3411_PARAMS             |
| pkcs11t.h, 948                 | pkcs11t.h, 952                   |
| CKA_BASE                       | CKA_HAS_RESET                    |
| pkcs11t.h, 948                 | pkcs11t.h, 952                   |
| CKA_BITS_PER_PIXEL             | CKA_HASH_OF_ISSUER_PUBLIC_KEY    |
| pkcs11t.h, 948                 | pkcs11t.h, 952                   |
| CKA_CERTIFICATE_CATEGORY       | CKA_HASH_OF_SUBJECT_PUBLIC_KEY   |
| pkcs11t.h, 948                 | pkcs11t.h, 952                   |
| CKA_CERTIFICATE_TYPE           | CKA_HW_FEATURE_TYPE              |
| pkcs11t.h, 948                 | pkcs11t.h, 952                   |
| CKA_CHAR_COLUMNS               | CKA_ID                           |
| pkcs11t.h, 949                 | pkcs11t.h, 952                   |
| CKA_CHAR_ROWS                  | CKA_ISSUER                       |
| pkcs11t.h, 949                 | pkcs11t.h, 952                   |
| CKA_CHAR_SETS                  | CKA_JAVA_MIDP_SECURITY_DOMAIN    |
| pkcs11t.h, 949                 | pkcs11t.h, 952                   |
| CKA_CHECK_VALUE                | CKA_KEY_GEN_MECHANISM            |
| pkcs11t.h, 949                 | pkcs11t.h, 953                   |
| CKA CLASS                      | CKA_KEY_TYPE                     |
| pkcs11t.h, 949                 | pkcs11t.h, 953                   |
| CKA COEFFICIENT                | CKA LABEL                        |
| pkcs11t.h, 949                 | pkcs11t.h, 953                   |
| CKA COLOR                      | CKA_LOCAL                        |
| pkcs11t.h, 949                 | pkcs11t.h, 953                   |
| CKA COPYABLE                   | CKA_MECHANISM_TYPE               |
| <del>_</del>                   |                                  |
| pkcs11t.h, 949<br>CKA_DECRYPT  | pkcs11t.h, 953<br>CKA_MIME_TYPES |
|                                |                                  |
| pkcs11t.h, 950                 | pkcs11t.h, 953                   |
| CKA_DEFAULT_CMS_ATTRIBUTES     | CKA_MODIFIABLE                   |
| pkcs11t.h, 950                 | pkcs11t.h, 953                   |
| CKA_DERIVE                     | CKA_MODULUS                      |
| pkcs11t.h, 950                 | pkcs11t.h, 953                   |
| CKA_DERIVE_TEMPLATE            | CKA_MODULUS_BITS                 |
| pkcs11t.h, 950                 | pkcs11t.h, 954                   |
| CKA_DESTROYABLE                | CKA_NAME_HASH_ALGORITHM          |
| pkcs11t.h, 950                 | pkcs11t.h, 954                   |
| CKA_EC_PARAMS                  | CKA_NEVER_EXTRACTABLE            |
| pkcs11t.h, 950                 | pkcs11t.h, 954                   |
| CKA_EC_POINT                   | CKA_OBJECT_ID                    |
| pkcs11t.h, 950                 | pkcs11t.h, 954                   |
| CKA_ECDSA_PARAMS               | CKA_OTP_CHALLENGE_REQUIREMENT    |
| pkcs11t.h, 950                 | pkcs11t.h, 954                   |
| CKA_ENCODING_METHODS           | CKA_OTP_COUNTER                  |

| 1 4411 054                  | 1 441 050                    |
|-----------------------------|------------------------------|
| pkcs11t.h, 954              | pkcs11t.h, 958               |
| CKA_OTP_COUNTER_REQUIREMENT | CKA_SIGN                     |
| pkcs11t.h, 954              | pkcs11t.h, 958               |
| CKA_OTP_FORMAT              | CKA_SIGN_RECOVER             |
| pkcs11t.h, 954              | pkcs11t.h, 958               |
| •                           | •                            |
| CKA_OTP_LENGTH              | CKA_START_DATE               |
| pkcs11t.h, 955              | pkcs11t.h, 958               |
| CKA_OTP_PIN_REQUIREMENT     | CKA_SUB_PRIME_BITS           |
| pkcs11t.h, 955              | pkcs11t.h, 958               |
| CKA_OTP_SERVICE_IDENTIFIER  | CKA_SUBJECT                  |
|                             |                              |
| pkcs11t.h, 955              | pkcs11t.h, 958               |
| CKA_OTP_SERVICE_LOGO        | CKA_SUBPRIME                 |
| pkcs11t.h, 955              | pkcs11t.h, 959               |
| CKA_OTP_SERVICE_LOGO_TYPE   | CKA_SUBPRIME_BITS            |
| pkcs11t.h, 955              | pkcs11t.h, 959               |
| CKA_OTP_TIME                | CKA_SUPPORTED_CMS_ATTRIBUTES |
|                             |                              |
| pkcs11t.h, 955              | pkcs11t.h, 959               |
| CKA_OTP_TIME_INTERVAL       | CKA_TOKEN                    |
| pkcs11t.h, 955              | pkcs11t.h, 959               |
| CKA OTP TIME REQUIREMENT    | CKA TRUSTED                  |
| pkcs11t.h, 955              | pkcs11t.h, 959               |
| •                           | •                            |
| CKA_OTP_USER_FRIENDLY_MODE  | CKA_UNWRAP                   |
| pkcs11t.h, 956              | pkcs11t.h, 959               |
| CKA_OTP_USER_IDENTIFIER     | CKA_UNWRAP_TEMPLATE          |
| pkcs11t.h, 956              | pkcs11t.h, 959               |
| CKA_OWNER                   | CKA URL                      |
| pkcs11t.h, 956              | pkcs11t.h, 959               |
| CKA PIXEL X                 | CKA VALUE                    |
|                             | <del>_</del>                 |
| pkcs11t.h, 956              | pkcs11t.h, 960               |
| CKA_PIXEL_Y                 | CKA_VALUE_BITS               |
| pkcs11t.h, 956              | pkcs11t.h, 960               |
| CKA_PRIME                   | CKA_VALUE_LEN                |
| pkcs11t.h, 956              | pkcs11t.h, 960               |
| CKA PRIME 1                 | CKA_VENDOR_DEFINED           |
| pkcs11t.h, 956              | pkcs11t.h, 960               |
| •                           | •                            |
| CKA_PRIME_2                 | CKA_VERIFY                   |
| pkcs11t.h, 956              | pkcs11t.h, 960               |
| CKA_PRIME_BITS              | CKA_VERIFY_RECOVER           |
| pkcs11t.h, 957              | pkcs11t.h, 960               |
| CKA PRIVATE                 | CKA WRAP                     |
| pkcs11t.h, 957              | pkcs11t.h, 960               |
| •                           | •                            |
| CKA_PRIVATE_EXPONENT        | CKA_WRAP_TEMPLATE            |
| pkcs11t.h, 957              | pkcs11t.h, 960               |
| CKA_PUBLIC_EXPONENT         | CKA_WRAP_WITH_TRUSTED        |
| pkcs11t.h, 957              | pkcs11t.h, 961               |
| CKA PUBLIC KEY INFO         | CKC_OPENPGP                  |
| pkcs11t.h, 957              | pkcs11t.h, 961               |
| •                           | •                            |
| CKA_REQUIRED_CMS_ATTRIBUTES | CKC_VENDOR_DEFINED           |
| pkcs11t.h, 957              | pkcs11t.h, 961               |
| CKA_RESET_ON_INIT           | CKC_WTLS                     |
| pkcs11t.h, 957              | pkcs11t.h, 961               |
| CKA_RESOLUTION              | CKC_X_509                    |
| pkcs11t.h, 957              | pkcs11t.h, 961               |
| CKA_SECONDARY_AUTH          |                              |
|                             | CKC_X_509_ATTR_CERT          |
| pkcs11t.h, 958              | pkcs11t.h, 961               |
| CKA_SENSITIVE               | CKD_CPDIVERSIFY_KDF          |
| pkcs11t.h, 958              | pkcs11t.h, 961               |
| CKA SERIAL NUMBER           | CKD NULL                     |

| pkcs11t.h, 961                          | pkcs11t.h, 965                               |
|-----------------------------------------|----------------------------------------------|
| CKD_SHA1_KDF                            | CKF_HW                                       |
| pkcs11t.h, 962                          | pkcs11t.h, 965                               |
| CKD_SHA1_KDF_ASN1                       | CKF_HW_SLOT                                  |
| pkcs11t.h, 962                          | pkcs11t.h, 965                               |
| CKD_SHA1_KDF_CONCATENATE                | CKF_LIBRARY_CANT_CREATE_OS_THREADS           |
| pkcs11t.h, 962                          | pkcs11t.h, 965                               |
| CKD_SHA224_KDF                          | CKF_LOGIN_REQUIRED                           |
| pkcs11t.h, 962                          | pkcs11t.h, 966                               |
| CKD SHA256 KDF                          | CKF_NEXT_OTP                                 |
| pkcs11t.h, 962                          | <br>pkcs11t.h, 966                           |
| CKD_SHA384_KDF                          | CKF_OS_LOCKING_OK                            |
| pkcs11t.h, 962                          | pkcs11t.h, 966                               |
| CKD_SHA512_KDF                          | CKF_PROTECTED_AUTHENTICATION_PATH            |
| pkcs11t.h, 962                          | pkcs11t.h, 966                               |
| CKF_ARRAY_ATTRIBUTE                     | CKF_REMOVABLE_DEVICE                         |
| pkcs11t.h, 962                          | pkcs11t.h, 966                               |
| CKF_CLOCK_ON_TOKEN                      | CKF RESTORE KEY NOT NEEDED                   |
| pkcs11t.h, 963                          | pkcs11t.h, 966                               |
| CKF_DECRYPT                             | CKF_RNG                                      |
| pkcs11t.h, 963                          | pkcs11t.h, 966                               |
| CKF_DERIVE                              | CKF RW SESSION                               |
| pkcs11t.h, 963                          | pkcs11t.h, 966                               |
| CKF_DIGEST                              | CKF_SECONDARY_AUTHENTICATION                 |
| pkcs11t.h, 963                          | pkcs11t.h, 967                               |
| CKF_DONT_BLOCK                          | CKF_SERIAL_SESSION                           |
| pkcs11t.h, 963                          | pkcs11t.h, 967                               |
| CKF_DUAL_CRYPTO_OPERATIONS              | CKF_SIGN                                     |
| pkcs11t.h, 963                          | pkcs11t.h, 967                               |
| CKF_EC_COMPRESS                         | CKF_SIGN_RECOVER                             |
| pkcs11t.h, 963                          | pkcs11t.h, 967                               |
| CKF_EC_ECPARAMETERS                     | CKF_SO_PIN_COUNT_LOW                         |
| pkcs11t.h, 963                          | pkcs11t.h, 967                               |
| CKF_EC_F_2M                             | CKF_SO_PIN_FINAL_TRY                         |
| pkcs11t.h, 964                          | pkcs11t.h, 967                               |
| CKF_EC_F_P                              | CKF_SO_PIN_LOCKED                            |
| pkcs11t.h, 964                          | pkcs11t.h, 967                               |
| CKF_EC_NAMEDCURVE                       | CKF_SO_PIN_TO_BE_CHANGED                     |
| pkcs11t.h, 964                          | pkcs11t.h, 967                               |
| CKF_EC_UNCOMPRESS                       | CKF_TOKEN_INITIALIZED                        |
| pkcs11t.h, 964                          | pkcs11t.h, 968                               |
| CKF ENCRYPT                             | CKF_TOKEN_PRESENT                            |
| pkcs11t.h, 964                          | pkcs11t.h, 968                               |
| CKF ERROR STATE                         | CKF UNWRAP                                   |
| pkcs11t.h, 964                          | pkcs11t.h, 968                               |
| CKF_EXCLUDE_CHALLENGE                   | CKF_USER_FRIENDLY_OTP                        |
| pkcs11t.h, 964                          | pkcs11t.h, 968                               |
| CKF EXCLUDE COUNTER                     | CKF USER PIN COUNT LOW                       |
| pkcs11t.h, 964                          | pkcs11t.h, 968                               |
| CKF_EXCLUDE_PIN                         | CKF_USER_PIN_FINAL_TRY                       |
| pkcs11t.h, 965                          | pkcs11t.h, 968                               |
| CKF_EXCLUDE_TIME                        | CKF_USER_PIN_INITIALIZED                     |
|                                         |                                              |
| pkcs11t.h, 965<br>CKF EXTENSION         | pkcs11t.h, 968<br>CKF_USER_PIN_LOCKED        |
| pkcs11t.h, 965                          |                                              |
| CKF_GENERATE                            | pkcs11t.h, 968<br>CKF_USER_PIN_TO_BE_CHANGED |
|                                         |                                              |
| pkcs11t.h, 965<br>CKF GENERATE KEY PAIR | pkcs11t.h, 969<br>CKF VERIFY                 |
| AND ALIMINALI OF LEAD                   | V4VI VI III I                                |

| pkcs11t.h, 969        | pkcs11t.h, 972              |
|-----------------------|-----------------------------|
| CKF VERIFY RECOVER    | CKK ECDSA                   |
| pkcs11t.h, 969        | pkcs11t.h, 972              |
| CKF WRAP              | CKK_GENERIC_SECRET          |
| _                     | pkcs11t.h, 973              |
| pkcs11t.h, 969        | -                           |
| CKF_WRITE_PROTECTED   | CKK_GOST28147               |
| pkcs11t.h, 969        | pkcs11t.h, 973              |
| CKG_MGF1_SHA1         | CKK_GOSTR3410               |
| pkcs11t.h, 969        | pkcs11t.h, 973              |
| CKG_MGF1_SHA224       | CKK_GOSTR3411               |
| pkcs11t.h, 969        | pkcs11t.h, 973              |
| CKG_MGF1_SHA256       | CKK HOTP                    |
| pkcs11t.h, 969        | pkcs11t.h, 973              |
| CKG_MGF1_SHA384       | CKK IDEA                    |
| pkcs11t.h, 970        | <del>-</del>                |
| •                     | pkcs11t.h, 973              |
| CKG_MGF1_SHA512       | CKK_JUNIPER                 |
| pkcs11t.h, 970        | pkcs11t.h, 973              |
| CKH_CLOCK             | CKK_KEA                     |
| pkcs11t.h, 970        | pkcs11t.h, <mark>973</mark> |
| CKH_MONOTONIC_COUNTER | CKK_MD5_HMAC                |
| pkcs11t.h, 970        | pkcs11t.h, 974              |
| CKH_USER_INTERFACE    | CKK RC2                     |
| pkcs11t.h, 970        | pkcs11t.h, 974              |
| CKH_VENDOR_DEFINED    | CKK RC4                     |
|                       | _                           |
| pkcs11t.h, 970        | pkcs11t.h, 974              |
| CKK_ACTI              | CKK_RC5                     |
| pkcs11t.h, 970        | pkcs11t.h, 974              |
| CKK_AES               | CKK_RIPEMD128_HMAC          |
| pkcs11t.h, 970        | pkcs11t.h, 974              |
| CKK_ARIA              | CKK_RIPEMD160_HMAC          |
| pkcs11t.h, 971        | pkcs11t.h, 974              |
| CKK BATON             | CKK RSA                     |
| pkcs11t.h, 971        | pkcs11t.h, 974              |
| CKK BLOWFISH          | CKK SECURID                 |
| <del>_</del>          | <del>_</del>                |
| pkcs11t.h, 971        | pkcs11t.h, 974              |
| CKK_CAMELLIA          | CKK_SEED                    |
| pkcs11t.h, 971        | pkcs11t.h, 975              |
| CKK_CAST              | CKK_SHA224_HMAC             |
| pkcs11t.h, 971        | pkcs11t.h, 975              |
| CKK_CAST128           | CKK_SHA256_HMAC             |
| pkcs11t.h, 971        | pkcs11t.h, 975              |
| CKK CAST3             | CKK_SHA384_HMAC             |
| pkcs11t.h, 971        | pkcs11t.h, 975              |
| CKK CAST5             | CKK_SHA512_HMAC             |
| <del>_</del>          |                             |
| pkcs11t.h, 971        | pkcs11t.h, 975              |
| CKK_CDMF              | CKK_SHA_1_HMAC              |
| pkcs11t.h, 972        | pkcs11t.h, 975              |
| CKK_DES               | CKK_SKIPJACK                |
| pkcs11t.h, 972        | pkcs11t.h, 975              |
| CKK_DES2              | CKK_TWOFISH                 |
| pkcs11t.h, 972        | pkcs11t.h, 975              |
| CKK DES3              | CKK_VENDOR_DEFINED          |
| pkcs11t.h, 972        | pkcs11t.h, 976              |
| ·                     | -                           |
| CKK_DH                | CKK_X9_42_DH                |
| pkcs11t.h, 972        | pkcs11t.h, 976              |
| CKK_DSA               | CKM_ACTI                    |
| pkcs11t.h, 972        | pkcs11t.h, 976              |
| CKK_EC                | CKM_ACTI_KEY_GEN            |

| pkcs11t.h, 976            | pkcs11t.h, 980                |
|---------------------------|-------------------------------|
| CKM_AES_CBC               | CKM_ARIA_KEY_GEN              |
| pkcs11t.h, 976            | pkcs11t.h, 980                |
| CKM_AES_CBC_ENCRYPT_DATA  | CKM_ARIA_MAC                  |
| pkcs11t.h, 976            | pkcs11t.h, 980                |
| CKM AES CBC PAD           | CKM_ARIA_MAC_GENERAL          |
| pkcs11t.h, 976            | pkcs11t.h, 980                |
| ·                         | •                             |
| CKM_AES_CCM               | CKM_BATON_CBC128              |
| pkcs11t.h, 976            | pkcs11t.h, 980                |
| CKM_AES_CFB1              | CKM_BATON_COUNTER             |
| pkcs11t.h, 977            | pkcs11t.h, 980                |
| CKM_AES_CFB128            | CKM_BATON_ECB128              |
| pkcs11t.h, 977            | pkcs11t.h, 980                |
| CKM_AES_CFB64             | CKM_BATON_ECB96               |
| pkcs11t.h, 977            | pkcs11t.h, 980                |
| CKM_AES_CFB8              | CKM_BATON_KEY_GEN             |
| pkcs11t.h, 977            | pkcs11t.h, 981                |
| CKM_AES_CMAC              | CKM BATON SHUFFLE             |
| pkcs11t.h, 977            | pkcs11t.h, 981                |
| CKM_AES_CMAC_GENERAL      | CKM_BATON_WRAP                |
|                           |                               |
| pkcs11t.h, 977            | pkcs11t.h, 981                |
| CKM_AES_CTR               | CKM_BLOWFISH_CBC              |
| pkcs11t.h, 977            | pkcs11t.h, 981                |
| CKM_AES_CTS               | CKM_BLOWFISH_CBC_PAD          |
| pkcs11t.h, 977            | pkcs11t.h, 981                |
| CKM_AES_ECB               | CKM_BLOWFISH_KEY_GEN          |
| pkcs11t.h, 978            | pkcs11t.h, 981                |
| CKM_AES_ECB_ENCRYPT_DATA  | CKM_CAMELLIA_CBC              |
| pkcs11t.h, 978            | pkcs11t.h, 981                |
| CKM_AES_GCM               | CKM_CAMELLIA_CBC_ENCRYPT_DATA |
| pkcs11t.h, 978            | pkcs11t.h, 981                |
| CKM_AES_GMAC              | CKM_CAMELLIA_CBC_PAD          |
| pkcs11t.h, 978            | pkcs11t.h, 982                |
| •                         | •                             |
| CKM_AES_KEY_GEN           | CKM_CAMELLIA_CTR              |
| pkcs11t.h, 978            | pkcs11t.h, 982                |
| CKM_AES_KEY_WRAP          | CKM_CAMELLIA_ECB              |
| pkcs11t.h, 978            | pkcs11t.h, 982                |
| CKM_AES_KEY_WRAP_PAD      | CKM_CAMELLIA_ECB_ENCRYPT_DATA |
| pkcs11t.h, 978            | pkcs11t.h, 982                |
| CKM_AES_MAC               | CKM_CAMELLIA_KEY_GEN          |
| pkcs11t.h, 978            | pkcs11t.h, 982                |
| CKM_AES_MAC_GENERAL       | CKM_CAMELLIA_MAC              |
| pkcs11t.h, 979            | pkcs11t.h, 982                |
| CKM_AES_OFB               | CKM_CAMELLIA_MAC_GENERAL      |
|                           |                               |
| pkcs11t.h, 979            | pkcs11t.h, 982                |
| CKM_AES_XCBC_MAC          | CKM_CAST128_CBC               |
| pkcs11t.h, 979            | pkcs11t.h, 982                |
| CKM_AES_XCBC_MAC_96       | CKM_CAST128_CBC_PAD           |
| pkcs11t.h, 979            | pkcs11t.h, 983                |
| CKM_ARIA_CBC              | CKM_CAST128_ECB               |
| pkcs11t.h, 979            | pkcs11t.h, 983                |
| CKM_ARIA_CBC_ENCRYPT_DATA | CKM_CAST128_KEY_GEN           |
| pkcs11t.h, 979            | pkcs11t.h, 983                |
| CKM_ARIA_CBC_PAD          | CKM_CAST128_MAC               |
| pkcs11t.h, 979            | pkcs11t.h, 983                |
|                           | •                             |
| CKM_ARIA_ECB              | CKM_CAST128_MAC_GENERAL       |
| pkcs11t.h, 979            | pkcs11t.h, 983                |
| CKM_ARIA_ECB_ENCRYPT_DATA | CKM_CAST3_CBC                 |

| pkcs11t.h, 983                | pkcs11t.h, 987                     |
|-------------------------------|------------------------------------|
| CKM_CAST3_CBC_PAD             | CKM_DES3_CBC_ENCRYPT_DATA          |
| pkcs11t.h, 983                | pkcs11t.h, 987                     |
| CKM_CAST3_ECB                 | CKM_DES3_CBC_PAD                   |
| pkcs11t.h, 983                | pkcs11t.h, 987                     |
| CKM_CAST3_KEY_GEN             | CKM DES3 CMAC                      |
| pkcs11t.h, 984                | <br>pkcs11t.h, 987                 |
| CKM_CAST3_MAC                 | CKM_DES3_CMAC_GENERAL              |
| pkcs11t.h, 984                | pkcs11t.h, 987                     |
| CKM_CAST3_MAC_GENERAL         | CKM DES3 ECB                       |
|                               |                                    |
| pkcs11t.h, 984                | pkcs11t.h, 987                     |
| CKM_CAST5_CBC                 | CKM_DES3_ECB_ENCRYPT_DATA          |
| pkcs11t.h, 984                | pkcs11t.h, 988                     |
| CKM_CAST5_CBC_PAD             | CKM_DES3_KEY_GEN                   |
| pkcs11t.h, 984                | pkcs11t.h, 988                     |
| CKM_CAST5_ECB                 | CKM_DES3_MAC                       |
| pkcs11t.h, 984                | pkcs11t.h, 988                     |
| CKM_CAST5_KEY_GEN             | CKM_DES3_MAC_GENERAL               |
| pkcs11t.h, 984                | pkcs11t.h, 988                     |
| CKM CAST5 MAC                 | CKM_DES_CBC                        |
| pkcs11t.h, 984                | pkcs11t.h, 988                     |
| CKM_CAST5_MAC_GENERAL         | CKM_DES_CBC_ENCRYPT_DATA           |
| pkcs11t.h, 985                | pkcs11t.h, 988                     |
| CKM_CAST_CBC                  | CKM_DES_CBC_PAD                    |
| pkcs11t.h, 985                | pkcs11t.h, 988                     |
| •                             | •                                  |
| CKM_CAST_CBC_PAD              | CKM_DES_CFB64                      |
| pkcs11t.h, 985                | pkcs11t.h, 988                     |
| CKM_CAST_ECB                  | CKM_DES_CFB8                       |
| pkcs11t.h, 985                | pkcs11t.h, 989                     |
| CKM_CAST_KEY_GEN              | CKM_DES_ECB                        |
| pkcs11t.h, 985                | pkcs11t.h, 989                     |
| CKM_CAST_MAC                  | CKM_DES_ECB_ENCRYPT_DATA           |
| pkcs11t.h, 985                | pkcs11t.h, 989                     |
| CKM_CAST_MAC_GENERAL          | CKM_DES_KEY_GEN                    |
| pkcs11t.h, 985                | pkcs11t.h, 989                     |
| CKM_CDMF_CBC                  | CKM_DES_MAC                        |
| pkcs11t.h, 985                | pkcs11t.h, 989                     |
| CKM_CDMF_CBC_PAD              | CKM_DES_MAC_GENERAL                |
| pkcs11t.h, 986                | pkcs11t.h, 989                     |
| CKM_CDMF_ECB                  | CKM_DES_OFB64                      |
| pkcs11t.h, 986                | pkcs11t.h, 989                     |
| CKM_CDMF_KEY_GEN              | CKM DES OFB8                       |
| pkcs11t.h, 986                | pkcs11t.h, 989                     |
|                               |                                    |
| CKM_CDMF_MAC                  | CKM_DH_PKCS_DERIVE                 |
| pkcs11t.h, 986                | pkcs11t.h, 990                     |
| CKM_CDMF_MAC_GENERAL          | CKM_DH_PKCS_KEY_PAIR_GEN           |
| pkcs11t.h, 986                | pkcs11t.h, 990                     |
| CKM_CMS_SIG                   | CKM_DH_PKCS_PARAMETER_GEN          |
| pkcs11t.h, 986                | pkcs11t.h, 990                     |
| CKM_CONCATENATE_BASE_AND_DATA | CKM_DSA                            |
| pkcs11t.h, 986                | pkcs11t.h, 990                     |
| CKM_CONCATENATE_BASE_AND_KEY  | CKM_DSA_KEY_PAIR_GEN               |
| pkcs11t.h, 986                | pkcs11t.h, 990                     |
| CKM_CONCATENATE_DATA_AND_BASE | CKM_DSA_PARAMETER_GEN              |
| pkcs11t.h, 987                | pkcs11t.h, 990                     |
| CKM_DES2_KEY_GEN              | CKM_DSA_PROBABLISTIC_PARAMETER_GEN |
| pkcs11t.h, 987                | pkcs11t.h, 990                     |
| CKM DES3 CBC                  | CKM_DSA_SHA1                       |
| 01/m_DE00_ODO                 | OTAM_DOTA_OTIMAT                   |

| pkcs11t.h, 990                     | pkcs11t.h, 994               |
|------------------------------------|------------------------------|
| CKM_DSA_SHA224                     | CKM_GOSTR3410_KEY_WRAP       |
| pkcs11t.h, 991                     | pkcs11t.h, 994               |
| CKM_DSA_SHA256                     | CKM_GOSTR3410_WITH_GOSTR3411 |
| pkcs11t.h, 991                     | pkcs11t.h, 994               |
| CKM_DSA_SHA384                     | CKM GOSTR3411                |
| pkcs11t.h, 991                     | pkcs11t.h, 994               |
| CKM_DSA_SHA512                     | CKM_GOSTR3411_HMAC           |
|                                    | pkcs11t.h, 995               |
| pkcs11t.h, 991                     | •                            |
| CKM_DSA_SHAWE_TAYLOR_PARAMETER_GEN | CKM_HOTP                     |
| pkcs11t.h, 991                     | pkcs11t.h, 995               |
| CKM_EC_KEY_PAIR_GEN                | CKM_HOTP_KEY_GEN             |
| pkcs11t.h, 991                     | pkcs11t.h, 995               |
| CKM_ECDH1_COFACTOR_DERIVE          | CKM_IDEA_CBC                 |
| pkcs11t.h, 991                     | pkcs11t.h, 995               |
| CKM_ECDH1_DERIVE                   | CKM_IDEA_CBC_PAD             |
| pkcs11t.h, 991                     | pkcs11t.h, 995               |
| CKM_ECDH_AES_KEY_WRAP              | CKM_IDEA_ECB                 |
| pkcs11t.h, 992                     | pkcs11t.h, 995               |
| CKM ECDSA                          | CKM_IDEA_KEY_GEN             |
| pkcs11t.h, 992                     | pkcs11t.h, 995               |
| CKM_ECDSA_KEY_PAIR_GEN             | CKM IDEA MAC                 |
| pkcs11t.h, 992                     | pkcs11t.h, 995               |
| •                                  | CKM IDEA MAC GENERAL         |
| CKM_ECDSA_SHA1                     |                              |
| pkcs11t.h, 992                     | pkcs11t.h, 996               |
| CKM_ECDSA_SHA224                   | CKM_JUNIPER_CBC128           |
| pkcs11t.h, 992                     | pkcs11t.h, 996               |
| CKM_ECDSA_SHA256                   | CKM_JUNIPER_COUNTER          |
| pkcs11t.h, 992                     | pkcs11t.h, 996               |
| CKM_ECDSA_SHA384                   | CKM_JUNIPER_ECB128           |
| pkcs11t.h, 992                     | pkcs11t.h, 996               |
| CKM_ECDSA_SHA512                   | CKM_JUNIPER_KEY_GEN          |
| pkcs11t.h, 992                     | pkcs11t.h, 996               |
| CKM_ECMQV_DERIVE                   | CKM_JUNIPER_SHUFFLE          |
| pkcs11t.h, 993                     | pkcs11t.h, 996               |
| CKM_EXTRACT_KEY_FROM_KEY           | CKM JUNIPER WRAP             |
| pkcs11t.h, 993                     | pkcs11t.h, 996               |
| CKM FASTHASH                       | CKM KEA DERIVE               |
| pkcs11t.h, 993                     | pkcs11t.h, 996               |
| CKM_FORTEZZA_TIMESTAMP             | CKM_KEA_KEY_DERIVE           |
|                                    |                              |
| pkcs11t.h, 993                     | pkcs11t.h, 997               |
| CKM_GENERIC_SECRET_KEY_GEN         | CKM_KEA_KEY_PAIR_GEN         |
| pkcs11t.h, 993                     | pkcs11t.h, 997               |
| CKM_GOST28147                      | CKM_KEY_WRAP_LYNKS           |
| pkcs11t.h, 993                     | pkcs11t.h, 997               |
| CKM_GOST28147_ECB                  | CKM_KEY_WRAP_SET_OAEP        |
| pkcs11t.h, 993                     | pkcs11t.h, 997               |
| CKM_GOST28147_KEY_GEN              | CKM_KIP_DERIVE               |
| pkcs11t.h, 993                     | pkcs11t.h, 997               |
| CKM_GOST28147_KEY_WRAP             | CKM KIP MAC                  |
| pkcs11t.h, 994                     | pkcs11t.h, 997               |
| CKM_GOST28147_MAC                  | CKM_KIP_WRAP                 |
| pkcs11t.h, 994                     | pkcs11t.h, 997               |
| CKM GOSTR3410                      | CKM MD2                      |
| <del>_</del>                       | <del>_</del>                 |
| pkcs11t.h, 994                     | pkcs11t.h, 997               |
| CKM_GOSTR3410_DERIVE               | CKM_MD2_HMAC                 |
| pkcs11t.h, 994                     | pkcs11t.h, 998               |
| CKM_GOSTR3410_KEY_PAIR_GEN         | CKM_MD2_HMAC_GENERAL         |

| pkcs11t.h, 998              | pkcs11t.h, 1001            |
|-----------------------------|----------------------------|
| CKM_MD2_KEY_DERIVATION      | CKM_RC4                    |
| pkcs11t.h, 998              | pkcs11t.h, 1001            |
| CKM_MD2_RSA_PKCS            | CKM_RC4_KEY_GEN            |
| pkcs11t.h, 998              | pkcs11t.h, 1002            |
| CKM MD5                     | CKM RC5 CBC                |
| pkcs11t.h, 998              | pkcs11t.h, 1002            |
| CKM_MD5_HMAC                | CKM_RC5_CBC_PAD            |
|                             |                            |
| pkcs11t.h, 998              | pkcs11t.h, 1002            |
| CKM_MD5_HMAC_GENERAL        | CKM_RC5_ECB                |
| pkcs11t.h, 998              | pkcs11t.h, 1002            |
| CKM_MD5_KEY_DERIVATION      | CKM_RC5_KEY_GEN            |
| pkcs11t.h, 998              | pkcs11t.h, 1002            |
| CKM_MD5_RSA_PKCS            | CKM_RC5_MAC                |
| pkcs11t.h, 999              | pkcs11t.h, 1002            |
| CKM_PBA_SHA1_WITH_SHA1_HMAC | CKM_RC5_MAC_GENERAL        |
| pkcs11t.h, 999              | pkcs11t.h, 1002            |
| CKM_PBE_MD2_DES_CBC         | CKM_RIPEMD128              |
| pkcs11t.h, 999              | pkcs11t.h, 1002            |
| CKM_PBE_MD5_CAST128_CBC     | CKM_RIPEMD128_HMAC         |
| pkcs11t.h, 999              | pkcs11t.h, 1003            |
| CKM_PBE_MD5_CAST3_CBC       | CKM_RIPEMD128_HMAC_GENERAL |
| pkcs11t.h, 999              | pkcs11t.h, 1003            |
| CKM PBE MD5 CAST5 CBC       | CKM_RIPEMD128_RSA_PKCS     |
| pkcs11t.h, 999              | pkcs11t.h, 1003            |
| CKM_PBE_MD5_CAST_CBC        | CKM_RIPEMD160              |
| pkcs11t.h, 999              | pkcs11t.h, 1003            |
| CKM_PBE_MD5_DES_CBC         | CKM_RIPEMD160_HMAC         |
| pkcs11t.h, 999              | pkcs11t.h, 1003            |
| CKM_PBE_SHA1_CAST128_CBC    | CKM_RIPEMD160_HMAC_GENERAL |
| pkcs11t.h, 1000             | pkcs11t.h, 1003            |
| CKM_PBE_SHA1_CAST5_CBC      | CKM_RIPEMD160_RSA_PKCS     |
| pkcs11t.h, 1000             | pkcs11t.h, 1003            |
| CKM PBE SHA1 DES2 EDE CBC   | CKM RSA 9796               |
| pkcs11t.h, 1000             | pkcs11t.h, 1003            |
| ·                           | CKM_RSA_AES_KEY_WRAP       |
| CKM_PBE_SHA1_DES3_EDE_CBC   |                            |
| pkcs11t.h, 1000             | pkcs11t.h, 1004            |
| CKM_PBE_SHA1_RC2_128_CBC    | CKM_RSA_PKCS               |
| pkcs11t.h, 1000             | pkcs11t.h, 1004            |
| CKM_PBE_SHA1_RC2_40_CBC     | CKM_RSA_PKCS_KEY_PAIR_GEN  |
| pkcs11t.h, 1000             | pkcs11t.h, 1004            |
| CKM_PBE_SHA1_RC4_128        | CKM_RSA_PKCS_OAEP          |
| pkcs11t.h, 1000             | pkcs11t.h, 1004            |
| CKM_PBE_SHA1_RC4_40         | CKM_RSA_PKCS_OAEP_TPM_1_1  |
| pkcs11t.h, 1000             | pkcs11t.h, 1004            |
| CKM_PKCS5_PBKD2             | CKM_RSA_PKCS_PSS           |
| pkcs11t.h, 1001             | pkcs11t.h, 1004            |
| CKM_RC2_CBC                 | CKM_RSA_PKCS_TPM_1_1       |
| pkcs11t.h, 1001             | pkcs11t.h, 1004            |
| CKM_RC2_CBC_PAD             | CKM_RSA_X9_31              |
| pkcs11t.h, 1001             | pkcs11t.h, 1004            |
| CKM_RC2_ECB                 | CKM_RSA_X9_31_KEY_PAIR_GEN |
| pkcs11t.h, 1001             | pkcs11t.h, 1005            |
| CKM_RC2_KEY_GEN             | CKM_RSA_X_509              |
| pkcs11t.h, 1001             | pkcs11t.h, 1005            |
| CKM_RC2_MAC                 | CKM_SECURID                |
| pkcs11t.h, 1001             | pkcs11t.h, 1005            |
| CKM RC2 MAC GENERAL         | CKM SECURID KEY GEN        |

| pkcs11t.h, 1005                 | pkcs11t.h, 1009               |
|---------------------------------|-------------------------------|
| CKM_SEED_CBC                    | CKM_SHA384_RSA_PKCS_PSS       |
| pkcs11t.h, 1005                 | pkcs11t.h, 1009               |
| CKM_SEED_CBC_ENCRYPT_DATA       | CKM SHA512                    |
| pkcs11t.h, 1005                 | pkcs11t.h, 1009               |
| CKM_SEED_CBC_PAD                | CKM_SHA512_224                |
| pkcs11t.h, 1005                 | pkcs11t.h, 1009               |
| CKM_SEED_ECB                    | CKM_SHA512_224_HMAC           |
| pkcs11t.h, 1005                 | pkcs11t.h, 1009               |
| CKM_SEED_ECB_ENCRYPT_DATA       | CKM_SHA512_224_HMAC_GENERAL   |
| pkcs11t.h, 1006                 | pkcs11t.h, 1009               |
| CKM SEED KEY GEN                | CKM_SHA512_224_KEY_DERIVATION |
|                                 | pkcs11t.h, 1009               |
| pkcs11t.h, 1006<br>CKM_SEED_MAC | CKM_SHA512_256                |
|                                 |                               |
| pkcs11t.h, 1006                 | pkcs11t.h, 1009               |
| CKM_SEED_MAC_GENERAL            | CKM_SHA512_256_HMAC           |
| pkcs11t.h, 1006                 | pkcs11t.h, 1010               |
| CKM_SHA1_KEY_DERIVATION         | CKM_SHA512_256_HMAC_GENERAL   |
| pkcs11t.h, 1006                 | pkcs11t.h, 1010               |
| CKM_SHA1_RSA_PKCS               | CKM_SHA512_256_KEY_DERIVATION |
| pkcs11t.h, 1006                 | pkcs11t.h, 1010               |
| CKM_SHA1_RSA_PKCS_PSS           | CKM_SHA512_HMAC               |
| pkcs11t.h, 1006                 | pkcs11t.h, 1010               |
| CKM_SHA1_RSA_X9_31              | CKM_SHA512_HMAC_GENERAL       |
| pkcs11t.h, 1006                 | pkcs11t.h, 1010               |
| CKM_SHA224                      | CKM_SHA512_KEY_DERIVATION     |
| pkcs11t.h, 1007                 | pkcs11t.h, 1010               |
| CKM_SHA224_HMAC                 | CKM_SHA512_RSA_PKCS           |
| pkcs11t.h, 1007                 | pkcs11t.h, 1010               |
| CKM_SHA224_HMAC_GENERAL         | CKM_SHA512_RSA_PKCS_PSS       |
| pkcs11t.h, 1007                 | pkcs11t.h, 1010               |
| CKM_SHA224_KEY_DERIVATION       | CKM_SHA512_T                  |
| pkcs11t.h, 1007                 | pkcs11t.h, 1011               |
| CKM_SHA224_RSA_PKCS             | CKM_SHA512_T_HMAC             |
| pkcs11t.h, 1007                 | pkcs11t.h, 1011               |
| CKM_SHA224_RSA_PKCS_PSS         | CKM_SHA512_T_HMAC_GENERAL     |
| pkcs11t.h, 1007                 | pkcs11t.h, 1011               |
| CKM_SHA256                      | CKM_SHA512_T_KEY_DERIVATION   |
| pkcs11t.h, 1007                 | pkcs11t.h, 1011               |
| CKM_SHA256_HMAC                 | CKM_SHA_1                     |
| pkcs11t.h, 1007                 | pkcs11t.h, 1011               |
| CKM_SHA256_HMAC_GENERAL         | CKM_SHA_1_HMAC                |
| pkcs11t.h, 1008                 | pkcs11t.h, 1011               |
| CKM_SHA256_KEY_DERIVATION       | CKM_SHA_1_HMAC_GENERAL        |
| pkcs11t.h, 1008                 | pkcs11t.h, 1011               |
| CKM_SHA256_RSA_PKCS             | CKM_SKIPJACK_CBC64            |
| pkcs11t.h, 1008                 | pkcs11t.h, 1011               |
| CKM_SHA256_RSA_PKCS_PSS         | CKM_SKIPJACK_CFB16            |
| pkcs11t.h, 1008                 | pkcs11t.h, 1012               |
| CKM_SHA384                      | CKM_SKIPJACK_CFB32            |
| pkcs11t.h, 1008                 | pkcs11t.h, 1012               |
| CKM_SHA384_HMAC                 | CKM_SKIPJACK_CFB64            |
| pkcs11t.h, 1008                 | pkcs11t.h, 1012               |
| CKM_SHA384_HMAC_GENERAL         | CKM_SKIPJACK_CFB8             |
| pkcs11t.h, 1008                 | pkcs11t.h, 1012               |
| CKM_SHA384_KEY_DERIVATION       | CKM_SKIPJACK_ECB64            |
| pkcs11t.h, 1008                 | pkcs11t.h, 1012               |
| CKM_SHA384_RSA_PKCS             | CKM_SKIPJACK_KEY_GEN          |
|                                 |                               |

| pkcs11t.h, 1012                | pkcs11t.h, 1016                    |
|--------------------------------|------------------------------------|
| CKM_SKIPJACK_OFB64             | CKM_WTLS_CLIENT_KEY_AND_MAC_DERIVE |
| pkcs11t.h, 1012                | pkcs11t.h, 1016                    |
| •                              |                                    |
| CKM_SKIPJACK_PRIVATE_WRAP      | CKM_WTLS_MASTER_KEY_DERIVE         |
| pkcs11t.h, 1012                | pkcs11t.h, 1016                    |
| CKM_SKIPJACK_RELAYX            | CKM_WTLS_MASTER_KEY_DERIVE_DH_ECC  |
| pkcs11t.h, 1013                | pkcs11t.h, 1016                    |
| CKM_SKIPJACK_WRAP              | CKM_WTLS_PRE_MASTER_KEY_GEN        |
| pkcs11t.h, 1013                | pkcs11t.h, 1016                    |
| CKM_SSL3_KEY_AND_MAC_DERIVE    | CKM_WTLS_PRF                       |
| pkcs11t.h, 1013                | pkcs11t.h, 1016                    |
| CKM_SSL3_MASTER_KEY_DERIVE     | CKM_WTLS_SERVER_KEY_AND_MAC_DERIVE |
| pkcs11t.h, 1013                | pkcs11t.h, 1017                    |
| CKM_SSL3_MASTER_KEY_DERIVE_DH  | CKM_X9_42_DH_DERIVE                |
| pkcs11t.h, 1013                | pkcs11t.h, 1017                    |
| CKM_SSL3_MD5_MAC               | CKM_X9_42_DH_HYBRID_DERIVE         |
| pkcs11t.h, 1013                | pkcs11t.h, 1017                    |
| CKM_SSL3_PRE_MASTER_KEY_GEN    | CKM_X9_42_DH_KEY_PAIR_GEN          |
| pkcs11t.h, 1013                | pkcs11t.h, 1017                    |
| CKM_SSL3_SHA1_MAC              | CKM_X9_42_DH_PARAMETER_GEN         |
|                                |                                    |
| pkcs11t.h, 1013                | pkcs11t.h, 1017                    |
| CKM_TLS10_MAC_CLIENT           | CKM_X9_42_MQV_DERIVE               |
| pkcs11t.h, 1014                | pkcs11t.h, 1017                    |
| CKM_TLS10_MAC_SERVER           | CKM_XOR_BASE_AND_DATA              |
| pkcs11t.h, 1014                | pkcs11t.h, 1017                    |
| CKM_TLS12_KDF                  | CKN_OTP_CHANGED                    |
| pkcs11t.h, 1014                | pkcs11t.h, 1017                    |
| CKM_TLS12_KEY_AND_MAC_DERIVE   | CKN_SURRENDER                      |
| pkcs11t.h, 1014                | pkcs11t.h, 1018                    |
| CKM_TLS12_KEY_SAFE_DERIVE      | CKO_CERTIFICATE                    |
| pkcs11t.h, 1014                | pkcs11t.h, 1018                    |
| CKM_TLS12_MAC                  | CKO DATA                           |
| pkcs11t.h, 1014                | pkcs11t.h, 1018                    |
| CKM_TLS12_MASTER_KEY_DERIVE    | CKO DOMAIN PARAMETERS              |
| pkcs11t.h, 1014                | pkcs11t.h, 1018                    |
| •                              | •                                  |
| CKM_TLS12_MASTER_KEY_DERIVE_DH | CKO_HW_FEATURE                     |
| pkcs11t.h, 1014                | pkcs11t.h, 1018                    |
| CKM_TLS_KDF                    | CKO_MECHANISM                      |
| pkcs11t.h, 1015                | pkcs11t.h, 1018                    |
| CKM_TLS_KEY_AND_MAC_DERIVE     | CKO_OTP_KEY                        |
| pkcs11t.h, 1015                | pkcs11t.h, 1018                    |
| CKM_TLS_MAC                    | CKO_PRIVATE_KEY                    |
| pkcs11t.h, 1015                | pkcs11t.h, 1018                    |
| CKM_TLS_MASTER_KEY_DERIVE      | CKO_PUBLIC_KEY                     |
| pkcs11t.h, 1015                | pkcs11t.h, 1019                    |
| CKM_TLS_MASTER_KEY_DERIVE_DH   | CKO_SECRET_KEY                     |
| pkcs11t.h, 1015                | pkcs11t.h, 1019                    |
| CKM TLS PRE MASTER KEY GEN     | CKO_VENDOR_DEFINED                 |
| pkcs11t.h, 1015                | pkcs11t.h, 1019                    |
| CKM_TLS_PRF                    | CKP_PKCS5_PBKD2_HMAC_GOSTR3411     |
| pkcs11t.h, 1015                | pkcs11t.h, 1019                    |
| CKM_TWOFISH_CBC                | CKP_PKCS5_PBKD2_HMAC_SHA1          |
|                                |                                    |
| pkcs11t.h, 1015                | pkcs11t.h, 1019                    |
| CKM_TWOFISH_CBC_PAD            | CKP_PKCS5_PBKD2_HMAC_SHA224        |
| pkcs11t.h, 1016                | pkcs11t.h, 1019                    |
| CKM_TWOFISH_KEY_GEN            | CKP_PKCS5_PBKD2_HMAC_SHA256        |
| pkcs11t.h, 1016                | pkcs11t.h, 1019                    |
| CKM_VENDOR_DEFINED             | CKP_PKCS5_PBKD2_HMAC_SHA384        |

| pkcs11t.h, 1019                  | pkcs11t.h, 1023                |
|----------------------------------|--------------------------------|
| CKP_PKCS5_PBKD2_HMAC_SHA512      | CKR_FUNCTION_REJECTED          |
| pkcs11t.h, 1020                  | pkcs11t.h, 1023                |
| CKP_PKCS5_PBKD2_HMAC_SHA512_224  | CKR_GENERAL_ERROR              |
| pkcs11t.h, 1020                  | pkcs11t.h, 1023                |
| CKP_PKCS5_PBKD2_HMAC_SHA512_256  | CKR_HOST_MEMORY                |
| pkcs11t.h, 1020                  | pkcs11t.h, 1023                |
| CKR_ACTION_PROHIBITED            | CKR_INFORMATION_SENSITIVE      |
| pkcs11t.h, 1020                  | pkcs11t.h, 1024                |
| CKR_ARGUMENTS_BAD                |                                |
|                                  | CKR_KEY_CHANGED                |
| pkcs11t.h, 1020                  | pkcs11t.h, 1024                |
| CKR_ATTRIBUTE_READ_ONLY          | CKR_KEY_FUNCTION_NOT_PERMITTED |
| pkcs11t.h, 1020                  | pkcs11t.h, 1024                |
| CKR_ATTRIBUTE_SENSITIVE          | CKR_KEY_HANDLE_INVALID         |
| pkcs11t.h, 1020                  | pkcs11t.h, 1024                |
| CKR_ATTRIBUTE_TYPE_INVALID       | CKR_KEY_INDIGESTIBLE           |
| pkcs11t.h, 1020                  | pkcs11t.h, 1024                |
| CKR_ATTRIBUTE_VALUE_INVALID      | CKR_KEY_NEEDED                 |
| pkcs11t.h, 1021                  | pkcs11t.h, 1024                |
| CKR_BUFFER_TOO_SMALL             | CKR_KEY_NOT_NEEDED             |
| pkcs11t.h, 1021                  | pkcs11t.h, 1024                |
| CKR_CANCEL                       | CKR_KEY_NOT_WRAPPABLE          |
| pkcs11t.h, 1021                  | pkcs11t.h, 1024                |
| CKR_CANT_LOCK                    | CKR_KEY_SIZE_RANGE             |
| pkcs11t.h, 1021                  | pkcs11t.h, 1025                |
| CKR_CRYPTOKI_ALREADY_INITIALIZED | CKR_KEY_TYPE_INCONSISTENT      |
| pkcs11t.h, 1021                  | pkcs11t.h, 1025                |
| CKR_CRYPTOKI_NOT_INITIALIZED     | CKR_KEY_UNEXTRACTABLE          |
| pkcs11t.h, 1021                  | pkcs11t.h, 1025                |
| CKR_CURVE_NOT_SUPPORTED          | CKR_LIBRARY_LOAD_FAILED        |
| pkcs11t.h, 1021                  | pkcs11t.h, 1025                |
| CKR_DATA_INVALID                 | CKR_MECHANISM_INVALID          |
| pkcs11t.h, 1021                  | pkcs11t.h, 1025                |
| CKR_DATA_LEN_RANGE               | CKR_MECHANISM_PARAM_INVALID    |
| pkcs11t.h, 1022                  | pkcs11t.h, 1025                |
| CKR_DEVICE_ERROR                 | CKR_MUTEX_BAD                  |
| pkcs11t.h, 1022                  | pkcs11t.h, 1025                |
| CKR_DEVICE_MEMORY                | CKR_MUTEX_NOT_LOCKED           |
| pkcs11t.h, 1022                  | pkcs11t.h, 1025                |
| CKR DEVICE REMOVED               | CKR_NEED_TO_CREATE_THREADS     |
| pkcs11t.h, 1022                  | pkcs11t.h, 1026                |
| CKR_DOMAIN_PARAMS_INVALID        | CKR NEW PIN MODE               |
| pkcs11t.h, 1022                  | pkcs11t.h, 1026                |
| CKR_ENCRYPTED_DATA_INVALID       | CKR NEXT OTP                   |
| pkcs11t.h, 1022                  | pkcs11t.h, 1026                |
| CKR_ENCRYPTED_DATA_LEN_RANGE     | CKR_NO_EVENT                   |
| pkcs11t.h, 1022                  | pkcs11t.h, 1026                |
| CKR EXCEEDED MAX ITERATIONS      | CKR_OBJECT_HANDLE_INVALID      |
| pkcs11t.h, 1022                  | pkcs11t.h, 1026                |
| CKR_FIPS_SELF_TEST_FAILED        | CKR OK                         |
| pkcs11t.h, 1023                  | pkcs11t.h, 1026                |
| CKR_FUNCTION_CANCELED            | CKR_OPERATION_ACTIVE           |
| pkcs11t.h, 1023                  | pkcs11t.h, 1026                |
| CKR_FUNCTION_FAILED              | CKR_OPERATION_NOT_INITIALIZED  |
| pkcs11t.h, 1023                  | pkcs11t.h, 1026                |
| CKR_FUNCTION_NOT_PARALLEL        | CKR_PIN_EXPIRED                |
| pkcs11t.h, 1023                  | pkcs11t.h, 1027                |
| CKR FUNCTION NOT SUPPORTED       | CKR PIN INCORRECT              |

| pkcs11t.h, 1027                      | pkcs11t.h, 1030                    |
|--------------------------------------|------------------------------------|
| CKR_PIN_INVALID                      | CKR_USER_ANOTHER_ALREADY_LOGGED_IN |
| pkcs11t.h, 1027                      | pkcs11t.h, 1030                    |
| CKR_PIN_LEN_RANGE                    | CKR_USER_NOT_LOGGED_IN             |
| pkcs11t.h, 1027                      | pkcs11t.h, 1031                    |
| CKR PIN LOCKED                       | CKR_USER_PIN_NOT_INITIALIZED       |
| pkcs11t.h, 1027                      | pkcs11t.h, 1031                    |
| CKR_PIN_TOO_WEAK                     | CKR_USER_TOO_MANY_TYPES            |
| pkcs11t.h, 1027                      | pkcs11t.h, 1031                    |
| CKR_PUBLIC_KEY_INVALID               | CKR_USER_TYPE_INVALID              |
| pkcs11t.h, 1027                      | pkcs11t.h, 1031                    |
| CKR_RANDOM_NO_RNG                    | CKR VENDOR DEFINED                 |
| pkcs11t.h, 1027                      | pkcs11t.h, 1031                    |
| CKR_RANDOM_SEED_NOT_SUPPORTED        | CKR_WRAPPED_KEY_INVALID            |
|                                      |                                    |
| pkcs11t.h, 1028                      | pkcs11t.h, 1031                    |
| CKR_SAVED_STATE_INVALID              | CKR_WRAPPED_KEY_LEN_RANGE          |
| pkcs11t.h, 1028                      | pkcs11t.h, 1031                    |
| CKR_SESSION_CLOSED                   | CKR_WRAPPING_KEY_HANDLE_INVALID    |
| pkcs11t.h, 1028                      | pkcs11t.h, 1031                    |
| CKR_SESSION_COUNT                    | CKR_WRAPPING_KEY_SIZE_RANGE        |
| pkcs11t.h, 1028                      | pkcs11t.h, 1032                    |
| CKR_SESSION_EXISTS                   | CKR_WRAPPING_KEY_TYPE_INCONSISTENT |
| pkcs11t.h, 1028                      | pkcs11t.h, 1032                    |
| CKR_SESSION_HANDLE_INVALID           | CKS_RO_PUBLIC_SESSION              |
| pkcs11t.h, 1028                      | pkcs11t.h, 1032                    |
| CKR_SESSION_PARALLEL_NOT_SUPPORTED   | CKS_RO_USER_FUNCTIONS              |
| pkcs11t.h, 1028                      | pkcs11t.h, 1032                    |
| CKR_SESSION_READ_ONLY                | CKS_RW_PUBLIC_SESSION              |
| pkcs11t.h, 1028                      | pkcs11t.h, 1032                    |
| CKR_SESSION_READ_ONLY_EXISTS         | CKS_RW_SO_FUNCTIONS                |
| pkcs11t.h, 1029                      | pkcs11t.h, 1032                    |
| CKR_SESSION_READ_WRITE_SO_EXISTS     | CKS_RW_USER_FUNCTIONS              |
| pkcs11t.h, 1029                      | pkcs11t.h, 1032                    |
| CKR_SIGNATURE_INVALID                | CKU_CONTEXT_SPECIFIC               |
| pkcs11t.h, 1029                      | pkcs11t.h, 1032                    |
| CKR_SIGNATURE_LEN_RANGE              | CKU_SO                             |
| pkcs11t.h, 1029                      | pkcs11t.h, 1033                    |
| CKR_SLOT_ID_INVALID                  | CKU_USER                           |
| pkcs11t.h, 1029                      | pkcs11t.h, 1033                    |
| CKR_STATE_UNSAVEABLE                 | CKZ_DATA_SPECIFIED                 |
| pkcs11t.h, 1029                      | pkcs11t.h, 1033                    |
| CKR_TEMPLATE_INCOMPLETE              | CKZ_SALT_SPECIFIED                 |
| pkcs11t.h, 1029                      | pkcs11t.h, 1033                    |
| CKR_TEMPLATE_INCONSISTENT            | CL_hash                            |
| pkcs11t.h, 1029                      | sha1_routines.c, 1065              |
| CKR_TOKEN_NOT_PRESENT                | sha1_routines.h, 1069              |
| pkcs11t.h, 1030                      | CL_HashContext, 527                |
| CKR_TOKEN_NOT_RECOGNIZED             | buf, 528                           |
| pkcs11t.h, 1030                      | byteCount, 528                     |
| CKR_TOKEN_WRITE_PROTECTED            | byteCountHi, 528                   |
| pkcs11t.h, 1030                      | h, 528                             |
| CKR_UNWRAPPING_KEY_HANDLE_INVALID    | CL_hashFinal                       |
| pkcs11t.h, 1030                      | sha1_routines.c, 1066              |
| CKR_UNWRAPPING_KEY_SIZE_RANGE        | sha1_routines.h, 1069              |
| pkcs11t.h, 1030                      | CL_hashInit                        |
| CKR_UNWRAPPING_KEY_TYPE_INCONSISTENT | sha1_routines.c, 1066              |
| pkcs11t.h, 1030                      | sha1_routines.h, 1070              |
| CKR_USER_ALREADY_LOGGED_IN           | CL_hashUpdate                      |
|                                      |                                    |

| sha1_routines.c, 1066      | calib_command.h, 731                     |
|----------------------------|------------------------------------------|
| sha1_routines.h, 1070      | COUNTER_MAX_VALUE                        |
| CLAIM                      | calib_command.h, 731                     |
| license.txt, 877           | COUNTER_MODE_IDX                         |
| class_id                   | calib_command.h, 731                     |
| _pkcs11_object, 395        | COUNTER_MODE_INCREMENT                   |
| class_type                 | calib_command.h, 732                     |
| _pkcs11_object, 395        | COUNTER_MODE_MASK                        |
| client_chal                | calib_command.h, 732                     |
| atca_check_mac_in_out, 408 | COUNTER_MODE_READ                        |
| client_resp                | calib_command.h, 732                     |
| atca_check_mac_in_out, 408 | COUNTER_RSP_SIZE                         |
| clock_divider              | calib_command.h, 732                     |
| atca_command, 410          | COUNTER_SIZE                             |
| CMD_STATUS_BYTE_COMM       | calib_command.h, 732                     |
| calib_command.h, 730       | counter_size                             |
| CMD STATUS BYTE ECC        | atca_aes_ctr_ctx, 403                    |
| calib command.h, 730       | CountMatch                               |
| CMD_STATUS_BYTE_EXEC       | _atecc608_config, 386                    |
| calib_command.h, 730       | create_mutex                             |
| CMD_STATUS_BYTE_PARSE      | pkcs11 lib ctx, 393                      |
| calib_command.h, 730       | CreateMutex                              |
| CMD_STATUS_SUCCESS         | CK_C_INITIALIZE_ARGS, 466                |
| calib command.h, 731       | crypto data                              |
| CMD_STATUS_WAKEUP          | Host side crypto methods (atcah_), 321   |
| calib_command.h, 731       | CRYPTOAUTH_ROOT_CA_002_PUBLIC_KEY_OFFSET |
| comp_cert_dev_loc          | TNG API (tng ), 374                      |
| atcacert_def_s, 445        | cryptoauthlib.h, 816                     |
| conditions                 | ATCA_AES128_BLOCK_SIZE, 817              |
| license.txt, 877           | ATCA_AES128_KEY_SIZE, 817                |
| conf                       | ATCA ATECC608 SUPPORT, 818               |
| hal_esp32_i2c.c, 839       | ATCA_CA_SUPPORT, 818                     |
| config                     | ATCA_DLL, 818                            |
| pkcs11 object, 395         | ATCA_ECC_SUPPORT, 818                    |
| config_path                | ATCA ECCP256 KEY SIZE, 818               |
| pkcs11 lib ctx, 393        | ATCA_ECCP256_PUBKEY_SIZE, 818            |
| Configuration (cfg_), 121  | ATCA_ECCP256_SIG_SIZE, 818               |
| CONTRACT                   | ATCA_SHA256_BLOCK_SIZE, 818              |
| license.txt, 877           | ATCA_SHA256_DIGEST_SIZE, 819             |
| сору                       | ATCA_SHA_SUPPORT, 819                    |
| license.txt, 877           | ATCA STRINGIFY, 819                      |
| count                      | ATCA TA SUPPORT, 819                     |
| _pkcs11_object, 395        | ATCA_TOSTRING, 819                       |
| atcacert_cert_loc_s, 442   | ATCA_TRACE, 819                          |
| atcacert_device_loc_s, 447 | ATCA ZONE CONFIG, 819                    |
| Counter                    | ATCA ZONE DATA, 820                      |
| _atsha204a_config, 389     | ATCA ZONE OTP, 820                       |
| counter                    | SHA_MODE_TARGET_MSGDIGBUF, 820           |
| atca_gen_dig_in_out, 416   | SHA_MODE_TARGET_OUT_ONLY, 820            |
| Counter0                   | SHA MODE TARGET TEMPKEY, 820             |
| _atecc508a_config, 382     | cryptoki.h, 820                          |
| _atecc608_config, 386      | CK_CALLBACK_FUNCTION, 821                |
| Counter1                   | CK_DECLARE_FUNCTION, 821                 |
| _atecc508a_config, 382     | CK DECLARE FUNCTION POINTER, 821         |
| _atecc608_config, 386      | CK PTR, 821                              |
| COUNTER_COUNT              | NULL PTR, 821                            |
| calib command.h, 731       | PKCS11 API, 822                          |
| COUNTER_KEYID_IDX          | PKCS11_HELPER_DLL_EXPORT, 822            |

| PKCS11_HELPER_DLL_IMPORT, 822                     | deleteATCAlface                                   |
|---------------------------------------------------|---------------------------------------------------|
| PKCS11_HELPER_DLL_LOCAL, 822                      | ATCAlface (atca_), 151                            |
| PKCS11_LOCAL, 822                                 | DERIVE_KEY_COUNT_LARGE                            |
| CRYPTOKI_VERSION_AMENDMENT                        | calib_command.h, 732                              |
| pkcs11t.h, 1033                                   | DERIVE_KEY_COUNT_SMALL                            |
| CRYPTOKI_VERSION_MAJOR                            | calib_command.h, 733                              |
| pkcs11t.h, 1033                                   | DERIVE_KEY_MAC_IDX                                |
| CRYPTOKI_VERSION_MINOR                            | calib_command.h, 733                              |
| pkcs11t.h, 1033                                   | DERIVE_KEY_MAC_SIZE                               |
| cryptokiVersion                                   | calib_command.h, 733                              |
| CK_INFO, 482                                      | DERIVE_KEY_MODE                                   |
| cur                                               | calib_command.h, 733                              |
| atca_jwt_t, 424                                   | DERIVE_KEY_RANDOM_FLAG                            |
| curve_type                                        | calib_command.h, 733                              |
| Host side crypto methods (atcah_), 321            | DERIVE_KEY_RANDOM_IDX                             |
| DAMAGE                                            | calib_command.h, 733                              |
| license.txt, 878                                  | DERIVE_KEY_RSP_SIZE                               |
| DAMAGES                                           | calib_command.h, 734                              |
| license.txt, 874                                  | DERIVE_KEY_TARGETKEY_IDX                          |
| data                                              | calib_command.h, 734                              |
| _pkcs11_object, 395                               | destroy_mutex                                     |
| atca_io_decrypt_in_out, 423                       | _pkcs11_lib_ctx, 393                              |
| ATCAPacket, 458                                   | DestroyMutex                                      |
| data_size                                         | CK_C_INITIALIZE_ARGS, 466                         |
| atca_aes_gcm_ctx, 406                             | dev_identity                                      |
| atca_io_decrypt_in_out, 423                       | ATCAlfaceCfg, 454                                 |
| DATEFMT_ISO8601_SEP                               | dev_interface                                     |
| Certificate manipulation methods (atcacert_), 165 | ATCAlfaceCfg, 454                                 |
| DATEFMT_ISO8601_SEP_SIZE                          | device                                            |
| Certificate manipulation methods (atcacert_), 161 | atca_aes_cbc_ctx, 401                             |
| DATEFMT_MAX_SIZE                                  | atca_aes_ctr_ctx, 404                             |
| Certificate manipulation methods (atcacert ), 161 | device_ctx                                        |
| DATEFMT POSIX UINT32 BE                           | _pkcs11_slot_ctx, 400                             |
| Certificate manipulation methods (atcacert_), 165 | device_loc                                        |
| DATEFMT_POSIX_UINT32_BE_SIZE                      | atcacert_cert_element_s, 441                      |
| Certificate manipulation methods (atcacert_), 161 | device_sn                                         |
| DATEFMT_POSIX_UINT32_LE                           | atcacert_build_state_s, 440                       |
| Certificate manipulation methods (atcacert_), 166 | devtype                                           |
| DATEFMT_POSIX_UINT32_LE_SIZE                      | ATCAlfaceCfg, 455                                 |
| Certificate manipulation methods (atcacert_), 161 | DEVZONE_CONFIG                                    |
| DATEFMT_RFC5280_GEN                               | Certificate manipulation methods (atcacert_), 166 |
| Certificate manipulation methods (atcacert_), 166 | DEVZONE_DATA                                      |
| DATEFMT_RFC5280_GEN_SIZE                          | Certificate manipulation methods (atcacert_), 166 |
| Certificate manipulation methods (atcacert_), 161 | DEVZONE_NONE                                      |
| DATEFMT_RFC5280_UTC                               | Certificate manipulation methods (atcacert_), 166 |
| Certificate manipulation methods (atcacert_), 165 | DEVZONE_OTP                                       |
| DATEFMT_RFC5280_UTC_SIZE                          | Certificate manipulation methods (atcacert_), 166 |
| Certificate manipulation methods (atcacert_), 161 | digest                                            |
| day                                               | atca_secureboot_enc_in_out, 426                   |
| CK_DATE, 471                                      | atca_secureboot_mac_in_out, 427                   |
| DEBUG_PIN_1                                       | atca_sign_internal_in_out, 430                    |
| Hardware abstraction layer (hal_), 262            | digest_enc                                        |
| DEBUG_PIN_2                                       | atca_secureboot_enc_in_out, 426                   |
| Hardware abstraction layer (hal_), 262            | DigestMechanism                                   |
| deleteATCACommand                                 | CK_WTLS_KEY_MAT_PARAMS, 519                       |
| ATCACommand (atca_), 122                          | CK_WTLS_MASTER_KEY_DERIVE_PARAMS,                 |
| deleteATCADevice                                  | 520                                               |
| ATCADevice (atca.), 144                           | CK WTLS PRF PARAMS, 521                           |

| DIRECT                                     | example_pkcs11_config.c, 825                      |
|--------------------------------------------|---------------------------------------------------|
| license.txt, 878                           | atecc608_config, 826                              |
| distribute                                 | pkcs11_config_cert, 826                           |
| license.txt, 879                           | pkcs11_config_key, 826                            |
| dt                                         | pkcs11_config_load_objects, 826                   |
| atca_command, 410                          | pkcs11configLABEL_DEVICE_CERTIFICATE_FOR_TLS, 825 |
| ECDH_COUNT                                 | pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS,     |
| calib_command.h, 734                       | 825                                               |
| ECDH_KEY_SIZE                              | pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS,      |
| calib_command.h, 734                       | 825                                               |
| ECDH_MODE_COPY_COMPATIBLE                  | pkcs11configLABEL_JITP_CERTIFICATE, 826           |
| calib_command.h, 734                       | execTime                                          |
| ECDH_MODE_COPY_EEPROM_SLOT                 | ATCAPacket, 458                                   |
| calib_command.h, 734                       | execution_time_msec                               |
| ECDH_MODE_COPY_MASK                        | atca_command, 410                                 |
| calib_command.h, 734                       | EXEMPLARY                                         |
| ECDH_MODE_COPY_OUTPUT_BUFFER               | license.txt, 879                                  |
| calib_command.h, 735                       | expire_date_format                                |
| ECDH_MODE_COPY_TEMP_KEY                    | atcacert_def_s, 445                               |
| calib_command.h, 735                       | expire_years                                      |
| ECDH_MODE_OUTPUT_CLEAR                     | atcacert_def_s, 445                               |
| calib_command.h, 735                       | EXPRESS                                           |
| ECDH_MODE_OUTPUT_ENC                       | license.txt, 879                                  |
| calib_command.h, 735 ECDH_MODE_OUTPUT_MASK | 54.05                                             |
| calib_command.h, 735                       | FALSE                                             |
|                                            | Certificate manipulation methods (atcacert_), 162 |
| ECDH_MODE_SOURCE_EEPROM_SLOT               | pkcs11t.h, 1033                                   |
| calib_command.h, 735                       | FEES                                              |
| ECDH_MODE_SOURCE_MASK calib_command.h, 735 | license.txt, 879                                  |
| ECDH_MODE_SOURCE_TEMPKEY                   | files                                             |
| calib command.h, 735                       | license.txt, 874                                  |
| ECDH_PREFIX_MODE                           | firmwareVersion                                   |
| calib_command.h, 736                       | CK_SLOT_INFO, 505                                 |
| ECDH_RSP_SIZE                              | CK_TOKEN_INFO, 515                                |
| calib_command.h, 736                       | flags                                             |
| enc_cb                                     | _pkcs11_object, 396                               |
| atca_aes_gcm_ctx, 406                      | _pkcs11_slot_ctx, 400                             |
| encrypted data                             | CK_C_INITIALIZE_ARGS, 466                         |
| atca_write_mac_in_out, 438                 | CK_INFO, 482<br>CK_MECHANISM_INFO, 487            |
| ENCRYPTION_KEY_SIZE                        | CK_MECHANISM_INFO, 487 CK SESSION INFO, 500       |
| Host side crypto methods (atcah_), 310     | CK_SLOT_INFO, 505                                 |
| error                                      | CK_TOKEN_INFO, 515                                |
| pkcs11 session ctx, 398                    | for invalidate                                    |
| ets_delay_us                               | atca_sign_internal_in_out, 430                    |
| hal_esp32_timer.c, 840                     | forms                                             |
| event                                      | license.txt, 880                                  |
| pkcs11t.h, 1057                            | FROM                                              |
| example_cert_chain.c, 822                  | license.txt, 880                                  |
| g_cert_def_0_root, 823                     | func                                              |
| g_cert_def_1_signer, 823                   | _pkcs11_attrib_model, 392                         |
| g_cert_def_2_device, 823                   |                                                   |
| g_cert_elements_1_signer, 823              | g_cert_def_0_root                                 |
| g_cert_template_1_signer, 823              | example_cert_chain.c, 823                         |
| g_cert_template_2_device, 823              | g_cert_def_1_signer                               |
| example_cert_chain.h, 824                  | example_cert_chain.c, 823                         |
| g_cert_def_1_signer, 824                   | example_cert_chain.h, 824                         |
| g_cert_def_2_device, 824                   | g_cert_def_2_device                               |

| example_cert_chain.c, 823          | gen_dig_data              |
|------------------------------------|---------------------------|
| example_cert_chain.h, 824          | atca_temp_key, 433        |
| g_cert_elements_1_signer           | gen_key_data              |
| example_cert_chain.c, 823          | atca_temp_key, 433        |
| g_cert_template_1_signer           | GENDIG_COUNT              |
| example_cert_chain.c, 823          | calib_command.h, 736      |
| g_cert_template_2_device           | GENDIG_DATA_IDX           |
| example_cert_chain.c, 823          | calib_command.h, 736      |
| g_cryptoauth_root_ca_002_cert      | GENDIG_KEYID_IDX          |
| TNG API (tng_), 379                | calib_command.h, 736      |
| tng_root_cert.c, 1089              | GENDIG_RSP_SIZE           |
| g_cryptoauth_root_ca_002_cert_size | calib_command.h, 736      |
| TNG API (tng_), 379                | GENDIG_ZONE_CONFIG        |
| tng_root_cert.c, 1090              | calib_command.h, 737      |
| g_tflxtls_cert_def_4_device        | GENDIG_ZONE_COUNTER       |
| TNG API (tng_), 379                | calib_command.h, 737      |
| g_tflxtls_cert_elements_4_device   | GENDIG_ZONE_DATA          |
| tflxtls cert def 4 device.c, 1082  | calib_command.h, 737      |
| g_tflxtls_cert_template_4_device   | GENDIG_ZONE_IDX           |
| tflxtls cert def 4 device.c, 1082  | calib_command.h, 737      |
| g tnglora cert def 1 signer        | GENDIG_ZONE_KEY_CONFIG    |
| TNG API (tng_), 379                | calib_command.h, 737      |
| g_tnglora_cert_def_2_device        | GENDIG_ZONE_OTP           |
| TNG API (tng_), 379                | calib_command.h, 737      |
| g_tnglora_cert_def_4_device        | GENDIG_ZONE_SHARED_NONCE  |
| TNG API (tng_), 380                | calib_command.h, 738      |
| tnglora_cert_def_4_device.c, 1093  | GENKEY_COUNT              |
| g_tnglora_cert_elements_4_device   | calib_command.h, 738      |
| tnglora_cert_def_4_device.c, 1093  | GENKEY_COUNT_DATA         |
| g_tnglora_cert_template_4_device   | calib_command.h, 738      |
| tnglora_cert_def_4_device.c, 1094  | GENKEY_DATA_IDX           |
| g_tngtls_cert_def_1_signer         | calib_command.h, 738      |
| TNG API (tng_), 380                | GENKEY_KEYID_IDX          |
| tngtls_cert_def_1_signer.c, 1095   | calib_command.h, 738      |
| g_tngtls_cert_def_2_device         | GENKEY_MODE_DIGEST        |
| TNG API (tng_), 380                | calib_command.h, 738      |
|                                    | GENKEY_MODE_IDX           |
| tngtls_cert_def_2_device.c, 1096   | calib_command.h, 739      |
| g_tngtls_cert_def_3_device         | GENKEY_MODE_MASK          |
| TNG API (tng_), 380                | calib_command.h, 739      |
| tngtls_cert_def_3_device.c, 1098   | GENKEY_MODE_PRIVATE       |
| g_tngtls_cert_elements_1_signer    | calib_command.h, 739      |
| tnglora_cert_def_1_signer.c, 1091  | GENKEY_MODE_PUBKEY_DIGES  |
| tngtls_cert_def_1_signer.c, 1095   | calib_command.h, 739      |
| g_tngtls_cert_elements_2_device    | GENKEY_MODE_PUBLIC        |
| tnglora_cert_def_2_device.c, 1092  | calib_command.h, 739      |
| tngtls_cert_def_2_device.c, 1096   | GENKEY_OTHER_DATA_SIZE    |
| g_tngtls_cert_elements_3_device    | calib_command.h, 739      |
| tngtls_cert_def_3_device.c, 1098   | GENKEY_PRIVATE_TO_TEMPKEY |
| g_tngtls_cert_template_1_signer    | calib_command.h, 740      |
| tnglora_cert_def_1_signer.c, 1091  | GENKEY_RSP_SIZE_LONG      |
| tngtls_cert_def_1_signer.c, 1095   | calib_command.h, 740      |
| g_tngtls_cert_template_2_device    | GENKEY_RSP_SIZE_SHORT     |
| tnglora_cert_def_2_device.c, 1092  | calib_command.h, 740      |
| tngtls_cert_def_2_device.c, 1096   | granted                   |
| g_tngtls_cert_template_3_device    | license.txt, 880          |
| tngtls_cert_def_3_device.c, 1098   | •                         |
| g_trace_fp                         | h                         |
| atca_debug.c, 584                  | atca_aes_gcm_ctx, 406     |

| CL_HashContext, 528                    | hal_i2c_idle                           |
|----------------------------------------|----------------------------------------|
| hal all platforms kit hidapi.c, 827    | hal_esp32_i2c.c, 833                   |
| hal_check_wake                         | Hardware abstraction layer (hal_), 273 |
|                                        |                                        |
| Hardware abstraction layer (hal_), 269 | hal_i2c_init                           |
| hal_create_mutex                       | hal_esp32_i2c.c, 833                   |
| Hardware abstraction layer (hal_), 269 | Hardware abstraction layer (hal_), 273 |
| hal_data                               | hal_i2c_post_init                      |
| atca_iface, 421                        | hal_esp32_i2c.c, 835                   |
| ATCAHAL_t, 450                         | Hardware abstraction layer (hal_), 275 |
| hal_delay_10us                         | hal_i2c_receive                        |
| Hardware abstraction layer (hal_), 270 | hal_esp32_i2c.c, 835                   |
| hal_delay_ms                           | Hardware abstraction layer (hal_), 276 |
| Hardware abstraction layer (hal_), 270 | hal_i2c_release                        |
| hal_delay_us                           | hal_esp32_i2c.c, 836                   |
| Hardware abstraction layer (hal_), 270 | Hardware abstraction layer (hal_), 276 |
| hal_destroy_mutex                      | hal_i2c_send                           |
| Hardware abstraction layer (hal_), 270 | hal_esp32_i2c.c, 837                   |
| hal_esp32_i2c.c, 828                   | Hardware abstraction layer (hal_), 277 |
| ACK_CHECK_DIS, 829                     | hal_i2c_sleep                          |
| ACK_CHECK_EN, 829                      | hal_esp32_i2c.c, 838                   |
|                                        |                                        |
| ACK_VAL, 830                           | Hardware abstraction layer (hal_), 278 |
| ATCAI2CMaster_t, 830                   | hal_i2c_start.c, 842                   |
| conf, 839                              | hal_i2c_start.h, 843                   |
| hal_i2c_change_baud, 831               | hal_i2c_wake                           |
| hal_i2c_discover_buses, 831            | hal_esp32_i2c.c, 838                   |
| hal_i2c_discover_devices, 832          | Hardware abstraction layer (hal_), 278 |
| hal_i2c_idle, 833                      | hal_iface_init                         |
| hal_i2c_init, 833                      | Hardware abstraction layer (hal_), 279 |
| hal_i2c_post_init, 835                 | hal_iface_register_hal                 |
| hal_i2c_receive, 835                   | Hardware abstraction layer (hal_), 279 |
| hal_i2c_release, 836                   | hal_iface_release                      |
| hal_i2c_send, 837                      | Hardware abstraction layer (hal_), 279 |
| hal_i2c_sleep, 838                     | hal_kit_hid_discover_buses             |
| hal_i2c_wake, 838                      | Hardware abstraction layer (hal_), 280 |
| i2c_bus_ref_ct, 839                    | hal_kit_hid_discover_devices           |
| i2c_hal_data, 839                      | Hardware abstraction layer (hal_), 280 |
|                                        | hal_kit_hid_idle                       |
| LOG_LOCAL_LEVEL, 830                   |                                        |
| MAX_I2C_BUSES, 830                     | Hardware abstraction layer (hal_), 281 |
| NACK_VAL, 830                          | hal_kit_hid_init                       |
| SCL_PIN, 830                           | Hardware abstraction layer (hal_), 281 |
| SDA_PIN, 830                           | hal_kit_hid_post_init                  |
| TAG, 839                               | Hardware abstraction layer (hal_), 281 |
| hal_esp32_timer.c, 839                 | hal_kit_hid_receive                    |
| atca_delay_ms, 840                     | Hardware abstraction layer (hal_), 282 |
| ets_delay_us, 840                      | hal_kit_hid_release                    |
| hal_free                               | Hardware abstraction layer (hal_), 282 |
| Hardware abstraction layer (hal_), 271 | hal_kit_hid_send                       |
| hal_freertos.c, 840                    | Hardware abstraction layer (hal_), 282 |
| ATCA_MUTEX_TIMEOUT, 841                | hal_kit_hid_sleep                      |
| hal_i2c_change_baud                    | Hardware abstraction layer (hal_), 283 |
| hal_esp32_i2c.c, 831                   | hal_kit_hid_wake                       |
| hal_i2c_discover_buses                 | Hardware abstraction layer (hal_), 283 |
| hal_esp32_i2c.c, 831                   | hal_linux.c, 844                       |
|                                        |                                        |
| Hardware abstraction layer (hal_), 271 | hal_linux_i2c_userspace.c, 844         |
| hal_i2c_discover_devices               | hal_linux_i2c_userspace.h, 845         |
| hal_esp32_i2c.c, 832                   | hal_linux_spi_userspace.c, 846         |
| Hardware abstraction layer (hal_), 272 | hal_spi_discover_buses, 847            |
| hal_i2c_harmony.c, 841                 | hal_spi_discover_devices, 847          |

| hal_spi_idle, 847                      | hal_swi_discover_buses                 |
|----------------------------------------|----------------------------------------|
| hal spi init, 847                      | Hardware abstraction layer (hal_), 289 |
| hal_spi_open_file, 848                 | hal swi discover devices               |
| hal_spi_post_init, 848                 | Hardware abstraction layer (hal_), 289 |
| hal_spi_receive, 848                   | hal swi idle                           |
| hal_spi_release, 849                   | Hardware abstraction layer (hal.), 290 |
| hal_spi_send, 849                      | hal_swi_init                           |
| hal_spi_sleep, 850                     | Hardware abstraction layer (hal_), 290 |
| hal_spi_wake, 850                      | hal_swi_post_init                      |
| hal_linux_spi_userspace.h, 851         | Hardware abstraction layer (hal_), 291 |
| hal_lock_mutex                         | hal swi receive                        |
| Hardware abstraction layer (hal_), 284 | Hardware abstraction layer (hal_), 291 |
| hal malloc                             | hal_swi_release                        |
| Hardware abstraction layer (hal_), 284 | Hardware abstraction layer (hal_), 292 |
| hal_memset_s                           | hal_swi_send                           |
| Hardware abstraction layer (hal_), 262 | Hardware abstraction layer (hal_), 292 |
| hal_rtos_delay_ms                      | hal_swi_send_flag                      |
| Hardware abstraction layer (hal.), 284 | Hardware abstraction layer (hal_), 292 |
| hal_sam0_i2c_asf.c, 851                | hal swi sleep                          |
| hal_sam0_i2c_asf.h, 852                | Hardware abstraction layer (hal_), 293 |
| i2c_sam0_instance_t, 853               | hal swi uart.c, 857                    |
| sam0 change baudrate, 853              | hal_swi_uart.h, 858                    |
| hal_sam_i2c_asf.c, 853                 | hal_swi_wake                           |
| hal sam i2c asf.h, 854                 | Hardware abstraction layer (hal_), 293 |
| hal_sam_timer_asf.c, 855               | hal_timer_start.c, 858                 |
| hal_spi_discover_buses                 | hal_uc3_i2c_asf.c, 859                 |
| hal_linux_spi_userspace.c, 847         | hal_uc3_i2c_asf.h, 860                 |
| Hardware abstraction layer (hal_), 284 | hal_uc3_timer_asf.c, 861               |
| hal_spi_discover_devices               | hal_unlock_mutex                       |
| hal_linux_spi_userspace.c, 847         | Hardware abstraction layer (hal_), 293 |
| Hardware abstraction layer (hal_), 285 | hal_windows.c, 861                     |
| hal_spi_harmony.c, 856                 | halidle                                |
| hal_spi_idle                           | ATCAHAL_t, 450                         |
| hal_linux_spi_userspace.c, 847         | ATCAlfaceCfg, 455                      |
| Hardware abstraction layer (hal_), 285 | halinit                                |
| hal_spi_init                           | ATCAHAL t, 450                         |
| hal_linux_spi_userspace.c, 847         | ATCAlfaceCfg, 455                      |
| Hardware abstraction layer (hal_), 285 | halpostinit                            |
| hal_spi_open_file                      | ATCAHAL t, 450                         |
| hal_linux_spi_userspace.c, 848         | ATCAlfaceCfg, 455                      |
| hal spi post init                      | halreceive                             |
| hal_linux_spi_userspace.c, 848         | ATCAHAL_t, 450                         |
| Hardware abstraction layer (hal_), 286 | ATCAlfaceCfg, 455                      |
| hal spi receive                        | halrelease                             |
| hal_linux_spi_userspace.c, 848         | ATCAHAL t, 450                         |
| Hardware abstraction layer (hal_), 286 | ATCAlfaceCfg, 455                      |
| hal spi release                        | halsend                                |
| hal_linux_spi_userspace.c, 849         | ATCAHAL_t, 450                         |
| Hardware abstraction layer (hal_), 287 | ATCAlfaceCfg, 455                      |
| hal_spi_send                           | halsleep                               |
| hal_linux_spi_userspace.c, 849         | ATCAHAL_t, 450                         |
| Hardware abstraction layer (hal_), 287 | ATCAlfaceCfg, 455                      |
| hal_spi_sleep                          | halwake                                |
| hal_linux_spi_userspace.c, 850         | ATCAHAL_t, 451                         |
| Hardware abstraction layer (hal_), 287 | ATCAlfaceCfg, 456                      |
| hal_spi_wake                           | handle                                 |
| hal_linux_spi_userspace.c, 850         | _pkcs11_object_cache_t, 397            |
| Hardware abstraction layer (hal_), 289 | _pkcs11_session_ctx, 398               |

| hand | dle_info                            | hal_spi_sleep, 287              |
|------|-------------------------------------|---------------------------------|
|      | _pkcs11_object, 396                 | hal spi wake, 289               |
| Harc | dware abstraction layer (hal_), 257 | hal swi discover buses, 289     |
|      | atca_delay_10us, 267                | hal_swi_discover_devices, 289   |
|      | atca delay ms, 268                  | hal swi idle, 290               |
|      | atca_delay_us, 268                  | hal_swi_init, 290               |
|      | ATCA_POLLING_FREQUENCY_TIME_MSEC,   | hal_swi_post_init, 291          |
|      | 262                                 | hal_swi_receive, 291            |
|      |                                     |                                 |
|      | ATCA_POLLING_INIT_TIME_MSEC, 262    | hal_swi_release, 292            |
|      | ATCA_POLLING_MAX_TIME_MSEC, 262     | hal_swi_send, 292               |
|      | ATCAI2CMaster_t, 266                | hal_swi_send_flag, 292          |
|      | ATCASPIMaster_t, 266                | hal_swi_sleep, 293              |
|      | ATCASWIMaster_t, 266                | hal_swi_wake, 293               |
|      | change_i2c_speed, 268               | hal_unlock_mutex, 293           |
|      | DEBUG_PIN_1, 262                    | HID_PACKET_MAX, 262             |
|      | DEBUG_PIN_2, 262                    | i2c_sam_instance_t, 267         |
|      | hal_check_wake, 269                 | i2c_start_instance_t, 267       |
|      | hal_create_mutex, 269               | kit_id_from_devtype, 294        |
|      | hal_delay_10us, 270                 | kit_idle, 294                   |
|      | hal_delay_ms, 270                   | kit_init, 294                   |
|      | hal_delay_us, 270                   | kit_interface_from_kittype, 294 |
|      | hal_destroy_mutex, 270              | KIT_MAX_SCAN_COUNT, 262         |
|      | hal_free, 271                       | KIT MAX TX BUF, 263             |
|      | hal_i2c_discover_buses, 271         | KIT_MSG_SIZE, 263               |
|      | hal_i2c_discover_devices, 272       | kit_parse_rsp, 295              |
|      | hal_i2c_idle, 273                   | kit_phy_num_found, 295          |
|      | hal_i2c_init, 273                   |                                 |
|      |                                     | kit_phy_receive, 295, 296       |
|      | hal_i2c_post_init, 275              | kit_phy_send, 296               |
|      | hal_i2c_receive, 276                | kit_receive, 297                |
|      | hal_i2c_release, 276                | KIT_RX_WRAP_SIZE, 263           |
|      | hal_i2c_send, 277                   | kit_send, 297                   |
|      | hal_i2c_sleep, 278                  | kit_sleep, 298                  |
|      | hal_i2c_wake, 278                   | KIT_TX_WRAP_SIZE, 263           |
|      | hal_iface_init, 279                 | kit_wake, 298                   |
|      | hal_iface_register_hal, 279         | kit_wrap_cmd, 298               |
|      | hal_iface_release, 279              | MAX_I2C_BUSES, 263              |
|      | hal_kit_hid_discover_buses, 280     | MAX_SPI_BUSES, 263              |
|      | hal_kit_hid_discover_devices, 280   | MAX_SWI_BUSES, 263, 264         |
|      | hal_kit_hid_idle, 281               | pin_conf, 302                   |
|      | hal_kit_hid_init, 281               | RECEIVE_MODE, 264               |
|      | hal_kit_hid_post_init, 281          | RX_DELAY, 264                   |
|      | hal_kit_hid_receive, 282            | sam change baudrate, 267        |
|      | hal_kit_hid_release, 282            | start change baudrate, 267      |
|      | hal_kit_hid_send, 282               | strnchr, 299                    |
|      | hal_kit_hid_sleep, 283              | SWI_FLAG_CMD, 264               |
|      | hal_kit_hid_wake, 283               | SWI_FLAG_IDLE, 265              |
|      | hal_lock_mutex, 284                 | SWI FLAG SLEEP, 265             |
|      | hal malloc, 284                     | SWI_FLAG_TX, 265                |
|      | hal_memset_s, 262                   | swi_uart_deinit, 299            |
|      |                                     |                                 |
|      | hal_rtos_delay_ms, 284              | swi_uart_discover_buses, 300    |
|      | hal_spi_discover_buses, 284         | swi_uart_init, 300              |
|      | hal_spi_discover_devices, 285       | swi_uart_mode, 300              |
|      | hal_spi_idle, 285                   | swi_uart_receive_byte, 301      |
|      | hal_spi_init, 285                   | swi_uart_send_byte, 301         |
|      | hal_spi_post_init, 286              | swi_uart_setbaud, 302           |
|      | hal_spi_receive, 286                | SWI_WAKE_TOKEN, 265             |
|      | hal_spi_release, 287                | TRANSMIT_MODE, 265              |
|      | hal_spi_send, 287                   | TX_DELAY, 266                   |

| hardwareVersion                        | ATCA_MSG_SIZE_ENCRYPT_MAC, 308      |
|----------------------------------------|-------------------------------------|
| CK_SLOT_INFO, 505                      | ATCA_MSG_SIZE_GEN_DIG, 308          |
| CK_TOKEN_INFO, 515                     | ATCA_MSG_SIZE_HMAC, 308             |
| hash                                   | ATCA_MSG_SIZE_MAC, 308              |
| CK_DSA_PARAMETER_GEN_PARAM, 472        | ATCA_MSG_SIZE_NONCE, 309            |
| sw_sha256_ctx, 534                     | ATCA_MSG_SIZE_PRIVWRITE_MAC, 309    |
| hashAlg                                | atca_nonce_in_out_t, 311            |
| CK_RSA_PKCS_OAEP_PARAMS, 497           | ATCA_PRIVWRITE_MAC_ZEROS_SIZE, 309  |
| CK_RSA_PKCS_PSS_PARAMS, 498            | ATCA_PRIVWRITE_PLAIN_TEXT_SIZE, 309 |
| hashed_key                             | atca_secureboot_enc_in_out_t, 311   |
| atca_secureboot_enc_in_out, 426        | atca_secureboot_mac_in_out_t, 311   |
| atca_secureboot_mac_in_out, 427        | atca_sign_internal_in_out_t, 311    |
| hClientKey                             | ATCA_SN_0_DEF, 309                  |
| CK_SSL3_KEY_MAT_OUT, 506               | ATCA_SN_1_DEF, 309                  |
| hClientMacSecret                       | ATCA_SN_8_DEF, 309                  |
| CK_SSL3_KEY_MAT_OUT, 506               | atca_temp_key_t, 311                |
| HID_PACKET_MAX                         | atca_verify_in_out_t, 312           |
| Hardware abstraction layer (hal_), 262 | atca_verify_mac_in_out_t, 312       |
| hKey                                   | atca_write_mac_in_out_t, 312        |
| CK_GOSTR3410_KEY_WRAP_PARAMS, 481      | ATCA_WRITE_MAC_ZEROS_SIZE, 310      |
| CK KIP PARAMS, 485                     | atcah_check_mac, 312                |
| CK_WTLS_KEY_MAT_OUT, 518               | atcah_config_to_sign_internal, 312  |
| HMAC_COUNT                             | atcah_decrypt, 313                  |
| calib_command.h, 740                   | atcah_derive_key, 313               |
| HMAC_DIGEST_SIZE                       | atcah_derive_key_mac, 314           |
| calib_command.h, 740                   | atcah_encode_counter_match, 314     |
| HMAC_KEYID_IDX                         | atcah_gen_dig, 315                  |
| calib_command.h, 740                   | atcah_gen_key_msg, 315              |
| HMAC_MODE_FLAG_FULLSN                  | atcah_gen_mac, 316                  |
| calib_command.h, 741                   | atcah_hmac, 316                     |
| HMAC_MODE_FLAG_OTP64                   | atcah_include_data, 316             |
| calib command.h, 741                   | atcah_io_decrypt, 317               |
| HMAC MODE FLAG OTP88                   | atcah_mac, 317                      |
| calib command.h, 741                   | atcah nonce, 318                    |
| HMAC_MODE_FLAG_TK_NORAND               | atcah_privwrite_auth_mac, 318       |
| calib command.h, 741                   | atcah secureboot enc, 318           |
| HMAC_MODE_FLAG_TK_RAND                 | atcah secureboot mac, 319           |
| calib_command.h, 741                   | atcah_sha256, 319                   |
| HMAC_MODE_IDX                          | atcah_sign_internal_msg, 319        |
| calib command.h, 741                   | atcah verify mac, 320               |
| HMAC MODE MASK                         | atcah_write_auth_mac, 320           |
| calib_command.h, 742                   | challenge, 321                      |
| HMAC_RSP_SIZE                          | crypto_data, 321                    |
| calib command.h, 742                   | curve_type, 321                     |
| hMacSecret                             | ENCRYPTION_KEY_SIZE, 310            |
| CK WTLS KEY MAT OUT, 518               | key, 321                            |
| Host side crypto methods (atcah ), 303 | key_id, 322                         |
| atca_check_mac_in_out_t, 310           | MAC MODE USE TEMPKEY MASK, 310      |
| ATCA_COMMAND_HEADER_SIZE, 307          | mode, 322                           |
| ATCA_DERIVE_KEY_ZEROS_SIZE, 307        | num_in, 322                         |
| atca_gen_dig_in_out_t, 310             | otp, 323                            |
| atca_gen_key_in_out_t, 310             | p_temp, 323                         |
| ATCA_GENDIG_ZEROS_SIZE, 307            | public_key, 323                     |
| ATCA_HMAC_BLOCK_SIZE, 308              | rand_out, 323                       |
| atca_io_decrypt_in_out_t, 311          | response, 324                       |
| atca_mac_in_out_t, 311                 | signature, 324                      |
| ATCA_MSG_SIZE_DERIVE_KEY, 308          | sn, 324                             |
| ATCA MSG SIZE DERIVE KEY MAC. 308      | temp kev. 325                       |

| zero, 325                              | ATCAlfaceCfg, 456           |
|----------------------------------------|-----------------------------|
| host_generate_random_number            | IMPLIED                     |
| secure boot.h, 1063                    | license.txt, 881            |
| hPrivateData                           | INCIDENTAL                  |
| CK ECDH2 DERIVE PARAMS, 474            | license.txt, 881            |
| CK ECMQV DERIVE PARAMS, 477            | INCLUDING                   |
|                                        |                             |
| CK_X9_42_DH2_DERIVE_PARAMS, 524        | license.txt, 881            |
| CK_X9_42_MQV_DERIVE_PARAMS, 526        | INDIRECT                    |
| hServerKey                             | license.txt, 882            |
| CK_SSL3_KEY_MAT_OUT, 506               | info                        |
| hServerMacSecret                       | _pcks11_mech_table_e, 392   |
| CK_SSL3_KEY_MAT_OUT, 506               | INFO COUNT                  |
| http                                   | calib_command.h, 742        |
| license.txt, 880                       | INFO DRIVER STATE MASK      |
| hw_sha256_ctx, 528                     | calib_command.h, 742        |
| block, 528                             |                             |
| block_size, 529                        | INFO_MODE_GPIO              |
|                                        | calib_command.h, 742        |
| total_msg_size, 529                    | INFO_MODE_KEY_VALID         |
| I2C Address                            | calib_command.h, 742        |
| <del>-</del>                           | INFO_MODE_MAX               |
| _atecc508a_config, 382                 | calib command.h, 743        |
| _atecc608_config, 386                  | INFO MODE REVISION          |
| _atsha204a_config, 390                 | calib command.h, 743        |
| i2c_bus_ref_ct                         | INFO MODE STATE             |
| hal_esp32_i2c.c, 839                   | <del>-</del> -              |
| i2c_descriptor                         | calib_command.h, 743        |
| i2c_start_instance, 530                | INFO_MODE_VOL_KEY_PERMIT    |
| I2C Enable                             | calib_command.h, 743        |
| _atecc508a_config, 382                 | INFO_NO_STATE               |
| _atecc608_config, 386                  | calib_command.h, 743        |
| _atsha204a_config, 390                 | INFO_OUTPUT_STATE_MASK      |
| i2c_file                               | calib_command.h, 743        |
| atcal2Cmaster, 451                     | INFO PARAM1 IDX             |
|                                        | calib_command.h, 744        |
| i2c_hal_data                           | INFO PARAM2 IDX             |
| hal_esp32_i2c.c, 839                   | calib command.h, 744        |
| i2c_instance                           | INFO_PARAM2_LATCH_CLEAR     |
| i2c_sam0_instance, 529                 |                             |
| i2c_sam_instance, 530                  | calib_command.h, 744        |
| i2c_sam0_instance, 529                 | INFO_PARAM2_LATCH_SET       |
| change_baudrate, 529                   | calib_command.h, 744        |
| i2c_instance, 529                      | INFO_PARAM2_SET_LATCH_STATE |
| i2c_sam0_instance_t                    | calib_command.h, 744        |
| hal_sam0_i2c_asf.h, 853                | INFO_RSP_SIZE               |
| i2c_sam_instance, 530                  | calib_command.h, 744        |
| change_baudrate, 530                   | INFO SIZE                   |
| i2c_instance, 530                      | calib_command.h, 745        |
| i2c sam instance t                     | INFRINGEMENT                |
|                                        | license.txt, 882            |
| Hardware abstraction layer (hal_), 267 | initATCACommand             |
| i2c_start_instance, 530                |                             |
| change_baudrate, 530                   | ATCACommand (atca_), 123    |
| i2c_descriptor, 530                    | initATCADevice              |
| i2c_start_instance_t                   | ATCADevice (atca_), 144     |
| Hardware abstraction layer (hal_), 267 | initATCAlface               |
| id                                     | ATCAlface (atca_), 151      |
| atcacert_cert_element_s, 441           | initialized                 |
| atcal2Cmaster, 451                     | _pkcs11_lib_ctx, 393        |
| idx                                    | _pkcs11_session_ctx, 398    |
| ATCAlfaceCfg, 456                      | _pkcs11_slot_ctx, 400       |
| iface_type                             | input_data                  |
| 1700                                   | put data                    |

| atca_write_mac_in_out, 438      | iv                                                                |
|---------------------------------|-------------------------------------------------------------------|
| interface_config                | CK_AES_CBC_ENCRYPT_DATA_PARAMS, 461                               |
| _pkcs11_slot_ctx, 400           | CK_ARIA_CBC_ENCRYPT_DATA_PARAMS, 464                              |
| io_key                          | CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS,                              |
| atca_io_decrypt_in_out, 423     | 467                                                               |
| atca_secureboot_enc_in_out, 426 | CK_DES_CBC_ENCRYPT_DATA_PARAMS, 472                               |
| atca_verify_mac, 436            | CK_RC2_CBC_PARAMS, 494                                            |
| io_protection_get_key           | CK SEED CBC ENCRYPT DATA PARAMS, 499                              |
| _, _ <del>,</del> _ ,           | OK_OLED_ODO_ENOTET T_D/M/_17/11/M/O, 400                          |
| io_protection_key.h, 862        | j0                                                                |
| io_protection_key.h, 862        | atca_aes_gcm_ctx, 406                                             |
| io_protection_get_key, 862      | JSON Web Token (JWT) methods (atca_jwt_), 326                     |
| io_protection_set_key, 862      | atca_jwt_add_claim_numeric, 326                                   |
| io_protection_set_key           | atca_jwt_add_claim_string, 326                                    |
| io_protection_key.h, 862        | atca_jwt_add_claint_string, 320 atca_jwt_check_payload_start, 327 |
| is_64                           | atca_jwt_finalize, 327                                            |
| atca_temp_key, 433              | atca_jwt_init, 327                                                |
| is_device_sn                    | atca_jwt_init, 327 atca_jwt_verify, 327                           |
| atcacert_build_state_s, 440     | alca_jwi_verily, 327                                              |
| is_genkey                       | kdf                                                               |
| atcacert_device_loc_s, 447      | CK_ECDH1_DERIVE_PARAMS, 473                                       |
| is_key_nomac                    |                                                                   |
| atca_gen_dig_in_out, 416        | CK_ECDH2_DERIVE_PARAMS, 474                                       |
| is_slot_locked                  | CK_ECDH_AES_KEY_WRAP_PARAMS, 476                                  |
| atca sign internal in out, 431  | CK_ECMQV_DERIVE_PARAMS, 477                                       |
| isAlpha                         | CK_GOSTR3410_DERIVE_PARAMS, 480                                   |
| atca_helpers.c, 599             | CK_X9_42_DH1_DERIVE_PARAMS, 523                                   |
| atca_helpers.h, 610             | CK_X9_42_DH2_DERIVE_PARAMS, 524                                   |
| isATCAError                     | CK_X9_42_MQV_DERIVE_PARAMS, 526                                   |
| calib_command.c, 692            | KDF_DETAILS_AES_KEY_LOC_MASK                                      |
| calib_command.h, 794            | calib_command.h, 745                                              |
|                                 | KDF_DETAILS_HKDF_MSG_LOC_INPUT                                    |
| isBase64                        | calib_command.h, 745                                              |
| atca_helpers.c, 599             | KDF_DETAILS_HKDF_MSG_LOC_IV                                       |
| atca_helpers.h, 610             | calib_command.h, 745                                              |
| isBase64Digit                   | KDF_DETAILS_HKDF_MSG_LOC_MASK                                     |
| atca_helpers.c, 600             | calib_command.h, 745                                              |
| atca_helpers.h, 610             | KDF_DETAILS_HKDF_MSG_LOC_SLOT                                     |
| isDigit                         | calib_command.h, 745                                              |
| atca_helpers.c, 600             | KDF_DETAILS_HKDF_MSG_LOC_TEMPKEY                                  |
| atca_helpers.h, 611             | calib_command.h, 746                                              |
| isHex                           | KDF_DETAILS_HKDF_ZERO_KEY                                         |
| atca_helpers.c, 601             | calib command.h, 746                                              |
| atca_helpers.h, 611             | KDF_DETAILS_IDX                                                   |
| isHexAlpha                      | calib command.h, 746                                              |
| atca_helpers.c, 601             | KDF_DETAILS_PRF_AEAD_MASK                                         |
| atca_helpers.h, 611             | calib_command.h, 746                                              |
| isHexDigit                      | KDF_DETAILS_PRF_AEAD_MODE0                                        |
| atca_helpers.c, 601             | calib_command.h, 746                                              |
| atca_helpers.h, 612             | KDF_DETAILS_PRF_AEAD_MODE1                                        |
| isSender                        | calib_command.h, 746                                              |
| CK_KEA_DERIVE_PARAMS, 483       | KDF_DETAILS_PRF_KEY_LEN_16                                        |
| issue_date_format               | calib_command.h, 747                                              |
| atcacert_def_s, 445             | KDF_DETAILS_PRF_KEY_LEN_32                                        |
| isWhiteSpace                    |                                                                   |
| •                               | calib_command.h, 747                                              |
| atca_helpers.c, 602             | KDF_DETAILS_PRF_KEY_LEN_48                                        |
| atca_helpers.h, 612             | calib_command.h, 747                                              |
| iterations                      | KDF_DETAILS_PRF_KEY_LEN_64                                        |
| CK_PKCS5_PBKD2_PARAMS, 491      | calib_command.h, 747                                              |
| CK_PKCS5_PBKD2_PARAMS2, 492     | KDF_DETAILS_PRF_KEY_LEN_MASK                                      |

| calib command.h, 747                   | atca_gen_dig_in_out, 416                    |
|----------------------------------------|---------------------------------------------|
| KDF_DETAILS_PRF_TARGET_LEN_32          | key config                                  |
| calib_command.h, 747                   | atca_sign_internal_in_out, 431              |
| KDF DETAILS PRF TARGET LEN 64          | key_id                                      |
| calib_command.h, 748                   | atca_aes_cbc_ctx, 402                       |
| KDF_DETAILS_PRF_TARGET_LEN_MASK        | atca_aes_ctr_ctx, 404                       |
| calib_command.h, 748                   | atca_aes_gcm_ctx, 406                       |
| KDF DETAILS SIZE                       | atca_check_mac_in_out, 408                  |
| calib_command.h, 748                   | atca_gen_dig_in_out, 416                    |
| KDF_KEYID_IDX                          | atca_gen_key_in_out, 418                    |
| calib_command.h, 748                   | atca_sign_internal_in_out, 431              |
| KDF_MESSAGE_IDX                        | atca_temp_key, 434                          |
| calib_command.h, 748                   | atca_terrify_mac, 436                       |
|                                        | _ •                                         |
| KDF_MODE_ALG_AES                       | atca_write_mac_in_out, 438                  |
| calib_command.h, 748                   | Host side crypto methods (atcah_), 322      |
| KDF_MODE_ALG_HKDF                      | KeyConfig                                   |
| calib_command.h, 749                   | _atecc508a_config, 382                      |
| KDF_MODE_ALG_MASK                      | _atecc608_config, 386                       |
| calib_command.h, 749                   | KIND                                        |
| KDF_MODE_ALG_PRF                       | license.txt, 882                            |
| calib_command.h, 749                   | kit_id_from_devtype                         |
| KDF_MODE_IDX                           | Hardware abstraction layer (hal_), 294      |
| calib_command.h, 749                   | kit_idle                                    |
| KDF_MODE_SOURCE_ALTKEYBUF              | Hardware abstraction layer (hal_), 294      |
| calib_command.h, 749                   | kit_init                                    |
| KDF_MODE_SOURCE_MASK                   | Hardware abstraction layer (hal_), 294      |
| calib_command.h, 749                   | kit_interface_from_kittype                  |
| KDF_MODE_SOURCE_SLOT                   | Hardware abstraction layer (hal_), 294      |
| calib_command.h, 750                   | KIT_MAX_SCAN_COUNT                          |
| KDF_MODE_SOURCE_TEMPKEY                | Hardware abstraction layer (hal_), 262      |
| calib_command.h, 750                   | KIT MAX TX BUF                              |
| KDF_MODE_SOURCE_TEMPKEY_UP             | Hardware abstraction layer (hal_), 263      |
| calib_command.h, 750                   | KIT MSG SIZE                                |
| KDF_MODE_TARGET_ALTKEYBUF              | Hardware abstraction layer (hal_), 263      |
| calib_command.h, 750                   | kit_parse_rsp                               |
| KDF MODE TARGET MASK                   | Hardware abstraction layer (hal_), 295      |
| calib_command.h, 750                   | kit_phy.h, 863                              |
| KDF_MODE_TARGET_OUTPUT                 | kit_phy_num_found                           |
| calib_command.h, 750                   | Hardware abstraction layer (hal_), 295      |
| KDF_MODE_TARGET_OUTPUT_ENC             | kit_phy_receive                             |
| calib_command.h, 751                   | Hardware abstraction layer (hal.), 295, 296 |
| KDF_MODE_TARGET_SLOT                   | kit phy send                                |
|                                        | Hardware abstraction layer (hal.), 296      |
| calib_command.h, 751                   | • • —                                       |
| KDF_MODE_TARGET_TEMPKEY                | kit_protocol.c, 863                         |
| calib_command.h, 751                   | kit_protocol.h, 864                         |
| KDF_MODE_TARGET_TEMPKEY_UP             | kit_receive                                 |
| calib_command.h, 751                   | Hardware abstraction layer (hal_), 297      |
| KdflvLoc                               | KIT_RX_WRAP_SIZE                            |
| _atecc608_config, 386                  | Hardware abstraction layer (hal_), 263      |
| KdflvStr                               | kit_send                                    |
| _atecc608_config, 386                  | Hardware abstraction layer (hal_), 297      |
| key                                    | kit_sleep                                   |
| Host side crypto methods (atcah_), 321 | Hardware abstraction layer (hal_), 298      |
| key_block                              | KIT_TX_WRAP_SIZE                            |
| atca_aes_cbc_ctx, 402                  | Hardware abstraction layer (hal_), 263      |
| atca_aes_ctr_ctx, 404                  | kit_wake                                    |
| atca_aes_gcm_ctx, 406                  | Hardware abstraction layer (hal_), 298      |
| key_conf                               | kit_wrap_cmd                                |

| Hardware abstraction layer (hal_), 298 | license, 883              |
|----------------------------------------|---------------------------|
| lahal                                  | LOSS, 884                 |
| label                                  | MERCHANTABILITY, 884      |
| _pkcs11_slot_ctx, 400                  | merge, 884                |
| CK_TOKEN_INFO, 515                     | met, 884                  |
| LastKeyUse                             | modification, 885         |
| _atecc508a_config, 382                 | modify, 885               |
| _atsha204a_config, 390                 | notice, 885               |
| LAW                                    | OTHERWISE, 885            |
| license.txt, 883                       | Ott, 886                  |
| leftRotate                             | publish, 886              |
| sha1_routines.h, 1068                  | PUNITIVE, 886             |
| length                                 | restriction, 886          |
| CK_AES_CBC_ENCRYPT_DATA_PARAMS, 461    | so, 887                   |
| CK_ARIA_CBC_ENCRYPT_DATA_PARAMS, 465   | SOFTWARE, 887             |
| CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS,   | Software, 887             |
| 467                                    | software, 875             |
| CK_DES_CBC_ENCRYPT_DATA_PARAMS, 472    | SPECIAL, 887              |
| CK_SEED_CBC_ENCRYPT_DATA_PARAMS, 499   | STATUTORY, 888            |
| LIABILITY                              | sublicense, 888           |
| license.txt, 883                       | terms, 888                |
| libraryDescription                     |                           |
| CK_INFO, 482                           | TO, 888                   |
| libraryVersion                         | TORT, 875                 |
| CK_INFO, 482                           | use, 889                  |
| License                                | VanderVoord, 889          |
| license.txt, 883                       | Version, 875              |
| license                                | WARRANTIES, 889           |
| license.txt, 883                       | LOCK_COUNT                |
| license.txt, 865                       | calib_command.h, 751      |
| ANY, 876                               | lock_mutex                |
| BASIS, 876                             | _pkcs11_lib_ctx, 394      |
| CAUSED, 876                            | LOCK_RSP_SIZE             |
| charge, 876                            | calib_command.h, 751      |
| CLAIM, 877                             | LOCK_SUMMARY_IDX          |
| conditions, 877                        | calib_command.h, 752      |
| CONTRACT, 877                          | LOCK_ZONE_CONFIG          |
| copy, 877                              | calib_command.h, 752      |
| DAMAGE, 878                            | LOCK_ZONE_DATA            |
| DAMAGES, 874                           | calib_command.h, 752      |
| DIRECT, 878                            | LOCK_ZONE_DATA_SLOT       |
| distribute, 879                        | calib_command.h, 752      |
| EXEMPLARY, 879                         | LOCK_ZONE_IDX             |
| EXPRESS, 879                           | calib_command.h, 752      |
| FEES, 879                              | LOCK ZONE MASK            |
| files, 874                             | calib command.h, 752      |
| forms, 880                             | LOCK ZONE NO CRC          |
| FROM, 880                              | calib command.h, 753      |
| granted, 880                           | LockConfig                |
| http, 880                              | _atecc508a_config, 382    |
| IMPLIED, 881                           | atecc608 config, 387      |
| INCIDENTAL, 881                        | atsha204a config, 390     |
| INCLUDING, 881                         | LockMutex                 |
|                                        | CK C INITIALIZE ARGS, 466 |
| INDIRECT, 882                          | LockValue                 |
| INFRINGEMENT, 882                      |                           |
| KIND, 882                              | _atecc508a_config, 382    |
| LAW, 883                               | _atecc608_config, 387     |
| LIABILITY, 883                         | _atsha204a_config, 390    |
| License, 883                           | LOG_LOCAL_LEVEL           |

| hal esp32 i2c.c, 830                   | hal_esp32_i2c.c, 830                                   |
|----------------------------------------|--------------------------------------------------------|
| logged_in                              | Hardware abstraction layer (hal_), 263                 |
|                                        |                                                        |
| _pkcs11_session_ctx, 398               | MAX_SPI_BUSES                                          |
| LOSS                                   | Hardware abstraction layer (hal_), 263                 |
| license.txt, 884                       | MAX_SWI_BUSES                                          |
|                                        | Hardware abstraction layer (hal_), 263, 264            |
| mac                                    | mbedTLS Wrapper methods (atca_mbedtls_), 328           |
| atca_derive_key_mac_in_out, 413        | atca_mbedtls_cert_add, 328                             |
| atca_secureboot_mac_in_out, 428        | atca mbedtls ecdh ioprot cb, 328                       |
| atca_verify_mac, 436                   | atca_mbedtls_ecdh_slot_cb, 328                         |
| MAC_CHALLENGE_IDX                      | atca_mbedtls_pk_init, 329                              |
| calib_command.h, 753                   | mbedtls_calloc                                         |
| MAC CHALLENGE SIZE                     |                                                        |
| calib_command.h, 753                   | atca_mbedtls_wrap.c, 624                               |
| MAC COUNT LONG                         | MBEDTLS_CMAC_C                                         |
| calib_command.h, 753                   | atca_crypto_sw.h, 575                                  |
| MAC_COUNT_SHORT                        | mbedtls_free                                           |
|                                        | atca_mbedtls_wrap.c, 624                               |
| calib_command.h, 753                   | mCommands                                              |
| MAC_KEYID_IDX                          | atca_device, 414                                       |
| calib_command.h, 753                   | mechanism                                              |
| MAC_MODE_BLOCK1_TEMPKEY                | CK_MECHANISM, 486                                      |
| calib_command.h, 754                   | memcpy P                                               |
| MAC_MODE_BLOCK2_TEMPKEY                | —                                                      |
| calib_command.h, 754                   | sha1_routines.h, 1068                                  |
| MAC MODE CHALLENGE                     | memory_parameters, 531                                 |
| calib_command.h, 754                   | memory_size, 531                                       |
| MAC_MODE_IDX                           | reserved, 531                                          |
| calib_command.h, 754                   | signature, 531                                         |
| MAC MODE INCLUDE OTP 64                | start_address, 531                                     |
| calib_command.h, 754                   | version_info, 531                                      |
|                                        | memory_params                                          |
| MAC_MODE_INCLUDE_OTP_88                | secure_boot_parameters, 533                            |
| calib_command.h, 754                   | memory_size                                            |
| MAC_MODE_INCLUDE_SN                    | memory_parameters, 531                                 |
| calib_command.h, 755                   | MERCHANTABILITY                                        |
| MAC_MODE_MASK                          |                                                        |
| calib_command.h, 755                   | license.txt, 884                                       |
| MAC_MODE_PASSTHROUGH                   | merge                                                  |
| calib_command.h, 755                   | license.txt, 884                                       |
| MAC MODE PTNONCE TEMPKEY               | message                                                |
| calib_command.h, 755                   | atca_sign_internal_in_out, 431                         |
| MAC MODE SOURCE FLAG MATCH             | met                                                    |
| calib_command.h, 755                   | license.txt, 884                                       |
| MAC MODE USE TEMPKEY MASK              | mgf                                                    |
| Host side crypto methods (atcah ), 310 | CK RSA PKCS OAEP PARAMS, 498                           |
| · —                                    | CK RSA PKCS PSS PARAMS, 499                            |
| MAC_RSP_SIZE                           | mlface                                                 |
| calib_command.h, 755                   |                                                        |
| MAC_SIZE                               | atca_device, 414                                       |
| calib_command.h, 756                   | mlfaceCFG                                              |
| major                                  | atca_iface, 421                                        |
| CK_VERSION, 518                        | minor                                                  |
| manufacturerID                         | CK_VERSION, 518                                        |
| CK INFO, 482                           | mode                                                   |
| CK SLOT INFO, 505                      | atca_check_mac_in_out, 408                             |
| CK_TOKEN_INFO, 515                     | atca_derive_key_in_out, 411                            |
| MAX BUSES                              | atca_derive_key_mac_in_out, 413                        |
| calib_basic.c, 673                     | atca_gen_key_in_out, 418                               |
|                                        | atca_gen_key_in_out, 416 atca_include_data_in_out, 422 |
| max_cert_size                          |                                                        |
| atcacert_build_state_s, 440            | atca_secureboot_mac_in_out, 428                        |
| MAX_I2C_BUSES                          | atca_sign_internal_in_out, 431                         |

| atca_verify_mac, 436                   | NONCE_MODE_TARGET_MSGDIGBUF            |
|----------------------------------------|----------------------------------------|
| Host side crypto methods (atcah_), 322 | calib command.h, 758                   |
| model                                  | NONCE_MODE_TARGET_TEMPKEY              |
| CK_TOKEN_INFO, 516                     | calib_command.h, 758                   |
| modification                           | NONCE_NUMIN_SIZE                       |
| license.txt, 885                       | calib_command.h, 759                   |
| modify                                 | NONCE_NUMIN_SIZE_PASSTHROUGH           |
| license.txt, 885                       | calib_command.h, 759                   |
| month                                  | NONCE PARAM2 IDX                       |
| CK DATE, 471                           | calib_command.h, 759                   |
| <del>-</del>                           | NONCE RSP SIZE LONG                    |
| msg_dig_buf                            | calib_command.h, 759                   |
| atca_verify_mac, 436                   |                                        |
| mType                                  | NONCE_RSP_SIZE_SHORT                   |
| atca_iface, 422                        | calib_command.h, 759                   |
| mutex                                  | NONCE_ZERO_CALC_MASK                   |
| _pkcs11_lib_ctx, 394                   | calib_command.h, 759                   |
| NACK VAL                               | NONCE_ZERO_CALC_RANDOM                 |
| NACK_VAL                               | calib_command.h, 760                   |
| hal_esp32_i2c.c, 830                   | NONCE_ZERO_CALC_TEMPKEY                |
| name                                   | calib_command.h, 760                   |
| _pkcs11_object, 396                    | notice                                 |
| newATCACommand                         | license.txt, 885                       |
| ATCACommand (atca_), 123               | NULL_PTR                               |
| newATCADevice                          | cryptoki.h, 821                        |
| ATCADevice (atca_), 144                | num_in                                 |
| newATCAlface                           | Host side crypto methods (atcah_), 322 |
| ATCAlface (atca_), 151                 |                                        |
| no_mac_flag                            | object                                 |
| atca_temp_key, 434                     | _pkcs11_object_cache_t, 397            |
| NONCE_COUNT_LONG                       | object_count                           |
| calib_command.h, 756                   | _pkcs11_session_ctx, 398               |
| NONCE_COUNT_LONG_64                    | object_index                           |
| calib_command.h, 756                   | _pkcs11_session_ctx, 398               |
| NONCE_COUNT_SHORT                      | offset                                 |
| calib_command.h, 756                   | atcacert cert loc s, 442               |
| NONCE_INPUT_IDX                        | atcacert_device_loc_s, 447             |
| calib command.h, 756                   | opcode                                 |
| NONCE_MODE_IDX                         | ATCAPacket, 458                        |
|                                        |                                        |
| calib_command.h, 756                   | other_data                             |
| NONCE_MODE_INPUT_LEN_32                | atca_check_mac_in_out, 408             |
| calib_command.h, 757                   | atca_gen_dig_in_out, 416               |
| NONCE_MODE_INPUT_LEN_64                | atca_gen_key_in_out, 418               |
| calib_command.h, 757                   | atca_verify_mac, 436                   |
| NONCE_MODE_INPUT_LEN_MASK              | OTHERWISE                              |
| calib_command.h, 757                   | license.txt, 885                       |
| NONCE_MODE_INVALID                     | otp                                    |
| calib_command.h, 757                   | atca_check_mac_in_out, 408             |
| NONCE_MODE_MASK                        | Host side crypto methods (atcah_), 323 |
| calib_command.h, 757                   | otpcode                                |
| NONCE_MODE_NO_SEED_UPDATE              | tng_cert_map_element, 535              |
| calib_command.h, 757                   | OTPmode                                |
| NONCE MODE PASSTHROUGH                 | _atecc508a_config, 383                 |
| calib command.h, 758                   | _atsha204a_config, 390                 |
| NONCE_MODE_SEED_UPDATE                 | Ott                                    |
| calib_command.h, 758                   | license.txt, 886                       |
| NONCE_MODE_TARGET_ALTKEYBUF            | out nonce                              |
| calib command.h, 758                   | atca_io_decrypt_in_out, 423            |
| NONCE_MODE_TARGET_MASK                 | OUTNONCE_SIZE                          |
| calib_command.h, 758                   | calib_command.h, 760                   |
| Jano Commandili, 700                   | oans_command.n, 700                    |

| p_temp                                 | CK_SEED_CBC_ENCRYPT_DATA_PARAMS, 499    |
|----------------------------------------|-----------------------------------------|
| Host side crypto methods (atcah_), 323 | pDigestMechanism                        |
| pAAD                                   | CK_CMS_SIG_PARAMS, 470                  |
| CK_AES_CCM_PARAMS, 462                 | PEM_CERT_BEGIN                          |
| CK_AES_GCM_PARAMS, 463                 | atcacert_pem.h, 662                     |
| CK_CCM_PARAMS, 468                     | PEM_CERT_END                            |
| CK_GCM_PARAMS, 479                     | atcacert_pem.h, 662                     |
| packetsize                             | PEM_CSR_BEGIN                           |
| ATCAlfaceCfg, 456                      | atcacert_pem.h, 662                     |
| packHex                                | PEM_CSR_END                             |
| atca_helpers.c, 602                    | atcacert_pem.h, 663                     |
| atca_helpers.h, 613                    | pid                                     |
| pApplication                           | ATCAlfaceCfg, 456                       |
| pkcs11t.h, 1057                        | pin_conf                                |
| param1                                 | Hardware abstraction layer (hal_), 302  |
| ATCAPacket, 458                        | pInitVector                             |
| param2                                 | CK_PBE_PARAMS, 489                      |
| atca_secureboot_mac_in_out, 428        | pIV                                     |
| ATCAPacket, 458                        | CK WTLS KEY MAT OUT, 518                |
| parent_key                             | plv                                     |
| atca_derive_key_in_out, 411            | CK_AES_GCM_PARAMS, 463                  |
| atca derive key mac in out, 413        | CK_GCM_PARAMS, 479                      |
| parity                                 | CK RC5 CBC PARAMS, 495                  |
| ATCAlfaceCfg, 456                      | pIVClient                               |
| partial_aad                            | CK_SSL3_KEY_MAT_OUT, 507                |
| atca_aes_gcm_ctx, 407                  | plVServer                               |
| partial_aad_size                       | CK_SSL3_KEY_MAT_OUT, 507                |
| atca_aes_gcm_ctx, 407                  | pkcs11.h, 890                           |
| PAUSE_COUNT                            | PASTE, 890                              |
| calib_command.h, 760                   | CK_NEED_ARG_LIST, 890, 891              |
| PAUSE_PARAM2_IDX                       | CK_PKCS11_FUNCTION_INFO, 891            |
| calib_command.h, 760                   | PKCS11 API                              |
| PAUSE_RSP_SIZE                         | cryptoki.h, 822                         |
| calib_command.h, 760                   | pkcs11_attrib.c, 891                    |
| PAUSE_SELECT_IDX                       | pkcs11_attrib.h, 892                    |
| calib_command.h, 761                   | attrib_f, 893                           |
| pBaseG                                 | pkcs11_attrib_model, 893                |
| CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501   | pkcs11_attrib_model_ptr, 893            |
| PCKS11_MECH_ECC508_EC_CAPABILITY       | pkcs11_attrib_empty                     |
| Attributes (pkcs11 attrib ), 337       | Attributes (pkcs11_attrib_), 353        |
| pcks11_mech_table_e                    | pkcs11_attrib_false                     |
| Attributes (pkcs11_attrib_), 337       | Attributes (pkcs11_attrib_), 353        |
| pcks11_mech_table_ptr                  | pkcs11_attrib_fill                      |
| Attributes (pkcs11_attrib_), 337       | Attributes (pkcs11_attrib_), 353        |
| pClientRandom                          | pkcs11_attrib_model                     |
| CK_SSL3_RANDOM_DATA, 509               | pkcs11_attrib.h, 893                    |
| CK_WTLS_RANDOM_DATA, 522               | pkcs11 attrib model ptr                 |
| pContentType                           | pkcs11_attrib.h, 893                    |
| CK_CMS_SIG_PARAMS, 470                 | pkcs11_attrib_true                      |
| pContextData                           | Attributes (pkcs11_attrib_), 353        |
| CK_TLS_KDF_PARAMS, 512                 | pkcs11_attrib_value                     |
| pData                                  | Attributes (pkcs11_attrib_), 354        |
| CK_AES_CBC_ENCRYPT_DATA_PARAMS, 461    | pkcs11_cert.c, 893                      |
| CK_ARIA_CBC_ENCRYPT_DATA_PARAMS, 465   | pkcs11_cert.h, 894                      |
| CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS,   | . —                                     |
| 467                                    | Attributes (pkcs11_attrib_), 354        |
| CK_DES_CBC_ENCRYPT_DATA_PARAMS, 472    | pkcs11_cert_get_encoded                 |
| CK_KEY_DERIVATION_STRING_DATA, 484     | Attributes (pkcs11_attrib_), 354        |
|                                        | / ((( ) ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( |

| pkcs11_cert_get_subject                       | pkcs11_digest                                        |
|-----------------------------------------------|------------------------------------------------------|
| Attributes (pkcs11_attrib_), 354              | pkcs11_digest.c, 897                                 |
| pkcs11_cert_get_subject_key_id                | pkcs11_digest.h, 899                                 |
| Attributes (pkcs11_attrib_), 354              | pkcs11_digest.c, 897                                 |
| pkcs11_cert_get_trusted_flag                  | pkcs11_digest, 897                                   |
| Attributes (pkcs11_attrib_), 354              | pkcs11_digest_final, 897                             |
| pkcs11_cert_get_type                          | pkcs11_digest_init, 898                              |
| Attributes (pkcs11_attrib_), 355              | pkcs11_digest_update, 898                            |
| pkcs11_cert_wtlspublic_attributes             | pkcs11_digest.h, 898                                 |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest, 899                                   |
| pkcs11_cert_wtlspublic_attributes_count       | pkcs11_digest_final, 899                             |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest_init, 899                              |
| pkcs11_cert_x509_attributes                   | pkcs11_digest_update, 899                            |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest_final                                  |
| pkcs11_cert_x509_attributes_count             | pkcs11_digest.c, 897                                 |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest.h, 899                                 |
| pkcs11_cert_x509_write                        | pkcs11_digest_init                                   |
| Attributes (pkcs11_attrib_), 355              | pkcs11_digest.c, 898                                 |
| pkcs11_cert_x509public_attributes             | pkcs11_digest.h, 899                                 |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest_update                                 |
| pkcs11_cert_x509public_attributes_count       | pkcs11_digest.c, 898                                 |
| Attributes (pkcs11_attrib_), 369              | pkcs11_digest.h, 899                                 |
| pkcs11_config.c, 895                          | pkcs11_find.c, 900                                   |
| pkcs11_config_cert                            | pkcs11_find.h, 900                                   |
| Attributes (pkcs11_attrib_), 355              | pkcs11_find_continue                                 |
| example_pkcs11_config.c, 826                  | Attributes (pkcs11_attrib_), 356                     |
| pkcs11_config_init_cert                       | pkcs11_find_finish                                   |
| Attributes (pkcs11_attrib_), 355              | Attributes (pkcs11_attrib_), 357                     |
| pkcs11_config_init_private                    | pkcs11_find_get_attribute                            |
| Attributes (pkcs11_attrib_), 355              | Attributes (pkcs11_attrib_), 357                     |
| pkcs11_config_init_public                     | pkcs11_find_init                                     |
| Attributes (pkcs11_attrib_), 355              | Attributes (pkcs11_attrib_), 357                     |
| pkcs11_config_key                             | pkcs11_get_context                                   |
| Attributes (pkcs11_attrib_), 356              |                                                      |
| example_pkcs11_config.c, 826                  | Attributes (pkcs11_attrib_), 357 pkcs11_get_lib_info |
| pkcs11_config_load                            | Attributes (pkcs11_attrib_), 357                     |
| Attributes (pkcs11_attrib_), 356              | pkcs11_get_session_context                           |
| pkcs11_config_load_objects                    | Attributes (pkcs11_attrib_), 357                     |
| Attributes (pkcs11_attrib_), 356              | PKCS11_HELPER_DLL_EXPORT                             |
| example_pkcs11_config.c, 826                  | cryptoki.h, 822                                      |
|                                               | PKCS11_HELPER_DLL_IMPORT                             |
| pkcs11_config_remove_object                   | cryptoki.h, 822                                      |
| Attributes (pkcs11_attrib_), 356 PKCS11 DEBUG | •                                                    |
| <del>_</del>                                  | PKCS11_HELPER_DLL_LOCAL                              |
| pkcs11_debug.h, 896                           | cryptoki.h, 822                                      |
| pkcs11_debug.c, 895                           | pkcs11_info.c, 901                                   |
| pkcs11_debug.h, 896                           | pkcs11_info.h, 902                                   |
| PKCS11_DEBUG, 896                             | pkcs11_init                                          |
| pkcs11_debug_attributes, 896                  | Attributes (pkcs11_attrib_), 358                     |
| PKCS11_DEBUG_NOFILE, 896                      | pkcs11_init.c, 902                                   |
| PKCS11_DEBUG_RETURN, 897                      | pkcs11_init.h, 903                                   |
| pkcs11_debug_attributes                       | pkcs11_lib_ctx, 904                                  |
| pkcs11_debug.h, 896                           | pkcs11_lib_ctx_ptr, 904                              |
| PKCS11_DEBUG_NOFILE                           | pkcs11_init_check                                    |
| pkcs11_debug.h, 896                           | Attributes (pkcs11_attrib_), 358                     |
| PKCS11_DEBUG_RETURN                           | pkcs11_key.c, 904                                    |
| pkcs11_debug.h, 897                           | pkcs11_key.h, 905                                    |
| pkcs11_deinit                                 | pkcs11_key_derive                                    |
| Attributes (pkcs11_attrib_), 356              | Attributes (pkcs11_attrib_), 358                     |

| pkcs11_key_ec_private_attributes                      | pkcs11_object_check                                                |
|-------------------------------------------------------|--------------------------------------------------------------------|
| Attributes (pkcs11_attrib_), 369                      | Attributes (pkcs11_attrib_), 359                                   |
| pkcs11_key_ec_public_attributes                       | pkcs11_object_create                                               |
| Attributes (pkcs11_attrib_), 370                      | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_key_generate_pair                              | pkcs11_object_deinit                                               |
| Attributes (pkcs11_attrib_), 358                      | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_key_private_attributes                         | pkcs11_object_destroy                                              |
| Attributes (pkcs11_attrib_), 370                      | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_key_private_attributes_count                   | pkcs11_object_find                                                 |
| Attributes (pkcs11_attrib_), 370                      | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_key_public_attributes                          | PKCS11_OBJECT_FLAG_DESTROYABLE                                     |
| Attributes (pkcs11_attrib_), 370                      | pkcs11_object.h, 914                                               |
| pkcs11_key_public_attributes_count                    | PKCS11_OBJECT_FLAG_DYNAMIC                                         |
| Attributes (pkcs11_attrib_), 370                      | pkcs11_object.h, 914                                               |
| pkcs11_key_rsa_private_attributes                     | PKCS11_OBJECT_FLAG_MODIFIABLE                                      |
| Attributes (pkcs11_attrib_), 370                      | pkcs11_object.h, 914                                               |
| pkcs11_key_secret_attributes                          | PKCS11_OBJECT_FLAG_SENSITIVE                                       |
| Attributes (pkcs11_attrib_), 371                      | pkcs11 object.h, 914                                               |
| pkcs11_key_secret_attributes_count                    | PKCS11_OBJECT_FLAG_TA_TYPE                                         |
| Attributes (pkcs11_attrib_), 371                      | pkcs11_object.h, 914                                               |
| pkcs11 key write                                      | PKCS11_OBJECT_FLAG_TRUST_TYPE                                      |
| Attributes (pkcs11_attrib_), 359                      | pkcs11 object.h, 914                                               |
| pkcs11_lib_ctx                                        | pkcs11_object_free                                                 |
| pkcs11_init.h, 904                                    | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_lib_ctx_ptr                                    | pkcs11_object_get_class                                            |
| pkcs11_init.h, 904                                    | Attributes (pkcs11_attrib_), 360                                   |
| pkcs11_lib_description                                | pkcs11_object_get_destroyable                                      |
| Attributes (pkcs11_attrib_), 371                      | Attributes (pkcs11_attrib_), 361                                   |
| pkcs11_lib_manufacturer_id                            | pkcs11_object_get_handle                                           |
| Attributes (pkcs11_attrib_), 371                      | Attributes (pkcs11_attrib_), 361                                   |
| PKCS11_LOCAL                                          | pkcs11_object_get_name                                             |
| cryptoki.h, 822                                       | Attributes (pkcs11_attrib_), 361                                   |
| pkcs11_lock_context                                   | pkcs11_object_get_size                                             |
| Attributes (pkcs11_attrib_), 359                      | Attributes (pkcs11_attrib_), 361                                   |
| pkcs11_main.c, 906                                    | pkcs11_object_get_type                                             |
| pkcs11_mech.c, 910                                    | Attributes (pkcs11_attrib_), 361                                   |
|                                                       |                                                                    |
| pkcs11_mech.h, 911                                    | pkcs11_object_load_handle_info<br>Attributes (pkcs11_attrib_), 361 |
| pkcs11_mech_get_list Attributes (pkcs11_attrib_), 359 | pkcs11_object_monotonic_attributes                                 |
|                                                       | Attributes (pkcs11_attrib_), 371                                   |
| pkcs11_object                                         |                                                                    |
| pkcs11_object.h, 915                                  | pkcs11_object_monotonic_attributes_count                           |
| pkcs11_object.c, 911                                  | Attributes (pkcs11_attrib_), 372                                   |
| pkcs11_object.h, 912                                  | pkcs11_object_ptr                                                  |
| pkcs11_object, 915                                    | pkcs11_object.h, 915                                               |
| pkcs11_object_cache_t, 915                            | pkcs11_os.c, 915                                                   |
| PKCS11_OBJECT_FLAG_DESTROYABLE, 914                   | pkcs11_os.h, 916                                                   |
| PKCS11_OBJECT_FLAG_DYNAMIC, 914                       | pkcs11_os_free, 916                                                |
| PKCS11_OBJECT_FLAG_MODIFIABLE, 914                    | pkcs11_os_malloc, 916                                              |
| PKCS11_OBJECT_FLAG_SENSITIVE, 914                     | pkcs11_os_create_mutex                                             |
| PKCS11_OBJECT_FLAG_TA_TYPE, 914                       | Attributes (pkcs11_attrib_), 362                                   |
| PKCS11_OBJECT_FLAG_TRUST_TYPE, 914                    | pkcs11_os_destroy_mutex                                            |
| pkcs11_object_ptr, 915                                | Attributes (pkcs11_attrib_), 362                                   |
| pkcs11_object_alloc                                   | pkcs11_os_free                                                     |
| Attributes (pkcs11_attrib_), 359                      | pkcs11_os.h, 916                                                   |
| pkcs11_object_cache                                   | pkcs11_os_lock_mutex                                               |
| Attributes (pkcs11_attrib_), 371                      | Attributes (pkcs11_attrib_), 362                                   |
| pkcs11_object_cache_t                                 | pkcs11_os_malloc                                                   |
| pkcs11_object.h, 915                                  | pkcs11_os.h, 916                                                   |

| pkcs11_os_unlock_mutex           | Attributes (pkcs11_attrib_), 366             |
|----------------------------------|----------------------------------------------|
| Attributes (pkcs11_attrib_), 362 | pkcs11_slot_get_list                         |
| pkcs11_session.c, 917            | Attributes (pkcs11_attrib_), 366             |
| pkcs11_session.h, 917            | pkcs11_slot_init                             |
| pkcs11_session_authorize, 919    | Attributes (pkcs11_attrib_), 366             |
| pkcs11_session_ctx, 918          | pkcs11_slot_initslots                        |
| pkcs11_session_ctx_ptr, 918      | Attributes (pkcs11_attrib_), 366             |
| pkcs11_session_authorize         | pkcs11_token.c, 923                          |
| pkcs11_session.h, 919            | pkcs11_token.h, 923                          |
| pkcs11_session_check             | pkcs11_token_convert_pin_to_key              |
| Attributes (pkcs11_attrib_), 362 | Attributes (pkcs11_attrib_), 366             |
| pkcs11_session_close             | pkcs11_token_get_access_type                 |
| Attributes (pkcs11_attrib_), 362 | Attributes (pkcs11_attrib_), 366             |
| pkcs11_session_closeall          | pkcs11_token_get_info                        |
| Attributes (pkcs11_attrib_), 363 | Attributes (pkcs11_attrib_), 367             |
| pkcs11_session_ctx               | pkcs11_token_get_storage                     |
| pkcs11_session.h, 918            | Attributes (pkcs11_attrib_), 367             |
| pkcs11_session_ctx_ptr           | pkcs11_token_get_writable                    |
| pkcs11_session.h, 918            | Attributes (pkcs11 attrib ), 367             |
| pkcs11_session_get_info          | pkcs11 token init                            |
| Attributes (pkcs11_attrib_), 363 | Attributes (pkcs11_attrib_), 367             |
| pkcs11_session_login             | pkcs11_token_random                          |
| Attributes (pkcs11_attrib_), 363 | Attributes (pkcs11_attrib_), 367             |
| pkcs11_session_logout            | pkcs11_token_set_pin                         |
| Attributes (pkcs11_attrib_), 363 | Attributes (pkcs11_attrib_), 367             |
| pkcs11_session_open              | pkcs11_unlock_context                        |
| Attributes (pkcs11_attrib_), 363 | Attributes (pkcs11_attrib_), 368             |
| pkcs11_signature.c, 919          | pkcs11_util.c, 924                           |
| pkcs11_signature.h, 920          | pkcs11_util.h, 925                           |
| pkcs11_signature_sign            | PKCS11_UTIL_ARRAY_SIZE, 925                  |
| Attributes (pkcs11_attrib_), 363 | PKCS11_UTIL_ARRAY_SIZE                       |
| pkcs11_signature_sign_continue   | pkcs11_util.h, 925                           |
| Attributes (pkcs11_attrib_), 364 | pkcs11_util_convert_rv                       |
| pkcs11_signature_sign_finish     | Attributes (pkcs11_attrib_), 368             |
| Attributes (pkcs11_attrib_), 364 | · – –                                        |
| pkcs11_signature_sign_init       | pkcs11_util_escape_string                    |
| Attributes (pkcs11_attrib_), 364 | Attributes (pkcs11_attrib_), 368             |
| pkcs11_signature_verify          | pkcs11_util_memset                           |
| Attributes (pkcs11_attrib_), 364 | Attributes (pkcs11_attrib_), 368             |
| pkcs11_signature_verify_continue | pkcs11configLABEL_DEVICE_CERTIFICATE_FOR_TLS |
| Attributes (pkcs11_attrib_), 365 | example_pkcs11_config.c, 825                 |
| pkcs11_signature_verify_finish   | pkcs11configLABEL_DEVICE_PRIVATE_KEY_FOR_TLS |
| Attributes (pkcs11_attrib_), 365 | example_pkcs11_config.c, 825                 |
| pkcs11_signature_verify_init     | pkcs11configLABEL_DEVICE_PUBLIC_KEY_FOR_TLS  |
| Attributes (pkcs11_attrib_), 365 | example_pkcs11_config.c, 825                 |
| pkcs11_slot.c, 921               | pkcs11configLABEL_JITP_CERTIFICATE           |
| pkcs11_slot.h, 921               | example_pkcs11_config.c, 826                 |
| pkcs11_slot_ctx, 922             | pkcs11f.h, 926                               |
| pkcs11_slot_ctx_ptr, 922         | pkcs11t.h, 926                               |
| pkcs11_slot_config               | CK_AES_CBC_ENCRYPT_DATA_PARAMS, 1034         |
| Attributes (pkcs11_attrib_), 365 | CK_AES_CBC_ENCRYPT_DATA_PARAMS_PTR,          |
| pkcs11_slot_ctx                  | 1034                                         |
| pkcs11_slot.h, 922               | CK_AES_CCM_PARAMS, 1034                      |
| pkcs11_slot_ctx_ptr              | CK_AES_CCM_PARAMS_PTR, 1034                  |
| pkcs11_slot.h, 922               | CK_AES_CTR_PARAMS, 1034                      |
| pkcs11_slot_get_context          | CK_AES_CTR_PARAMS_PTR, 1034                  |
| Attributes (pkcs11_attrib_), 365 | CK_AES_GCM_PARAMS, 1035                      |
| pkcs11_slot_get_info             | CK_AES_GCM_PARAMS_PTR, 1035                  |

| CK_ARIA_CBC_ENCRYPT_DATA_PARAMS,         | CK_FUNCTION_LIST_PTR, 1040                      |
|------------------------------------------|-------------------------------------------------|
| 1035                                     | CK_FUNCTION_LIST_PTR_PTR, 1040                  |
| CK_ARIA_CBC_ENCRYPT_DATA_PARAMS_PTR,     | CK_GCM_PARAMS, 1040                             |
| 1035                                     | CK_GCM_PARAMS_PTR, 1040                         |
| CK ATTRIBUTE, 1035                       | CK_GOSTR3410_DERIVE_PARAMS, 1040                |
| CK_ATTRIBUTE_PTR, 1035                   | CK_GOSTR3410_DERIVE_PARAMS_PTR, 1040            |
| CK_ATTRIBUTE_TYPE, 1035                  | CK_GOSTR3410_KEY_WRAP_PARAMS, 1041              |
| CK_BBOOL, 1035                           | CK_GOSTR3410_KEY_WRAP_PARAMS_PTR,               |
| CK_BYTE, 1036                            | 1041                                            |
| CK_BYTE_PTR, 1036                        | CK_HW_FEATURE_TYPE, 1041                        |
| CK C INITIALIZE ARGS, 1036               | CK_INFO, 1041                                   |
| CK_C_INITIALIZE_ARGS, 1036               | CK_INFO_PTR, 1041                               |
|                                          |                                                 |
| CK_CALLBACK_FUNCTION, 1057, 1058         | CK_INVALID_HANDLE, 944                          |
| CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS,     | CK_JAVA_MIDP_SECURITY_DOMAIN, 1041              |
| 1036                                     | CK_KEA_DERIVE_PARAMS, 1041                      |
| CK_CAMELLIA_CBC_ENCRYPT_DATA_PARAMS_PTR, |                                                 |
| 1036                                     | CK_KEY_DERIVATION_STRING_DATA, 1042             |
| CK_CAMELLIA_CTR_PARAMS, 1036             | CK_KEY_DERIVATION_STRING_DATA_PTR,              |
| CK_CAMELLIA_CTR_PARAMS_PTR, 1036         | 1042                                            |
| CK_CCM_PARAMS, 1037                      | CK_KEY_TYPE, 1042                               |
| CK_CCM_PARAMS_PTR, 1037                  | CK_KEY_WRAP_SET_OAEP_PARAMS, 1042               |
| CK_CERTIFICATE_CATEGORY, 1037            | CK_KEY_WRAP_SET_OAEP_PARAMS_PTR,                |
| CK_CERTIFICATE_CATEGORY_AUTHORITY,       | 1042                                            |
| 944                                      | CK_KIP_PARAMS, 1042                             |
| CK_CERTIFICATE_CATEGORY_OTHER_ENTITY,    | CK_KIP_PARAMS_PTR, 1042                         |
| 944                                      | CK_LONG, 1042                                   |
| CK_CERTIFICATE_CATEGORY_TOKEN_USER,      | CK_MAC_GENERAL_PARAMS, 1043                     |
| 944                                      | CK_MAC_GENERAL_PARAMS_PTR, 1043                 |
| CK_CERTIFICATE_CATEGORY_UNSPECIFIED,     | CK_MECHANISM, 1043                              |
| 944                                      | CK_MECHANISM_INFO, 1043                         |
| CK_CERTIFICATE_TYPE, 1037                | CK_MECHANISM_INFO_PTR, 1043                     |
| CK_CHAR, 1037                            | CK_MECHANISM_PTR, 1043                          |
| CK_CHAR_PTR, 1037                        | CK_MECHANISM_TYPE, 1043                         |
| CK_CMS_SIG_PARAMS, 1037                  | CK_MECHANISM_TYPE_PTR, 1043                     |
| CK_CMS_SIG_PARAMS_PTR, 1037              | CK_NOTIFICATION, 1044                           |
| CK_DATE, 1038                            | CK_OBJECT_CLASS, 1044                           |
| CK_DES_CBC_ENCRYPT_DATA_PARAMS, 1038     | CK_OBJECT_CLASS_PTR, 1044                       |
| CK_DES_CBC_ENCRYPT_DATA_PARAMS_PTR,      | CK_OBJECT_HANDLE, 1044                          |
| 1038                                     | CK_OBJECT_HANDLE_PTR, 1044                      |
| CK DSA PARAMETER GEN PARAM, 1038         | CK_OTP_CHALLENGE, 945                           |
| CK_DSA_PARAMETER_GEN_PARAM_PTR,          | CK_OTP_COUNTER, 945                             |
| 1038                                     | CK OTP FLAGS, 945                               |
| CK_EC_KDF_TYPE, 1038                     | CK_OTP_FORMAT_ALPHANUMERIC, 945                 |
| CK ECDH1 DERIVE PARAMS, 1038             | CK OTP FORMAT BINARY, 945                       |
| CK_ECDH1_DERIVE_PARAMS_PTR, 1038         | CK_OTP_FORMAT_DECIMAL, 945                      |
| CK ECDH2 DERIVE PARAMS, 1039             | CK_OTP_FORMAT_HEXADECIMAL, 945                  |
| CK ECDH2 DERIVE PARAMS PTR, 1039         | CK OTP OUTPUT FORMAT, 945                       |
| CK ECDH AES KEY WRAP PARAMS, 1039        | CK OTP OUTPUT LENGTH, 946                       |
| CK_ECDH_AES_KEY_WRAP_PARAMS_PTR,         | CK_OTP_COTFOT_LENGTH, 940<br>CK_OTP_PARAM, 1044 |
| 1039                                     |                                                 |
|                                          | CK_OTP_PARAM_IGNORED, 946                       |
| CK_ECMQV_DERIVE_PARAMS, 1039             | CK_OTP_PARAM_MANDATORY, 946                     |
| CK_ECMQV_DERIVE_PARAMS_PTR, 1039         | CK_OTP_PARAM_OPTIONAL, 946                      |
| CK_EFFECTIVELY_INFINITE, 944             | CK_OTP_PARAM_PTR, 1044                          |
| CK_EXTRACT_PARAMS, 1039                  | CK_OTP_PARAM_TYPE, 1044                         |
| CK_EXTRACT_PARAMS_PTR, 1039              | CK_OTP_PARAMS, 1045                             |
| CK_FALSE, 944                            | CK_OTP_PARAMS_PTR, 1045                         |
| CK_FLAGS, 1040                           | CK_OTP_PIN, 946                                 |
| CK_FUNCTION_LIST, 1040                   | CK_OTP_SIGNATURE_INFO, 1045                     |

| CK_OTP_SIGNATURE_INFO_PTR, 1045             | CK_SKIPJACK_PRIVATE_WRAP_PARAMS_PTR,                   |
|---------------------------------------------|--------------------------------------------------------|
| CK_OTP_TIME, 946                            | 1050                                                   |
| CK_OTP_VALUE, 946                           | CK_SKIPJACK_RELAYX_PARAMS, 1050                        |
| CK_PARAM_TYPE, 1045                         | CK_SKIPJACK_RELAYX_PARAMS_PTR, 1050                    |
| CK PBE PARAMS, 1045                         | CK_SLOT_ID, 1051                                       |
| CK PBE PARAMS PTR, 1045                     | CK_SLOT_ID_PTR, 1051                                   |
| CK_PKCS5_PBKD2_PARAMS, 1045                 | CK_SLOT_INFO, 1051                                     |
| CK_PKCS5_PBKD2_PARAMS2, 1046                | CK_SLOT_INFO_PTR, 1051                                 |
| CK_PKCS5_PBKD2_PARAMS2_PTR, 1046            | CK_SSL3_KEY_MAT_OUT, 1051                              |
| CK_PKCS5_PBKD2_PARAMS_PTR, 1046             | CK_SSL3_KEY_MAT_OUT_PTR, 1051                          |
| CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_      |                                                        |
| 1046                                        | CK_SSL3_KEY_MAT_PARAMS_PTR, 1051                       |
| CK_PKCS5_PBKD2_PSEUDO_RANDOM_FUNCTION_ 1046 | TÇKESSHA, MASTER_KEY_DERIVE_PARAMS,<br>1052            |
| CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE,           | CK_SSL3_MASTER_KEY_DERIVE_PARAMS_PTR,                  |
| 1046                                        | 1052                                                   |
| CK_PKCS5_PBKDF2_SALT_SOURCE_TYPE_PTR,       | CK_SSL3_RANDOM_DATA, 1052<br>CK_STATE, 1052            |
| 1046                                        | CK_TLS12_KEY_MAT_PARAMS, 1052                          |
| CK_RC2_CBC_PARAMS, 1046                     | CK_TLS12_KEY_MAT_PARAMS_PTR, 1052                      |
| CK_RC2_CBC_PARAMS_PTR, 1047                 | CK_TLS12_MASTER_KEY_DERIVE_PARAMS,                     |
| CK_RC2_MAC_GENERAL_PARAMS, 1047             | 1052                                                   |
| CK_RC2_MAC_GENERAL_PARAMS_PTR, 1047         | CK_TLS12_MASTER_KEY_DERIVE_PARAMS_PTR,                 |
| CK_RC2_PARAMS, 1047                         | 1052                                                   |
| CK_RC2_PARAMS_PTR, 1047                     | CK_TLS_KDF_PARAMS, 1053                                |
| CK_RC5_CBC_PARAMS, 1047                     | CK_TLS_KDF_PARAMS_PTR, 1053                            |
| CK_RC5_CBC_PARAMS_PTR, 1047                 | CK_TLS_MAC_PARAMS, 1053                                |
| CK_RC5_MAC_GENERAL_PARAMS, 1047             | CK_TLS_MAC_PARAMS_PTR, 1053                            |
| CK_RC5_MAC_GENERAL_PARAMS_PTR, 1048         | CK_TLS_PRF_PARAMS, 1053                                |
| CK_RC5_PARAMS, 1048                         | CK_TLS_PRF_PARAMS_PTR, 1053                            |
| CK_RC5_PARAMS_PTR, 1048                     | CK_TOKEN_INFO, 1053                                    |
| CK_RSA_AES_KEY_WRAP_PARAMS, 1048            | CK_TOKEN_INFO_PTR, 1053                                |
| CK_RSA_AES_KEY_WRAP_PARAMS_PTR,             | CK TRUE, 947                                           |
| 1048                                        | CK_ULONG, 1054                                         |
| CK_RSA_PKCS_MGF_TYPE, 1048                  | CK_ULONG_PTR, 1054                                     |
| CK_RSA_PKCS_MGF_TYPE_PTR, 1048              | CK_UNAVAILABLE_INFORMATION, 947                        |
| CK_RSA_PKCS_OAEP_PARAMS, 1048               | CK_USER_TYPE, 1054                                     |
| CK_RSA_PKCS_OAEP_PARAMS_PTR, 1049           | CK UTF8CHAR, 1054                                      |
| CK_RSA_PKCS_OAEP_SOURCE_TYPE, 1049          | CK UTF8CHAR PTR, 1054                                  |
| CK_RSA_PKCS_OAEP_SOURCE_TYPE_PTR,           | CK_VERSION, 1054                                       |
| 1049                                        | CK VERSION PTR, 1054                                   |
| CK_RSA_PKCS_PSS_PARAMS, 1049                | CK VOID PTR, 1054                                      |
| CK_RSA_PKCS_PSS_PARAMS_PTR, 1049            | CK_VOID_PTR_PTR, 1055                                  |
| CK_RV, 1049                                 | CK WTLS KEY MAT OUT, 1055                              |
| CK_SECURITY_DOMAIN_MANUFACTURER,            | CK_WTLS_KEY_MAT_OUT_PTR, 1055                          |
| 946                                         | CK WTLS KEY MAT PARAMS, 1055                           |
| CK_SECURITY_DOMAIN_OPERATOR, 947            | CK WTLS KEY MAT PARAMS PTR, 1055                       |
| CK_SECURITY_DOMAIN_THIRD_PARTY, 947         | CK WTLS MASTER KEY DERIVE PARAMS,                      |
| CK_SECURITY_DOMAIN_UNSPECIFIED, 947         | 1055                                                   |
| CK_SEED_CBC_ENCRYPT_DATA_PARAMS, 1049       | CK_WTLS_MASTER_KEY_DERIVE_PARAMS_PTR, 1055             |
| CK_SEED_CBC_ENCRYPT_DATA_PARAMS_PTR,        | CK_WTLS_PRF_PARAMS, 1055                               |
| 1049                                        | CK_WTLS_PRF_PARAMS_PTR, 1056                           |
| CK_SESSION_HANDLE, 1050                     | CK_WTLS_PRF_PARAMS_FTR, 1056 CK_WTLS_RANDOM_DATA, 1056 |
| CK_SESSION_HANDLE_PTR, 1050                 | CK_WTLS_RANDOM_DATA_PTR, 1056                          |
| CK_SESSION_INFO, 1050                       | CK_X9_42_DH1_DERIVE_PARAMS, 1056                       |
| CK_SESSION_INFO_PTR, 1050                   | CK_X9_42_DH1_DERIVE_PARAMS_PTR, 1056                   |
| CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 1050       | CK X9 42 DH2 DERIVE PARAMS 1056                        |

| CK_X9_42_DH2_DERIVE_PARAMS_PTR, 1056                         | CKA_NEVER_EXTRACTABLE, 954         |
|--------------------------------------------------------------|------------------------------------|
|                                                              | CKA_OBJECT_ID, 954                 |
| CK_X9_42_DH_KDF_TYPE, 1056                                   |                                    |
| CK_X9_42_DH_KDF_TYPE_PTR, 1057                               | CKA_OTP_CHALLENGE_REQUIREMENT, 954 |
| CK_X9_42_MQV_DERIVE_PARAMS, 1057                             | CKA_OTP_COUNTER, 954               |
| CK_X9_42_MQV_DERIVE_PARAMS_PTR, 1057                         | CKA_OTP_COUNTER_REQUIREMENT, 954   |
| CKA_AC_ISSUER, 947                                           | CKA_OTP_FORMAT, 954                |
| CKA_ALLOWED_MECHANISMS, 947                                  | CKA_OTP_LENGTH, 955                |
| CKA_ALWAYS_AUTHENTICATE, 947                                 | CKA_OTP_PIN_REQUIREMENT, 955       |
| CKA_ALWAYS_SENSITIVE, 948                                    | CKA_OTP_SERVICE_IDENTIFIER, 955    |
| CKA_APPLICATION, 948                                         | CKA_OTP_SERVICE_LOGO, 955          |
| CKA_ATTR_TYPES, 948                                          | CKA_OTP_SERVICE_LOGO_TYPE, 955     |
| CKA_AUTH_PIN_FLAGS, 948                                      | CKA_OTP_TIME, 955                  |
| CKA_BASE, 948                                                | CKA_OTP_TIME_INTERVAL, 955         |
| CKA_BITS_PER_PIXEL, 948                                      | CKA_OTP_TIME_REQUIREMENT, 955      |
| CKA_CERTIFICATE_CATEGORY, 948                                | CKA_OTP_USER_FRIENDLY_MODE, 956    |
| CKA_CERTIFICATE_TYPE, 948                                    | CKA_OTP_USER_IDENTIFIER, 956       |
| CKA_CHAR_COLUMNS, 949                                        | CKA_OWNER, 956                     |
| CKA CHAR ROWS, 949                                           | CKA PIXEL X, 956                   |
| CKA_CHAR_SETS, 949                                           | CKA PIXEL Y, 956                   |
| CKA_CHECK_VALUE, 949                                         | CKA PRIME, 956                     |
| CKA CLASS, 949                                               | CKA_PRIME_1, 956                   |
| CKA COEFFICIENT, 949                                         | CKA_PRIME_2, 956                   |
| CKA_COLOR, 949                                               | CKA_PRIME_BITS, 957                |
| CKA_COPYABLE, 949                                            | CKA PRIVATE, 957                   |
| CKA_DECRYPT, 950                                             | CKA_PRIVATE_EXPONENT, 957          |
| CKA_DEFAULT_CMS_ATTRIBUTES, 950                              | CKA_PUBLIC_EXPONENT, 957           |
| CKA DERIVE, 950                                              | CKA PUBLIC KEY INFO, 957           |
| CKA_DERIVE_TEMPLATE, 950                                     | CKA_REQUIRED_CMS_ATTRIBUTES, 957   |
| CKA_DESTROYABLE, 950                                         | CKA_RESET_ON_INIT, 957             |
| CKA_EC_PARAMS, 950                                           | CKA_RESOLUTION, 957                |
| CKA_EC_POINT, 950                                            | CKA_SECONDARY_AUTH, 958            |
| CKA_ECDSA_PARAMS, 950                                        | CKA_SENSITIVE, 958                 |
| CKA_ENCODING_METHODS, 951                                    | CKA_SERIAL_NUMBER, 958             |
| CKA ENCRYPT, 951                                             | CKA SIGN, 958                      |
| CKA_END_DATE, 951                                            | CKA_SIGN_RECOVER, 958              |
| CKA_EXPONENT_1, 951                                          | CKA_START_DATE, 958                |
| CKA_EXPONENT_2, 951                                          | CKA_SUB_PRIME_BITS, 958            |
| CKA_EXTRACTABLE, 951                                         | CKA_SUBJECT, 958                   |
| CKA_GOST28147_PARAMS, 951                                    | CKA_SUBPRIME, 959                  |
| CKA_GOSTR3410_PARAMS, 951                                    | CKA_SUBPRIME_BITS, 959             |
| CKA GOSTR3411 PARAMS, 952                                    | CKA SUPPORTED CMS ATTRIBUTES, 959  |
| CKA_HAS_RESET, 952                                           | CKA_TOKEN, 959                     |
| CKA_HASH_OF_ISSUER_PUBLIC_KEY, 952                           | CKA_TRUSTED, 959                   |
| CKA_HASH_OF_SUBJECT_PUBLIC_KEY, 952                          | CKA_UNWRAP, 959                    |
| CKA HW FEATURE TYPE, 952                                     | CKA_UNWRAP_TEMPLATE, 959           |
| CKA ID, 952                                                  | CKA_URL, 959                       |
| CKA_ISSUER, 952                                              | CKA_VALUE, 960                     |
| CKA_ISSUEN, 952 CKA_JAVA_MIDP_SECURITY_DOMAIN, 952           | CKA_VALUE_BITS, 960                |
| CKA_SAVA_MIDF_SECONTT_DOMAIN, 952 CKA_KEY_GEN_MECHANISM, 953 | CKA_VALUE_LEN, 960                 |
|                                                              |                                    |
| CKA_KEY_TYPE, 953                                            | CKA_VENIEV_060                     |
| CKA_LABEL, 953                                               | CKA_VERIEY_BECOVER_060             |
| CKA_LOCAL, 953                                               | CKA_VERIFY_RECOVER, 960            |
| CKA_MECHANISM_TYPE, 953                                      | CKA_WRAP, 960                      |
| CKA_MIME_TYPES, 953                                          | CKA_WRAP_TEMPLATE, 960             |
| CKA_MODIFIABLE, 953                                          | CKA_WRAP_WITH_TRUSTED, 961         |
| CKA_MODULUS, 953                                             | CKC_OPENPGP, 961                   |
| CKA_MODULUS_BITS, 954                                        | CKC_VENDOR_DEFINED, 961            |
| CKA_NAME_HASH_ALGORITHM, 954                                 | CKC_WTLS, 961                      |

| CKC_X_509, 961                      | CKF_USER_PIN_COUNT_LOW, 968     |
|-------------------------------------|---------------------------------|
| CKC_X_509_ATTR_CERT, 961            | CKF_USER_PIN_FINAL_TRY, 968     |
| CKD_CPDIVERSIFY_KDF, 961            | CKF_USER_PIN_INITIALIZED, 968   |
| CKD_NULL, 961                       | CKF_USER_PIN_LOCKED, 968        |
| CKD_SHA1_KDF, 962                   | CKF USER PIN TO BE CHANGED, 969 |
| CKD_SHA1_KDF_ASN1, 962              | CKF_VERIFY, 969                 |
| CKD_SHA1_KDF_CONCATENATE, 962       | CKF_VERIFY_RECOVER, 969         |
| CKD_SHA224_KDF, 962                 | CKF_WRAP, 969                   |
|                                     |                                 |
| CKD_SHA256_KDF, 962                 | CKF_WRITE_PROTECTED, 969        |
| CKD_SHA384_KDF, 962                 | CKG_MGF1_SHA1, 969              |
| CKD_SHA512_KDF, 962                 | CKG_MGF1_SHA224, 969            |
| CKF_ARRAY_ATTRIBUTE, 962            | CKG_MGF1_SHA256, 969            |
| CKF_CLOCK_ON_TOKEN, 963             | CKG_MGF1_SHA384, 970            |
| CKF_DECRYPT, 963                    | CKG_MGF1_SHA512, 970            |
| CKF_DERIVE, 963                     | CKH_CLOCK, 970                  |
| CKF_DIGEST, 963                     | CKH_MONOTONIC_COUNTER, 970      |
| CKF_DONT_BLOCK, 963                 | CKH_USER_INTERFACE, 970         |
| CKF_DUAL_CRYPTO_OPERATIONS, 963     | CKH_VENDOR_DEFINED, 970         |
| CKF_EC_COMPRESS, 963                | CKK_ACTI, 970                   |
|                                     |                                 |
| CKF_EC_ECPARAMETERS, 963            | CKK_AES, 970                    |
| CKF_EC_F_2M, 964                    | CKK_ARIA, 971                   |
| CKF_EC_F_P, 964                     | CKK_BATON, 971                  |
| CKF_EC_NAMEDCURVE, 964              | CKK_BLOWFISH, 971               |
| CKF_EC_UNCOMPRESS, 964              | CKK_CAMELLIA, 971               |
| CKF_ENCRYPT, 964                    | CKK_CAST, 971                   |
| CKF ERROR STATE, 964                | CKK_CAST128, 971                |
| CKF_EXCLUDE_CHALLENGE, 964          | CKK CAST3, 971                  |
| CKF_EXCLUDE_COUNTER, 964            | CKK_CAST5, 971                  |
| CKF_EXCLUDE_PIN, 965                | CKK_CDMF, 972                   |
| CKF_EXCLUDE_TIME, 965               | CKK_DES, 972                    |
|                                     | CKK_DES2, 972                   |
| CKF_EXTENSION, 965                  |                                 |
| CKF_GENERATE, 965                   | CKK_DES3, 972                   |
| CKF_GENERATE_KEY_PAIR, 965          | CKK_DH, 972                     |
| CKF_HW, 965                         | CKK_DSA, 972                    |
| CKF_HW_SLOT, 965                    | CKK_EC, 972                     |
| CKF_LIBRARY_CANT_CREATE_OS_THREADS, | CKK_ECDSA, 972                  |
| 965                                 | CKK_GENERIC_SECRET, 973         |
| CKF_LOGIN_REQUIRED, 966             | CKK_GOST28147, 973              |
| CKF_NEXT_OTP, 966                   | CKK_GOSTR3410, 973              |
| CKF OS LOCKING OK, 966              | CKK_GOSTR3411, 973              |
| CKF_PROTECTED_AUTHENTICATION_PATH,  | CKK_HOTP, 973                   |
| 966                                 | CKK_IDEA, 973                   |
| CKF_REMOVABLE_DEVICE, 966           | CKK JUNIPER, 973                |
| CKF_RESTORE_KEY_NOT_NEEDED, 966     | CKK_KEA, 973                    |
| CKF RNG, 966                        | CKK MD5 HMAC, 974               |
| _ :                                 |                                 |
| CKF_RW_SESSION, 966                 | CKK_RC2, 974                    |
| CKF_SECONDARY_AUTHENTICATION, 967   | CKK_RC4, 974                    |
| CKF_SERIAL_SESSION, 967             | CKK_RC5, 974                    |
| CKF_SIGN, 967                       | CKK_RIPEMD128_HMAC, 974         |
| CKF_SIGN_RECOVER, 967               | CKK_RIPEMD160_HMAC, 974         |
| CKF_SO_PIN_COUNT_LOW, 967           | CKK_RSA, 974                    |
| CKF_SO_PIN_FINAL_TRY, 967           | CKK_SECURID, 974                |
| CKF_SO_PIN_LOCKED, 967              | CKK_SEED, 975                   |
| CKF SO PIN TO BE CHANGED, 967       | CKK_SHA224_HMAC, 975            |
| CKF TOKEN INITIALIZED, 968          | CKK_SHA256_HMAC, 975            |
| CKF_TOKEN_PRESENT, 968              | CKK_SHA384_HMAC, 975            |
| CKF UNWRAP, 968                     | CKK SHA512 HMAC, 975            |
| <del>-</del>                        | <del>-</del>                    |
| CKF_USER_FRIENDLY_OTP, 968          | CKK_SHA_1_HMAC, 975             |

| CKK_SKIPJACK, 975                  | CKM_CAST128_CBC_PAD, 983           |
|------------------------------------|------------------------------------|
| CKK_TWOFISH, 975                   | CKM_CAST128_ECB, 983               |
| CKK_VENDOR_DEFINED, 976            | CKM_CAST128_KEY_GEN, 983           |
| CKK_X9_42_DH, 976                  | CKM CAST128 MAC, 983               |
| CKM_ACTI, 976                      | CKM CAST128 MAC GENERAL, 983       |
| CKM_ACTI_KEY_GEN, 976              | CKM CAST3 CBC, 983                 |
| CKM_AES_CBC, 976                   | CKM_CAST3_CBC_PAD, 983             |
| CKM_AES_CBC_ENCRYPT_DATA, 976      | CKM_CAST3_ECB, 983                 |
| CKM_AES_CBC_PAD, 976               | CKM CAST3 KEY GEN, 984             |
|                                    | :                                  |
| CKM_AES_CCM, 976                   | CKM_CAST3_MAC, 984                 |
| CKM_AES_CFB1, 977                  | CKM_CAST3_MAC_GENERAL, 984         |
| CKM_AES_CFB128, 977                | CKM_CAST5_CBC, 984                 |
| CKM_AES_CFB64, 977                 | CKM_CAST5_CBC_PAD, 984             |
| CKM_AES_CFB8, 977                  | CKM_CAST5_ECB, 984                 |
| CKM_AES_CMAC, 977                  | CKM_CAST5_KEY_GEN, 984             |
| CKM_AES_CMAC_GENERAL, 977          | CKM_CAST5_MAC, 984                 |
| CKM_AES_CTR, 977                   | CKM_CAST5_MAC_GENERAL, 985         |
| CKM_AES_CTS, 977                   | CKM_CAST_CBC, 985                  |
| CKM_AES_ECB, 978                   | CKM_CAST_CBC_PAD, 985              |
| CKM_AES_ECB_ENCRYPT_DATA, 978      | CKM_CAST_ECB, 985                  |
| CKM AES GCM, 978                   | CKM_CAST_KEY_GEN, 985              |
| CKM_AES_GMAC, 978                  | CKM_CAST_MAC, 985                  |
| CKM_AES_KEY_GEN, 978               | CKM_CAST_MAC_GENERAL, 985          |
| CKM AES KEY WRAP, 978              | CKM CDMF CBC, 985                  |
| CKM_AES_KEY_WRAP_PAD, 978          | CKM_CDMF_CBC_PAD, 986              |
| CKM_AES_MAC, 978                   | CKM_CDMF_ECB, 986                  |
|                                    |                                    |
| CKM_AES_MAC_GENERAL, 979           | CKM_CDMF_KEY_GEN, 986              |
| CKM_AES_OFB, 979                   | CKM_CDMF_MAC, 986                  |
| CKM_AES_XCBC_MAC, 979              | CKM_CDMF_MAC_GENERAL, 986          |
| CKM_AES_XCBC_MAC_96, 979           | CKM_CMS_SIG, 986                   |
| CKM_ARIA_CBC, 979                  | CKM_CONCATENATE_BASE_AND_DATA, 986 |
| CKM_ARIA_CBC_ENCRYPT_DATA, 979     | CKM_CONCATENATE_BASE_AND_KEY, 986  |
| CKM_ARIA_CBC_PAD, 979              | CKM_CONCATENATE_DATA_AND_BASE, 987 |
| CKM_ARIA_ECB, 979                  | CKM_DES2_KEY_GEN, 987              |
| CKM_ARIA_ECB_ENCRYPT_DATA, 980     | CKM_DES3_CBC, 987                  |
| CKM_ARIA_KEY_GEN, 980              | CKM_DES3_CBC_ENCRYPT_DATA, 987     |
| CKM_ARIA_MAC, 980                  | CKM_DES3_CBC_PAD, 987              |
| CKM_ARIA_MAC_GENERAL, 980          | CKM_DES3_CMAC, 987                 |
| CKM_BATON_CBC128, 980              | CKM_DES3_CMAC_GENERAL, 987         |
| CKM_BATON_COUNTER, 980             | CKM_DES3_ECB, 987                  |
| CKM BATON ECB128, 980              | CKM_DES3_ECB_ENCRYPT_DATA, 988     |
| CKM_BATON_ECB96, 980               | CKM_DES3_KEY_GEN, 988              |
| CKM BATON KEY GEN, 981             | CKM_DES3_MAC, 988                  |
| CKM_BATON_SHUFFLE, 981             | CKM_DES3_MAC_GENERAL, 988          |
| CKM BATON WRAP, 981                | CKM DES CBC, 988                   |
| CKM BLOWFISH CBC, 981              | CKM DES CBC ENCRYPT DATA, 988      |
|                                    |                                    |
| CKM_BLOWFISH_CBC_PAD, 981          | CKM_DES_CBC_PAD, 988               |
| CKM_BLOWFISH_KEY_GEN, 981          | CKM_DES_CFB64, 988                 |
| CKM_CAMELLIA_CBC, 981              | CKM_DES_CFB8, 989                  |
| CKM_CAMELLIA_CBC_ENCRYPT_DATA, 981 | CKM_DES_ECB, 989                   |
| CKM_CAMELLIA_CBC_PAD, 982          | CKM_DES_ECB_ENCRYPT_DATA, 989      |
| CKM_CAMELLIA_CTR, 982              | CKM_DES_KEY_GEN, 989               |
| CKM_CAMELLIA_ECB, 982              | CKM_DES_MAC, 989                   |
| CKM_CAMELLIA_ECB_ENCRYPT_DATA, 982 | CKM_DES_MAC_GENERAL, 989           |
| CKM_CAMELLIA_KEY_GEN, 982          | CKM_DES_OFB64, 989                 |
| CKM_CAMELLIA_MAC, 982              | CKM_DES_OFB8, 989                  |
| CKM CAMELLIA MAC GENERAL, 982      | CKM DH PKCS DERIVE, 990            |
| CKM_CAST128_CBC, 982               | CKM_DH_PKCS_KEY_PAIR_GEN, 990      |
| ,                                  |                                    |

| CKM_DH_PKCS_PARAMETER_GEN, 990      | CKM_KEY_WRAP_LYNKS, 997          |
|-------------------------------------|----------------------------------|
| CKM_DSA, 990                        | CKM_KEY_WRAP_SET_OAEP, 997       |
| CKM_DSA_KEY_PAIR_GEN, 990           | CKM_KIP_DERIVE, 997              |
| CKM_DSA_PARAMETER_GEN, 990          | CKM_KIP_MAC, 997                 |
| CKM_DSA_PROBABLISTIC_PARAMETER_GEN, | CKM_KIP_WRAP, 997                |
| 990                                 | CKM_MD2, 997                     |
| CKM_DSA_SHA1, 990                   | CKM_MD2_HMAC, 998                |
| CKM_DSA_SHA224, 991                 | CKM_MD2_HMAC_GENERAL, 998        |
| CKM_DSA_SHA256, 991                 | CKM_MD2_KEY_DERIVATION, 998      |
| CKM_DSA_SHA384, 991                 | CKM_MD2_RSA_PKCS, 998            |
| CKM_DSA_SHA512, 991                 | CKM_MD5, 998                     |
| CKM_DSA_SHAWE_TAYLOR_PARAMETER_GEN, | CKM_MD5_HMAC, 998                |
| 991                                 | CKM_MD5_HMAC_GENERAL, 998        |
| CKM_EC_KEY_PAIR_GEN, 991            | CKM_MD5_KEY_DERIVATION, 998      |
| CKM_ECDH1_COFACTOR_DERIVE, 991      | CKM_MD5_RSA_PKCS, 999            |
| CKM_ECDH1_DERIVE, 991               | CKM_PBA_SHA1_WITH_SHA1_HMAC, 999 |
| CKM_ECDH_AES_KEY_WRAP, 992          | CKM_PBE_MD2_DES_CBC, 999         |
| CKM_ECDSA, 992                      | CKM_PBE_MD5_CAST128_CBC, 999     |
| CKM_ECDSA_KEY_PAIR_GEN, 992         | CKM_PBE_MD5_CAST3_CBC, 999       |
| CKM_ECDSA_SHA1, 992                 | CKM_PBE_MD5_CAST5_CBC, 999       |
| CKM_ECDSA_SHA224, 992               | CKM_PBE_MD5_CAST_CBC, 999        |
| CKM_ECDSA_SHA256, 992               | CKM_PBE_MD5_DES_CBC, 999         |
| CKM_ECDSA_SHA384, 992               | CKM_PBE_SHA1_CAST128_CBC, 1000   |
| CKM_ECDSA_SHA512, 992               | CKM_PBE_SHA1_CAST5_CBC, 1000     |
| CKM_ECMQV_DERIVE, 993               | CKM_PBE_SHA1_DES2_EDE_CBC, 1000  |
| CKM_EXTRACT_KEY_FROM_KEY, 993       | CKM_PBE_SHA1_DES3_EDE_CBC, 1000  |
| CKM_FASTHASH, 993                   | CKM_PBE_SHA1_RC2_128_CBC, 1000   |
| CKM_FORTEZZA_TIMESTAMP, 993         | CKM_PBE_SHA1_RC2_40_CBC, 1000    |
| CKM_GENERIC_SECRET_KEY_GEN, 993     | CKM_PBE_SHA1_RC4_128, 1000       |
| CKM_GOST28147, 993                  | CKM_PBE_SHA1_RC4_40, 1000        |
| CKM_GOST28147_ECB, 993              | CKM_PKCS5_PBKD2, 1001            |
| CKM_GOST28147_KEY_GEN, 993          | CKM_RC2_CBC, 1001                |
| CKM_GOST28147_KEY_WRAP, 994         | CKM_RC2_CBC_PAD, 1001            |
| CKM_GOST28147_MAC, 994              | CKM_RC2_ECB, 1001                |
| CKM_GOSTR3410, 994                  | CKM_RC2_KEY_GEN, 1001            |
| CKM_GOSTR3410_DERIVE, 994           | CKM_RC2_MAC, 1001                |
| CKM_GOSTR3410_KEY_PAIR_GEN, 994     | CKM_RC2_MAC_GENERAL, 1001        |
| CKM_GOSTR3410_KEY_WRAP, 994         | CKM_RC4, 1001                    |
| CKM_GOSTR3410_WITH_GOSTR3411, 994   | CKM_RC4_KEY_GEN, 1002            |
| CKM_GOSTR3411, 994                  | CKM_RC5_CBC, 1002                |
| CKM_GOSTR3411_HMAC, 995             | CKM_RC5_CBC_PAD, 1002            |
| CKM_HOTP, 995                       | CKM_RC5_ECB, 1002                |
| CKM_HOTP_KEY_GEN, 995               | CKM_RC5_KEY_GEN, 1002            |
| CKM_IDEA_CBC, 995                   | CKM_RC5_MAC, 1002                |
| CKM_IDEA_CBC_PAD, 995               | CKM_RC5_MAC_GENERAL, 1002        |
| CKM_IDEA_ECB, 995                   | CKM_RIPEMD128, 1002              |
| CKM_IDEA_KEY_GEN, 995               | CKM_RIPEMD128_HMAC, 1003         |
| CKM_IDEA_MAC, 995                   | CKM_RIPEMD128_HMAC_GENERAL, 1003 |
| CKM_IDEA_MAC_GENERAL, 996           | CKM_RIPEMD128_RSA_PKCS, 1003     |
| CKM_JUNIPER_CBC128, 996             | CKM_RIPEMD160, 1003              |
| CKM_JUNIPER_COUNTER, 996            | CKM_RIPEMD160_HMAC, 1003         |
| CKM_JUNIPER_ECB128, 996             | CKM_RIPEMD160_HMAC_GENERAL, 1003 |
| CKM_JUNIPER_KEY_GEN, 996            | CKM_RIPEMD160_RSA_PKCS, 1003     |
| CKM_JUNIPER_SHUFFLE, 996            | CKM_RSA_9796, 1003               |
| CKM_JUNIPER_WRAP, 996               | CKM_RSA_AES_KEY_WRAP, 1004       |
| CKM_KEA_DERIVE, 996                 | CKM_RSA_PKCS, 1004               |
| CKM_KEA_KEY_DERIVE, 997             | CKM_RSA_PKCS_KEY_PAIR_GEN, 1004  |
| CKM_KEA_KEY_PAIR_GEN, 997           | CKM_RSA_PKCS_OAEP, 1004          |

| CKM_RSA_PKCS_OAEP_TPM_1_1, 1004     | CKM_SHA_1_HMAC_GENERAL, 1011         |
|-------------------------------------|--------------------------------------|
| CKM_RSA_PKCS_PSS, 1004              | CKM_SKIPJACK_CBC64, 1011             |
| CKM_RSA_PKCS_TPM_1_1, 1004          | CKM_SKIPJACK_CFB16, 1012             |
| CKM_RSA_X9_31, 1004                 | CKM_SKIPJACK_CFB32, 1012             |
| CKM_RSA_X9_31_KEY_PAIR_GEN, 1005    | CKM_SKIPJACK_CFB64, 1012             |
| CKM_RSA_X_509, 1005                 | CKM_SKIPJACK_CFB8, 1012              |
| CKM_SECURID, 1005                   | CKM SKIPJACK ECB64, 1012             |
| CKM_SECURID_KEY_GEN, 1005           | CKM_SKIPJACK_KEY_GEN, 1012           |
| CKM SEED CBC, 1005                  | CKM SKIPJACK OFB64, 1012             |
| CKM_SEED_CBC_ENCRYPT_DATA, 1005     | CKM_SKIPJACK_PRIVATE_WRAP, 1012      |
| CKM SEED CBC PAD, 1005              | CKM SKIPJACK RELAYX, 1013            |
| CKM SEED ECB, 1005                  | CKM SKIPJACK WRAP, 1013              |
| CKM_SEED_ECB_ENCRYPT_DATA, 1006     | CKM SSL3 KEY AND MAC DERIVE, 1013    |
| CKM SEED KEY GEN, 1006              | CKM_SSL3_MASTER_KEY_DERIVE, 1013     |
| CKM SEED MAC, 1006                  | CKM_SSL3_MASTER_KEY_DERIVE_DH, 1013  |
| CKM_SEED_MAC_GENERAL, 1006          | CKM SSL3 MD5 MAC, 1013               |
| CKM SHA1 KEY DERIVATION, 1006       | CKM_SSL3_PRE_MASTER_KEY_GEN, 1013    |
| CKM SHA1 RSA PKCS, 1006             |                                      |
|                                     | CKM_SSL3_SHA1_MAC, 1013              |
| CKM_SHA1_RSA_PKCS_PSS, 1006         | CKM_TLS10_MAC_CLIENT, 1014           |
| CKM_SHA1_RSA_X9_31, 1006            | CKM_TLS10_MAC_SERVER, 1014           |
| CKM_SHA224, 1007                    | CKM_TLS12_KDF, 1014                  |
| CKM_SHA224_HMAC, 1007               | CKM_TLS12_KEY_AND_MAC_DERIVE, 1014   |
| CKM_SHA224_HMAC_GENERAL, 1007       | CKM_TLS12_KEY_SAFE_DERIVE, 1014      |
| CKM_SHA224_KEY_DERIVATION, 1007     | CKM_TLS12_MAC, 1014                  |
| CKM_SHA224_RSA_PKCS, 1007           | CKM_TLS12_MASTER_KEY_DERIVE, 1014    |
| CKM_SHA224_RSA_PKCS_PSS, 1007       | CKM_TLS12_MASTER_KEY_DERIVE_DH, 1014 |
| CKM_SHA256, 1007                    | CKM_TLS_KDF, 1015                    |
| CKM_SHA256_HMAC, 1007               | CKM_TLS_KEY_AND_MAC_DERIVE, 1015     |
| CKM_SHA256_HMAC_GENERAL, 1008       | CKM_TLS_MAC, 1015                    |
| CKM_SHA256_KEY_DERIVATION, 1008     | CKM_TLS_MASTER_KEY_DERIVE, 1015      |
| CKM_SHA256_RSA_PKCS, 1008           | CKM_TLS_MASTER_KEY_DERIVE_DH, 1015   |
| CKM_SHA256_RSA_PKCS_PSS, 1008       | CKM_TLS_PRE_MASTER_KEY_GEN, 1015     |
| CKM_SHA384, 1008                    | CKM_TLS_PRF, 1015                    |
| CKM_SHA384_HMAC, 1008               | CKM_TWOFISH_CBC, 1015                |
| CKM_SHA384_HMAC_GENERAL, 1008       | CKM_TWOFISH_CBC_PAD, 1016            |
| CKM_SHA384_KEY_DERIVATION, 1008     | CKM_TWOFISH_KEY_GEN, 1016            |
| CKM SHA384 RSA PKCS, 1009           | CKM VENDOR DEFINED, 1016             |
| CKM SHA384 RSA PKCS PSS, 1009       | CKM_WTLS_CLIENT_KEY_AND_MAC_DERIVE,  |
| CKM SHA512, 1009                    | 1016                                 |
| CKM SHA512 224, 1009                | CKM_WTLS_MASTER_KEY_DERIVE, 1016     |
| CKM_SHA512_224_HMAC, 1009           | CKM_WTLS_MASTER_KEY_DERIVE_DH_ECC,   |
| CKM_SHA512_224_HMAC_GENERAL, 1009   | 1016                                 |
| CKM_SHA512_224_KEY_DERIVATION, 1009 | CKM_WTLS_PRE_MASTER_KEY_GEN, 1016    |
| CKM_SHA512_256, 1009                | CKM_WTLS_PRF, 1016                   |
| CKM SHA512 256 HMAC, 1010           | CKM WTLS SERVER KEY AND MAC DERIVE,  |
| CKM_SHA512_256_HMAC_GENERAL, 1010   | 1017                                 |
| CKM SHA512 256 KEY DERIVATION, 1010 | CKM X9 42 DH DERIVE, 1017            |
|                                     |                                      |
| CKM_SHA512_HMAC, 1010               | CKM_X9_42_DH_HYBRID_DERIVE, 1017     |
| CKM_SHA512_HMAC_GENERAL, 1010       | CKM_X9_42_DH_KEY_PAIR_GEN, 1017      |
| CKM_SHA512_KEY_DERIVATION, 1010     | CKM_X9_42_DH_PARAMETER_GEN, 1017     |
| CKM_SHA512_RSA_PKCS, 1010           | CKM_X9_42_MQV_DERIVE, 1017           |
| CKM_SHA512_RSA_PKCS_PSS, 1010       | CKM_XOR_BASE_AND_DATA, 1017          |
| CKM_SHA512_T, 1011                  | CKN_OTP_CHANGED, 1017                |
| CKM_SHA512_T_HMAC, 1011             | CKN_SURRENDER, 1018                  |
| CKM_SHA512_T_HMAC_GENERAL, 1011     | CKO_CERTIFICATE, 1018                |
| CKM_SHA512_T_KEY_DERIVATION, 1011   | CKO_DATA, 1018                       |
| CKM_SHA_1, 1011                     | CKO_DOMAIN_PARAMETERS, 1018          |
| CKM SHA 1 HMAC, 1011                | CKO HW FEATURE, 1018                 |

| CKO_MECHANISM, 1018                    | CKR_MUTEX_NOT_LOCKED, 1025            |
|----------------------------------------|---------------------------------------|
| CKO_OTP_KEY, 1018                      | CKR_NEED_TO_CREATE_THREADS, 1026      |
| CKO PRIVATE KEY, 1018                  | CKR_NEW_PIN_MODE, 1026                |
| CKO_PUBLIC_KEY, 1019                   | CKR_NEXT_OTP, 1026                    |
| CKO_SECRET_KEY, 1019                   | CKR_NO_EVENT, 1026                    |
| CKO_VENDOR_DEFINED, 1019               | CKR_OBJECT_HANDLE_INVALID, 1026       |
|                                        |                                       |
| CKP_PKCS5_PBKD2_HMAC_GOSTR3411, 1019   | CKR_OK, 1026                          |
| CKP_PKCS5_PBKD2_HMAC_SHA1, 1019        | CKR_OPERATION_ACTIVE, 1026            |
| CKP_PKCS5_PBKD2_HMAC_SHA224, 1019      | CKR_OPERATION_NOT_INITIALIZED, 1026   |
| CKP_PKCS5_PBKD2_HMAC_SHA256, 1019      | CKR_PIN_EXPIRED, 1027                 |
| CKP_PKCS5_PBKD2_HMAC_SHA384, 1019      | CKR_PIN_INCORRECT, 1027               |
| CKP_PKCS5_PBKD2_HMAC_SHA512, 1020      | CKR_PIN_INVALID, 1027                 |
| CKP_PKCS5_PBKD2_HMAC_SHA512_224, 1020  | CKR_PIN_LEN_RANGE, 1027               |
| CKP_PKCS5_PBKD2_HMAC_SHA512_256, 1020  | CKR_PIN_LOCKED, 1027                  |
| CKR_ACTION_PROHIBITED, 1020            | CKR_PIN_TOO_WEAK, 1027                |
| CKR_ARGUMENTS_BAD, 1020                | CKR_PUBLIC_KEY_INVALID, 1027          |
| CKR_ATTRIBUTE_READ_ONLY, 1020          | CKR_RANDOM_NO_RNG, 1027               |
| CKR_ATTRIBUTE_SENSITIVE, 1020          | CKR_RANDOM_SEED_NOT_SUPPORTED, 1028   |
| CKR_ATTRIBUTE_TYPE_INVALID, 1020       | CKR_SAVED_STATE_INVALID, 1028         |
| CKR_ATTRIBUTE_VALUE_INVALID, 1021      | CKR_SESSION_CLOSED, 1028              |
| CKR_BUFFER_TOO_SMALL, 1021             | CKR SESSION COUNT, 1028               |
| CKR CANCEL, 1021                       | CKR_SESSION_EXISTS, 1028              |
| CKR_CANT_LOCK, 1021                    | CKR_SESSION_HANDLE_INVALID, 1028      |
|                                        |                                       |
| CKR_CRYPTOKI_ALREADY_INITIALIZED, 1021 | CKR_SESSION_PARALLEL_NOT_SUPPORTED,   |
| CKR_CRYPTOKI_NOT_INITIALIZED, 1021     | 1028                                  |
| CKR_CURVE_NOT_SUPPORTED, 1021          | CKR_SESSION_READ_ONLY, 1028           |
| CKR_DATA_INVALID, 1021                 | CKR_SESSION_READ_ONLY_EXISTS, 1029    |
| CKR_DATA_LEN_RANGE, 1022               | CKR_SESSION_READ_WRITE_SO_EXISTS,     |
| CKR_DEVICE_ERROR, 1022                 | 1029                                  |
| CKR_DEVICE_MEMORY, 1022                | CKR_SIGNATURE_INVALID, 1029           |
| CKR_DEVICE_REMOVED, 1022               | CKR_SIGNATURE_LEN_RANGE, 1029         |
| CKR_DOMAIN_PARAMS_INVALID, 1022        | CKR_SLOT_ID_INVALID, 1029             |
| CKR_ENCRYPTED_DATA_INVALID, 1022       | CKR_STATE_UNSAVEABLE, 1029            |
| CKR_ENCRYPTED_DATA_LEN_RANGE, 1022     | CKR_TEMPLATE_INCOMPLETE, 1029         |
| CKR_EXCEEDED_MAX_ITERATIONS, 1022      | CKR_TEMPLATE_INCONSISTENT, 1029       |
| CKR_FIPS_SELF_TEST_FAILED, 1023        | CKR_TOKEN_NOT_PRESENT, 1030           |
| CKR_FUNCTION_CANCELED, 1023            | CKR_TOKEN_NOT_RECOGNIZED, 1030        |
| CKR_FUNCTION_FAILED, 1023              | CKR_TOKEN_WRITE_PROTECTED, 1030       |
| CKR_FUNCTION_NOT_PARALLEL, 1023        | CKR_UNWRAPPING_KEY_HANDLE_INVALID,    |
| CKR_FUNCTION_NOT_SUPPORTED, 1023       | 1030                                  |
| CKR FUNCTION REJECTED, 1023            | CKR_UNWRAPPING_KEY_SIZE_RANGE, 1030   |
| CKR_GENERAL_ERROR, 1023                | CKR UNWRAPPING KEY TYPE INCONSISTENT  |
| CKR_HOST_MEMORY, 1023                  | 1030                                  |
| CKR INFORMATION SENSITIVE, 1024        | CKR_USER_ALREADY_LOGGED_IN, 1030      |
| CKR_KEY_CHANGED, 1024                  | CKR USER ANOTHER ALREADY LOGGED IN,   |
| CKR_KEY_FUNCTION_NOT_PERMITTED, 1024   | 1030                                  |
| CKR_KEY_HANDLE_INVALID, 1024           | CKR_USER_NOT_LOGGED_IN, 1031          |
| CKR_KEY_INDIGESTIBLE, 1024             | CKR_USER_PIN_NOT_INITIALIZED, 1031    |
|                                        |                                       |
| CKR_KEY_NEEDED, 1024                   | CKR_USER_TOO_MANY_TYPES, 1031         |
| CKR_KEY_NOT_NEEDED, 1024               | CKR_USER_TYPE_INVALID, 1031           |
| CKR_KEY_NOT_WRAPPABLE, 1024            | CKR_VENDOR_DEFINED, 1031              |
| CKR_KEY_SIZE_RANGE, 1025               | CKR_WRAPPED_KEY_INVALID, 1031         |
| CKR_KEY_TYPE_INCONSISTENT, 1025        | CKR_WRAPPED_KEY_LEN_RANGE, 1031       |
| CKR_KEY_UNEXTRACTABLE, 1025            | CKR_WRAPPING_KEY_HANDLE_INVALID, 1031 |
| CKR_LIBRARY_LOAD_FAILED, 1025          | CKR_WRAPPING_KEY_SIZE_RANGE, 1032     |
| CKR_MECHANISM_INVALID, 1025            | CKR_WRAPPING_KEY_TYPE_INCONSISTENT,   |
| CKR_MECHANISM_PARAM_INVALID, 1025      | 1032                                  |
| CKR_MUTEX_BAD, 1025                    | CKS_RO_PUBLIC_SESSION, 1032           |

| CKS RO USER FUNCTIONS, 1032             | CK_PBE_PARAMS, 490                   |
|-----------------------------------------|--------------------------------------|
| CKS_RW_PUBLIC_SESSION, 1032             | CK_PKCS5_PBKD2_PARAMS, 491           |
| CKS_RW_SO_FUNCTIONS, 1032               | CK_PKCS5_PBKD2_PARAMS2, 492          |
| CKS_RW_USER_FUNCTIONS, 1032             | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501 |
| CKU_CONTEXT_SPECIFIC, 1032              | pPrfData                             |
| CKU_SO, 1033                            | CK_PKCS5_PBKD2_PARAMS, 491           |
| CKU_USER, 1033                          | CK_PKCS5_PBKD2_PARAMS2, 492          |
| CKZ_DATA_SPECIFIED, 1033                | pPrimeP                              |
| CKZ_SALT_SPECIFIED, 1033                | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501 |
| CRYPTOKI_VERSION_AMENDMENT, 1033        | pPublicData                          |
| CRYPTOKI_VERSION_MAJOR, 1033            | CK ECDH1 DERIVE PARAMS, 473          |
| CRYPTOKI_VERSION_MINOR, 1033            | CK ECDH2 DERIVE PARAMS, 475          |
| event, 1057                             | CK_ECMQV_DERIVE_PARAMS, 477          |
|                                         |                                      |
| FALSE, 1033                             | CK_GOSTR3410_DERIVE_PARAMS, 480      |
| pApplication, 1057                      | CK_KEA_DERIVE_PARAMS, 483            |
| TRUE, 1034                              | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501 |
| pkcs_mech_get_info                      | CK_X9_42_DH1_DERIVE_PARAMS, 523      |
| Attributes (pkcs11_attrib_), 368        | CK_X9_42_DH2_DERIVE_PARAMS, 525      |
| pLabel                                  | CK_X9_42_MQV_DERIVE_PARAMS, 526      |
| CK_TLS_KDF_PARAMS, 512                  | pPublicData2                         |
| CK_TLS_PRF_PARAMS, 514                  | CK_ECDH2_DERIVE_PARAMS, 475          |
| CK_WTLS_PRF_PARAMS, 521                 | CK_ECMQV_DERIVE_PARAMS, 477          |
| pMechanism                              | CK_X9_42_DH2_DERIVE_PARAMS, 525      |
| CK_KIP_PARAMS, 485                      | CK_X9_42_MQV_DERIVE_PARAMS, 526      |
| pNewPassword                            | pRandomA                             |
| CK_SKIPJACK_RELAYX_PARAMS, 503          | CK_KEA_DERIVE_PARAMS, 483            |
| pNewPublicData                          | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 501 |
| CK_SKIPJACK_RELAYX_PARAMS, 503          | pRandomB                             |
| pNewRandomA                             | CK_KEA_DERIVE_PARAMS, 483            |
| CK_SKIPJACK_RELAYX_PARAMS, 503          | pRequestedAttributes                 |
| pNonce                                  | CK_CMS_SIG_PARAMS, 470               |
| CK_AES_CCM_PARAMS, 462                  | pRequiredAttributes                  |
| CK_CCM_PARAMS, 469                      | CK_CMS_SIG_PARAMS, 470               |
| pOAEPParams                             | pReserved                            |
| CK_RSA_AES_KEY_WRAP_PARAMS, 497         | CK C INITIALIZE ARGS, 466            |
| pOldPassword                            | pReturnedKeyMaterial                 |
| CK_SKIPJACK_RELAYX_PARAMS, 503          | CK_SSL3_KEY_MAT_PARAMS, 507          |
| pOldPublicData                          | CK_TLS12_KEY_MAT_PARAMS, 510         |
| CK_SKIPJACK_RELAYX_PARAMS, 503          | CK_WTLS_KEY_MAT_PARAMS, 519          |
| pOldRandomA                             | prf                                  |
| CK_SKIPJACK_RELAYX_PARAMS, 504          | CK_PKCS5_PBKD2_PARAMS, 491           |
| pOldWrappedX                            | CK_PKCS5_PBKD2_PARAMS2, 493          |
| CK_SKIPJACK_RELAYX_PARAMS, 504          | prfHashMechanism                     |
| . – – – – – – – – – – – – – – – – – – – | •                                    |
| ATCA Hanne Cfg. 450                     | CK_TLS12_KEY_MAT_PARAMS, 510         |
| ATCAlfaceCfg, 456                       | CK_TLS12_MASTER_KEY_DERIVE_PARAMS,   |
| pOtherInfo                              | 511<br>OK TI O MAG BARANG 540        |
| CK_X9_42_DH1_DERIVE_PARAMS, 523         | CK_TLS_MAC_PARAMS, 513               |
| CK_X9_42_DH2_DERIVE_PARAMS, 525         | prfMechanism                         |
| CK_X9_42_MQV_DERIVE_PARAMS, 526         | CK_TLS_KDF_PARAMS, 512               |
| pOutput                                 | private_key_slot                     |
| CK_TLS_PRF_PARAMS, 514                  | atcacert_def_s, 445                  |
| CK_WTLS_PRF_PARAMS, 521                 | PRIVWRITE_COUNT                      |
| pParameter                              | calib_command.h, 761                 |
| CK_MECHANISM, 486                       | PRIVWRITE_KEYID_IDX                  |
| pParams                                 | calib_command.h, 761                 |
| CK_OTP_PARAMS, 488                      | PRIVWRITE_MAC_IDX                    |
| CK_OTP_SIGNATURE_INFO, 489              | calib_command.h, 761                 |
| pPassword                               | PRIVWRITE_MODE_ENCRYPT               |

| calib_command.h, 761                   | CK_SSL3_MASTER_KEY_DERIVE_PARAMS,                  |
|----------------------------------------|----------------------------------------------------|
| PRIVWRITE_RSP_SIZE                     | 508                                                |
| calib_command.h, 761                   | CK_TLS12_MASTER_KEY_DERIVE_PARAMS,                 |
| PRIVWRITE_VALUE_IDX                    | 511                                                |
| calib_command.h, 762                   | CK_WTLS_MASTER_KEY_DERIVE_PARAMS,                  |
| PRIVWRITE_ZONE_IDX                     | 520                                                |
| calib_command.h, 762                   | pWrapOID                                           |
| PRIVWRITE_ZONE_MASK                    | CK_GOSTR3410_KEY_WRAP_PARAMS, 481                  |
| calib_command.h, 762                   | pX                                                 |
| pSalt                                  | CK_KEY_WRAP_SET_OAEP_PARAMS, 485                   |
| CK_PBE_PARAMS, 490                     | rand_out                                           |
| pSaltSourceData                        | Host side crypto methods (atcah_), 323             |
| CK_PKCS5_PBKD2_PARAMS, 491             | RANDOM COUNT                                       |
| CK_PKCS5_PBKD2_PARAMS2, 493            | calib_command.h, 762                               |
| pSeed                                  | RANDOM_MODE_IDX                                    |
| CK_DSA_PARAMETER_GEN_PARAM, 472        | calib_command.h, 762                               |
| CK_KIP_PARAMS, 486                     | RANDOM_NO_SEED_UPDATE                              |
| CK_TLS_PRF_PARAMS, 514                 | calib_command.h, 762                               |
| CK_WTLS_PRF_PARAMS, 521                | RANDOM_NUM_SIZE                                    |
| pServerRandom                          | calib_command.h, 763                               |
| CK_SSL3_RANDOM_DATA, 509               | RANDOM_PARAM2_IDX                                  |
| CK_WTLS_RANDOM_DATA, 522               | calib_command.h, 763                               |
| pSharedData                            | RANDOM_RSP_SIZE                                    |
| CK_ECDH1_DERIVE_PARAMS, 473            | calib_command.h, 763                               |
| CK_ECDH2_DERIVE_PARAMS, 475            | RANDOM_SEED_UPDATE                                 |
| CK_ECDH_AES_KEY_WRAP_PARAMS, 476       | calib_command.h, 763                               |
| CK_ECMQV_DERIVE_PARAMS, 477            | RandomInfo                                         |
| pSigningMechanism                      | CK_SSL3_KEY_MAT_PARAMS, 507                        |
| CK_CMS_SIG_PARAMS, 470                 | CK_SSL3_MASTER_KEY_DERIVE_PARAMS,                  |
| pSourceData                            | 508                                                |
| CK_RSA_PKCS_OAEP_PARAMS, 498           | CK_TLS12_KEY_MAT_PARAMS, 510                       |
| pSubprimeQ                             | CK_TLS12_MASTER_KEY_DERIVE_PARAMS,                 |
| CK SKIPJACK PRIVATE WRAP PARAMS, 502   | 511                                                |
| public_key                             | CK_TLS_KDF_PARAMS, 512                             |
| atca_gen_key_in_out, 419               | CK_WTLS_KEY_MAT_PARAMS, 519                        |
| Host side crypto methods (atcah_), 323 | CK_WTLS_MASTER_KEY_DERIVE_PARAMS,                  |
| public_key_dev_loc                     | 521                                                |
| atcacert_def_s, 445                    | READ_32_RSP_SIZE                                   |
| public_key_size                        | calib_command.h, 763                               |
| atca_gen_key_in_out, 419               | READ_4_RSP_SIZE                                    |
| publicKey                              | calib_command.h, 763                               |
| CK_ECMQV_DERIVE_PARAMS, 477            | READ_ADDR_IDX                                      |
| CK X9 42 MQV DERIVE PARAMS, 527        | calib_command.h, 764                               |
| publish                                | READ_COUNT                                         |
| license.txt, 886                       | calib_command.h, 764                               |
| pUKM                                   | read_key                                           |
| CK GOSTR3410 DERIVE PARAMS, 480        | _pkcs11_session_ctx, 399                           |
| CK_GOSTR3410_KEY_WRAP_PARAMS, 481      | READ_ZONE_IDX                                      |
| pulOutputLen                           | calib_command.h, 764                               |
| CK_TLS_PRF_PARAMS, 514                 | READ_ZONE_MASK                                     |
| CK_WTLS_PRF_PARAMS, 522                | calib_command.h, 764                               |
| PUNITIVE                               | README.md, 1059                                    |
| license.txt, 886                       | readme.md, 1059                                    |
| pValue                                 | RECEIVE_MODE  Hardware abstraction layor (bal) 264 |
| CK_ATTRIBUTE, 465                      | Hardware abstraction layer (hal_), 264             |
| CK_ATTAIBUTE, 465<br>CK_OTP_PARAM, 488 | ref_ct atcal2Cmaster_452                           |
| — — — ·                                | atcal2Cmaster, 452<br>atcaSPImaster, 459           |
| pVersion                               | aluaui iiilasidi, 403                              |

| atcaSWImaster, 460                               | bind_host_and_secure_element_with_io_protection, |
|--------------------------------------------------|--------------------------------------------------|
| releaseATCADevice                                | 1062                                             |
| ATCADevice (atca_), 145                          | host_generate_random_number, 1063                |
| releaseATCAlface                                 | SECURE_BOOT_CONFIG_DISABLE, 1061                 |
| ATCAlface (atca_), 152                           | SECURE_BOOT_CONFIG_FULL_BOTH, 1061               |
| reserved                                         | SECURE_BOOT_CONFIG_FULL_DIG, 1061                |
| memory_parameters, 531                           | SECURE_BOOT_CONFIG_FULL_SIGN, 1062               |
| Reserved0                                        | SECURE_BOOT_CONFIGURATION, 1062                  |
| _atecc508a_config, 383                           | SECURE_BOOT_DIGEST_ENCRYPT_ENABLED,              |
| _atsha204a_config, 390                           | 1062                                             |
| Reserved1                                        | secure boot process, 1063                        |
| _atecc508a_config, 383                           | SECURE BOOT UPGRADE SUPPORT, 1062                |
| _atecc608_config, 387                            | secure_boot_check_full_copy_completion           |
| _atsha204a_config, 390                           | secure_boot_memory.h, 1064                       |
| Reserved2                                        | secure_boot_config                               |
| _atecc508a_config, 383                           | atca_secureboot_mac_in_out, 428                  |
| _atecc608_config, 387                            |                                                  |
| _atsha204a_config, 391                           | secure_boot_config_bits, 532                     |
| Reserved3                                        | secure_boot_mode, 532                            |
| _atecc608_config, 387                            | secure_boot_persistent_enable, 532               |
|                                                  | secure_boot_pub_key, 532                         |
| response                                         | secure_boot_rand_nonce, 532                      |
| Host side crypto methods (atcah_), 324           | secure_boot_reserved1, 532                       |
| restriction                                      | secure_boot_reserved2, 533                       |
| license.txt, 886                                 | secure_boot_sig_dig, 533                         |
| RETURN                                           | SECURE_BOOT_CONFIG_DISABLE                       |
| calib_aes_gcm.c, 668                             | secure_boot.h, 1061                              |
| RevNum                                           | SECURE_BOOT_CONFIG_FULL_BOTH                     |
| _atecc508a_config, 383                           | secure_boot.h, 1061                              |
| _atecc608_config, 387                            | SECURE BOOT CONFIG FULL DIG                      |
| _atsha204a_config, 391                           | secure_boot.h, 1061                              |
| RFU                                              | SECURE_BOOT_CONFIG_FULL_SIGN                     |
| _atecc508a_config, 383                           | secure_boot.h, 1062                              |
| rotate_right                                     | SECURE BOOT CONFIGURATION                        |
| sha2_routines.c, 1071                            |                                                  |
| RSA2048 KEY SIZE                                 | secure_boot.h, 1062                              |
| calib_command.h, 764                             | secure_boot_deinit_memory                        |
| RX_DELAY                                         | secure_boot_memory.h, 1064                       |
| Hardware abstraction layer (hal_), 264           | SECURE_BOOT_DIGEST_ENCRYPT_ENABLED               |
| rx retries                                       | secure_boot.h, 1062                              |
| ATCAlfaceCfg, 456                                | secure_boot_init_memory                          |
| 7th of theodolg, 100                             | secure_boot_memory.h, 1064                       |
| s sha context                                    | secure_boot_mark_full_copy_completion            |
| secure boot parameters, 533                      | secure_boot_memory.h, 1064                       |
| saltSource                                       | secure_boot_memory.h, 1063                       |
| CK_PKCS5_PBKD2_PARAMS, 491                       | secure_boot_check_full_copy_completion, 1064     |
| CK_PKCS5_PBKD2_PARAMS2, 493                      | secure_boot_deinit_memory, 1064                  |
| sam0_change_baudrate                             | secure boot init memory, 1064                    |
| hal sam0 i2c asf.h, 853                          | secure_boot_mark_full_copy_completion, 1064      |
| sam change baudrate                              | secure_boot_read_memory, 1064                    |
| _ • -                                            | secure_boot_write_memory, 1064                   |
| Hardware abstraction layer (hal_), 267           | secure_boot_mode                                 |
| SCL_PIN                                          |                                                  |
| hal_esp32_i2c.c, 830                             | secure_boot_config_bits, 532                     |
| SDA_PIN                                          | secure_boot_parameters, 533                      |
| hal_esp32_i2c.c, 830                             | app_digest, 533                                  |
| secure_boot.c, 1059                              | memory_params, 533                               |
| bind_host_and_secure_element_with_io_protection, | s_sha_context, 533                               |
| 1060                                             | secure_boot_persistent_enable                    |
| secure_boot_process, 1060                        | secure_boot_config_bits, 532                     |
| secure_boot.h, 1060                              | secure_boot_process                              |

| secure boot.c, 1060                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | SECUREBOOTCONFIG OFFSET                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| secure_boot.h, 1063                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot_pub_key                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | select_pin                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| secure_boot_config_bits, 532                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | ATCAlfaceCfg, 457                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| secure boot rand nonce                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Selector                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| secure_boot_config_bits, 532                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | _atecc508a_config, 383                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| secure_boot_read_memory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | _atsha204a_config, 391                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| secure_boot_memory.h, 1064                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | SELFTEST COUNT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| secure_boot_reserved1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot_config_bits, 532                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | SELFTEST_MODE_AES                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| secure_boot_reserved2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot_config_bits, 533                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | SELFTEST_MODE_ALL                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| secure_boot_sig_dig                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot_config_bits, 533                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | SELFTEST_MODE_ECDH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| SECURE_BOOT_UPGRADE_SUPPORT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot.h, 1062                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | SELFTEST_MODE_ECDSA_SIGN_VERIFY                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| secure_boot_write_memory                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | calib_command.h, 768                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| secure_boot_memory.h, 1064                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | SELFTEST_MODE_IDX                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SecureBoot                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | calib_command.h, 769                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| _atecc608_config, 387                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | SELFTEST_MODE_RNG                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SECUREBOOT_COUNT_DIG                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | calib_command.h, 769                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| calib_command.h, 764                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | SELFTEST_MODE_SHA                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SECUREBOOT_COUNT_DIG_SIG                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | calib_command.h, 769                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | SELFTEST_RSP_SIZE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SECUREBOOT_DIGEST_SIZE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | calib_command.h, 769                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | sercom_core_freq                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| SECUREBOOT_MAC_SIZE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | atcaSWImaster, 460                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | serialNumber                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| SECUREBOOT_MODE_ENC_MAC_FLAG                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | CK_TOKEN_INFO, 516                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | , -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | session                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | session                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | session _pkcs11_slot_ctx, 400                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414                                                                                                                                                                                                                                                                                                                                                                                                                             |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414                                                                                                                                                                                                                                                                                                                                                                                                                             |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | sessionpkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len                                                                                                                                                                                                                                                                                                                                                                               |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | sessionpkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415                                                                                                                                                                                                                                                                                                                                                              |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state                                                                                                                                                                                                                                                                                                                                              |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_MASK SECUREBOOT_MODE_PROHIBIT_FLAG                                                                                                                                                                                                                                                                                                                                                                                                                  | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415                                                                                                                                                                                                                                                                                                                             |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766                                                                                                                                                                                                                                                                                                                                                                                                                  | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065                                                                                                                                                                                                                                                                                                       |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG SECUREBOOT_RSP_SIZE_MAC                                                                                                                                                                                                                                                                                                                                                            | sessionpkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065                                                                                                                                                                                                                                                                                           |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766                                                                                                                                                                                                                                                                                                                                                                     | sessionpkcs11_slot_ctx, 400 session_counteratca_device, 414 session_keyatca_device, 414 session_key_idatca_device, 415 session_key_lenatca_device, 415 session_stateatca_device, 415 sha1_routines.c, 1065CL_hash, 1065CL_hashFinal, 1066                                                                                                                                                                                                                                                                               |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC                                                                                                                                                                                                                                                                                                                                          | sessionpkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashInit, 1066                                                                                                                                                                                                                                                      |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766                                                                                                                                                                                                                                                                                                                     | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashUpdate, 1066                                                                                                                                                                                                                                                  |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC selib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE                                                                                                                                                                                           | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashUpdate, 1066 shaEngine, 1067                                                                                                                                                                                                                                  |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767                                                                                                                                                                                                                      | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067                                                                                                                                                                                                            |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED                                                                                                                                                                                       | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068                                                                                                                                                                                                 |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767                                                                                                                                                                  | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashInit, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068                                                                                                                                                                |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH                                                                                                                                  | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashInit, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068 CL_hash, 1069                                                                                                                                                  |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767                                                                                                                                                             | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashInit, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068 CL_hash, 1069 CL_hashFinal, 1069                                                                                                                               |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG                                                                                                                              | session _pkcs11_slot_ctx, 400 session_counter atca_device, 414 session_key atca_device, 414 session_key_id atca_device, 415 session_key_len atca_device, 415 session_state atca_device, 415 sha1_routines.c, 1065 CL_hash, 1065 CL_hashFinal, 1066 CL_hashInit, 1066 CL_hashUpdate, 1066 shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068 CL_hash, 1069 CL_hashFinal, 1069 CL_hashInit, 1070                                                                                                             |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767                                                                                                         | sessionpkcs11_slot_ctx, 400 session_counter     atca_device, 414 session_key     atca_device, 414 session_key_id     atca_device, 415 session_key_len     atca_device, 415 session_state     atca_device, 415 sha1_routines.c, 1065     CL_hash, 1065     CL_hashFinal, 1066     CL_hashInit, 1066     CL_hashUpdate, 1066     shaEngine, 1067 sha1_routines.h, 1067     _NOP, 1068     _WDRESET, 1068     CL_hashFinal, 1069     CL_hashInit, 1070     CL_hashUpdate, 1070                                             |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_SIG                                                                          | session _pkcs11_slot_ctx, 400 session_counter    atca_device, 414 session_key    atca_device, 414 session_key_id    atca_device, 415 session_key_len    atca_device, 415 session_state    atca_device, 415 sha1_routines.c, 1065    CL_hash, 1065    CL_hashFinal, 1066    CL_hashUpdate, 1066    shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068 CL_hashInit, 1069 CL_hashInit, 1070 CL_hashUpdate, 1070 leftRotate, 1068                                                                              |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_DISABLED calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_SIG calib_command.h, 767 | sessionpkcs11_slot_ctx, 400 session_counter     atca_device, 414 session_key     atca_device, 414 session_key_id     atca_device, 415 session_key_len     atca_device, 415 session_state     atca_device, 415 sha1_routines.c, 1065     CL_hash, 1065     CL_hashFinal, 1066     CL_hashInit, 1066     CL_hashUpdate, 1066     shaEngine, 1067     sha1_routines.h, 1067     _NOP, 1068     _WDRESET, 1068     CL_hashFinal, 1069     CL_hashInit, 1070     CL_hashUpdate, 1070     leftRotate, 1068     memcpy_P, 1068 |
| calib_command.h, 765 SECUREBOOT_MODE_FULL calib_command.h, 765 SECUREBOOT_MODE_FULL_COPY calib_command.h, 765 SECUREBOOT_MODE_FULL_STORE calib_command.h, 766 SECUREBOOT_MODE_IDX calib_command.h, 766 SECUREBOOT_MODE_MASK calib_command.h, 766 SECUREBOOT_MODE_PROHIBIT_FLAG calib_command.h, 766 SECUREBOOT_RSP_SIZE_MAC calib_command.h, 766 SECUREBOOT_RSP_SIZE_NO_MAC calib_command.h, 766 SECUREBOOT_SIGNATURE_SIZE calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_BOTH calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_DIG calib_command.h, 767 SECUREBOOTCONFIG_MODE_FULL_SIG                                                                          | session _pkcs11_slot_ctx, 400 session_counter    atca_device, 414 session_key    atca_device, 414 session_key_id    atca_device, 415 session_key_len    atca_device, 415 session_state    atca_device, 415 sha1_routines.c, 1065    CL_hash, 1065    CL_hashFinal, 1066    CL_hashUpdate, 1066    shaEngine, 1067 sha1_routines.h, 1067 _NOP, 1068 _WDRESET, 1068 CL_hashInit, 1069 CL_hashInit, 1070 CL_hashUpdate, 1070 leftRotate, 1068                                                                              |

| U16, 1068                                | sha2_routines.h, 1073                 |
|------------------------------------------|---------------------------------------|
| U32, 1069                                | SHA256_BLOCK_SIZE, 1073               |
| U8, 1069                                 | SHA256_DIGEST_SIZE, 1074              |
| sha206a_authenticate                     | sw sha256, 1074                       |
| api_206a.c, 538                          | sw sha256 final, 1074                 |
| api_206a.h, 545                          | sw sha256 init, 1074                  |
| sha206a_check_dk_useflag_validity        | sw_sha256_update, 1075                |
| api_206a.c, 538                          | SHA CONTEXT MAX SIZE                  |
| api_206a.h, 546                          | Basic Crypto API methods (atcab_), 59 |
| sha206a_check_pk_useflag_validity        |                                       |
| <del>-</del>                             | SHA_COUNT_LONG                        |
| api_206a.c, 539                          | calib_command.h, 769                  |
| api_206a.h, 546                          | SHA_COUNT_SHORT                       |
| SHA206A_DATA_STORE0                      | calib_command.h, 769                  |
| api_206a.h, 545                          | SHA_DATA_MAX                          |
| SHA206A_DATA_STORE1                      | calib_command.h, 770                  |
| api_206a.h, 545                          | SHA_MODE_608_HMAC_END                 |
| SHA206A_DATA_STORE2                      | calib_command.h, 770                  |
| api_206a.h, 545                          | SHA_MODE_HMAC_END                     |
| sha206a_diversify_parent_key             | calib_command.h, 770                  |
| api 206a.c, 539                          | SHA MODE HMAC START                   |
| api 206a.h, 546                          | calib command.h, 770                  |
| sha206a_generate_challenge_response_pair | SHA_MODE_HMAC_UPDATE                  |
| api_206a.c, 539                          | calib_command.h, 770                  |
| api 206a.h, 547                          | SHA MODE MASK                         |
| sha206a_generate_derive_key              | calib_command.h, 770                  |
| api_206a.c, 540                          | SHA_MODE_READ_CONTEXT                 |
| • —                                      |                                       |
| api_206a.h, 547                          | calib_command.h, 771                  |
| sha206a_get_data_store_lock_status       | SHA_MODE_SHA256_END                   |
| api_206a.c, 540                          | calib_command.h, 771                  |
| api_206a.h, 548                          | SHA_MODE_SHA256_PUBLIC                |
| sha206a_get_dk_update_count              | calib_command.h, 771                  |
| api_206a.c, 541                          | SHA_MODE_SHA256_START                 |
| api_206a.h, 548                          | calib_command.h, 771                  |
| sha206a_get_dk_useflag_count             | SHA_MODE_SHA256_UPDATE                |
| api_206a.c, 541                          | calib_command.h, 771                  |
| api_206a.h, 548                          | SHA_MODE_TARGET_MASK                  |
| sha206a_get_pk_useflag_count             | calib_command.h, 771                  |
| api_206a.c, 541                          | SHA_MODE_TARGET_MSGDIGBUF             |
| api 206a.h, 549                          | cryptoauthlib.h, 820                  |
| sha206a_read_data_store                  | SHA_MODE_TARGET_OUT_ONLY              |
| api_206a.c, 542                          | cryptoauthlib.h, 820                  |
| api 206a.h, 549                          | SHA MODE TARGET TEMPKEY               |
| sha206a_verify_device_consumption        | cryptoauthlib.h, 820                  |
| api_206a.c, 542                          | SHA MODE WRITE CONTEXT                |
| api_206a.6, 542<br>api_206a.h, 550       | calib command.h, 772                  |
| • —                                      | <del>-</del>                          |
| sha206a_write_data_store                 | SHA_RSP_SIZE                          |
| api_206a.c, 543                          | calib_command.h, 772                  |
| api_206a.h, 550                          | SHA_RSP_SIZE_LONG                     |
| SHA256_BLOCK_SIZE                        | calib_command.h, 772                  |
| sha2_routines.h, 1073                    | SHA_RSP_SIZE_SHORT                    |
| SHA256_DIGEST_SIZE                       | calib_command.h, 772                  |
| sha2_routines.h, 1074                    | shaEngine                             |
| sha2_routines.c, 1070                    | sha1_routines.c, 1067                 |
| rotate_right, 1071                       | sha1_routines.h, 1070                 |
| sw_sha256, 1071                          | SIGN_COUNT                            |
| sw_sha256_final, 1072                    | calib_command.h, 772                  |
| sw sha256 init, 1072                     | SIGN KEYID IDX                        |
| sw_sha256_update, 1072                   | calib_command.h, 772                  |
|                                          |                                       |

| SIGN_MODE_EXTERNAL                     | slots                                             |
|----------------------------------------|---------------------------------------------------|
| calib_command.h, 773                   | _pkcs11_lib_ctx, 394                              |
| SIGN_MODE_IDX                          | sn                                                |
| calib_command.h, 773                   | atca_check_mac_in_out, 409                        |
| SIGN_MODE_INCLUDE_SN                   | atca_derive_key_in_out, 411                       |
| calib_command.h, 773                   | atca_derive_key_mac_in_out, 413                   |
| SIGN_MODE_INTERNAL                     | atca_gen_dig_in_out, 417                          |
| calib_command.h, 773                   |                                                   |
|                                        | atca_gen_key_in_out, 419                          |
| SIGN_MODE_INVALIDATE                   | atca_sign_internal_in_out, 432                    |
| calib_command.h, 773                   | atca_verify_mac, 437                              |
| SIGN_MODE_MASK                         | atca_write_mac_in_out, 438                        |
| calib_command.h, 773                   | Host side crypto methods (atcah_), 324            |
| SIGN_MODE_SOURCE_MASK                  | SN03                                              |
| calib_command.h, 774                   | _atecc508a_config, 384                            |
| SIGN_MODE_SOURCE_MSGDIGBUF             | _atecc608_config, 388                             |
| calib_command.h, 774                   | _atsha204a_config, 391                            |
| SIGN_MODE_SOURCE_TEMPKEY               | SN47                                              |
| calib_command.h, 774                   | _atecc508a_config, 384                            |
| SIGN RSP SIZE                          | _atecc608_config, 388                             |
| calib_command.h, 774                   | atsha204a config, 391                             |
| signature                              | SN8                                               |
| atca_secureboot_mac_in_out, 428        | _atecc508a_config, 384                            |
| atca_verify_mac, 437                   | _atecc608_config, 388                             |
| Host side crypto methods (atcah_), 324 | _atsha204a_config, 391                            |
|                                        | <del>-</del>                                      |
| memory_parameters, 531                 | sn_source                                         |
| Size                                   | atcacert_def_s, 446                               |
| _pkcs11_object, 396                    | SNSRC_DEVICE_SN                                   |
| slave_address                          | Certificate manipulation methods (atcacert_), 165 |
| ATCAlfaceCfg, 457                      | SNSRC_DEVICE_SN_HASH                              |
| sLen                                   | Certificate manipulation methods (atcacert_), 165 |
| CK_RSA_PKCS_PSS_PARAMS, 499            | SNSRC_DEVICE_SN_HASH_POS                          |
| slot                                   | Certificate manipulation methods (atcacert_), 165 |
| _pkcs11_object, 396                    | SNSRC_DEVICE_SN_HASH_RAW                          |
| _pkcs11_session_ctx, 399               | Certificate manipulation methods (atcacert_), 165 |
| atcacert_device_loc_s, 447             | SNSRC_PUB_KEY_HASH                                |
| slot_cnt                               | Certificate manipulation methods (atcacert_), 165 |
| _pkcs11_lib_ctx, 394                   | SNSRC_PUB_KEY_HASH_POS                            |
| slot_conf                              | Certificate manipulation methods (atcacert_), 165 |
| atca_gen_dig_in_out, 416               | SNSRC_PUB_KEY_HASH_RAW                            |
| slot_config                            | Certificate manipulation methods (atcacert_), 165 |
| atca_sign_internal_in_out, 431         | SNSRC SIGNER ID                                   |
| slot id                                | Certificate manipulation methods (atcacert_), 165 |
| _pkcs11_slot_ctx, 400                  | SNSRC_STORED                                      |
| slot key                               | Certificate manipulation methods (atcacert_), 165 |
| _ ,                                    | SNSRC_STORED_DYNAMIC                              |
| atca_check_mac_in_out, 409             |                                                   |
| slot_locked                            | Certificate manipulation methods (atcacert_), 165 |
| atca_gen_dig_in_out, 417               | SO                                                |
| SlotConfig                             | license.txt, 887                                  |
| _atecc508a_config, 383                 | so_pin_handle                                     |
| _atecc608_config, 387                  | _pkcs11_slot_ctx, 401                             |
| _atsha204a_config, 391                 | SOFTWARE                                          |
| slotDescription                        | license.txt, 887                                  |
| CK_SLOT_INFO, 506                      | Software                                          |
| slotID                                 | license.txt, 887                                  |
| CK_SESSION_INFO, 500                   | software                                          |
| SlotLocked                             | license.txt, 875                                  |
| _atecc508a_config, 384                 | Software crypto methods (atcac_), 251             |
| _atecc608_config, 388                  | ATCA_ECC_P256_FIELD_SIZE, 251                     |

| ATCA_ECC_P256_PRIVATE_KEY_SIZE, 252               | sha1_routines.h, 1068                  |
|---------------------------------------------------|----------------------------------------|
| ATCA_ECC_P256_PUBLIC_KEY_SIZE, 252                | strnchr                                |
| ATCA_ECC_P256_SIGNATURE_SIZE, 252                 | Hardware abstraction layer (hal_), 299 |
| atcac_sha256_hmac_finish, 252                     | sublicense                             |
| atcac_sha256_hmac_init, 252                       | license.txt, 888                       |
| atcac_sha256_hmac_update, 253                     | sw_sha256                              |
| atcac_sw_ecdsa_verify_p256, 253                   | sha2_routines.c, 1071                  |
| atcac_sw_random, 253                              | sha2_routines.h, 1074                  |
| atcac_sw_random, 255<br>atcac_sw_sha1, 254        | sw_sha256_ctx, 534                     |
| — — ·                                             |                                        |
| atcac_sw_sha1_finish, 254                         | block, 534                             |
| atcac_sw_sha1_init, 254                           | block_size, 534                        |
| atcac_sw_sha1_update, 255                         | hash, 534                              |
| atcac_sw_sha2_256, 255                            | total_msg_size, 534                    |
| atcac_sw_sha2_256_finish, 255                     | sw_sha256_final                        |
| atcac_sw_sha2_256_init, 255                       | sha2_routines.c, 1072                  |
| atcac_sw_sha2_256_update, 256                     | sha2_routines.h, 1074                  |
| source                                            | sw sha256 init                         |
| CK_RSA_PKCS_OAEP_PARAMS, 498                      | sha2 routines.c, 1072                  |
| source_flag                                       | sha2_routines.h, 1074                  |
| atca_temp_key, 434                                | sw_sha256_update                       |
| SPECIAL                                           | sha2_routines.c, 1072                  |
|                                                   | sha2_routines.h, 1075                  |
| license.txt, 887                                  |                                        |
| spi_file                                          | SWI_FLAG_CMD                           |
| atcaSPImaster, 459                                | Hardware abstraction layer (hal_), 264 |
| start_address                                     | SWI_FLAG_IDLE                          |
| memory_parameters, 531                            | Hardware abstraction layer (hal_), 265 |
| start_change_baudrate                             | SWI_FLAG_SLEEP                         |
| Hardware abstraction layer (hal_), 267            | Hardware abstraction layer (hal_), 265 |
| state                                             | SWI_FLAG_TX                            |
| _pkcs11_session_ctx, 399                          | Hardware abstraction layer (hal_), 265 |
| CK_SESSION_INFO, 500                              | swi_uart_deinit                        |
| STATUTORY                                         | Hardware abstraction layer (hal_), 299 |
| license.txt, 888                                  | swi_uart_discover_buses                |
| std cert elements                                 | Hardware abstraction layer (hal_), 300 |
| atcacert def s, 446                               | swi_uart_init                          |
| STDCERT_AUTH_KEY_ID                               | Hardware abstraction layer (hal_), 300 |
|                                                   | · · · · · · · · · · · · · · · · · · ·  |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_mode                          |
| STDCERT_CERT_SN                                   | Hardware abstraction layer (hal_), 300 |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_receive_byte                  |
| STDCERT_EXPIRE_DATE                               | Hardware abstraction layer (hal_), 301 |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_samd21_asf.c, 1075            |
| STDCERT_ISSUE_DATE                                | swi_uart_samd21_asf.h, 1076            |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_send_byte                     |
| STDCERT NUM ELEMENTS                              | Hardware abstraction layer (hal_), 301 |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_setbaud                       |
| STDCERT_PUBLIC_KEY                                | Hardware abstraction layer (hal_), 302 |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_start.c, 1077                 |
| STDCERT SIGNATURE                                 | USART BAUD RATE, 1078                  |
| <del>-</del>                                      |                                        |
| Certificate manipulation methods (atcacert_), 166 | swi_uart_start.h, 1078                 |
| STDCERT_SIGNER_ID                                 | SWI_WAKE_TOKEN                         |
| Certificate manipulation methods (atcacert_), 166 | Hardware abstraction layer (hal_), 265 |
| STDCERT_SUBJ_KEY_ID                               | symmetric_authenticate                 |
| Certificate manipulation methods (atcacert_), 166 | symmetric_authentication.c, 1080       |
| stopbits                                          | symmetric_authentication.h, 1081       |
| ATCAlfaceCfg, 457                                 | symmetric_authentication.c, 1079       |
| stored_value                                      | symmetric_authenticate, 1080           |
| atca_gen_dig_in_out, 417                          | symmetric_authentication.h, 1080       |
| strcpy_P                                          | symmetric_authenticate, 1081           |

| TA100                                             | tm_mon                                    |
|---------------------------------------------------|-------------------------------------------|
| ATCADevice (atca_), 143                           | atcacert_tm_utc_s, 449                    |
| TABLE_SIZE                                        | tm_sec                                    |
| Attributes (pkcs11_attrib_), 337                  | atcacert_tm_utc_s, 449                    |
| TAG                                               | tm_year                                   |
| hal_esp32_i2c.c, 839                              | atcacert_tm_utc_s, 449                    |
| target_key                                        | TNG API (tng_), 373                       |
| atca_check_mac_in_out, 409                        | CRYPTOAUTH_ROOT_CA_002_PUBLIC_KEY_OFFSET, |
| atca_derive_key_in_out, 412                       | 374                                       |
| target_key_id                                     | g_cryptoauth_root_ca_002_cert, 379        |
| atca_derive_key_in_out, 412                       | g_cryptoauth_root_ca_002_cert_size, 379   |
| atca_derive_key_mac_in_out, 413                   | g_tflxtls_cert_def_4_device, 379          |
| tbs_cert_loc                                      | g_tnglora_cert_def_1_signer, 379          |
| atcacert_def_s, 446                               | g_tnglora_cert_def_2_device, 379          |
| temp_key                                          | g_tnglora_cert_def_4_device, 380          |
| atca_check_mac_in_out, 409                        | g_tngtls_cert_def_1_signer, 380           |
| atca_derive_key_in_out, 412                       | g_tngtls_cert_def_2_device, 380           |
| atca_gen_dig_in_out, 417                          | g_tngtls_cert_def_3_device, 380           |
| atca_gen_key_in_out, 419                          | tng_atcacert_device_public_key, 374       |
| atca_secureboot_enc_in_out, 427                   | tng_atcacert_max_device_cert_size, 375    |
| atca_sign_internal_in_out, 432                    | tng_atcacert_max_signer_cert_size, 375    |
| atca_verify_mac, 437                              | tng_atcacert_read_device_cert, 375        |
| atca_write_mac_in_out, 438                        | tng_atcacert_read_signer_cert, 376        |
| Host side crypto methods (atcah_), 325            | tng_atcacert_root_cert, 376               |
| template_id                                       | tng_atcacert_root_cert_size, 377          |
| atcacert_def_s, 446                               | tng_atcacert_root_public_key, 377         |
| terms                                             | tng_atcacert_signer_public_key, 377       |
| license.txt, 888                                  | tng_get_device_cert_def, 378              |
| TF BIN2HEX LC                                     | tng_get_device_pubkey, 378                |
| Certificate manipulation methods (atcacert_), 168 | tng_map_get_device_cert_def, 379          |
| TF_BIN2HEX_SPACE_LC                               | TNGLORA_CERT_TEMPLATE_4_DEVICE_SIZE,      |
| Certificate manipulation methods (atcacert_), 168 | 374                                       |
| TF_BIN2HEX_SPACE_UC                               | TNGTLS CERT ELEMENTS 2 DEVICE COUNT,      |
| Certificate manipulation methods (atcacert_), 168 | 374                                       |
| TF_BIN2HEX_UC                                     | TNGTLS_CERT_TEMPLATE_1_SIGNER_SIZE,       |
| Certificate manipulation methods (atcacert_), 168 | 374                                       |
| TF_HEX2BIN_LC                                     | TNGTLS_CERT_TEMPLATE_2_DEVICE_SIZE,       |
| Certificate manipulation methods (atcacert_), 168 | 374                                       |
| TF_HEX2BIN_SPACE_LC                               | TNGTLS_CERT_TEMPLATE_3_DEVICE_SIZE,       |
| Certificate manipulation methods (atcacert_), 168 | 374                                       |
| TF_HEX2BIN_SPACE_UC                               | tng_atca.c, 1083                          |
| Certificate manipulation methods (atcacert_), 168 | tng_atca.h, 1083                          |
| TF_HEX2BIN_UC                                     | tng_atcacert_client.c, 1084               |
| Certificate manipulation methods (atcacert), 168  | tng_atcacert_device_public_key, 1085      |
| TF_NONE                                           | tng_atcacert_max_signer_cert_size, 1085   |
| Certificate manipulation methods (atcacert_), 168 | tng_atcacert_read_device_cert, 1086       |
| TF REVERSE                                        | tng_atcacert_read_signer_cert, 1086       |
| Certificate manipulation methods (atcacert_), 168 | tng_atcacert_root_cert, 1086              |
| tflxtls_cert_def_4_device.c, 1081                 | tng_atcacert_root_cert_size, 1087         |
| g_tflxtls_cert_elements_4_device, 1082            | tng_atcacert_root_public_key, 1087        |
| g_tflxtls_cert_template_4_device, 1082            | tng_atcacert_signer_public_key, 1088      |
| tflxtls_cert_def_4_device.h, 1082                 | tng_atcacert_client.h, 1088               |
| tm_hour                                           | tng_atcacert_device_public_key            |
| atcacert_tm_utc_s, 448                            | TNG API (tng_), 374                       |
| tm_mday                                           | tng_atcacert_client.c, 1085               |
| atcacert_tm_utc_s, 448                            | tng_atcacert_max_device_cert_size         |
| tm_min                                            | TNG API (tng_), 375                       |
| atcacert_tm_utc_s, 448                            | tng_atcacert_max_signer_cert_size         |

| TNG API (tng ), 375                      | tngtls_cert_def_3_device.c, 1097                  |
|------------------------------------------|---------------------------------------------------|
| tng_atcacert_client.c, 1085              | g_tngtls_cert_def_3_device, 1098                  |
| tng_atcacert_read_device_cert            | g_tngtls_cert_elements_3_device, 1098             |
| TNG API (tng_), 375                      | g_tngtls_cert_template_3_device, 1098             |
| tng atcacert client.c, 1086              | tngtls_cert_def_3_device.h, 1098                  |
| tng_atcacert_read_signer_cert            | TNGTLS_CERT_ELEMENTS_2_DEVICE_COUNT               |
| TNG API (tng_), 376                      | TNG API (tng_), 374                               |
| tng_atcacert_client.c, 1086              | TNGTLS_CERT_TEMPLATE_1_SIGNER_SIZE                |
| tng_atcacert_root_cert                   | TNG API (tng_), 374                               |
| TNG API (tng_), 376                      | TNGTLS_CERT_TEMPLATE_2_DEVICE_SIZE                |
| tng_atcacert_client.c, 1086              | TNG API (tng_), 374                               |
| tng_atcacert_root_cert_size              | TNGTLS_CERT_TEMPLATE_3_DEVICE_SIZE                |
| TNG API (tng_), 377                      | TNG API (tng_), 374                               |
| tng_atcacert_client.c, 1087              | ТО                                                |
| tng_atcacert_root_public_key             | license.txt, 888                                  |
| TNG API (tng_), 377                      | TORT                                              |
| tng_atcacert_client.c, 1087              | license.txt, 875                                  |
| tng_atcacert_signer_public_key           | total_msg_size                                    |
| TNG API (tng_), 377                      | atca_sha256_ctx, 429                              |
| tng_atcacert_client.c, 1088              | hw_sha256_ctx, 529                                |
| tng_cert_map_element, 535                | sw_sha256_ctx, 534                                |
| cert_def, 535                            | transforms                                        |
| otpcode, 535                             | atcacert_cert_element_s, 441                      |
| tng_get_device_cert_def                  | TRANSMIT_MODE                                     |
| TNG API (tng_), 378                      | Hardware abstraction layer (hal_), 265            |
| tng_get_device_pubkey                    | TRUE                                              |
| TNG API (tng_), 378                      | Certificate manipulation methods (atcacert_), 162 |
| tng_map_get_device_cert_def              | pkcs11t.h, 1034                                   |
| TNG API (tng_), 379                      | trust_pkcs11_config.c, 1098                       |
| tng_root_cert.c, 1089                    | twi_id                                            |
| g_cryptoauth_root_ca_002_cert, 1089      | atcal2Cmaster, 452                                |
| g_cryptoauth_root_ca_002_cert_size, 1090 | twi_master_instance                               |
| tng_root_cert.h, 1090                    | atcal2Cmaster, 452 TX DELAY                       |
| tnglora_cert_def_1_signer.c, 1090        | Hardware abstraction layer (hal_), 266            |
| g_tngtls_cert_elements_1_signer, 1091    | txsize                                            |
| g_tngtls_cert_template_1_signer, 1091    | ATCAPacket, 459                                   |
| tnglora_cert_def_1_signer.h, 1091        | type                                              |
| tnglora_cert_def_2_device.c, 1092        | _pcks11_mech_table_e, 392                         |
| g_tngtls_cert_elements_2_device, 1092    | _pkcs11_attrib_model, 392                         |
| g_tngtls_cert_template_2_device, 1092    | atcacert_def_s, 446                               |
| tnglora_cert_def_2_device.h, 1092        | CK_ATTRIBUTE, 465                                 |
| tnglora_cert_def_4_device.c, 1093        | CK_OTP_PARAM, 488                                 |
| g_tnglora_cert_def_4_device, 1093        | ,                                                 |
| g_tnglora_cert_elements_4_device, 1093   | U16                                               |
| g_tnglora_cert_template_4_device, 1094   | sha1_routines.h, 1068                             |
| tnglora_cert_def_4_device.h, 1094        | U32                                               |
| TNGLORA_CERT_TEMPLATE_4_DEVICE_SIZE      | sha1_routines.h, 1069                             |
| TNG API (tng_), 374                      | U8                                                |
| tngtls_cert_def_1_signer.c, 1094         | sha1_routines.h, 1069                             |
| g_tngtls_cert_def_1_signer, 1095         | ulAADLen                                          |
| g_tngtls_cert_elements_1_signer, 1095    | CK_AES_CCM_PARAMS, 462                            |
| g_tngtls_cert_template_1_signer, 1095    | CK_AES_GCM_PARAMS, 464                            |
| tngtls_cert_def_1_signer.h, 1095         | CK_CCM_PARAMS, 469                                |
| tngtls_cert_def_2_device.c, 1096         | CK_GCM_PARAMS, 479                                |
| g_tngtls_cert_def_2_device, 1096         | ulAESKeyBits                                      |
| g_tngtls_cert_elements_2_device, 1096    | CK_ECDH_AES_KEY_WRAP_PARAMS, 476                  |
| g_tngtls_cert_template_2_device, 1096    | CK_RSA_AES_KEY_WRAP_PARAMS, 497                   |
| tngtls_cert_def_2_device.h, 1097         | ulClientRandomLen                                 |

| CK SSL3 RANDOM DATA, 509           | CV MILE VEY MAT DADAME FOO           |
|------------------------------------|--------------------------------------|
|                                    | CK_WTLS_KEY_MAT_PARAMS, 520          |
| CK_WTLS_RANDOM_DATA, 523           | ulMaxKeySize                         |
| ulContextDataLength                | CK_MECHANISM_INFO, 487               |
| CK_TLS_KDF_PARAMS, 512             | ulMaxPinLen                          |
| ulCount                            | CK_TOKEN_INFO, 516                   |
| CK_OTP_PARAMS, 488                 | ulMaxRwSessionCount                  |
| CK_OTP_SIGNATURE_INFO, 489         | CK_TOKEN_INFO, 516                   |
| ulCounterBits                      | ulMaxSessionCount                    |
| CK_AES_CTR_PARAMS, 463             | CK_TOKEN_INFO, 516                   |
| CK_CAMELLIA_CTR_PARAMS, 468        | ulMinKeySize                         |
| ulDataLen                          | CK_MECHANISM_INFO, 487               |
| CK_AES_CCM_PARAMS, 462             | ulMinPinLen                          |
| CK CCM PARAMS, 469                 | CK_TOKEN_INFO, 516                   |
| ulDeviceError                      | ulNewPasswordLen                     |
| CK_SESSION_INFO, 500               | CK_SKIPJACK_RELAYX_PARAMS, 504       |
| ulEffectiveBits                    | ulNewPublicDataLen                   |
| CK_RC2_CBC_PARAMS, 494             | CK SKIPJACK RELAYX PARAMS, 504       |
| CK RC2 MAC GENERAL PARAMS, 494     | ulNewRandomLen                       |
| ulFreePrivateMemory                | CK_SKIPJACK_RELAYX_PARAMS, 504       |
|                                    |                                      |
| CK_TOKEN_INFO, 516                 | ulNonceLen                           |
| ulFreePublicMemory                 | CK_AES_CCM_PARAMS, 462               |
| CK_TOKEN_INFO, 516                 | CK_CCM_PARAMS, 469                   |
| ullndex                            | ulOldPasswordLen                     |
| CK_DSA_PARAMETER_GEN_PARAM, 473    | CK_SKIPJACK_RELAYX_PARAMS, 504       |
| ullteration                        | ulOldPublicDataLen                   |
| CK_PBE_PARAMS, 490                 | CK_SKIPJACK_RELAYX_PARAMS, 504       |
| ullvBits                           | ulOldRandomLen                       |
| CK_AES_GCM_PARAMS, 464             | CK_SKIPJACK_RELAYX_PARAMS, 504       |
| CK_GCM_PARAMS, 479                 | ulOldWrappedXLen                     |
| ullvLen                            | CK_SKIPJACK_RELAYX_PARAMS, 505       |
| CK_AES_GCM_PARAMS, 464             | ulOtherInfoLen                       |
| CK_GCM_PARAMS, 479                 | CK_X9_42_DH1_DERIVE_PARAMS, 524      |
| CK_RC5_CBC_PARAMS, 495             | CK_X9_42_DH2_DERIVE_PARAMS, 525      |
| ullVSizeInBits                     | CK_X9_42_MQV_DERIVE_PARAMS, 527      |
| CK SSL3 KEY MAT PARAMS, 508        | ulPAndGLen                           |
| CK_TLS12_KEY_MAT_PARAMS, 510       | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 502 |
| CK_WTLS_KEY_MAT_PARAMS, 519        | ulParameterLen                       |
| ulKeySizeInBits                    | CK MECHANISM, 486                    |
| CK_SSL3_KEY_MAT_PARAMS, 508        | ulPasswordLen                        |
| CK_TLS12_KEY_MAT_PARAMS, 510       | CK PBE PARAMS, 490                   |
| CK_WTLS_KEY_MAT_PARAMS, 520        | CK PKCS5 PBKD2 PARAMS, 491           |
| ulLabelLen                         | CK_PKCS5_PBKD2_PARAMS2, 493          |
| CK_TLS_PRF_PARAMS, 514             | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 502 |
|                                    |                                      |
| CK_WTLS_PRF_PARAMS, 522            | ulPrfDataLen                         |
| ulLabelLength                      | CK_PKCS5_PBKD2_PARAMS, 491           |
| CK_TLS_KDF_PARAMS, 512             | CK_PKCS5_PBKD2_PARAMS2, 493          |
| ulLen                              | ulPrivateDataLen                     |
| CK_KEY_DERIVATION_STRING_DATA, 484 | CK_ECDH2_DERIVE_PARAMS, 475          |
| ulMACLen                           | CK_ECMQV_DERIVE_PARAMS, 478          |
| CK_AES_CCM_PARAMS, 462             | CK_X9_42_DH2_DERIVE_PARAMS, 525      |
| CK_CCM_PARAMS, 469                 | CK_X9_42_MQV_DERIVE_PARAMS, 527      |
| ulMacLength                        | ulPublicDataLen                      |
| CK_RC2_MAC_GENERAL_PARAMS, 494     | CK_ECDH1_DERIVE_PARAMS, 474          |
| CK_RC5_MAC_GENERAL_PARAMS, 496     | CK_ECDH2_DERIVE_PARAMS, 475          |
| CK_TLS_MAC_PARAMS, 513             | CK_ECMQV_DERIVE_PARAMS, 478          |
| ulMacSizeInBits                    | CK_GOSTR3410_DERIVE_PARAMS, 480      |
| CK_SSL3_KEY_MAT_PARAMS, 508        | CK_KEA_DERIVE_PARAMS, 483            |
| CK_TLS12_KEY_MAT_PARAMS, 511       | CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 502 |
|                                    |                                      |

| CK_X9_42_DH1_DERIVE_PARAMS, 524      | CK_GOSTR3410_KEY_WRAP_PARAMS, 481      |
|--------------------------------------|----------------------------------------|
| CK_X9_42_DH2_DERIVE_PARAMS, 525      | ulValueLen                             |
| CK_X9_42_MQV_DERIVE_PARAMS, 527      | CK_ATTRIBUTE, 465                      |
| ulPublicDataLen2                     | CK_OTP_PARAM, 488                      |
| CK_ECDH2_DERIVE_PARAMS, 475          | ulWordsize                             |
| CK_ECMQV_DERIVE_PARAMS, 478          | CK_RC5_CBC_PARAMS, 495                 |
| CK_X9_42_DH2_DERIVE_PARAMS, 525      | CK_RC5_MAC_GENERAL_PARAMS, 496         |
| CK_X9_42_MQV_DERIVE_PARAMS, 527      | CK_RC5_PARAMS, 496                     |
| ulQLen                               | ulWrapOIDLen                           |
| CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 502 | CK_GOSTR3410_KEY_WRAP_PARAMS, 481      |
| ulRandomLen                          | ulXLen                                 |
| CK_KEA_DERIVE_PARAMS, 484            | CK_KEY_WRAP_SET_OAEP_PARAMS, 485       |
| CK_SKIPJACK_PRIVATE_WRAP_PARAMS, 502 | unlock_mutex                           |
| ulRequestedAttributesLen             | _pkcs11_lib_ctx, 394                   |
| CK_CMS_SIG_PARAMS, 470               | UnlockMutex                            |
| ulRequiredAttributesLen              | CK_C_INITIALIZE_ARGS, 467              |
| CK_CMS_SIG_PARAMS, 470               | UPDATE_COUNT                           |
| ulRounds                             | calib_command.h, 774                   |
| CK_RC5_CBC_PARAMS, 495               | update_count                           |
| CK_RC5_MAC_GENERAL_PARAMS, 496       | atca_sign_internal_in_out, 432         |
| CK_RC5_PARAMS, 496                   | UPDATE_MODE_DEC_COUNTER                |
| ulRwSessionCount                     | calib_command.h, 774                   |
| CK_TOKEN_INFO, 517                   | UPDATE_MODE_IDX                        |
| ulSaltLen                            | calib_command.h, 775                   |
| CK_PBE_PARAMS, 490                   | UPDATE_MODE_SELECTOR                   |
| ulSaltSourceDataLen                  | calib_command.h, 775                   |
| CK_PKCS5_PBKD2_PARAMS, 492           | UPDATE_MODE_USER_EXTRA                 |
| CK_PKCS5_PBKD2_PARAMS2, 493          | calib_command.h, 775                   |
| ulSeedLen                            | UPDATE_MODE_USER_EXTRA_ADD             |
| CK_DSA_PARAMETER_GEN_PARAM, 473      | calib_command.h, 775                   |
| CK_KIP_PARAMS, 486                   | UPDATE_RSP_SIZE                        |
| CK_TLS_PRF_PARAMS, 514               | calib_command.h, 775                   |
| CK_WTLS_PRF_PARAMS, 522              | UPDATE_VALUE_IDX                       |
| ulSequenceNumber                     | calib_command.h, 775                   |
| CK_WTLS_KEY_MAT_PARAMS, 520          | USART_BAUD_RATE                        |
| ulServerOrClient                     | swi_uart_start.c, 1078                 |
| CK_TLS_MAC_PARAMS, 513               | usart_instance                         |
| ulServerRandomLen                    | atcaSWImaster, 460                     |
| CK_SSL3_RANDOM_DATA, 509             | USART_SWI                              |
| CK_WTLS_RANDOM_DATA, 523             | atcaSWImaster, 460                     |
| ulSessionCount                       | use license.txt, 889                   |
| CK_TOKEN_INFO, 517                   |                                        |
| ulSharedDataLen                      | use_flag                               |
| CK_ECDH1_DERIVE_PARAMS, 474          | atca_sign_internal_in_out, 432 UseLock |
| CK_ECDH2_DERIVE_PARAMS, 475          | _atecc608_config, 388                  |
| CK_ECDH_AES_KEY_WRAP_PARAMS, 476     | user_pin_handle                        |
| CK_ECMQV_DERIVE_PARAMS, 478          | pkcs11 slot ctx, 401                   |
| ulSourceDataLen                      | prcs+1_siot_ctx, 401<br>UserExtra      |
| CK_RSA_PKCS_OAEP_PARAMS, 498         | _atecc508a_config, 384                 |
| ulTagBits                            | _atecc608_config, 388                  |
| CK_AES_GCM_PARAMS, 464               | _atsha204a_config, 391                 |
| CK_GCM_PARAMS, 479                   | UserExtraAdd                           |
| ulTotalPrivateMemory                 | _atecc608_config, 388                  |
| CK_TOKEN_INFO, 517                   | utcTime                                |
| ulTotalPublicMemory                  | CK TOKEN INFO, 517                     |
| CK_TOKEN_INFO, 517                   | ON_TONER_INTO, OTT                     |
| ulUKMLen                             | valid                                  |
| CK_GOSTR3410_DERIVE_PARAMS, 480      | atca_temp_key, 434                     |

| value                          | VERIFY_OTHER_DATA_SIZE                   |
|--------------------------------|------------------------------------------|
| atca_temp_key, 434             | calib_command.h, 780                     |
| VanderVoord                    | VERIFY_RSP_SIZE                          |
| license.txt, 889               | calib_command.h, 780                     |
| VERIFY_256_EXTERNAL_COUNT      | VERIFY_RSP_SIZE_MAC                      |
| calib_command.h, 776           | calib_command.h, 780                     |
| VERIFY_256_KEY_SIZE            | Version                                  |
| calib_command.h, 776           | license.txt, 875                         |
| VERIFY_256_SIGNATURE_SIZE      | version                                  |
| calib_command.h, 776           | CK_FUNCTION_LIST, 478                    |
| VERIFY_256_STORED_COUNT        | version_info                             |
| calib_command.h, 776           | memory_parameters, 531                   |
| VERIFY_256_VALIDATE_COUNT      | vid                                      |
| calib_command.h, 776           | ATCAlfaceCfg, 457                        |
| VERIFY_283_EXTERNAL_COUNT      | VolatileKeyPermission                    |
| calib_command.h, 776           | _atecc608_config, 388                    |
| VERIFY_283_KEY_SIZE            |                                          |
| calib_command.h, 777           | wake_delay                               |
| VERIFY_283_SIGNATURE_SIZE      | ATCAlfaceCfg, 457                        |
| calib_command.h, 777           | WARRANTIES                               |
| VERIFY_283_STORED_COUNT        | license.txt, 889                         |
| calib_command.h, 777           | wordsize                                 |
| VERIFY_283_VALIDATE_COUNT      | ATCAlfaceCfg, 457                        |
| calib_command.h, 777           | WRITE_ADDR_IDX                           |
| VERIFY_DATA_IDX                | calib_command.h, 780                     |
| calib_command.h, 777           | WRITE_MAC_SIZE                           |
| VERIFY KEY B283                | calib_command.h, 781                     |
| calib_command.h, 777           | WRITE_MAC_VL_IDX                         |
| VERIFY_KEY_K283                | calib_command.h, 781                     |
| calib_command.h, 778           | WRITE_MAC_VS_IDX                         |
| VERIFY_KEY_P256                | calib_command.h, 781                     |
| calib_command.h, 778           | WRITE_RSP_SIZE                           |
| VERIFY_KEYID_IDX               | calib_command.h, 781                     |
| calib_command.h, 778           | WRITE_VALUE_IDX                          |
| VERIFY_MODE_EXTERNAL           | calib_command.h, 781                     |
| calib_command.h, 778           | WRITE_ZONE_DATA                          |
| VERIFY_MODE_IDX                | calib_command.h, 781                     |
| calib_command.h, 778           | WRITE_ZONE_IDX                           |
| VERIFY_MODE_INVALIDATE         | calib_command.h, 782                     |
| calib_command.h, 778           | WRITE_ZONE_MASK                          |
| VERIFY_MODE_MAC_FLAG           | calib_command.h, 782                     |
| calib_command.h, 779           | WRITE_ZONE_OTP                           |
| VERIFY_MODE_MASK               | calib_command.h, 782 WRITE ZONE WITH MAC |
| calib_command.h, 779           | calib command.h, 782                     |
| VERIFY_MODE_SOURCE_MASK        | Calib_Collinatio.11, 762                 |
| calib_command.h, 779           | X509format                               |
| VERIFY_MODE_SOURCE_MSGDIGBUF   | atecc508a config, 384                    |
| calib_command.h, 779           | _atecc608_config, 389                    |
| VERIFY_MODE_SOURCE_TEMPKEY     | _atoocco_comig, ccc                      |
| calib_command.h, 779           | у                                        |
| VERIFY_MODE_STORED             | atca aes gcm ctx, 407                    |
| calib_command.h, 779           | year                                     |
| VERIFY_MODE_VALIDATE           | CK_DATE, 471                             |
| calib_command.h, 780           | _ ,                                      |
| VERIFY_MODE_VALIDATE_EXTERNAL  | zero                                     |
| calib_command.h, 780           | Host side crypto methods (atcah_), 325   |
| verify_other_data              | zone                                     |
| atca_sign_internal_in_out, 432 | atca_gen_dig_in_out, 417                 |

atca\_write\_mac\_in\_out, 439 atcacert\_device\_loc\_s, 448