

Sample Manual Page 1. The heater operates on 12V DC power and requires proper ventilation for safe operation. Always check the fuel line before ignition.

Sample Manual Page 2. Error code E3 indicates a flame sensor failure. Reset the heater by holding the power button for five seconds and try again.