4.2 BATTERY WIRING

Connect the house battery to the heater fuse block with 10 AWG wire.