

FS-1-WL Connection Guide

(Connecting to the Aerophone)

© 2023 Roland Corporation

02

This guide explains how you can use “MIDI over **Bluetooth®** Low Energy” to wirelessly pair (connect) the FS-1-WL to the Aerophone.

“Pairing” means registering a MIDI device with the FS-1-WL (making the two devices recognize each other).

After pairing, you can transmit and receive MIDI data between the FS-1-WL and your compatible device.

What is “MIDI over Bluetooth Low Energy”?

“MIDI over Bluetooth Low Energy” is the technology used to transmit and receive MIDI messages wirelessly via Bluetooth LE Standard.

Operating the FS-1-WL

Connecting the FS-1-WL to the Aerophone via Bluetooth lets you control various operations, such as switching between scenes using the pedal and so on.

Pairing with the FS-1-WL

MEMO

If Bluetooth has been deactivated on the Aerophone, set “Bluetooth” to “On” from the MENU.

- 1. Place the FS-1-WL near the Aerophone, and turn on the power with the FS-1-WL set to MIDI mode.**
- 2. Press the [Bluetooth] (INSTRUMENT) button on the FS-1-WL.**

The Bluetooth indicator on the FS-1-WL blinks white, and pairing begins.

When pairing is finished, the Bluetooth indicator on the FS-1-WL remains lit, and “MIDI Online” is shown on the Aerophone’s screen.



- * If the devices do not pair after one minute, pairing mode on the FS-1-WL is automatically canceled.
 - * The devices automatically reconnect next time they are restarted.
 - * For more about the FS-1-WL, refer to the “FS-1-WL Owner’s Manual” (Roland website), and “Using the FS-1-WL Editor” (Roland website).
- ➔ <https://www.boss.info/global/products/fs-1-wl/support/>

Using the Aerophone Pro Editor While Using the FS-1-WL

You can use the Aerophone along with the FS-1-WL and Aerophone Pro Editor. To use these devices and the software at the same time, you must follow the two steps shown below in order.

STEP 1: Connect the FS-1-WL to the Aerophone.

STEP 2: Connect the FS-1-WL to the Aerophone Pro Editor.

* This example shows the settings to make when using Aerophone Pro Editor with an iPhone.

- 1. Place the FS-1-WL near the Aerophone, and turn on the power with the unit set to MIDI mode.**
- 2. Press the [Bluetooth] (INSTRUMENT) button on the FS-1-WL.**

The [Bluetooth] (INSTRUMENT) indicator on the FS-1-WL blinks white, and pairing begins. When pairing is finished, the [Bluetooth] (INSTRUMENT) indicator on the FS-1-WL remains lit, and "MIDI Online" is shown on this unit's screen.



3. In your smartphone's settings, turn Bluetooth on.



4. Launch the Aerophone Pro Editor app that you installed on your smartphone.

5. Press the [Bluetooth] (Smartphone/PC) button on the FS-1-WL.

The unit enters pairing mode, and the [Bluetooth] (Smartphone/PC) indicator on the FS-1-WL blinks blue.

6. Start pairing from the Aerophone Pro Editor, and select "FS-1-WL+".

The [Bluetooth] (Smartphone/PC) indicator on the FS-1-WL lights up when pairing is completed. When the devices are correctly connected, their respective statuses are as follows.

FS-1-WL [Bluetooth] (INSTRUMENT) indicator	Lit white
FS-1-WL [Bluetooth] (Smartphone/PC) indicator	Lit blue
Aerophone Pro Editor device name	FS-1-WL+

* If the devices do not pair after one minute, pairing mode on the FS-1-WL is automatically canceled.

- * The Aerophone automatically connects to the FS-1-WL next time you launch them.
- * If the devices aren't connecting, unpair the Aerophone from your smartphone, unpair the FS-1-WL from your smartphone and go back to step 1.