

DigicoXSoundscape - User Manual

Version: 0.2.0-beta

Date: 10 S

1. Overview

DigicoXSoundscape is a bidirectional OSC bridge between a DiGiCo Quantum mixing console (External Control -> DiGiCo Pad) and a d&b audiotechnik DS100 Soundscape processor.

It maps DiGiCo Aux send levels to DS100 parameters such as:

- En-Space Send (per sound object / matrix input)

- Function

Optionally, the DiGiCo Aux Master fader and mute can control all four En-Space zone gains and mutes.

All continuous levels are clamped to -120.0 dB ... +10.0 dB.

2. System architecture

Setting | Meaning

DiGiCo IP

All three devices must share the same show network.

3. Installation

3.1 Download packages

From [GitHub Releases](<https://github.com/sergeXYZ/Digico-x-Soundscape/releases>):

Package | Platform | How to start

Digico-x-S

Web UI: <http://127.0.0.1:8765/>

3.2 macOS notes

- Unsigned binary: if Gatekeeper blocks it, right-click -> Open.

- Allow inc

3.3 Windows notes

- Portable package includes Python; first start runs a one-time setup.

- Allow inb

3.4 Linux / Raspberry Pi

```
sudo apt install python3 python3-venv python3-pip
```

```
chmod +x i
```

3.5 Run from source (developers)

```
cd Digico-x-Soundscape
```

```
python3 -m
```

4. DiGiCo console setup

1. Open Setup -> External Control.

2. Enable E

Example (common defaults):

Side | Port

Bridge liste

5. DS100 setup

- DS100 OSC ports are fixed:

- Bridge ->

6. Using the web UI

1. Start DigicoxSoundscape - the browser opens <http://127.0.0.1:8765/>

2. Configur

Status LEDs:

- Header: DiGiCo / DS100 RX & TX activity

- Per mapp

The Log section is collapsed by default; click Log to expand.

7. Mappings

Each mapping links one DiGiCo Aux to one DS100 parameter for every channel in Start-End.

7.1 En-Space Send

Direction | Behaviour

Digico Aux

7.2 Function Group Routing 1-32

Direction | Behaviour

Level | /dba

Click + Add Mapping for additional Aux -> parameter pairs. At least one mapping is required.

8. Aux Master -> En-Space Zones

Enable switch in the UI. When enabled for a chosen Aux Master:

Digico | DS100 (zones 1-4)

/Aux_Outp

Use this to ride overall En-Space zone level and mute from the Digico Aux master.

9. Polling

- Polling Interval (ms): 100-60000 (default 500).

- Only map

10. Settings file

Settings are saved to settings.json next to the application when you click Start.

11. Troubleshooting

Symptom | Check

No Digico a

12. License

MIT - see LICENSE in the repository.

DigicoxSoundscape - manual dated 10 September 2026.