

MEMORIZE THIS

Leakage limits: with the engine off and brakes released, under **2 psi/min** (single) or **3 psi/min** (combination). With the brakes applied, under **3 psi/min** (single) or **4 psi/min** (combination).

~125 / ~100

psi cut-out / cut-in

Governor stops the compressor at cut-out, restarts it at cut-in.

55

psi low-air warning

Light and buzzer must come on before pressure drops below this.

20–45

psi spring-brake apply

Parking/spring brakes come on automatically in this range.

Rate of air-pressure buildup

In a typical dual air system, pressure should build from **85 to 100 psi within about 45 seconds** with the engine at operating rpm. Slow buildup means the system may not keep up with heavy braking — get it fixed before driving.

TEST TIP

Two closing tests every examiner loves: the **parking-brake test** (in low gear, gently pull against the set parking brake — it must hold) and the **service-brake test** (roll at about 5 mph, apply firmly — no pulling to one side, no delay, no odd feel).