

# Miryoku Keyboard Layers

Page 1/2

Legend: Yellow background = Layer access key | Red dashed border = Combined thumb key

## TAP

Q	W	E	R	T
A	S	D	F	G
Z	X	C	V	B
SPACE TAB				
ESC				

Access: →TAP from other layers

Y	U	I	O	P
H	J	K	L	'
N	M	,	.	/
BSPC RET				
DEL				

## NUM

BOOT	→TAP	→EXT	→BASE	-
LCTRL	LALT	LGUI	LSHFT	-
-	→NUM	→NAV	RALT	-
-				
-				

Access: left outer

[	7	8	9	]
;	4	5	6	=
'	1	2	3	\
0	.			
-				

## SYM

{	&	*	(	)
:	\$	%	^	+
~	!	@	#	
)				
(				

Access: right inner

-	→BASE	→EXT	→TAP	BOOT
-	RSHFT	RGUI	LALT	RCTRL
-	→SYM	→MOUSE	RALT	-
-				
-				

## NAV

BOOT	→TAP	→EXT	→BASE	-
LCTRL	LALT	LGUI	LSHFT	-
-	RALT	→NUM	→NAV	-
-				
-				

Access: left inner

-	-	-	-	-
←	↓	↑	→	-
HOME	PgDn	PgUp	END	-
-				
-				

BSPC	RET
DEL	

# Miryoku Keyboard Layers

Page 2/2

Legend: Yellow background = Layer access key | Red dashed border = Combined thumb key

## BUTTON

RDO	UND	PST	CPY	CUT
LCTRL	LALT	LGUI	LSHFT	CPY
UND	CUT	CPY	PST	PST
BTN1      BTN2			BTN3	

CUT	CPY	PST	UND	RDO	
CPY	RSHFT	RGUI	LALT	RCTRL	
PST	PST	CPY	CUT	UND	
BTN2	BTN1	BTN3			

## MEDIA

BOOT	→TAP	→EXT	→BASE	-
LCTRL	LALT	LGUI	LSHFT	-
-	RALT	→FUN	→MEDIA	-
-			-	
-				

RGB_T	RGB_E	RGB_H+	RGB_S+	RGB_B+
EP_TOG	PREV	VOL-	VOL+	NEXT
OUT_T	BT0	BT1	BT2	BT3
STOP	PP	MUTE		

## FUN

BOOT	→TAP	→EXT	→BASE	-
LCTRL	LALT	LGUI	LSHFT	-
-	→NUM	→NAV	RALT	-
-			-	
-				

F12	F7	F8	F9	PrSc
F11	F4	F5	F6	SILk
F10	F1	F2	F3	Pause
-			-	
-				