



Reuse Offload Standard Operating Procedure (SOP)

All produced water traffic arriving at Gulfport locations receiving reuse water must follow the following SOP in order to promote a safe and efficient operation.

- 1) All traffic into the Gulfport reuse location shall follow the Traffic Control Plan (TCP) for the respective location and shall follow all posted speed limits.
- 2) Upon entering the authorized haul route, trucks should radio in on the designated CB channel of their position (utilizing the callout signs).
- 3) When space is verified at the offload station on the pad, driver shall proceed into the location at a speed not exceeding 5mph.
- 4) **Before backing into position, driver must verify that there are two spotters** (one in front; one in the rear) to assist in safe movement.
- 5) Once backed into the designated lane for offloading, driver shall set their brakes & await further instruction.
- 6) Offload station attendant will **review JSA & truck manifest** for verification prior to the driver exiting the vehicle.
- 7) Driver shall place **fire extinguisher at the front of the truck, catch pan at their pump, and wheel chocks.**
- 8) Offload station attendant will place a large cone with a flag at the front of the truck, designating that this truck is not to move. **Cone and flag shall only be moved by offload station attendant.**
- 9) Driver will connect hose and ground to truck.
- 10) Once verified by offload station attendant & driver, driver will open their valves and begin offloading. Driver is the only qualified persons to operate valves on their truck.
- 11) Once offload is complete, driver will disconnect hose and verify that all valves and caps on truck are in proper position.
- 12) Driver will complete a 360 walk around inspection and remove their fire extinguisher/catch pan/wheel chocks. **Note: Driver shall not go back into their vehicle to leave without first doing a 360 inspection.**
- 13) Offload station attendant will remove the flag in the front of the truck once verified that the driver is allowed pull away from the offload manifold and will escort the truck from its lane.
- 14) Follow TCP for exit from the Gulfport location.