

Eprad eCNA Cinema Automation Plugin

Version 1.1.1 | Build 35

Use this plugin to monitor and control an Eprad eCNA Cinema Automation system from within your Q-SYS designs. The plugin communicates over two independent channels: the CAI (Cinema Automation Interface) ASCII TCP protocol for commands and status, and a direct HTTP connection for I/O flag detail.

- [Compatibility](#)
- [Configuration Overview](#)
- [Properties](#)
- [Controls](#)
- [Input & Output Flag Names](#)
- [Control Pins](#)
- [Copyright](#)

Compatibility

This plugin was developed and tested with Q-SYS Designer Software version 9.x and Eprad eCNA firmware v1.23 and v1.26. It is designed to work with all eCNA models.

Note: The plugin communicates via the CAI TCP interface (default port 13002) and the eCNA HTTP web interface (port 80). Both must be reachable from the Q-SYS Core on your network. Because the eCNA supports only one CAI TCP connection per port at a time, avoid using the same port number in multiple concurrent designs.

Configuration Overview

Connect the Plugin

1. Drag the Eprad eCNA plugin into your Q-SYS schematic.
2. In the plugin Properties, configure the number of Macros and RDI devices for your installation.
3. Save the design to your Core and run (F5).
4. On the Setup page, enter the IP address of the eCNA and confirm the TCP Port (default 13002).

The plugin connects automatically once a valid IP address is entered. A Connection Status of **OK** confirms a successful connection.

Communication Architecture

The plugin uses two simultaneous communication channels:

- **CAI TCP (port 13002):** The primary control channel. Sends commands (EVT, OUT, RDI, MAC) and receives status responses (RST, RID) and unsolicited event reports (RPT,EVT). Polled at the RST Poll

Rate interval as a safety net; most status updates arrive as unsolicited events. Only one device may have a port open at a time.

- **HTTP (port 80):** A secondary read-only channel for I/O flag detail, providing the state of all 44 output flags and 31 input flags, including house lights, curtain, masking, lens, sound, and aux outputs. Polled independently at the Web Scrape Rate.

Note: The HTTP scrape does not consume a CAI port. Multiple Q-SYS designs can scrape the eCNA web interface simultaneously without conflict. Only the CAI TCP connection is exclusive per port.

Unsolicited Event Reports

The plugin subscribes to unsolicited event reports from the eCNA (CFG, RPTON) on connection. The eCNA sends RPT, EVT messages when key state changes occur (START, STOP, CUE, projector power changes, fire stop, etc.). The plugin triggers an immediate RST status re-poll on receipt of these events, providing near-instant UI updates without relying solely on the poll timer.

Properties

Num Macros

Integer, 0–50 (default 50). Sets the number of Macro trigger buttons available on the Macros tab. Set to 0 to hide the Macros tab entirely.

Num RDI

Integer, 0–5 (default 5). Sets the number of RDI (Remote Device Interface) devices. Each device has 16 command buttons. Set to 0 to hide the RDI tab entirely.

Poll Rate

Integer, 1–60 seconds (default 30). Interval in seconds between RST status poll commands sent over the CAI TCP connection. Because the plugin subscribes to unsolicited event reports, most real-time updates arrive without waiting for this timer. This rate primarily serves as a safety net to correct any state drift. Values of 30–60 seconds are appropriate for production use.

Scrape Rate

Integer, 1–60 seconds (default 3). Interval in seconds between HTTP requests to the eCNA web interface for I/O flag detail. This is the primary update mechanism for the output and input flag indicators (house lights, curtain, masking, lens, sound, aux outputs, and input flags). Values below 3 seconds may interfere with direct operation of the eCNA device. The original script used 1.3 seconds; 3 seconds is recommended.

Auto Refresh Names

Boolean (default on). When enabled, the plugin periodically re-fetches input and output flag names from the eCNA web interface, alternating between the two pages roughly every 30 seconds so each page refreshes approximately once per minute. Disable this if you do not want background name refreshes;

names will still be fetched once on initial connection. Names can always be refreshed manually using the buttons on the Inputs and Outputs pages.

Controls

Setup Page

IP Address

Text entry. Enter the IP address of the eCNA. The plugin connects automatically when a valid address is entered or changed.

TCP Port

Text entry. The CAI TCP port number (default 13002). Change this to match the CAI channel assigned to this Q-SYS design. Common values: 13000 (channel 1), 13001 (channel 2), 13002 (channel 3), 13003 (channel 4).

Note: Port 13003 (channel 4) requires eCNA firmware version 1.25 or later.

Status LED / Status

Indicator LED and text field, read only. Displays the current connection state:

- **OK** (green): Connected and communicating.
- **Initializing** (blue): Connecting or establishing initial communication.
- **Disconnected / Fault** (red): Connection lost or error received.
- **Missing** (orange): No IP address configured.

Reconnect

Trigger button. Forces an immediate reconnection attempt. Useful if the connection has stalled, the IP address was changed, or the port was changed. Note: changing the TCP Port does not take effect until Reconnect is pressed.

Model

Text field, read only. Displays the eCNA device model returned by the RID command on connection.

Firmware

Text field, read only. Displays the eCNA firmware version returned by the RID command.

Outputs Page

The Outputs page contains all eCNA output controls, grouped by type. Toggle buttons both send commands to the eCNA and reflect the current output state as returned by the web scrape.

Digital Projectors (Dig Proj1 Power, Dig Proj1 Video, Dig Proj2 Power, Dig Proj2 Video, Slide Projector)

Toggle buttons. Control and indicate the power and video output state of the two digital projectors and the slide/auxiliary projector. State is updated from the web scrape (flags 1–4, 19).

House Lights

Mutually exclusive Toggle buttons: None / Down / Mid1 / Mid2 / Up. Sends OUT HLxxx commands. State updated from scrape flags 5–8.

Stage Lights

Mutually exclusive Toggle buttons: None / Down / Up. Sends OUT SLxxx commands. State updated from scrape flags 9–10.

Curtain

Mutually exclusive Toggle buttons: None / Close / Open. Sends OUT CURTxxx commands. State updated from scrape flags 11–12.

Masking

Mutually exclusive Toggle buttons: None / Flat / Scope / Special. Sends OUT MSKxxx commands. State updated from scrape flags 13–15.

Lens

Mutually exclusive Toggle buttons: None / Flat / Scope / Special. Sends OUT LENxxx commands. State updated from scrape flags 16–18.

Sound

Mutually exclusive Toggle buttons: None / Aux1 / Aux2 / Dig1 / Dig2 / Mono / NonSync / SR / SVA. Sends OUT SNDxxx commands. State updated from scrape flags 20–28.

Mute

Independent Toggle button. Sends OUT MUTEON or OUT MUTEOFF. State updated from scrape flag 25.

Aux Output Flags 1–16

Toggle buttons arranged in two columns of eight. Each row shows the flag number (Out 1–Out 16), the toggle button, and the user-defined name fetched from the eCNA. Send OUT OUTnON/OFF commands. State updated from scrape flags 29–44.

Note: Names refer to Output Flag names as configured in the eCNA web interface, not physical output names on any I/O board.

Refresh Output Names

Trigger button. Immediately refreshes the current output flag names from the eCNA. The names will update within a few seconds. Available regardless of the Auto Refresh Names property setting.

Inputs Page

Displays all 31 eCNA input flags as LED indicators. Two columns: General Inputs (In1–In16) on the left and System Inputs on the right. Each General Input row shows the LED, the flag number (In1–In16), and the user-defined name fetched from the eCNA.

Note: Names refer to Input Flag names as configured in the eCNA web interface, not physical input names on any I/O board. Input flags are read-only indicators; they cannot be set from the plugin.

Refresh Input Names

Trigger button. Immediately refreshes the current input flag names from the eCNA. The names will update within a few seconds. Available regardless of the Auto Refresh Names property setting.

Macros Page

Visible only when Num Macros is greater than 0. Contains trigger buttons for Macros 1 through N, arranged 10 per row. Each press sends EVT MAC , n to the eCNA. Text labels appear above each button.

RDI Page

Visible only when Num RDI is greater than 0. Contains trigger buttons for up to 5 RDI (Remote Device Interface) devices, each with 16 commands (labelled RDI 1-1 through RDI 5-16), arranged in two rows of 8 per device. Each press sends EVT RDI , device , command to the eCNA. Text labels appear above each button.

Program Page

Transport Controls (Start, Stop, Cue, Abort)

Trigger buttons. Send EVT STA, EVT STP, EVT CUE, and EVT ABT commands respectively.

Fault Controls (Set Fault, Clear Fault, Reset Fault, Cancel Alarm)

Trigger buttons. Send EVT FLT, EVT CLR, EVT RES, and EVT CNL commands respectively.

Program # / Set Prog / Set & Run

Combo box and trigger buttons. Select a program number (1–9) and press Set Prog to send EVT PGM , n, or Set & Run to send EVT SPR , n (set and immediately start).

Control State

Text field, read only. Displays the current control state from the RST response: **IDL** (idle) or **RUN** (running).

Stopped State

Text field, read only. Displays the stopped state: **OK**, **STP** (stopped), **FLT** (fault), or **FIR** (fire stop active).

Cue Number

Text field, read only. Displays the current cue number within the running program.

Program Number

Text field, read only. Displays the currently active program number.

Segment Name

Text field, read only. Displays the name of the current program segment.

Segment Index

Text field, read only. Displays the current segment index within the program.

CMD Access

Text field, read only. Displays the CAI command access status: **OK** (full access) or **BLK** (blocked — the eCNA is not accepting CAI commands).

Input & Output Flag Names

Version 1.1 adds the ability to display user-defined names for the 16 General Input flags (In1–In16) and the 16 Aux Output flags (Out1–Out16). These names are configured on the eCNA web interface under Setup → Input Flag Names and Setup → Output Flag Names.

How Names Are Fetched

Input and output flag names are retrieved automatically from the eCNA on initial connection. When Auto Refresh Names is enabled, names are refreshed approximately once per minute in the background with minimal impact on normal operation.

Manual Refresh

The Refresh Input Names button on the Inputs page and the Refresh Output Names button on the Outputs page each immediately refresh the relevant names from the eCNA, typically appearing within a few seconds. These buttons work regardless of the Auto Refresh Names setting.

Where Names Appear

- **Inputs page:** Each General Input row (In1–In16) shows the LED indicator, the flag number label, and the user-defined name in a text field alongside it.
- **Outputs page:** Each Aux Output Flag row shows the flag number, the toggle button, and the user-defined name in a text field to the right of the button.
- **Control pins:** In Names 1–16 and Out Names 1–16 expose the names as readable output pins for use elsewhere in the Q-SYS design.

Note: Names reflect the flag names as configured in the eCNA, not the physical label on any I/O board terminal. The eCNA supports up to 14 characters per name.

Control Pins

The following table lists the control pins available when this plugin is used in a Q-SYS schematic. All pins are optional; connect only those required by your design.

Pin Name	Value	String	Position	Direction
Setup				
IP Address		(text)		Input
TCP Port		(text)		Input
Connection Status	0	OK (Green)	—	Output
	1	Compromised (Yellow)		
	2	Fault (Red)		
	3	Not Present (Grey)		

Pin Name	Value	String	Position	Direction
	4 5	Missing (Orange) Initializing (Blue)		
Status LED	0–5	(same as Status)	—	Output
Connected	0 / 1	Off / On	0 / 1	Output
Reconnect	trigger	—	—	Input
Model		(text)		Output
Firmware Version		(text)		Output
Program State				
Control State		IDL / RUN		Output
Stopped State		OK / STP / FLT / FIR		Output
Cue Number		(text)		Output
Program Number		(text)		Output
Segment Name		(text)		Output
Segment Index		(text)		Output
CAI CMD Access		OK / BLK		Output
Transport Commands				
Cmd Start	trigger	—	—	Input
Cmd Stop	trigger	—	—	Input
Cmd Cue	trigger	—	—	Input
Cmd Abort	trigger	—	—	Input
Cmd Fault	trigger	—	—	Input
Cmd Clear Fault	trigger	—	—	Input
Cmd Reset	trigger	—	—	Input
Cmd Cancel Alarm	trigger	—	—	Input
Set Program		(text / combo box, 1–9)		Input
Cmd Set Program	trigger	—	—	Input
Cmd Set And Run	trigger	—	—	Input
Macros (1 – Num Macros)				
Macros 1 ... Macros N	trigger	—	—	Input
RDI (1 – Num RDI × 16)				
RDI 1 ... RDI 80	trigger	—	—	Input
Outputs				
House Lights 1–5 (1=None 2=Down 3=Mid1 4=Mid2 5=Up)	0 / 1	Off / On	0 / 1	Input / Output
Stage Lights 1–3 (1=None 2=Down 3=Up)	0 / 1	Off / On	0 / 1	Input / Output
Curtain 1–3 (1=None 2=Close 3=Open)	0 / 1	Off / On	0 / 1	Input / Output
Masking 1–4 (1=None 2=Flat 3=Scope 4=Special)	0 / 1	Off / On	0 / 1	Input / Output
Lens 1–4 (1=None 2=Flat 3=Scope 4=Special)	0 / 1	Off / On	0 / 1	Input / Output
Sound 1–9 (1=None 2=Aux1 3=Aux2 4=Dig1)	0 / 1	Off / On	0 / 1	Input / Output

Pin Name	Value	String	Position	Direction
5=Dig2 6=Mono 7=NonSync 8=SR 9=SVA)				
Mute	0 / 1	Off / On	0 / 1	Input / Output
Dig1 Power	0 / 1	Off / On	0 / 1	Input / Output
Dig1 Video	0 / 1	Off / On	0 / 1	Input / Output
Dig2 Power	0 / 1	Off / On	0 / 1	Input / Output
Dig2 Video	0 / 1	Off / On	0 / 1	Input / Output
Aux Projector (Slide Projector)	0 / 1	Off / On	0 / 1	Input / Output
Aux Out 1–16	0 / 1	Off / On	0 / 1	Input / Output
Input & Output Flag Names				
In Names 1–16	(text — user-defined name for In1–In16)			Output
Out Names 1–16	(text — user-defined name for Out1–Out16)			Output
Refresh Input Names	trigger	—	—	Input
Refresh Output Names	trigger	—	—	Input

Copyright

MIT License

Copyright © 2026 Jay Wyatt and Steven Guttag

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.