

Nexa HomeHub Pro

Product ID: NEX-P2001 | Professional automation gateway | Overview and Setup

Product overview

HomeHub Pro is a local-first automation gateway for larger homes and small offices. It coordinates Wi-Fi, Zigbee, Thread, and Matter accessories, keeps essential routines running during an internet outage, and exposes a role-based management console for administrators.

Core capabilities

- Supports up to 180 connected accessories across 25 rooms or zones.
- Runs scheduled, sensor-driven, and conditional routines locally.
- Provides three administrator accounts and up to 20 standard household or staff profiles.
- Stores 30 days of local activity history with optional encrypted cloud backup.

Installation and first configuration

1. Connect the gateway to the supplied power adapter and wired Ethernet when available.
2. Wait for the status bar to become solid white, then open the Nexa Admin app on the same network.
3. Create the owner account, apply the device update, and set the local time zone before adding accessories.
4. Create rooms, then enroll devices one at a time and label each device by physical location.

Environment and operational requirements

A broadband connection is required for remote access and updates. A wired Ethernet connection is recommended for installations with more than 60 devices. Keep the gateway in a central, ventilated location, away from metal cabinets and large appliances.

Nexa HomeHub Pro

Product ID: NEX-P2001 | Professional automation gateway | Operation, Maintenance, and Troubleshooting

How to use and operate

- Use the Dashboard to see online devices, active routines, alerts, and recent administrator actions.
- Build a routine by choosing a trigger, optional conditions, then one or more actions. Test it before enabling it for all users.
- Assign roles from Users. Standard users can control devices but cannot change network, security, or billing settings.
- Export diagnostic logs from Support when troubleshooting with an administrator or service provider.

Preventive maintenance

- Review firmware updates monthly and install them during a low-use period.
- Check the device-health page after adding a large group of accessories.
- Back up configuration before resetting the gateway or changing the network.

Error codes and recommended resolution

P201: Gateway cannot reach cloud services.

Confirm internet access, DNS availability, and outbound HTTPS access; local routines can continue while cloud access is restored.

P214: Mesh capacity warning.

Move heavily used devices closer to powered repeaters or split devices between zones.

P227: Administrator authentication blocked.

Wait 15 minutes after repeated failed sign-ins, then reset the account password from the verified owner email.

P241: Configuration backup failed.

Check available storage and confirm the backup passphrase has not changed.

P255: Local automation engine restarted.

Review the activity log, install pending updates, and contact support if restarts repeat.

Nexa SecureCam Pro

Product ID: NEX-P2002 | 4K security camera system | Overview and Setup

Product overview

SecureCam Pro is a 4K indoor or sheltered-outdoor camera with person, vehicle, and package detection. It supports privacy zones, encrypted local recording, and a continuous live view for administrators who need a dependable front entrance, warehouse, or office monitoring point.

Core capabilities

- 4K video with HDR, infrared night vision, and two-way audio.
- Configurable motion zones, privacy masks, and detection confidence settings.
- Continuous recording to a compatible local recorder plus optional cloud event backup.
- Administrator-only export, retention, and user-access controls.

Installation and first configuration

1. Choose a mounting point with a clear view, stable Wi-Fi or Ethernet coverage, and no direct glare from lights.
2. Mount the camera, connect power or PoE, then add it in the Nexa Admin app.
3. Update firmware before enabling continuous recording or sharing camera access.
4. Draw privacy masks first, then define motion zones and test alerts during daylight and night conditions.

Environment and operational requirements

For 4K continuous recording, use wired Ethernet or a strong Wi-Fi 6 connection and a compatible Nexa Recorder Pro. Do not point the camera at public areas where recording is restricted. Follow local laws and workplace notice requirements before use.

Nexa SecureCam Pro

Product ID: NEX-P2002 | 4K security camera system | Operation, Maintenance, and Troubleshooting

How to use and operate

- Use Live View for a current image and Events for detections organized by time, camera, and type.
- Set person detection for entrances; use vehicle detection only where vehicles remain visible long enough for reliable classification.
- Export an event clip with its timestamp and camera name when it must be reviewed outside the system.
- Audit shared access monthly and remove former users immediately.

Preventive maintenance

- Clean the lens with a dry microfiber cloth; do not use abrasive cleaner.
- Inspect mounts, weather seals, and cable strain relief every three months.
- Review storage retention and verify a recent test recording can be played back.

Error codes and recommended resolution

P301: Video stream unavailable.

Check camera power, network link, and recorder availability; restart the camera only after saving diagnostic logs.

P318: Low-light image degraded.

Clean the lens, remove nearby reflective surfaces, and verify the night-vision setting is Auto.

P326: Recording storage nearly full.

Confirm the retention policy, archive required clips, or increase recorder capacity.

P337: Privacy zone overlaps detection zone.

Redraw the two zones so detection does not rely on masked pixels.

P349: Time synchronization failed.

Verify the gateway's time zone and internet time access, then restart the camera connection.

Nexa ClimateControl Pro

Product ID: NEX-P2003 | Zoned HVAC controller | Overview and Setup

Product overview

ClimateControl Pro manages compatible multi-zone HVAC systems for small commercial spaces and large residences. It combines schedules, occupancy signals, temperature sensors, and equipment safeguards to maintain comfort while giving administrators a clear view of runtime and alert history.

Core capabilities

- Up to eight temperature zones with individual schedules and override limits.
- Supports heating, cooling, ventilation, humidity targets, and demand-response events.
- Equipment protection timers reduce short cycling and preserve compressor life.
- Exports runtime and temperature trend data for energy reviews.

Installation and first configuration

1. Turn off HVAC power at the service breaker and document all existing wire labels.
2. Install the controller and remote zone sensors according to the wiring guide for the supported equipment.
3. Restore power, run the equipment compatibility test, then verify each zone sensor against a room thermometer.
4. Set normal occupancy hours and safe minimum/maximum limits before allowing users to adjust setpoints.

Environment and operational requirements

Installation must be performed by a qualified technician when equipment wiring or high-voltage components are involved. The controller requires a stable 24V control circuit and a wired or approved wireless network connection.

Nexa ClimateControl Pro

Product ID: NEX-P2003 | Zoned HVAC controller | Operation, Maintenance, and Troubleshooting

How to use and operate

- Use Zones to view the current temperature, mode, setpoint, and sensor health for each area.
- Create schedules with an occupied setpoint, an unoccupied setback, and a preconditioning time.
- Use temporary override for short comfort changes; the system returns to schedule automatically.
- Review runtime trends before changing setpoints, because a long runtime may indicate a mechanical issue rather than a scheduling issue.

Preventive maintenance

- Review filter reminders and equipment alerts at least monthly.
- Confirm sensor batteries and placement after any office layout change.
- Have a technician inspect recurring high-runtime or short-cycle alerts.

Error codes and recommended resolution

P401: Zone sensor offline.

Check sensor power or battery, then verify it is within approved wireless range.

P417: Compressor safety delay active.

Wait for the configured protection timer; do not repeatedly change modes during the delay.

P428: Heating and cooling demand conflict.

Review zone schedules and deadband settings; request technician support if the conflict persists.

P436: Humidity target unavailable.

Confirm compatible humidification equipment is configured for the selected zone.

P452: Equipment response timeout.

Check breaker, thermostat wiring, and service status; contact a qualified HVAC technician.

Nexa PowerStation Pro

Product ID: NEX-P2004 | Managed power and UPS unit | Overview and Setup

Product overview

PowerStation Pro is a rack or desk-mountable managed power unit with battery backup, metered outlets, and remote restart controls. It protects networking, recording, and automation equipment while reporting load, battery health, and power events to the Nexa Admin console.

Core capabilities

- Eight individually controlled AC outlets with per-outlet current monitoring.
- Integrated UPS for orderly shutdown during a short power outage.
- Configurable startup sequence to prevent inrush current.
- Power-event history, battery-health report, and remote restart permission controls.

Installation and first configuration

1. Mount the unit with clear ventilation and plug it directly into a properly grounded wall outlet.
2. Connect critical equipment first, then label each outlet in the Admin app.
3. Set the shutdown order for servers, recorders, and network equipment before enabling automatic actions.
4. Run a controlled battery test after installation and record the expected backup duration.

Environment and operational requirements

Do not connect heaters, large motors, refrigerators, or other high-wattage appliances. The total connected load must remain below the rated capacity. Battery replacement should use only the specified compatible pack.

Nexa PowerStation Pro

Product ID: NEX-P2004 | Managed power and UPS unit | Operation, Maintenance, and Troubleshooting

How to use and operate

- Use the Power tab to review load, estimated runtime, outlet status, and recent events.
- Set a staged startup so network gear is online before dependent devices restart.
- Use Remote Restart only for equipment that can safely restart without local confirmation.
- After an outage, review the event log and confirm every critical outlet returned to the intended state.

Preventive maintenance

- Run a battery self-test quarterly and replace the battery when capacity falls below the recommended threshold.
- Keep ventilation openings dust-free and confirm the unit has no unusual heat or smell.
- Review surge-protection status after a major electrical event.

Error codes and recommended resolution

P501: Load exceeds safe threshold.

Move noncritical equipment to another circuit and reduce load before resetting the unit.

P516: Battery replacement required.

Schedule a replacement with the approved battery pack; backup runtime is no longer guaranteed.

P523: Outlet restart denied.

Sign in with an administrator role or request permission from the system owner.

P539: Ground fault detected.

Disconnect equipment and have the electrical installation inspected by a qualified electrician.

P547: UPS runtime estimate unavailable.

Run a battery self-test and confirm that the current load is within the supported range.

Nexa CleanBot Pro

Product ID: NEX-P2005 | Autonomous floor-care robot | Overview and Setup

Product overview

CleanBot Pro is a commercial-style autonomous floor-care robot for hard floors and low-pile carpet. It uses structured maps, access permissions, and maintenance reporting to clean offices, studios, and large homes while avoiding restricted areas and scheduling around occupied periods.

Core capabilities

- Multi-floor maps with named zones, no-go areas, and room-by-room schedules.
- High-capacity bin, washable filter, and automatic return-to-dock charging.
- Obstacle detection, edge cleaning, and quiet operating mode.
- Administrator dashboard for runtime, maintenance, and task-completion reports.

Installation and first configuration

1. Place the dock on a level wall with a clear approach path and reliable network coverage.
2. Charge the robot fully, then create a mapping run for each floor without people or loose objects in the path.
3. Name zones carefully and mark restricted areas, stairs, wet zones, and locations with loose cables.
4. Set operating windows that avoid meetings, sleeping hours, or high foot traffic.

Environment and operational requirements

Use only on dry, indoor floors. Remove cords, small toys, fragile objects, and loose rugs before a first run. The robot is not a substitute for spill response; wet or hazardous areas must be cleaned manually first.

Nexa CleanBot Pro

Product ID: NEX-P2005 | Autonomous floor-care robot | Operation, Maintenance, and Troubleshooting

How to use and operate

- Choose a whole-floor task for routine coverage or select zones for targeted cleaning.
- Review the map after a layout change and run a short remapping task where furniture moved.
- Use Quiet mode for occupied spaces; use Standard mode for deeper daily cleaning.
- Confirm the task summary after each scheduled run and inspect repeated missed-area alerts.

Preventive maintenance

- Empty the bin after major runs and clean the main brush weekly.
- Wash and fully dry the filter according to the maintenance prompt.
- Inspect wheel wells, sensors, and charging contacts every month.

Error codes and recommended resolution

P601: Navigation blocked.

Remove the obstruction, return the robot to clear floor, and resume the task.

P617: Map confidence low.

Run a new mapping pass with doors open and the floor clear of temporary obstacles.

P625: Dock contact failure.

Clean the robot and dock contacts with a dry cloth and check dock power.

P638: Bin or filter service required.

Empty the bin and clean or replace the filter before continuing.

P646: Restricted zone crossed.

Review the saved map boundary and update it to cover the full restricted area.

Nexa WaterGuard Pro

Product ID: NEX-P2006 | Leak detection and shutoff controller | Overview and Setup

Product overview

WaterGuard Pro is a monitored water-protection system for homes, offices, and small facilities. It combines leak sensors, flow monitoring, and a compatible automatic shutoff valve to detect likely leaks early, alert responsible users, and reduce damage when a verified incident occurs.

Core capabilities

- Supports up to 60 wireless leak and temperature sensors.
- Flow pattern analysis identifies sustained unexpected water use.
- Optional automatic shutoff with manual override and maintenance mode.
- Escalating alerts by app notification, email, and selected administrator roles.

Installation and first configuration

1. Have a qualified plumber install the compatible shutoff valve on the main supply line.
2. Place leak sensors near appliances, sinks, water heaters, and other likely leak points with contacts flat on a dry surface.
3. Add sensors in the Admin app and label them with exact physical locations.
4. Run a supervised valve test, then document the manual override procedure for occupants.

Environment and operational requirements

Automatic shutoff must be enabled only after the plumbing layout and operational needs are understood. Do not enable unattended shutoff for life-safety systems, fire suppression, or equipment that requires continuous water without professional review.

Nexa WaterGuard Pro

Product ID: NEX-P2006 | Leak detection and shutoff controller | Operation, Maintenance, and Troubleshooting

How to use and operate

- Treat a confirmed water alert as urgent: inspect the named location before dismissing it.
- Use Flow History to distinguish normal scheduled use from unusual sustained flow.
- Use Maintenance Mode before planned plumbing work so alarms and shutoff actions are temporarily suppressed.
- After a shutoff event, resolve the cause, dry sensors, inspect the property, then restore water deliberately.

Preventive maintenance

- Test one sensor and the alert path monthly; test the valve on the maintenance schedule set by the installer.
- Replace sensor batteries as indicated, not one at a time after a critical low-battery alert.
- Review alert recipients quarterly and remove outdated contacts.

Error codes and recommended resolution

P701: Active water detected.

Inspect the named location immediately, stop the source if safe, dry the sensor, and reset only after verification.

P713: Valve did not reach closed position.

Use the manual override if needed and contact a qualified plumber to inspect the valve.

P726: Unusual flow pattern detected.

Check fixtures and appliances for continuous use, then review the flow history before enabling automatic shutoff.

P734: Sensor communication degraded.

Replace the battery, move the gateway or add an approved repeater, then retest.

P748: Maintenance mode expired.

Confirm plumbing work is complete and re-enable protection from the Admin app.