

Nexa HomeHub Mini

Product ID: NEX-1001 | Category: Smart-home voice hub

Description

- A compact Wi-Fi hub that brings compatible lights, plugs, sensors, and routines into one voice-controlled dashboard. It supports room-based controls and scheduled automations for a small home or apartment.

Key features

- 2.4 GHz Wi-Fi setup with Bluetooth-assisted pairing.
- Voice commands, mobile dashboard, and routines.
- Up to 40 compatible devices on a single home profile.

Setup

- Connect the supplied USB-C power cable and wait for the status ring to pulse blue.
- Open the Nexa Home app, choose Add Device, and scan the QR code on the base.
- Join a 2.4 GHz network, assign a room, then add compatible devices from the Devices tab.

How to use

- Say a command such as 'Turn on living room lights,' or select a room in the app.
- Create routines from Automations; for example, turn lights off at 11:00 PM.
- Check the dashboard activity log when a routine did not run as expected.

Error codes and resolutions

E101: Wi-Fi connection failed.

Confirm a 2.4 GHz network is available, move closer to the router, then restart setup.

E118: Device limit reached.

Remove an unused accessory or create a separate home profile.

E201: Voice service unavailable.

Verify internet access and restart the HomeHub from Settings > System.

Nexa AirSense

Product ID: NEX-1002 | Category: Indoor air-quality monitor

Description

- A desktop monitor that tracks temperature, humidity, PM2.5 particles, and carbon dioxide trends. It gives plain-language alerts and can trigger compatible fans or purifiers through a connected HomeHub.

Key features

- Color-coded air-quality indicator with five-minute updates.
- Seven-day in-app history and threshold alerts.
- USB-C powered; optional HomeHub automation support.

Setup

- Place the unit on a stable shelf away from windows, vents, and direct sunlight.
- Connect power, then add AirSense from the Nexa Home app.
- Allow 20 minutes for the first sensor calibration before reviewing readings.

How to use

- Read the front display for a quick air-quality status.
- Use History in the app to compare daily or weekly changes.
- Set alerts for a preferred PM2.5 or CO2 level, then review the suggested action.

Error codes and resolutions

E301: Sensor warming up.

Wait 20 minutes after power-on; readings are not final during warm-up.

E312: Particle sensor blocked.

Gently clean the side intake with a dry soft brush and restart the unit.

E325: Calibration failed.

Move the monitor to fresh indoor air, power-cycle it, and run calibration again.

Nexa Glow Bulb A19

Product ID: NEX-1003 | Category: Tunable smart LED bulb

Description

- An energy-efficient A19 LED bulb with adjustable brightness and white color temperature. It is designed for lamps and standard indoor fixtures, with controls from the Nexa Home app, schedules, or a paired HomeHub.

Key features

- 800-lumen output with warm-to-cool white adjustment.
- Dimmable in the app without a separate dimmer switch.
- Schedules, room groups, and energy-use estimates.

Setup

- Turn off fixture power, install the bulb, then restore power.
- Wait for the bulb to blink twice, then select Add Device in the app.
- Name the bulb and assign it to a room before creating schedules.

How to use

- Use the Brightness slider for light level and the Temperature slider for tone.
- Group bulbs by room to control several fixtures together.
- Use a wake-up routine to increase brightness gradually in the morning.

Error codes and resolutions

E401: Bulb not discovered.

Cycle fixture power three times, wait for a blink, and begin pairing again.

E407: Unsupported wall dimmer detected.

Use a standard on/off switch; do not place the bulb on a legacy dimmer.

E415: Firmware update interrupted.

Keep power on, remain on Wi-Fi, and retry the update from Device Settings.

Nexa SecureCam Door

Product ID: NEX-1004 | Category: Battery video doorbell

Description

- A weather-resistant video doorbell with motion alerts, two-way audio, local event history, and optional cloud backup. It is intended for a front door or protected outdoor entrance with a reliable Wi-Fi signal.

Key features

- 1080p live video, night vision, and adjustable motion zones.
- Rechargeable battery with low-battery notifications.
- Two-way talk from the Nexa Home mobile app.

Setup

- Charge the unit fully before mounting it at chest height beside the door.
- Add SecureCam in the app while standing near the installation location.
- Set motion zones to exclude public roads or constantly moving trees.

How to use

- Tap a notification to open live view or speak with a visitor.
- Review Events to see clips sorted by date and motion type.
- Charge when the app reports 20 percent battery or less.

Error codes and resolutions

E501: Camera offline.

Check Wi-Fi strength at the door, then press and hold the side button for 10 seconds.

E514: Storage unavailable.

Confirm the local storage card is inserted correctly or free space in cloud storage.

E527: Motion zone invalid.

Redraw the zone so it remains inside the visible camera frame.

Nexa BrewMate

Product ID: NEX-1005 | Category: Connected coffee maker

Description

- A programmable drip coffee maker that prepares scheduled brews and sends maintenance alerts to the Nexa Home app. It supports a thermal carafe, strength selection, and a water-level check before a scheduled start.

Key features

- 1.2-liter thermal carafe and three brew-strength settings.
- Scheduled start with water and carafe safety checks.
- Cleaning reminders and brew-history counter.

Setup

- Rinse the removable filter basket and run one water-only cycle.
- Add BrewMate in the app while the machine is powered on.
- Set local time, preferred strength, and a default weekday schedule.

How to use

- Fill the reservoir, insert a filter and grounds, then choose Brew Now.
- For a schedule, prepare ingredients first and confirm the app's readiness notice.
- Run the guided cleaning cycle when the maintenance alert appears.

Error codes and resolutions

E601: Water level too low.

Fill the reservoir above the minimum mark, then start the brew again.

E609: Carafe not detected.

Center the carafe on the warming plate and clean any spilled liquid beneath it.

E618: Descale required.

Run the guided descale cycle before scheduling another brew.

Nexa PowerStrip Pro

Product ID: NEX-1006 | Category: Surge-protected smart power strip

Description

- A six-outlet smart power strip with individually controlled outlets, energy monitoring, and surge protection. It is useful for desks, media centers, or small appliance stations where scheduled shutoff can reduce standby consumption.

Key features

- Six controlled outlets and two USB-C charging ports.
- Per-outlet naming, schedules, and energy usage totals.
- Built-in overload and surge status indicator.

Setup

- Plug the strip directly into a wall outlet; do not connect it to another power strip.
- Add PowerStrip Pro from the app and label each outlet by the connected device.
- Set an off schedule only for equipment that can safely lose power.

How to use

- Toggle individual outlets from the app or add them to routines.
- Review energy totals to identify devices with high standby use.
- Press the physical main button once to turn all controlled outlets off.

Error codes and resolutions

E701: Overload protection active.

Unplug high-wattage devices, wait one minute, then press Reset.

E716: Outlet unavailable.

Turn the outlet on in the app and inspect the connected device's own power switch.

E724: Surge protection expired.

Replace the power strip; its protection components are no longer reliable.

Nexa ThermoDial

Product ID: NEX-1007 | Category: Smart thermostat controller

Description

- A wall-mounted thermostat controller for compatible heating and cooling systems. ThermoDial supports temperature schedules, occupancy-aware setbacks, and clear system status messages in the Nexa Home app.

Key features

- Heating, cooling, and fan schedules with manual override.
- Energy report with setpoint and runtime trends.
- Compatible with common 24V HVAC installations.

Setup

- Turn off HVAC power at the breaker before replacing an existing thermostat.
- Match labels from the old terminals to the in-app wiring guide.
- Restore power, complete the compatibility check, and set home/away temperatures.

How to use

- Turn the dial for a temporary temperature change.
- Set schedules from Climate > Schedule and confirm the selected system mode.
- Use Away mode when the home will be empty for an extended period.

Error codes and resolutions

E801: Wiring check failed.

Turn off breaker power and verify wire labels against the installation guide.

E813: System not responding.

Wait five minutes for HVAC safety delay, then check the indoor unit breaker.

E829: Temperature sensor mismatch.

Remove the front cover, reseal it firmly, and run Sensor Check in Settings.

Nexa CleanBot S2

Product ID: NEX-1008 | Category: Robot vacuum cleaner

Description

- A compact robot vacuum that maps hard floors and low-pile carpets, supports room cleaning, and returns to its charging dock automatically. It includes a washable dustbin filter and app-based cleaning history.

Key features

- Room map, no-go zones, and scheduled cleaning.
- Auto-return charging dock and edge-cleaning brush.
- Washable dustbin filter with replacement reminder.

Setup

- Place the dock against a clear wall with open space on both sides.
- Charge the robot fully, then start a Mapping Run from the app.
- Name rooms after the map is saved and add no-go zones for cables or pet bowls.

How to use

- Choose Clean All for the full map or select one or more rooms.
- Empty the dustbin after each major clean for best suction.
- Clean the brush and filter when the maintenance reminder appears.

Error codes and resolutions

E901: Robot stuck.

Move the robot to clear floor, remove nearby cables, then tap Resume.

E914: Dock not found.

Check dock power and ensure the approach path is not blocked.

E922: Brush jam detected.

Turn off the robot and remove hair or thread from the main brush and end caps.

Nexa SafeLock

Product ID: NEX-1009 | Category: Keypad smart door lock

Description

- A keypad smart lock for a standard residential deadbolt. It offers temporary entry codes, auto-lock timing, activity history, and an emergency mechanical key. It should be installed only on a correctly aligned door.

Key features

- Up to 30 entry codes with optional expiration dates.
- Auto-lock timer and door-ajar reminder.
- Physical key override and battery-level alerts.

Setup

- Install with the door open and confirm the bolt moves freely by hand.
- Pair the lock in the app, then create an owner code and a backup code.
- Test lock and unlock actions before closing the door for normal use.

How to use

- Enter a valid code followed by the confirm key to unlock.
- Create a temporary code for guests and remove it after the visit.
- Replace all four AA batteries when the app sends a low-battery warning.

Error codes and resolutions

E1001: Bolt obstructed.

Open the door and test bolt movement; adjust strike alignment before retrying.

E1012: Code rejected.

Confirm the code is active in the app and enter it slowly before pressing confirm.

E1020: Battery critically low.

Use the mechanical key, then replace all batteries with new matching cells.

Nexa LeakGuard

Product ID: NEX-1010 | Category: Water-leak sensor

Description

- A small battery-powered sensor that detects water beneath sinks, washing machines, water heaters, and similar risk areas. It sends an immediate alert to the Nexa Home app and can trigger a compatible shutoff valve.

Key features

- Water-contact detection and loud local alarm.
- Temperature warning for potential pipe-freeze conditions.
- Optional automation with a compatible smart shutoff valve.

Setup

- Place the metal contact points flat on a dry surface near, not inside, the likely leak path.
- Add LeakGuard in the app and label it with its exact location.
- Test once by touching a few drops of clean water to the contacts, then dry them.

How to use

- Treat every water alert as urgent and inspect the named location first.
- Use event history to confirm when the sensor became wet or dry.
- Replace the battery annually or whenever the low-battery alert appears.

Error codes and resolutions

E1101: Sensor wet.

Inspect for a leak immediately, dry the contacts, and resolve the source before resetting.

E1110: Battery low.

Replace the coin-cell battery with the specified type and retest the sensor.

E1124: Temperature reading unavailable.

Remove the battery for 30 seconds, reinstall it, and check the device connection.