

Nexa SecureCam Door

Product ID: NEX-1004 | Category: Battery video doorbell

Description

- A weather-resistant video doorbell with motion alerts, two-way audio, local event history, and optional cloud backup. It is intended for a front door or protected outdoor entrance with a reliable Wi-Fi signal.

Key features

- 1080p live video, night vision, and adjustable motion zones.
- Rechargeable battery with low-battery notifications.
- Two-way talk from the Nexa Home mobile app.

Setup

- Charge the unit fully before mounting it at chest height beside the door.
- Add SecureCam in the app while standing near the installation location.
- Set motion zones to exclude public roads or constantly moving trees.

How to use

- Tap a notification to open live view or speak with a visitor.
- Review Events to see clips sorted by date and motion type.
- Charge when the app reports 20 percent battery or less.

Error codes and resolutions

E501: Camera offline.

Check Wi-Fi strength at the door, then press and hold the side button for 10 seconds.

E514: Storage unavailable.

Confirm the local storage card is inserted correctly or free space in cloud storage.

E527: Motion zone invalid.

Redraw the zone so it remains inside the visible camera frame.