

Nexa CleanBot S2

Product ID: NEX-1008 | Category: Robot vacuum cleaner

Description

- A compact robot vacuum that maps hard floors and low-pile carpets, supports room cleaning, and returns to its charging dock automatically. It includes a washable dustbin filter and app-based cleaning history.

Key features

- Room map, no-go zones, and scheduled cleaning.
- Auto-return charging dock and edge-cleaning brush.
- Washable dustbin filter with replacement reminder.

Setup

- Place the dock against a clear wall with open space on both sides.
- Charge the robot fully, then start a Mapping Run from the app.
- Name rooms after the map is saved and add no-go zones for cables or pet bowls.

How to use

- Choose Clean All for the full map or select one or more rooms.
- Empty the dustbin after each major clean for best suction.
- Clean the brush and filter when the maintenance reminder appears.

Error codes and resolutions

E901: Robot stuck.

Move the robot to clear floor, remove nearby cables, then tap Resume.

E914: Dock not found.

Check dock power and ensure the approach path is not blocked.

E922: Brush jam detected.

Turn off the robot and remove hair or thread from the main brush and end caps.