

# SOAR AND SCUM REMOVER

NON-ACID BOWL CLEANER
DISSOLVES SOAP, SCUM AND LIME DEPOSITS INSTANTLY

WARNING

Causes serious eye irritation. Suspected of causing cancer.

KEEP OUT OF REACH OF CHILDREN
NET CONTENTS: 1 1 5 20 35 55 Gallon(s)



PO BOX 245013 MILWAUKEE, WI 53224 800.776.7192 www.sharecorp.com



## WARNING:

Causes serious eye irritation. Suspected of causing cancer

### PREVENTION:

Obtain special instructions before use. Do not handle until all safety precautions have been read and understood. Wash thoroughly after handling. Weat eye protection, protective alongs.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lendes in present and easy to do. Continue rinsin If eye irritation persists: Get medical advice/attention. If exposed or concerned: Get medical advice/attention.

Store le ked up

Dispose of contents/container to comply with local/regional/national/international regulations.

# WARNING:

This product contains, or may contain, trace quantities of a substance(s) known to the state of California to cause cancer and/or reproductive toxicity.

For additional information, see Safety Data Sheet.

For industrial and commercial use only.

NFPA\* RATINGS
Health: 1: Flammability: 0: Reactivity: 0

### ICDEDIENTS /CAC #

INGREDIENTS/CAS #:
Water (7732-18-5); Sodium Tripolyphosphate (7758-29-4);
Tetrasodium Ethylenediamine Tetraacetate (64-02-8); Sodium Laureth Sulfate (9004-82-4); Sodium Hydroxyacetate (2836-32-0).

SOAP AND SCUM REMOVER represents a new concept in formulated chemical cleaners. A blend of powerful cleaning agents is transformed into an effective but easy to handle cleaner. It may be used for dissolving scale, scum, soap, mineral or lime deposits that form on metal, machinery or parts – also for cleaning radiators and cooling systems. Simply add SOAP AND SCUM REMOVER, allow to remain a short period, and rinse with water. For more stubborn cases, completely immerse part in SOAP AND SCUM REMOVER and allow to soak overnight. Prolonged contact will not harm most metal surfaces.

**TO REMOVE SCUM BUILDUP** from shower stalls, drinking fountains, lavatories, painted metal, chrome, etc. apply liberally with a sprayer, soft brush or sponge. Scour gently. Rinse with clear water.

**FOR ALUMINUM** - Apply with mop, sponge or brush. Rinse thoroughly within 3 minutes after application. Test a small area before using on anodized aluminum.

**SOAP AND SCUM REMOVER** is excellent for descaling condensers and heat exchangers and water meters. It may also be used to clean and remove scale from and entire cooling tower system.

**TO REMOVE WAX BUILDUP** more easily from all types of resilient floors, add 1 pint of **SOAP AND SCUM REMOVER** to 5 gallons of conventional stripping solution. Agitate with machine or brush. Pick up dirty solution with vacuum or scrub mop. To remove soap and alkali buildup from all mosaic and concrete floors – add 1 pint **SOAP AND SCUM REMOVER** to 5 parts of a conventional stripping solution. Agitate with machine or brush. Pick up dirty solution with vacuum or scrub mop.

TO REMOVE WET SOAP FILM FROM ALL SURFACES - add 1 pint SOAP AND SCUM REMOVER to 5 gallons of rinse water. Spread on surface and pick up with mop or sponge.



Diagra Dac

1401.052915