



PLAYBACK & BACKUP

INSTRUCTION GUIDE



DEFAULT
USERNAME
admin

DEFAULT
PASSWORD
123456



HOW TO PLAY BACK on DVR:

- 1** Right click to activate the main control "**MENU**"
- 2** Go to "**Time Search**"
- 3** Specify the Date and Time required, then select the "**Play**" Icon
- 4** To end the PLAYBACK, select the "X" on the button left

HOW TO BACKUP VIA USB

- 1** First step, make sure that your USB is Formatted
- 2** Insert the formatted USB Drive in the DVR USB Port located at rear panel
- 3** Right click to activate the main control "**MENU**"
- 4** Go to "**BACKUP**"
- 5** Specify the "**START**" and "**END**" Date and Time required to BACKUP
- 6** Tick and choose the cameras you require to backup.
- 7** Click on "**Calculate**" icon in order to confirm that the Backup file size is within the USB capacity
- 8** Click on "**Backup**" to complete the Backup process

VEROX

P2P INSTRUCTION GUIDE

DEFAULT
USERNAME
admin

DEFAULT
PASSWORD
123456



HOW TO SETUP P2P:

- 1** On the DVR, go to "**Network Setup**" page: **Main Control Menu > Configuration > Network Setup**
- 2** On the top part of "**Network Setup**" page, click on "**DHCP**" & enable it by ticking the icon, Press OK
- 3** Go to "**System Information**": **Control Panel > Configuration > System Information** (Under the network tab, you can find a QR code or Access key)
- 4** Mobile Phone and Tablets: Please download the App called "**VEROX**" Click "+" (IOS) or "**New**" (Android) located on the top right corner on the App to add a new device
- 5** Click on "**SCAN QR**" Code button on the App
- 6** Scan the code from the DVR that is on the "**System Information**" Page
- 7** Your default username is : **admin** and password is : **123456**

PC STEP BY STEP P2P SETUP:

- 1** On the DVR go to "**System Information**" **Control Panel > Configuration > System Information** (Under the network tab, you can find the IP Address)
- 1** Choose (**Download DVR Remote Desktop, Windows XP, Windows Vista, Windows 7**) and open it
- 1** On the PC, go to Internet Explorer and Type the IP address that is on "**System Information**"
- 2** Make sure you add "**http://**" before the IP address, once you have done this it will ask you for the username and password
- 5** Your "**Host**" is located on the "**System Information**" page of the DVR under the QR code