XR-21E1 GXR Parent-Barrier Design Immutability Crash Test

PARENT_BARRIER_DESIGN_IMMUTABILITY — TOTAL: 20 PASS: 20 FAIL: 0

Hard requirement: adding, moving, editing or removing an opening, Chest Bucky/Bucky shield or Control Wall must not change N/E/S/W parent-wall material, thickness, occupancy T or design goal P. Each scenario checks model state, live Barrier editor and rendered canvas after every UI action. Both default and deliberately mixed/non-default parent-wall constructions are exercised.

#	Status	Scenario	Failure detail
1	PASS	immut_0001_Bdefault_DN_SELN_TDoor_Pplain_Sadd	-
2	PASS	immut_0002_Bdefault_DN_SELN_TDoor_Pplain_Sadd_move	-
3	PASS	immut_0003_Bdefault_DN_SELN_TDoor_Pplain_Sadd_wall_cycle	-
4	PASS	immut_0004_Bdefault_DN_SELN_TDoor_Pplain_Sadd_type_toggle	-
5	PASS	immut_0005_Bdefault_DN_SELN_TDoor_Pcontrol_pb_Sadd	-
6	PASS	immut_0006_Bdefault_DN_SELN_TDoor_Pcontrol_pb_Sadd_move	-
7	PASS	immut_0007_Bdefault_DN_SELN_TDoor_Pcontrol_pb_Sadd_wall_cycle	-
8	PASS	immut_0008_Bdefault_DN_SELN_TDoor_Pcontrol_pb_Sadd_type_toggle	-
9	PASS	immut_0009_Bdefault_DN_SELN_TDoor_Pcontrol_concrete_Sadd	-
10	PASS	immut_0010_Bdefault_DN_SELN_TDoor_Pcontrol_concrete_Sadd_move	-
11	PASS	immut_0011_Bdefault_DN_SELN_TDoor_Pcontrol_concrete_Sadd_wall_cycle	-
12	PASS	immut_0012_Bdefault_DN_SELN_TDoor_Pcontrol_concrete_Sadd_type_toggle	-
13	PASS	immut_0013_Bdefault_DN_SELN_TDoor_Pbucky_control_concrete_Sadd	-
14	PASS	immut_0014_Bdefault_DN_SELN_TDoor_Pbucky_control_concrete_Sadd_move	-
15	PASS	immut_0015_Bdefault_DN_SELN_TDoor_Pbucky_control_concrete_Sadd_wall_cycle	-
16	PASS	immut_0016_Bdefault_DN_SELN_TDoor_Pbucky_control_concrete_Sadd_type_toggle	-
17	PASS	immut_0017_Bdefault_DN_SELN_TViewingPanel_Pplain_Sadd	-
18	PASS	immut_0018_Bdefault_DN_SELN_TViewingPanel_Pplain_Sadd_move	-
19	PASS	immut_0019_Bdefault_DN_SELN_TViewingPanel_Pplain_Sadd_wall_cycle	-
20	PASS	immut_0020_Bdefault_DN_SELN_TViewingPanel_Pplain_Sadd_type_toggle	-