XR-21E2 GXR Opening-Only Parent-Barrier Immutability Crash Test

PARENT_BARRIER_DESIGN_IMMUTABILITY — TOTAL: 96 PASS: 96 FAIL: 0

Focused requirement: adding, moving, editing or removing an Opening must never change N/E/S/W parent-wall material, thickness, occupancy T or design goal P. Each case exercises a complete opening lifecycle and checks model state, live Barrier editor and rendered canvas after every action. No Chest Bucky or Control Wall operations are included.

#	Status	Scenario	Failure detail
1	PASS	opening_001_Bdefault_DN_SELN_TDoor	-
2	PASS	opening_002_Bdefault_DN_SELN_TViewingPanel	-
3	PASS	opening_003_Bdefault_DN_SELE_TDoor	-
4	PASS	opening_004_Bdefault_DN_SELE_TViewingPanel	-
5	PASS	opening_005_Bdefault_DN_SELS_TDoor	-
6	PASS	opening_006_Bdefault_DN_SELS_TViewingPanel	-
7	PASS	opening_007_Bdefault_DN_SELW_TDoor	-
8	PASS	opening_008_Bdefault_DN_SELW_TViewingPanel	-
9	PASS	opening_009_Bdefault_DN_SELFloor_TDoor	-
10	PASS	opening_010_Bdefault_DN_SELFloor_TViewingPanel	-
11	PASS	opening_011_Bdefault_DN_SELCeiling_TDoor	-
12	PASS	opening_012_Bdefault_DN_SELCeiling_TViewingPanel	-
13	PASS	opening_013_Bdefault_DE_SELN_TDoor	-
14	PASS	opening_014_Bdefault_DE_SELN_TViewingPanel	-
15	PASS	opening_015_Bdefault_DE_SELE_TDoor	-
16	PASS	opening_016_Bdefault_DE_SELE_TViewingPanel	-
17	PASS	opening_017_Bdefault_DE_SELS_TDoor	-
18	PASS	opening_018_Bdefault_DE_SELS_TViewingPanel	-
19	PASS	opening_019_Bdefault_DE_SELW_TDoor	-
20	PASS	opening_020_Bdefault_DE_SELW_TViewingPanel	-
21	PASS	opening_021_Bdefault_DE_SELFloor_TDoor	-
22	PASS	opening_022_Bdefault_DE_SELFloor_TViewingPanel	-

#	Status	Scenario	Failure detail
23	PASS	opening_023_Bdefault_DE_SELCeiling_TDoor	-
24	PASS	opening_024_Bdefault_DE_SELCeiling_TViewingPanel	-
25	PASS	opening_025_Bdefault_DS_SELN_TDoor	-
26	PASS	opening_026_Bdefault_DS_SELN_TViewingPanel	-
27	PASS	opening_027_Bdefault_DS_SELE_TDoor	-
28	PASS	opening_028_Bdefault_DS_SELE_TViewingPanel	-
29	PASS	opening_029_Bdefault_DS_SELS_TDoor	-
30	PASS	opening_030_Bdefault_DS_SELS_TViewingPanel	-
31	PASS	opening_031_Bdefault_DS_SELW_TDoor	-
32	PASS	opening_032_Bdefault_DS_SELW_TViewingPanel	-
33	PASS	opening_033_Bdefault_DS_SELFloor_TDoor	-
34	PASS	opening_034_Bdefault_DS_SELFloor_TViewingPanel	-
35	PASS	opening_035_Bdefault_DS_SELCeiling_TDoor	-
36	PASS	opening_036_Bdefault_DS_SELCeiling_TViewingPanel	-
37	PASS	opening_037_Bdefault_DW_SELN_TDoor	-
38	PASS	opening_038_Bdefault_DW_SELN_TViewingPanel	-
39	PASS	opening_039_Bdefault_DW_SELE_TDoor	-
40	PASS	opening_040_Bdefault_DW_SELE_TViewingPanel	-
41	PASS	opening_041_Bdefault_DW_SELS_TDoor	-
42	PASS	opening_042_Bdefault_DW_SELS_TViewingPanel	-
43	PASS	opening_043_Bdefault_DW_SELW_TDoor	-
44	PASS	opening_044_Bdefault_DW_SELW_TViewingPanel	-
45	PASS	opening_045_Bdefault_DW_SELFloor_TDoor	-
46	PASS	opening_046_Bdefault_DW_SELFloor_TViewingPanel	-
47	PASS	opening_047_Bdefault_DW_SELCeiling_TDoor	-
48	PASS	opening_048_Bdefault_DW_SELCeiling_TViewingPanel	-
49	PASS	opening_049_Bmixed_custom_DN_SELN_TDoor	-
50	PASS	opening_050_Bmixed_custom_DN_SELN_TViewingPanel	-

#	Status	Scenario	Failure detail
51	PASS	opening_051_Bmixed_custom_DN_SELE_TDoor	-
52	PASS	opening_052_Bmixed_custom_DN_SELE_TViewingPanel	-
53	PASS	opening_053_Bmixed_custom_DN_SELS_TDoor	-
54	PASS	opening_054_Bmixed_custom_DN_SELS_TViewingPanel	-
55	PASS	opening_055_Bmixed_custom_DN_SELW_TDoor	-
56	PASS	opening_056_Bmixed_custom_DN_SELW_TViewingPanel	-
57	PASS	opening_057_Bmixed_custom_DN_SELFloor_TDoor	-
58	PASS	opening_058_Bmixed_custom_DN_SELFloor_TViewingPanel	-
59	PASS	opening_059_Bmixed_custom_DN_SELCeiling_TDoor	-
60	PASS	opening_060_Bmixed_custom_DN_SELCeiling_TViewingPanel	-
61	PASS	opening_061_Bmixed_custom_DE_SELN_TDoor	-
62	PASS	opening_062_Bmixed_custom_DE_SELN_TViewingPanel	-
63	PASS	opening_063_Bmixed_custom_DE_SELE_TDoor	-
64	PASS	opening_064_Bmixed_custom_DE_SELE_TViewingPanel	-
65	PASS	opening_065_Bmixed_custom_DE_SELS_TDoor	-
66	PASS	opening_066_Bmixed_custom_DE_SELS_TViewingPanel	-
67	PASS	opening_067_Bmixed_custom_DE_SELW_TDoor	-
68	PASS	opening_068_Bmixed_custom_DE_SELW_TViewingPanel	-
69	PASS	opening_069_Bmixed_custom_DE_SELFloor_TDoor	-
70	PASS	opening_070_Bmixed_custom_DE_SELFloor_TViewingPanel	-
71	PASS	opening_071_Bmixed_custom_DE_SELCeiling_TDoor	-
72	PASS	opening_072_Bmixed_custom_DE_SELCeiling_TViewingPanel	-
73	PASS	opening_073_Bmixed_custom_DS_SELN_TDoor	-
74	PASS	opening_074_Bmixed_custom_DS_SELN_TViewingPanel	-
75	PASS	opening_075_Bmixed_custom_DS_SELE_TDoor	-
76	PASS	opening_076_Bmixed_custom_DS_SELE_TViewingPanel	-
77	PASS	opening_077_Bmixed_custom_DS_SELS_TDoor	-
78	PASS	opening_078_Bmixed_custom_DS_SELS_TViewingPanel	-

#	Status	Scenario	Failure detail
79	PASS	opening_079_Bmixed_custom_DS_SELW_TDoor	-
80	PASS	opening_080_Bmixed_custom_DS_SELW_TViewingPanel	-
81	PASS	opening_081_Bmixed_custom_DS_SELFloor_TDoor	-
82	PASS	opening_082_Bmixed_custom_DS_SELFloor_TViewingPanel	-
83	PASS	opening_083_Bmixed_custom_DS_SELCeiling_TDoor	-
84	PASS	opening_084_Bmixed_custom_DS_SELCeiling_TViewingPanel	-
85	PASS	opening_085_Bmixed_custom_DW_SELN_TDoor	-
86	PASS	opening_086_Bmixed_custom_DW_SELN_TViewingPanel	-
87	PASS	opening_087_Bmixed_custom_DW_SELE_TDoor	-
88	PASS	opening_088_Bmixed_custom_DW_SELE_TViewingPanel	-
89	PASS	opening_089_Bmixed_custom_DW_SELS_TDoor	-
90	PASS	opening_090_Bmixed_custom_DW_SELS_TViewingPanel	-
91	PASS	opening_091_Bmixed_custom_DW_SELW_TDoor	-
92	PASS	opening_092_Bmixed_custom_DW_SELW_TViewingPanel	-
93	PASS	opening_093_Bmixed_custom_DW_SELFloor_TDoor	-
94	PASS	opening_094_Bmixed_custom_DW_SELFloor_TViewingPanel	-
95	PASS	opening_095_Bmixed_custom_DW_SELCeiling_TDoor	-
96	PASS	opening_096_Bmixed_custom_DW_SELCeiling_TViewingPanel	-