XR-21E2 GXR Opening-Only Parent-Barrier Immutability Crash Test

PARENT_BARRIER_DESIGN_IMMUTABILITY — TOTAL: 54 PASS: 54 FAIL: 0

Focused requirement: adding, moving, editing or removing an Opening must never change N/E/S/W parent-wall material, thickness, occupancy T or design goal P. Each case exercises a complete opening lifecycle and checks model state, live Barrier editor and rendered canvas after every action. No Chest Bucky or Control Wall operations are included.

#	Status	Scenario	Failure detail
1	PASS	control_001_default_N_north_west	-
2	PASS	control_002_default_N_centre	-
3	PASS	control_003_default_N_south_east	-
4	PASS	control_004_default_E_north_west	-
5	PASS	control_005_default_E_centre	-
6	PASS	control_006_default_E_south_east	-
7	PASS	control_007_default_S_north_west	-
8	PASS	control_008_default_S_centre	-
9	PASS	control_009_default_S_south_east	-
10	PASS	control_010_default_W_north_west	-
11	PASS	control_011_default_W_centre	-
12	PASS	control_012_default_W_south_east	-
13	PASS	control_013_default_Floor_north_west	-
14	PASS	control_014_default_Floor_centre	-
15	PASS	control_015_default_Floor_south_east	-
16	PASS	control_016_default_Ceiling_north_west	-
17	PASS	control_017_default_Ceiling_centre	-
18	PASS	control_018_default_Ceiling_south_east	-
19	PASS	control_019_north_pb_glass_N_north_west	-
20	PASS	control_020_north_pb_glass_N_centre	-
21	PASS	control_021_north_pb_glass_N_south_east	-
22	PASS	control_022_north_pb_glass_E_north_west	-

#	Status	Scenario	Failure detail
23	PASS	control_023_north_pb_glass_E_centre	-
24	PASS	control_024_north_pb_glass_E_south_east	-
25	PASS	control_025_north_pb_glass_S_north_west	-
26	PASS	control_026_north_pb_glass_S_centre	-
27	PASS	control_027_north_pb_glass_S_south_east	-
28	PASS	control_028_north_pb_glass_W_north_west	-
29	PASS	control_029_north_pb_glass_W_centre	-
30	PASS	control_030_north_pb_glass_W_south_east	-
31	PASS	control_031_north_pb_glass_Floor_north_west	-
32	PASS	control_032_north_pb_glass_Floor_centre	-
33	PASS	control_033_north_pb_glass_Floor_south_east	-
34	PASS	control_034_north_pb_glass_Ceiling_north_west	-
35	PASS	control_035_north_pb_glass_Ceiling_centre	-
36	PASS	control_036_north_pb_glass_Ceiling_south_east	-
37	PASS	control_037_mixed_custom_N_north_west	-
38	PASS	control_038_mixed_custom_N_centre	-
39	PASS	control_039_mixed_custom_N_south_east	-
40	PASS	control_040_mixed_custom_E_north_west	-
41	PASS	control_041_mixed_custom_E_centre	-
42	PASS	control_042_mixed_custom_E_south_east	-
43	PASS	control_043_mixed_custom_S_north_west	-
44	PASS	control_044_mixed_custom_S_centre	-
45	PASS	control_045_mixed_custom_S_south_east	-
46	PASS	control_046_mixed_custom_W_north_west	-
47	PASS	control_047_mixed_custom_W_centre	-
48	PASS	control_048_mixed_custom_W_south_east	-
49	PASS	control_049_mixed_custom_Floor_north_west	-
50	PASS	control_050_mixed_custom_Floor_centre	-

#	Status	Scenario	Failure detail
51	PASS	control_051_mixed_custom_Floor_south_east	-
52	PASS	control_052_mixed_custom_Ceiling_north_west	-
53	PASS	control_053_mixed_custom_Ceiling_centre	-
54	PASS	control_054_mixed_custom_Ceiling_south_east	-