## **CC31xx UDP Socket Application**

**UDP Socket** 

### Overview and application details

This example demonstrates how to open and use a standard UDP socket with CC31xx.

#### **Usage**

- Open 'main.c' and change 'SSID\_NAME' Build and launch the application using CCS
- Open an 'Ipef' UDP server listening on port 'PORT\_NUM' on Windows-PC

```
Iperf -s -p <PORT_NUM> -i 1 -u
```

- · The application will connect to 'Iperf' server and send few dummy packets
- The application also starts a UDP server on 'PORT\_NUM'
- Open an 'Ipef' client on Windows and connect on 'PORT\_NUM'

```
Iperf -c <DEST_IP_ADDR> -p <PORT_NUM> -i 1 -u
```

#### **Limitations/Known Issues**

None

# **Article Sources and Contributors**

 $\textbf{CC31xx UDP Socket Application} \ \ \textit{Source}: \ \text{http://ap-fpdsp-swapps.dal.design.ti.com/index.php?oldid=187665} \ \ \textit{Contributors}: \ \ \text{Giansway of the policy o$