TECHNICAL REFERENCE COMPENDIUM

DDJ-FLX10

4-channel DJ controller for rekordbox & Serato DJ Pro
Pioneer DJ / AlphaTheta

Compiled from
Instruction Manual DRI1822-D (183 pp, EN, rev. 23 Oct 2024)
List of MIDI Messages E1 (7 pp)

Contents
Specifications · I/O · Control properties (rekordbox / Serato) · On Jog Display · Pad modes · Effects · Settings & defaults · Events & triggers · Workflows · Complete MIDI map (IN + OUT) · Signal flow · Troubleshooting

Restructured reference built from AlphaTheta's official documentation. Not an official AlphaTheta publication. Manual page numbers are cited as [p.N] for cross-checking. Specs and firmware behaviour are subject to change — verify against the latest docs at support.alphatheta.com.

Contents

1. Specifications
2. Hardware layout, I/O & connections
3. Control properties — Browse section
4. Control properties — Deck section
5. Control properties — Mixer section
6. Control properties — Effects section
7. On Jog Display
8. Performance Pad modes
9. Effects reference
10. Settings & properties (rekordbox / Utilities / Setting Utility)
11. Events, triggers & automatic behaviours
12. Workflows
13. MIDI map — conventions & channels
14. MIDI map — Browser, Deck, Mixer, Effects
15. MIDI map — Performance Pads & pad-mode buttons
16. MIDI-OUT (feedback / display control)
17. Signal flow
18. Troubleshooting
19. Source notes & discrepancies

1 · Specifications

In the box
AC adapter · power cord · USB cable · Quick Start Guide · Precautions for Use · Serato Pitch 'n Time DJ voucher · warranty (some regions). Voucher codes can't be reissued. [p.5]

Software
rekordbox (Performance mode via Hardware Unlock — no subscription required) and Serato DJ Pro (unlocked by the unit). Any other MIDI-capable DJ app via the MIDI map in §13–16. Windows needs the dedicated ASIO driver; Mac needs only the Setting Utility. [p.6–9, 179]

Group	Item	Value
AC adapter	**Power requirements**	AC 100–240 V, 50/60 Hz
	Rated current	0.9 A
	Rated output	DC 12 V, 3 A
General	**Power consumption**	DC 12 V, 1 800 mA
	Power consumption (off)	0.2 W
	Weight	6.7 kg / 14.8 lb
	Max. dimensions (W×D×H)	716 × 400.3 × 73.4 mm / 28.2 × 15.8 × 2.9 in
	Operating temperature	+5 °C – +35 °C (+41 °F – +95 °F)
	Operating humidity	5 % – 85 % (no condensation)
Audio	**Sampling rate**	44.1 kHz
	A/D, D/A converters	24 bit
	Frequency response (USB, LINE, MIC1, MIC2)	20 Hz – 20 kHz
	S/N ratio (rated out, A-weighted)	USB 110 dB · LINE 94 dB · PHONO 83 dB · MIC1 81 dB · MIC2 81 dB
	THD (20 Hz–20 kHz BW)	USB 0.002 % · LINE 0.007 % · PHONO 0.025 %
	Standard input level / impedance	LINE −12 dBu / 47 kΩ · PHONO −52 dBu / 47 kΩ · MIC1 −57 dBu / 3 kΩ · MIC2 −57 dBu / 3 kΩ
	Standard output level / load / output Z	MASTER 1 +6 dBu / 10 kΩ / ≤330 Ω · MASTER 2 +2 dBu / 10 kΩ / ≤750 Ω · BOOTH +6 dBu / 10 kΩ / ≤900 Ω · PHONES +8 dBu / 32 Ω / ≤10 Ω
	Rated output level / load	MASTER 1 +25 dBu / 10 kΩ · MASTER 2 +21 dBu / 10 kΩ · BOOTH +25 dBu / 10 kΩ
	Crosstalk	LINE 88 dB · PHONO 77 dB
	Channel EQ	HI −26 to +6 dB (20 kHz) · MID −26 to +6 dB (1 kHz) · LOW −26 to +6 dB (20 Hz)
	Mic EQ	HI −12 to +12 dB (10 kHz) · LOW −12 to +12 dB (100 Hz)
DMX	**DMX channel**	1 universe (512 ch)
Terminals	**LINE inputs**	RCA × 2 sets (CH1, CH2)
	LINE/PHONO inputs	RCA × 2 sets (CH3, CH4)
	MIC inputs	MIC 1: XLR / ¼″ TRS combo × 1 · MIC 2: ¼″ TRS × 1
	MASTER 1 out	XLR (balanced) × 1
	MASTER 2 out	RCA × 1
	BOOTH out	¼″ TRS (balanced) × 1
	PHONES out	¼″ stereo × 1, 3.5 mm stereo mini × 1 (min. 32 Ω headphones)
	USB	USB Type-C × 2 (labelled USB A / USB B — two computers)
	DMX	XLR 3-pin × 1

Group	Item	Value
EU PSU	**Model / maker**	UNI336-1230 · AlphaTheta EMEA Ltd
	Electrical	In AC 100–240 V 50/60 Hz · Out DC 12.0 V 3.0 A 36.0 W · avg. efficiency 88.7 % · 10 % load 84.9 % · no-load 0.04 W

Source: manual pp.175–178.

2 · Hardware layout, I/O & connections

Top panel zones: **Browse** (centre top), **Deck sections** (left = decks 1/3, right = decks 2/4), **Mixer** (centre), **Effects** (centre, above/beside mixer). [p.10]

Rear panel

#	Terminal / control	Properties & rules
1	Kensington slot	Cable lock.
2	MASTER 1 (XLR, balanced)	To amp/powered speakers. Use balanced only — XLR→RCA adapters degrade sound/add noise. Never connect phantom-power sources; don't insert other power plugs.
3	MASTER 2 (RCA)	Unbalanced master output (manual text says 'balanced input' on p.58 — it is the unbalanced feed; see §19).
4	BOOTH (¼″ TRS, balanced)	Booth monitor. Unbalanced connection degrades sound.
5	SIGNAL GND	Turntable ground wire.
6	LINE/PHONO switch (CH3/CH4)	LINE for multi players; PHONO for MM-cartridge turntables.
7	LINE/PHONO inputs (CH3/CH4)	Set top-panel [A, PHONO/LINE, B] to PHONO/LINE first.
8	LINE inputs (CH1/CH2)	Line-level only. Set top-panel [A, LINE, B] to LINE first.
9	DMX out	rekordbox Lighting mode / Performance-mode lighting sync only.
10	USB B (Type-C)	Computer 2. Type-C host: supplied cable or USB 2.0 cable. Type-A host: certified cable ≤3 m.
11	USB A (Type-C)	Computer 1. Same cable rules. Hubs: only those recommended by the computer maker.
12	MIC 2	¼″ TRS.
13	MIC 1	XLR/TRS combo.
14	Power switch	
15	DC IN	Supplied AC adapter only; connect last.
16	Cord hook	Prevents accidental disconnect (sound stops if pulled). Don't bend the cable base.

Front panel

PHONES: ¼″ stereo + 3.5 mm mini. Headphones below 32 Ω won't work.

Connection order (manual p.66)

1. Headphones → front PHONES (¼″ or 3.5 mm, ≥32 Ω).
2. Amplifier/speakers → MASTER 1 (XLR) or MASTER 2 (RCA); booth monitor → BOOTH; multi player → CH3/CH4 with rear LINE/PHONO switch set.
3. Unit → computer via USB.
4. Power on computer.
5. Connect AC adapter.
6. Press rear power switch (Windows may show "preparing device" → wait for "ready").
7. Power on amps/speakers and any external sources last.

Rule: unit off and unplugged while connecting; power cord in only after everything else is cabled.

3 · Control properties — Browse section

Control / gesture	rekordbox	Serato DJ Pro
Rotary selector — turn	Move cursor	Move cursor in library / crates
Rotary — [SHIFT]+turn	Zoom enlarged waveform (right = in)	Zoom detailed waveform on On Jog Display
Rotary — press	Track: load to deck · Playlist: jump to track list · Folder: open	Track: load · Library/crates: toggle panel focus
Rotary — press twice	Instant Doubles (copy playing deck incl. position)	Instant Doubles
BACK — press	Toggle tree view ⇄ track list (⇄ playlist palette if shown)	Toggle library ⇄ crates
BACK — hold	—	Enter Utilities mode (§10)
BACK — [SHIFT]+press	Show/hide playlist palette	Load track to PREPARE panel
VIEW — press	Shrink decks / enlarge browser (toggle)	Change screen layout
VIEW — hold	Add/remove selected track to Tag List	—
VIEW — [SHIFT]+press	Jump to Related Tracks	Cycle panel display

Source: pp.11–13.

4 · Control properties — Deck section

Numbers match the manual's deck diagram. Mute vs Solo for ACTIVE PART in rekordbox: *Preferences › Extensions › TRACK SEPARATION › ACTIVE PART setting*.

# Control	rekordbox	Serato DJ Pro
1 CUE/LOOP CALL ◀	Call previous cue/loop · SHIFT: save cue/loop point	Select loop slot · SHIFT: lock loop slot
2 CUE/LOOP CALL ▶	Call next cue/loop · SHIFT: delete cue/loop point	Select loop slot · SHIFT: delete loop slot
3 MIX POINT SELECT ◀	Pick mix point (Hot Cue/cue) on deck being mixed · SHIFT: cancel Mix Point Link	Key down (semitone)
4 MIX POINT SELECT ▶	Pick mix point · SHIFT: select deck to be mixed (Mix Point Link)	Key up · SHIFT: select other deck shown in Waveform mode
5 MIX POINT LINK	Open Mix Point Link screen · SHIFT: Silent (mute until mix point)	Key Lock on/off
6 QUANTIZE	Quantize on/off · cancels Off mode (left deck) · SHIFT: Tap tempo	Same
7 SLIP	Slip on/off · SHIFT: Vinyl mode on/off	Same
8 JOG FEEL	Jog weight (CW = heavier)	Same
9 BEAT SYNC	Sync tempo+grid to master · press again: cancel · hold during sync: Sync Rate (×1, ×2, ×½) · SHIFT: set as master	Sync · SHIFT: cancel sync
10 TEMPO slider	Playback speed	Same
11 KEY SYNC	Match key to other deck · SHIFT: reset to original key	Same
12 TEMPO RESET	Return to original speed regardless of slider · SHIFT: range ±6 → ±10 → ±16 → WIDE	SHIFT: range ±8 → ±16 → ±50 %
13 HOT CUE mode	Hot Cue · SHIFT: Keyboard	Hot Cue · hold: Saved Flip · SHIFT: Pitch Play
14 PAD FX1 mode	Pad FX 1 · SHIFT: Pad FX 2	Pad FX · SHIFT: Roll
15 BEAT JUMP mode	Beat Jump · SHIFT: Beat Loop	Beat Jump · SHIFT: Auto Loop
16 SAMPLER mode	Sampler · SHIFT: Key Shift	Sampler · SHIFT: Key Shift
17 PAGE ◀ / ▶	Change pad page · hold: show pad functions on jog · SHIFT: switch jog display mode	Adjust pad-mode parameter (press or SHIFT+press) · hold: show pad functions · SHIFT+hold: switch jog display
18 Performance Pads	Trigger current pad mode (§8)	Same
19 PLAY/PAUSE	Play/pause	Play/pause · SHIFT: Stutter (play from temp cue)
20 CUE	Paused: set cue · playing: Back Cue · hold after return: Cue Point Sampler · SHIFT: jump to track start	Same
21 4 BEAT JUMP ◀/▶	Jump 4 beats · hold: fast search · SHIFT: jump 16 beats	Same
22 SHIFT	Modifier · double-press: toggle Digital Marker on jog display	Same
23 On Jog Display	See §7	See §7
24 Jog wheel	Top (Vinyl on): scratch · side or top (Vinyl off): pitch bend · SHIFT+top: beatgrid interval · SHIFT+side: slide beatgrid · 4 BEAT JUMP + top: fast search	Same; BEAT JUMP+top = Skip mode
25 DECK SELECT	Switch deck 1⇄3 / 2⇄4 · SHIFT: Dual Deck mode	Same
26 SLIP REVERSE	Hold: reverse with slip (auto-cancels after 8 beats) · SHIFT: latching reverse	Same
27 LOOP IN, 1/2X	Set loop in · in loop: halve · SHIFT (in loop): adjust in-point with jog	Same

# Control	rekordbox	Serato DJ Pro
28 LOOP OUT, 2X	Set loop out & start loop · in loop: double · SHIFT: reloop · SHIFT (in loop): adjust out-point with jog	Same
29 4 BEAT/EXIT	4-beat auto loop · in loop: exit · SHIFT: Active Loop toggle	Same
30 ACTIVE PART DRUMS	Mute (or Solo, per prefs) Drums · SHIFT×2: Part Instant Doubles (this deck plays drums only, other mutes drums)	Mute Drums stem · SHIFT×2: Part Instant Doubles
31 ACTIVE PART VOCAL	Mute/Solo Vocal · SHIFT×2: Part Instant Doubles	Mute Vocal stem · SHIFT×2: Part Instant Doubles
32 ACTIVE PART INST	Mute/Solo INST · SHIFT×2: Part Instant Doubles	Mute Bass+Melody stems · SHIFT×2: Part Instant Doubles

Source: pp.14–32.

5 · Control properties — Mixer section

# Control	Property / behaviour
1 A, PHONO/LINE, B (CH3/4)	Source: deck A (PC-A), deck B (PC-B), or external PHONO/LINE input
2 A, LINE, B (CH1/2)	Source: PC-A, PC-B, or external LINE input
3 MASTER LEVEL	Master output volume
4 BOOTH LEVEL	Booth output volume
5 CLIP indicator	Slow flash = just before distortion · fast flash = distorting
6 Master level meter	Master output level
7 TRIM	Channel gain (aim for orange at loudest peaks)
8 Channel level meter	Pre-fader channel level
9 EQ HI/MID/LOW	EQ mode: ±freq bands (−26 to +6 dB). Part ISO mode: stem volume. rekordbox default: HI=INST, MID=Vocal, LOW=Drums (change in Preferences › Extensions › TRACK SEPARATION › Layout). Serato: HI=Vocal, MID=Bass+Melody, LOW=Drums
10 Headphones CUE (master)	Master to headphones
11 Headphones CUE (channel)	Channel to headphones · SHIFT: toggle EQ mode ⇄ Part ISO mode
12 Channel faders	Channel volume (SHIFT + move = Fader Start, if enabled)
13 Crossfader assign	A (left) · B (right) · THRU (bypass crossfader)
14 Crossfader	Blend A/B sides (SHIFT + move = Crossfader Start). Curve and cut lag configurable
15 HEADPHONES LEVEL	Phones volume
16 HEADPHONES MIX	Cue ⇄ master blend in phones
17 SAMPLER VOL	Sampler volume
18 SAMPLER CUE	Sampler to headphones (Serato: Sample Player Output Select = A)
19 MIC OFF/ON/TALKOVER	ON = indicator lit · TALKOVER = indicator flashes, ducks music
20 MIC indicator	Mic state
21 MIC EQ HI/LOW	HI ±12 dB @10 kHz · LOW ±12 dB @100 Hz (shared for MIC1/2)
22 MIC2 LEVEL	Mic 2 volume
23 MIC1 LEVEL	Mic 1 volume

> Don't pull fader/crossfader caps off by force — they can break. [p.53]

Source: pp.50–53. The 4-channel mixer works standalone (no computer) for external inputs.

6 · Control properties — Effects section

# Control	Property / behaviour
1 FX PART SELECT (VOCAL/DRUMS/INST)	Choose stems that Beat FX / Sound Color FX (and Pad FX in rekordbox) hit. All lit = whole track. External inputs, mic and sampler always get full-signal FX.
2 Effects display	Effect name · AUTO/TAP · BPM (flashes last value if undetectable) · channel (SP, MIC, CH1–4, MST) · parameter
3 BEAT ◀	Fewer beats · SHIFT: BPM Auto mode
4 BEAT ▶	More beats · SHIFT: BPM Tap mode (tap the button)
5 BEAT FX select	Choose Beat FX (rekordbox: changes first FX on FX1 unit)
6 BEAT FX CH select	SP · MIC · 1 · 2 · 3 · 4 · MST
7 LEVEL/DEPTH	Effect parameter (dry/wet etc.)
8 BEAT FX ON/OFF	On/off (flashes when on) · SHIFT: Release FX (rekordbox only)
9 BEAT FX indicators	Lit for selected channel(s); MST lights all; flash on target while FX on
10 COLOR knobs	Per-channel Sound Color FX amount
11 SOUND COLOR FX buttons	SPACE · DUB ECHO · CRUSH · PITCH · NOISE · FILTER (one at a time, same type on all channels)

Source: pp.54–57. Mic and external inputs always use the unit's onboard FX, even in rekordbox/Serato.

7 · On Jog Display

Switch modes: rekordbox [SHIFT]+[PAGE ◀/▶]; Serato [SHIFT]+hold [PAGE]. Hold [PAGE ◀/▶] (no shift) to overlay pad-mode functions temporarily (pad mode, function name/parameter/colour, time). Double-press [SHIFT] toggles the Digital Marker (default: hidden).

Mode	rekordbox elements	Serato DJ Pro elements
Deck Info / Virtual Deck	BPM · Master Tempo · key · key change · cue/loop/hot-cue markers · playback position · cue scope (−4 to +16 bars, 4-bar ticks) · time (elapsed/remaining) · SYNC · artwork · deck # · Track Separation status · tempo range · playing speed · On Air (white = deck 1/2, blue = 3/4) · Digital Marker · waveform (full/half) · MASTER · cue point	BPM · playing speed · loop length (blue while looping) · elapsed · remaining · SYNC · deck # · tempo range · Key Lock · key · key change · selected deck · nearest Hot Cue · Digital Marker · playback position
Waveform	As above + deck # for mixing deck · enlarged waveform of playing deck AND mixing deck (stacked)	Loop · speed · selected deck · position · detailed waveform (zoom: SHIFT+rotary) · mixing-deck # · SYNC · key · BPM · deck # · range · Key Lock · mixing-deck waveform · Digital Marker · time
Mix Point Link overlay (rekordbox)	Playing-deck position · countdown to auto-start (flashing, vanishes at 0:00) · mixing-deck position · link position (centred) · green status indicator	—
Artwork Display	Artwork · SYNC · deck # · On Air · Digital Marker · MASTER · cue point	Artwork · SYNC · deck # · selected deck · Digital Marker
DJ Logo Display	Custom logo (set via Setting Utility) · cue point · SYNC · deck # · On Air · Digital Marker · MASTER	Logo · SYNC · deck # · selected deck · Digital Marker

Source: pp.33–49. LCD notes: dead/bright pixels are normal; display is dim when cold until it warms up; shade from direct sun. [p.173]

8 · Performance Pad modes

Pad numbering: top row 1–4, bottom row 5–8.

Mode (entry)	rekordbox pad assignment	Serato DJ Pro pad assignment
Hot Cue (HOT CUE)	16 per track: PAGE◀ = A–H, PAGE▶ = I–P. Pad sets/plays; SHIFT+pad clears. Pads can store 4-beat or manual loops. Optional Gate playback while paused (Prefs › Controller › Deck › HOT CUE)	8 per track (1–8). SHIFT+pad clears
Keyboard / Pitch Play (SHIFT+HOT CUE)	Pick a Hot Cue (or current pos.), pads play it at pitch: 1:+4 2:+5 3:+6 4:+7 / 5:0 6:+1 7:+2 8:+3 semitones (PAGE shifts range)	Pitch Play (Pitch 'n Time pack). SHIFT+pad selects cue. Up: +4 +5 +6 +7 / 0 +1 +2 +3 · Middle: 0 +1 +2 +3 / −4 −3 −2 −1 · Down: −3 −2 −1 0 / −7 −6 −5 −4. SHIFT+PAGE shifts by semitone
Saved Flip (hold HOT CUE)	—	Pads 1–6 = Flip slots (7–8 unused). Press to save/recall; SHIFT+pad = start when track reaches Flip start; SHIFT+pad during Flip = cancel. Needs Serato Expansion Pack
Pad FX 1 (PAD FX1)	16 effects: PAGE◀ A–H, PAGE▶ I–P. Hold = on, release = off. Release FX pad: hold another FX pad, tap Release pad	Effects A–H, hold to apply
Pad FX 2 / Roll (SHIFT+PAD FX1)	Effects Q–X (PAGE◀), Y–AF (PAGE▶)	Roll: e.g. 1/8, 1/4, 1/2, 1, 2, 4, 8, 16 beats while held; slip resumes. PAGE changes range during roll
Beat Jump (BEAT JUMP)	Default: 1:−1 2:+1 3:−2 4:+2 5:−4 6:+4 7:−8 8:+8 beats (odd = back, even = forward). PAGE changes beat/bar sizes	1: jump back · 2: halve size · 3: double size · 4: jump forward · 5: previous track · 6: search ◀ · 7: search ▶ · 8: Censor
Beat Loop / Auto Loop (SHIFT+BEAT JUMP)	1:1/64 2:1/32 3:1/16 4:1/8 5:1/4 6:1/2 7:1 8:2 beats (latching; same pad exits). PAGE shifts range	1:1/8 2:1/4 3:1/2 4:1 5:2 6:4 7:8 8:16 beats. PAGE◀ halve, PAGE▶ double, SHIFT+PAGE = Loop Shift; same pad exits
Sampler (SAMPLER)	Pads = slots 1–8 (deck 2/4 pads = slots 9–16). PAGE changes bank. SHIFT+pad loads selected track into slot / stops playing slot. Re-press = retrigger	4 banks A–D × 8 slots; PAGE changes bank. Load by drag-drop. SHIFT+pad stops slot. Behaviour per Serato sampler mode
Key Shift (SHIFT+SAMPLER)	1:+4 2:+5 3:+6 4:+7 / 5:0 6:+1 7:+2 8:+3 semitones; PAGE changes; SHIFT+KEY SYNC resets	Same Up/Middle/Down ranges as Pitch Play (Pitch 'n Time pack)

Source: rekordbox pp.78–87; Serato pp.126–135.

9 · Effects reference

Beat FX (onboard list; identical in rekordbox and Serato docs)

Beat FX	What it does	BEAT ◀/▶ range	LEVEL/DEPTH
LOW CUT ECHO	Low-cut delay repeats decaying by beat	Delay 1/16–16 beats	Dry/wet balance
ECHO	Delay repeats decaying by beat	Delay 1/16–16	Dry/wet
MULTI TAP DELAY	Up to 7 repeats in 1/8-beat units	1/16–16	Dry/wet
SPIRAL	Reverb; pitch shifts as delay time changes	1/16–16	Dry/wet + feedback
REVERB	Reverb	Size 1–100 %	Dry/wet
TRANS	Rhythmic cut	Cycle 1/16–16	Dry/wet + cut length
ENIGMA JET	Flanger with endlessly rising/falling pitch	+1/16…+64 (rise), −64…−1/16 (fall)	Effect amount
FLANGER	One-cycle flanger	1/16–64 beats	Effect amount
PHASER	Phaser	1/16–64	Effect amount
STRETCH	Records input, outputs time-stretched	Retrigger 1/16–16	Stretch beats
SLIP ROLL	Records & repeats; re-records when time changes	1/16–16	Dry/wet
ROLL	Records & repeats	1/16–16	Dry/wet
MOBIUS (SAW)	Shepard-style saw tone mixed in (sounds even without input)	±1/16…±64	Saw volume
MOBIUS (TRI)	Same with triangle wave	±1/16…±64	Triangle volume

Sound Color FX (per-channel COLOR knob)

Effect	Type	COLOR knob behaviour
SPACE	Reverb	CCW: reverb on mid+low · CW: reverb on mid+high
DUB ECHO	Decaying echo	CCW: echo on mids · CW: echo on highs
CRUSH	Bit-crush	CCW: crush · CW: crush + HPF
PITCH	Pitch shift	CCW: down · CW: up
NOISE	White noise through filter	CCW: lower cutoff · CW: raise cutoff
FILTER	Filter	CCW: LPF down · CW: HPF up

Signal placement (from signal-flow diagram): NOISE and Beat FX can sit pre-EQ; FILTER/CRUSH/PITCH sit after the 3-band EQ (pre-fader); DUB ECHO/SPACE and Beat FX post-fader. Mic has its own REVERB (rekordbox MIC panel — reverb only).

Source: pp.92–101, 141–150, 174.

10 · Settings & properties

Three places to configure the unit: **rekordbox Preferences** (when connected to rekordbox — Utilities mode is locked out), **Utilities mode** on the hardware (hold BACK; for Serato/other/standalone), and the **Setting Utility** app.

rekordbox › Preferences

Tab	Setting	Values	Notes
Controller › Deck	Ring Brightness	OFF, 1–3	Jog ring brightness
	Ring Color	ACTIVE PART Linked 1 (mixed colours) · Linked 2 (white if >1 part) · Customize	Jog ring colour
	Display Brightness	1–5	On Jog Display
	Time Mode	Elapsed · Remaining	Jog time readout
	Slip Mode Flashing	Enable · Disable	Slip-capable buttons flash
	Slip button LED	Light is On · Blink	
	Vinyl Speed Adjust › Touch/Brake	slider	Used for Slip Braking
Controller › Mixer	CROSSFADER Curve	slow ↔ fast	
	Fader Start	checkbox	SHIFT + fader/crossfader starts playback
	CROSSFADER Cut Lag	0.3–5.5 mm (0.1 steps), default 1.0 mm	Approximate
	Booth Output	'Don't output microphone sound to the Booth output.'	Mic → booth on unless ticked
	Microphone › Talkover Mode	Advanced (mids only) · Normal (full band)	
	Microphone › Talkover Level	−6 / −12 / −18 / −24 dB	
	Headphones	STEREO · MONO SPLIT (+ invert L/R)	Mono split: cue L, master R
	Display Brightness	1–3	FX display
Controller › DDJ-FLX10	Master Output › Attenuator	0 / −6 / −12 dB	
	Master Output › Mono/Stereo	Monaural · Stereo	
	Booth Output › Attenuator	0 / −6 / −12 dB	
	Booth Output › Mono/Stereo	Monaural · Stereo	
	Peak Limiter › Master/Booth	Enable · Disable	
	Peak Limiter › Mic (Master) / Mic (Booth)	Enable · Disable	
	REC OUT	Mix the MIC audio to REC OUT	
	Demo / Screen saver	Demo 1/5/10 min (default 10) · Screen Saver (30 min) · Disable	
	Power Management	ON · OFF	Auto Off after 20 min idle
Controller › Recordings	Save destination	path	
Audio (Mac)	Audio / Master / Headphones	DDJ-FLX10 · MASTER (+ Mac device if PC Master Out) · PHONES	
Audio (Win)	Audio / Master / Headphones	DDJ-FLX10 ASIO · MASTER (+PC device) · PHONES	PC Master Out default ON

Utilities mode (hardware) — * = default

Hold BACK → turn rotary to item → press → turn to value → press. BACK cancels/exits.

Item	Values
POWER MANAGEMENT	OFF, ON*
DEMO/S.SAVER	DISABLE, DEMO 1min, DEMO 5min, DEMO 10min*, S.SAVER (30 min)
TALKOVER MODE	ADVANCED*, NORMAL
TALKOVER LEVEL	−6dB, −12dB, −18dB*, −24dB
PHONES OUT	STEREO*, MONO SPLIT
SPLIT CUE OUTPUT	NORMAL*, INVERT
MIC TO BOOTH	OFF, ON*
MIC LMT (MSTR)	OFF, ON*
MIC LMT (BOOTH)	OFF, ON*
MASTER ATT.	0dB*, −6dB, −12dB
MASTER OUT	STEREO*, MONO
MASTER LIMITER	OFF, ON*
BOOTH ATT.	0dB*, −6dB, −12dB
BOOTH OUT	STEREO*, MONO
JOG RING BRT.	OFF, 1, 2, 3*
JOG DISP. BRT.	1, 2, 3, 4, 5*
DISPLAY BRT. (FX display)	1, 2, 3*
CR FDR CUT LAG	0–52, default 7
FACTORY RESET	CANCEL*, RESET

Setting Utility (PC/Mac app)

Item	Values / purpose
Software	Selects which items appear (Serato DJ Pro / Other software)
Slip Mode Flashing	Serato: flash related LEDs in slip
Slip button LED	Serato: Light is on / Blink
Fader Start options	Serato/Other: ON + optional Sync on Fader Start
JOG RING COLOR	Serato: MODE 1 / 2 / 3
Time Mode	Serato: Elapsed / Remaining (Waveform mode)
Display HOT CUE INDICATOR	Serato: Hot Cues on Virtual Deck mode
REC OUT	Serato/Other: WITH MIC / WITHOUT MIC
ASIO tab (Windows)	Buffer size: larger = fewer dropouts, more latency. Quit apps using the unit first
About tab	Firmware & driver versions; DJ Logo image (bmp/jpeg/png/gif) via Image Transfer Tool — quit DJ software first

Source: pp.107–113, 154–164. Note: Utilities cut-lag scale (0–52 steps) and rekordbox scale (0.3–5.5 mm) describe the same range in different units.

11 · Events, triggers & automatic behaviours

Hardware/firmware behaviours that fire on a condition rather than a direct button meaning. Software-level MIDI events are in §13–16.

Event	Trigger condition	Result
Power Management → Off mode	20 min with no control input AND no input signal ≥ −24 dB (when ON)	Left-deck QUANTIZE lights; press it to wake
Demo mode	No operation for 1/5/10 min (default 10)	Any knob/button cancels
Screen saver	No operation for 30 min (S.SAVER setting)	Any control cancels
Talkover ducking	Mic switch at TALKOVER and mic input ≥ −10 dB	Other channels attenuated by Talkover Level (default −18 dB); Advanced = mids only
CLIP indicator	Master near/at clipping	Slow flash = near · fast flash = distorting
Peak limiter	Master/Booth/Mic output would clip digitally (when enabled)	Limits output
Slip Reverse auto-cancel	8 beats of held reverse	Returns to background position
Fader Start	SHIFT + channel fader up from zero / crossfader toward channel	Play from cue; SHIFT + fader back = Back Cue. No cue = play from start
Mix Point Link auto-start	Playing deck reaches linked mix point	Next track starts from its beginning so its mix point lands on link; countdown on jog
Mix Point Link cancel	Playing deck jumps before mix point (hot cue, scratch…)	Link drops; MIX POINT LINK flashes — press to relink
Instant Doubles	Rotary pressed twice on idle deck	Clones playing deck & position
Part Instant Doubles	SHIFT + ACTIVE PART ×2	Clone; this deck = that part only, other deck mutes it
BPM display flash	Beat FX can't detect BPM	Shows last detected value, flashing
On Air colour	Deck playing	White = decks 1/2, blue = decks 3/4
Track Separation indicator	Stem separation finished (rekordbox)	Lights on jog
Mic in PC Master Out	Always	Mic sound never goes to computer speakers
Recording without unit	rekordbox, no subscription	Recording unavailable unless unit/Hardware Unlock device connected
Software switch	Changing DJ apps	Power-cycle the unit; never run two DJ apps at once

12 · Workflows

A. First-time setup

1. pioneerdj.com/support › Software & firmware updates › DDJ-FLX10 › Drivers → download. Windows: run DDJ-FLX10_#.###.exe (driver + Setting Utility). Mac: install DDJ-FLX10SettingUtility.pkg only.
2. Unit off & USB unplugged during install; admin rights; close all apps.
3. Install rekordbox (rekordbox.com; requires Pioneer DJ account) and/or Serato DJ Pro (serato.com; no licence purchase needed with this unit — ignore BUY/ACTIVATE). Don't connect the unit until installs finish.
4. Cable per §2, power on. In rekordbox confirm Audio = DDJ-FLX10 (ASIO on Windows). Switch rekordbox to PERFORMANCE mode if controls do nothing.

B. Gain staging & first playback (deck 1)

1. Input switch = A · TRIM fully CCW · EQ 12 o'clock · COLOR centre · fader down · MASTER LEVEL fully CCW · crossfader centre · assign THRU.
2. Load: rotary to track, press. Press PLAY.
3. Raise TRIM until channel meter hits orange on peaks.
4. Fader up. Bring MASTER LEVEL up to taste (use computer volume if using PC Master Out).

C. Headphone cueing

1. HEADPHONES MIX centre, LEVEL fully CCW.
2. Press channel CUE.
3. Raise HEADPHONES LEVEL.

D. Loops

- 4-beat: press 4 BEAT/EXIT (again = exit; track continues past loop).
- Manual: LOOP IN at start, LOOP OUT at end. In loop: LOOP IN = halve, LOOP OUT = double. SHIFT+LOOP IN/OUT + jog = move in/out point. SHIFT+LOOP OUT = reloop. Quantize may delay snap slightly.
- Save loop/cue (rekordbox): pause at point → CUE → SHIFT+CUE/LOOP CALL ◀. Recall with CUE/LOOP CALL ◀/▶; delete with SHIFT+CUE/LOOP CALL ▶.

E. Slip techniques (SLIP on; Vinyl on for scratch)

- Slip Scratch: scratch top of jog, release → resumes background position.
- Slip Hot Cue: hold pad, release → resumes.
- Slip Braking: set brake time (rekordbox Vinyl Speed Adjust › Touch/Brake; Serato BRAKING › Stop Time) → PLAY/PAUSE slows to stop → PLAY resumes background position.
- Slip Auto/Manual Loop: loop, then 4 BEAT/EXIT → resumes.

F. Fader Start

1. Enable (rekordbox Prefs › Mixer › Fader Start; Serato via Setting Utility).
2. Set cue on paused deck.
3. Channel: SHIFT + fader up = play; SHIFT + fader down = Back Cue.
4. Crossfader: assign channel to A/B, park crossfader on opposite side, SHIFT + move toward channel = play.

G. Mix Point Link (rekordbox) — deck 1 playing track A, track B on deck 2

1. SHIFT+PAGE → Waveform mode (have cues/hot cues set at intended mix points).
2. Load B to deck 2 (upper waveform = B, lower = A).
3. On deck 2 call up B's start point (CUE/LOOP CALL or hot-cue pad).
4. On deck 2 press MIX POINT SELECT ◀/▶ to choose A's end point (status turns green).
5. Press MIX POINT LINK on deck 2 → B auto-starts so the points align. SHIFT+MIX POINT LINK at a point = Silent until there. Cancel: MIX POINT LINK again or SHIFT+MIX POINT SELECT ◀.

H. Stems

- ACTIVE PART buttons mute/solo stems; SHIFT+CH CUE flips EQ knobs to Part ISO; FX PART SELECT targets FX at stems; SHIFT+ACTIVE PART ×2 for Part Instant Doubles.

I. Beat FX

1. SHIFT+BEAT ◀ = AUTO BPM, SHIFT+BEAT ▶ = TAP.
2. Pick FX (select knob) and channel (CH knob).
3. BEAT ◀/▶ sets beat length.
4. BEAT FX ON/OFF, ride LEVEL/DEPTH.

J. Sound Color FX

1. Press a SOUND COLOR FX button (flashes).
2. Turn the channel's COLOR knob. Press flashing button again to cancel.

K. Sampler (rekordbox)

1. Show SAMPLER panel. SAMPLER mode, PAGE for bank.
2. Rotary to track, SHIFT+pad to load slot.
3. Pad plays; re-press retriggers; SHIFT+pad stops. Cue via SAMPLER CUE, level via SAMPLER VOL.

L. Microphone

1. Mic into MIC 1/2. Switch ON (lit) or TALKOVER (flashing).
2. MIC LEVEL knob (full right = loud). Shape with MIC EQ.
3. rekordbox MIC panel: FX knob + REVERB. Serato can't process mic.

M. External sources (works without a computer)

1. Multi player → LINE (CH1/2) or LINE/PHONO (CH3/4, rear switch LINE). Turntable → CH3/4 only, rear switch PHONO, ground to SIGNAL GND.
2. Top switch to LINE or PHONO/LINE. TRIM + fader.

N. Recording

- rekordbox: REC panel → record button; file auto-saves (destination: Prefs › Controller › Recordings). Serato: REC panel → REC. Mic inclusion set by REC OUT setting.

O. Two computers / B2B

- USB A and USB B each carry a full audio/MIDI stream (PC-A / PC-B). Channel input switches pick A or B per channel, so two DJs can transition on one mixer.

P. Custom DJ logo

1. Quit DJ software. Setting Utility › About › Setting → Image Transfer Tool.
2. Open image (bmp/jpeg/png/gif) → Transfer. Delete to remove. Check in DJ Logo Display.

Q. Lighting (DMX)

- DMX cable (XLR 3-pin) to fixture. Map fixtures in rekordbox LIGHTING › FIXTURE LIBRARY; [No Assign] = unsupported fixture.

R. Using another DJ app (MIDI)

1. Windows: install ASIO driver first.
2. Only one DJ app running. Power-cycle unit when switching apps.
3. Map controls in the app using §13–16. Some controls may not be usable.

13 · MIDI map — conventions & channels

- **Status bytes:** 0x9* = Note, 0xB* = Control Change. Low nibble = MIDI channel − 1.
- **Buttons:** Note with velocity 0x7F = pressed, 0x00 = released. Buttons that also list a MIDI-OUT echo accept the same note back to light the LED (0x7F on, 0x00 off).
- **14-bit faders/knobs:** two CCs — MSB on CC x, LSB on CC x+32. Range 0x00/0x00 → 0x7F/0x7F. Knob min = fully CCW, faders min = bottom (crossfader min = left).
- **Relative encoders** (jog, browse): value is the delta since last message. Jog: CW = 65 (0x41) and up; CCW = 63 (0x3F) and down. Browse: CW 1–30 (0x01–0x1E); CCW 127–98 (0x7F–0x62).
- **Note names** in this list use the convention 60 = C4 (so 0 = C−1, 127 = G9).
- **Right-hand decks** send identical data to the left decks; only the channel differs.
- **Notation in tables:** "Ch" = MIDI channel 1–16; "1-4" = deck channel n; IN = controller → computer; OUT = computer → controller (LED/feedback).

Category	MIDI ch	Hex nibble	Status
DECK 1 (non-pad)	1	0	9n / Bn, n=0
DECK 2 (non-pad)	2	1	n=1
DECK 3 (non-pad)	3	2	n=2
DECK 4 (non-pad)	4	3	n=3
EFFECT	5	4	0x94 / 0xB4
(unused)	6	5	—
BROWSER / global mixer	7	6	0x96 / 0xB6
DECK 1 PADS (no SHIFT)	8	7	9p, p=7
DECK 1 PADS (SHIFT)	9	8	p=8
DECK 2 PADS (no SHIFT)	10	9	p=9
DECK 2 PADS (SHIFT)	11	A	p=A
DECK 3 PADS (no SHIFT)	12	B	p=B
DECK 3 PADS (SHIFT)	13	C	p=C
DECK 4 PADS (no SHIFT)	14	D	p=D
DECK 4 PADS (SHIFT)	15	E	p=E
MIDI-OUT communication (display/LED)	16	F	0x9F / 0xBF

Source: DDJ-FLX10 List of MIDI Messages (E1), p.1. Use this when mapping in VirtualDJ, Traktor, djay, Mixxx, etc.

14 · MIDI map — Browser, Deck, Mixer, Effects

'Ch 1-4' = deck channel (status 0x90–0x93 / 0xB0–0xB3). 'LED out = yes' means the same Note can be sent back on the same channel to drive the button LED.

Browser

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
B1	**BROWSE rotate**	—	7	CC	64	—	0x40	—	relative: CW 0x01–0x1E, CCW 0x7F–0x62
B1	**BROWSE rotate**	+SHIFT	7	CC	100	—	0x64	—	relative
B1	**BROWSE press (deck1 sel, left)**	—	7	NOTE	70	A#4	0x46	—	
B1	**BROWSE press (deck1)**	+SHIFT	7	NOTE	93	A6	0x5D	—	
B1	**BROWSE press (deck2 sel, right)**	—	7	NOTE	71	B4	0x47	—	
B1	**BROWSE press (deck2)**	+SHIFT	7	NOTE	109	C#8	0x6D	—	
B1	**BROWSE press (deck3 sel, left)**	—	7	NOTE	72	C5	0x48	—	
B1	**BROWSE press (deck3)**	+SHIFT	7	NOTE	94	A#6	0x5E	—	
B1	**BROWSE press (deck4 sel, right)**	—	7	NOTE	73	C#5	0x49	—	
B1	**BROWSE press (deck4)**	+SHIFT	7	NOTE	111	D#8	0x6F	—	
B2	**BACK**	press	7	NOTE	101	F7	0x65	—	
B2	**BACK**	+SHIFT	7	NOTE	102	F#7	0x66	—	
B3	**VIEW**	press	7	NOTE	122	D9	0x7A	—	
B3	**VIEW**	long press	7	NOTE	103	G7	0x67	—	
B3	**VIEW**	+SHIFT	7	NOTE	104	G#7	0x68	—	

Deck (left and right decks identical; channel selects deck)

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
D1	**PLAY/PAUSE**	press	1-4	NOTE	11	B-1	0x0B	yes	
D1	**PLAY/PAUSE**	+SHIFT	1-4	NOTE	71	B4	0x47	yes	
D2	**CUE**	press	1-4	NOTE	12	C0	0x0C	yes	
D2	**CUE**	+SHIFT	1-4	NOTE	72	C5	0x48	yes	
D3	**JOG platter rotate (Vinyl on)**	—	1-4	CC	34	—	0x22	—	relative, 0x41+ CW / 0x3F− CCW
D3	**JOG platter rotate (Vinyl off)**	—	1-4	CC	35	—	0x23	—	relative
D3	**JOG platter rotate**	+4 BEAT JUMP	1-4	CC	41	—	0x29	—	relative
D3	**JOG platter rotate**	+SHIFT	1-4	CC	31	—	0x1F	—	relative
D3	**JOG platter touch**	—	1-4	NOTE	54	F#3	0x36	—	
D3	**JOG platter touch**	+SHIFT	1-4	NOTE	103	G7	0x67	—	
D3	**JOG side rotate**	—	1-4	CC	33	—	0x21	—	relative
D3	**JOG side rotate**	+SHIFT	1-4	CC	38	—	0x26	—	relative
D4	**TEMPO slider**	—	1-4	CC	0 / 32	—	0x00 / 0x20	—	14-bit MSB/LSB; '−' end = min
D4	**TEMPO slider**	+SHIFT	1-4	CC	5 / 37	—	0x05 / 0x25	—	14-bit
D5	**DECK SELECT (any press)**	press	3 / 4	NOTE	114	F#8	0x72	—	sent on ch3 (left) / ch4 (right)
D5	**DECK SELECT → DECK 1**	press	1 & 3	NOTE	60	C4	0x3C	—	ch1 0x7F (deck1 on) + ch3 0x00 (deck3 off)

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
D5	**DECK SELECT → DECK 3**	press	1 & 3	NOTE	60	C4	0x3C	—	ch1 0x00 + ch3 0x7F
D5	**DECK SELECT → DECK 2**	press	2 & 4	NOTE	60	C4	0x3C	—	ch2 0x7F + ch4 0x00
D5	**DECK SELECT → DECK 4**	press	2 & 4	NOTE	60	C4	0x3C	—	ch2 0x00 + ch4 0x7F
D5	**DECK SELECT 1/3**	+SHIFT	7	NOTE	124	E9	0x7C	—	
D5	**DECK SELECT 2/4**	+SHIFT	7	NOTE	125	F9	0x7D	—	
D6	**BEAT SYNC**	press	1-4	NOTE	88	E6	0x58	yes	
D6	**BEAT SYNC**	long press	1-4	NOTE	120	C9	0x78	yes	
D6	**BEAT SYNC**	+SHIFT	1-4	NOTE	92	G#6	0x5C	yes	
D7	**TEMPO RESET**	press	1-4	NOTE	65	F4	0x41	yes	
D7	**TEMPO RESET**	+SHIFT	1-4	NOTE	96	C7	0x60	yes	
D8	**KEY SYNC**	press	1-4	NOTE	101	F7	0x65	yes	
D8	**KEY SYNC**	long press	1-4	NOTE	26	D1	0x1A	yes	
D8	**KEY SYNC**	+SHIFT	1-4	NOTE	100	E7	0x64	yes	
D9	**ACTIVE PART DRUMS**	press	1-4	NOTE	13	C#0	0x0D	yes	
D9	**DRUMS +SHIFT ×2 deck1/2/3/4**	+SHIFT ×2	7	NOTE	36	C2	0x24	yes	deck1=36, deck2=37, deck3=38, deck4=39
D10	**ACTIVE PART VOCAL**	press	1-4	NOTE	14	D0	0x0E	yes	
D10	**VOCAL +SHIFT ×2 deck1–4**	+SHIFT ×2	7	NOTE	40	E2	0x28	yes	40, 41, 42, 43
D11	**ACTIVE PART INST**	press	1-4	NOTE	15	D#0	0x0F	yes	
D11	**INST +SHIFT ×2 deck1–4**	+SHIFT ×2	7	NOTE	44	G#2	0x2C	yes	44, 45, 46, 47
D12	**CUE/LOOP CALL ◀**	press	1-4	NOTE	81	A5	0x51	—	
D12	**CUE/LOOP CALL ◀**	+SHIFT	1-4	NOTE	61	C#4	0x3D	—	
D13	**CUE/LOOP CALL ▶**	press	1-4	NOTE	83	B5	0x53	—	
D13	**CUE/LOOP CALL ▶**	+SHIFT	1-4	NOTE	62	D4	0x3E	—	
D14	**LOOP IN 1/2X**	press	1-4	NOTE	16	E0	0x10	yes	
D14	**LOOP IN 1/2X**	+SHIFT	1-4	NOTE	76	E5	0x4C	yes	
D15	**LOOP OUT 2X**	press	1-4	NOTE	17	F0	0x11	yes	
D15	**LOOP OUT 2X**	+SHIFT	1-4	NOTE	77	F5	0x4D	yes	
D16	**4 BEAT/EXIT**	press	1-4	NOTE	20	G#0	0x14	yes	
D16	**4 BEAT/EXIT**	+SHIFT	1-4	NOTE	80	G#5	0x50	yes	
D17	**MIX POINT SELECT ◀**	press	1-4	NOTE	89	F6	0x59	—	
D17	**MIX POINT SELECT ◀**	+SHIFT	1-4	NOTE	73	C#5	0x49	—	
D18	**MIX POINT SELECT ▶**	press	1-4	NOTE	90	F#6	0x5A	—	
D18	**MIX POINT SELECT ▶**	+SHIFT	1-4	NOTE	66	F#4	0x42	—	
D19	**MIX POINT LINK**	press	1-4	NOTE	74	D5	0x4A	yes	
D19	**MIX POINT LINK**	+SHIFT	1-4	NOTE	67	G4	0x43	yes	
D20	**SLIP REVERSE**	press	1-4	NOTE	21	A0	0x15	yes	
D20	**SLIP REVERSE**	+SHIFT	1-4	NOTE	56	G#3	0x38	yes	
D21	**QUANTIZE**	press	1-4	NOTE	53	F3	0x35	yes	
D21	**QUANTIZE**	+SHIFT	1-4	NOTE	104	G#7	0x68	yes	
D22	**SLIP**	press	1-4	NOTE	64	E4	0x40	yes	

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
D22	**SLIP**	+SHIFT	1-4	NOTE	23	B0	0x17	yes	
D23	**4 BEAT JUMP ◀**	press	1-4	NOTE	94	A#6	0x5E	—	
D23	**4 BEAT JUMP ◀**	long press	1-4	NOTE	112	E8	0x70	—	
D23	**4 BEAT JUMP ◀**	+SHIFT	1-4	NOTE	97	C#7	0x61	—	
D24	**4 BEAT JUMP ▶**	press	1-4	NOTE	95	B6	0x5F	—	
D24	**4 BEAT JUMP ▶**	long press	1-4	NOTE	113	F8	0x71	—	
D24	**4 BEAT JUMP ▶**	+SHIFT	1-4	NOTE	98	D7	0x62	—	
D25	**SHIFT**	press	1-4	NOTE	63	D#4	0x3F	—	

Mixer

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
M1	**CROSSFADER**	slide	7	CC	31 / 63	—	0x1F / 0x3F	—	14-bit; min left, max right
M2	**CH FADER**	slide	1-4	CC	19 / 51	—	0x13 / 0x33	—	14-bit; min bottom
M1/M2	**Fader start: zero → not zero**	+SHIFT	1-4	NOTE	102	F#7	0x66	—	PLAY message
M1/M2	**Fader start: zero → not zero (sync)**	+SHIFT	1-4	NOTE	93	A6	0x5D	—	SYNC message
M1/M2	**Fader start: not zero → zero**	+SHIFT	1-4	NOTE	82	A#5	0x52	—	CUE message
M3	**TRIM**	rotate	1-4	CC	4 / 36	—	0x04 / 0x24	—	14-bit MSB/LSB
M4	**EQ HI**	rotate	1-4	CC	7 / 39	—	0x07 / 0x27	—	14-bit MSB/LSB
M5	**EQ MID**	rotate	1-4	CC	11 / 43	—	0x0B / 0x2B	—	14-bit MSB/LSB
M6	**EQ LOW**	rotate	1-4	CC	15 / 47	—	0x0F / 0x2F	—	14-bit MSB/LSB
M7	**CH CUE**	press	1-4	NOTE	84	C6	0x54	yes	
M7	**CH CUE**	+SHIFT	1-4	NOTE	57	A3	0x39	yes	
M8	**MASTER LEVEL**	rotate	7	CC	8 / 40	—	0x08 / 0x28	—	14-bit MSB/LSB
M9	**MASTER CUE**	press	7	NOTE	99	D#7	0x63	—	
M9	**MASTER CUE**	+SHIFT	7	NOTE	98	D7	0x62	—	
M10	**BOOTH LEVEL**	rotate	7	CC	9 / 41	—	0x09 / 0x29	—	14-bit MSB/LSB
M11	**CROSSFADER ASSIGN**	switch	1-4	NOTE	22 / 24 / 29	A#0 / C1 / F1	0x16 / 0x18 / 0x1D	—	Position state: A → 0x16=7F · B → 0x18=7F · THRU → 0x1D=7F (others 00)
M12	**HEADPHONES MIX**	rotate	7	CC	12 / 44	—	0x0C / 0x2C	—	14-bit MSB/LSB
M13	**HEADPHONES LEVEL**	rotate	7	CC	13 / 45	—	0x0D / 0x2D	—	14-bit MSB/LSB
M14	**MIC EQ HI**	rotate	7	CC	7 / 39	—	0x07 / 0x27	—	14-bit MSB/LSB
M15	**MIC EQ LOW**	rotate	7	CC	15 / 47	—	0x0F / 0x2F	—	14-bit MSB/LSB

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
M16	**LINE/PHONO (CH3/CH4 rear)**	switch	3 / 4	NOTE	70	A#4	0x46	—	PHONO = 0x00, LINE = 0x7F
M17	**INPUT SELECT**	switch	1-4	NOTE	85 / 86 / 87	C#6 / D6 / D#6	0x55 / 0x56 / 0x57	—	PC-A → 0x55=7F · LINE or PHONO/LINE → 0x56=7F · PC-B → 0x57=7F
M18	**MIC OFF/ON/TALKOVER**	switch	7	NOTE	106 / 107 / 108	A#7 / B7 / C8	0x6A / 0x6B / 0x6C	—	OFF → 0x6A=7F · ON → 0x6B=7F · TALKOVER → 0x6C=7F
M19	**SAMPLER CUE**	press	7	NOTE	105	A7	0x69	yes	
M19	**SAMPLER CUE**	+SHIFT	7	NOTE	110	D8	0x6E	yes	
M20	**SAMPLER VOL**	rotate	7	CC	3 / 35	—	0x03 / 0x23	—	14-bit MSB/LSB
M21	**MASTER LEVEL METER**	—	—	—	–	—	–	—	No MIDI control
M22	**CH LEVEL METER**	OUT	1-4	CC	2	—	0x02	OUT only	Computer sends Bn 02 hh; used when input = PC-A/PC-B

Effects

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
F1	**COLOR (CH1)**	rotate	7	CC	23 / 55	—	0x17 / 0x37	—	14-bit MSB/LSB
F1	**COLOR (CH2)**	rotate	7	CC	24 / 56	—	0x18 / 0x38	—	14-bit MSB/LSB
F1	**COLOR (CH3)**	rotate	7	CC	25 / 57	—	0x19 / 0x39	—	14-bit MSB/LSB
F1	**COLOR (CH4)**	rotate	7	CC	26 / 58	—	0x1A / 0x3A	—	14-bit MSB/LSB
F2	**SOUND COLOR FX SPACE**	press	7	NOTE	0	C-1	0x00	yes	
F2	**SPACE**	+SHIFT	7	NOTE	8	G#-1	0x08	yes	
F3	**SOUND COLOR FX DUB ECHO**	press	7	NOTE	1	C#-1	0x01	yes	
F3	**DUB ECHO**	+SHIFT	7	NOTE	9	A-1	0x09	yes	
F4	**SOUND COLOR FX CRUSH**	press	7	NOTE	2	D-1	0x02	yes	
F4	**CRUSH**	+SHIFT	7	NOTE	10	A#-1	0x0A	yes	
F5	**SOUND COLOR FX PITCH**	press	7	NOTE	3	D#-1	0x03	yes	
F5	**PITCH**	+SHIFT	7	NOTE	11	B-1	0x0B	yes	
F6	**SOUND COLOR FX NOISE**	press	7	NOTE	4	E-1	0x04	yes	
F6	**NOISE**	+SHIFT	7	NOTE	12	C0	0x0C	yes	
F7	**SOUND COLOR FX FILTER**	press	7	NOTE	5	F-1	0x05	yes	
F7	**FILTER**	+SHIFT	7	NOTE	13	C#0	0x0D	yes	
F8	**FX PART SELECT VOCAL**	press	7	NOTE	27	D#1	0x1B	yes	
F8	**VOCAL**	+SHIFT	7	NOTE	30	F#1	0x1E	yes	
F9	**FX PART SELECT DRUMS**	press	7	NOTE	28	E1	0x1C	yes	
F9	**DRUMS**	+SHIFT	7	NOTE	31	G1	0x1F	yes	
F10	**FX PART SELECT INST**	press	7	NOTE	29	F1	0x1D	yes	
F10	**INST**	+SHIFT	7	NOTE	32	G#1	0x20	yes	
F11	**BEAT ◀**	press	5	NOTE	74	D5	0x4A	—	
F11	**BEAT ◀**	+SHIFT	5	NOTE	102	F#7	0x66	—	
F12	**BEAT ▶**	press	5	NOTE	75	D#5	0x4B	—	
F12	**BEAT ▶**	+SHIFT	5	NOTE	107	B7	0x6B	—	
F13	**BEAT FX SELECT → LOW CUT ECHO**	rotate	5	NOTE	32	G#1	0x20	—	position state (see §19)

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
F13	**BEAT FX SELECT → ECHO**	rotate	5	NOTE	33	A1	0x21	—	position state (see §19)
F13	**BEAT FX SELECT → MT DELAY**	rotate	5	NOTE	34	A#1	0x22	—	position state (see §19)
F13	**BEAT FX SELECT → SPIRAL**	rotate	5	NOTE	35	B1	0x23	—	position state (see §19)
F13	**BEAT FX SELECT → REVERB**	rotate	5	NOTE	36	C2	0x24	—	position state (see §19)
F13	**BEAT FX SELECT → TRANS**	rotate	5	NOTE	37	C#2	0x25	—	position state (see §19)
F13	**BEAT FX SELECT → ENIGMA JET**	rotate	5	NOTE	38	D2	0x26	—	position state (see §19)
F13	**BEAT FX SELECT → FLANGER**	rotate	5	NOTE	39	D#2	0x27	—	position state (see §19)
F13	**BEAT FX SELECT → PHASER**	rotate	5	NOTE	40	E2	0x28	—	position state (see §19)
F13	**BEAT FX SELECT → STRETCH**	rotate	5	NOTE	41	F2	0x29	—	position state (see §19)
F13	**BEAT FX SELECT → SLIP ROLL**	rotate	5	NOTE	42	F#2	0x2A	—	position state (see §19)
F13	**BEAT FX SELECT → ROLL**	rotate	5	NOTE	43	G2	0x2B	—	position state (see §19)
F13	**BEAT FX SELECT → MOBIUS SAW**	rotate	5	NOTE	44	G#2	0x2C	—	position state (see §19)
F13	**BEAT FX SELECT → MOBIUS TRI**	rotate	5	NOTE	45	A2	0x2D	—	position state (see §19)
F14	**BEAT FX CH SELECT → CH 1**	rotate	5	NOTE	16	E0	0x10	—	position state
F14	**BEAT FX CH SELECT → CH 2**	rotate	5	NOTE	17	F0	0x11	—	position state
F14	**BEAT FX CH SELECT → CH 3**	rotate	5	NOTE	18	F#0	0x12	—	position state
F14	**BEAT FX CH SELECT → CH 4**	rotate	5	NOTE	19	G0	0x13	—	position state
F14	**BEAT FX CH SELECT → MASTER**	rotate	5	NOTE	20	G#0	0x14	—	position state
F14	**BEAT FX CH SELECT → MIC**	rotate	5	NOTE	21	A0	0x15	—	position state
F14	**BEAT FX CH SELECT → SAMPLER**	rotate	5	NOTE	22	A#0	0x16	—	position state
F15	**LEVEL/DEPTH**	rotate	5	CC	2 / 34	—	0x02 / 0x22	—	14-bit MSB/LSB
F16	**BEAT FX ON/OFF**	press	5	NOTE	71	B4	0x47	yes	
F16	**BEAT FX ON/OFF**	+SHIFT	5	NOTE	67	G4	0x43	yes	

15 · MIDI map — Performance Pads & pad-mode buttons

Each pad sends a Note whose number depends on **pad mode** and **page**: `note = mode_base + (page−1)×8 + (pad−1)`. The same numbers are used with and without SHIFT; SHIFT moves the message to the next MIDI channel. All pads echo (LED out): send the note back with velocity 1–127 = palette colour, 0x00 = dimmed. Pad press: 0x7F on / 0x00 off.

Pad channels

Deck	Ch (no SHIFT)	Status	Ch (+SHIFT)	Status
1	8	0x97	9	0x98
2	10	0x99	11	0x9A
3	12	0x9B	13	0x9C
4	14	0x9D	15	0x9E

Pad note matrix (decimal · hex · note name)

Pad mode	Page	Pad 1	Pad 2	Pad 3	Pad 4	Pad 5	Pad 6	Pad 7	Pad 8
HOT CUE	P1	0 0x00 · C-1	1 0x01 · C#-1	2 0x02 · D-1	3 0x03 · D#-1	4 0x04 · E-1	5 0x05 · F-1	6 0x06 · F#-1	7 0x07 · G-1
HOT CUE	P2	8 0x08 · G#-1	9 0x09 · A-1	10 0x0A · A#-1	11 0x0B · B-1	12 0x0C · C0	13 0x0D · C#0	14 0x0E · D0	15 0x0F · D#0
PAD FX 1	P1	16 0x10 · E0	17 0x11 · F0	18 0x12 · F#0	19 0x13 · G0	20 0x14 · G#0	21 0x15 · A0	22 0x16 · A#0	23 0x17 · B0
PAD FX 1	P2	24 0x18 · C1	25 0x19 · C#1	26 0x1A · D1	27 0x1B · D#1	28 0x1C · E1	29 0x1D · F1	30 0x1E · F#1	31 0x1F · G1
BEAT JUMP	P1	32 0x20 · G#1	33 0x21 · A1	34 0x22 · A#1	35 0x23 · B1	36 0x24 · C2	37 0x25 · C#2	38 0x26 · D2	39 0x27 · D#2
BEAT JUMP	P2	40 0x28 · E2	41 0x29 · F2	42 0x2A · F#2	43 0x2B · G2	44 0x2C · G#2	45 0x2D · A2	46 0x2E · A#2	47 0x2F · B2
SAMPLER	P1	48 0x30 · C3	49 0x31 · C#3	50 0x32 · D3	51 0x33 · D#3	52 0x34 · E3	53 0x35 · F3	54 0x36 · F#3	55 0x37 · G3
SAMPLER	P2	56 0x38 · G#3	57 0x39 · A3	58 0x3A · A#3	59 0x3B · B3	60 0x3C · C4	61 0x3D · C#4	62 0x3E · D4	63 0x3F · D#4
KEYBOARD	P1	64 0x40 · E4	65 0x41 · F4	66 0x42 · F#4	67 0x43 · G4	68 0x44 · G#4	69 0x45 · A4	70 0x46 · A#4	71 0x47 · B4
KEYBOARD	P2	72 0x48 · C5	73 0x49 · C#5	74 0x4A · D5	75 0x4B · D#5	76 0x4C · E5	77 0x4D · F5	78 0x4E · F#5	79 0x4F · G5
PAD FX 2	P1	80 0x50 · G#5	81 0x51 · A5	82 0x52 · A#5	83 0x53 · B5	84 0x54 · C6	85 0x55 · C#6	86 0x56 · D6	87 0x57 · D#6
PAD FX 2	P2	88 0x58 · E6	89 0x59 · F6	90 0x5A · F#6	91 0x5B · G6	92 0x5C · G#6	93 0x5D · A6	94 0x5E · A#6	95 0x5F · B6
BEAT LOOP	P1	96 0x60 · C7	97 0x61 · C#7	98 0x62 · D7	99 0x63 · D#7	100 0x64 · E7	101 0x65 · F7	102 0x66 · F#7	103 0x67 · G7
BEAT LOOP	P2	104 0x68 · G#7	105 0x69 · A7	106 0x6A · A#7	107 0x6B · B7	108 0x6C · C8	109 0x6D · C#8	110 0x6E · D8	111 0x6F · D#8
KEY SHIFT	P1	112 0x70 · E8	113 0x71 · F8	114 0x72 · F#8	115 0x73 · G8	116 0x74 · G#8	117 0x75 · A8	118 0x76 · A#8	119 0x77 · B8
KEY SHIFT	P2	120 0x78 · C9	121 0x79 · C#9	122 0x7A · D9	123 0x7B · D#9	124 0x7C · E9	125 0x7D · F9	126 0x7E · F#9	127 0x7F · G9

Pad-mode buttons (deck channel 1-4, LED out yes)

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
P9	**HOT CUE MODE**	press	1-4	NOTE	27	D#1	0x1B	yes	

Fig	Control	Condition	Ch	Type	Dec	Note	Data1	LED out	Notes
P9	**HOT CUE MODE**	long press	1-4	NOTE	75	D#5	0x4B	yes	
P9	**HOT CUE MODE**	+SHIFT	1-4	NOTE	105	A7	0x69	yes	
P10	**PAD FX 1 MODE**	press	1-4	NOTE	30	F#1	0x1E	yes	
P10	**PAD FX 1 MODE**	+SHIFT	1-4	NOTE	107	B7	0x6B	yes	
P11	**BEAT JUMP MODE**	press	1-4	NOTE	32	G#1	0x20	yes	
P11	**BEAT JUMP MODE**	+SHIFT	1-4	NOTE	109	C#8	0x6D	yes	
P12	**SAMPLER MODE**	press	1-4	NOTE	34	A#1	0x22	yes	
P12	**SAMPLER MODE**	+SHIFT	1-4	NOTE	111	D#8	0x6F	yes	

PAGE ◀ / PAGE ▶ (deck channel; message depends on current pad mode; LED out yes)

Pad mode	PAGE ◀	PAGE ◀ +SHIFT	PAGE ▶	PAGE ▶ +SHIFT
HOT CUE	36 (0x24)	1 (0x01)	44 (0x2C)	9 (0x09)
PAD FX 1	37 (0x25)	2 (0x02)	45 (0x2D)	122 (0x7A)
BEAT JUMP	38 (0x26)	3 (0x03)	46 (0x2E)	123 (0x7B)
SAMPLER	39 (0x27)	4 (0x04)	47 (0x2F)	124 (0x7C)
KEYBOARD	40 (0x28)	5 (0x05)	48 (0x30)	125 (0x7D)
PAD FX 2	41 (0x29)	6 (0x06)	49 (0x31)	126 (0x7E)
BEAT LOOP	42 (0x2A)	7 (0x07)	50 (0x32)	127 (0x7F)
KEY SHIFT	43 (0x2B)	8 (0x08)	51 (0x33)	0 (0x00)

PAGE ◀ selects page 1 and PAGE ▶ page 2 in every mode; switching page changes the pad notes (e.g. deck 1 Hot Cue: page 1 = 97 00–07, page 2 = 97 08–0F).

Source: MIDI list pp.4–6. Pad matrix verified against every row in the official list.

16 · MIDI-OUT (feedback / display control)

Channel 16 (0x9F / 0xBF) carries display data from software to the On Jog Displays. This is what a third-party mapping must send to make the jog screens and rings show deck state.

Function	Type	Data 1 (MSB/LSB)	Value / range
Digital Marker deck 1/2/3/4	CC (BF)	0x10/0x30 · 0x11/0x31 · 0x12/0x32 · 0x13/0x33	14-bit 0–359° (max MSB 0x02, LSB 0x67)
BPM deck 1–4	CC (BF)	0x14/0x34 · 0x15/0x35 · 0x16/0x36 · 0x17/0x37	0.0–999.9 BPM (max 0x4E/0x0F ⇒ value ×10, 7-bit split: 9999)
Playing speed deck 1–4	CC (BF)	0x18/0x38 · 0x19/0x39 · 0x1A/0x3A · 0x1B/0x3B	−100.0 % to +100.0 % (0x00/0x00 – 0x4E/0x0F)
Time minutes deck 1–4	CC (BF)	0x42 · 0x44 · 0x46 · 0x48	0–99
Time seconds deck 1–4	CC (BF)	0x43 · 0x45 · 0x47 · 0x49	0–99
Time mode deck 1–4	NOTE (9F)	0x14 · 0x15 · 0x16 · 0x17	Elapsed 0x00 · Remaining 0x7F
Cue point deck 1–4	CC (BF)	0x1C/0x3C · 0x1D/0x3D · 0x1E/0x3E · 0x1F/0x3F	0–359° on the ring; hide = 0x7F/0x7F
Key	CC (Bn, deck ch)	0x49	0x00–0x18 (key index; table in source is an image — see §19)
Key change amount	CC (Bn)	0x4A	0x01–0x0C = −12…−1 · 0x0D = 0 · 0x0E–0x19 = +1…+12
Key display format	NOTE (9F)	0x5B	Classic 0x00 · Camelot 0x7F
Master tempo deck 1–4	NOTE (9F)	0x20 · 0x21 · 0x22 · 0x23	OFF 0x00 · ON 0x7F
MASTER (Beat Sync) deck 1–4	NOTE (9F)	0x18 · 0x19 · 0x1A · 0x1B	OFF/ON
SYNC (Beat Sync) deck 1–4	NOTE (9F)	0x1C · 0x1D · 0x1E · 0x1F	OFF/ON
Jog ring illumination deck 1–4	listed as NOTE, status BF	0x09 · 0x0A · 0x0B · 0x0C	OFF 0x00 · WHITE 0x01
Hide jog info display deck 1–4	NOTE (9F)	0x5D · 0x5E · 0x5F · 0x60	Show 0x00 · Hide 0x7F
Channel level meter	CC (Bn)	0x02	Level value (when channel input = PC-A/B)
Button / pad LEDs	NOTE (same ch & note as input)	see §14–15	0x7F on / 0x00 off; pads: colour 1–127

Source: MIDI list p.7.

17 · Signal flow

Reconstructed from the signal-flow diagram (manual p.174) — text form, not the original artwork.

```
CH1/2:  LINE | Timecode | USB-A stream | USB-B stream
          → Digital Trim → [BPM detect] → COLOR FX (NOISE) / BEAT FX pre-EQ
          → 3-band EQ → COLOR FX (FILTER/CRUSH/PITCH) / BEAT FX pre-fader
          → CH CUE tap → Channel fader → COLOR FX (DUB ECHO/SPACE) / BEAT FX post-fader
          → Crossfader assign (A/B/THRU) → Crossfader (curve)
CH3/4:  same, plus PHONO input → SUBSONIC FILTER before trim

MIC 1/2: MIC IN → Low-cut → 2-band MIC EQ → On/Off → Level → [level detect → Talkover control]
          → MIC REVERB / BEAT FX (mic) → added to Master (and Booth if MIC TO BOOTH)

MASTER bus: sum + MIC → Peak limiter → Mono/Stereo → Master ATT → MASTER OUT (1 & 2)
                                    → [BPM detect] → BEAT FX (MST)
BOOTH:  master → Mono/Stereo → Booth ATT → BOOTH OUT (mic optional, own limiter)
HEADPHONES: CH1–4 CUE + MASTER CUE → HP MIX → HP LEVEL → SPLIT CUE (Stereo/Mono split, Normal/Inverse) → PHONES

USB (each of USB A / USB B):
  to computer:  CH1–4 timecode · MASTER · REC OUT (with or without MIC) → USB Audio In 1–5
  from computer: Audio Out 1 = deck MASTER feed (PC-A/PC-B) · Out 2 = HEADPHONE cue
```

18 · Troubleshooting

Symptom	Fix
No power	Check power cord; press rear power switch.
Not recognised by computer	Correct USB cable/port; recommended hubs only; disconnect other USB devices; (re)install driver/Setting Utility; quit other apps/antivirus (go offline first); Windows: remove other ASIO drivers; check firmware version shows in Setting Utility.
No/quiet/distorted sound	Check input switches, rear LINE/PHONO, TRIM, faders, crossfader, MASTER LEVEL; reseat/clean cables; raise buffer size (Mac: in DJ app; Win: Setting Utility).
No mic	MIC switch position.
Can't cue sampler	SAMPLER VOL; Serato: Sample Player Output Select = A.
rekordbox unstable	Update; quit other apps, disable Wi-Fi/antivirus/screen saver/low-power; disconnect USB devices; laptop on AC.
rekordbox ignores unit / no platter	Switch from EXPORT to PERFORMANCE mode.
Wrong BPM / beatgrid	Change BPM analysis range and re-analyse, or set grid manually.
rekordbox dropouts	Preferences › Audio buffer size.
Fader Start not working	Set a cue; enable Fader Start in Prefs › Controller › Mixer.
Can't record in rekordbox	Without subscription, recording needs the unit (Hardware Unlock) connected.
DMX fixture dead	DMX only works with rekordbox Lighting; check fixture channel, cable, and FIXTURE LIBRARY mapping ([No Assign] = unsupported).
Serato unstable	Same as rekordbox list.
Serato: no tracks / iTunes missing	Import; pick a non-empty crate; toggle Show iTunes Library in Library + Display.
Serato: can't edit tags	Disable Protect Library.
Serato: offline player shown	Reconnect USB; update Serato.
Serato: no BPM / Sync / Auto Loop / Skip	Tick Set Beat Grid / BPM in Analysis Settings and re-analyse; set grid.
Indicator flashing, unit odd	Unplug power, wait, reconnect. If persistent, service.
Static / glitches	Power-cycle the unit.

Source: pp.165–173. Cleaning: dry soft cloth only — no solvents, acids or alkalis.

19 · Source notes & discrepancies

- **MASTER 2 wording.** Manual p.58 says "To connect to a balanced input (RCA, etc.), use the MASTER 2 terminals." Everywhere else (pp.65, 178) MASTER 2 is the *unbalanced* RCA output. Treat p.58 as a typo.
- **BEAT FX SELECT / CH SELECT values.** The official MIDI list gives Data 2 as "ON=0x8F, 0x9F, 0x10F … 0x27F" for successive positions. Those aren't valid MIDI data bytes (max 0x7F) — almost certainly a spreadsheet auto-fill error. The usable information is the Data 1 note per position (0x20–0x2D for FX type, 0x10–0x16 for channel); expect 0x7F for the selected position. Confirm with a MIDI monitor before relying on it.
- **Jog ring illumination** is listed with type NOTE but status BF (CC). Test both 0x9F and 0xBF if implementing.
- **BPM/Speed 14-bit** max is listed as MSB 0x4E, LSB 0x0F = 9999 in 7-bit-pair encoding, which is consistent with BPM ×10 (999.9).
- **Key value table (*3)** in the MIDI list is an image, not text; the 25 key codes (0x00–0x18) couldn't be extracted. Check page 7 of the original list.
- **Crossfader cut lag**: rekordbox expresses it in mm (0.3–5.5, default 1.0); Utilities mode uses steps 0–52 (default 7). Same feature, different units.
- **Tempo ranges differ by software**: rekordbox ±6/10/16/WIDE; Serato ±8/16/50.
- **Hot Cue count differs**: rekordbox 16 per track (2 pages), Serato 8.
- **Not included**: diagrams/photos and the illustrated controller figure from the originals; safety and licence boilerplate (pp.180–183) is summarised only.

Sources

- AlphaTheta, *DDJ-FLX10 Instruction Manual*, DRI1822-D — support.alphatheta.com/en-US/articles/16716272919193
- AlphaTheta, *DDJ-FLX10 List of MIDI Messages* E1 — support.alphatheta.com/en-US/articles/16716711647129