1Function berif

Suitable for blinds gereral 485 protocol (basic format refer to general principle)

2 suitable read write address instruction

data address	description	data format	can read write
0x00	ID_L	0x01~0xfe	write
0x01	ID_H	0x01~0xfe	
0x02	Current position (percentage)	0x00~0x64 (0xff no limit set)	only read
		Open(UP) to limit poistion 100%	
		Close(DOWN)to limit position 0%	
0x03	Motor default direction	0x00 default postion	read and write
		0x01 opposite position	
0x05	Motor status	0x00- stop	only write
		0x01- open	
		0x02- close	
		0x03- setting	
0x06	current angle	0-180	only read
0x07	angel adjustable direction	0x00- Default direction	read and write
		0x01- opposite direction	
0x08	angle factor	0-255	read and write
0x09	limit status	Bit1 have set limit1	only read
		Bit2 have set limit 2	
		Bit3 have set limit 3	
		Bit4 have set limit 4	
0x0A	jog mode	0 no jog	read and write
		1 jog mode (jog distance related to angel factor)	
0x0C	Power on reminder	0: no hint	read and write
		1: only sound	
		2:only jog	
		3:sound and jog	
0xe0-0xef	message	only for host read and write	read and write
0xF0	device type	0x11 blinds	only read
		0x22 ventian blinds	
0xf1	Channel number for module	1 to 15	only read
0xfd	software version	0-255	only read
0xfe	protocol version	0xA4	only read

3 suitable control command instruction

command	description	command	
0x01	open up command	No	
0x02	close down command	No	
0x03	stop command	No	
0x04	percentage, angle command	0 to 100(percentage, 0xff only for angle adjustment	blinds
		0 to 100 (percetage, 0xff only for angle adjustment, 0-180 (angle vaule)	Venetian blinds
0x05	set limit	1-4 set limit,1 (up limit),2 (down limit), 3 (third limit),4(fourth limit)	
0x06	running to limit	1-4 runing to limit,1 (up limit),2 (down limit), 3 (third limit),4(fourth limit)	
0x07	delete limit	no (delete all) 1-4 delete all limit 1 (up limit),2 (down limit), 3 (third limit),4(fourth limit)	
0x08	back to factory mode	no	
0x09	set scene mode	refer to general principle	
0xA	running scene mode	refer to general principle	
0xB	delete scene mode	refer to general principle	
0xf	catch opposite command	no, previous operation is open command, then close command, or running open command	

4 Other instructions

The first step of using the motor: set the limit

Send open (upward) command to observe whether the motor is running upward, if not, read the default direction of the motor, and then write the opposite

The motor goes up to a suitable position, send stop command, then send set limit command (set up limit); then send close (down) command, the motor will run up to a suitable position, send stop command, then send set limit command (set up limit).

Then send the close (down) command, the motor goes down to the appropriate position, send the stop command, and then send the set travel command (set the down limit), the limit setting is completed.

After that, send open (up) command, the motor moves up to the up limit and stops automatically, send close (down) command, the motor moves down to the down limit

Venetian is able to adjust the angle of the slat, the angle value is not valid for roller blinds.

Venetians have a variety of slat(such as aluminum blinds, wooden blinds, etc.), and a variety of brackets, etc., which may have an impact on the slat

These may have an impact on the blade angle adjustment, so before normal use of venetian, the angle of the blade needs to be corrected.

1. First set the limit correctly

2. first up or down to the slat completely turned over, and then sent to stop, and then send the percentage, angle command, set the angle to 90

Observe whether the slat is horizontal or not. If not, read the angle coefficient, increase or decrease the angle coefficient, and repeat the process

If not, read the angle coefficient, increase or decrease the angle coefficient, and repeat the process again until the blade is horizontal when the angle

3. Set 180 degrees, observe whether the slat is in the shape of /, 0 degrees is in\ . If not, read the direction of angle adjustment and write the

5.1 control command (0x03)

5.1.1 control command- open